

Dell™ OpenManage™
Server Administrator Version 6.1
Compatibility Guide

Notes and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

Information in this document is subject to change without notice.

© 2009 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, *PowerEdge*, *PowerVault*, and *OpenManage* are trademarks of Dell Inc.; *Microsoft*, *Windows*, *Windows NT*, *Windows Server*, *Vista*, and *MS-DOS* are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries; *Novell*, *NetWare*, *ConsoleOne*, and *SUSE* are registered trademarks of Novell Inc.; *Red Hat*, and *Red Hat Enterprise Linux* are registered trademarks of Red Hat, Inc, in the U. S. and other countries.; *Intel*, *Pentium*, and *EtherExpress* are trademarks of Intel Corporation in the U.S. and other countries.; *3COM* is a registered trademark of 3Com Corporation; *VMware* is a registered trademark of VMware Inc, in the United States and/or other jurisdictions.; *VESA* is a registered trademark of Video Electronics Standards Association; *OS/2* is a registered trademark of International Business Machines Corporation; *UNIX* is a registered trademark of The Open Group in the United States and other countries; *ACENic* is a trademark of Alteon WebSystems; *Broadcom* is a registered trademark and *NetXtreme* is a trademark of Broadcom Corporation; *RDRAM* is a registered trademark of Rambus Inc.; *Apple* and *Macintosh* are trademarks of Apple Inc., registered in the U.S. and other countries.

Server Administrator includes software developed by the Apache Software Foundation (www.apache.org). Server Administrator utilizes the OverLIB JavaScript library. This library can be obtained from www.bosrup.com.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

April 2009

Contents

1	Introduction	9
	Overview	9
	Where Can I Find The Server Administrator Application?	9
	Purpose of This Guide	10
	Update of Compatibility Guide	10
	Supported Instrumentation	10
	Supported Operating Systems	12
	Supported Browsers	13
	Supported GUI Languages	13
	Other Documents You Might Need	14
2	Server Administrator Services	17
	Overview	17
	Descriptions of Server Administrator Services	17
	Instrumentation Service	17
	Remote Access Service	17
	Storage Management Service	18
	Logs	18
	Available Services on Supported Operating Systems	18

3	Systems Management Standards Availability	21
	Overview	21
	Availability on Supported Systems	22
	Availability on Supported Operating Systems	22
4	Dell OpenManage Supported Applications and Systems	23
	Version Number Information	23
	Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage	24
	Device Drivers and Red Hat Enterprise Linux Kernel Support	72
5	Server Agent Supported Applications and Systems	73
6	Hardware Instrumentation Package Supported Applications and Systems	77

7	BIOS Update Requirements	79
	Overview	79
	Minimum Requirements for BIOS Update Support	79
	Downloading the Latest BIOS Packages	80
	Minimum Required and Latest Available BIOS for Update by System	80
8	RAID Controller Supported Servers, Operating Systems, Firmware, and Driver Versions	83
	Overview	83
	Key to Table Footnotes	84
	PERC 4/DC	85
	PERC 4e/DC	86
	PERC 3/DC	89
	PERC 3/QC	91
	PERC 4/Di	93
	CERC ATA 100 4/CH	95
	PERC 3/Di	96
	PERC 4/IM	100
	PERC 4/SC	103
	CERC SATA 1.5/6 Channel	104
	PERC 4e/Di	107

PERC 4e/Si	109
PERC 5/E Adapter	110
PERC 5/i Adapter	112
PERC 5/i Integrated	114
CERC 6/i Integrated	117
SAS 5/iR Adapter	118
SAS 5/iR Integrated	121
SAS 5/i Integrated	123
SAS 5/E Adapter	125
PERC 6/i Integrated and Adapter	127
PERC 6/E Adapter	128
SAS 6/iR Integrated and Adapter	130
LSI Logic 1020/1030 Ultra320 SCSI Adapter	132
CERC SATA 1.5/2S	134
LSI 1020/1030 Embedded SCSI Controller	136
LSI Logic 2032 Card	139

**9 Network Interface Controllers
and Supported Operating Systems 141**

Overview 141

NIC Drivers and Operating Systems 141

10 Remote Access Service	
Availability	145
Overview	145
RAC Types	145
Availability of RACs on Specific Dell Systems	146
RAC Firmware Versions	148
11 Historical Release Information for Legacy Systems	151
Overview	151
Server Agent 4.5	151
Requirements	151
New in Server Agent Version 4.5	152
Server Agent 4.4.1	152
Requirements	152
New in Server Agent Version 4.4.1	152
Server Agent 4.4.0	153
Requirements	153
New in Server Agent Version 4.4.0	153
Server Agent 4.3.0	153
Requirements	153
New in Server Agent Version 4.3.0	154
Server Agent 4.3.0 Resolved Issues	154
Server Agent 4.2.2	155
Requirements	155
New and Resolved Issues in Server Agent Version 4.2.2	155

Server Agent 4.2.1	155
Requirements	156
New in Server Agent Version 4.2.1	156
Resolved Issues for Server Agent Version 4.2.1	156
Server Agent 4.2.0	157
Requirements	157
Glossary	159

Introduction

Overview

Dell™ OpenManage™ Server Administrator provides a powerful, integrated set of systems management applications for keeping the systems on your network healthy. Server Administrator provides fault management information, prefailure information, and asset and inventory information to management applications. In addition to supporting systems management industry standards, Server Administrator also provides additional systems management information about the components of your specific system. Server Administrator can also configure BIOS and system settings. Server Administrator's integrated security draws on the system's operating system security. Server Administrator uses the secure socket layer (SSL) encryption protocol. For more information on SSL, see the Dell Support website at support.dell.com.

Where Can I Find The Server Administrator Application?

Depending on the version of Dell OpenManage you are using, the Server Administrator is available on different CDs and DVDs. See Table 1-1 for more information.

Table 1-1. Server Administrator and Corresponding Media

Dell OpenManage Version	Available on Media
5.4 and later	<i>Dell Systems Management Tools and Documentation DVD</i>
5.3–5.3.2	<i>Dell Systems Console and Agent CD or the Dell Systems Management Tools and Documentation DVD</i>
4.3–5.2.3	<i>Dell PowerEdge Installation and Server Management CD</i>
3.0–4.2	<i>Systems Management CD</i>
2.2 and earlier	<i>Applications CD</i>

Purpose of This Guide

Server Administrator operates on many Dell hardware platforms (hereafter called systems) with operating systems such as Microsoft® Windows®, SUSE® Linux Enterprise Server, and Red Hat Enterprise Linux. To use the systems management features of Server Administrator fully, you must understand which features of Server Administrator match your system's hardware configuration and operating system.

Update of Compatibility Guide

The Server Administrator Compatibility Guide is updated with each major OpenManage release. It summarizes all systems management releases that precede the current release date. Always see the *Dell Systems Software Support Matrix* available on the Dell Support website at support.dell.com for each release for the most current information on compatible systems management elements. See Table 1-1 for information on where you can find the systems management software.

Supported Instrumentation

Each supported systems management software contains instrumentation for your Dell system. The sections of this guide are organized around the primary instrumentation product names and show the relationship among the following variables:

- Systems management software
- Supported operating systems
- Instrumentation service
- Dell system (for example, M610)

In Table 1-2, the instrumentation product names are associated with a range of systems management software CD/DVD version.

Table 1-2. Systems Management Product Name and Corresponding Version Numbers

Instrumentation Product Names	Media Version	Section in This Guide
Dell OpenManage Server Administrator	<ul style="list-style-type: none"> • 5.4 through 6.1 (<i>Dell Systems Management Tools and Documentation DVD</i>) • 5.3 through 5.3.2 (<i>Dell Systems Console and Agent CD or Dell Systems Management Tools and Documentation DVD</i>) • 4.3 through 5.2 (<i>Installation and Server Management CD</i>) • 3.0 through 4.2 (<i>Systems Management CD</i>) 	<ul style="list-style-type: none"> • Dell OpenManage Supported Applications and Systems
Dell OpenManage Server Agent	2.0 through 2.2 (<i>Applications CD</i>)	Server Agent Supported Applications and Systems
Dell OpenManage Hardware Instrumentation Package (HIP)	1.2 through 1.7 (<i>Applications CD</i>)	Hardware Instrumentation Package Supported Applications and Systems

Supported Operating Systems

Server Administrator supports major operating systems offered by Microsoft, Novell®, and Red Hat. See the tables in "Dell OpenManage Supported Applications and Systems" to find the operating system that matches the configuration of your Dell system and applications that you are installing or upgrading.

 **NOTE:** Each systems management software CD supports specific operating system versions, service packs, support packs, and kernels.

 **NOTE:** For Dell OpenManage information specific to VMware®, see the latest Installation Guide, Release Notes, and the VMware Software Compatibility Matrix for Dell systems at www.dell.com/vmware, under the **Resource Archive** section.

For precise operating system, application, firmware, and other requirements, see the table that lists the systems management software CD version for the system that you are configuring. The tables in the following sections of this guide are a good place to begin:

- Dell OpenManage Supported Applications and Systems
- Server Agent Supported Applications and Systems
- Hardware Instrumentation Package Supported Applications and Systems

Operating system version numbers, support packs, service packs, and kernel versions can vary with each systems management software version and cannot be accurately generalized. For example, a particular systems management software version may support only a version of the Red Hat Enterprise Linux operating system with a specific kernel. Some systems management applications are available only on specific operating systems.

 **NOTE:** To address any Simple Network Management Protocol (SNMP) security vulnerabilities associated with an operating system, see the appropriate website for your system's operating system (for example, www.microsoft.com, www.redhat.com, or www.novell.com).

Supported Browsers

Server Administrator supports Microsoft Internet Explorer (IE) versions 6.0 SP2 7.0, and 8.0, and Mozilla Firefox™ version 2.0 and 3.0 open-source Web browsers.



NOTE: Windows 2000 supports only Internet Explorer version 6.0 SP1.



NOTE: Server Administrator versions 4.3 and later do not support Netscape Navigator.

Supported GUI Languages

Dell OpenManage is localized into French, German, Spanish, Japanese, and Simplified Chinese. Dell OpenManage software is localized according to the matrix in the following table. Dell OpenManage does not support languages outside of this table.

Table 1-3 plots the language of the Dell OpenManage GUI against the operating system languages.

Table 1-3. Supported Dell OpenManage GUI Languages

Dell OpenManage GUI Language	English Operating System	French Operating System	German Operating System	Spanish Operating System	Simplified Chinese Operating System	Japanese Operating System
English	X	X	X	X	X	X
French		X				
German			X			
Spanish				X		
Simplified Chinese					X	
Japanese						X

Other Documents You Might Need

In addition to this *Compatibility Guide*, you can find the following guides either on the Dell Support website at support.dell.com or on the *Dell Systems Tools and Documentation DVD*:

- *The Dell Unified Server Configurator User's Guide* provides information on updating the platform, configuring the hardware, deploying the operating system using Unified Server Configurator.
- *The Dell OpenManage Installation and Security User's Guide* provides complete information on installation procedures and step-by-step instructions for installing, upgrading, and uninstalling Server Administrator for each supported operating system.
- *The Dell OpenManage Software Quick Installation Guide* provides an overview of applications that you can install on your management station (console) and on your managed systems and procedures for installing your console and managed system applications on systems running supported operating systems.
- *The Dell Systems Software Support Matrix* allows you to identify operating systems and Dell OpenManage software that your Dell system supports.
- *The Dell OpenManage Server Administrator User's Guide* describes the installation and use of Server Administrator. Server Administrator is a suite of management agents, installed on the managed system, that provide fault management information, prefailure information, and asset inventory information to management console applications such as Server Administrator and IT Assistant. This guide also provides information about configuring your remote access controller (RAC).
- *The Dell OpenManage Server Administrator SNMP Reference Guide* documents the SNMP management information base (MIB). The SNMP MIB files define variables that extend the standard MIB to cover the capabilities of systems management agents.
- *The Dell OpenManage Server Administrator CIM Reference Guide* documents the Common Information Model (CIM) provider, an extension of the standard management object format (MOF) file. The CIM provider MOF documents supported classes of management objects.

- The *Dell OpenManage Server Administrator Messages Reference Guide* lists the messages that are displayed in your Server Administrator home page Alert log or on your operating system's event viewer. This guide explains the text, severity, and cause of each alert message that Server Administrator issues.
- The *Dell OpenManage Server Administrator Command Line Interface User's Guide* documents the complete command line interface (CLI) for Server Administrator, including an explanation of CLI commands to view system status, access logs, create reports, configure various component parameters, and set critical thresholds.
- The *Dell Remote Access Controller Installation and Setup Guide* provides complete information about installing and configuring a DRAC III, DRAC III/XT, and an ERA/O controller, configuring an ERA controller, and using a RAC to remotely access an inoperable system.
- The *Dell OpenManage Baseboard Management Controller Utilities User's Guide* provides information about installing and using the baseboard management controller.
- The *Dell Remote Access Controller 4 User's Guide* provides complete information about installing and configuring a DRAC 4 controller and using DRAC 4 to remotely access an inoperable system.
- The *Dell Remote Access Controller Modular Chassis User's Guide* provides complete information about configuring and using the DRAC/MC to remotely manage and monitor your modular system and its shared resources through a network.
- The *Dell Remote Access Controller 5 User's Guide* provides complete information about installing and configuring a DRAC 5 controller and using DRAC 5 to remotely access an inoperable system.
- The *Integrated Dell Remote Access Controller User's Guide* provides complete information about installing and configuring an iDRAC and using it to remotely access an inoperable system.
- The *Chassis Management Controller User's Guide* provides complete information about installing and configuring the CMC and using it to remotely access an inoperable system. The Dell Chassis Management Controller (CMC) is a hot-pluggable systems management hardware and software solution designed to provide remote management capabilities and power control functions for the Dell M1000e chassis systems.

- The *Dell OpenManage Remote Install User's Guide* provides information about unattended, simultaneous provisioning and configuration solutions of PowerEdge 1655MC only over the network by leveraging image-based technology.
- The *Dell Update Packages User's Guide* provides information about obtaining and using Dell Update Packages as part of your system update strategy.
- The *Server Update Utility User's Guide* provides information about obtaining and using the Server Update Utility (SUU) to update your Dell system or to view the updates available for any system listed in the Repository.

Server Administrator Services

Overview

Dell™ OpenManage™ Server Administrator has a modular architecture that allows you to select and install the functions most needed in your particular IT environment. The available services vary from one operating system to another. The following sections describe the contribution of each service to your systems management capabilities.

Descriptions of Server Administrator Services

Each service provides a functionally related set of systems management tasks that you can use to manage your system.

Instrumentation Service

The Instrumentation Service provides rapid access to detailed fault and performance information gathered by industry-standard systems management agents. The instrumentation service allows remote administration of monitored systems, including shutdown, start-up, and security.

Remote Access Service

The Remote Access Service provides a complete remote systems management solution for systems equipped with a remote access controller (RAC) solution. The Remote Access Service provides remote access to an inoperable system, allowing the system administrator to get the system up and running as quickly as possible. The Remote Access Service also provides alert notification when a system is down and allows the system administrator to restart a system remotely. Additionally, the Remote Access Service logs the probable cause of system crashes and saves the most recent crash screen.

Storage Management Service

Express Setup installs the Storage Management Service (earlier known as the enhanced Storage Management Service) by default on Microsoft® Windows®. On Red Hat® Enterprise Linux® and SUSE® Linux Enterprise Server systems, you can either install the Storage Management Service through the Red Hat Package Manager (RPM) or use the `srvadmin-install.sh` script — a menu driven script that installs the appropriate RPMs based on the options you choose.



NOTE: The Red Hat Enterprise Linux operating system provides drivers for some of the RAID controllers listed in the "RAID Controller Supported Servers, Operating Systems, Firmware, and Driver Versions" section.

See the *Dell OpenManage Server Administrator User's Guide* for more information on Storage Management Service.

Logs

Server Administrator displays logs of commands issued to or by the system, monitored hardware events, POST events, and system alerts. You can view logs on the home page, print or save them as reports, and send them by e-mail to a designated service contact.

Available Services on Supported Operating Systems

Table 2-1 summarizes the services that are available for each supported operating system.



NOTE: See the *Dell Systems Software Support Matrix* on the Dell Support website at support.dell.com, or the *Dell Systems Management Tools and Documentation* DVD to identify the operating systems that your Dell PowerEdge™ system supports.

Table 2-1. Server Administrator Services Available With Supported Operating Systems

Operating System	Services Available
<ul style="list-style-type: none"> • Microsoft Windows Server® 2008 Web, Standard, and Enterprise (32-bit x86) editions with SP2 	<ul style="list-style-type: none"> • Instrumentation • Storage Management
<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Core Standard and Enterprise (32-bit x86) editions with SP2 	<ul style="list-style-type: none"> • Remote Access
<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Standard, Enterprise, and Datacenter (x64) editions with SP2 	
<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Core Standard, Enterprise, and Datacenter (x64) editions with SP2 	

NOTE: For more information about when Microsoft Windows Server 2008 SP2 will be available, see www.microsoft.com.

- Microsoft Windows Server 2003 Web, Standard and Enterprise (32-bit x86) editions with SP2
- Microsoft Windows Server 2003 Standard, Enterprise, and Datacenter (x64) editions with SP2
- Microsoft Windows Server 2003 R2 Standard and Enterprise (32-bit x86) editions with SP2
- Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter (x64) editions with SP2
- Microsoft Windows® Essential Business Server 2008 Standard and Premium editions
- Microsoft Windows Small Business Server 2008 Standard and Premium editions

Table 2-1. Server Administrator Services Available With Supported Operating Systems (continued)

Operating System	Services Available
<ul style="list-style-type: none"> • Microsoft Windows Small Business Server 2003 Standard and Premium editions with SP2 • Windows Server 2008 Foundation • Microsoft Windows Storage Server 2008 Express, Workgroup, Standard, and Enterprise x64 editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 editions with SP2 • Microsoft Windows Server 2003 Compute Cluster Edition and Microsoft Windows Server 2008 HPC Edition • Microsoft Windows Unified Data Storage Server 2003 Standard and Enterprise x64 editions 	<ul style="list-style-type: none"> • Instrumentation • Storage Management • Remote Access
Red Hat Enterprise Linux WS, ES, and AS Version 4.7 (x86) and (x86_64)	<ul style="list-style-type: none"> • Instrumentation • Remote Access • Storage Management Service
Red Hat Enterprise Linux 5.3 server (x86) and (x86_64) Gold	<ul style="list-style-type: none"> • Instrumentation • Remote Access • Storage Management Service
SUSE Linux Enterprise Server 10 (SP2) (x86_64)	<ul style="list-style-type: none"> • Instrumentation • Remote Access • Storage Management Service
SUSE Linux Enterprise Server 11 (x86_64)	<ul style="list-style-type: none"> • Instrumentation • Remote Access • Storage Management Service
VMware® ESX/ESXi	<ul style="list-style-type: none"> • Instrumentation • Remote Access • Storage Management Service

Systems Management Standards Availability

Overview

Dell™ OpenManage™ Server Administrator supports the following major systems management protocols:

- HyperText Transfer Protocol Secure (HTTPS)
- Common Information Model (CIM)
- Simple Network Management Protocol (SNMP)



NOTE: See Table 1-1 for information on where you can find the Server Administrator application.



NOTE: See the Dell OpenManage Server Administrator **readme** file (packaged with the Server Administrator application) as well as the Dell Support website at **support.dell.com** for information on SNMP security concerns. You must apply updates from your operating system's master SNMP agents to ensure that Dell's SNMP subagents are secure.

If your system supports SNMP, you must install and enable the service on your operating system. If SNMP services are available on your operating system, the Server Administrator installation program installs the supporting agents for SNMP.



NOTE: After you install SNMP, it must be enabled. For more information on enabling SNMP-supported agents, see the *Server Administrator User's Guide*.

HTTPS is supported on all operating systems. Support for CIM and SNMP is operating system dependent and, in some cases, operating system-version dependent.

Availability on Supported Systems

On supported Microsoft® Windows® operating systems, Server Administrator supports two systems management standards: CIM/WMI and SNMP.

On supported Red Hat® Enterprise Linux® and SUSE® Linux Enterprise Server operating systems, Server Administrator supports the SNMP systems management standard.

Server Administrator adds considerable security to these systems management standards. All set operations for attributes (for example, changing the value of an asset tag) must be performed with Dell OpenManage IT Assistant while logged in with the required authority. As a result of the added security that IT Assistant offers for systems management, IT Assistant is the only management console that you can use to change attributes.

Availability on Supported Operating Systems

Table 3-1 shows the availability of the systems management standards for each supported operating system.

Table 3-1. Availability of Systems Management Standard by Operating System

Operating System	SNMP	CIM
Windows Server® 2008 family and Windows Server 2003 family	Available from the operating system installation media	Always installed
Red Hat Enterprise Linux AS, ES, and WS Version 4.7 (x86) and (x86_64)	Available in the net-snmp package from the operating system installation media	Unavailable
Red Hat Enterprise Linux 5.3 Server (x86) and (x86_64)	Available in the net-snmp package from the operating system installation media	Unavailable
SUSE Linux Enterprise Server version 10 SP2 and version 11	Available in the net-snmp package from the operating system installation media	Unavailable
VMware ESX/ESXi	Available snmp traps only on VMware ESX/ESXi version 4.0	Unavailable

Dell OpenManage Supported Applications and Systems

This section provides information on instrumentation, applications, and systems that are supported by the systems management software.

Version Number Information

All software supporting the Dell™ systems and Dell PowerVault™ appliances are delivered in Dell OpenManage™ *stack releases* that include the complete group of programs and that are fully tested for the supported platforms. An example is the Dell OpenManage 5.3.2 release of the Dell OpenManage software that supports most Dell systems from February 2002 through March 2008. The version of the software is significant. In this example, the first number (5) represents the major version number. You should upgrade your software any time Dell delivers a new major version. The second number (3) is the release number. A new release may have some minor features and fixes associated with it. You do not need to upgrade to the latest release unless that release is enabling your specific hardware or solving an issue you may be experiencing. You may skip releases as needed. The last number (2) is the hardware *platform refresh* number. This indicates that the software has been updated to support a new system. For example, if you have older systems running version 5.2.1, there is no need to upgrade to version 5.2.2 for a platform refresh.

Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage

Table 4-1 shows compatible applications and Dell systems.

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
Dell systems	800	R610*	600SC**
(* indicates new systems for the given version of the DVD)	830	R710*	650
	840	T610*	700
	850	M610*	750
	860	M710*	750N
	1800		755N
	1850		770N
	1855		775N
	1900		800
	1950		830
	1955		840
	2800		850
	2850		860
	2900		1600SC**
	2950		1650
	2970		1655MC
	6800		1750
	6850		1800
	6950		1850
	T100**		1855
	T105**		1900
	T300		1950
	R200		1955
	R300		2600
	M600		2650

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
	M605		2800
	T605		2850
	R900		2900
	M805		2950
	M905		2970
	R805		4600
	R905		6600
	R610		6650
	R710		6800
	T610		6850
	M610		6950
	M710		T300
	R410*		R200
	T410*		R300
	T710*		M600
	SC1435**		M605
	SC1430**		T605
	SC1425**		R900
	SC440**		M805*
	SC430**		M905*
	SC420**		T100**
	PowerVault 100		MD1120
	PowerVault 500		PowerVault 100
	PowerVault 600		PowerVault 500
	PowerVault NX1950		PowerVault 600
	PowerVault NX3000*		PowerVault
	PowerVault DL2000		NX1950
			PowerVault
			DL2000*

** indicates systems do not support installation of Dell OpenManage Server Administrator. However, you can use Dell Systems Build and Update Utility to install the operating system.

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
Supported operating systems	<ul style="list-style-type: none"> • Microsoft® Windows Server® 2008 Web, Standard, Enterprise, and Core Edition (x86) with SP2. • Microsoft Windows Server 2008 Standard, Enterprise, DataCenter, and Core Edition (x64) with SP2. <p>NOTE: For more information about when Microsoft Windows Server 2008 SP2 will be available, see www.microsoft.com.</p> <ul style="list-style-type: none"> • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2008 Foundation 	<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Web, Standard, Enterprise, and Core Edition (x86). • Microsoft Windows Server 2008 Standard, Enterprise, and Core Edition (x64). • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Web, Standard, Enterprise, and Core Edition (x86). • Microsoft Windows Server 2008 Standard, Enterprise, DataCenter, and Core Edition (x64). • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Essential Business Server 2008 Standard and Premium Editions • Microsoft Windows Small Business Server 2008 Standard and Premium Editions • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions 	<ul style="list-style-type: none"> • Microsoft Windows Essential Business Server 2008 Standard and Premium Editions • Microsoft Windows Small Business Server 2008 Standard and Premium Editions • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows XP Professional with SP2 • Red Hat® Enterprise Linux® WS, ES, and AS (Version 4.7) (x86) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Small Business Server 2008 Standard and Premium Editions

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
	<ul style="list-style-type: none"> • Microsoft Windows Storage Server 2008 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions with SP2 • Microsoft Windows Server 2003 Compute Cluster Edition • Microsoft Windows Server HPC 2008 • Microsoft Windows[®] XP Professional with SP3 • Microsoft Windows Unified Data Storage Server 2003 Standard and Enterprise x64 editions 	<ul style="list-style-type: none"> • Red Hat Enterprise Linux WS, ES, and AS (Version 4.7) (x86_64) • Red Hat Enterprise Linux 5.2 server (x86) • Red Hat Enterprise Linux 5.2 server (x86_64) • SUSE Linux Enterprise Server 10 SP2 (x86_64) • VMware[®] ESX Version 3.5 Update 4 • VMware ESXi Version 3.5 Update 4 • Microsoft Hyper-V and Hyper-V Server • Citrix XenServer 5.0 Hotfix 2 HDD 	<ul style="list-style-type: none"> • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions • Microsoft Windows XP Professional with SP2

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
	<ul style="list-style-type: none"> • Red Hat Enterprise Linux WS, ES, and AS (Version 4.7) (x86) • Red Hat Enterprise Linux WS, ES, and AS (Version 4.7) (x86_64) • Red Hat Enterprise Linux 5.3 server (x86) • Red Hat Enterprise Linux 5.3 server (x86_64) • SUSE Linux Enterprise Server 10 SP2 (x86_64) • SUSE Linux Enterprise Server 11 • VMware ESX Version 3.5 Update 4 • VMware ESX Version 4 • VMware ESXi Version 3.5 Update 4 		<ul style="list-style-type: none"> • Microsoft Windows Server 2003 Compute Cluster Edition • Microsoft Windows Server HPC 2008 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86) • Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86_64)

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
	<ul style="list-style-type: none"> • VMware® ESXi Version 4 <p>NOTE: For more information about when VMware® ESXi 4.0 will be available, see www.dell.com/vmware</p> <ul style="list-style-type: none"> • Microsoft Hyper-V and Hyper-V Server • Citrix XenServer 5.5 Flash and HDD Image 		<ul style="list-style-type: none"> • Red Hat Enterprise Linux 5.2 server (x86) • Red Hat Enterprise Linux 5.2 server (x86_64) • SUSE Linux Enterprise Server 9 SP4 (x86_64) • SUSE Linux Enterprise Server 10 SP2 (x86_64) • Citrix XenServer Dell Edition 5.0 Flash and HDD Image • VMware ESX Version 3.5 Update 2 • Microsoft Hyper-V and Hyper-V Server

NOTE: See the *Dell Systems Software Support Matrix* on the Dell Support website at support.dell.com for the latest information on supported operating systems.

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
Server Administrator	6.1	6.0.1	5.5
Server Administrator Framework	4.1	4.0	3.5
Instrumentation Service: Server Agent	6.1	6.0	5.9.5
Dell Online Diagnostics	2.14	2.13	2.12
IT Assistant	8.5	8.4	8.3
Storage Management Service	3.1	3.0.2	3.0
RAC Firmware			
CMC	2.0	1.0	1.0
iDRAC6	1.10	1.0	
iDRAC	1.2	1.0/2.0	1.2
DRAC 5	1.48		1.40
DRAC 4	1.75		1.61
DRAC/MC	1.50		1.50
DRAC III, DRAC III/XT, ERA, ERA/O, ERA/XT	3.38		3.38
ERA/MC	1.44		1.44

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage (continued)

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
BMC/iDRAC Firmware Version On Dell Systems			
800	1.30 or later		1.30 or later
830	1.44 or later		1.44 or later
840	1.67 or later		1.67 or later
850	1.44 or later		1.44 or later
860	1.67 or later		1.67 or later
1425SC	1.30 or later		1.30 or later
1800	1.23 or later		1.23 or later
1850	1.23 or later		1.23 or later
1855	1.01 or later		1.11 or later
1900	2.29		1.29 or later
1950	2.28		1.29 or later
1955	2.03		1.10 or later
2800	1.23 or later		1.23 or later
2850	1.23 or later		1.23 or later
2900	2.28		1.29 or later
2950	2.28		1.29 or later
2970	See the appropriate readme file for the latest information.		
6800	1.40 or later		1.64 or later
6850	1.40 or later		1.64 or later
6950	2.29		1.29 or later
T300	2.34		3.0 or later
R200	1.29 or later		3.0 or later

Table 4-1. Compatible Dell Systems and Applications for the Dell Systems Management Tools and Documentation DVD for Dell OpenManage *(continued)*

Dell Systems Management Tools and Documentation DVD	Supported System/Version Number for Dell OpenManage 6.1	Supported System/Version Number for Dell OpenManage 6.0.1	Supported System/Version Number for Dell OpenManage 5.5
R300	2.34		3.0 or later
T605	2.30		3.0 or later
R900	2.32		3.0 or later
M805	1.29 or later		3.0 or later
M905	1.29 or later		3.0 or later
PowerVault 100	1.29 or later		3.0 or later
PowerVault 500	1.29 or later		3.0 or later
PowerVault 600	1.29 or later		3.0 or later
PowerVault NX1950	1.29 or later		3.0 or later
PowerVault NX3000	1.10		3.0 or later
PowerVault DL2000	1.29 or later		3.0 or later
R610	1.10	1.0	
R710	1.10	1.0	
T610	1.10	1.0	
M610	2.0	1.0	
M710	2.0	1.0	
R410	1.10	1.0	
T410	1.10	1.0	
T710	1.10	1.0	

Table 4-2 shows compatible applications and Dell systems for the *Dell Systems Console and Agent CD* (version 5.3) or *Dell Systems Management Tools and Documentation DVD*.

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
Dell systems	600SC	600SC	600SC
(* indicates new systems for the given version of the CD)	650	650	650
	700	700	700
	750	750	750
	750N	750N	750N
	755N	755N	755N
	770N	770N	770N
	775N	775N	775N
	800	800	800
	830	830	830
	840	840	840
	850	850	850
	860	860	860
	1600SC	1600SC	1600SC
	1650	1650	1650
	1655MC	1655MC	1655MC
	1750	1750	1750
	1800	1800	1800
	1850	1850	1850
	1855	1855	1855
	1900	1900	1900
	1950	1950	1950
	1955	1955	1955
	2600	2600	2600
	2650	2650	2650

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
	2800	2800	2800
	2850	2850	2850
	2900	2900	2900
	2950	2950	2950
	2970	2970	2970
	4600	4600	4600
	6600	6600	6600
	6650	6650	6650
	6800	6800	6800
	6850	6850	6850
	6950	6950	6950
	T300*	R200	R200
	R200	M600	M600
	R300*	M605	M605
	M600	R900	R900
	M605	PowerVault 100	PowerVault 100
	T605	PowerVault 500	PowerVault 500
	R900	PowerVault 600	PowerVault 600
	MD1120*	PowerVault NX1950	PowerVault NX1950
	PowerVault 100		
	PowerVault 500		
	PowerVault 600		
	PowerVault		
	NX1950		

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
Supported operating systems	<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Web, Standard, Enterprise, and Core Edition (x86). • Microsoft Windows Server 2008 Standard, Enterprise, DataCenter, and Core Edition (x64). • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Web, Standard, Enterprise, and Core Edition (x86). • Microsoft Windows Server 2008 Standard, Enterprise, DataCenter, and Core Edition (x64). • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 	<ul style="list-style-type: none"> • Microsoft Windows Server 2008 Web, Standard, Enterprise, and Core Edition (x86). • Microsoft Windows Server 2008 Standard, Enterprise, DataCenter, and Core Edition (x64). • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows® Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
	<ul style="list-style-type: none"> • Microsoft Windows XP Professional with SP2 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86) • Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86_64) • Red Hat Enterprise Linux 5 server (x86) • Red Hat Enterprise Linux 5 server (x86_64) 	<ul style="list-style-type: none"> • Microsoft Windows XP Professional with SP2 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux 5 server (x86) • Red Hat Enterprise Linux 5 server (x86_64) • SUSE Linux Enterprise Server 9 SP3 (x86_64) • SUSE Linux Enterprise Server 10 (x86_64) 	<ul style="list-style-type: none"> • Microsoft Windows XP Professional with SP2 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux 5 server (x86) • Red Hat Enterprise Linux 5 server (x86_64) • SUSE Linux Enterprise Server 9 SP3 (x86_64) • SUSE Linux Enterprise Server 10 (x86_64)

NOTE: See the *Dell Systems Software Support Matrix* on the Dell Support website at support.dell.com for the latest information on supported operating systems.

Server Administrator	5.4	5.3	5.3.0.1
Server Administrator Framework	3.4	3.3	3.3

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
Instrumentation Service: Server Agent	5.4	5.8	5.8
Diagnostic Service	3.4	NA	NA
IT Assistant	5.8	8.1	8.1
Storage Management Service	NA	2.3	2.3
RAC Firmware			
CMC	2.4	1.0	1.0
iDRAC		1.0	1.0
DRAC 5	1.0	1.30	1.30
DRAC 4		1.60	1.60
DRAC/MC	1.0	1.4	1.4
DRAC III, ERA, ERA/O, ERA/XT	1.3.3	3.35	3.35
ERA/MC	1.6.1	1.44	1.44
BMC Firmware Version On Dell Systems			
R900	3.3.8	3.0 or later	3.0 or later
PowerVault 100	1.44	3.0 or later	3.0 or later
PowerVault 500		3.0 or later	3.0 or later
PowerVault 600	1.30 or later	3.0 or later	3.0 or later
PowerVault NX1950	1.41 or later	3.0 or later	3.0 or later
800	1.67 or later	1.30 or later	1.30 or later

Table 4-2. Compatible Dell Systems and Applications for Dell Systems Console and Agent CD Version 5.3 and 5.3.0.1 (continued)

Dell Systems Console and Agent CD Component	5.4	5.3	5.3.0.1
830	1.41 or later	1.41 or later	1.41 or later
840	1.67 or later	1.67 or later	1.67 or later
850	1.30 or later	1.41 or later	1.41 or later
860	1.23 or later	1.67 or later	1.67 or later
1425SC	1.23 or later	1.30 or later	1.30 or later
1800	1.11 or later	1.23 or later	1.23 or later
1850	1.27 or later	1.23 or later	1.23 or later
1855	1.27 or later	1.11 or later	1.11 or later
1900	1.10 or later	1.27 or later	1.27 or later
1950	1.23 or later	1.27 or later	1.27 or later
1955	1.23 or later	1.23 or later	1.23 or later
2800	1.27 or later	1.23 or later	1.23 or later
2850	1.27 or later	1.23 or later	1.23 or later
2900		1.27 or later	1.27 or later
2950	1.64 or later	1.27 or later	1.27 or later
2970	1.64 or later	See the appropriate readme file for the latest information.	
6800	1.26 or later	1.64 or later	1.64 or later
6850	3.0 or later	1.64 or later	1.64 or later
6950	3.0 or later	1.26 or later	1.26 or later

Table 4-3 shows compatible applications and Dell systems for the *Dell PowerEdge Installation and Server Management* CD (versions 5.2 and 5.2.1).

Table 4-3. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.2 and 5.2.1

Installation and Server Management CD Version	5.2	5.2.1
Dell PowerEdge systems	600SC	R200*
(* Indicates new systems for the given version of the CD)	650	
	700	
	750	
	750N	
	755N	
	770N	
	775N	
	800	
	830	
	840	
	850	
	860	
	1600SC	
	1650	
	1655MC	
	1750	
	1800	
	1850	
	1855	
	1900	
	1950	
	1955	
	2600	
	2650	
	2800	
	2850	
	2900	
	2950	
	2970*	
	4600	
	6600	
	6650	
	6800	
	6850	
	6950	

Table 4-3. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.2 and 5.2.1 (continued)

Installation and Server Management CD Version	5.2	5.2.1
Supported operating systems	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions • Microsoft Windows XP Professional with SP2 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux WS, ES, and AS (version 4) (x86) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 R2 Standard, Enterprise, and Datacenter x64 Editions with SP2 • Microsoft Windows Server 2003 R2 Standard and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Server 2003 Web and Enterprise Editions with SP2 (32-bit x86) • Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions • Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions • Microsoft Windows Unified Data Storage Server 2003 Gold Standard and Enterprise x64 Editions • Microsoft Windows XP Professional with SP2 • Microsoft Windows 2000 Server and Advanced Server with SP4 • Red Hat Enterprise Linux WS, ES, and AS (version 4) (x86)

Table 4-3. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.2 and 5.2.1 (continued)

Installation and Server Management CD Version	5.2	5.2.1
	<ul style="list-style-type: none"> • Red Hat Enterprise Linux WS, ES, and AS (version 4) (x86_64) • Red Hat Enterprise Linux 5 server (x86) • Red Hat Enterprise Linux 5 server (x86_64) • SUSE Linux Enterprise Server 9 SP3 (x86_64) • SUSE Linux Enterprise Server 10 Gold (x86_64) 	<ul style="list-style-type: none"> • Red Hat Enterprise Linux WS, ES, and AS (version 4) (x86_64) • Red Hat Enterprise Linux 5 server (x86) • Red Hat Enterprise Linux 5 server (x86_64) • SUSE Linux Enterprise Server 9 (x86_64) • SUSE Linux Enterprise Server 10 (x86_64)
Server Administrator	5.2	5.2.1
Server Administrator Framework	3.2	3.2
Instrumentation Service: Server Agent	5.7	5.7
Diagnostic Service	NA	NA
IT Assistant	8.0.1	8.0.1
Storage Management Service	2.2	2.2
RAC Firmware		
DRAC 5	1.20	1.20
DRAC 4	1.50	1.50
DRAC/MC	1.4	1.4
DRAC III, ERA, ERA/O, ERA/XT	3.35	3.35
ERA/MC	1.44	1.44

Table 4-3. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.2 and 5.2.1 (continued)

Installation and Server Management CD Version	5.2	5.2.1
BMC Firmware Version On Dell Systems		
800	1.30 or later	1.30 or later
830	1.41 or later	1.41 or later
840	1.67 or later	1.67 or later
850	1.41 or later	1.41 or later
860	1.67 or later	1.67 or later
1425SC	1.30 or later	1.30 or later
1800	1.23 or later	1.23 or later
1850	1.23 or later	1.23 or later
1855	1.11 or later	1.11 or later
1900	1.27 or later	1.27 or later
1950	1.27 or later	1.27 or later
1955	1.23 or later	1.23 or later
2800	1.23 or later	1.23 or later
2850	1.23 or later	1.23 or later
2900	1.27 or later	1.27 or later
2950	1.27 or later	1.27 or later
2970	See the appropriate readme file for the latest information.	
6800	1.64 or later	1.64 or later
6850	1.64 or later	1.64 or later
6950	1.26 or later	1.26 or later
R200	NA	2.1 or later

Table 4-4 shows compatible applications and Dell systems for the *Dell PowerEdge Installation and Server Management CD* (versions 5.0 to 5.1.1).

Table 4-4. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.0 to 5.1.1

Installation and Server Management CD Version	5.0	5.1	5.1.1
Dell PowerEdge systems (* Indicates new systems for the given version of the CD)	600SC 650 700 750 750N 755N 770N 775N 800 830 850 1600SC 1650 1655MC 1750 1800 1850 1855 1950* 1955* 2600 2650 2800 2850 2900* 2950* 4600 6600 6650 6800 6850	600SC 650 700 750 750N 755N 770N 775N 800 830 840* 850 860* 1600SC 1650 1655MC 1750 1850 1855 1900 1950 1955 2600 2800 2850 2900 2950 4600 6600 6650 6800 6850	6950*

Table 4-4. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.0 to 5.1.1 (continued)

Installation and Server Management CD Version	5.0	5.1	5.1.1
Supported operating systems	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, Enterprise, and x64 Editions) (SP1) • Microsoft Windows Small Business Server 2003 (SP1) • Microsoft Windows Server 2003 R2 • Microsoft Windows Storage Server 2003 R2 (includes Express, Standard, Workgroup, and Enterprise editions) • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server and Microsoft Windows Small Business Server 2000) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, Enterprise, and x64 Editions) (SP1) • Microsoft Windows Small Business Server 2003 (SP1) • Microsoft Windows Server 2003 R2 • Microsoft Windows Storage Server 2003 R2 (includes Express, Standard, Workgroup, and Enterprise editions) • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server and Microsoft Windows Small Business Server 2000) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (Standard and Enterprise Editions [R2]) (32- and 64 bit)

Table 4-4. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.0 to 5.1.1 (continued)

Installation and Server Management CD Version	5.0	5.1	5.1.1
	<ul style="list-style-type: none"> Red Hat Enterprise Linux AS, ES, and WS version 3 (Update 6) (x86 and x86_64) Red Hat Enterprise Linux version 4 (x86 and x86_64) SUSE Linux Enterprise Server version 9 (SP3) (x86_64) 	<ul style="list-style-type: none"> Red Hat Enterprise Linux AS, ES, and WS version 3 (Update 6) (x86 and x86_64) Red Hat Enterprise Linux version 4 (x86 and x86_64) SUSE Linux Enterprise Server version 9 (SP3) and 10 (Gold) (x86_64) 	<ul style="list-style-type: none"> Red Hat Enterprise Linux AS version 4 (Gold) (x86 and x86_64) SUSE Linux Enterprise Server version 10 (Gold) (x86_64)
		<p>NOTE: SUSE Linux Enterprise Server version 10 does not support the DRAC 4 and DRAC 5 client GUI.</p>	
Server Administrator	5.0	5.1	5.1.1
Server Administrator Framework	3.0	3.1	3.1.1
Instrumentation Service: Server Agent	5.6	5.6	5.6
Diagnostic Service	3.6	NA	NA
IT Assistant	7.2	8.0	8.0
Storage Management Service	2.0	2.1	2.1

Table 4-4. Compatible Dell Systems and Applications for Installation and Server Management CD Version 5.0 to 5.1.1 (continued)

Installation and Server Management CD Version	5.0	5.1	5.1.1
RAC Firmware			
DRAC 5	1.0	1.0	1.0
DRAC 4	1.35	1.35	NA
DRAC/MC	1.3	1.3	NA
DRAC III, ERA, ERA/O, ERA/XT	3.3.5	3.3.5	NA
ERA/MC	1.4.4	1.4.4	NA
BMC Firmware Version On			
800	1.30 or later	1.30 or later	NA
830	1.41 or later	1.41 or later	NA
840	1.0 or later	1.0 or later	NA
850	1.41 or later	1.41 or later	NA
860	1.0 or later	1.0 or later	NA
1425SC	1.30 or later	1.30 or later	NA
1800	1.23 or later	1.23 or later	NA
1850	1.23 or later	1.23 or later	NA
1855	1.0 or later	1.0 or later	NA
1950	1.0 or later	1.0 or later	NA
1955	1.0 or later	1.0 or later	NA
2800	1.23 or later	1.23 or later	NA
2850	1.23 or later	1.23 or later	NA
2900	1.0 or later	1.0 or later	NA
2950	1.0 or later	1.0 or later	NA
6800	1.40 or later	1.40 or later	NA
6850	1.40 or later	1.40 or later	NA
6950	NA	NA	1.0 or later

Table 4-5 shows compatible applications and Dell systems for the *Dell PowerEdge Installation and Server Management* CD (versions 4.3 to 4.5.1).

Table 4-5. Compatible Dell Systems and Applications for Installation and Server Management CD Version 4.3 to 4.5.1

Installation and Server Management CD Version	4.3	4.4	4.5	4.5.1^a
Dell	350	350	350	1850
PowerEdge systems	500SC 600SC	500SC 600SC	500SC 600SC	2850 6800
(* indicates new systems for the given version of the CD)	650 700 750 800 1400 1500SC 1550 1600SC 1650 1655MC 1750 1800 1850 1855 2400 2450 2500 2550 2600 2650 2800 2850 4400	650 700 750 800 1400 1500SC 1550 1600SC 1650 1655MC 1750 1800 1850 1855 2400 2450 2500 2550 2600 2650 2800 2850 4400	650 700 750 800 830* 850* 1400 1500SC 1550 1600SC 1650 1655MC 1650 1655MC 1750 1800 1850 1855 2400 2450 2500 2550 2500 2550 2600 2650 2600 2650 2600 2650 2800 2850 2800	6850

Table 4-5. Compatible Dell Systems and Applications for Installation and Server Management CD Version 4.3 to 4.5.1 (continued)

Installation and Server Management CD Version	4.3	4.4	4.5	4.5.1 ^a
	4600	4600	2850	
	6400	6400	4400	
	6450	6450	4600	
	6600	6600	6400	
	6650	6650	6450	
	6800* ^a	6800	6600	
	6850* ^a	6850	6650	
	8450	8450	6800	
	750N	750N	6850	
	755N	755N	8450	
	770N	770N	750N	
	775N	775N	755N	
			770N	
			775N	
Supported operating systems	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, and Enterprise editions) • Microsoft Windows Small Business Server [SBS] 2003 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, Enterprise, and x64 Editions) (SP1) • Microsoft Windows Small Business Server 2003 (SP1) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, Enterprise, and x64 Editions) (SP1) • Microsoft Windows Small Business Server 2003 (SP1) 	<ul style="list-style-type: none"> • Microsoft Windows Server 2003 family (includes Web, Standard, Enterprise, and x64 Editions) (SP1) • Microsoft Windows Small Business Server 2003 (SP1)

Table 4-5. Compatible Dell Systems and Applications for Installation and Server Management CD Version 4.3 to 4.5.1 (continued)

Installation and Server Management CD Version	4.3	4.4	4.5	4.5.1^a
<ul style="list-style-type: none"> • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows Small Business Server 2000) • Novell® NetWare® 5.1 (Support Pack 7 or later, plus hot fixes) • Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes) • Red Hat Enterprise Linux AS and ES (version 2.1) 	<ul style="list-style-type: none"> • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Microsoft Windows Small Business Server 2000) • Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes) • Red Hat Enterprise Linux AS, ES, and WS version 3 (x86 and x86_64) 	<ul style="list-style-type: none"> • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Microsoft Windows Small Business Server 2000) • Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes) • Red Hat Enterprise Linux AS, ES, and WS version 3 (x86 and x86_64) 	<ul style="list-style-type: none"> • Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Microsoft Windows Small Business Server 2000) • NA • Red Hat Enterprise Linux AS, ES, and WS version 3 (x86 and x86_64) 	

Table 4-5. Compatible Dell Systems and Applications for Installation and Server Management CD Version 4.3 to 4.5.1 (continued)

Installation and Server Management CD Version	4.3	4.4	4.5	4.5.1^a
	<ul style="list-style-type: none"> Red Hat Enterprise Linux AS, ES, and WS version 3 	<ul style="list-style-type: none"> Red Hat Enterprise Linux version 4 (x86 and x86_64) 	<ul style="list-style-type: none"> Red Hat Enterprise Linux version 4 (x86 and x86_64) 	<ul style="list-style-type: none"> Red Hat Enterprise Linux version 4 (x86 and x86_64)
Server Administrator	2.0	2.1	2.2	2.3
ManagedNode Framework (MNF)	2.0	2.1	2.2	2.3
Instrumentation Service: Server Agent	5.3	5.3	5.3	5.5.1
Diagnostic Service	3.2	3.3	3.4	3.4.1
Server Administrator Core	2.0	2.1	2.2	2.2
IT Assistant	7.0	7.0	7.1	7.1
Storage Management Service: Array Manager	3.7	3.7	3.7	3.7
Enhanced Storage Management Service	1.1	1.2	1.2	1.4

Table 4-5. Compatible Dell Systems and Applications for Installation and Server Management CD Version 4.3 to 4.5.1 (continued)

Installation and Server Management CD Version	4.3	4.4	4.5	4.5.1^a
RAC Firmware				
DRAC 4	1.20	1.30	1.30	1.30
DRAC/MC	1.1	1.2	1.2	NA
DRACIII, ERA, ERA/O, and ERA/XT	3.21	3.3	3.3	NA
RAC firmware: DRAC II	NOTE: The DRAC II software is no longer included on the <i>Dell Systems Management Consoles</i> CD, but can be obtained from earlier releases or support.dell.com			
ERA/MC	1.44	NA	NA	NA
BMC Firmware Version On Dell Systems				
800	1.30 or later	1.30 or later	1.30 or later	NA
830	NA	NA	1.41 or later	NA
850	NA	NA	1.41 or later	NA
1425SC	1.30 or later	1.30 or later	1.30 or later	NA
1800	1.23 or later	1.23 or later	1.23 or later	NA
1850	1.23 or later	1.23 or later	1.23 or later	1.23 or later
1855	1.0 or later	1.0 or later	1.0 or later	NA
2800	1.23 or later	1.23 or later	1.23 or later	NA
2850	1.23 or later	1.23 or later	1.23 or later	1.23 or later
6800	1.33 or later	1.33 or later	1.33 or later	1.40 or later
6850	1.33 or later	1.33 or later	1.33 or later	1.40 or later

a. Introduced SAS support for these Dell systems: 6800 and 6850.

Table 4-6 shows compatible applications and Dell systems for *Systems Management* CD version 4.1.3 to 4.2.

Table 4-6. Compatible Dell Systems and Applications for Systems Management CD Versions 4.1.3 to 4.2

Systems Management CD Version	4.1.3	4.1.4	4.2
Dell PowerEdge systems (* indicates new systems for the given version of the CD)	1855*	1855	350 500SC 600SC 650 700 750 800 1400 1500SC 1550 1600SC 1650 1655MC 1750 1800 1850 1855 2400 2450 2500 2550 2600 2650 2800 2850 4400 4600 6400 6450 6600 6650 8450 750N 755N 770N 775N

Table 4-6. Compatible Dell Systems and Applications for Systems Management CD Versions 4.1.3 to 4.2 (continued)

Systems Management CD Version	4.1.3	4.1.4	4.2
Supported operating systems	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003 (supported by PowerEdge 2800 only)	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003 (supported by PowerEdge 2800 only)	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003
	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows 2000 SBS)
	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes) NOTE: Novell NetWare is not supported on the PowerEdge 650 system.
	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes)	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes)	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes) NOTE: Novell NetWare is not supported on the PowerEdge 650 system.
	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3

Table 4-6. Compatible Dell Systems and Applications for Systems Management CD Versions 4.1.3 to 4.2 (continued)

Systems Management CD Version	4.1.3	4.1.4	4.2
Server Administrator	1.9.1	1.9.1	1.9.2
ManagedNode Framework (MNF)	1.9	1.9	1.9
Instrumentation Service: Server Agent	5.2	5.2	5.2
Diagnostic Service	3.1.1	3.1.1	3.1
Update Service	1.9.2	NA	1.9.1
Server Administrator Core	See "MNF" in this table.	See "MNF" in this table.	See "MNF" in this table.
IT Assistant	6.5.3	6.5.3	6.5.3
Storage Management Service: Array Manager	NA	NA	3.6
enhanced Storage Management Service	1.0	1.0.1	1.0
RAC Firmware			
DRAC 4	1.0	1.1	1.1
DRAC/MC	1.0	NA	NA
DRACIII, ERA, ERA/O, and ERA/XT	NA	NA	3.21

Table 4-6. Compatible Dell Systems and Applications for Systems Management CD Versions 4.1.3 to 4.2 (continued)

Systems Management CD Version	4.1.3	4.1.4	4.2
RAC firmware: DRAC II	NA		NA NOTE: The DRAC II software is no longer included on the <i>Systems Management CD</i> , but can be obtained from earlier releases or support.dell.com .
ERA/MC	NA	NA	1.44
BMC Firmware Version	1.0	1.0.1	1.0.1

Table 4-7 shows compatible applications and Dell systems for *Systems Management* CD version 4.0.1 to 4.1.2.

Table 4-7. Compatible Dell Systems and Applications for Systems Management CD Versions 4.0.1 to 4.1.2

Systems Management CD Version	4.0.1	4.1	4.1.1	4.1.2
Dell	1850*	350	1800*	800*
PowerEdge systems	2800* 2850*	500SC 600SC		
(* indicates new systems for the given version of the CD)		650 700 750 1400 1500SC 1550 1600SC 1650 1655MC 1750 1850 2400 2450 2500 2550 2600 2650 2800 2850 4400 4600 6400 6450 6600 6650 8450 750N 755N 770N 775N		

Table 4-7. Compatible Dell Systems and Applications for Systems Management CD Versions 4.0.1 to 4.1.2 (continued)

Systems Management CD Version	4.0.1	4.1	4.1.1	4.1.2
Supported operating systems	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003 (supported by PowerEdge 2800 only)	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003
	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows 2000 SBS)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows 2000 SBS)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows 2000 SBS)
	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)	Novell NetWare 5.1 (Support Pack 7 or later, plus hot fixes)
	<p>NOTE: Novell NetWare is not supported on the PowerEdge 650 system.</p>			

Table 4-7. Compatible Dell Systems and Applications for Systems Management CD Versions 4.0.1 to 4.1.2 (continued)

Systems Management CD Version	4.0.1	4.1	4.1.1	4.1.2
	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes)	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes) NOTE: Novell NetWare is not supported on the PowerEdge 650 system.	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes)	Novell NetWare 6.5 (Support Pack 1 or later, plus hot fixes)
	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3	Red Hat Enterprise Linux AS and ES version 2.1 and AS, ES, and WS version 3
Server Administrator	1.8.1	1.9	1.9	1.9
ManagedNode Framework (MNF)	1.8.1	1.9	1.9	1.9
Instrumentation Service: Server Agent	5.1.1	5.2	5.2	5.2
Remote Access Service SW	4.0.0	3.30 (DRAC III) 4.0.0 (DRAC 4)	NA	NA
BMC Firmware Version	1.0	1.0.1	1.0.1	1.0.1
Diagnostic Service	3.0.1	3.1	3.1	3.1
Update Service	1.9	1.9.1	1.9.1	1.9.1
Server Administrator Core	See "MNF" in this table.	See "MNF" in this table.	See "MNF" in this table.	See "MNF" in this table.

Table 4-7. Compatible Dell Systems and Applications for Systems Management CD Versions 4.0.1 to 4.1.2 (continued)

Systems Management CD Version	4.0.1	4.1	4.1.1	4.1.2
IT Assistant	6.5.2	6.5.3	6.5.3	6.5.3
Storage Management Service: Array Manager	3.5	3.6	3.6	3.6
enhanced Storage Management Service	NA	1.0	1.0	1.0
RAC Firmware				
DRAC 4	1.0	1.0	NA	NA
RAC firmware: DRAC II	NA	NA	NA	NA
		NOTE: The DRAC II software is no longer included on the <i>Systems Management CD</i> , but can be obtained from earlier releases or support.dell.com		
RAC firmware: DRAC III	NA	3.12	NA	NA
RAC firmware: DRAC III/XT	NA	3.12	NA	NA
RAC firmware: ERA	NA	3.12	NA	NA
RAC firmware: ERA/O	NA	3.12	NA	NA

Table 4-8 shows compatible applications and Dell systems for *Systems Management* CD version 3.5 to 3.8.

Table 4-8. Compatible Dell Systems and Applications for Systems Management CD Versions 3.5 Through 3.8

Systems Management CD Version	3.5	3.6	3.7	3.8
Dell	350	350	350	350
PowerEdge	500SC	500SC	500SC	500SC
systems	600SC	600SC	600SC	600SC
(* indicates	650	650	650	650
new systems	1400	1400	1400	700*
for the given	1500SC	1500SC	1500SC	750*
version of	1550	1550	1550	1400
the CD)	1600SC	1600SC	1600SC	1500SC
	1650	1650	1650	1550
	1655MC	1655MC	1655MC	1600SC
	1750	1750	1750	1650
	2400	2400	2400	1655MC
	2450	2450	2450	1750
	2500	2500	2500	2400
	2550	2550	2550	2450
	2600	2600	2600	2500
	2650	2650	2650	2550
	4400	4400	4400	2600
	4600	4600	4600	2650
	6400	6400	6400	4400
	6450	6450	6450	4600
	6600	6600	6600	6400
	6650	6650	6650	6450
	8450	8450	8450	6600
				6650
				8450

Table 4-8. Compatible Dell Systems and Applications for Systems Management CD Versions 3.5 Through 3.8 (continued)

Systems Management CD Version	3.5	3.6	3.7	3.8
Supported operating systems	Microsoft Windows Server 2003	Windows Server 2003 family	Windows Server 2003 family	Windows Server 2003 family (includes Web, Standard, and Enterprise editions) and Microsoft Windows Small Business Server [SBS] 2003
	Windows 2000 Server family (SP3 recommended)	Windows 2000 Server family (SP3 recommended)	Windows 2000 Server family (SP3 recommended)	Windows 2000 Server family (includes Windows 2000 Server, Windows 2000 Advanced Server, and Windows 2000 SBS)
	Novell NetWare 5.1 (SP4 or later)	Novell NetWare 5.1 (SP5 or later)	Novell NetWare 5.1 (Support Pack 6 or later)	Novell NetWare 5.1 (Support Pack 6 or later)
	NetWare 6.0 (SP1 or later)	NetWare 6.5	Novell NetWare 6.5 (Support Pack 1 or later)	Novell NetWare 6.5 (Support Pack 1 or later)
	Red Hat Linux Advanced Server 2.1	Red Hat Enterprise Linux AS version 2.1	Red Hat Enterprise Linux AS and ES versions 2.1 and 3, and WS version 3	Red Hat Enterprise Linux AS version 2.1 and AS, ES, and WS version 3
	Red Hat Linux 9	Red Hat Linux 9	Red Hat Linux 9	NA

Table 4-8. Compatible Dell Systems and Applications for Systems Management CD Versions 3.5 Through 3.8 (continued)

Systems Management CD Version	3.5	3.6	3.7	3.8
Server Administrator	1.5	1.6	1.7	1.8
Managed Node Framework (MNF)	1.5	1.6	1.7	1.8
Instrumentation Service: Server Agent	4.10.0	4.11	4.12	5.1
Diagnostic Service	2.5	2.6	2.7	3.0
Update Service	1.6	1.7	1.8	1.9
Server Administrator Core	See "MNF" in this table.			
IT Assistant	6.4.4	6.5	6.5	6.5
Storage Management Service: Array Manager	3.4	3.5	3.5	3.5

Table 4-8. Compatible Dell Systems and Applications for Systems Management CD Versions 3.5 Through 3.8 (continued)

Systems Management CD Version	3.5	3.6	3.7	3.8
RAC Firmware				
Remote Access Service (RAS)	2.5	3.0	3.10	3.20
RAC firmware: DRAC II	2.5	2.5	2.5	2.5
RAC firmware: DRAC III	2.5	3.0	3.10	3.10
RAC firmware: DRAC III/XT	2.5	3.0	3.10	3.10
RAC firmware: ERA	2.5	3.0	3.10	3.10
RAC firmware: ERA/O	2.5	3.0	3.10	3.10

Table 4-9 shows compatible applications and Dell systems for *Systems Management CD* versions 3.2.3 through 3.4.

Table 4-9. Compatible Dell Systems and Applications for Systems Management CD Versions 3.2.3 Through 3.4

Systems Management CD Version	3.2.3	3.3	3.3.3	3.4
Dell PowerEdge systems	300 350	300 350	300 350	300 350
(* Indicates new systems for the given version of the CD)	500SC 600SC 1300 1400 1500SC 1550 1600SC 1650 1655MC* 2300 2400 2450 2500 2550 2600 2650 4300 4350 4400 4600 6300 6350 6400 6450 6600 6650 8450	500SC 600SC 1300 1400 1500SC 1550 1600SC 1650 2300 2400 2450 2550 2600 2650 4300 4350 4400 4600 6300 6350 6400 6450 6600 6650 8450	500SC 600SC 650* 1300 1400 1500SC 1550 1600SC 1650 1655MC 1750* 2300 2400 2450 2500 2550 2600 2650 4300 4350 4400 4600 6300 6350 6400 6450 6600 6650 8450	500SC 600SC 650 1300 1400 1500SC 1550 1600SC 1650 1655MC 1750 2300 2400 2450 2500 2550 2600 2650 4300 4350 4400 4600 6300 6350 6400 6450 6600 6650 8450

Table 4-9. Compatible Dell Systems and Applications for Systems Management CD Versions 3.2.3 Through 3.4 (continued)

Systems Management CD Version	3.2.3	3.3	3.3.3	3.4	
Supported operating systems	Microsoft Windows 2000 Server Family (SP3 recommended)	Microsoft Windows NT® 4.0 Server family (SP6a or later)	Windows NT 4.0 Server family (SP6a or later)	Windows Server 2003	
	NetWare 5.1 (SP2 or later)	Windows 2000 Server family (SP3 recommended)	Windows 2000 Server family (SP3 recommended)	Windows 2000 Server family (SP3 recommended)	
	NetWare 6.0 (SP1 or later)	NetWare 5.1 (SP2 or later)	NetWare 5.1 (SP2 or later)	NetWare 5.1 (SP2 or later)	
	Red Hat Enterprise Linux Advanced Server 2.1	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)	
	Red Hat Linux 7.3 (with the 2.4.18-4smp kernel)	Linux Advanced Server 2.1	Linux Advanced Server 2.1	Linux Advanced Server 2.1	Linux Advanced Server 2.1
			Linux 7.3 (with the 2.4.18-4smp kernel)	Linux 7.3 (with the 2.4.18-4smp kernel)	Linux 8.0 and Linux 9
		Linux 8.0 (with the 2.4.18-14smp kernel)	Linux 8.0 (with the 2.4.18-14smp kernel)		
Server Administrator	1.2.3	1.3	1.3.4	1.4	
Managed Node Framework (MNF)	1.2.3	1.3	1.3	1.4	

Table 4-9. Compatible Dell Systems and Applications for Systems Management CD Versions 3.2.3 Through 3.4 (continued)

Systems Management CD Version	3.2.3	3.3	3.3.3	3.4
Instrumentation Service: Server Agent	4.7.2	4.8	4.8.1	4.9
Remote Access Service (RAS)	1.3.1	2.0	2.1	2.2
RAC firmware: DRAC II	2.5	2.5	2.5	2.5
RAC firmware: DRAC III	1.3	2.0	2.0	2.2
RAC firmware: DRAC III/XT	NA	2.0	2.0	2.2
RAC firmware: ERA	1.2	2.0	2.1	2.2
RAC firmware: ERA/O	1.2	2.0	2.0	2.2
Diagnostic Service	2.2.1	2.3	2.3.1	2.4
Update Service	1.3	1.4	1.4.3	1.5
Server Administrator Core	See "MNF" in this table.			
IT Assistant	6.4.2	6.4.3	6.4.3	6.4.4
Storage Management Service: Array Manager	3.3	3.3	3.4	3.4

Table 4-10 shows supported elements for *Systems Management CD* versions 3.0 through 3.2.2.

Table 4-10. Compatible Dell Systems and Applications for Systems Management CD Versions 3.0 Through 3.2.2

Systems Management CD Version	3.0	3.0.1	3.0.2	3.1	3.2	3.2.2
Dell PowerEdge systems	300 350	300 350	300 350	300 350	300 350	300 350
(* Indicates new systems for the given version of the CD)	500SC 1300 1400 1500SC 1550 2300 2400 2450 2500 2550 4300 4350 4400 6300 6350 6400 6450 8450	500SC 1300 1400 1500SC 1550 1650* 2300 2400 2450 2500 2550 4300 4350 4400 4600* 6300 6350 6400 6450 8450	500SC 1300 1400 1500SC 1550 1650 2300 2400 2450 2500 2550 2650* 4300 4350 4400 4600 6300 6350 6400 6450 8450	500SC 1300 1400 1500SC 1550 1650 2300 2400 2450 2500 2550 2650 4300 4350 4400 4600 6300 6350 6400 6450 8450	500SC 600SC* 1300 1400 1500SC 1550 1650 2300 2400 2450 2500 2550 2600* 2650 4300 4350 4400 4600 6300 6350 6400 6450 6650 8450	500SC 600SC 1300 1400 1500SC 1550 1600SC* 1650 2300 2400 2450 2500 2550 2550 2650 2650 2650 2650 4300 4300 4350 4350 4600 4600 6300 6300 6400 6400 6450 6600 6650 6650 8450

Table 4-10. Compatible Dell Systems and Applications for Systems Management CD Versions 3.0 Through 3.2.2 (continued)

Systems Management CD Version	3.0	3.0.1	3.0.2	3.1	3.2	3.2.2
Supported operating systems	Windows NT 4.0 with SP4	Windows NT 4.0 Server family (SP6a or later)	Windows NT 4.0 Server family (SP6a or later)	Windows NT 4.0 Server family (SP6a or later)	Windows NT 4.0 Server family (SP6a or later)	Windows NT 4.0 Server family (SP6a or later)
	Windows 2000 Server family	Windows 2000 Server family (hot fixes rec. for SNMP)	Windows 2000 Server family (hot fixes rec. for SNMP)	Windows 2000 Server family (hot fixes rec. for SNMP)	Windows 2000 Server family (SP3 rec.)	Windows 2000 Server family (SP3 rec.)
	Novell NetWare 4.x, 5.x, or 6.x	Novell NetWare 5.1 (SP2 or later)	Novell NetWare 5.1 (SP2 or later)	Novell NetWare 5.1 (SP2 or later)	Novell NetWare 5.1 (SP2 or later)	Novell NetWare 5.1 (SP2 or later)
	Linux 7.1	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)	NetWare 6.0 (SP1 or later)
	Linux Advanced Server 2.1	Linux 7.1 (with latest ucd-snmp package)	Linux 7.1 (with latest ucd-snmp package)	Linux 7.1 (with latest ucd-snmp package)	Linux Advanced Server 2.1	Linux Advanced Server 2.1
				Linux Advanced Server 2.1	Linux 7.3 (with the 2.4.18-4smp kernel)	Linux 7.3 (with the 2.4.18-4smp kernel)
Server Administrator	1.0	1.0.1	1.0.2	1.1	1.2	1.2.2

Table 4-10. Compatible Dell Systems and Applications for Systems Management CD Versions 3.0 Through 3.2.2 (continued)

Systems Management CD Version	3.0	3.0.1	3.0.2	3.1	3.2	3.2.2
Managed Node Framework	NA	NA	NA	NA	1.2	1.2.2
Instrumentation Service: Server Agent	4.5.1	4.5.1 4.5.2	4.5.1 4.5.2	4.6	NA	1.2.1
Remote Access Service (RAS)	NA	NA	NA	NA	4.7	4.7.1
RAC firmware: DRAC II	2.4.1	2.4.1	2.5	2.5	NA	1.3
RAC firmware: DRAC III	NA	1.1	1.1	1.2	2.5	2.5
RAC firmware: DRAC III/XT	NA	NA	NA	NA	1.3	1.3
RAC firmware: ERA	NA	NA	1.05	1.05	NA	1.0
RAC firmware: ERA/O	NA	NA	NA	1.1	1.07	1.2
Diagnostic Service	2.0	2.0.1	2.0.2	2.1	1.2	1.2
Update Service	1.1	1.1	1.1	1.2	1.2	1.2.1
Server Administrator Core	NA	NA	NA	1.10	1.3	1.3
IT Assistant	6.2	6.2	6.2	6.3	1.2	See "MNF" in this table.
Storage Management Service: Array Manager	3.1.1	3.1.2	3.1.2	3.1.3	3.2	3.3

NOTE: The Systems Management CD versions 3.0 and later do not fully support the following Dell systems: 1300, 2100, 2200, 2300, 4100, 4200, 4300, 4350, 6100, 6300, and 6350.

Device Drivers and Red Hat Enterprise Linux Kernel Support

 **NOTE:** The "Supported Operating Systems" section of Table 4-9 and Table 4-10 includes Red Hat Enterprise Linux kernel versions. Updated or later versions of Red Hat Enterprise Linux may require the use of dynamic kernel support (see *Dell OpenManage Installation and Security User's Guide* for an explanation of this feature).

The Instrumentation Service provides device drivers for the precompiled kernels listed in Table 4-9 and Table 4-10. When the Instrumentation Service detects that none of its prebuilt device drivers supports the running kernel, it attempts to build a device driver for that kernel. This feature of Server Administrator is called dynamic kernel support. Server Administrator's dynamic kernel support builds a device driver when needed during the Instrumentation Service installation or start-up.

Server Agent Supported Applications and Systems

This section provides information on instrumentation, applications, and systems that are supported by *Dell OpenManage Applications* CD versions 2.0 through 2.2. The Dell™ OpenManage™ Server Agent was supported concurrently with the Dell OpenManage Hardware Instrumentation Package (HIP) by the *Applications* CD versions 1.3 through 1.7.

For more information about applications and systems supported by HIP, see "Hardware Instrumentation Package Supported Applications and Systems."

For more information about Server Administrator supported applications and systems, see "Dell OpenManage Supported Applications and Systems."



NOTE: The *Applications* CD version 2.0.1 and later does not fully support the following Dell PowerEdge™ systems: 1300, 2100, 2200, 2300, 4100, 4200, 4300, 4350, 6100, 6300, and 6350.

Table 5-1 shows compatible applications and Dell PowerEdge systems for each *Applications* CD, versions 2.0 through 2.2.

Table 5-1. Server Agent Versions, Applications, and Dell Systems

Applications CD Version	2.0	2.0.1	2.0.2	2.1	2.2
Dell	300	300SC	350	300	300
PowerEdge	350	350	500SC*	350	350
systems	1300	1400SC	1550	500SC	500SC
(* indicates	1400	1550		1300	1300
new systems	1550	2400		1400	1400
for the given	2300	2450		1550	1500SC*
version of	2400	2500		2300	1550
the CD)	2450	2500SC		2400	2300
	2500*	2550		2450	2400
	2550*	4400		2500	2450
	4300	6400		2550	2500
	4350	6450		4300	2550
	4400	8450		4350	4300
	6300			4400	4350
	6350			6300	4400
	6400			6350	6300
	6450			6400	6350
	8450			6450	6400
				8450	6450
					8450
Supported operating systems	Microsoft® Windows NT® 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP 4 or later	Windows NT 4.0 with SP4 or later
	Windows® 2000 Server family	Windows 2000 Server family	Windows 2000 Server family	Windows 2000 Server family	Windows 2000 Server family
	Novell® NetWare® 4.x or 5.x	NetWare 4.x or 5.x	NetWare 4.x or 5.x	NetWare 4.x or 5.x	NetWare 4.x or 5.x
	Red Hat® Linux 7.0 (kernel version: 2.2.16)	Linux 7.0 (kernel version: 2.2.16)	Linux 7.0 (kernel version: 2.2.16)	Linux 7.0	Linux 7.0

Table 5-1. Server Agent Versions, Applications, and Dell Systems (continued)

Applications CD Version	2.0	2.0.1	2.0.2	2.1	2.2
Instrumentation Service: Server Agent	4.3	4.3	4.4	4.4.1	4.5
Remote Access Service: DRAC II	2.3.2	2.3.3	2.3.3	2.4	2.4
Remote Access Service: DRAC III	NA	NA	NA	NA	NA
Online Diagnostics	1.1	1.1	1.1	1.1.1	1.1.2
IT Assistant	6.0	6.0	6.0	6.0	6.0
Storage Management Service: Array Manager	2.7	3.0	3.0	3.0	3.1

Hardware Instrumentation Package Supported Applications and Systems

This section provides information about instrumentation, applications, and systems that are supported by the *Dell OpenManage Applications* CD versions 1.1 through 1.7. Both the Dell™ OpenManage™ Hardware Instrumentation Package (HIP) and the Dell OpenManage Server Agent are supported by the *Applications* CD versions 1.3 through 1.7.

For more information about applications and systems supported by Server Agent, see "Server Agent Supported Applications and Systems."

Table 6-1 shows compatible applications and Dell PowerEdge™ systems for the *Applications* CD versions 1.1 through 1.7.

Table 6-1. HIP Versions, Applications, and Dell PowerEdge Systems

<i>Applications</i> CD Version	1.1	1.2	1.3	1.4	1.5	1.6	1.7
PowerEdge systems	1300	1300	1300	1300	1300	300*	300
(* Indicates new systems for the given version of the CD)	2100	2100	2100	2100	1400*	1300	350*
	2200	2200	2200	2200	2100	1400	1300
	2300	2300	2300	2300	2200	1550*	1400
	2400	2400	2400	2400	2300	2300	1550
	2450	2450	2450	2450	2400	2400	2300
	4100	4100	4100	4100	2450	2450	2400
	4200	4200	4200	4200	4100	4300	2450
	4300	4300	4300	4300	4200	4350	4300
	4350	4350	4350	4350	4300	4400	4350
	4400	4400	4400	4400	4350	6300	4400
	6100	6100	6100	6100	4400	6350	6300
	6300	6300	6300	6300	6100	6400	6350
	6350	6350	6350	6350	6300	6450	6400
	6400	6400	6400	6400	6350	8450	6450
	6450	6450	6450	6450	6400		8450
	8450	8450	8450	8450	6450		
					8450		

Table 6-1. HIP Versions, Applications, and Dell PowerEdge Systems (continued)

Applications CD Version	1.1	1.2	1.3	1.4	1.5	1.6	1.7
Supported operating systems	Microsoft® Windows NT® 4.0 with SP3 or later	Windows NT 4.0 with SP3 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later	Windows NT 4.0 with SP4 or later
			Windows® 2000 Server family	Windows 2000 Server family	Windows 2000 Server family	Windows 2000 Server family	Windows 2000 Server family
	Novell® NetWare® 4.11 with SP5 or later	Novell NetWare 4.11 with SP5 or later					
	NetWare 5.0	NetWare 5.0	NetWare 4.x or 5.x				
Instrumentation Service: HIP	3.5.2	3.5.2	3.5.2	3.5.2	3.5.2	3.5.2	3.5.2
Instrumentation Service: Server Agent	NA	NA	4.0	4.0	4.0	4.2.1	4.2.2
Remote Access Service: DRAC II	2.2.1	2.2.1	2.3	2.3	2.3	2.3.1	2.3.1
Online Diagnostics	NA	NA	NA	NA	NA	NA	1.0
IT Assistant	5.1	5.1	5.1	5.2	6.0	6.0	6.0
Storage Management Service: Array Manager	1.5	1.5	2.0	2.0	2.5	2.5	2.7

BIOS Update Requirements

Overview

Prior to Dell OpenManage 4.3, Server Administrator Update Service provided the ability to update system BIOS remotely from within the Server Administrator GUI. The Update Service also provided interfaces for updating many firmware and driver packages. The remote BIOS update capability did not require that you be logged in directly to the system whose BIOS you were updating. If the target system had the minimum required BIOS version installed, you could update the BIOS to the latest version *remotely*. The purpose of this section is to help you to identify the minimum prerequisite BIOS version to update to the latest available BIOS for each supported Dell™ PowerEdge™ system. You can use this method of BIOS update only if you are running *Dell OpenManage™ Systems Management CD* version 4.2 or earlier.



NOTE: Starting with Dell OpenManage version 4.3, the *Systems Management CD* has been replaced by the *Dell PowerEdge Installation and Server Management CD*. References in this guide to the *Systems Management CD* are for Dell OpenManage versions 3.0 through 4.2.



NOTE: Starting with Dell OpenManage version 4.3, you can update your system's BIOS, drivers, and firmware from the *Dell PowerEdge Server Update Utility CD* or the *Dell Server Updates DVD* or from the Dell Support website at support.dell.com.

Minimum Requirements for BIOS Update Support

This section lists the minimum BIOS requirements for upgrading to the latest BIOS version available for each Dell PowerEdge system supported by Server Administrator. You can download the latest BIOS versions from the Dell Support website at support.dell.com.

To locate the BIOS update files that you want, perform the steps in the following subsections.

Downloading the Latest BIOS Packages

- 1 Go to the Dell Support website at support.dell.com.
- 2 Click **I'm looking for drivers and downloads**.
- 3 Specify your system either by entering your Service Tag or by selecting the product model. Click **Go** or **Confirm**.
- 4 Expand **Bios** and click **Download Now**.
The **File Download** window appears.
- 5 Specify where you want to save your FlashBIOS file and click **OK**.
A download complete pop-up window appears.
- 6 Follow the installation instructions (appropriate for your file format) that appear on the **Download and Install** page.

Minimum Required and Latest Available BIOS for Update by System

Table 7-1 lists the minimum version of the BIOS that must be installed on each system for the latest FlashBIOS package to be applied by remote update. For the latest available BIOS version for each system that Server Administrator supports, see the *Dell PowerEdge Server Update Utility* CD or the *Dell Server Updates* DVD.

Table 7-1. PowerEdge Systems and Minimum BIOS Versions Required for Remote Flash Update

PowerEdge System	Minimum BIOS Required for Remote Flash Update
300	A00
350	BIOS update is not supported for PowerEdge 350 systems.
500SC	A05
600SC	A00
650	A01
700	A00

Table 7-1. PowerEdge Systems and Minimum BIOS Versions Required for Remote Flash Update (continued)

PowerEdge System	Minimum BIOS Required for Remote Flash Update
750	A00
800	A00
1300	A04
1400/1400SC	A00
1500SC	A04
1550	A01
1600SC	A00
1650	A05
1655MC	A00
1750	A05
1800	A00
1850	A00
1855	A00
2300	A09
2400	A01
2450	A02
2500/2500SC	A00
2550	A06
2600	A01
2650	A00
4300	A06
4350	A03
4400	A04
4600	A00

Table 7-1. PowerEdge Systems and Minimum BIOS Versions Required for Remote Flash Update (continued)

PowerEdge System	Minimum BIOS Required for Remote Flash Update
6300	A08
6350	A08
6400	A01
6450	A01
6600	A08
6650	A08
8450	A06

RAID Controller Supported Servers, Operating Systems, Firmware, and Driver Versions

Overview

Starting with Dell™ OpenManage™ Server Administrator version 5.0, only the enhanced Storage Management Service will be supported. The Storage Management Service allows you to configure and manage your storage devices from within Server Administrator.



NOTE: Support for SUSE® Linux Enterprise Server (versions 9) operating system is removed in Dell OpenManage version 6.0.1.



NOTE: The Storage Management Service mentioned in this guide refers to the enhanced Storage Management Service. Server Administrator no longer supports the basic Storage Management Service (also known as Array Manager).



NOTE: See Table 1-1 for information on where you can find the systems management software.

Most versions of the systems management CD support management of RAID controllers in the form of PERC cards, and some systems management releases also support CERC IDE and SATA controllers. System administrators responsible for monitoring the compatibility of their systems' storage devices need a clear matrix that shows the elements that are compatible with a particular storage controller. Each storage controller version in turn supports a specific array of elements, including:

- Version of the Storage Management Service
- Dell system
- Firmware version number required for a particular controller
- Supported operating systems, where each operating system requires a specific driver

For more information on Storage Management Services see the *Dell OpenManage Server Administrator User's Guide* and the *Dell OpenManage Storage Management User's Guide* either on the Dell Support website at support.dell.com or on the *Dell Systems Management Tools and Documentation DVD*.

Five types of controllers are included in this section:

- The RAID controller card group contains the following controllers: PERC 3/DC, PERC 3/SC, PERC 3/QC, PERC 4/SC, PERC 4/DC, PERC 4e/DC, PERC 5/E, PERC 5/i Adapter, PERC 5/i Integrated, SAS 5/iR Adapter, SAS 6/iR Integrated, PERC 6/E, PERC 6/i Adapter, PERC 6/i Integrated, SAS 6/iR Adapter, CERC 6/i Integrated, CERC ATA 100/4 Channel, and CERC SATA 1.5/6 Channel.
- The RAID on motherboard (ROMB) group includes the following controllers: PERC 3/Di, PERC 4/Di, PERC 4e/Di, PERC 4e/Si, CERC SATA 1.5/2S, and SAS 5/iR Integrated.
- The internal mirroring group, provided through the system BIOS, includes the PERC 4/IM controller.
- The LSI 1020/1030 embedded SCSI controller.
- The SAS 5/i Integrated and SAS 5/E controller.



NOTE: The firmware and drivers listed in this section refer to the minimum supported version as of the publication date of this document. Later versions of the firmware and drivers may also be supported or required. For the most recent driver and firmware requirements, see the Dell Support website at support.dell.com for the Storage Management Service.

Key to Table Footnotes

Some drivers in the following tables are marked with an asterisk. You can refer to the following paragraph for more information:

Linux Driver Included in RPM*

The 1.1.4 Linux driver is included in RPM 2302 (Red Hat® Package Manager 2302).

PERC 4/DC

The PERC 4/DC supports the following Dell PowerEdge™ systems: 650, 750, 800, 1650, 1750, 1800, 1850, 2500, 2550, 2600, 2650, 2800, 2850, 4400, 4600, 6400, 6450, 6600, 6650, 6800, 6850, and 8450.

The PERC 4/DC supports the following Dell PowerVault systems: PV745N, PV770N, and PV775N.

Table 8-1 shows the other elements supported by the PERC 4/DC.

Table 8-1. Storage Management Service Supported Elements: PERC 4/DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Microsoft® Windows® 2000 Driver	Windows Server® 2003 Driver	Red Hat Enterprise Linux® 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise server Linux 5 Driver	SUSE® Linux Enterprise Server (versions 10 and 11)
1.1	4.3	3500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	351Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	351X (32-bit) 351S (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	351X (32-bit) 351S (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	351S (64-bit)	NA	6.46.3.64	NA	NA	NA	NA
2.3	5.3	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.4	5.4	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Table 8-1. Storage Management Service Supported Elements: PERC 4/DC (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Microsoft® Windows® 2000 Driver	Windows Server® 2003 Driver	Red Hat Enterprise Linux® 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE® Linux Enterprise Server (versions 10 and 11)
3.0	5.5	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0.2	6.0.1	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.1	6.1	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

PERC 4e/DC

The PERC 4e/DC supports the following Dell PowerEdge systems: 830, 850, 1800, 1850, 1900, 1950, 2800, 2850, 2900, 2950, 2970, 6800, and 6850.

Table 8-2 shows the other elements supported by the PERC 4e/DC.

Table 8-2. Storage Management Service Supported Elements: PERC 4/e DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008 Driver
1.1	4.3	513T	5.46	6.41.2.32	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA

Table 8-2. Storage Management Service Supported Elements: PERC 4/e DC (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008 Driver
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA
2.3	5.3	5A2D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	Native
2.4	5.4	5A2D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	Native
3.0	5.5	5B2D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	Native
3.0.2	6.0.1	5B2D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	Native
3.1	6.1	5B2D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	Native

Table 8-3. Storage Management Service Supported Elements: PERC 4/e DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	513T	2.10.7	NA	NA	NA
1.2	4.4	521Q	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	521X	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	522A	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.3	5.3	5A2D	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.4	5.4	5A2D	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.0	5.5	5B2D	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.0.2	6.0.1	5B2D	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.1	6.1	5B2D	2.10.10.1	2.20.4.4	NA	2.20.4.7

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 3/DC

The PERC 3/DC supports the following Dell PowerEdge systems: 1550, 1650, 1750, 2400, 2450, 2500, 2550, 2600, 2650, 4400, 4600, 6400, 6450, 6600, 6650, 7150, and 8450.

The PERC 3/DC supports the following Dell PowerVault systems: PV735N, PV750N, PV755N, PV770N, and PV775N.

Table 8-4 shows the other elements supported by the PERC 3/DC.

Table 8-4. Storage Management Service Supported Elements: PERC 3/DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	1970	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	198Q	5.48	6.46.2.32 (32-bit) 6.41.2.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	199A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA

Table 8-4. Storage Management Service Supported Elements: PERC 3/DC (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3	5.3	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.4	5.4	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0	5.5	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0.2	6.0.1	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.1	6.1	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 3/QC

The PERC 3/QC supports the following Dell PowerEdge systems: 2400, 2450, 2500, 2550, 2600, 2650, 4400, 4600, 6400, 6450, 6600, 6650, 7150, and 8450.

The PERC 3/QC supports the following Dell PowerVault systems: PV735N, PV750N, PV755N, PV770N, and PV775N.

Table 8-5 shows the other elements supported by the PERC 3/QC.

Table 8-5. Storage Management Service Supported Elements: PERC 3/QC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	1970	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	198Q	5.48	6.46.2.32 (32-bit) 6.41.2.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	199A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	199D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Table 8-5. Storage Management Service Supported Elements: PERC 3/QC (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.4	5.4	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0	5.5	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0.2	6.0.1	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.1	6.1	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

PERC 4/Di

The PERC 4/Di supports the following Dell PowerEdge systems: 1750 and 2600.

Table 8-6 shows the other elements supported by the PERC 4/Di.

Table 8-6. Storage Management Service Supported Elements: PERC 4/Di

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1 on a PowerEdge™ 1750	4.3	4130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.1 on a PowerEdge 2600	4.3	2.500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2 on a PowerEdge 1750	4.4	421Q	5.48	6.46.2.32 (32-bit) 6.41.2.32 (64-bit)	2.10.7	2.20.4.4	NA	NA
1.2 on a PowerEdge 2600	4.4	251Q	5.48	6.46.2.32 (32-bit) 6.41.2.32 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0 on a PowerEdge 1750	5.0	421W	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.0 on a PowerEdge 2600	5.0	251X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1 on a PowerEdge 1750	5.1	421W	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Table 8-6. Storage Management Service Supported Elements: PERC 4/Di (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.1 on a PowerEdge 2600	5.1	251X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2 on a PowerEdge 2600	5.2	252A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.2 on a PowerEdge 1750	5.2	422A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3 on a PowerEdge 2600	5.3	252D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.3 on a PowerEdge 1750	5.3	422D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.4 on a PowerEdge 2600	5.4	252D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.4 on a PowerEdge 1750	5.4	422D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0 on a PowerEdge 2600	5.5	252D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Table 8-6. Storage Management Service Supported Elements: PERC 4/Di (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0 on a PowerEdge 1750	5.5	422D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0.2	6.0.1	422D	NA	NA	NA	NA	NA	NA
3.1	6.1	422D	NA	NA	NA	NA	NA	NA

CERC ATA 100 4/CH

The CERC ATA 100 4/CH supports the following Dell PowerEdge systems: 400, 500SC, 600SC, 650, 1400SC, and 1600SC.

The CERC ATA 100 4/CH supports the following Dell PowerVault system: PV725N.

Table 8-7 shows the other elements supported by the CERC ATA 100 4/CH.

Table 8-7. Storage Management Service Supported Elements: CERC ATA 100 4/CH

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	6.62	5.46	6.41.2.32	Native	NA	NA	NA
1.2	4.4	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.0	5.0	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.1	5.1	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.2	5.2	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA
2.3	5.3	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA
2.4	5.4	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA

Table 8-7. Storage Management Service Supported Elements: CERC ATA 100 4/CH (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0	5.5	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA
3.0.2	6.0.1	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA
3.1	6.1	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA

PERC 3/Di

The PERC 3/Di supports the following Dell PowerEdge systems: 1650, 2500, 2550, 2650, 4400, and 4600.

Table 8-8 and Table 8-9 show the other elements supported by the PERC 3/Di.

Table 8-8. Storage Management Service Supported Elements: PERC 3/Di

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server® 2003 Driver	Windows Server 2008
1.1 on a PowerEdge 1650	4.3	2.8.0.6092	2.8.0.6085	2.8.0.6085	NA
1.1 on a PowerEdge 2650	4.3	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.1 on a PowerEdge 4600	4.3	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.2 on a PowerEdge 1650	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085	NA
1.2 on a PowerEdge 2650	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.2 on a PowerEdge 4600	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
2.0 on a PowerEdge 1650	5.0	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA

Table 8-8. Storage Management Service Supported Elements: PERC 3/Di (continued)

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server® 2003 Driver	Windows Server 2008
2.0 on a PowerEdge 2650	5.0	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA
2.0 on a PowerEdge 4600	5.0	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 1650	5.1	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 2650	5.1	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 4600	5.1	2.8.1-6098	2.8.0.6085*	2.8.0.6085*	NA
2.2 on a PowerEdge 1650	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.2 on a PowerEdge 2650	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.2 on a PowerEdge 4600	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.3 on a PowerEdge 1650	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.3 on a PowerEdge 2650	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.3 on a PowerEdge 4600	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.4 on a PowerEdge 1650	5.4	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.4 on a PowerEdge 2650	5.4	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.4 on a PowerEdge 4600	5.4	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
3.0	5.5	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
3.0.2	6.0.1	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
3.1	6.1	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

Table 8-9. Storage Management Service Supported Elements: PERC 3/Di

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1 on a PowerEdge 1650	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.1 on a PowerEdge 2650	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.1 on a PowerEdge 4600	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.2 on a PowerEdge 1650	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
1.2 on a PowerEdge 2650	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
1.2 on a PowerEdge 4600	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
2.0 on a PowerEdge 1650	5.0	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.0 on a PowerEdge 2650	5.0	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.0 on a PowerEdge 4600	5.0	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 1650	5.1	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 2650	5.1	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 4600	5.1	2.8.1-6098	1.1.4*	1.1.5.2392	NA	NA
2.2 on a PowerEdge 1650	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA
2.2 on a PowerEdge 2650	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA
2.2 on a PowerEdge 4600	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA

Table 8-9. Storage Management Service Supported Elements: PERC 3/Di (continued)

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3 on a PowerEdge 1650	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.3 on a PowerEdge 2650	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.3 on a PowerEdge 4600	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.4 on a PowerEdge 1650	5.4	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.4 on a PowerEdge 2650	5.4	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.4 on a PowerEdge 4600	5.4	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
3.0	5.5	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
3.0.2	6.0.1	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
3.1	6.1	2.8.1-7692	NA	1.1.5.2372.1	NA	NA

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

PERC 4/IM

The PERC 4/IM supports the following Dell PowerEdge systems: 1655MC and 1855.

Table 8-10 and Table 8-11 show the other elements supported by the PERC 4/IM.

Table 8-10. Storage Management Service Supported Elements: PERC 4/IM

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.1 on PowerEdge 1655MC	4.3	1.00.12.00 1.00.0c.00 Hex	1.08.06	1.08.18 (Native)	NA
1.0.1 on PowerEdge 1855	4.1.4	1.03.23.90	1.09.11	1.09.11	NA
1.2 on PowerEdge 1655MC	4.4	1.00.12.00 1.00.0c.00 Hex	1.08.06	1.08.18 (Native)	NA
1.2 on PowerEdge 1855	4.4	1.03.23.90	1.09.11	1.09.11	NA
2.0 on PowerEdge 1655MC	5.0	1.03.23.90	1.08.06	Native	NA
2.0 on PowerEdge 1855	5.0	1.03.23.90	1.09.11	1.09.11	NA
2.1 on PowerEdge 1655MC	5.1	1.03.23.90	1.08.06	Native	NA
2.1 on PowerEdge 1855	5.1	1.03.23.90	1.09.11	1.09.11	NA
2.2 on PowerEdge 1655MC	5.2	1.03.23.90	NA	Native	NA
2.2 on PowerEdge 1855	5.2	1.03.23.90	NA	1.09.11	NA
2.3 on PowerEdge 1655MC	5.3	1.00.12.00	1.08.06	Native	NA
2.3 on PowerEdge 1855	5.3	1.03.23.90	1.09.11	1.09.11	Native
2.4 on PowerEdge 1655MC	5.4	1.00.12.00	1.08.06	Native	NA

Table 8-10. Storage Management Service Supported Elements: PERC 4/IM (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.4 on PowerEdge 1855	5.4	1.03.23.90	1.09.11	1.09.11	Native
3.0 on PowerEdge 1655MC	5.5	1.00.12.00	1.08.06	Native	NA
3.0 on PowerEdge 1855	5.5	1.03.23.90	1.09.11	1.09.11	Native
3.0.2	6.0.2	1.03.23.90	NA	NA	NA
3.1	6.1	1.03.23.90	NA	NA	NA

Table 8-11. Storage Management Service Supported Elements: PERC 4/IM

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1 on PowerEdge 1655MC	4.3	1.00.12.00 1.00.0c.00 Hex	NA	NA	NA	NA
1.0.1 on PowerEdge 1855	4.1.4	1.03.23.90	Native	NA	NA	NA
1.2 on PowerEdge 1655MC	4.4	1.00.12.00 1.00.0c.00 Hex	NA	NA	NA	NA
1.2 on PowerEdge 1855	4.4	1.03.23.90	Native	Native	NA	NA
2.0 on PowerEdge 1655MC	5.0	1.03.23.90	NA	NA	NA	NA
2.0 on PowerEdge 1855	5.0	1.03.23.90	Native	Native	NA	NA

Table 8-11. Storage Management Service Supported Elements: PERC 4/IM (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.1 on PowerEdge 1655MC	5.1	1.03.23.90	NA	NA	NA	NA
2.1 on PowerEdge 1855	5.1	1.03.23.90	Native	Native	NA	NA
2.2 on PowerEdge 1655MC	5.2	1.03.23.90	NA	NA	NA	NA
2.2 on PowerEdge 1855	5.2	1.03.23.90	NA	Native	NA	NA
2.3 on PowerEdge 1655MC	5.3	1.00.12.00	NA	NA	NA	NA
2.3 on PowerEdge 1855	5.3	1.03.23.90	2.05.16	Native	NA	NA
2.4 on PowerEdge 1655MC	5.4	1.00.12.00	NA	NA	NA	NA
2.4 on PowerEdge 1855	5.4	1.03.23.90	2.05.16	Native	NA	NA
3.0 on PowerEdge 1655MC	5.5	1.00.12.00	NA	NA	NA	NA
3.0 on PowerEdge 1855	5.5	1.03.23.90	2.05.16	Native	NA	NA
3.0.2	6.0.1	1.03.23.90	NA	NA	NA	NA
3.1	6.1	1.03.23.90	NA	NA	NA	NA

PERC 4/SC

The PERC 4/SC supports the following Dell PowerEdge systems: 500SC, 600SC, 650, 700, 750, 800, 830, 850, 1400SC, 1500SC, 1600SC, 1800, and 1850.

Table 8-12 shows the other elements supported by the PERC 4/SC.

Table 8-12. Storage Management Service Supported Elements: PERC 4/SC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	3500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	351Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	351X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	351X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	352B	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.4	5.4	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Table 8-12. Storage Management Service Supported Elements: PERC 4/SC (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0	5.5	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.0.2	6.0.1	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
3.1	6.1	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

CERC SATA 1.5/6 Channel

The CERC SATA 1.5/6 Channel supports the following Dell PowerEdge systems: 700, 750, 800, 830, 850, 1420SC, and 1800.

The CERC SATA 1.5/6 Channel supports the following Dell PowerVault system: PV745N.

Table 8-13 and Table 8-14 show the other elements supported by the CERC SATA 1.5/6 Channel.

**Table 8-13. Storage Management Service Supported Elements:
CERC SATA 1.5/6 Channel**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.1	4.3	4.1.0-7403	4.1.0-7010	4.1.0-7010	NA
1.2	4.4	4.1.0.7406	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7035 (64-bit)	NA
2.0	5.0	4.1.0.7417	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.1	5.1	4.1.0.7417	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.2	5.2	4.1.0.7417	NA	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.3	5.3	4.1.0.7419	4.1.1.7040	4.1.1.7040	4.1.1.7040
2.4	5.4	4.1.0.7419	4.1.1.7040	4.1.1.7043	4.1.1.7040
3.0	5.5	4.1.0.7419	4.1.1.7040	4.1.1.7043	4.1.1.7040
3.0.2	6.0.1	4.1.0.7419	4.1.1.7040	4.1.1.7043	4.1.1.7040
3.1	6.1	4.1.0.7419	4.1.1.7040	4.1.1.7043	4.1.1.7040

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

**Table 8-14. Storage Management Service Supported Elements:
CERC SATA 1.5/6 Channel**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	4.1.0-7403	1.1.4*	NA	NA	NA
1.2	4.4	4.1.0.7406	1.1.4*	NA	NA	NA
2.0	5.0	4.1.0.7417	1.1.4*	1.1.5-2372	NA	NA
2.1	5.1	4.1.0.7417	1.1.4*	1.1.5-2372	NA	NA
2.2	5.2	4.1.0.7417	NA	1.1.5-2392	NA	NA
2.3	5.3	4.1.0.7419	NA	1.1.5-2392	NA	NA
2.4	5.4	4.1.0.7419	NA	1.1.5-2392	NA	NA
3.0	5.5	4.1.0.7419	NA	1.1.5-2392	NA	NA
3.0.2	6.0.1	4.1.0.7419	NA	1.1.5-2392	NA	NA
3.1	6.1	4.1.0.7419	NA	1.1.5-2392	NA	NA

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

PERC 4e/Di

The PERC 4e/DI supports the following Dell PowerEdge systems: 2800, 2850, 6800, and 6850.

Table 8-15 shows the other elements supported by the PERC 4e/Di.

Table 8-15. Storage Management Service Supported Elements: PERC 4e/Di

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	5130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	2.20.4.7
2.3 on PowerEdge 2850	5.3	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.3 on PowerEdge 6850	5.3	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7

Table 8-15. Storage Management Service Supported Elements: PERC 4e/Di (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.4 on PowerEdge 2850	5.4	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.4 on PowerEdge 6850	5.4	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.0 on PowerEdge 2850	5.5	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.0 on PowerEdge 6850	5.5	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.0.2	6.0.1	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
3.1	6.1	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 4e/Si

The PERC 4e/Si supports the following Dell PowerEdge system: 1850.

Table 8-16 show the other elements supported by the PERC 4e/Si.

Table 8-16. Storage Management Service Supported Elements: PERC 4e/Si

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	5130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	Native
2.4	5.4	5A2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	Native
3.0	5.5	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	Native

Table 8-16. Storage Management Service Supported Elements: PERC 4e/Si (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0.2	6.0.1	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	Native
3.1	6.1	5B2D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	Native

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 5/E Adapter

The PERC 5/E Adapter supports the following Dell PowerEdge systems: 840, 860, 1850, 1900, 1950, 2850, 2900, 2950, 2970, 6800, 6850, 6950, and R805.

The PERC 5/E Adapter supports the following Dell PowerVault systems: PowerVault 100, PowerVault 500, PowerVault 600, and PowerVault DL2000.

Table 8-17 and Table 8-18 show the other elements supported by the PERC 5/E Adapter.

 **NOTE:** The RAID cards support both 32- and 64-bit versions of Red Hat Enterprise Linux operating systems and only 64-bit versions of the SUSE Linux Enterprise Server operating systems. However, ia64 versions of any operating system are not supported.

**Table 8-17. Storage Management Service Supported Elements:
PERC 5/E Adapter**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.4	4.5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0066	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	NA
2.4	5.4	5.2.1-0066	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	Native
3.0	5.5	5.2.2-0072	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.0.2	6.0.1	5.2.2-0076	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.1	6.1	5.2.2-0076	2.14.0.32	2.24.0.32 Dell A07 (32-bit) 2.24.0.64 Dell A07 (64-bit)	2.24.0.32 Dell A03 (32-bit) 2.24.0.64 Dell A03 (64-bit)

**Table 8-18. Storage Management Service Supported Elements:
PERC 5/E Adapter**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06

**Table 8-18. Storage Management Service Supported Elements:
PERC 5/E Adapter (continued)**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3	5.3	5.2.1-0066	NA	00.00.03.13	00.00.03.13	00.00.03.13
2.4	5.4	5.2.1-0066	NA	00.00.03.13	00.00.03.16	00.00.03.16
3.0	5.5	5.2.2-0072	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.0.2	6.0.1	5.2.2-0076	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	5.2.2-0076	NA	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 5/i Adapter

The PERC 5/i Adapter supports the following Dell PowerEdge systems: 840, 6850, 6950, and 1430SC.

The PERC 5/i Adapter supports the following Dell PowerVault system: PowerVault 100.

Table 8-19 and Table 8-20 show the other elements supported by the PERC 5/i Adapter.

**Table 8-19. Storage Management Service Supported Elements:
PERC 5/i Adapter**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008 Driver
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0066	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	NA
2.4	5.4	5.2.1-0066	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	Native
3.0	5.5	5.2.2-0072	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.0.2	6.0.1	5.2.2-0072	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.1	6.1	5.2.2-0072	2.14.0.32	2.24.0.32 Dell A07 (32-bit) 2.24.0.64 Dell A07 (64-bit)	2.24.0.32 Dell A03 (32-bit) 2.24.0.64 Dell A03 (64-bit)

Table 8-20. Storage Management Service Supported Elements: PERC 5/i Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06
2.3	5.3	5.2.1-0066	NA	00.00.03.16	00.00.03.16	00.00.03.16
2.4	5.4	5.2.1-0066	NA	00.00.03.16	00.00.03.16	00.00.03.16
3.0	5.5	5.2.2-0072	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.0.2	6.0.1	5.2.2-0072	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	5.2.2-0072	NA	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 5/i Integrated

The PERC 5/i Integrated supports the following Dell PowerEdge systems: 1900, 1950, 2900, 2950, and 2970.

The PERC 5/i Integrated supports the following Dell PowerVault system: PowerVault NX1950.

Table 8-21 and Table 8-22 show the other elements supported by the PERC 5/i Integrated.

Table 8-21. Storage Management Service Supported Elements: PERC 5/i Integrated

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0067	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	NA
2.4	5.4	5.2.1-0067	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	Native
3.0	5.5	5.2.2-0072	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.0.2	6.0.1	5.2.2-0072	2.14.0.32	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.1	6.1	5.2.2-0072	2.14.0.32	2.24.0.32 Dell A07 (32-bit) 2.24.0.64 Dell A07 (64-bit)	2.24.0.32 Dell A03 (32-bit) 2.24.0.64 Dell A03 (64-bit)

Table 8-22. Storage Management Service Supported Elements: PERC 5/i Integrated

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06
2.3	5.3	5.2.1-0067	NA	00.00.03.16	00.00.03.16	00.00.03.16
2.4	5.4	5.2.1-0067	NA	00.00.03.16	00.00.03.16	00.00.03.16
3.0	5.5	5.2.2-0072	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.0.2	6.0.1	5.2.2-0072	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	5.2.2-0072	NA	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

CERC 6/i Integrated

The CERC 6/i Integrated supports the following Dell PowerEdge systems: M600, M605, M805, and M905.

Table 8-25 and Table 8-26 show the other elements supported by the CERC 6/i Integrated.

Table 8-23. Storage Management Service Supported Elements: CERC 6/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/BIOS Version	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	NA	NA	NA
2.4	5.4	6.0.2-0002	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	Native
3.0	5.5	6.1.1-0045	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.0.2	6.0.1	6.1.1-0047	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.1	6.1	6.2.0-0013	2.24.0.32 Dell A07 (32-bit) 2.24.0.64 Dell A07 (64-bit)	2.24.0.32 Dell A03 (32-bit) 2.24.0.64 Dell A03 (64-bit)

Table 8-24. Storage Management Service Supported Elements: CERC 6/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3	5.3	NA	NA	NA	NA	NA
2.4	5.4	6.0.2-0002	NA	00.00.03.16	00.00.03.16	00.00.03.16
3.0	5.5	6.1.1-0045	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.0.2	6.0.1	6.1.1-0047	NA	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	6.2.0-0013	NA	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

SAS 5/iR Adapter

The SAS 5/iR Adapter supports the following Dell PowerEdge systems: 440SC, 1435SC, 1430SC, 840, 860, 1900, 2900, 6950, T605, and T610.

The SAS 5/iR Adapter supports the following Dell PowerVault systems: PowerVault 600, and PowerVault 100.

Table 8-25 and Table 8-26 show the other elements supported by the SAS 5/iR Adapter.

**Table 8-25. Storage Management Service Supported Elements:
SAS 5/iR Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00/ 06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.05.00	1.24.4.0	1.24.04.00	NA
2.4	5.4	00.10.51.00.06.12.05.00	1.24.04.40	1.24.04.40	1.26.05.00
3.0	5.5	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.0.2	6.0.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.1	6.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01

**Table 8-26. Storage Management Service Supported Elements:
SAS 5/iR Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63
2.1	5.1	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63
2.2	5.2	00.10.47.00/ 06.12.02.00	NA	3.02.83.12	4.00.00.00	3.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06 .12.05.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)

**Table 8-26. Storage Management Service Supported Elements:
SAS 5/iR Adapter (continued)**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.4	5.4	00.10.51.00.06 .12.05.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) Native (version 9 SP4) 4.00.07.00-2 (version 10)
3.0	5.5	00.10.51.00.06 .12.05.00	NA	3.12.29.00-4	4.00.38.02-2	3.02.29.00-4 (version 9) 4.00.38.02-2 (version 10)
3.0.2	6.0.1	00.10.51.00.06 .12.05.00	NA	3.12.29.00-4	4.00.38.02-2	4.00.38.02-2 (version 10)
3.1	6.1	00.10.51.00.06 .12.05.00	NA	3.12.29.00-6 Dell A07	4.00.38.02-3 Dell A03	4.00.38.02-3 Dell A03 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

SAS 5/iR Integrated

The SAS 5/iR Integrated supports the following Dell PowerEdge system: 1955.

Table 8-27 and Table 8-28 show the other elements supported by the SAS 5/iR Integrated.

Table 8-27. Storage Management Service Supported Elements: SAS 5/iR Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.05.00	1.24.04.00	1.24.04.00	NA
2.4	5.4	00.10.51.00.06.12.05.00	1.24.04.40	1.24.04.40	1.26.05.00
3.0	5.5	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.0.2	6.0.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.1	6.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01

Table 8-28. Storage Management Service Supported Elements: SAS 5/iR Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63
2.1	5.1	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63

**Table 8-28. Storage Management Service Supported Elements:
SAS 5/iR Integrated (continued)**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.2	5.2	00.10.47.00.06.12.02.00	NA	3.02.83.12	4.00.00.00	3.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06.12.05.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)
2.4	5.4	00.10.51.00.06.12.05.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) Native (version 9 SP4) 4.00.07.00-2 (version 10)
3.0	5.5	00.10.51.00.06.12.05.00	NA	3.12.29.00-4	4.00.38.02-2	3.02.29.00-4 (version 9) 4.00.38.02-2 (version 10)
3.0.2	6.0.1	00.10.51.00.06.12.05.00	NA	3.12.29.00-4	4.00.38.02-2	4.00.38.02-2 (version 10)
3.1	6.1	00.10.51.00.06.12.05.00	NA	3.12.29.00-6 Dell A07	4.00.38.02-3 Dell A03	4.00.38.02-3 Dell A03 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

SAS 5/i Integrated

The SAS 5/i Integrated controller supports the following Dell PowerEdge systems: 1950, 2900, 2950, and 2970.

Table 8-29 and Table 8-30 show the other elements supported by the SAS 5/i Integrated controller.

Table 8-29. Storage Management Service Supported Elements: SAS 5/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.05.00	1.24.04.00	1.24.04.00	NA
2.4	5.4	00.10.51.00.06.12.05.00	1.24.04.40	1.24.04.40	1.26.05.00
3.0	5.5	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.0.2	6.0.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.1	6.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01

Table 8-30. Storage Management Service Supported Elements: SAS 5/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	00.06.40.00/06.06.00.01	2.06.32	3.02.63	NA	3.02.63
2.1	5.1	00.06.40.00/06.06.00.01	2.06.32	3.02.63	NA	3.02.63
2.2	5.2	00.10.47.00.06.12.02.00	NA	3.02.83.12	4.00.00.00	3.02.83.12 (version 9) 4.00.00.00 (version 10)

**Table 8-30. Storage Management Service Supported Elements:
SAS 5/i Integrated (continued)**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3	5.3	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)
2.4	5.4	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) Native (version 9 SP4) 4.00.07.00-2 (version 10)
3.0	5.5	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-4	4.00.38.02-2	3.02.29.00-4 (version 9) 4.00.38.02-2 (version 10)
3.0.2	6.0.1	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-4	4.00.38.02-2	4.00.38.02-2 (version 10)
3.1	6.1	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-6 Dell A05	4.00.38.02-3 Dell A05	4.00.38.02-3 Dell A05 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

SAS 5/E Adapter

The SAS 5/E Adapter supports the following Dell PowerEdge systems: 1800, 1850, 1900, 1950, 2800, 2850, 2900, 2950, 2970, 6800, 6850, 6950, R900, T300, T605, R200, R300, R805, R905, and R610, R710, and T610.

The SAS 5/E Adapter supports the following Dell PowerVault systems: PowerVault NX1950, PowerVault 500, PowerVault 600, and PowerVault DL2000.

Table 8-31 and Table 8-32 show the other elements supported by the SAS 5/E Adapter.

Table 8-31. Storage Management Service Supported Elements: SAS 5/E Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.05.00	1.24.04.00	1.24.04.00	NA
2.4	5.4	00.10.51.00.06.12.05.00	1.24.04.40	1.24.04.40	1.26.05.00
3.0	5.5	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.0.2	6.0.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01
3.1	6.1	00.10.51.00.06.12.05.00	1.24.04.40	1.28.03.01	1.28.03.01

Table 8-32. Storage Management Service Supported Elements: SAS 5/E Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.0	5.0	00.06.40.00/06.06.00.01	2.06.32	3.02.63	NA	3.02.63
2.1	5.1	00.06.40.00/06.06.00.01	2.06.32	3.02.63	NA	3.02.63

**Table 8-32. Storage Management Service Supported Elements:
SAS 5/E Adapter (continued)**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.2	5.2	00.10.47.00.0 6.12.02.00	NA	3.02.83.12	4.00.00.00	3.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)
2.4	5.4	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) Native (version 9 SP4) 4.00.07.00-2 (version 10)
3.0	5.5	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-4	4.00.38.02-2	3.02.29.00-4 (version 9) 4.00.38.02-2 (version 10)
3.0.2	6.0.1	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-4	4.00.38.02-2	4.00.38.02-2 (version 10)
3.1	6.1	00.10.51.00. 06.12.05.00	2.06.48.02-2	3.12.29.00-6 Dell A05	4.00.38.02-3 Dell A05	4.00.38.02-3 Dell A05 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 6/i Integrated and Adapter

The PERC 6/i Integrated supports the following Dell PowerEdge systems: 1950, 2900, 2950, 2970, R805, 900, T610, R610, R710, M610, and M710 .

The PERC 6/i Integrated supports the following Dell PowerVault systems: PowerVault 500, PowerVault NX1950, and PowerVault 600.

The PERC 6/i Adapter supports the following Dell PowerEdge systems: R905, T300, and T605.

Table 8-33 and Table 8-34 show the other elements supported by the PERC 6/i Integrated and Adapter.

Table 8-33. Storage Management Service Supported Elements: PERC 6/i Integrated and Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	6.0.1-0080	2.14.0.32 (32-bit)	NA
			2.14.0.64 (64-bit)	
2.4	5.4	6.0.2-0002	2.14.0.32 (32-bit)	Native
			2.14.0.64 (64-bit)	
3.0	5.5	6.1.1-0045	2.23.0.32 (32-bit)	2.23.0.32 (32-bit)
			2.23.0.64 (64-bit)	2.23.0.64 (64-bit)
3.0.2	6.0.1	6.1.1-0047	2.23.0.32 (32-bit)	2.23.0.32 (32-bit)
			2.23.0.64 (64-bit)	2.23.0.64 (64-bit)
3.1	6.1	6.2.0-0013	2.24.0.32 (32-bit)	2.24.0.32 (32-bit)
			Dell A07 2.24.0.64 (64-bit)	Dell A03 2.24.0.64 (64-bit)
			Dell A07	Dell A03

Table 8-34. Storage Management Service Supported Elements: PERC 6/i Integrated and Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
2.3	5.3	6.0.1-0080	00.00.03.16	00.00.03.16	00.00.03.16
2.4	5.4	6.0.2-0002	00.00.03.16	00.00.03.16	00.00.03.16
3.0	5.5	6.1.1-0045	00.00.03.21	00.00.03.21	00.00.03.21
3.0.2	6.0.1	6.1.1-0047	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	6.2.0-0013	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

PERC 6/E Adapter

The PERC 6/E Adapter supports the following Dell PowerEdge systems: 1950, 2900, 2950, 2970, 6950, R200, R300, R805, R900, R905, T300, T610, R610, and R710.

The PERC 6/E Adapter supports the following Dell PowerVault systems: PowerVault 500, PowerVault 600, and PowerVault DL2000.

Table 8-35 and Table 8-36 show the other elements supported by the PERC 6/E Adapter.

Table 8-35. Storage Management Service Supported Elements: PERC 6/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	6.0.1-0080	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	NA
2.4	5.4	6.0.2-0002	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	Native
3.0	5.5	6.1.1-0045	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.0.2	6.0.1	6.1.1-0047	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)	2.23.0.32 (32-bit) 2.23.0.64 (64-bit)
3.1	6.1	6.2.0-0013	2.24.0.32 (32-bit) Dell A07 2.24.0.64 (64-bit) Dell A07	2.24.0.32 (32-bit) Dell A03 2.24.0.64 (64-bit) Dell A03

Table 8-36. Storage Management Service Supported Elements: PERC 6/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
2.3	5.3	6.0.1-0080	00.00.03.16	00.00.03.16	00.00.03.16
2.4	5.4	6.0.2-0002	00.00.03.16	00.00.03.16	00.00.03.16
3.0	5.5	6.1.1-0045	00.00.03.21	00.00.03.21	00.00.03.21

**Table 8-36. Storage Management Service Supported Elements:
PERC 6/E Adapter (continued)**

Storage Management Service	Dell OpenManage Version	PERC Firmware	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
3.0.2	6.0.1	6.1.1-0047	00.00.03.21	00.00.03.21	00.00.03.21
3.1	6.1	6.2.0-0013	00.00.03.21-6 Dell A09	Native	00.00.03.21-6 Dell A09 (version 10) Native (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

SAS 6/iR Integrated and Adapter

The SAS 6/iR Integrated supports the following Dell PowerVault systems: PowerVault 500, PowerVault 600, and PowerVault DL2000.

The SAS 6/iR Integrated also supports the following Dell PowerEdge systems: 1950, 2900, 2950, 2970, R805, R900, M600, M605, M805, M905, T610, R610, R710, M610, and M710.

The SAS 6/iR Adapter supports the following Dell PowerEdge systems: R200, R300, T105, T300, R905, T100, and T605.

Table 8-37 shows the other elements supported by the SAS 6/iR Integrated and Adapter.

**Table 8-37. Storage Management Service Supported Elements:
SAS 6/iR Integrated and Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	00.20.46.00.06.14.10.00	1.24.04.00	NA
2.4	5.4	00.20.48.00.06.14.10.00	1.24.04.40	1.26.05.00
3.0	5.5	00.25.47.00.06.22.03.00	1.28.03.01	1.28.03.01
3.0.2	6.0.1	00.25.47.00.06.22.03.00	1.28.03.01	1.28.03.01
3.1	6.1	00.25.47.00.06.22.03.00	1.28.03.01	1.28.03.01

**Table 8-38. Storage Management Service Supported Elements:
SAS 6/iR Integrated and Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.3	5.3	00.20.46.00.06.14.10.00	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)
2.4	5.4	00.20.48.00.06.14.10.00	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) Native (version 9 SP4) 4.00.07.00-2 (version 10)
3.0	5.5	00.25.47.00.06.22.03.00	3.12.29.00-4	4.00.38.02-2	3.12.29.00-4 (version 9) 4.00.38.02-2 (version 10)

**Table 8-38. Storage Management Service Supported Elements:
SAS 6/iR Integrated and Adapter (continued)**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0.2	6.0.1	00.25.47.00.06.22.03.00	3.12.29.00-4	4.00.38.02-2	4.00.38.02-2 (version 10)
3.1	6.1	00.25.47.00.06.22.03.00	3.12.29.00-6 Dell A07	4.00.38.02-3 Dell A03	4.00.38.02-3 Dell A03 (version 10) Nativer (version 11)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

LSI Logic 1020/1030 Ultra320 SCSI Adapter

LSI Logic 1020/1030 Ultra320 SCSI adapter supports the following Dell PowerEdge systems: 1950, 2950, 2970, 6950, R200, R300, R900, R805, R905, T100, T105, T300, and T605.

LSI Logic 1020/1030 Ultra320 SCSI adapter supports the following Dell PowerVault systems: PowerVault NX1950 and PowerVault 500.

Table 8-39 and Table 8-40 show the other elements supported by LSI Logic 1020/1030 Ultra320 SCSI adapter.

Table 8-39. Storage Management Service Supported Elements: LSI Logic 1020/1030 Ultra320 SCSI Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver
2.2	5.2	NOTE: See the appropriate readme file for the latest information.	1.21.25.00	1.21.25.00
2.3	5.3	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00
2.4	5.4	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00
3.0	5.5	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00
3.0.2	6.0.1	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00
3.1	6.1	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00

Table 8-40. Storage Management Service Supported Elements: LSI Logic 1020/1030 Ultra320 SCSI Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.2	5.2	NOTE: See the appropriate readme file for the latest information.	NA	3.02.83.01	NA	3.02.83.01 (version 9) 3.03.15 (version 10)
2.3	5.3	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	3.02.83.12-5 (version 9 only)
2.4	5.4	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	3.02.83.12-5 (version 9 only)
3.0	5.5	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	3.02.83.12-5 (version 9 only)

Table 8-40. Storage Management Service Supported Elements: LSI Logic 1020/1030 Ultra320 SCSI Adapter (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware/BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0.2	6.0.1	1.03.27.00.5.1 0.08.00.12	NA	3.02.83.12-5	NA	NA
3.1	6.1	1.03.27.00.5.1 0.08.00.12	NA	3.02.83.12-5	NA	NA

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9. Dell OpenManage version 5.4 supports only Gold for Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and Gold for SUSE Linux Enterprise Server version 10. Dell OpenManage version 5.5 supports only Update 5 of Red Hat Enterprise Linux 4, Update 2 of Red Hat Enterprise Linux 5 server, SP4 for SUSE Linux Enterprise Server version 9, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10. Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

CERC SATA 1.5/2S

The CERC SATA 1.5/2s supports the following Dell PowerEdge systems: 800, 1425, 1420SC, 420SC, and 1800.

Table 8-41 show the other elements supported by the CERC SATA 1.5/2S.

Table 8-41. Storage Management Service Supported Elements: CERC SATA 1.5/2S

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
1.1	4.3	NA	6.00.048	6.00.048	NA	NA	NA	NA
1.2	4.4	NA	6.00.050	6.00.050	NA	NA	NA	NA
2.0	5.0	NA	6.00.050	6.00.050	NA	NA	NA	NA
2.1	5.1	NA	6.00.050	6.00.050	NA	NA	NA	NA

**Table 8-41. Storage Management Service Supported Elements:
CERC SATA 1.5/2S (continued)**

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
2.2	5.2	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
2.3	5.3	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
2.4	5.4	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
3.0	5.5	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
3.0.2	6.0.1	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
3.1	6.1	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

LSI 1020/1030 Embedded SCSI Controller

This embedded SCSI controller is an onboard chip. It supports the following systems: 1600SC, 1750, 1800, 1850, 2600, 2800, 2850, 6800, and 6850.

Table 8-42 and Table 8-43 show the other elements supported by the LSI 1020/1030.

Table 8-42. Storage Management Service Supported Elements: LSI 1020

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
1.1 on a PowerEdge 1600SC	4.3	1.03.04.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA
1.2 on a PowerEdge 1600SC	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 1600SC	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.1 on a PowerEdge 1600SC	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.2 on a PowerEdge 1600SC	5.2	1.03.23	NA	Native	NA	Native	NA	NA
2.3 on a PowerEdge 1600SC	5.3	1.03.23	NA	Native	NA	Native	NA	NA
2.4 on a PowerEdge 1600SC	5.4	1.03.23	NA	Native	NA	Native	NA	NA

Table 8-42. Storage Management Service Supported Elements: LSI 1020 (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
3.0 on a PowerEdge 1600SC	5.5	1.03.23	NA	Native	NA	Native	NA	NA
3.0.2	6.0.1	1.03.23	NA	Native	NA	Native	NA	NA
3.1	6.1	1.03.23	NA	1.09.11	NA	Native	NA	NA

Table 8-43. Storage Management Service Supported Elements: LSI 1030

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
1.1 on PowerEdge 1750	4.3	1.01.61.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA
1.1 on PowerEdge 2600	4.3	1.01.61.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA
1.2 on a PowerEdge 1750	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
1.2 on a PowerEdge 2600	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 1750	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 2600	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA

Table 8-43. Storage Management Service Supported Elements: LSI 1030 (continued)

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (version 10 and 11)
2.1 on a PowerEdge 1750	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.1 on a PowerEdge 2600	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.2 on a PowerEdge 1750	5.2	1.01.61.00	NA	Native	NA	NA	NA	NA
2.2 on a PowerEdge 2600	5.2	1.01.61.00	NA	Native	NA	NA	NA	NA
2.3 on a PowerEdge 1750	5.3	1.01.61.00	NA	Native	NA	NA	NA	NA
2.3 on a PowerEdge 2600	5.3	1.01.61.00	NA	Native	NA	NA	NA	NA
2.4 on a PowerEdge 1750	5.4	1.01.61.00	NA	Native	NA	NA	NA	NA
2.4 on a PowerEdge 2600	5.4	1.01.61.00	NA	Native	NA	NA	NA	NA
3.0 on a PowerEdge 1750	5.5	1.01.61.00	NA	Native	NA	NA	NA	NA
3.0 on a PowerEdge 2600	5.5	1.01.61.00	NA	Native	NA	NA	NA	NA
3.0.2	6.0.1	1.01.61.00	NA	Native	NA	NA	NA	NA
3.1	6.1	1.03.23	NA	1.09.11	NA	NA	NA	NA

LSI Logic 2032 Card

The LSI Logic 2032 card supports the following Dell PowerEdge systems: R610, R710, and T610.

The LSI Logic 2032 card supports the following Dell PowerVault systems: PowerVault DL2000.

Table 8-44 and Table 8-45 show the other elements supported by LSI Logic 2032 card.

Table 8-44. Storage Management Service Supported Elements: LSI Logic 2032 Card

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver
3.0.2	6.0.1	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00
3.1	6.1	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00

Table 8-45. Storage Management Service Supported Elements: LSI Logic 2032 Card

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux 5 server Driver	SUSE Linux Enterprise Server (versions 10 and 11)
3.0.2	6.0.1	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	NA
3.1	6.1	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	NA

Dell OpenManage version 6.0.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 2 for Red Hat Enterprise Linux 5 server, and SP2 for SUSE Linux Enterprise Server version 10.

Dell OpenManage version 6.1 supports only Update 7 for Red Hat Enterprise Linux 4, Update 3 for Red Hat Enterprise Linux 5 server, SP2 for SUSE Linux Enterprise Server version 10, and SUSE Linux Enterprise Server version 11.

Network Interface Controllers and Supported Operating Systems

Overview

The drivers required for a Network Interface Card (NIC) depend on the operating system installed on your system.

Table 9-1 shows the relationship between NICs supported by Dell™ OpenManage™ Server Administrator and the drivers that they require on each supported operating system.

NIC Drivers and Operating Systems

To determine required drivers for NIC systems management, locate your NIC manufacturer in Table 9-1 and the operating system that is installed on your system.

In Table 9-1, "NA" indicates that the driver is supplied by the operating system rather than by the manufacturer of the NIC.

Table 9-1. NIC Manufacturers and Drivers Required for Supported Operating Systems

NIC Product Name	Microsoft® Windows® 2000	Microsoft Windows 2003	Microsoft Windows 2008	Red Hat Enterprise Linux 4.7	Red Hat Enterprise Linux Server 5.3	SUSE® Linux Enterprise Server (version 10 SP2 and version 11)
Broadcom NetXtreme Family of Adapters (5721, 5722)	NA	11.7	11.7	3.92n	3.92n	3.92n
Broadcom NetXtreme II Family of Adapters (BCM5708, BCM5709)	NA	4.6	4.6	1.8.7b	1.8.7b	1.8.7b
Broadcom NetXtreme II Family of Adapter 10GbE (BCM57710)	NA	4.6	4.6	1.48.107	1.48.107	1.48.107
Intel® EtherExpress® Family of Adapters	6.0	8.0.17 (Intel PRO/100 Adapters) 8.4.21 (Intel PRO/1000 Adapters)	NA	NA (Intel PRO/100 Adapters) 5.7.6.1 (Intel PRO/1000 Adapters)	See the appropriate readme file for the latest information.	3.4.14p1-NAPI (Intel PRO/100 Network Driver) 6.2.15-NAPI (Intel PRO/1000 Network Driver)

Table 9-1. NIC Manufacturers and Drivers Required for Supported Operating Systems (continued)

NIC Product Name	Microsoft® Windows® 2000	Microsoft Windows 2003	Microsoft Windows 2008	Red Hat Enterprise Linux 4.7	Red Hat Enterprise Linux Server 5.3	SUSE® Linux Enterprise Server (version 10 SP2 and version 11)
3COM® 3C98x Family of Adapters.	NA	NA	NA	NA	NA	NA
Alteon™ ACEnic™ Copper Gigabit	NA	NA	NA	NA	NA	NA

Remote Access Service Availability

Overview

Although all supported operating systems for Server Administrator support remote access, remote access availability is system-dependent. The Remote Access Service is supported only on the following Dell™ PowerEdge™ systems: 700, 750, 800, 830, 840, 850, 860, 1600SC, 1650, 1655MC, 1750, 1800, 1850, 1855, 1900, 1950, 1955, 2600, 2650, 2800, 2850, 2900, 2950, 2970, 4600, 6600, 6650, 6800, 6850, 6950, T300, R200, R300, M600, M605, T605, R805, R900, R905, M805, M905, T100, R710, R610, T610, M610, M710, R410, T410, T710, and on the following Dell PowerVault™ systems: PowerVault 100, PowerVault 500, PowerVault 600, PowerVault NX1950, PowerVault NX3000, and PowerVault DL2000.

The Server Administrator GUI does not display any services on your system that are not available for that system or for that system configuration.



NOTE: See Table 1-1 for information on where you can find the systems management software.

RAC Types

The remote access controller (RAC) cards that are available for specific Dell systems are: DRAC III, DRAC III/XT, ERA, ERA/O, ERA/MC (for Dell PowerEdge 1655MC) DRAC 4/I (for PowerEdge 1850, 2800, and 2850), DRAC 4/P (for PowerEdge 800, 830, 840, 850, 860, 1800, 6800, 6850, R200, PowerVault 100), DRAC/MC (for PowerEdge 1855 and 1955), DRAC 5 (for PowerEdge 1900, 1950, 2900, 2950, 2970, 6950, T300, R300, T605, R805, R900, R905, T100, PowerVault 500, PowerVault 600, and PowerVault DL2000), and iDRAC6 (for PowerEdge R610, R710, T610, M610, and M710 systems) and iDRAC supports the PowerEdge M600, M605, M805, and M905 systems in the Dell PowerEdge M1000e system enclosure).



NOTE: The DRAC III occupies a PCI slot, and has a modem, a battery, and an external AC power connection unlike the other RACs.

Availability of RACs on Specific Dell Systems

Table 10-1 shows the RACs that are available on specific Dell systems.

 **NOTE:** The ERA/MC is supported only on PowerEdge 1655MC systems.

Table 10-1. Availability of RACs on Specific Dell Systems

Dell System	DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4	DRAC/MC	DRAC 5	iDRAC	iDRAC6
700				X					
750				X					
800					X				
830					X				
840					X				
850					X				
860					X				
1600SC				X					
1650	X		X						
1750			X						
1800					X				
1850					X				
1855						X			
1900							X		
1950							X		
1955						X			
2600			X						
2650		X							
2800					X				
2850					X				
2900							X		
2950							X		

Table 10-1. Availability of RACs on Specific Dell Systems (continued)

Dell System	DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4	DRAC/MC	DRAC 5	iDRAC	iDRAC6
2970							X		
4600	X								
6600	X								
6650	X								
6800					X				
6850					X				
6950							X		
R200					X				
T300							X		
R300							X		
M600								X	
M605								X	
T605							X		
R805							X		
R900							X		
R905							X		
T100							X		
M805								X	
M905								X	
PowerVault DL2000							X		
PowerVault NX1950							X		
PowerVault NX3000									X
PowerVault 100							X		

Table 10-1. Availability of RACs on Specific Dell Systems (continued)

Dell System	DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4	DRAC/MC	DRAC 5	iDRAC	iDRAC6
PowerVault 500							X		
PowerVault 600							X		
R610									X
R710									X
T610									X
M610									X
M710									X
R410									X
T410									X
T710									X

RAC Firmware Versions

Table 10-2 shows the firmware version required for each RAC that is offered on the corresponding Dell OpenManage media.

Table 10-2. RAC Firmware Version by Dell OpenManage Media Version

Dell OpenManage Media Version	Firmware Version				
	DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4
3.0	1.10	NA	NA	NA	NA
3.0.1	1.10	NA	NA	NA	NA
3.0.2	1.10	1.05	NA	NA	NA
3.1	1.20	1.05	1.10	NA	NA
3.1.1	1.20	1.05	1.20	NA	NA
3.2	1.30	1.07	1.20	NA	NA
3.2.2	1.30	1.07	1.20	1.30	NA

Table 10-2. RAC Firmware Version by Dell OpenManage Media Version (continued)

Dell OpenManage Media Version	Firmware Version				
	DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4
NA	NA	1.21	NA	NA	NA
3.3	2.0	2.0	2.0	2.0	NA
3.4	2.2	2.2	2.2	2.2	NA
3.5	2.5	2.5	2.5	2.5	NA
3.6	3.0	3.0	3.0	3.0	NA
3.7	3.10	3.10	3.10	3.10	NA
3.8	3.12	3.12	3.12	3.12	NA
4.0.1	NA	NA	NA	NA	1.0
4.1	3.14	3.14	3.14	3.14	1.0
4.1.1	NA	NA	NA	NA	1.0
4.1.2	NA	NA	NA	NA	1.0
4.1.3	NA	NA	NA	NA	1.0
4.1.4	NA	NA	NA	NA	NA
4.2	3.20	3.20	3.20	3.20	1.1

Table 10-3 shows the firmware version required for each RAC that is offered on the corresponding *Dell PowerEdge Server Update Utility* CD or *Dell Systems Management Tools and Documentation* DVD.

Table 10-3. RAC Firmware Version by Server Update Utility Media Version

Dell OpenManage Version	Server Update Utility Media Version	Firmware Version								
		DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4	DRAC/ MC	DRAC 5	iDRAC 6	iDRAC 6
4.3	1.0	3.2.1	3.20	3.20	3.20	1.2	1.1.0	NA	NA	NA
4.4	1.1	3.3.0	3.3.0	3.3.0	3.3.0	1.30	1.1.1	NA	NA	NA
4.5	1.2	3.3.0	3.3.0	3.3.0	3.3.0	1.30	1.2.0	NA	NA	NA
5.0	1.3	3.35	3.35	3.35	3.35	1.35	1.3	1.0	NA	NA

Table 10-3. RAC Firmware Version by Server Update Utility Media Version (continued)

Dell OpenManage Version	Server Update Utility Media Version	Firmware Version								
		DRAC III	ERA	ERA/O	DRAC III/XT	DRAC 4	DRAC/ MC	DRAC 5	iDRAC	iDRAC 6
5.1	1.4	3.35	3.35	3.35	3.35	1.35	1.3	1.0	NA	NA
5.1.1	1.5	NA	NA	NA	NA	NA	NA	1.0	NA	NA
5.2	1.5	3.35	3.35	3.35	3.35	1.50	1.4	1.20	NA	NA
5.3	1.6	3.3.5	3.3.5	3.3.5	3.3.5	1.6	1.5	1.30	1.0	NA
5.4	1.7	3.3.8	3.3.5	3.3.5	3.3.5	1.6.1	1.5	1.3.3	1.0	NA
5.5	1.8.1	3.38	3.38	3.38	3.38	1.61	1.5	1.40	1.2	NA
6.0.1	1.8.2	NA	NA	NA	NA	NA	NA	NA	NA	1.0
6.1	1.8.2	3.38	3.38	3.38	3.38	1.75	1.5	1.48	1.2	1.10

Historical Release Information for Legacy Systems

Overview

The following sections contain historical information about releases of the Dell™ OpenManage™ Server Agent running on supported Microsoft® Windows®, Red Hat® Enterprise Linux®, and Novell® NetWare® operating systems. The following excerpts from previous **readme.txt** files show a record of features and resolved issues for releases of Server Agent only. For the complete text of **readme.txt** files, see the Dell Support website at support.dell.com.

You can find additional information on more recent systems management applications in the Server Administrator **readme.txt** found on the *Systems Management* CDs, version 3.0 or later.

Server Agent 4.5

The following subsections contain requirements, features, and open issues for Server Agent version 4.5.

Release date: October 2001

Requirements

Supported systems: Dell PowerEdge™ 1500SC

Operating Systems

- Microsoft Windows NT® Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 5.x
- Red Hat Linux® 7.1



NOTE: Server Agent is not supported on a PowerEdge 1500SC system running either the Red Hat Linux 7.0 operating system or the Novell NetWare 4.x operating system.

New in Server Agent Version 4.5

Support was added for the PowerEdge 1500SC system.

Server Agent 4.4.1

The following subsections contain requirements, features, and open issues for Server Agent version 4.4.1.

Release date: September 2001

Requirements

Supported systems: Dell PowerEdge 300, 350, 500SC, 1300, 1400, 1550, 2300, 2400, 2450, 2500, 2550, 4300, 4350, 4400, 6300, 6350, 6400, 6450, and 8450

Operating Systems

- Microsoft Windows NT Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 4.x or 5.x
- Red Hat Linux 7.0



NOTE: Server Agent is not supported on a PowerEdge 500SC system running the Red Hat Linux 7.0 operating system.

New in Server Agent Version 4.4.1

This release contains the following new features and changes:

- Support for Red Hat Linux 7.1 SBE (Kernels 2.4.3-6 and 2.4.3-12) with prebuilt device drivers
- Dynamic Kernel Support for Red Hat Linux
- Removal of support for the DMI management protocol
- In the Server Agent MIB file **10892.mib**, replacement of "Dell" by "Server" in the annotation TYPE field for each trap
- In the Server Agent event configuration file **10892evt.cfg**, the changing of the OID_ALIAS value from "Dell_Server3_Baseboard_Agent" to "Server_Agent," and replacement of "Dell" by "Server" in the **Short Descr** field for each event

Server Agent 4.4.0

The following subsections contain requirements, features, and open issues for Server Agent version 4.4.0.

Release date: July 2001

Requirements

Supported systems: Dell PowerEdge 350, 500SC, and 1550

Operating Systems

- Microsoft Windows NT Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 4.x or 5.x
- Red Hat Linux 7.0; Kernel version: 2.2.16; Red Hat Linux SNMP agent: ucd-snmp version 4.1.2-8smux

New in Server Agent Version 4.4.0

This release adds support for the following Dell systems and features:

- PowerEdge 500SC
- PowerEdge 1550 with the Intel® Pentium® III microprocessor
- PowerEdge 350 watchdog support

Server Agent 4.3.0

Version 4.3.0 is the first release of Server Agent that combines supported operating systems for Microsoft Windows, Novell NetWare, and Red Hat Linux. All of these supported operating systems are documented in this [readme.txt](#) file.

Release date: March 2001

Requirements

Supported systems: Dell PowerEdge 300, 350, 1300, 1400, 1550, 2300, 2400, 2450, 2500, 2550, 4300, 4350, 4400, 6300, 6350, 6400, 6450, and 8450

Operating Systems

- Microsoft Windows NT Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 4.x or 5.x
- Red Hat Linux 7.0; Kernel version: 2.2.16; Red Hat Linux SNMP agent: ucd-snmp version 4.1.2-8smux

New in Server Agent Version 4.3.0

This release adds support for the following Dell systems:

- PowerEdge 2500
- PowerEdge 2550

Server Agent 4.3.0 Resolved Issues

- Hung server alerts for PowerEdge 8450 systems
When you configure the hung server action for a Dell PowerEdge 8450 system, the system either performs a system reset or a recycle system power action.
- PowerEdge 350 issues

This release addressed the following Dell PowerEdge 350 issues that were originally addressed by Dell OpenManage Server Agent 4.2.0 Update 1:

- Changes thresholds for the -12 volt (V) voltage probe on the system board. These new thresholds prevent erroneous probe failures and warnings.
- Corrects erroneous fan failure reports in the event log.
- Corrects system crashes at start-up caused by incorrect event log record length.
- Disables the chassis identification feature.

- Dell PowerVault™ 2xxS SCSI disk systems and SNMP

This release addresses the following PowerVault 2xxS SCSI disk system issue that was originally addressed by Server Agent 4.2.0 Update 1:

- Allows Dell PowerEdge systems attached to the PowerVault 2xxS SCSI disk system to respond to SNMP requests for information. Under certain rare circumstances, some Dell systems with PowerVault 2xxS attached were not responding to SNMP requests.

Server Agent 4.2.2

The following subsections contain requirements, features, and open issues for Server Agent version 4.2.2.

Release date: February 2001

Requirements

Supported systems: Dell PowerEdge 300, 350, 1300, 1400, 1550, 2300, 2400, 2450, 4300, 4350, 4400, 6300, 6350, 6400, 6450, and 8450

Operating Systems

- Microsoft Windows NT Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 4.x or 5.x

New and Resolved Issues in Server Agent Version 4.2.2

Dell OpenManage Server Agent 4.2.2 now supports the Dell PowerEdge 350 system. In addition, Dell OpenManage Server Agent 4.2.2 resolves the following issues:

- Incorrect current sensor data
 - In rare circumstances, Dell OpenManage Server Agent incorrectly reported data for current (amperage) sensors. Incorrect amperage readings may have been reported for the following PowerEdge systems: 4300, 4350, 4400, 6300, 6350, 6400, and 6450.
- SNMP time-outs with PowerVault 2xxS SCSI disk systems
 - In rare circumstances, the Dell OpenManage Server Agent SNMP interface stops responding when a Dell PowerVault 2xxS storage system is attached to a system. The DMI and CIM interfaces may also stop responding.

Server Agent 4.2.1

The following subsections contain requirements, features, and open issues for Server Agent version 4.2.1.

Release date: December 2000

Requirements

Supported systems: Dell PowerEdge 1300, 1400, 1550, 2300, 2400, 2450, 4300, 4350, 4400, 6300, 6350, 6400, 6450, and 8450

Operating Systems

- Microsoft Windows NT Server 4.x with SP 4 or later
- Microsoft Windows 2000 Server family (includes Windows 2000 Server and Windows 2000 Advanced Server)
- Novell NetWare 4.x or 5.x

New in Server Agent Version 4.2.1

Added support for PowerEdge 1550 system

Resolved Issues for Server Agent Version 4.2.1

Table 11-1. Resolved Issues for Server Agent Version 4.2.1

Problem	Solution
IT Assistant is unable to perform a remote flash BIOS update for the PowerEdge 300 system.	Server Agent 4.2.1 enables IT Assistant to perform a remote flash BIOS update for the PowerEdge 300 system.
Server Agent reports an error message that values are incorrect for CPU voltage threshold values for the PowerEdge 8450 system on systems with a CPU speed of 700 MHz and higher.	Server Agent 4.2.1 reports correct CPU voltage threshold values.
Server Agent 4.0 did not implement the %6 alert parameter correctly in the local response agent.	Server Agent 4.2.1 correctly parses the %ALERT parameter. The %ALERT parameter can now be located anywhere in the command line and can optionally be enclosed in double quotes when the user wants to pass the alert message to the command line as a single string.

Table 11-1. Resolved Issues for Server Agent Version 4.2.1 (continued)

Problem	Solution
Intermittent incorrect fan probe readings of zero RPMs cause faulty alerts to be generated. Invalid fan probe readings also compromise the usability of Server Agent.	Server Agent 4.2.1 prevents false alerts for fan probes based on incorrect readings of fan RPM values. This update also addresses usability issues caused by these incorrect fan RPM values. The incorrect fan RPM readings originate on PowerEdge systems that report systems management information to the management console using Server Agent version 4.0.
Seven-character service tags display incorrectly.	Formerly, certain combinations of characters and numbers in the seven-character service tag either did not display correctly or did not display at all. Server Agent 4.2.1 displays service tags correctly.
False power supply fan readings. Server Agent reports high power supply fan RPM readings. The readings exceed the upper failure threshold and are reported as failures.	Server Agent 4.2.1 corrects the problem of false fan probe alerts.

Server Agent 4.2.0

The following subsections contain requirements, and features for Server Agent version 4.2.0.

Release date: December 2000

Requirements

Supported systems: Dell PowerEdge 300, 1300, 1400, 1550, 2300, 2400, 2450, 4300, 4350, 4400, 6300, 6350, 6400, 6450, and 8450

Operating Systems

Red Hat Linux 7.0 (Kernel version: 2.2.16), Red Hat Linux SNMP agent: ucd-snmp version 4.1.2-8smux or later

Glossary

The following list defines or identifies technical terms, abbreviations, and acronyms used in your system documents.

A

Abbreviation for ampere(s).

AC

Abbreviation for alternating current.

AC power switch

A switch with two AC power inputs that provides AC power redundancy by failing over to a standby AC input in the event of a failure to the primary AC input.

access

Refers to the actions a user can take on a variable value. Examples include read-only and read-write.

ACL

Abbreviation for access control list. ACL files are text files that contain lists that define who can access resources stored on a Novell® Web server.

adapter card

An expansion card that plugs into an expansion-card connector on the system's system board. An adapter card adds some specialized function to the system by providing an interface between the expansion bus and a peripheral device. Examples of adapter cards include network cards, sound cards, and SCSI adapters.

ADB

Abbreviation for assign database.

AGP

Abbreviation for advanced graphics port.

ASCII

Acronym for American Standard Code for Information Interchange. A text file containing only characters from the ASCII character set (usually created with a text editor, such as Notepad in Microsoft® Windows®), is called an ASCII file.

ASIC

Acronym for application-specific integrated circuit.

ASPI

Acronym for advanced SCSI programming interface.

asset tag code

An individual code assigned to a system, usually by a system administrator, for security or tracking purposes.

attribute

An attribute, or property, contains a specific piece of information about a manageable component. Attributes can be combined to form groups. If an attribute is defined as read-write, it may be defined by a management application.

autoexec.bat file

The **autoexec.bat** file is executed when you boot your system (after executing any commands in the **config.sys** file). This start-up file contains commands that define the characteristics of each device connected to your system, and it finds and executes programs stored in locations other than the active directory.

backup

A copy of a program or data file. As a precaution, you should back up your system's hard drive on a regular basis. Before making a change to the configuration of your system, you should back up important start-up files from your operating system.

baud rate

A measurement of data transmission speed. For example, modems are designed to transmit data at one or more specified baud rate(s) through the COM (serial) port of a system.

beep code

A diagnostic message in the form of a pattern of beeps from your system's speaker. For example, one beep, followed by a second beep, and then a burst of three beeps is beep code 1-1-3.

BGA

Abbreviation for ball grid array, an integrated circuit (IC) package that uses an array of solder balls, instead of pins, to connect to a system board.

binary

A base-2 numbering system that uses 0 and 1 to represent information. The system performs operations based on the ordering and calculation of these numbers.

BIOS

Acronym for basic input/output system. Your system's BIOS contains programs stored on a flash memory chip. The BIOS controls the following:

- Communications between the microprocessor and peripheral devices, such as the keyboard and the video adapter
- Miscellaneous functions, such as system messages

bit

The smallest unit of information interpreted by your system.

BMC

Abbreviation for baseboard management controller, which is a controller that provides the intelligence in the IPMI structure.

boot routine

When you start your system, it clears all memory, initializes devices, and loads the operating system. Unless the operating system fails to respond, you can reboot (also called warm boot) your system by pressing <Ctrl><Alt>; otherwise, you must perform a cold boot by pressing the reset button or by turning the system off and then back on.

bootable diskette

You can start your system from a diskette. To make a bootable diskette, insert a diskette in the diskette drive, type `sys a:` at the command line prompt, and press <Enter>. Use this bootable diskette if your system will not boot from the hard drive.

bpi

Abbreviation for bits per inch.

bps

Abbreviation for bits per second.

BTU

Abbreviation for British thermal unit.

bus

An information pathway between the components of a system. Your system contains an expansion bus that allows the microprocessor to communicate with controllers for all the various peripheral devices connected to the system. Your system also contains an address bus and a data bus for communications between the microprocessor and RAM.

byte

Eight contiguous bits of information, the basic data unit used by your system.

C

Abbreviation for Celsius.

CA

Abbreviation for certification authority.

cache

A fast storage area that keeps a copy of data or instructions for quicker data retrieval. For example, your system's BIOS may cache ROM code in faster RAM. Or, a disk-cache utility may reserve RAM in which to store frequently accessed information from your system's disk drives; when a program makes a request to a disk drive for data that is in the cache, the disk-cache utility can retrieve the data from RAM faster than from the disk drive.

capability

Refers to the actions that an object can perform, or actions that can be taken on a managed object. For example, if a card is hot-pluggable, it is capable of being replaced while the system power is on.

CDRAM

Abbreviation for cached DRAM, which is a high-speed DRAM memory chip developed by Mitsubishi that includes a small SRAM cache.

CD-ROM

Abbreviation for compact disc read-only memory. CD drives use optical technology to read data from CDs. CDs are read-only storage devices; you cannot write new data to a CD with standard CD drives.

CHAP

Acronym for Challenge-Handshake Authentication Protocol, an authentication scheme used by PPP servers to validate the identity of the originator of the connection upon connection or any time later.

chip

A set of microminiaturized, electronic circuits that are designed for use as processors and memory in systems. Small chips can hold from a handful to tens of thousands of transistors. They look like tiny chips of aluminum, no more than 1/16 inch square by 1/30 inch thick, which is where the term "chip" came from. Large chips, which can be more than a half inch square, hold millions of transistors. It is actually only the top one thousandth of an inch of a chip's surface that holds the circuits. The rest of it is just a base.

CIM

Acronym for Common Information Model, which is a model for describing management information from the DMTF. CIM is implementation independent, allowing different management applications to collect the required data from a variety of sources. CIM includes schemas for systems, networks, applications and devices, and new schemas will be added. It provides mapping techniques for interchange of CIM data with MIB data from SNMP agents.

CIMOM

Acronym for common information model object manager.

CI/O

Abbreviation for comprehensive input/output.

CLI

Abbreviation for command line interface.

cm

Abbreviation for centimeter(s).

CMOS

Acronym for complementary metal-oxide semiconductor. In systems, CMOS memory chips are often used for NVRAM storage.

COM n

The device names for the first through fourth serial ports on your system are COM1, COM2, COM3, and COM4. The default interrupt for COM1 and COM3 is IRQ4, and the default interrupt for COM2 and COM4 is IRQ3. Therefore, you must be careful when configuring software that runs a serial device so that you don't create an interrupt conflict.

config.sys file

The `config.sys` file is executed when you boot your system (before running any commands in the `autoexec.bat` file). This start-up file contains commands that specify which devices to install and which drivers to use. This file also contains commands that determine how the operating system uses memory and controls files.

ConsoleOne[®]

Novell[®] ConsoleOne is a Java-based foundation for graphical utilities that manage and administer network resources from different locations and platforms. ConsoleOne provides a single point of control for all Novell and external products.

controller

A chip that controls the transfer of data between the microprocessor and memory or between the microprocessor and a peripheral device such as a disk drive or the keyboard.

control panel

The part of the system that contains indicators and controls, such as the power switch, hard drive access indicator, and power indicator.

conventional memory

The first 640 KB of RAM. Conventional memory is found in all systems. Unless they are specially designed, MS-DOS[®] programs are limited to running in conventional memory.

COO

Abbreviation for cost of ownership.

cooling unit

Sets of fans or other cooling devices in a system chassis.

coprocessor

A chip that relieves the system's microprocessor of specific processing tasks. A math coprocessor, for example, handles numeric processing. A graphics coprocessor handles video rendering.

cpi

Abbreviation for characters per inch.

CPU

Abbreviation for central processing unit. See also microprocessor.

CRC

Abbreviation for cyclic redundancy code, which is a number derived from, and stored or transmitted with, a block of data in order to detect corruption. By recalculating the CRC and comparing it to the value originally transmitted, the receiver can detect some types of transmission errors.

CSR

Abbreviation for certificate signing request.

cursor

A marker, such as a block, underscore, or pointer that represents the position at which the next keyboard or mouse action will occur.

DAT

Acronym for digital audio tape.

dB

Abbreviation for decibel(s).

dBA

Abbreviation for adjusted decibel(s).

DBS

Abbreviation for Demand Based Switching. DBS is power management performed by switching to a low power state (frequency and voltage) when the processor utilization is low. It maintains application performance while lowering the average system power.

DC

Abbreviation for direct current.

Also, abbreviation for Dual Channel.

device driver

A program that allows the operating system or some other program to interface correctly with a peripheral device, such as a printer. Some device drivers—such as network drivers—must be loaded from the `config.sys` file (with a `device=` statement) or as memory-resident programs (usually, from the `autoexec.bat` file). Others—such as video drivers—must load when you start the program for which they were designed.

DHCP

Abbreviation for Dynamic Host Configuration Protocol, a protocol that provides a means to dynamically allocate IP addresses to computers on a LAN.

DIMM

Acronym for dual in-line memory module. A small circuit board containing DRAM chips that connects to the system board.

DIN

Acronym for Deutsche Industrie Norm which is the standards-setting organization for Germany. A DIN connector is a connector that conforms to one of the many standards defined by DIN. DIN connectors are used widely in personal computers. For example, the keyboard connector for personal computers is a DIN connector.

DIP

Acronym for dual in-line package. A circuit board, such as a system board or expansion card, may contain DIP switches for configuring the circuit board. DIP switches are always toggle switches, with an on position and an off position.

directory

Directories help keep related files organized on a disk in a hierarchical, "inverted tree" structure. Each disk has a "root" directory; for example, a `C:\>` prompt normally indicates that you are at the root directory of hard drive C. Additional directories that branch off of the root directory are called subdirectories. Subdirectories may contain additional directories branching off of them.

display adapter

See "video adapter."

DKS

Abbreviation for dynamic kernel support.

DMA

Abbreviation for direct memory access. A DMA channel allows certain types of data transfer between RAM and a device to bypass the microprocessor.

DMTF

Abbreviation for Distributed Management Task Force, a consortium of companies representing hardware and software providers.

dpi

Abbreviation for dots per inch.

DPMS

Abbreviation for Display Power Management Signaling. A standard developed by the Video Electronics Standards Association (VESA[®]) that defines the hardware signals sent by a video controller to activate power management states in a monitor. A monitor is said to be DPMS-compliant when it is designed to enter a power management state after receiving the appropriate signal from a system's video controller.

DRAC

Acronym for Dell™ Remote Access Controller.

DRAM

Acronym for dynamic random-access memory. A system's RAM is usually made up entirely of DRAM chips. Because DRAM chips cannot store an electrical charge indefinitely, your system continually refreshes each DRAM chip in the system.

DRMK

Acronym for Dell Real Mode Kernel.

drive-type number

Your system can recognize a number of specific hard drives. Each is assigned a drive-type number that is stored in NVRAM. The hard drive(s) specified in your system's System Setup program must match the actual drive(s) installed in the system. The System Setup program also allows you to specify physical parameters (logical cylinders, logical heads, cylinder number, and logical sectors per pack) for drives not included in the table of drive types stored in NVRAM.

DTE

Abbreviation for data terminal equipment. Any device, such as a computer system, that can send data in digital form by means of a cable or communications line. The DTE is connected to the cable or communications line through a data communications equipment (DCE) device, such as a modem.

ECC

Abbreviation for error checking and correction.

ECP

Abbreviation for Extended Capabilities Port.

EDO

Acronym for extended data output dynamic random access memory which is a type of DRAM that is faster than conventional DRAM. EDO RAM can start fetching the next block of memory at the same time that it sends the previous block to the microprocessor.

EEPROM

Acronym for electrically erasable programmable read-only memory.

EIDE

Abbreviation for enhanced integrated drive electronics. EIDE devices add one or more of the following enhancements to the traditional IDE standard:

- Data transfer rates of up to 16 MB/sec
- Support for drives other than just hard drives, such as CD and tape drives
- Support for hard drives with capacities greater than 528 MB
- Support for up to two controllers, each with up to two devices attached

EISA

Acronym for Extended Industry-Standard Architecture, a 32-bit expansion-bus design. The expansion-card connectors in an EISA system are also compatible with 8- or 16-bit ISA expansion cards.

To avoid a configuration conflict when installing an EISA expansion card, you must use the EISA Configuration Utility. This utility allows you to specify which expansion slot contains the card and obtains information about the card's required system resources from a corresponding EISA configuration file.

EMC

Abbreviation for electromagnetic compatibility.

EMI

Abbreviation for electromagnetic interference.

EMM

Abbreviation for expanded memory manager. A utility that uses extended memory to emulate expanded memory on systems with an x86 or higher microprocessor.

EMS

Abbreviation for Expanded Memory Specification.

EPP

Abbreviation for Enhanced Parallel Port which provides improved bidirectional data transmission. Many devices are designed to take advantage of the EPP standard, especially devices, such as network or SCSI adapters that connect to the parallel port of a portable computer.

EPROM

Acronym for erasable programmable read-only memory.

ERA

Abbreviation for embedded remote access.

ERA/MC

Abbreviation for embedded remote access modular computer. See modular system.

ERA/O

Abbreviation for embedded remote access option.

ESD

Abbreviation for electrostatic discharge.

ESM

Abbreviation for embedded systems management.

expanded memory

A technique for accessing RAM above 1 MB. To enable expanded memory on your system, you must use an EMM. You should configure your system to support expanded memory only if you run application programs that can use (or require) expanded memory.

expansion bus

Your system contains an expansion bus that allows the microprocessor to communicate with controllers for peripheral devices, such as a network card or an internal modem.

expansion-card connector

A connector on the system's system board or riser board for plugging in an expansion card.

extended memory

RAM above 1 MB. Most software that can use it, such as the Windows operating system, requires that extended memory be under the control of an XMM.

external cache memory

A RAM cache using SRAM chips. Because SRAM chips operate at several times the speed of DRAM chips, the microprocessor can retrieve data and instructions faster from external cache memory than from RAM.

F

Abbreviation for Fahrenheit.

FAT

Acronym for file allocation table. FAT and FAT32 are file systems that are defined as follows:

- **FAT** — A file system used by MS-DOS, Windows 3.x, Windows 95, and Windows 98. Windows NT[®] and Windows 2000 also can use the FAT file system. The operating system maintains a table to keep track of the status of various segments of disk space used for file storage.
- **FAT32** — A derivative of the FAT file system. FAT32 supports smaller cluster sizes than FAT, thus providing more efficient space allocation on FAT32 drives.

FCC

Abbreviation for Federal Communications Commission.

FEPROM

Acronym for flash erasable programmable read-only memory. Flash memory is a kind of nonvolatile storage device similar to EEPROM, but the erasing is done only in blocks or the entire chip.

Fibre Channel

A data transfer interface technology that allows for high-speed I/O and networking functionality in a single connectivity technology. The Fibre Channel Standard supports several topologies, including Fibre Channel Point-to-Point, Fibre Channel Fabric (generic switching topology), and Fibre Channel Arbitrated Loop (FC_AL).

firmware

Software (programs or data) that has been written onto read-only memory (ROM). Firmware can boot and operate a device. Each controller contains firmware which helps provide the controller's functionality.

flash bios

A BIOS that is stored in flash memory rather than in ROM. A flash BIOS chip can be updated in place, whereas a ROM BIOS must be replaced with a newer chip.

flash memory

A type of EEPROM chip that can be reprogrammed from a utility on diskette while still installed in a system; most EEPROM chips can only be rewritten with special programming equipment.

format

To prepare a hard drive or diskette for storing files. An unconditional format deletes all data stored on the disk.

FPBGA

Abbreviation for field programmable gate array, a programmable logic chip (PLD) with a high density of gates.

FRU

Abbreviation for field replaceable unit.

ft

Abbreviation for feet.

FTP

Abbreviation for file transfer protocol.

g

Abbreviation for gram(s).

G

Abbreviation for gravities.

GB

Abbreviation for gigabyte(s). A gigabyte equals 1024 megabytes or 1,073,741,824 bytes.

gcc

Abbreviation for gnu C compiler.

graphics coprocessor

See coprocessor.

graphics mode

A video mode that can be defined as x horizontal by y vertical pixels by z colors.

GUI

Acronym for graphical user interface.

h

Abbreviation for hexadecimal. A base-16 numbering system, often used in programming to identify addresses in the system's RAM and I/O memory addresses for devices. The sequence of decimal numbers from 0 through 16, for example, is expressed in hexadecimal notation as: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, F, 10. In text, hexadecimal numbers are often followed by h.

HBA

Abbreviation for host bus adapter. A PCI adapter card that resides in the system whose only function is to convert data commands from PCI-bus format to storage interconnect format (examples: SCSI, Fibre Channel) and communicate directly with hard drives, tape drives, CD drives, or other storage devices.

heat sink

A metal plate with metal pegs or ribs that help dissipate heat. Most microprocessors include a heat sink.

HMA

Abbreviation for high memory area. The first 64 KB of extended memory above 1 MB. A memory manager that conforms to the XMS can make the HMA a direct extension of conventional memory. Also see XMM.

host adapter

A host adapter implements communication between the system's bus and the controller for a peripheral device. (hard drive controller subsystems include integrated host adapter circuitry.) To add a SCSI expansion bus to your system, you must install or connect the appropriate host adapter.

hot plug

The ability to remove and replace a redundant part while the system is still running. Also called a "hot spare."

HPFS

Abbreviation for the High Performance File System option in the Windows NT operating systems.

HTTP

Abbreviation for Hypertext Transfer Protocol. HTTP is the client-server TCP/IP protocol used on the World Wide Web for the exchange of HTML documents.

HTTPS

Abbreviation for HyperText Transmission Protocol, Secure. HTTPS is a variant of HTTP used by Web browsers for handling secure transactions. HTTPS is a unique protocol that is simply SSL underneath HTTP. You need to use "https://" for HTTP URLs with SSL, whereas you continue to use "http://" for HTTP URLs without SSL.

Hz

Abbreviation for hertz.

ICES

Abbreviation for Interface-Causing Equipment Standard (in Canada).

ICMP

Abbreviation for Internet Control Message Protocol. ICMP is a TCP/IP protocol used to send error and control messages.

ICU

Abbreviation for ISA Configuration Utility.

ID

Abbreviation for identification.

IDE

Abbreviation for Integrated Drive Electronics. IDE is a computer system interface, used primarily for hard drives and CDs.

I/O

Abbreviation for input/output. The keyboard is an input device, and a printer is an output device. In general, I/O activity can be differentiated from computational activity. For example, when a program sends a document to the printer, it is engaging in output activity; when the program sorts a list of terms, it is engaging in computational activity.

IHV

Abbreviation for independent hardware vendor. IHVs often develop their own MIBs for components that they manufacture.

interlacing

A technique for increasing video resolution by only updating alternate horizontal lines on the screen. Because interlacing can result in noticeable screen flicker, most users prefer noninterlaced video adapter resolutions.

internal microprocessor cache

An instruction and data cache built in to the microprocessor.

IP address

Abbreviation for Internet Protocol address. See TCP/IP.

IPMI

Abbreviation for Intelligent Platform Management Interface, which is an industry standard for management of peripherals used in enterprise computers based on Intel architecture. The key characteristic of IPMI is that inventory, monitoring, logging, and recovery control functions are available independent of the main processors, BIOS, and operating system.

IPX

Abbreviation for internetwork packet exchange.

IRQ

Abbreviation for interrupt request. A signal that data is about to be sent to or received by a peripheral device travels by an **IRQ** line to the microprocessor. Each peripheral connection must be assigned an **IRQ** number. For example, the first serial port in your system (COM1) is assigned to **IRQ4** by default. Two devices can share the same **IRQ** assignment, but you cannot operate both devices simultaneously.

ISA

Acronym for Industry-Standard Architecture. A 16-bit expansion bus design. The expansion-card connectors in an ISA system are also compatible with 8-bit ISA expansion cards.

ISV

Abbreviation for independent software vendor.

ITE

Abbreviation for information technology equipment.

Java

A cross-platform programming language developed by Sun Microsystems.

JSSE

Abbreviation for Java Secure Socket Extension.

jumper

Jumpers are small blocks on a circuit board with two or more pins emerging from them. Plastic plugs containing a wire fit down over the pins. The wire connects the pins and creates a circuit. Jumpers provide a simple and reversible method of changing the circuitry in a printed circuit board.

K

Abbreviation for kilo-, indicating 1000.

KB

Abbreviation for kilobyte(s), 1024 bytes.

KB/sec

Abbreviation for kilobyte(s) per second.

Kbit(s)

Abbreviation for kilobit(s), 1024 bits.

Kbit(s)/sec

Abbreviation for kilobit(s) per second.

key combination

A command requiring you to press multiple keys at the same time. For example, you can reboot your system by pressing the <Ctrl><Alt> key combination.

kg

Abbreviation for kilogram(s), 1000 grams.

kHz

Abbreviation for kilohertz, 1000 hertz.

LAN

Acronym for local area network. A LAN system is usually confined to the same building or a few nearby buildings, with all equipment linked by wiring dedicated specifically to the LAN.

lb

Abbreviation for pound(s).

LCC

Abbreviation for leaded or leadless chip carrier.

LIF

Acronym for low insertion force. Some systems use LIF sockets and connectors to allow devices, such as the microprocessor chip, to be installed or removed with minimal stress to the device.

LED

Abbreviation for light-emitting diode. An electronic device that lights up when a current is passed through it.

local bus

On a system with local-bus expansion capability, certain peripheral devices (such as the video adapter circuitry) can be designed to run much faster than they would with a traditional expansion bus. Some local-bus designs allow peripherals to run at the same speed and with the same width data path as the system's microprocessor.

LPT*n*

The device names for the first through third parallel printer ports on your system are LPT1, LPT2, and LPT3.

LRA

Abbreviation for local response agent.

m

Abbreviation for meter(s).

mA

Abbreviation for milliamper(e)s.

mAh

Abbreviation for milliamper(e)-hour(s).

managed system

A managed system is any system that is monitored and managed using Server Administrator. Systems running Server Administrator can be managed locally or remotely through a supported Web browser. See remote management system.

math coprocessor

See coprocessor.

Mb

Abbreviation for megabit.

MB

Abbreviation for megabyte(s). The term megabyte means 1,048,576 bytes; however, when referring to hard drive storage, the term is often rounded to mean 1,000,000 bytes.

MB/sec

Abbreviation for megabytes per second.

Mbps

Abbreviation for megabits per second.

MBR

Abbreviation for master boot record.

MCA

Abbreviation for Micro Channel Architecture, which is designed for multiprocessing. MCA eliminates potential conflicts that arise when installing new peripheral devices. MCA is not compatible with either EISA or XT bus architecture, so older cards cannot be used with it.

memory

A system can contain several different forms of memory, such as RAM, ROM, and video memory. Frequently, the word memory is used as a synonym for RAM; for example, an unqualified statement such as "a system with 16 MB of memory" refers to a system with 16 MB of RAM.

memory address

A specific location, usually expressed as a hexadecimal number, in the system's RAM.

memory manager

A utility that controls the implementation of memory in addition to conventional memory, such as extended or expanded memory.

memory module

A small circuit board containing DRAM chips that connects to the system board.

MHz

Abbreviation for megahertz.

MIB

Acronym for management information base. The MIB is used to send detailed status/commands from or to an SNMP managed device.

microprocessor

The primary computational chip inside the system that controls the interpretation and execution of arithmetic and logic functions. Software written for one microprocessor must usually be revised to run on another microprocessor. CPU is a synonym for microprocessor.

MIDI

Acronym for musical instrument digital interface.

mm

Abbreviation for millimeter(s).

modem

A device that allows your system to communicate with other systems over telephone lines.

modular system

A system that can include multiple server modules. Each server module functions as an individual system. To function as a system, a server module is inserted into a chassis which includes power supplies, fans, a system management module, and at least one network switch module. The power supplies, fans, system management module, and network switch module are shared resources of the server modules in the chassis. See server module.

MOF

Acronym for managed object format, which is an ASCII file that contains the formal definition of a CIM schema.

mouse

A pointing device that controls the movement of the cursor on a screen. Mouse-aware software allows you to activate commands by clicking a mouse button while pointing at objects displayed on the screen.

MPEG

Acronym for Motion Picture Experts Group. MPEG is a digital video file format.

ms

Abbreviation for millisecond(s).

MS-DOS

Acronym for Microsoft Disk Operating System.

MTBF

Abbreviation for mean time between failures.

multifrequency monitor

A monitor that supports several video standards. A multifrequency monitor can adjust to the frequency range of the signal from a variety of video adapters.

mV

Abbreviation for millivolt(s).

name

The name of an object or variable is the exact string that identifies it in an SNMP Management Information Base (MIB) file or in a CIM Management Object File (MOF).

NDIS

Abbreviation for Network Driver Interface Specification.

NIC

Acronym for network interface controller.

NIF

Acronym for network interface function. This term is equivalent to NIC.

NMI

Abbreviation for nonmaskable interrupt. A device sends an NMI to signal the microprocessor about hardware errors, such as a parity error.

noninterlaced

A technique for decreasing screen flicker by sequentially refreshing each horizontal line on the screen.

ns

Abbreviation for nanosecond(s), one billionth of a second.

NTFS

Abbreviation for the Windows NT File System option in the Windows NT operating system. NTFS is an advanced file system designed for use specifically within the Windows NT operating system. It supports file system recovery, extremely large storage media, and long file names. It also supports object-oriented applications by treating all files as objects with user-defined and system-defined attributes. See also FAT and FAT32.

NTLM

Abbreviation for Windows NT LAN Manager. NTLM is the security protocol for the Windows NT operating system.

NuBus

Proprietary expansion bus used on Apple® Macintosh® personal computers.

NVRAM

Acronym for nonvolatile random-access memory. Memory that does not lose its contents when you turn off your system. NVRAM is used for maintaining the date, time, and system configuration information.

OID

Abbreviation for object identifier. An implementation-specific integer or pointer that uniquely identifies an object.

online access service

A service that typically provides access to the Internet, e-mail, bulletin boards, chat rooms, and file libraries.

OTP

Abbreviation for one-time programmable.

PAM

Acronym for Pluggable Authentication Modules. PAM allows system administrators to set an authentication policy without having to recompile authentication programs.

parallel port

An I/O port used most often to connect a parallel printer to your system. You can usually identify a parallel port on your system by its 25-hole connector.

parameter

A value or option that you specify to a program. A parameter is sometimes called a switch or an argument.

partition

You can divide a hard drive into multiple physical sections called partitions with the fdisk command. Each partition can contain multiple logical drives. After partitioning the hard drive, you must format each logical drive with the format command.

PC card

A credit-card sized, removable module for portable computers standardized by PCMCIA. PC cards are also known as "PCMCIA cards." PC Cards are 16-bit devices that are used to attach modems, network adapters, sound cards, radio transceivers, solid state disks and hard disks to a portable computer. The PC Card is a "plug and play" device, which is configured automatically by the Card Services software.

PCI

Abbreviation for Peripheral Component Interconnect. The predominant 32-bit or 64-bit local-bus standard developed by Intel Corporation.

PCMCIA

Personal Computer Memory Card International Association. An international trade association that has developed standards for devices, such as modems and external hard drives, that can be plugged into portable computers.

PERC

Acronym for PowerEdge Expandable RAID controller.

peripheral device

An internal or external device—such as a printer, a disk drive, or a keyboard—connected to a system.

PGA

Abbreviation for pin grid array, a type of microprocessor socket that allows you to remove the microprocessor chip.

physical memory array

The physical memory array is the entire physical memory of a system. Variables for physical memory array include maximum size, total number of memory slots on the motherboard, and total number of slots in use.

physical memory array mapped

The physical memory array mapped refers to the way physical memory is divided. For example, one mapped area may have 640 KB and the other mapped area may have between 1 MB and 127 MB.

PIC

Acronym for programmable interrupt controller.

PIP

Acronym for peripheral interchange program.

pixel

A single point on a video display. Pixels are arranged in rows and columns to create an image. A video resolution, such as 640 x 480, is expressed as the number of pixels across by the number of pixels up and down.

PKCS #7

Abbreviation for Public Key Cryptography Standard #7. PKCS #7 is an RSA Data Security, Inc., standard for encapsulating signed data such as a certificate chain.

PKIS

Abbreviation for Novell Public Key Infrastructure Services.

PLCC

Abbreviation for plastic leaded chip carrier.

Plug and Play

An industry-standard specification that makes it easier to add hardware devices to personal computers. Plug and Play provides automatic installation and configuration, compatibility with existing hardware, and dynamic support of mobile computing environments.

PME

Abbreviation for Power Management Event. A PME is a pin on a peripheral component interconnect that allows a PCI device to assert a wake event.

POST

Acronym for power-on self-test. Before the operating system loads when you turn on your system, the POST tests various system components such as RAM, the disk drives, and the keyboard.

power supply

An electrical system that converts AC current from the wall outlet into the DC currents required by the system circuitry. The power supply in a personal computer typically generates multiple voltages.

power unit

A set of power supplies in a system chassis.

ppm

Abbreviation for pages per minute.

PPP

Abbreviation for Point-to-Point Protocol.

PQFP

Abbreviation for plastic quad flat pack, a type of microprocessor socket in which the microprocessor chip is permanently mounted.

program diskette set

The set of diskettes from which you can perform a complete installation of an operating system or application program. When you reconfigure a program, you often need its program diskette set.

protected mode

An operating mode supported by 80286 or higher microprocessors, protected mode allows operating systems to implement:

- A memory address space of 16 MB (80286 microprocessor) to 4 GB (x86 or higher microprocessor)
- Multitasking
- Virtual memory, a method for increasing addressable memory by using the hard drive

The Windows NT, OS/2[®], and UNIX[®] 32-bit operating systems run in protected mode. MS-DOS cannot run in protected mode; however, some programs that you can start from MS-DOS, such as the Windows operating system, are able to put the system into protected mode.

provider

A provider is an extension of a CIM schema that communicates with managed objects and accesses data and event notifications from a variety of sources. Providers forward this information to the CIM Object Manager for integration and interpretation.

PS

Abbreviation for power supply.

PS/2

Abbreviation for Personal System/2.

PXE

Abbreviation for Pre-boot eXecution Environment.

QFP

Abbreviation for quad flat pack.

RAC

Acronym for remote access controller.

RAID

Acronym for redundant array of independent drives.

RAM

Acronym for random-access memory. A system's primary temporary storage area for program instructions and data. Each location in RAM is identified by a number called a memory address. Any information stored in RAM is lost when you turn off your system.

RAMDAC

Acronym for random-access memory digital-to-analog converter.

RAW

Unprocessed. The term refers to data that is passed along to an I/O device without being interpreted. In contrast, cooked refers to data that is processed before being passed to the I/O device. It often refers to uncompressed text that is not stored in any proprietary format. The term comes from UNIX, which supports cooked and raw modes for data output to a terminal.

RBAC

Abbreviation for role-based access control.

RDRAM®

Acronym for Rambus™ DRAM®. A dynamic RAM chip technology from Rambus, Inc. Direct RDRAMs are used in systems. Direct RDRAM chips are housed in RIMM modules, which are similar to DIMMs but have different pin settings. The chips can be built with dual channels, doubling the transfer rate to 3.2 GB/sec.

read-only file

A read-only file is one that you are prohibited from editing or deleting. A file can have read-only status if:

- Its read-only attribute is enabled.
- It resides on a physically write-protected diskette or on a diskette in a write-protected drive.
- It is located on a network in a directory to which the system administrator has assigned read-only rights to you.

readme file

A text file included with a software package or hardware product that contains information supplementing or updating the documentation for the software or hardware. Typically, readme files provide installation information, describe new product enhancements or corrections that have not yet been documented, and list known problems or other things you need to be aware of as you use the software or hardware.

real mode

An operating mode supported by 80286 or higher microprocessors, real mode imitates the architecture of an 8086 microprocessor.

refresh rate

The rate at which the monitor redraws the video image on the monitor screen. More precisely, the refresh rate is the frequency, measured in Hz, at which the screen's horizontal lines are recharged (sometimes also referred to as its vertical frequency). The higher the refresh rate, the less video flicker can be seen by the human eye. The higher refresh rates are also noninterlaced.

remote management system

A remote management system is any system that accesses the Server Administrator home page on a managed system from a remote location using a supported Web browser. See managed system.

RFI

Abbreviation for radio frequency interference.

RGB

Abbreviation for red/green/blue.

RIMM

Acronym for Rambus In-line Memory Module, which is the Rambus equivalent of a DIMM module.

RMI

Acronym for Remote Method Invocation. RMI is a part of the Java programming language library that enables a Java program running on one system to access the objects and methods of another Java program running on a different system.

ROM

Acronym for read-only memory. Your system contains some programs essential to its operation in ROM code. Unlike RAM, a ROM chip retains its contents even after you turn off your system. Examples of code in ROM include the program that initiates your system's boot routine and the POST.

rpm

Abbreviation for revolutions per minute.

RPM

Abbreviation for Red Hat® Package Manager.

RTC

Abbreviation for real-time clock. Battery-powered clock circuitry inside the system that keeps the date and time after you turn off the system.

SAN

Acronym for storage area network.

SAS

Acronym for Secure Authentication Services or Serial-attached SCSI. When referring to security protocols or authentication, SAS is Secure Authentication Services. When referring to computer peripheral devices that employ a serial (one bit at a time) means of digital data transfer over thin cables, SAS is Serial-attached SCSI.

SCA

Abbreviation for single connector attachment.

schema

A collection of class definitions that describes managed objects in a particular environment. A CIM schema is a collection of class definitions used to represent managed objects that are common to every management environment, which is why CIM is called the Common Information Model.

SCSI

Acronym for small computer system interface. An I/O bus interface with faster data transmission rates than standard ports. You can connect up to seven devices (15 for some newer SCSI types) to one SCSI interface.

SEL

Acronym for system event log.

SDMS

Abbreviation for SCSI device management system.

sec

Abbreviation for second(s).

SEC

Abbreviation for single-edge contact.

secure port server

An application that makes Web pages available for viewing by Web browsers using the HTTPS protocol. See Web server.

serial port

An I/O port used most often to connect a modem to your system. You can usually identify a serial port on your system by its 9-pin connector.

settings

Settings are conditions of a manageable object help to determine what happens when a certain value is detected in a component. For example, a user can set the upper critical threshold of a temperature probe to 75 degrees Celsius. If the probe reaches that temperature, the setting results in an alert being sent to the management system so that user intervention can be taken. Some settings, when reached, can trigger a system shutdown or other response that can prevent damage to the system.

server module

A modular system component that functions as an individual system. To function as a system, a server module is inserted into a chassis which includes power supplies, fans, a system management module, and at least one network switch module. The power supplies, fans, system management module, and network switch module are shared resources of the server modules in the chassis. See modular system.

service tag number

A bar code label that identifies each system in the event that you need to call for customer or technical support.

SGRAM

Acronym for synchronous graphics RAM.

shadowing

A computer's system and video BIOS code is usually stored on ROM chips. Shadowing refers to the performance-enhancement technique that copies BIOS code to faster RAM chips in the upper memory area (above 640 KB) during the boot routine.

SIMD

Abbreviation for Single Instruction Multiple Data.

SIMM

Acronym for single in-line memory module. A small circuit board containing DRAM chips that connects to the system board.

SIP

Acronym for single in-line package, which is a type of housing for electronic components in which the connecting pins protrude from one side. A SIP is also called a Single In-line Pin Package (SIPP).

SKU

Acronym for stock keeping unit.

SMART

Acronym for Self-Monitoring Analysis and Reporting Technology. A technology that allows hard drives to report errors and failures to the system BIOS, which then displays an error message on the screen. To take advantage of this technology, you must have a SMART-compliant hard drive and the proper support in the system BIOS.

SMBIOS

Acronym for system management BIOS.

SMD

Abbreviation for surface mount device.

SMTP

Abbreviation for Simple Mail Transfer Protocol.

SNMP

Abbreviation for Simple Network Management Protocol. SNMP, a popular network control and monitoring protocol, is part of the original TCP/IP protocol suite. SNMP provides the format in which vital information about different network devices, such as network servers or routers, can be sent to a management application.

SODIMM

Acronym for small outline-DIMM. A DIMM module with a thinner profile due to the use of TSOP chip packages. SODIMMs are commonly used in portable computers.

SOIC

Abbreviation for Small Outline IC, a small-dimension, plastic, rectangular, surface mount chip package that uses gull-wing pins extending outward.

SOJ

Abbreviation for small outline package J-lead, a small-dimension, plastic, rectangular surface mount chip package with j-shaped pins on its two long sides.

SRAM

Abbreviation for static random-access memory. Because SRAM chips do not require continual refreshing, they are substantially faster than DRAM chips.

SSL

Abbreviation for secure socket layer.

state

Refers to the condition of an object that can have more than one condition. For example, an object may be in the "not ready" state.

status

Refers to the health or functioning of an object. For example, a temperature probe can have the status normal if the probe is measuring acceptable temperatures. When the probe begins reading temperatures that exceed limits set by the user, it reports a critical status.

SVGA

Abbreviation for super video graphics array. VGA and SVGA are video standards for video adapters with greater resolution and color display capabilities than previous standards.

To display a program at a specific resolution, you must install the appropriate video drivers and your monitor must support the resolution. Similarly, the number of colors that a program can display depends on the capabilities of the monitor, the video driver, and the amount of video memory installed in the system.

switch

On a system board, switches control various circuits or functions in your computer system. These switches are known as DIP switches; they are normally packaged in groups of two or more switches in a plastic case. Two common DIP switches are used on system boards: slide switches and rocker switches. The names of the switches are based on how the settings (on and off) of the switches are changed.

syntax

The rules that dictate how you must type a command or instruction so that the system understands it. A variable's syntax indicates its data type.

system board

As the main circuit board, the system board usually contains most of your system's integral components, such as the following:

- Microprocessor
- RAM
- Controllers for standard peripheral devices, such as the keyboard
- Various ROM chips

Frequently used synonyms for system board are motherboard and logic board.

system configuration information

Data stored in memory that tells a system what hardware is installed and how the system should be configured for operation.

system diskette

System diskette is a synonym for bootable diskette.

system memory

System memory is a synonym for RAM.

System Setup program

A BIOS-based program that allows you to configure your system's hardware and customize the system's operation by setting such features as password protection and energy management. Some options in the System Setup program require that you reboot the system (or the system may reboot automatically) in order to make a hardware configuration change. Because the System Setup program is stored in NVRAM, any settings remain in effect until you change them again.

system.ini file

A start-up file for the Windows operating system. When you start Windows, it consults the **system.ini** file to determine a variety of options for the Windows operating environment. Among other things, the **system.ini** file records which video, mouse, and keyboard drivers are installed for Windows.

Running the Control Panel or Windows Setup program may change options in the **system.ini** file. On other occasions, you may need to change or add options to the **system.ini** file manually with a text editor, such as Notepad.

table

In SNMP MIBs, a table is a two dimensional array that describes the variables that make up a managed object.

TCP/IP

Abbreviation for Transmission Control Protocol/Internet Protocol. A system for transferring information over a computer network containing dissimilar systems, such as systems running Windows and UNIX.

termination

Some devices (such as the last device at each end of a SCSI cable) must be terminated to prevent reflections and spurious signals in the cable. When such devices are connected in a series, you may need to enable or disable the termination on these devices by changing jumper or switch settings on the devices or by changing settings in the configuration software for the devices.

text editor

An application program for editing text files consisting exclusively of ASCII characters. Windows Notepad is a text editor, for example. Most word processors use proprietary file formats containing binary characters, although some can read and write text files.

TFTP

Abbreviation for Trivial File Transfer Protocol. TFTP is a version of the TCP/IP FTP protocol that has no directory or password capability.

text mode

A video mode that can be defined as x columns by y rows of characters.

threshold values

Systems are normally equipped with various sensors that monitor temperature, voltage, current, and fan speed. The sensor's threshold values specify the ranges (min and max values) for determining whether the sensor is operating under normal, noncritical, critical or fatal conditions. Server Administrator-supported threshold values are

- UpperThresholdFatal
- UpperThresholdCritical
- UpperThresholdNon-critical
- Normal
- LowerThresholdNon-critical
- LowerThresholdCritical
- LowerThresholdFatal

time-out

A specified period of system inactivity that must occur before an energy conservation feature is activated.

tpi

Abbreviation for tracks per inch.

TQFP

Abbreviation for thin quad flat pack.

TSR

Abbreviation for terminate-and-stay-resident. A TSR program runs "in the background." Most TSR programs implement a predefined key combination (sometimes referred to as a hot key) that allows you to activate the TSR program's interface while running another program. When you finish using the TSR program, you can return to the other application program and leave the TSR program resident in memory for later use. TSR programs can sometimes cause memory conflicts. When troubleshooting, rule out the possibility of such a conflict by rebooting your system without starting any TSR programs.

TSOP

Abbreviation for thin small outline package. A very thin, plastic, rectangular surface mount chip package with gull-wing pins on its two short sides.

UART

Acronym for universal asynchronous receiver transmitter, the electronic circuit that makes up the serial port.

UDP

Abbreviation for user datagram protocol.

UL

Abbreviation for Underwriters Laboratories.

UMB

Abbreviation for upper memory blocks.

unicode

A fixed width, 16-bit world wide character encoding, developed and maintained by the Unicode Consortium.

upper memory area

The 384 KB of RAM located between 640 KB and 1 MB. If the system has an x86 or higher microprocessor, a utility called a memory manager can create UMBs in the upper memory area, in which you can load device drivers and memory-resident programs.

UPS

Abbreviation for uninterruptible power supply. A battery-powered unit that automatically supplies power to your system in the event of an electrical failure.

URL

Abbreviation for Uniform Resource Locator (formerly Universal Resource Locator).

USB

Abbreviation for Universal Serial Bus. A USB connector provides a single connection point for multiple USB-compliant devices, such as mice, keyboards, printers, and computer speakers. USB devices can also be connected and disconnected while the system is running.

utility

A program used to manage system resources—memory, disk drives, or printers, for example.

utility partition

A bootable partition on the hard drive that provides utilities and diagnostics for your hardware and software. When activated, the partition boots and provides an executable environment for the partition's utilities.

UTP

Abbreviation for unshielded twisted pair.

UUID

Abbreviation for Universal Unique Identification.

V

Abbreviation for volt(s).

VAC

Abbreviation for volt(s) alternating current.

varbind

An algorithm used to assign an object identifier (OID). The varbind gives rules for arriving at the decimal prefix that uniquely identifies an enterprise, as well as the formula for specifying a unique identifier for the objects defined in that enterprise's MIB.

variable

A component of a managed object. A temperature probe, for example, has a variable to describe its capabilities, its health or status, and certain indexes that you can use to help you in locating the right temperature probe.

VCCI

Abbreviation for Voluntary Control Council for Interference.

VDC

Abbreviation for volt(s) direct current.

VESA

Acronym for Video Electronics Standards Association.

VGA

Abbreviation for video graphics array. VGA and SVGA are video standards for video adapters with greater resolution and color display capabilities than previous standards. To display a program at a specific resolution, you must install the appropriate video drivers and your monitor must support the resolution. Similarly, the number of colors that a program can display depends on the capabilities of the monitor, the video driver, and the amount of video memory installed for the video adapter.

VGA feature connector

On some systems with a built-in VGA video adapter, a VGA feature connector allows you to add an enhancement adapter, such as a video accelerator, to your system. A VGA feature connector can also be called a VGA pass-through connector.

video adapter

The logical circuitry that provides—in combination with the monitor—your system's video capabilities. A video adapter may support more or fewer features than a specific monitor offers. Typically, a video adapter comes with video drivers for displaying popular application programs and operating systems in a variety of video modes.

On some systems, a video adapter is integrated into the system board. Also available are many video adapter cards that plug into an expansion-card connector.

Video adapters often include memory separate from RAM on the system board. The amount of video memory, along with the adapter's video drivers, may affect the number of colors that can be simultaneously displayed. Video adapters can also include their own coprocessor for faster graphics rendering.

video driver

A program that allows graphics-mode application programs and operating systems to display at a chosen resolution with the desired number of colors. A software package may include some "generic" video drivers. Any additional video drivers may need to match the video adapter installed in the system.

video memory

Most VGA and SVGA video adapters include memory chips in addition to your system's RAM. The amount of video memory installed primarily influences the number of colors that a program can display (with the appropriate video drivers and monitor capabilities).

video mode

Video adapters normally support multiple text and graphics display modes. Character-based software displays in text modes that can be defined as x columns by y rows of characters. Graphics-based software displays in graphics modes that can be defined as x horizontal by y vertical pixels by z colors.

video resolution

Video resolution—800 x 600, for example—is expressed as the number of pixels across by the number of pixels up and down. To display a program at a specific graphics resolution, you must install the appropriate video drivers and your monitor must support the resolution.

virtual memory

A method for increasing addressable RAM by using the hard drive. For example, in a system with 16 MB of RAM and 16 MB of virtual memory set up on the hard drive, the operating system would manage the system as though it had 32 MB of physical RAM.

virus

A self-starting program designed to inconvenience you. Virus programs have been known to corrupt the files stored on a hard drive or to replicate themselves until a computer system or network runs out of memory. The most common way that virus programs move from one system to another is through "infected" diskettes, from which they copy themselves to the hard drive. To guard against virus programs, you should do the following:

- Periodically run a virus-checking utility on your system's hard drive
- Always run a virus-checking utility on any diskettes (including commercially sold software) before using them

VLSI

Abbreviation for very-large-scale integration.

VLVESA

Acronym for very low voltage enterprise system architecture.

vpp

Abbreviation for peak-point voltage.

VRAM

Acronym for video random-access memory. Some video adapters use VRAM chips (or a combination of VRAM and DRAM) to improve video performance. VRAM is dual-ported, allowing the video adapter to update the screen and receive new image data at the same time.

VRM

Abbreviation for voltage regulator module.

W

Abbreviation for watt(s).

Wakeup on LAN

The ability for the power in a client station to be turned on by the network. Remote wake-up enables software upgrading and other management tasks to be performed on users' systems after the work day is over. It also enables remote users to gain access to machines that have been turned off.

Web server

An application that makes Web pages available for viewing by Web browsers using the HTTP protocol.

WH

Abbreviation for watt-hour(s).

win.ini file

A start-up file for the Windows operating system. When you start Windows, it consults the **win.ini** file to determine a variety of options for the Windows operating environment. Among other things, the **win.ini** file records what printer(s) and fonts are installed for Windows. The **win.ini** file also usually includes sections that contain optional settings for Windows application programs that are installed on the hard drive. Running the Control Panel or Windows Setup program may change options in the **win.ini** file. On other occasions, you may need to change or add options to the **win.ini** file manually with a text editor such as Notepad.

Windows 95

An integrated and complete Microsoft Windows operating system that does not require MS-DOS and that provides advanced operating system performance, improved ease of use, enhanced workgroup functionality, and simplified file management and browsing.

Windows NT

High-performance server and workstation operating system software developed by Microsoft that is intended for technical, engineering, and financial applications.

write-protected

Read-only files are said to be write-protected. You can write-protect a 3.5-inch diskette by sliding its write-protect tab to the open position or by setting the write-protect feature in the System Setup program.

WMI

Acronym for Windows Management Instrumentation. WMI provides CIM Object Manager services.

X.509 Certificate

An X.509 certificate binds a public encryption key to the identity or other attribute of its principal. Principals can be people, application code (such as a signed applet) or any other uniquely identified entity (such as a secure port server or Web server).

XMM

Abbreviation for extended memory manager, a utility that allows application programs and operating systems to use extended memory in accordance with the XMS.

XMS

Abbreviation for eXtended Memory Specification.

X Window System

The graphical user interface used in the Red Hat Enterprise Linux environment.

ZIF

Acronym for zero insertion force. Some systems use ZIF sockets and connectors to allow devices such as the microprocessor chip to be installed or removed with no stress applied to the device.

ZIP

A 3.5-inch removable disk drive from Iomega. Originally, it provided 100-MB removable cartridges. The drive is bundled with software that can catalog the disks and lock the files for security. A 250-MB version of the Zip drive also reads and writes the 100-MB Zip cartridges.

