




Dell D1918H User's Guide

Regulatory model: D1918Ho



Notes, cautions, and warnings

-  **NOTE:** A NOTE indicates important information that helps you make better use of your computer.
-  **CAUTION:** A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.
-  **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2017 Dell Inc. All rights reserved.

This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.











2017-05 Rev. A01

Contents

Safety instructions	4
About your monitor	5
Package contents	5
Technical specifications	6
Monitor specifications	6
Power Management Modes	7
Supported resolutions and refresh rates	8
Setting up the monitor	9
Attaching the stand	9
Removing the stand	9
Connecting Your Monitor	10
Parts and controls	11
Front view	11
Back view	11
Using On Screen Display (OSD) Functions	12
The main menu	12
Maintenance guidelines	16
Care	16
Troubleshooting	16
Appendix	17
Contacting Dell	17

Safety instructions

This monitor is manufactured and tested on a ground principle that a user's safety comes first. However, improper use or installation may result in danger to the user, damage to the monitor, or both. Use the following safety guidelines to protect your monitor from potential damage and ensure your personal safety.

-  **WARNING:** This monitor should be operated only with a correct power source as indicated at the label on the rear of the monitor. For more information on the power source you are using, contact your power service provider.
-  **WARNING:** You should only perform troubleshooting and repairs as authorized or directed by the Dell technical assistance team. Damage due to servicing that is not authorized by Dell is not covered by your warranty.
-  **WARNING:** To avoid electric shock, do not attempt to remove any cover or touch the inside of the monitor. Only a qualified service technician should open the monitor cover.
-  **WARNING:** Stop using the monitor if the cover is damaged. Have it checked by a service technician.
-  **WARNING:** Place the monitor on a flat, soft, and clean surface. If there is a liquid spill on the monitor, unplug the monitor from the power source and contact Dell for assistance.
-  **WARNING:** Before you clean your monitor, disconnect it from the electrical outlet. Clean your monitor with a soft cloth dampened with water or non-ammonia based cleaner.
-  **WARNING:** Keep the monitor away from magnetic objects, motors, TV sets, and electrical transformers.
-  **WARNING:** Do not place heavy objects on the cables.
-  **WARNING:** For monitors with reflective screens, position the monitor such that glares caused by other light sources are avoided.
-  **WARNING:** When you purchase a VESA wall mount, ensure it is UL-listed and that only a qualified service technician installs it.

About your monitor

Package contents

Your monitor ships with the components shown below. Make sure that you have received all the components and contact Dell if something is missing.

	Monitor
	Neck
	Base
	Power cable (varies by country)
	HDMI cable (Support up to 1080p @ 60Hz)
	VGA cable
	<ul style="list-style-type: none">• Drivers and documentation media• Quick Setup Guide• Safety and Regulatory Information

Technical specifications

Monitor specifications

LCD Panel	47.0 cm (18.5") TFT (with LED back light)
Power Management	VESA DPMS compatible Off Mode, < 0.3 W Power Saving Mode, < 0.3 W
Displayable Resolution	WXGA, 1366 x 768 max. Vertical Frequency, 60Hz max.
Pixel Dimension	0.3 x 0.3 mm
Color gamut	72% of NTSC (CIE1931)
Color Depth	16.7 Million
Contrast Ratio	600:1 (typical)
Viewing Angle	90° (Horizontal) typical 65° (Vertical) typical
Response Time	5 ms typical (white to black, black to white)
Connectivity	1 x VGA 1 x HDMI 1.4
Active Display Area	409.8 x 230.4 mm
Tilt	-5°~15° (±2°)
VESA mount support	75 x 75mm
Dimension (with stand)	
Height	34.2 cm (13.46 inches)
Width	43.8 cm (17.24 inches)
Depth	14.7 cm (5.78 inches)
Weight	
without packaging	2.1 kg (4.63 lb)
with packaging	3.1 kg (6.83 lb)
Temperature	Operating: 0°C ~ + 40°C Storage: -20°C ~ + 60°C
Compliance	Energy Star, TÜV Low Blue Light (Dell ComfortView)*
Power	Input Voltage AC100-240 V

* Optimize eye comfort with a flicker-free screen.

* The possible long-term effects of blue light emission from the monitor may cause damage to the eyes, including eye fatigue or digital eye strain.

* ComfortView feature is designed to reduce the amount of blue light emitted from the monitor to optimize eye comfort.

NOTE: For information on the refresh rate (vertical frequency) of the graphics card, see the documentation that shipped with the graphics card.

Power Management Modes

If you have VESA's DPM-compliant video card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. This is referred to as power save mode*. If the computer detects input from the keyboard, mouse, or other input devices, the monitor automatically resumes functioning. The following table shows the power consumption and signaling of this automatic power saving feature.

VESA Modes	Horizontal Sync	Vertical Sync	Video	Power Indicator	Power Consumption
Normal operation	Active	Active	Active	Blue	13 W (maximum)** 11 W (typical)
Active-off mode	Inactive	Inactive	Off	Orange	Less than 0.3 W
Switch off	-	-	-	Off	Less than 0.3 W

Energy Star	Power Consumption
P _{ON}	9.62 W***
E _{TEC}	30.9 kWh****

*Zero power consumption in OFF mode can only be achieved by disconnecting the AC mains cable from the monitor.

**Maximum power consumption with maximum luminance.

***Power consumption of on mode as defined in Energy Star 7.0 version.

****Total energy consumption in kWh as defined in Energy Star 7.0 version.

This document is informational only and reflects laboratory performance. Your product may perform differently, depending on the software, components and peripherals you ordered and shall have no obligation to update such information.

Accordingly, the customer should not rely upon this information in making decisions about electrical tolerances or otherwise. No warranty as to accuracy or completeness is expressed or implied.

Activate the computer and the monitor to gain access to the OSD.

NOTE: This monitor is **ENERGY STAR** Qualified.



Supported resolutions and refresh rates

⚠ WARNING: Do not set the graphics card on your computer to exceed these maximum refresh rates. Doing so may result in permanent damage to your monitor.


VGA	720 x 400 @ 70Hz
VGA	640 x 480 @ 60Hz
VESA	640 x 480 @ 75Hz
VESA	800 x 600 @ 60Hz
VESA	800 x 600 @ 75Hz
VESA	1024 x 768 @ 60Hz
VESA	1024 x 768 @ 75Hz
VESA	1280 x 1024 @ 75Hz
VESA	1366 x 768 @ 60Hz

***The following resolutions are supported only with a HDMI source:**

480i @ 60Hz
480p @ 60Hz
576i @ 50Hz
576p @ 50Hz
720p @ 50Hz / 720p @ 60Hz
1080p @ 60Hz


Setting Up the Monitor

Attaching the stand



1. Place the monitor face down on a flat and clean surface.
2. Insert stand riser and base into the monitor as shown above.

Removing the stand



1. Place the monitor face down on a flat and clean surface.
2. Push release button and pull stand away from monitor.

Connecting Your Monitor

1. Connect the video cable

Ensure both monitor and computer are turned off. Connect one end of the HDMI or VGA cable to the computer, and then connect the other end to the respective port on the monitor.

2. Connect the earphone

Connect the earphone to the earphone output terminal of the monitor. (Earphone not supplied).

3. Connect the power cord

Connect the power cord to a properly-grounded AC outlet, and then to the monitor.

4. Turn on the monitor

Press the power button to turn on the monitor.

5. Set the resolution and refresh rate in Microsoft Windows

• Windows 7


- i) Right-click on the desktop, and then click **Screen resolution > Resolution**.
- ii) Set the appropriate resolution.

• Windows 8 or Windows 8.1

- i) Select the desktop tile to switch to classic desktop mode.
- ii) Right-click on the desktop, and then click **Screen resolution > Resolution**.
- iii) Set the appropriate resolution.


• Windows 10

- i) Right-click on the desktop, and then click **Display settings > Advanced display settings > Resolution**.
- ii) Set the appropriate resolution.




Parts and controls

Front view



Back view



1	AUTO	Input Select/ Exit from OSD Menu	6		LED Indicator
2		Scroll Down/ Decrease/ Contrast/Brightness Menu	7	HDMI	HDMI input (HDMI 19 pin)
3		Scroll Up/ Increase/ Color Vision Mode select	8		VGA input (D-Sub 15 pin)
4	MENU	OSD Menu On/Off / Confirm Select	9		Earphone Jack
5		Power On/Off	10		Power input


Using On Screen Display (OSD) Functions











Your monitor's settings are adjusted with the following buttons:





Button	Function
MENU	Display main menu
	Confirm Selection
AUTO	Manual adjust mode select for VGA, HDMI mode
	Exit from main menu or return to previous menu
▶	Select the desired item when in OSD menu
	When not in OSD menu, directly enters Color Vision Mode
◀	Select the desired item when in OSD menu
	When not in OSD menu, directly enters Contrast/Brightness menu
◀ + ▶	Recall both Contrast and Brightness (when not in OSD menu)
AUTO + ▶	Power Lock, press 10 seconds to lock, repeat press 10 seconds to unlock(when not in OSD menu)
AUTO + ▶	OSD Lock, press 10 seconds to lock, repeat press 10 seconds to unlock(when not in OSD menu)





The main menu

Use the monitor's menu to make adjustments:



Menu item	Description
	<p>Auto Image Adjust</p> <p>Adjust the Horizontal Position, Vertical Position, Phase (Fine Tune) and Clock (H. Size) of the screen.</p> <p> NOTE: Only available for VGA input.</p>
	<p>Contrast/Brightness</p> <p>Adjust the Contrast, Brightness, DCR and ECO of screen image.</p> <ul style="list-style-type: none"> • Contrast Adjust the foreground white level of screen image. • Brightness Adjust the luminance of the video. • DCR Detects the distribution of the visual signal input, and creates an optimized contrast.  NOTE: Brightness and ECO adjustment are disabled when DCR is active. • ECO Allows the user to change the energy-saving settings.  NOTE: Brightness and DCR adjustment are disabled when ECO is active.
	<p>Input Source</p> <p>Press Input Source to change the input signal to VGA or HDMI.</p>
	<p>Audio Adjust</p> <p>To adjust the audio functions.</p> <p> NOTE: Only available for HDMI input.</p> <ul style="list-style-type: none"> • Volume To adjust the volume of earphone output. • Mute To turn the Mute ON/OFF.
	<p>Color Adjust</p> <p>Toggle between preset color settings such as Cool, Normal, Warm and User Color.</p> <ul style="list-style-type: none"> • Cool Adds blue to screen image for cooler white. • Normal Adds red to screen image for warmer white and richer red. • Warm Adds green to screen image for a darker color. • User Color Manually adjust settings for Red (R), Green (G), Blue (B). 1. Press AUTO button to select the desired color. 2. Press ◀ or ▶ button to adjust selected color.
	<p>Information</p> <p>Displays information about the input signal coming from the graphics card in your computer.</p>

Menu item	Description
 Manual Image Adjust	Manually adjust H. / V. Position, Clock, Fine Tune, Sharpness, Aspect Ratio and Color Vision Mode.
<ul style="list-style-type: none"> • H. / V. Position 	Adjust the horizontal and vertical position of the video. <ul style="list-style-type: none"> • H. Position: ► : move screen to the right, ◀ : move screen to the left. • V. Position: ► : move screen up, ◀ : move screen down. <p> NOTE: Only available for VGA input.</p>
<ul style="list-style-type: none"> • Clock 	Adjust the width of the screen image. <ul style="list-style-type: none"> ► : increase the width of screen image, ◀ : decrease the width of screen image. <p> NOTE: Only available for VGA input.</p>
<ul style="list-style-type: none"> • Fine Tune 	Adjust the delay time of data and clock. Press ◀ or ► to adjust to your preference. <p> NOTE: Only available for VGA input.</p>
<ul style="list-style-type: none"> • Sharpness 	Adjust the clarity of a non-Full HD resolution signal with ◀ or ► button.
<ul style="list-style-type: none"> • Aspect Ratio 	Toggles the video mode between Full Screen or 4:3.
<ul style="list-style-type: none"> • Color Vision Mode 	Provides an optimum display environment depending on the contents displayed. It contains 6 user-selectable presets. <ul style="list-style-type: none"> • Standard: For general Windows environment and the default setting. • Game: For optimal PC gaming. • Cinema: For optimal movie and video viewing. • Scenery: Optimized for displaying outdoor scenery images. • Text: Optimized for displaying text. • ComfortView: To decrease the blue light emitted from the display to reduce the risk of blue light exposure to your eyes. To reduce the risk of eye strain and neck/arm/back/shoulder pain from using the monitor for long periods of time, we suggest you to: <ul style="list-style-type: none"> • set the screen about 20 to 28 inches (50 - 70 cm) from your eyes. • blink frequently to moisten or rewet your eyes when working with the monitor.

Menu item	Description
 <ul style="list-style-type: none"> • Color Vision Mode 	<ul style="list-style-type: none"> • take regular and frequent breaks for 20 minutes every two hours. • look away from your monitor and gaze at a distant object at 20 feet away for at least 20 seconds during the breaks. • perform stretches to relieve tension in the neck/arm/back/shoulders during the breaks. <p> NOTE: Contrast/Brightness and Color Adjust adjustment are disabled when Color Vision Mode is active.</p>
 <ul style="list-style-type: none"> • Setup Menu • Language Select • OSD Position • OSD Timeout • OSD Background 	<p>Setup Language Select, OSD Position, OSD Timeout and OSD Background.</p> <p>Allows users to choose from available languages.</p> <p>Press ◀ or ▶ button to select between horizontal and vertical OSD position adjustment.</p> <ul style="list-style-type: none"> • OSD H. Position: To horizontally adjust the OSD position. <ul style="list-style-type: none"> ▶: move OSD to the right, ◀: move OSD to the left. • OSD V. Position: To vertically adjust the OSD position. <ul style="list-style-type: none"> ▶: move OSD up, ◀: move OSD down. <p>To automatically turn off On Screen Display (OSD) after a preset period of time.</p> <p>Allows the user to turn the OSD background On or Off.</p>
 <ul style="list-style-type: none"> • Memory Recall 	<p>To recall factory settings for Video controls. Press button AUTO to select the Memory Recall menu option.</p>

Maintenance guidelines

Care

- Avoid exposing your monitor directly to sunlight or other heat source. Place your monitor away from the sun to reduce glare.
- Place your monitor in a well-ventilated area.
- Do not place any heavy objects on top of your monitor.
- Ensure your monitor is installed in a clean and moisture-free area.
- Keep your monitor away from magnets, motors, transformers, speakers, and TV sets.

Troubleshooting

No power

- Ensure that the power cable connecting the monitor and the wall outlet is properly connected and secure.
- Plug another electrical device into the power outlet to verify that the outlet is supplying proper voltage.
- Ensure that the video cable connecting the monitor and the computer is properly connected and secure.

No video/power light turned on

- Make sure the video cable supplied with the monitor is tightly secured to the video output port on back of the computer. If not, tightly secure it.
- Adjust brightness.



Wrong or abnormal colors

- If any colors (red, green, blue) are missing, check the video cable to make sure it is securely connected. Check for bent or broken pins in the video cable connector.
- Connect the monitor to another computer.

Appendix

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

-  **NOTE:** Availability varies by country and product, and some services may not be available in your country.
-  **NOTE:** If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.