

Dell PowerEdge C410x


Hardware Owner's Manual



Notes, Cautions, and Warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**Information in this publication is subject to change without notice.
© 2010-2013 Dell Inc. All rights reserved.**

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, and PowerEdge™ are trademarks of Dell Inc.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

Regulatory Model B02S

2013-12 Rev. A04

Contents

NOTES, CAUTIONS, AND WARNINGS	1
CONTENTS	3
1 INTRODUCTION	6
POWER SEQUENCE.....	6
SUPPORTED GPGPU CONFIGURATIONS.....	10
GPGPU SUPPORT LIMITATION.....	10
INFINIBAND (IB) SUPPORT LIMITATION.....	10
CHECKLIST.....	10
2 PRODUCT OVERVIEW	11
A TOUR OF THE SYSTEM	11
<i>System Front View</i>	11
<i>System Back View</i>	11
SYSTEM LEDs DESCRIPTION.....	13
<i>Front System LEDs</i>	13
<i>Static / Dynamic IP Switch Function Instruction</i>	14
3 REMOVING AND INSTALLING HARDWARE	15
SAFETY MEASURES.....	15
SYSTEM COVER	15
<i>Removing System Cover</i>	15
<i>Installing the system cover</i>	18
PCI CAGE.....	19
<i>Removing the PCI Cage</i>	19
<i>Installing the PCI cage</i>	20
PCIe CARD	20
<i>Replacing PCIe Card</i>	20
<i>For M1060 Card</i>	20
<i>Installing the M1060 card</i>	21
<i>Installing the Intel 5110P Card</i>	25
<i>Removing the 5110P card</i>	28
<i>Installing the NVIDIA K10/K20 Card</i>	30
<i>Removing the NVIDIA K10/K20 Card</i>	36
<i>Replacing System Fans</i>	41
<i>Installing the system fans</i>	43
FAN CAGE.....	44
<i>Replacing System Fan Cage</i>	44
<i>Installing the system fan cage</i>	48
POWER SUPPLY	49
<i>Replacing Power Supplies</i>	49
POWER DISTRIBUTION BOARD (PDB).....	52



<i>Replacing Power Distribution Board (PDB)</i>	52
<i>Installing the power distribution board</i>	58
IPASS BOARD.....	59
<i>Replacing iPass Board</i>	59
<i>Installing the iPass board</i>	67
MIDDLE BOARD.....	68
<i>Replacing Middle Board</i>	68
<i>Installing the system middle board</i>	69
FRONT I/O PANEL.....	70
<i>Removing Front I/O Panel</i>	70
<i>Installing the Front IO panel</i>	71
INSTALLING THE RAIL AND THE SYSTEM.....	72
4 CABLE ROUTINGS.....	75
IPASS PORT MAPPING.....	76
5 BMC REMOTE MANAGEMENT CONSOLE.....	77
INITIAL CONFIGURATION USING A DHCP SERVER.....	77
STATIC/DHCP IP CONTROLLED BY FRONT PANEL BUTTON.....	78
REMOTE MANAGEMENT CONSOLE OVERVIEW.....	79
ENTER DELL REMOTE MANAGEMENT CONSOLE.....	80
<i>Properties</i>	80
CONFIGURATION.....	81
<i>Network</i>	81
<i>Security</i>	82
<i>Users</i>	83
<i>Services</i>	84
IPMI.....	85
SESSIONS.....	87
UPDATES.....	88
<i>Utilities</i>	89
SERVER INFORMATION.....	90
<i>Power Control</i>	90
<i>Power Consumption</i>	91
<i>GPU Power Consumption</i>	92
<i>Thermal</i>	93
<i>Fans</i>	93
<i>Temperatures</i>	93
SYSTEM EVENT LOG.....	94
<i>Platform Events</i>	95
<i>Traps Settings</i>	96
<i>Email Settings</i>	97
<i>Port Map</i>	98
6 TROUBLESHOOTING YOUR SYSTEM.....	99

SAFETY FIRST—FOR YOU AND YOUR SYSTEM	99
<i>Checking GPU Card</i>	100
<i>Checking iPass Cable</i>	100
<i>Checking iPass Connector to Host System</i>	101
<i>Check if iPass Board (GS-IPASS2 / GS-IPASS3) is installed properly</i>	101
7 JUMPERS AND CONNECTORS	102
DELL POWEREDGE C410X MIDDLE BOARD CONNECTORS AND JUMPERS	102
8 GETTING HELP	103
CONTACTING DELL	103
9 INDEX	104

Introduction





Power Sequence

It is recommended that the following power sequence be followed when using the C410x and BMC 1.34 (or newer) with a host server not Intel E5-2600 Series based:


1. For a single host server connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Power up the host server.
 - b. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.
 - iii. Power down the C410x.
2. For multiple host servers connected to a C410x:
 - a. Initial Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Power up the host server.
 - b. Power Up Sequence:
 - i. Power up the PCI cage(s) associated with the iPass port connected to the C410x.
 **NOTE:** The PCI cage power can be applied by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - ii. Wait for the Green power LEDs on the cage(s) to light.
 - iii. Power up the host server.
 - iv. Repeat for each host server connected to the C410x.
 - b. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.
 - iii. Power down the PCI cage(s) associated with the iPass port connected to the C410x.
 **NOTE:** The PCI cage power can be removed by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - iv. Wait for the Green power LEDs on the cage(s) to turn off.
 - v. Repeat for each host server connected to the C410x.

It is recommended that the following power sequence be followed when using the C410x and BMC 1.34 (or newer) with a host server that is Intel E5-2600 Series based:

1. For a single host server connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the C410x.


- ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Power up the host server.
 - b. Power Down Sequence:
 - i. Power down the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to turn off and the fans to turn off.
 -  **NOTE:** The host server may report errors of missing devices on the PCIe bus.
 - iii. Power down the host server.
 - iv. Wait for the host server to power off.
- 2. For multiple host servers connected to a C410x:
 - a. Initial Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Power up the host server.
 - b. Power Up Sequence:
 - i. Power up the PCI cage(s) associated with the iPass port connected to the C410x.
 -  **NOTE:** The PCI cage power can be applied by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - vi. Wait for the Green power LEDs on the cage(s) to light.
 - vii. Power up the host server.
 - viii. Repeat for each host server connected to the C410x.
 - c. Power Down Sequence:
 - i. Power down the PCI cage(s) associated with the iPass port connected to the C410x.
 -  **NOTE:** The PCI cage power can be removed by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - ii. Wait for the Green power LEDs on the cage(s) to turn off.
 -  **NOTE:** The host server may report errors of missing devices on the PCIe bus.
 - iii. Power down the host server.
 - iv. Wait for the host server to power off.
 - v. Repeat for each host serve connected to the C410x.


It is recommended that the following power sequence be followed when using the C410x and BMC 1.32 with a host server not Intel E5-2600 Series based:

- 3. For a single host server connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Wait for the Blue UID LED on the left ear tab to stop blinking and then turn off. When the UID LED turns off the PCIe bus initialization is complete.
 -  **NOTE:** After the C410x power up the PCIe bus initialization will start. The PCIe bus initialization status can be checked using IPMITool commands identified in the “Using the C410x Base Board Management Controller”.
 - iv. Power up the host server.
 - b. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.

- iii. Power down the C410x.
- 4. For multiple host servers connected to a C410x:
 - a. Initial Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Wait for the Blue UID LED on the left ear tab to stop blinking and then turn off. When the UID LED turns off the PCIe bus initialization is complete.


NOTE: After the C410x power up the PCIe bus initialization will start. The PCIe bus initialization status can be checked using IPMITool commands identified in the “Using the C410x Base Board Management Controller”.
 - iv. Power up the host server.
 - b. Power Up Sequence:
 - i. Power up the PCI cage(s) associated with the iPass port connected to the C410x.


 **NOTE:** The PCI cage power can be applied by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - vi. Wait for the Green power LEDs on the cage(s) to light.
 - vii. Power up the host server.
 - viii. Repeat for each host server connected to the C410x.
 - d. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.
 - iii. Power down the PCI cage(s) associated with the iPass port connected to the C410x.





 **NOTE:** The PCI cage power can be removed by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - iv. Wait for the Green power LEDs on the cage(s) to turn off.
 - v. Repeat for each host server connected to the C410x.

It is recommended that the following power sequence be followed when using the C410x and BMC 1.32 with a host server that is Intel E5-2600 Series based:


- 3. For a single host server connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Wait for the Blue UID LED on the left ear tab to stop blinking and then turn off. When the UID LED turns off the PCIe bus initialization is complete.


 **NOTE:** After the C410x power up the PCIe bus initialization will start. The PCIe bus initialization status can be checked using IPMITool commands identified in the “Using the C410x Base Board Management Controller”.
 - iv. Power up the host server.
 - b. Power Down Sequence:
 - i. Power down the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to turn off and the fans to turn off.

 **NOTE:** The host server may report errors of missing devices on the PCIe bus.
 - iii. Power down the host server.

- iv. Wait for the host server to power off.
- 4. For multiple host servers connected to a C410x:
 - a. Initial Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Wait for the Blue UID LED on the left ear tab to stop blinking and then turn off. When the UID LED turns off the PCIe bus initialization is complete.
 -  **NOTE:** After the C410x power up the PCIe bus initialization will start. The PCIe bus initialization status can be checked using IPMITool commands identified in the “Using the C410x Base Board Management Controller”.
 - iv. Power up the host server.
 - b. Power Up Sequence:
 - i. Power up the PCI cage(s) associated with the iPass port connected to the C410x.
 -  **NOTE:** The PCI cage power can be applied by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - vi. Wait for the Green power LEDs on the cage(s) to light.
 - vii. Power up the host server.
 - viii. Repeat for each host server connected to the C410x.
 - e. Power Down Sequence:
 - i. Power down the PCI cage(s) associated with the iPass port connected to the C410x.
 -  **NOTE:** The PCI cage power can be removed by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - ii. Wait for the Green power LEDs on the cage(s) to turn off.
 -  **NOTE:** The host server may report errors of missing devices on the PCIe bus.
 - iii. Power down the host server.
 - iv. Wait for the host server to power off.
 - v. Repeat for each host server connected to the C410x.

It is recommended that the following power sequence be followed when using the C410x and BMC 1.28 with a host server:

- 1. For a single host server connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the C410x.
 - ii. Wait for the Green power LEDs on the individual PCI cages to light.
 - iii. Power up the host server.
 - b. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.
 - iii. Power down the C410x.
- 2. For multiple host servers connected to a C410x:
 - a. Power Up Sequence:
 - i. Power up the PCI cage(s) associated with the iPass port connected to the C410x.
 -  **NOTE:** The PCI cage power can be applied by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - ii. Wait for the Green power LEDs on the cage(s) to light.

- iii. Power up the host server.
- iv. Repeat for each host server connected to the C410x.
- b. Power Down Sequence:
 - i. Power down the host server.
 - ii. Wait for the host server to power off.
 - iii. Power down the PCI cage(s) associated with the iPass port connected to the C410x.
 **NOTE:** The PCI cage power can be removed by pressing the cage power button or using IPMITool commands identified in the “Using the C410x Base Board Management Controller” document.
 - iv. Wait for the Green power LEDs on the cage(s) to turn off.
 - v. Repeat for each host server connected to the C410x.

Supported GPGPU Configurations

The C410x supports installing different GPGPU and other devices in the chassis.

Mixing different GPGPUs connected to the same host server is not supported. All GPGPUs connected to a host server must be the same type.

Mixing other devices with GPGPUs connected to the same host server is supported.

GPGPU Support Limitation

There are some host servers that have multiple PCIe16 expansion slots. This allows multiple Host Interface Cards (HIC) to be installed in a single host server. The flexibility of the C410x system allows 16 GPGPUs to be connected to a single host server with multiple PCIe16 expansion slots. Host servers that are based on x86 architecture have a 16 bit (total 64 K) IO address space hardware limit. The 16 bit IO address space hardware limit limits the number of PCI devices that can be connected to the host server. The host server does not boot or other POST errors occur if the IO address space limit is exceeded. The number of onboard host server PCI devices utilize a fixed amount of IO address space. The remaining IO address space is used to determine the number of GPGPU that can be installed in a C410x that is connected to the single host server. Each GPGPU requires 4K of IO address space. The number of onboard PCI devices plus the number of GPGPUs determine the amount of IO address space used. Therefore, the 16 bit IO address space limitation does not allow a single host server to support 16 GPGPUs installed in a C410x.

InfiniBand (IB) Support Limitation

Host servers will not support more than one IB card installed in a C410x.

If more than one IB card is installed in a C410x and connected to a single host server issues may be observed.

Checklist

Carefully unpack the Dell PowerEdge C410X server and check that the following items were included.

- One Dell PowerEdge C410X system
- Dell PowerEdge C410x Getting Started Guide
- Safety, Environmental, and Regulatory Information (SERI)
- Warranty and Support Information (WSI) or End User License Agreement (EULA)

Product Overview

A Tour of the System

The following sections describe the external features of the Dell PowerEdge C410X server.

System Front View




Figure 1 – Front View

1	Power LED/Button	8	PCI Cage 5
2	System LED	9	PCI Cage 6
3	UID LED/Button	10	PCI Cage 7
4	PCI Cage 1	11	PCI Cage 8
5	PCI Cage 2	12	PCI Cage 9
6	PCI Cage 3	13	PCI Cage 10
7	PCI Cage 4		

System Back View

Back view of system is shown below:




Figure 2 – Back View

1	Power Module 1	11	iPass connector 6
2	Power Module 2	12	iPass connector 7
3	Power Module 3	13	iPass connector 8
4	Power Module 4	14	PCI Cage 11
5	BMC LAN Cable	15	PCI Cage 12
6	iPass connector 1	16	PCI Cage 13
7	iPass connector 2	17	PCI Cage 14
8	iPass connector 3	18	PCI Cage 15
9	iPass connector 4	19	PCI Cage 16
10	iPass connector 5		

System LEDs Description

Front System LEDs

The front system LEDs contain System LED, Power LED and UID LED information.

The detailed LEDs information is listed below:







Figure 3 – Front System LEDs

Table 1-1. Front System LEDs

	System LED	Displays status/errors and is controlled by BMC.		
		Color	Condition	Occurrence
		Amber	Blink Fast	Power supply fail
			On	FAN fail or sensor error
Blink	GPU card fail			
	UID LED	Lights when front or rear ID button is pressed.		
		Color	Condition	Occurrence
		Blue	Off	No identification
Blinking	ID Button pressed on system (ID command executed)			
	Power LED	Lights green when server is powered on.		
		Color	Condition	Occurrence
		Green	On	Power on
			Off	Power off
Blinking	Power on fail or without any GPU card			

Static / Dynamic IP Switch Function Instruction

- To switch from DHCP to static or vice versa:
 - Hold down the ID button for 5 seconds
 - While pressing the ID button, press and hold the power button for 5 seconds
 - Release the power button, and then the ID button
 - It will take ~30 seconds to change the configuration
 - The ID light will indicate which mode has been selected:
 - Solid for 5 seconds indicates static IP
 - Flashing for 5 seconds indicates DHCP
- If the default IP address is changed, switching DHCP to static IP will change the IP address back to the default.
- Default IP address is 192.168.0.120

Removing and Installing Hardware

Safety Measures

⚠CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

⚠CAUTION: Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous. Follow the simple guidelines below to avoid damage to your computer or injury to yourself.

- Always disconnect the computer from the power outlet whenever you are working inside the computer case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal system of the computer case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Do not flex or stress the circuit board.
- Leave all components inside the static-proof packaging until you are ready to use the component for the installation.


System Cover

Removing System Cover


⚠CAUTION: Before you remove or install the system cover: Make sure the system is not turned on or connected to AC power.

Follow these instructions to remove the system cover:


1. Loosen and remove the screws securing the middle cover.




2. Remove the middle top cover from the system.



3. Loosen and remove the screws securing the back cover.



4. Slide the cover horizontally to the back using the traction pad and remove the back cover in the direction of the arrow.



NOTE: This system must be operated with the system cover installed to ensure proper cooling.

Installing the system cover

To install the system cover follow the instructions for removing the system cover in the reverse order.


PCI Cage

Removing the PCI Cage


 **NOTE:**

- Take note of the drive tray orientation before sliding it out.
- The tray will not fit back into the bay if inserted incorrectly.

1. Lift the release lever and pull on the cage handle at the same time.



2. Slide the cage assembly out of the system.



Installing the PCI cage

To install the PCI cage follow the instructions for removing the PCI cage in the reverse order.

PCIe Card

Replacing PCIe Card


⚠CAUTION: Before you remove or install the PCIe card, press PCI cage power button to turn off the specific single PCI cage power before replacing PCIe card.

Follow these instructions to replace a PCIe card:


For M1060 Card

1. See to [Chapter 4 Cable Routings on page 57](#) to connect switch button cable and PCI power cable.
2. Insert the PCIe card by 45 degree and push it into the socket vertically.


⚠CAUTION: Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when inserting the card into the socket.



3. Secure the card in place with screws and place the PCI side cover as shown in the illustration.



4. Secure the PCI side cover and back cover in place with screws.




Installing the M1060 card

To install the M1060 card follow the instructions for removing the M1060 card in the reverse order.


For M2050/M2070/M2070Q/M2075/M2090 Cards

1. Connect PCI power cable.
2. Insert the PCIe card by 45 degree and push it into the socket vertically.


CAUTION: Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when inserting the card into the socket.




3. Secure the card with screw.




4. Attach the support bracket on the PCIE board and secure it in place with 4 screws.




5. Connect power cable to card as shown.




6. Replace the side cover.



7. Secure the side cover with 4 screws.




8. Secure the PCIe side cover with 3 screws as illustration arrow show.




Installing the Intel 5110P Card

Follow the instructions to install the Intel 5110P card.

1. Attach two support brackets with screws to the 5110P card heatsink cover.



Screw 2/4	
Support Bracket 3	
Support Bracket 1	





2. Connect power cable to card as shown.

 **CAUTION:** Make sure the power cable is plugged before inserting the PCIe card into socket.






3. Insert the 5110P card into the socket as shown in the illustration.

 **CAUTION:** Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when inserting the card into the socket.



4. Secure the 511P card with 3 screws.




Screw 7	
Screw 8	

Removing the 5110P card


Follow the instructions to remove the Intel 5110P card.

1. Remove the 3 securing screws.



2. Remove the 5110P card from the socket.

CAUTION: Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when removing the card from the socket.




3. Unplug power cable as shown.

CAUTION: Make sure the card is completely removed from the socket before unplugging the power cable.




4. Remove the securing screws and the support bracket from the 5110P heatsink cover.




Installing the NVIDIA K10/K20 Card


Follow the instructions to install the NVIDIA K10/K20 card.

1. Remove the 5 securing screws of K10 heatsink top cover.




Remove the 8 securing screws of K20 heatsink top cover.



 **NOTE:** Please keep heatsink top cover and securing screws. The heatsink top cover should be attached to replaced card before returning.


2. Attach the support bracket with two screws to the K10/K20 card.



Screw 2






3. Insert the K10/K20 card into the socket as shown in the illustration.




 **CAUTION:** Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when inserting the card into the socket.


4. Secure the K10/K20 card with 3 screws.




<p>Screw 4 (Same as Screw 2)</p>	
<p>Screw 5</p>	


5. Attach K10 support bracket.




 **NOTE:** Use the right mounting holes to secure the mounting bracket for the K10 card.


Attach the K20 support bracket.




 **NOTE:** Use the left mounting holes to secure the mounting bracket for the K20 card.

 **NOTE:** Picture is showing a K10 card for a K20 installation.



6. Secure the K10 support bracket with 3 screws.




Secure the K20 support bracket with 3 screws.



 **NOTE:** Picture is showing a K10 card for a K20 installation.

<p>Screw 7 (Same as Screw 2)</p>	
<p>Screw 8</p>	


7. Connect power cable to card.




Removing the NVIDIA K10/K20 Card

Follow the instructions to remove the NVIDIA K10/20 card.


1. Unplug power cable as shown.




2. Remove the K10 3 securing screws.




Remove the K20 3 securing screws.




3. Remove the K10 support bracket.



Remove the K20 support bracket.




4. Remove the 3 securing screws.




5. Remove the card from the socket.


CAUTION: Care should be taken to prevent damage to components on the back side of the PCIe card. Make sure the card does not drag across the card mounting standoffs of the cage when removing the card from the socket.




6. Remove the securing screws and the support bracket from K10/K20 card.





7. Attach the heatsink top cover to the K10 card and secure with 5 screws.

 **NOTE:** The heatsink top cover must be assembled to the K10 card before it is returned for replacement.



Attach the heatsink top cover to the K20 card and secure with 8 screws.

 **NOTE:** The heatsink top cover must be assembled to the K20 card before it is returned for replacement.




Replacing System Fans

In case of system fan failure, you can quickly replace the system fan.


⚠CAUTION: Before you remove or install the system fans, take the steps: 1) Make sure the system is not turned on or connected to the AC power. 2) Disconnect all necessary cable connections. Failure to observe these warnings could result in personal injury or damage to the equipment.

Follow the instruction to remove the system fans:


1. Loosen and remove the screws securing the middle cover.




2. Remove the middle top cover from the system.



3. Lift the system fan ears.



4. Lift the system fan out of the system fan cage.



Installing the system fans


To install the system fans follow the instructions for removing the system fans in the reverse order.

Fan cage


Replacing System Fan Cage

⚠CAUTION: Before you remove or install the system fan cage, take the steps: 1) Make sure the system is not turned on or connected to the AC power. 2) Disconnect all necessary cable connections. Failure to observe these warnings could result in personal injury or damage to the equipment.


1. Loosen and remove the screws securing the middle cover.




2. Remove the middle top cover from the system.





3. Loosen and remove the screws securing the fan cage.







4. Lift the fan cage out of the system.


 **NOTE:** Watch the fan status LED cables as the fan cage is lifted out of the system. The fan status LED connector should be unplugged before removing the fan cage completely from the system.



5. Remove the fans from the fan cage.



6. Loosen and remove the screws on top of the system fan cage.



Installing the system fan cage

To install the system fan cage follow the instructions for removing the system fan cage in the reverse order.

Power supply


Replacing Power Supplies

In case of a power supply failure, you can quickly replace the power supply unit.


Follow these instructions to remove the power supply:

⚠CAUTION: In order to reduce the risk of injury from electric shock, disconnect AC power from the power supply before removing it from the system.


1. Pull up the power supply handle.




2. Press the retaining clip on the right side of the power supply along the direction of the arrow.




3. At the same time, pull out the power supply by using its handle.



 **NOTE:** It takes considerable force to remove the power supply.

Follow these instructions to install the power supply:

Insert the replacement power supply firmly into the bay. The retaining clip should snap. Fold the power supply handle down. Connect the AC power cord to the replaced power supply.




Power Distribution Board (PDB)

Replacing Power Distribution Board (PDB)


Follow these instructions to remove the PDB:

⚠CAUTION: Before you remove or install the power distribution board take the steps: 1) Make sure the system is not turned on or connected to the AC power. 2) Disconnect all necessary cable connections. Failure to observe these warnings could result in personal injury or damage to the equipment.


1. Remove all power supplies from the system following the steps outlined in [Section-Replacing Power supplies](#).
2. Loosen and remove the screws securing the middle cover.




3. Remove the middle top cover from the system.




4. Loosen and remove the screws securing the back cover.




5. Slide the cover horizontally to the back using the traction pad and remove the back cover in the direction of the arrow.




6. Then Remove the BMC LAN cable from the retention clip. Lay the BMC LAN cable across the fans out of the way.




7. Loosen and remove the screws securing the power supply cage.




8. Slide the power cage horizontally to the back.




9. Lift the power cage to remove it in the direction of the arrow.




10. Loosen and remove the screw securing the rail.




11. Remove the rail by lifting the retention clip and at the same time slide the rail in the direction of the arrow.




12. Loosen and remove the screws securing the PDB.



13. Remove the PDB in the direction of the arrow.

 **NOTE:** It takes considerable force to remove the PDB.



Installing the power distribution board

To install the power distribution board follow the instructions for removing the power distribution board in the reverse order.


iPass Board

Replacing iPass Board


Follow these instructions to replace the iPass board:

⚠CAUTION: Before you remove or install the iPass Board, take the steps: 1) Make sure the system is not turned on or connected to the AC power. 2) Disconnect all necessary cable connections. Failure to observe these warnings could result in personal injury or damage to the equipment.


1. Loosen and remove the screws securing the middle cover.




2. Remove the middle top cover from the system.




3. Loosen and remove the screws securing the back cover.




4. Slide the cover horizontally to the back using the traction pad and remove the back cover in the direction of the arrow.




5. Then Remove the BMC LAN cable from the retention clip. Lay the BMC LAN cable across the fans out of the way.




6. Pull up the power supply handle.




7. Remove the power supply in the direction of the arrow.




8. Loosen and remove the screws securing the power supply cage.




9. Slide the power cage horizontally to the back.




10. Lift the power cage to remove it in the direction of the arrow.




11. Loosen and remove the screws securing the top of the iPass connector cage.




12. Slide the iPass connector cage horizontally to the back.




13. Loosen and remove the screws securing the top iPass board.




14. Lift up the iPass board and remove it from the system.



15. Loosen and remove the screws securing the bottom iPass board.



16. Lift up the iPass board and remove it from the system.



Installing the iPass board

To install the iPass board follow the instructions for removing the iPass board in the reverse order.


Middle Board

Replacing Middle Board


Follow these instructions to replace the middle board:

⚠CAUTION: Before you remove or install the middle board, take the steps: 1) Make sure the system is not turned on or connected to the AC power. 2) Disconnect all necessary cable connections. Failure to observe these warnings could result in personal injury or damage to the equipment.

1. Remove the Fan Cage. See Section- [Replacing Fan Cage](#).
2. Remove the Power Distribution Board. See Section-[Replacing Power Distribution Board](#)
3. Remove the iPass board. See Section-[Replacing iPass Board](#).
4. Remove the fourteen (14) screws securing the middle board in place.



5. Lift the middle board out of the system in the direction of the arrow, front edge first , to clear the IO ports.



Installing the system middle board


To install the system middle board follow the instructions for removing the system middle board in the reverse order.

Front I/O Panel


Removing Front I/O Panel

⚠ CAUTION: Before you remove or install the Front I/O Panel, make sure the system is not turned on or connected to the AC power.


1. Remove the screws securing the Front I/O panel cover.




2. Remove the Front I/O panel cover.



3. Remove the screws securing the Front I/O panel.



4. Remove the Front I/O panel and disconnect the cable.




Installing the Front IO panel

To install the Front IO panel follow the instructions for removing the Front IO panel in the reverse order.


Installing the Rail and the System

Follow these instructions to install the rail into a rack:


1. Install the sliding rails into the rack.




2. Align the inner rails with the sliding rails of the rack.





3. Push the system into the sliding rails until the locking latch clicks into place.




4. Connect ipass connectors and power connectors.





















 **NOTE:** The 1400W Power Supplies require 220VAC.


Cable Routings



1	Fan Power Cable
2	Front I/O Cable
3	BMC LAN Cable
4	Fan LED Cable
5	PCI Power Cable
6	Switch Cable

iPass Port Mapping

2 to 1 mode					4 to 1 mode					8 to 1 mode							
		IPASS		PCIE				IPASS		PCIE				IPASS		PCIE	
Mapping1		1	VS	1,15		1	VS	1,2,15,16		1	VS	1,2,3,4,13,14,15,16		5	2,16	N/A	
		5				5				N/A							
Mapping2		2	VS	3,13		2	VS	3,4,13,14		2	VS	N/A		6	4,14	N/A	
		6				6				N/A							
Mapping3		3	VS	5,11		3	VS	5,6,11,12		3	VS	5,6,7,8,9,10,11,12		7	6,12	N/A	
		7				7				N/A							
Mapping4		4	VS	7,9		4	VS	7,8,9,10		4	VS	N/A		8	8,10	N/A	
		8				8				N/A							

 **NOTE:** The default port mapping is 2 to 1 mode.

BMC Remote Management Console

This chapter provides information on the various functions of the Dell Remote Management Console GUI's (Graphics User Interface).


Initial Configuration using a DHCP Server

Before entering the Dell Remote Management Console, you need to connect the DHCP server in the subnet to which it is physically connected. If a DHCP server is found, it may provide a valid IP address, gateway address and net mask. Before you connect the device to your local subnet, be sure to complete the corresponding configuration of your DHCP server. It is recommended to configure a fixed IP assignment to the MAC address of the system.


Static/DHCP IP Controlled by Front Panel Button


- To switch from DHCP to static or vice versa:
 - Hold down the ID button for 5 seconds
 - While pressing the ID button, press and hold the power button for 5 seconds
 - Release the power button, and then the ID button
 - It will take ~30 seconds to change the configuration
 - The ID light will indicate which mode has been selected:
 - Solid for 5 seconds indicates static IP
 - Flashing for 5 seconds indicates DHCP
- If the default IP address is changed, switching DHCP to static IP will change the IP address back to the default.
- The default IP address is 192.168.0.120


Remote Management Console Overview



1. Open a web browser and type in your identified IP. The IP address can be found using your **DHCP server**.
2. A dialog box prompts you to enter Username and Password.
3. Enter the following values:
Username: **root**
Password: **root**

 **NOTE:** The default user name and password are in lower-case characters.

 **NOTE:** When you log in using the root user name and password, you have full administrative privileges. It is advised that once you log in, you should change the root password.


 **NOTE:** Password cannot be reset to default and midplane replacement is required if password is missing.

Enter Dell Remote Management Console

After you successfully log in to your Dell Remote Management Console, the Remote Management Console GUI appears.

Properties


Properties displays the firmware version of current remote client system.



Configuration

Network

You can view and modify the network settings on this screen. Select whether to obtain an IP address automatically or configure one manually. It is recommended to use DHCP if your environment has a DHCP server. You can set DHCP (obtain the IP address automatically) or STATIC IP (configure the IP address manually). When you finish configuration, click **Apply Changes** or for re-configuration click **Refresh**.



Security

Security shows the current certificate status. To generate a new certificate, click **Generate Certificate**.

To upload a certificate, click **Upload Certificate**.




The screenshot displays the BMC Security configuration page. On the left is a navigation tree with categories like BMC, Configuration, Network, Security, Users, Services, IPMI, Sessions, Update, Utilities, Server Information, Power, Control, Power Consumption, PCIE, Thermal, Fans, Temperatures, System Event Log, Event Management, Platform Events, Trap Settings, Email Settings, and Port Map. The 'Security' section is selected and highlighted. The main content area is titled 'Security' and contains two buttons: 'Generate Certificate' and 'Upload Certificate'. Below these buttons, the 'Current Certificate:' section displays the following details:

```
Serial Number      : 00
Subject Information:
Country Code (CC) : US
State (S)         : FL
Locality (L)      : Sunrise
Organization (O)  : Avocent
Organizational Unit (OU) : ARES
Common Name (CN)  : avocent.com
Issuer Information:
Country Code (CC) : US
State (S)         : FL
Locality (L)      : Sunrise
Organization (O)  : Avocent
Organizational Unit (OU) : ARES
Common Name (CN)  : avocent.com
Valid From        : Apr 13 13:49:00 2009 GMT
Valid To          : Apr 11 13:49:00 2019 GMT
```

Users

To configure a specific user, click the **Users ID**. To display new user information, click **Refresh**.

Please note that BMC convention for enabling an 'anonymous' login is to configure the entry for User ID 1 with a null username (all zero's) and a null password (all zero's). Applications may then present this to the user as an anonymous login.



The screenshot displays the 'Users' configuration page in the BMC Remote Management Console. The page features a navigation sidebar on the left with categories like BMC, Properties, Configuration, Network, Security, Services, IPMI, Sessions, Update, Server Information, Power, Control, Power Consumption, PCIE, Thermal, Temperatures, System Event Log, Event Management, Platform Events, Trap Settings, Email Settings, and Port Map. The main content area is titled 'Users' and includes a 'Refresh' button. Below the title, there is a table listing users with the following columns: User ID, State, User Name, User Role, IPMI LAN Privilege, and IPMI Serial Privilege. The table contains 16 rows of data.

User ID	State	User Name	User Role	IPMI LAN Privilege	IPMI Serial Privilege
1	Disabled		None	Administrator	Administrator
2	Enabled	root	Administrator	Administrator	Administrator
3	Disabled		None	None	None
4	Disabled		None	None	None
5	Disabled		None	None	None
6	Disabled		None	None	None
7	Disabled		None	None	None
8	Disabled		None	None	None
9	Disabled		None	None	None
10	Disabled		None	None	None
11	Disabled		None	None	None
12	Disabled		None	None	None
13	Disabled		None	None	None
14	Disabled		None	None	None
15	Disabled		None	None	None
16	Disabled		None	None	None

Services

You can configure the web server parameters (such as, HTTP Port Number, HTTPS Port Number, and Timeout) on a remote computer. By default, the timeout is 1800 seconds; 5 for the Max Sessions and 1 for the Active Sessions.

When you finish the configuration, click **Apply Changes**.




The screenshot shows the Dell BMC Remote Management Console interface. The top navigation bar includes the Dell logo and the text "Welcome root (Administrator)". A left-hand navigation menu lists various system settings categories such as BMC, Configuration, Network, Security, Users, Services, IPMI, Sessions, Update, Utilities, Server Information, Power, Control, Power Consumption, PCIE, Power Consumption, Thermal, Fans, Temperatures, System Event Log, Event Management, Platform Events, Trap Settings, Email Settings, and Port Map. The "Services" menu item is highlighted. The main content area is titled "Services" and contains a sub-section for "Web Server". A table lists the following parameters and their values:

Parameter	Value
HTTP Port Number	80
HTTPS Port Number	443
Timeout	1800 seconds
Max Sessions	5
Active Sessions	2

An "Apply Changes" button is located in the top right corner of the configuration area.

IPMI

This screen contains two sections: IPMI Serial and IPMI Settings.



IPMI Serial

There are three serial configuration in IPMI Serial: Connection Mode Settings, Baud Rate, and Channel Privilege Level Limit.

The Connection Mode Settings allows user to select the Console redirection type and to manage the system from a remote location.

Once the connection mode is set, select the Baud Rate from the drop-down list.

With Channel Privilege Level Limit, users can be configured to operate with a particular maximum Privilege Level. Privilege levels tell the BMC which commands are allowed to be executed. Table 3 lists the currently defined User Privilege Levels.

Table 5-1. User Privilege Levels

User	This may be considered the lowest privilege level.
Operator	All BMC commands are allowed, except for configuration commands that can change the behavior of the out-of-band interfaces. For example, Operator privilege does not allow the capability to disable individual channels, or change user access privileges.
Administrator	All BMC commands are allowed, including configuration commands. An Administrator can even execute configuration commands that would disable the channel that the Administrator is communicating over.

IPMI Settings

IPMI Settings provides remote configuration over LAN. To activate IPMI remote configuration by LAN, check **Enable IPMI Over LAN** option, define the Channel Privilege Level Limit, and enter the Encryption Key.

When you finish the configuration, click **Apply Changes**.

Sessions

This screen displays information on Active Sessions. Additionally, the trash can icon provides the delete function for privileged users. Click **Refresh** to refresh the Sessions status.

The screenshot shows the BMC Remote Management Console interface. The top navigation bar includes the Dell logo and the text "Welcome root (Administrator)". A left-hand sidebar contains a tree view of system components, with "Sessions" highlighted. The main content area is titled "Sessions" and includes a "Refresh" button. Below the title, a message states: "Use this page to view information about the active sessions. Additionally, privileged users can click on the trash can icon to kill an active session." A table displays the following data:


Session ID	User Name	IP Address	Session Type	Kill
1	root	10.1.7.84	GUI	
2	root	10.1.2.87	GUI	


Updates

The firmware can be updated remotely.

To update firmware, follow the instruction below:

1. Select the file on your local system using **Browse**.
2. Select **Update Type**.
3. Select **Preserve Configuration**.
4. Click **Update** to delete the current version and update to the new version.




 **NOTE:** BMC firmware update should not be interrupted, any interruption may result unrecoverable firmware crash? ROM replacement is required to bring C410x back. (firmware upgrade time: around 8 minutes)

Utilities

Utilities provides BMC reboot and Factory default restore functions.

To reboot system, click **Reboot**.

To restore factory default, click **Factory Default**.




Server Information

Power Control


The Power Control allows you to power on/off/cycle the remote host system. Additionally you can see the remote power status.

To perform the power control operation, select the operation and click **Apply Changes**.



Power Consumption

This screen displays information on the system power consumption. The information includes Current Power Consumption, Power Consumption Monitoring Start Date, Max/Min Power Consumption, and Average Power Consumption.






The screenshot shows the BMC Remote Management Console interface. The top left corner features the Dell logo. The top right corner displays the user information: "Welcome root (Administrator)". The left sidebar contains a navigation menu with the following items: BMC, Properties, Configuration, Network, Security, Users, Services, IPMI, Sessions, Update, Utilities, Server Information, Power, Control, Power Consumption (highlighted), PCIE, Power Consumption, Thermal, Fans, Temperatures, System Event Log, Event Management, Platform Events, Trap Settings, Email Settings, and Port Map. The main content area is titled "Power Consumption" and contains a "Power Reading" table with the following data:


Power Reading	
Current Power Consumption	86W 328 BTU/hr
Power Consumption Monitoring Start Date	Sat, 26 Aug 2008 09:59:54
Max Power Consumption	185W 683 BTU/hr
Min Power Consumption	69W 235 BTU/hr
Average Power Consumption	93W 317 BTU/hr

GPU Power Consumption

This screen displays the status of GPU power consumption.

Each sensor displays different color to indicate the health status of a specified GPU device.

	The green color indicates the device is healthy and there's no sensor that has any alert.
	The yellow color indicates the device has at least one sensor that has warning alert.
	The red color indicates the device has at least one sensor that has a critical alert.






Power Consumption

Status	Probe Name	Reading	Warning Threshold		Failure Threshold	
			Minimum	Maximum	Minimum	Maximum
Good	PCIe 1 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 2 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 3 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 4 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 5 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 6 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 7 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 8 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 9 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 10 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 11 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 12 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 13 Watt	18 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 14 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 15 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts
Good	PCIe 16 Watt	0 Watts	0Watts	240Watts	0Watts	252Watts


Thermal

This screen displays the Fans and Temperatures sensors of a remote host system.

Click **Refresh** to update current health status for both Fans and Temperatures.


	The green color indicates the device is healthy and there's no sensor that has any alert.
	The yellow color indicates the device has at least one sensor that has a warning alert.
	The red color indicates the device has at least one sensor that has a critical alert.

Fans



Status	Probe Name	Reading	Warning Threshold Minimum	Warning Threshold Maximum	Failure Threshold Minimum	Failure Threshold Maximum
✔	FAN1	6600 RPM	800RPM	N/A	500RPM	N/A
✔	FAN2	6500 RPM	800RPM	N/A	500RPM	N/A
✔	FAN3	6700 RPM	800RPM	N/A	500RPM	N/A
✔	FAN4	6700 RPM	800RPM	N/A	500RPM	N/A
✔	FAN5	6600 RPM	800RPM	N/A	500RPM	N/A
✔	FAN6	6600 RPM	800RPM	N/A	500RPM	N/A
✔	FAN7	6600 RPM	800RPM	N/A	500RPM	N/A
✔	FAN8	6600 RPM	800RPM	N/A	500RPM	N/A

Temperatures



Status	Probe Name	Reading	Warning Threshold Minimum	Warning Threshold Maximum	Failure Threshold Minimum	Failure Threshold Maximum
✔	Board Temp 1	41.0 C	0.0C	70.9C	0.0C	75.0C
✔	Board Temp 2	42.0 C	0.0C	70.9C	0.0C	75.0C
✔	Board Temp 3	41.0 C	0.0C	70.9C	0.0C	75.0C
✔	Board Temp 4	39.0 C	0.0C	70.9C	0.0C	75.0C
✔	Board Temp 5	37.0 C	0.0C	70.9C	0.0C	75.0C
✔	PCIe 10 Temp	42.0 C	0.0C	70.9C	0.0C	75.0C
✔	PCIe 10 Temp	34.0 C	0.0C	60.9C	0.0C	90.0C

System Event Log

System Event Log: It records the event when sensor has an abnormal state. When the log matches the pre-defined alert, the system sends out the notification automatically, if it is pre-configured.

The screenshot shows the BMC System Event Log interface. On the left is a navigation menu with categories like BMC, Properties, Configuration, Network, Security, Users, Services, IPMI, Sessions, Update, Utilities, Server Information, Power, Control, Power Consumption, hCTE, Power Consumption, Thermal, Fans, Temperatures, System Event Log (highlighted), Event Management, Platform Events, Trap Settings, Email Settings, and Port Map. The main area is titled 'System Event Log' and contains a table of log entries. Above the table are buttons for 'Save Log', 'Clear Log', and 'Refresh'. The table has columns for 'Severity', 'Date/Time', and 'Description'. The entries show various fan sensor events (FAN1-FAN8) with failure and warning states, and a PSU 1 Power Unit sensor event.

Severity	Date/Time	Description
Failure	2000-08-26 09:59:24	FAN8: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN8: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN7: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN7: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN6: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN6: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN5: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN5: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN4: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN4: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN3: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN3: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN2: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN2: Fan sensor, warning event was asserted
Failure	2000-08-26 09:59:24	FAN1: Fan sensor, failure event was asserted
Warning	2000-08-26 09:59:24	FAN1: Fan sensor, warning event was asserted
Failure	2000-08-26 09:58:03	PSU 1: Power Unit sensor, AC lost was asserted
Warning	2000-08-26 09:50:51	Sys Pwr Mentor: Power Supply sensor, Predictive Failure was asserted

Platform Events

A platform event filter (PEF) can trigger an action and generate an alert when a critical hardware-related event occurs. For each PEF, you can choose the action to be taken when a platform event occurs. You can also choose to generate and send an alert when a platform event occurs.

In the Platform Events screen, you can enable the generation of platform event alerts globally by clicking **Global Alerting Enable**.

When you finish the configuration, click **Apply Changes**.

The screenshot displays the Dell BMC Platform Events configuration interface. The left sidebar contains a navigation menu with categories like BMC, Configuration, Server Information, and Event Management. The main content area is titled 'Platform Events' and includes a sub-section 'Platform Event Filters (PEF) List'. A checkbox for 'Global Alerting Enable' is checked, with a note: '(This enables/disables both PET and email alerts)'. Below this is a table with the following data:

Filter Name	None	Power Cycle	Power Off	Generate PET
Fan Assort Filter	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="checkbox"/>
Temperature Warning Assort Filter	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>
Temperature Critical Assort Filter	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="checkbox"/>

Traps Settings

In the Trap Settings, user can set the IPv4 and Ipv6 Destination List.

IPv6 and IPv4 are two completely separate protocols. IPv6 is not backwards compatible with IPv4, and IPv4 hosts and routers will not be able to deal directly with IPv6 traffic.

IPv6 has a significantly larger address space than IPv4. This results from the use of a 128-bit address, whereas IPv4 uses only 32 bits.

When you finish the configuration, click **Apply Changes**.

The screenshot displays the 'Trap Settings' page in the Dell BMC interface. The page is titled 'Trap Settings' and includes an 'Apply Changes' button in the top right corner. The interface is divided into three main sections: 'IPv4 Destination List', 'IPv6 Destination List', and 'Community String'.

IPv4 Destination List

	Enable	IPv4 Address	Send Test Trap
IPv4 Destination 1	<input checked="" type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 2	<input type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 3	<input type="checkbox"/>	0.0.0.0	Send Test Trap
IPv4 Destination 4	<input type="checkbox"/>	0.0.0.0	Send Test Trap

IPv6 Destination List

	Enable	IPv6 Address	Send Test Trap
IPv6 Destination 1	<input type="checkbox"/>		Send Test Trap
IPv6 Destination 2	<input type="checkbox"/>		Send Test Trap
IPv6 Destination 3	<input type="checkbox"/>		Send Test Trap
IPv6 Destination 4	<input type="checkbox"/>		Send Test Trap

Community String

Community Name: public

Email Settings

If you want the alert to be sent by email, you can configure to specify the e-mail address, subject and message in the Email Settings. After you finish the configuration, click **Apply Change** to save the settings.

The screenshot displays the 'Email Settings' configuration page in the Dell BMC Remote Management Console. The interface includes a navigation sidebar on the left, a main content area, and a top header with the Dell logo and user information.

Navigation Sidebar:

- BMC
 - Properties
 - Configuration
 - Network
 - Security
 - Users
 - Services
 - IPMI
 - Sessions
 - Update
 - Utilities
 - Server Information
 - Power
 - Control
 - Power Consumption
 - PCIE
 - Power Consumption
 - Thermal
 - Fans
 - Temperatures
 - System Event Log
 - Event Management
 - Platform Events
 - Trap Settings
 - Email Settings**
 - Port Map

Main Content Area:

Email Settings

Welcome root (Administrator)!

[Apply Changes](#)

Destination Email Addresses

Email Alert	Enable	Destination E-mail Address	Email Description	Test
Email Alert 1	<input type="checkbox"/>		MegaPoint_email_alert	Send Alert 1
Email Alert 2	<input type="checkbox"/>		MegaPoint_email_alert	Send Alert 2
Email Alert 3	<input type="checkbox"/>		MegaPoint_email_alert	Send Alert 3
Email Alert 4	<input type="checkbox"/>		MegaPoint_email_alert	Send Alert 4

SMTP (e-mail) Server IP Address

SMTP IP Address:

Port Map

User can identify the specified iPASS mapping to PCIE controller in Port Map. Click **Apply Change** to save the settings.

Port Map

Two host system in multi-host with two virtual switches inside, host 4 having taken over all of host 1's end-points

IPASS mapping to PCIE Controller

	Control By		Jumper		BMC	
	IPASS	PCIE	IPASS	PCIE	IPASS	PCIE
Mapping 1	<input checked="" type="radio"/> 1 VS 5	1,15 2,16	<input type="radio"/> 1 VS 5	1,2,15,16 N/A	<input type="checkbox"/> 1 VS 5	1,2,3,4,13,14,15,16 N/A
Mapping 2	<input checked="" type="radio"/> 2 VS 6	3,13 4,14	<input type="radio"/> 2 VS 6	3,4,13,14 N/A	<input type="checkbox"/> 2 VS 6	N/A N/A
Mapping 3	<input checked="" type="radio"/> 3 VS 7	5,11 6,12	<input type="radio"/> 3 VS 7	5,6,11,12 N/A	<input type="checkbox"/> 3 VS 7	5,6,7,8,9,10,11,12 N/A
Mapping 4	<input checked="" type="radio"/> 4 VS 8	7,9 8,10	<input type="radio"/> 4 VS 8	7,8,9,10 N/A	<input type="checkbox"/> 4 VS 8	N/A N/A

Troubleshooting Your System

Safety First—For You and Your System

⚠ WARNING: Whenever you need to lift the system, get others to assist you. To avoid injury, do not attempt to lift the system by yourself.

⚠ CAUTION: Before removing the system cover, turn off all power, then unplug the AC power cord, and then disconnect all peripherals, and all LAN lines.

⚠ CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

Symptom: iPass card / port not recognized by the system

Check System Status (System must stay switched off)


3. Look at the back of each power supply. A green LED should be lit when AC power is applied.

📌 NOTE: Do not press power button on the system.

4. Check front panel LED (UID and Power LED). See figure 1 on [Page 10](#)
 - ID and Power LED should not light at the beginning.
 - After 30 seconds or so, when BMC is ready, UID LED and Power LED blink once.



5. System power on and Power LED lights. Other PCIe devices will be powered on in 40 sec.



6. When PCIe cards are ready, power on the host system for test.

Checking GPU Card


1. Power off and remove the middle cover. See section-[Removing System Cover to remove the middle cover.](#)
2. Power on the system and PCIe device and check if the GPU card LED lights.



3. If not, see **Check iPass cable.**


Checking iPass Cable

1. Check if iPass cable is properly connected.



2. If the iPass cable is not plugged in correctly, power off the system and plug-in the iPass cable again.
3. If not, swap iPass cable.

Checking iPass Connector to Host System



1. Check the Board to Board (BTB) connectors to the iPass Boards.
2. Check System SMBus device routing table.

IPASS TOP		IPASS Bottom	
iPass 1:	Slot 1/15	iPass 5:	Slot 2/16
iPass 2:	Slot 3/13	iPass 6:	Slot 4/14
iPass 3:	Slot 5/11	iPass 7:	Slot 6/12
iPass 4:	Slot 7/9	iPass 8:	Slot 8/10

Check if iPass Board (GS-IPASS2 / GS-IPASS3) is installed properly

1. See Replacing iPass Board on page 40 for instructions to accessing the iPass boards.
2. Reverse the steps above to reassemble the system.
3. Restart system and test again.

Jumpers and Connectors

Dell PowerEdge C410X Middle Board Connectors and Jumpers

Figure 5 identifies critical components on the Dell PowerEdge C410X middle board.





Figure 5 – Middle Board Connectors and Jumpers

Item	Component
1.	PCI-E connectors
2.	PCI-E connectors
3.	Power connectors
4.	iPass board connectors
5.	Battery
6.	Front I/O connector
7.	FAN connectors
8.	FAN LED connectors
9.	Failover setting pin header

Getting Help

Contacting Dell

For customers in the United States, call 800-WWW-DELL (800-999-3355).

 **NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

1. Visit **support.dell.com**.
2. Click your country/region at the bottom of the page. For a full listing of country/region click **All**.
3. Click **All Support** from **Support** menu.
4. Select the appropriate service or support link based on your need.
5. Choose the method of contacting Dell that is convenient for you.

Index

- back view, 3
- cable routings, 51
- checking GPU card, 77
- checking iPass cable, 78
- checking iPass connector, 79
- checklist, 1
- configuring
 - IPMI, 61
 - network, 57
 - security, 58
 - services, 60
 - sessions, 63
 - user, 59
- email settings, 75
- firmware
 - updates, 64
- front I/O removing, 46
- front view, 2
- getting help
 - contacting Dell, 82
- GPU power consumption, 70
- initial configuration via DHCP server, 53
- iPass board
 - replacing, 35
- iPass port mapping, 52
- middle board
 - replacing, 44
- middle board connectors and jumpers, 7
- PCI Cage, 11
- platform events, 73
- Port Map, 76
- power consumption, 69
- power distribution board
 - removing, 27, 44
- power supplies, 24
- rail and system
 - installing, 48
- remote management console
 - overview, 55
- safety measures, 6
- server information
 - power control, 68
- system cover, 8
- system event log, 72
- system fans, 17
- system fans cages, 20
- system LEDs
 - front, 4
- traps settings, 74
- troubleshooting your system, 77
- utilities, 67