FTOS Command Line Reference Guide for the S60 System FTOS 8.3.3.9



Notes, Cautions, and Warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



\triangle CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Information in this publication is subject to change without notice. © 2013 Dell Force10. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text; DellTM, the Dell logo, Dell BoomiTM, Dell PrecisionTM, OptiPlexTM, LatitudeTM, PowerEdgeTM, PowerVaultTM, PowerConnectTM, OpenManageTM, EqualLogicTM, CompellentTM, KACETM, FlexAddressTM, Force 10TM and VostroTM are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core® and Celeron® are registered trademarks of Intel Corporation in the U.S. and other countries. AMD®is a registered trademark and AMD OpteronTM, AMD PhenomTM and AMD SempronTM are trademarks of Advanced Micro Devices, Inc. Microsoft®, Windows®, Windows Server®, Internet Explorer®, MS-DOS®, Windows Vista® and Active Directory® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Red Hat® and Red Hat®Enterprise Linux® are registered trademarks of Red Hat, Inc. in the United States and/or other countries. Novell® and SUSE® are registered trademarks of Novell Inc. in the United States and other countries. Oracle® is a registered trademark of Oracle Corporation and/or its affiliates. Citrix®, Xen®, XenServer® and XenMotion® are either registered trademarks or trademarks of Citrix Systems, Inc. in the United States and/or other countries. VMware®, Virtual SMP®, vMotion®, vCenter® and vSphere® are registered trademarks or trademarks of VMware, Inc. in the United States or other countries. IBM® is a registered trademark of International Business Machines Corporation.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

1	About this Guide
	Objectives
	Audience
	Conventions
	Information Symbols
	Related Documents
2	CLI Basics13
	Accessing the Command Line
	Multiple Configuration Users
	Navigating the Command Line Interface
	Obtaining Help
	Using the Keyword No
	Filtering show Commands
	Displaying All Output
	Filtering Command Output Multiple Times18
	Command Modes
	EXEC Mode
	EXEC Privilege Mode19
	CONFIGURATION Mode19
	INTERFACE Mode19
	LINE Mode
	TRACE-LIST Mode20
	MAC ACCESS LIST Mode20
	IP ACCESS LIST Mode
	ROUTE-MAP Mode
	PREFIX-LIST Mode21
	AS-PATH ACL Mode21
	IP COMMUNITY LIST Mode
	REDIRECT-LIST Mode
	SPANNING TREE Mode
	Per-VLAN SPANNING TREE Plus Mode22
	RAPID SPANNING TREE Mode
	MULTIPLE SPANNING TREE Mode
	PROTOCOL GVRP Mode
	ROUTER OSPF Mode23
	ROUTER RIP Mode24
	ROUTER ISIS Mode24
	ROUTER BGP Mode24
	Determining the Chassis Mode

3	Overview
4	Control and Monitoring.65Overview.65Commands.65
5	802.1ag
6	Access Control Lists (ACL) 169 Overview 169 Commands Common to all ACL Types 169 Common IP ACL Commands 172 Standard IP ACL Commands 175 Extended IP ACL Commands 183 Common MAC Access List Commands 214 Standard MAC ACL Commands 216 Extended MAC ACL Commands 226 IP Prefix List Commands 226 Route Map Commands 232 AS-Path Commands 256 IP Community List Commands 256
7	Border Gateway Protocol IPv4(BGPv4) .258 Overview .258 BGPv4 Commands .260 MBGP Commands .336 BGP Extended Communities (RFC 4360) .367
8	Bare Metal Provisioning
9	Content Addressable Memory (CAM)

10	Dynamic Host Configuration Protocol (DHCP)	393
	Overview	393
	Commands to Configure the System to be a DHCP Server	393
	Commands to Configure Secure DHCP	401
11	Force10 Resilient Ring Protocol (FRRP)	107
	Overview	407
	Commands	407
	Important Points to Remember	407
12	GARP VLAN Registration (GVRP)	115
	Overview	415
	Commands	
	Important Points to Remember	416
13	Internet Group Management Protocol (IGMP)	125
	Overview	
	IGMP Commands	425
	Important Points to Remember	425
	IGMP Snooping Commands	435
	Important Points to Remember for IGMP Snooping	435
	Important Points to Remember for IGMP Querier	436
14	Interfaces	141
	Overview	441
	Basic Interface Commands	441
	Port Channel Commands	498
	UDP Broadcast	508
	Important Points to Remember	508
15	IPv4 Routing	511
	Overview	511
	Commands	511
16	IPv6 Access Control Lists (IPv6 ACLs)	563
	Overview	563
	Important Points to Remember	563
	IPv6 ACL Commands	563
	IPv6 Route Map Commands	588

17	IPv6 Basics	.593
	Overview	.593
	Commands	.593
18	iSCSI Optimization	605
	Overview	
10	Link Aggregation Control Protocol (LACP)	613
19	Link Aggregation Control Protocol (LACP)	
	Overview	
	Commands	.613
20	Layer 2	.621
	Overview	.621
	MAC Addressing Commands	.621
	Virtual LAN (VLAN) Commands	.638
21	Link Layer Detection Protocol (LLDP)	.649
	Overview	
	Commands	
	LLDP-MED Commands	
	LEDI WED COmmands	.000
22	Multiple Chaming Tree Dretocal (MCTD)	eec
22	Multiple Spanning Tree Protocol (MSTP)	
	Overview	
	Commands	.669
23	Multicast	.683
	Overview	.683
	IPv4 Multicast Commands	.683
	IPv6 Multicast Commands	. 692
24	Neighbor Discovery Protocol (NDP)	.697
	Overview	
	Commands	
	Communica	.001
O.F.	Ones Chartest Dath First (OCDE) (2 and OCDE) (2)	705
25	Open Shortest Path First (OSPFv2 and OSPFv3)	
	Overview	
	OSPFv2 Commands	.705
26	PIM-Sparse Mode (PIM-SM)	.763
	Overview	.763
	IPv4 PIM-Sparse Mode Commands	.763

27	PIM-Source Specific Mode (PIM-SSM)	.779
	Overview	779
	IPv4 PIM Commands	779
	IPv4 PIM-Source Specific Mode COmmands	779
28	Port Monitoring	.783
	Overview	783
	Commands	783
	Important Points to Remember	783
29	Private VLAN (PVLAN)	.789
	Overview	789
	Commands	789
	Private VLAN Concepts	789
30	Per-VLAN Spanning Tree plus (PVST+)	.799
	Overview	799
	Commands	799
31	Quality of Service (QoS)	.811
	Overview	811
	Global Configuration Commands	
	Per-Port QoS Commands	
	Policy-Based QoS Commands	
	Important Points to Remember—multicast-bandwidth option	
	Queue-Level Debugging	857
32	Router Information Protocol (RIP)	.869
	Overview	869
	Commands	869
33	Remote Monitoring (RMON)	.889
	Overview	
	Commands	889
34	Rapid Spanning Tree Protocol (RSTP)	
	Overview	
	Commands	901
35	Security	.911
	Overview	911

	Commands	911
	AAA Accounting Commands	911
	Authorization and Privilege Commands	914
	Authentication and Password Commands	918
	RADIUS Commands	930
	TACACS+ Commands	935
	Port Authentication (802.1X) Commands	938
	Important Points to Remember	939
	SSH Server and SCP Commands	946
	Secure DHCP Commands	958
36	Service Provider Bridging	.963
	Overview	963
	Commands	963
	Important Points to Remember	963
37	sFlow	.969
	Overview	969
	Important Points to Remember	969
	Commands	970
38	SNMP and Syslog	.979
	Overview	
	SNMP Commands	
	Important Points to Remember	980
	Syslog Commands	995
39	S-Series Stacking Commands	1009
	Overview	
	Commands	
40	Storm Control	1019
. •	Overview	
	Commands	
	Important Points to Remember	
41	Spanning Tree Protocol (STP)	1029
• •	Overview	
	Commands	

42	Time and Network Time Protocol (NTP)	
	Overview	
	Commands	.1039
43	S60 u-Boot	1055
	Overview	.1055
	Commands	. 1055
44	Uplink Failure Detection (UFD)	1059
	Overview	.1059
	Commands	.1059
45	VLAN Stacking	1069
	Overview	.1069
	Commands	.1069
	Important Points to Remember	.1069
46	Virtual Router Redundancy Protocol (VRRP)	1079
	Overview	.1079
	Commands	.1079
47	S-Series Debugging and Diagnostics	1091
	Diagnostics and Monitoring Commands	.1091
	Offline Diagnostic Commands	.1092
	Important Points to Remember	.1092
	Buffer Tuning Commands	.1094
	Hardware Commands	.1099
٨	SNMD Trans	1111

About this Guide

This book provides information on the FTOS Command Line Interface (CLI). It includes some information on the protocols and features found in FTOS and on the Dell Networking systems supported by FTOS (C-Series C), E-Series E), and S-Series S).

This chapter includes:

- **Objectives**
- Audience
- Conventions
- **Related Documents**

Objectives

This document is intended as a reference guide for the FTOS command line interface (CLI) commands used with the S60 system.

Audience

This document is intended for system administrators who are responsible for configuring or maintaining networks. This guide assumes you are knowledgeable in Layer 2 and Layer 3 networking technologies.

Conventions

This document uses the following conventions to describe command syntax:

Convention	Description
keyword Keywords are in bold and should be entered in the CLI as listed.	
parameter	Parameters are in italics and require a number or word to be entered in the CLI.
{X}	Keywords and parameters within braces must be entered in the CLI.
[X]	Keywords and parameters within brackets are optional.
x y	Keywords and parameters separated by bar require you to choose one.
x y	Keywords and parameters separated by a double bar enables you to choose any or all of them.

Information Symbols

Table 1-1 describes symbols contained in this guide.

Table 1-1. Information Symbols

Symbol	Brief	Description
C	C-Series	This symbol indicates that the selected feature is supported on the C-Series.
E	E-Series	This symbol indicates that the selected feature is supported on the E-Series TeraScale AND E-Series ExaScale.
EŢ	E-Series TeraScale	This symbol indicates that the selected feature is supported on the E-Series TeraScale platform only.
EX	E-Series ExaScale	This symbol indicates that the selected feature is supported on the E-Series ExaScale platform only.
S	S-Series	This symbol indicates that the selected feature is supported on the S-Series. Note that when a feature is supported on all the S-Series systems, including the S60, this symbol is used.
S60	S60	This symbol indicates that the selected feature is supported on the S60 but not on other S-Series systems.

Related Documents

For more information about the system, refer to the following documents:

- FTOS Configuration Guide for the S60
- S60 Installation Guide
- Release Notes for FTOS

CLI Basics

This chapter describes the command structure and command modes. FTOS commands are in a text-based interface that allows you to use launch commands, change the command modes, and configure interfaces and protocols.

This chapter covers the following topics:

- Accessing the Command Line
- **Multiple Configuration Users**
- Navigating the Command Line Interface
- **Obtaining Help**
- Using the Keyword No
- Filtering show Commands
- **Command Modes**

Accessing the Command Line

When the system boots successfully, you are positioned on the command line in the EXEC mode and not prompted to log in. You can access the commands through a serial console port or a Telnet session. When you Telnet into the switch, you are prompted to enter a login name and password.

Figure 2-1 is an example of a successful Telnet login session.

Figure 2-1. Login Example

```
telnet 172.31.1.53
Trying 172.31.1.53..
Connected to 172.31.1.53.
Escape character is '^]'.
Login: username Password:
FTOS>
```

Once you log into the switch, the prompt provides you with current command-level information (refer to Table 2-1).

Multiple Configuration Users

When a user enters the CONFIGURATION mode and another user(s) is already in that configuration mode, FTOS generates an alert warning message similar to the following:

Figure 2-2. Configuration Mode User Alert

```
FTOS#conf

% Warning: The following users are currently configuring the system:

User "" on line console0

User "admin" on line vty0 ( 123.12.1.123 )

User "admin" on line vty1 ( 123.12.1.123 )

User "Irene" on line vty3 ( 123.12.1.321 )

FTOS(conf)#FTOS#
```

When another user enters the CONFIGURATION mode, FTOS sends a message similar to the following, where the user in this case is "admin" on vty2:

```
% Warning: User "admin" on line vty2 "172.16.1.210" is in configuration
```

Navigating the Command Line Interface

The Command Line Interface (CLI) prompt displayed by FTOS is comprised of:

- "hostname"— the initial part of the prompt, "FTOS" by default. You can change it with the **hostname** command, as described in hostname.
- The second part of the prompt, reflecting the current CLI mode, as shown in Table 2-1.

The CLI prompt changes as you move up and down the levels of the command structure. Table 2-1 lists the prompts and their corresponding command levels, called *modes*. Starting with the CONFIGURATION mode, the command prompt adds modifiers to further identify the mode. The command modes are explained in Command Modes.



Note: Some of the following modes are not available on C-Series or S-Series.

Table 2-1. Command Prompt and Corresponding Command Mode

Prompt	CLI Command Mode
FTOS>	EXEC
FTOS#	EXEC Privilege
FTOS(conf)#	CONFIGURATION

Table 2-1. Command Prompt and Corresponding Command Mode

Prompt	CLI Command Mode
FTOS(conf-if)#	INTERFACE
FTOS(conf-if-gi-0/0)#	
FTOS(conf-if-te-0/0)#	
FTOS(conf-if-lo-0)#	
FTOS(conf-if-nu-0)#	
FTOS(conf-if-po-0)#	
FTOS(conf-if-vl-0)#	
FTOS(conf-if-so-0/0)#	
FTOS(conf-if-ma-0/0)#	
FTOS(conf-if-range)#	
FTOS(config-ext-nacl)#	IP ACCESS LIST
FTOS(config-std-nacl)#	
FTOS(config-line-aux)#	LINE
FTOS(config-line-console)#	
FTOS(config-line-vty)#	
FTOS(config-ext-macl)#	MAC ACCESS LIST
FTOS(config-std-macl)#	
FTOS(config-mon-sess)#	MONITOR SESSION
FTOS(config-span)#	STP
FTOS(config-mstp)#	MULTIPLE SPANNING TREE
FTOS(config-pvst)#	Per-VLAN SPANNING TREE Plus
FTOS(config-rstp)#	RAPID SPANNING TREE
FTOS(config-gvrp)#	PROTOCOL GVRP
FTOS(config-route-map)#	ROUTE-MAP
FTOS(conf-nprefixl)#	PREFIX-LIST
FTOS(conf-router_rip)#	ROUTER RIP
FTOS(conf-redirect-list)#	REDIRECT
FTOS(conf-router_bgp)#	ROUTER BGP
FTOS(conf-router_ospf)#	ROUTER OSPF
FTOS(conf-router_isis)#	ROUTER ISIS
FTOS(conf-trace-acl)#	TRACE-LIST

Obtaining Help

As soon as you are in a command mode there are several ways to access help.

- To obtain a list of keywords at any command mode, do the following:
 - Enter a ? at the prompt or after a keyword. There must always be a space before the ?.
- To obtain a list of keywords with a brief functional description, do the following:
 - Enter **help** at the prompt.

- To obtain a list of available options, do the following:
 - Type a keyword followed by a space and a ?
- Type a partial keyword followed by a ?
 - A display of keywords beginning with the partial keyword is listed.

Figure 2-3 illustrates the results of entering **ip?** at the prompt.

Figure 2-3. Partial Keyword Example

```
FTOS(conf)#ip ?
access-list
                        Named access-list
as-path
                        BGP autonomous system path filter
community-list
                        Add a community list entry
domain-list
                        Domain name to complete unqualified host name
domain-lookup
                        Enable IP Domain Name System hostname translation
domain-name
                        Define the default domain name
fib
                        FIB configuration commands
ftp
                        FTP configuration commands
host
                        Add an entry to the ip hostname table
                       Max. fragmented packets allowed in IP re-assembly
max-fraq-count
multicast-routing
                        Enable IP multicast forwarding
                        Specify addess of name server to use
name-server
pim
                        Protocol Independent Multicast
prefix-list
                        Build a prefix list
radius
                        Interface configuration for RADIUS
                        Named redirect-list
redirect-list
                        Establish static routes
route
                        SCP configuration commands
SCD
source-route
                        Process packets with source routing header options
                        SSH configuration commands
ssh
tacacs
                        Interface configuration for TACACS+
telnet
                        Specify telnet options
tftp
                        TFTP configuration commands
trace-group
                        Named trace-list
trace-list
                        Named trace-list
FTOS(conf)#ip
```

When entering commands, you can take advantage of the following timesaving features:

- The commands are not case sensitive.
- You can enter partial (truncated) command keywords. For example, you can enter int gig int interface for the interface gigabitethernet interface command.
- Use the **TAB** key to complete keywords in commands.
- Use the **up arrow** key to display the last enabled command.
- Use either the **Backspace** key or the **Delete** key to erase the previous character.

Use the **left** and **right arrow** keys to navigate left or right in the FTOS command line. Table 2-2 defines the key combinations valid at the FTOS command line.

Table 2-2. Short-cut Keys and their Actions

Key Combination	Action
CNTL-A	Moves the cursor to the beginning of the command line.
CNTL-B	Moves the cursor back one character.
CNTL-D	Deletes character at cursor.
CNTL-E	Moves the cursor to the end of the line.
CNTL-F	Moves the cursor forward one character.
CNTL-I	Completes a keyword.
CNTL-K	Deletes all characters from the cursor to the end of the command line.
CNTL-L	Re-enters the previous command.
CNTL-N	Return to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key
CNTL-P	Recalls commands, beginning with the last command
CNTL-R	Re-enters the previous command.
CNTL-U	Deletes the line.
CNTL-W	Deletes the previous word.
CNTL-X	Deletes the line.
CNTL-Z	Ends continuous scrolling of command outputs.
Esc B	Moves the cursor back one word.
Esc F	Moves the cursor forward one word.
Esc D	Deletes all characters from the cursor to the end of the word.

Using the Keyword No

To disable, delete, or return to default values, use the no form of the commands. For most commands, if you type the keyword **no** in front of the command, you will disable that command or delete it from the running configuration. In this document, the no form of the command is discussed in the Command Syntax portion of the command description.

Filtering show Commands

You can filter the display output of a **show** command to find specific information, to display certain information only, or to begin the command output at the first instance of a regular expression or phrase.

When you execute a **show** command, followed by a pipe (|) and one of the parameters listed below and a regular expression, the resulting output either excludes or includes those parameters, as defined by the parameter:

display — display additional configuration information

- **except** display only text that does not match the pattern (or regular expression)
- **find** search for the first occurrence of a pattern
- **grep** display text that matches a pattern
- **no-more** do not paginate the display output
- **save** copy output to a file for future use



Note: FTOS accepts a space before or after the pipe, no space before or after the pipe, or any combination. For example:

FTOS#command | grep gigabit | except regular-expression | find regular-expression

The **grep** command option has an **ignore-case** sub-option that makes the search case-insensitive. For example, the commands:

- **show run | grep Ethernet** would return a search result with instances containing a capitalized "Ethernet," such as interface GigabitEthernet 0/0.
- **show run | grep ethernet** would not return the search result, above, because it only searches for instances containing a non-capitalized "ethernet."

Executing the command **show run | grep Ethernet ignore-case** would return instances containing both "Ethernet" and "ethernet."

Displaying All Output

To display the output all at once (not one screen at a time), use the **no-more** after the pipe. This is similar to the **terminal length** screen-length command except that the **no-more** option affects the output of just the specified command. For example:

FTOS#show running-config|no-more

Filtering Command Output Multiple Times

You can filter a single command output multiple times. Place the save option as the last filter. For example:

FTOS# command | grep regular-expression | except regular-expression | grep other-regular-expression | find regular-expression | no-more | save

Command Modes

To navigate to various CLI modes, you need to use specific commands to launch each mode. Navigation to these modes is discussed in the following sections.



Note: Some of the following modes are not available on C-Series or S-Series.

EXEC Mode

When you initially log in to the switch, by default, you are logged into the EXEC mode. This mode allows you to view settings and to enter the EXEC Privilege mode to configure the device. While you are in the EXEC mode, the > prompt is displayed following the "hostname" prompt, as described above. which is "FTOS" by default. You can change it with the **hostname** command. See the command hostname. Each mode prompt is preceded by the hostname.

EXEC Privilege Mode

The **enable** command accesses the EXEC Privilege mode. If an administrator has configured an "Enable" password, you will be prompted to enter it here.

The EXEC Privilege mode allows you to access all commands accessible in EXEC mode, plus other commands, such as to clear ARP entries and IP addresses. In addition, you can access the CONFIGURATION mode to configure interfaces, routes, and protocols on the switch. While you are logged in to the EXEC Privilege mode, the # prompt is displayed.

CONFIGURATION Mode

In the EXEC Privilege mode, use the configure command to enter the CONFIGURATION mode and configure routing protocols and access interfaces.

To enter the CONFIGURATION mode:

- 1. Verify that you are logged in to the EXEC Privilege mode.
- 2. Enter the **configure** command. The prompt changes to include (conf).

From this mode, you can enter INTERFACE by using the interface command.

INTERFACE Mode

Use the INTERFACE mode to configure interfaces or IP services on those interfaces. An interface can be physical (for example, a Gigabit Ethernet port) or virtual (for example, the Null interface).

To enter INTERFACE mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **interface** command followed by an interface type and interface number that is available on the switch.
- 3. The prompt changes to include the designated interface and slot/port number, as outlined in Table 2-3.

Table 2-3. Interface prompts

Prompt Interface Type	
FTOS(conf-if)# INTERFACE mode	
FTOS(conf-if-gi-0/0)# Gigabit Ethernet interface followed by slot/port information	
FTOS(conf-if-te-0/0)# Ten Gigabit Ethernet interface followed by slot/port information	
FTOS(conf-if-lo-0)#	Loopback interface number.

Table 2-3. Interface prompts

Prompt	Interface Type
FTOS(conf-if-nu-0)#	Null Interface followed by zero
FTOS(conf-if-po-0)#	Port-channel interface number
FTOS(conf-if-vl-0)#	VLAN Interface followed by VLAN number (range 1 to 4094)
FTOS(conf-if-so-0/0)#	SONET interface followed by slot/port information.
FTOS(conf-if-ma-0/0)#	Management Ethernet interface followed by slot/port information
FTOS(conf-if-range)#	Designated interface range (used for bulk configuration; see interface range).

LINE Mode

Use the LINE mode to configure console or virtual terminal parameters.

To enter LINE mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Enter the **line** command. You must include the keywords **console** or **vty** and their line number available on the switch. The prompt changes to include (config-line-console) or (config-line-vty).

You can exit this mode by using the **exit** command.

TRACE-LIST Mode

When in the CONFIGURATION mode, use the **trace-list** command to enter the TRACE-LIST mode and configure a Trace list.

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Enter the **ip trace-list** command. You must include the name of the Trace list. The prompt change to include (conf-trace-acl).

You can exit this mode by using the **exit** command.

MAC ACCESS LIST Mode

While in the CONFIGURATION mode, use the **mac access-list standard** or **mac access-list extended** command to enter the MAC ACCESS LIST mode and configure either standard or extended access control lists (ACL).

To enter MAC ACCESS LIST mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Use the **mac access-list standard** or **mac access-list extended** command. You must include a name for the ACL.The prompt changes to include (conf-std-macl) or (conf-ext-macl).

You can return to the CONFIGURATION mode by entering the **exit** command.

IP ACCESS LIST Mode

While in the CONFIGURATION mode, use the ip access-list standard or ip access-list extended command to enter the IP ACCESS LIST mode and configure either standard or extended access control lists (ACL).

To enter IP ACCESS LIST mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Use the ip access-list standard or ip access-list extended command. You must include a name for the ACL. The prompt changes to include (conf-std-nacl) or (conf-ext-nacl).

You can return to the CONFIGURATION mode by entering the exit command.

ROUTE-MAP Mode

While in the CONFIGURATION mode, use the **route-map** command to enter the ROUTE-MAP mode and configure a route map.

To enter ROUTE-MAP mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Use the **route-map** map-name [**permit** | **deny**] [sequence-number] command. The prompt changes to include (route-map).

You can return to the CONFIGURATION mode by entering the exit command.

PREFIX-LIST Mode

While in the CONFIGURATION mode, use the ip prefix-list command to enter the PREFIX-LIST mode and configure a prefix list.

To enter PREFIX-LIST mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Enter the ip prefix-list command. You must include a name for the prefix list. The prompt changes to include (conf-nprefixl).

You can return to the CONFIGURATION mode by entering the **exit** command.

AS-PATH ACL Mode

Use the AS-PATH ACL mode to configure an AS-PATH Access Control List (ACL) on the E-Series. See Chapter 6, Access Control Lists (ACL).

To enter AS-PATH ACL mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Enter the ip as-path access-list command. You must include a name for the AS-PATH ACL. The prompt changes to include (config-as-path).

You can return to the CONFIGURATION mode by entering the exit command.

IP COMMUNITY LIST Mode

Use the IP COMMUNITY LIST mode to configure an IP Community ACL on the E-Series. See Chapter 6, Access Control Lists (ACL).

To enter IP COMMUNITY LIST mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Enter the **ip community-list** command. You must include a name for the Community list. The prompt changes to include (config-community-list).

You can return to the CONFIGURATION mode by entering the exit command.

REDIRECT-LIST Mode

Use the REDIRECT-LIST mode to configure a Redirect list on the E-Series, as described in the E-Series *FTOS Command Reference Guide* chapter on Policy-based Routing

To enter REDIRECT-LIST mode:

- 1. Verify that you are logged in to the CONFIGURATION mode.
- 2. Use the **ip redirect-list** command. You must include a name for the Redirect-list. The prompt changes to include (conf-redirect-list).

You can return to the CONFIGURATION mode by entering the **exit** command.

SPANNING TREE Mode

Use the STP mode to enable and configure the Spanning Tree protocol, as described in Chapter 41, Spanning Tree Protocol (STP).

To enter STP mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **protocol spanning-tree** stp-id command.

You can return to the CONFIGURATION mode by entering the exit command.

Per-VLAN SPANNING TREE Plus Mode

Use PVST+ mode to enable and configure the Per-VLAN Spanning Tree (PVST+) protocol, as described in Chapter 30, Per-VLAN Spanning Tree plus (PVST+).



Note: The protocol is PVST+, but the plus sign is dropped at the CLI prompt

To enter PVST+ mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **protocol spanning-tree pvst** command.

You can return to the CONFIGURATION mode by entering the exit command.

RAPID SPANNING TREE Mode

Use PVST+ mode to enable and configure the RSTP protocol, as described in Chapter 34, Rapid Spanning Tree Protocol (RSTP).

To enter RSTP mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **protocol spanning-tree rstp** command.

You can return to the CONFIGURATION mode by entering the **exit** command.

MULTIPLE SPANNING TREE Mode

Use MULTIPLE SPANNING TREE mode to enable and configure the Multiple Spanning Tree protocol, as described in Chapter 22, Multiple Spanning Tree Protocol (MSTP).

To enter MULTIPLE SPANNING TREE mode:

- Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **protocol spanning-tree mstp** command.

You can return to the CONFIGURATION mode by entering the exit command.

PROTOCOL GVRP Mode

Use the PROTOCOL GVRP mode to enable and configure GARP VLAN Registration Protocol (GVRP), as described in Chapter 12, GARP VLAN Registration (GVRP).

To enter PROTOCOL GVRP mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **protocol gvrp** command syntax.

You can return to the CONFIGURATION mode by entering the exit command.

ROUTER OSPF Mode

Use the ROUTER OSPF mode to configure OSPF, as described in Chapter 25, Open Shortest Path First (OSPFv2 and OSPFv3).

To enter ROUTER OSPF mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- Use the **router ospf** { process-id} command. The prompt changes to include (conf-router_ospf-id).

You can switch to the INTERFACE mode by using the interface command or you can switch to the ROUTER RIP mode by using the **router rip** command.

ROUTER RIP Mode

Use the ROUTER RIP mode to configure RIP on the C-Series or E-Series, as described in Chapter 32, Router Information Protocol (RIP).

To enter ROUTER RIP mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **router rip** command. The prompt changes to include (conf-router_rip).

You can switch to the INTERFACE mode by using the **interface** command or you can switch to the ROUTER OSPF mode by using the **router ospf** command.

ROUTER ISIS Mode

Use the ROUTER ISIS mode to configure ISIS on the E-Series, as described in the E-Series *FTOS Command Reference Guide* chapter on Intermediate System to Intermediate System (IS-IS).

To enter ROUTER ISIS mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **router isis** [tag] command. The prompt changes to include (conf-router_isis).

You can switch to the INTERFACE mode by using the **interface** command or you can switch to the ROUTER RIP mode by using the **router rip** command.

ROUTER BGP Mode

Use the ROUTER BGP mode to configure BGP on the C-Series or E-Series, as described in Chapter 7, Border Gateway Protocol IPv4(BGPv4).

To enter ROUTER BGP mode:

- 1. Verify that you are logged into the CONFIGURATION mode.
- 2. Enter the **router bgp** as-number command. The prompt changes to include (conf-router_bgp).

You can return to the CONFIGURATION mode by entering the **exit** command.

Determining the Chassis Mode

The chassis mode in FTOS determines which hardware is being supported in an E-Series chassis. The chassis mode is programmed into an EEPROM on the backplane of the chassis and the change takes place only after the chassis is rebooted. Configuring the appropriate chassis mode enables the system to use all the ports on the card and recognize all software features.

File Management

Overview

This chapter contains commands needed to manage the configuration files and includes other file management commands found in FTOS. This chapter contains these sections:

Basic File Management Commands

Basic File Management Commands

The commands included in this chapter are:

- boot config
- boot host
- boot network
- boot system (S60)
- boot system (S60)
- boot system gateway
- change bootflash-image
- copy
- copy (Streamline Upgrade)
- copy running-config startup-config
- delete
- dir
- download alt-boot-image
- download alt-full-image
- download alt-system-image
- format (C-Series and E-Series)
- format flash (S-Series)
- logging coredump
- logging coredump server
- pwd
- rename
- restore factory-defaults
- restore fpga-image
- show boot system

- show bootvar
- show file
- show file-systems
- show linecard
- show os-version
- show running-config
- show sfm
- show startup-config
- show version
- upgrade (E-Series version)
- upgrade (C-Series version)
- upgrade (S-Series management unit)
- upgrade fpga-image (E-Series)
- upgrade fpga-image (C-Series)
- upgrade fpga-image (S60)

boot config



Set the location and name of the configuration file that is loaded at system start-up (or reload) instead of the default startup-configuration.

Syntax

boot config {remote-first | rpm0 file-url | rpm1 file-url}

To return to the default setting, enter **no boot config {remote-first | rpm0 | rpm1}**.

Parameters

remote-first	Enter the keywords remote-first to attempt to load the boot configuration files from a remote location.
rpm0	Enter the keywords rpm0 first to specify the local boot configuration file for RPM 0.
rpm1	Enter the keywords rpm1 first to specify the local boot configuration file for RPM 1.
file-url	 Enter the location information: For a file on the internal Flash, enter flash:// followed by the filename. For a file on the external Flash, enter slot0:// followed by the filename.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 7.5.1.0	Introduced on C-Series		
E-Series original C	ommand		

Usage Information

To display these changes in the show bootvar command output, you must save the running configuration to the startup configuration (copy running-config startup-config or write).

Dell Networking strongly recommends using local files for configuration (RPM0 or RPM1 flash or slot0).

When you specify a file as the **boot config** file, it is listed in the boot variables (bootvar) as LOCAL CONFIG FILE. If you do not specify a boot config file, then the startup-configuration is used, although the bootvar shows LOCAL CONFIG FILE = variable does not exist. When you specify a boot config file, the switch reloads with that config file, rather than the startup-config. Note that if you specify a local config file which is not present in the specified location, then the startup-configuration is loaded.

The write memory command always saves the running-configuration to the file labeled startup-configuration. When using a LOCAL CONFIG FILE other than the startup-config, use the **COPY** command to save any running-configuration changes to that local file.

Output for **show bootvar** with *no* boot configuration configured

```
FTOS#show bootvar
PRIMARY IMAGE FILE = flash://FTOS-EF-8.2.1.0.bin
SECONDARY IMAGE FILE =
                                flash://FTOS-EF-7.6.1.0.bin
DEFAULT IMAGE FILE = flash://FTOS-EF-7.5.1.0.bin
LOCAL CONFIG FILE = variable does not exist
PRIMARY HOST CONFIG FILE = variable does not exist
SECONDARY HOST CONFIG FILE = variable does not exist
PRIMARY NETWORK CONFIG FILE = variable does not exist
SECONDARY NETWORK CONFIG FILE = variable does not exist
CURRENT IMAGE FILE = flash://FTOS-EF-8.2.1.0.bin
CURRENT CONFIG FILE 1 = flash://startup-config
CURRENT CONFIG FILE 2 = variable does not exist CONFIG LOAD PREFERENCE = local first
                                    local first
BOOT INTERFACE GATEWAY IP ADDRESS = variable does not exist
```

Output for **show bootvar** with boot configuration configured

```
FTOS#show bootvar
PRIMARY IMAGE FILE = flash://FTOS-EF-8.2.1.0.bin
SECONDARY IMAGE FILE = flash://FTOS-EF-7.6.1.0.bin
DEFAULT IMAGE FILE = flash://FTOS-EF-7.5.1.0.bin
LOCAL CONFIG FILE = variable does not exist
PRIMARY HOST CONFIG FILE = variable does not exist
SECONDARY HOST CONFIG FILE = variable does not exist PRIMARY NETWORK CONFIG FILE = variable does not exist
SECONDARY NETWORK CONFIG FILE = variable does not exist
CURRENT IMAGE FILE = flash://FTOS-EF-8.2.1.0.bin
CURRENT CONFIG FILE 1 = flash://CustomerA.cfq
CURRENT CONFIG FILE 2 = variable does not exist
CONFIG LOAD PREFERENCE = local first
BOOT INTERFACE GATEWAY IP ADDRESS = variable does not exist
```

Related Commands

show bootvar

Display the variable settings for the E-Series boot parameters.

boot host

[C][E]

Set the location of the configuration file from a remote host.

Syntax

boot host {primary | secondary} remote-url

To return to the default settings, enter **no boot host** {**primary** | **secondary**} command.

Parameters

primary

Enter the keywords **primary** to attempt to load the primary host configuration files.

secondary	Enter the keywords secondary to attempt to load the secondary host configuration files
remote-url	Enter the following location keywords and information:
	 For a file on an FTP server, enter ftp://user:password@hostip/filepath
	 For a file on a TFTP server, enter tftp://hostip/filepath
Not configured.	
CONFIGURATIO	ON
Version 7.5.1.0	Introduced on C-Series
E-Series original	Command
	changes in the show bootvar command output, you must save the running he startup configuration (using the copy command).

Display the variable settings for the E-Series boot parameters.

boot network

Commands

Defaults

Command History

Usage Information

Related

show bootvar

Command Modes

© E Set the location of the configuration file in a remote network.

Syntax boot network {primary | secondary} remote-url

To return to the default settings, enter **no boot network** {**primary** | **secondary**} command.

Parameters

primary	Enter the keywords primary to attempt to load the primary network configuration files.
secondary	Enter the keywords secondary to attempt to load the secondary network configuration files.
remote-url	Enter the following location keywords and information:
	 For a file on an FTP server, enter ftp://user:password@hostip/filepath For a file on a TFTP server, enter tftp://hostip/filepath

Defaults None

Command Modes CONFIGURATION

Command History

Version 7.5.1.0	Introduced on C-Series		
E-Series original C	Command		

Usage Information

To display these changes in the show bootvar command output, you must save the running configuration to the startup configuration (using the copy command).

Related Commands

show bootvar	Display the variable settings for the E-Series boot parameters.
--------------	---

boot system (C-Series and E-Series)

Tell the system where to access the FTOS image used to boot the system.

Syntax boot system {rpm0 | rpm1} (default | primary | secondary} file-url

> To return to the default boot sequence, use the **no boot system {rpm0 | rpm1} { primary | secondary**} command.

Parameters

rpm0	Enter the keyword rpm0 to configure boot parameters for RPM0.
rpm1	Enter the keyword rpm1 to configure boot parameters for RPM1.
default	After entering rpm0 or rpm1 , enter the keyword default to specify the parameters to be used if those specified by primary or secondary fail. The default location should always be the internal flash device (flash:), so that you can be sure that a verified image is available there.
primary	After entering rpm0 or rpm1 , enter the keyword primary to configure the boot parameters used in the first attempt to boot FTOS.
secondary	After entering rpm0 or rpm1 , enter the keyword secondary to configure boot parameters used if the primary operating system boot selection is not available.
file-url	To boot from a file:
	• on the internal Flash, enter flash:// followed by the filename.
	 on an FTP server, enter ftp://user:password@hostip/filepath
	 on the external Flash, enter slot0:// followed by the filename.
	 on a TFTP server, enter tftp://hostip/filepath

Defaults Not configured.

Command Modes

CONFIGURATION

Command **History**

Version 7.5.1.0	Introduced on C-Series	
E-Series original C	ommand	

Usage Information

To display these changes in the **show bootvar** command output, you must save the running configuration to the startup configuration (using the copy command) and reload system.

Related Commands

change bootflash-image	Change the primary, secondary, or default boot image configuration.
boot system gateway	Specify the IP address of the default next-hop gateway for the management subnet.

boot system (S60)

[S60]

Tell the system where to access the FTOS image used to boot the system.

Syntax

boot system {gateway ip address| stack-unit [0-11 | all] [default | primary {system {A: | B: } | tftp: | | secondary] }

To return to the default boot sequence, use the **no boot system** command.

Parameters

gateway	Enter the IP address of the default next-hop gateway for the management subnet	
stack-unit	Enter the stack-unit number for the master switch.	
p-address	Enter an IP address in dotted decimal format.	
0-11, all	Stack-unit number	
lefault	Enter the default keyword to use the primary FTOS image.	
rimary	Enter the primary keyword to use the primary FTOS image.	
econdary	Enter the secondary keyword to use the primary FTOS image.	
ftp:	Enter <i>TFTP</i> : to retrieve the image from a TFTP server. tftp://hostip/filepath	
N: B:	Enter A: or B: to boot one of the system partitions.	

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on the S60

Usage Information To display these changes in the **show bootvar** command output, you must save the running configuration to the startup configuration (using the copy command) and reload system.

Related Commands

boot system gateway Specify the IP address of the default next-hop gateway for the management subnet.

boot system gateway

Specify the IP address of the default next-hop gateway for the management subnet.

Syntax boot system gateway ip-address

ip-address

CONFIGURATION

To delete a gateway configuration, enter **no boot system gateway**.

Usage Saving the address to the startup configuration file preserves the address in NVRAM in case the startup configuration file is deleted.

Enter an IP address in dotted decimal format.

Command History

Parameters

Command Modes

Version 7.5.1.0 Introduced on C-Series

E-Series original Command

Related Commands

change bootflash-image Change the primary, secondary, or default boot image configuration.

cd

Change to a different working directory. [C][E][S]

Syntax cd directory

Parameters

directory (OPTONAL) Enter one of the following: flash: (internal Flash) or any sub-directory slot0: (external Flash) or any sub-directory (C-Series and E-Series only)

Command Modes

EXEC Privilege

Command **History**

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original C	Command

change bootflash-image

CEChange boot flash image from which to boot.

Syntax change bootflash-image {cp | linecard linecard-slot | rp}

Parameters

ср	Enter the keyword cp to change the bootflash image on the Control Processor on the RPM.
linecard linecard-slot	Enter the keyword linecard followed by the slot number to change the bootflash image on a specific line card. C-Series Range: 0-7 E-Series Range: 0 to 13 on the E1200; 0 on 6 on the E600, and 0 to 5 on the E300.
rp	Enter the keyword rp to change the bootflash image on the RPM Route Processor.

Defaults

Not configured.

Command Modes

EXEC Privilege

Command **History**

Version 7.5.1.0 Introduced on C-Series E-Series original Command

Usage Information A system message appears stating that the bootflash image has been changed. You must reload the system before the system can switch to the new bootflash image.

copy

CES

Copy one file to another location.

Syntax

copy source-file-url destination-file-url

Parameters

file-url

Enter the following location keywords and information:

- To copy a file from the internal FLASH, enter **flash://** followed by the filename.
- To copy a file on an FTP server, enter **ftp://**user:password@hostip/filepath
- To copy a file from the internal FLASH on RPM0, enter rpm0flash://filepath
- To copy a file from the external FLASH on RPM0, enter rpm0slot0://filepath
- To copy a file from the internal FLASH on RPM1, enter rpm1flash://filepath
- To copy a file from the external FLASH on RPM1, enter rpm1slot0://filepath
- To copy the running configuration, enter the keyword **running-config**.
- To copy the startup configuration, enter the keyword **startup-config**.
- To copy using Secure Copy (SCP), enter the keyword **scp:** (If **scp:** is entered in the source position, then enter the target URL;
 - If **scp:** is entered in the target position, first enter the source URL; see below for examples.)
- To copy a file on the external FLASH, enter **slot0://** followed by the filename.
- To copy a file on a TFTP server, enter **tftp://**hostip/filepath

ExaScale only

• To copy a file from a USB drive on RPM0, enter **rpm0usbflash:**//filepath

ExaScale and S60

To copy a file from an external USB drive, enter usbflash://filepath

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Added usbflash and rpm0usbflash commands on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series and added SSH port number to SCP prompt sequence on all systems.
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

FTOS supports a maximum of 100 files, at the root directory level, on both the internal and external Flach

The **usbflash** and **rpm0usbflash** commands are supported on E-Series ExaScale platform only. Refer to the FTOS Release Notes for a list of approved USB vendors.

When copying a file to a remote location (for example, using Secure Copy (SCP)), enter only the keywords and FTOS prompts you for the rest of the information.

For example, when using SCP, you can enter **copy running-config scp:**

The **running-config** is the source, and the target is specified in the ensuing prompts. FTOS prompts you to enter any required information, as needed for the named destination—remote destination, destination filename, user ID and password, etc.

When you use the **copy running-config startup-config** command to copy the running configuration (the startup configuration file amended by any configuration changes made since the system was started) to the startup configuration file, FTOS creates a backup file on the internal flash of the startup configuration.

FTOS supports copying the running-configuration to a TFTP server or to an FTP server:

copy running-config tftp:

copy running-config ftp:

Command Example: copy running-config scp:

```
FTOS#copy running-config scp:/
Address or name of remote host []: 10.10.10.1
Destination file name [startup-config]? old_running
User name to login remote host? home
Password to login remote host? home
```

In this example — copy scp: flash: — specifying SCP in the first position indicates that the target is to be specified in the ensuing prompts. Entering **flash:** in the second position means that the target is the internal Flash. In this example the source is on a secure server running SSH, so the user is prompted for the UDP port of the SSH server on the remote host.

Using **scp** to copy from an SSH Server

```
FTOS#copy scp: flash:
Address or name of remote host []: 10.11.199.134
Port number of the server [22]: 99
Source file name []: test.cfg
User name to login remote host: admin
Password to login remote host:
Destination file name [test.cfg]: test1.cfg
```

Related **Commands**

Change working directory. cd

copy (Streamline Upgrade)

Copy a system image to a local file and update the boot profile.

copy source-url target-url [boot-image [synchronize-rpm [external]]]

Parameters

Syntax

source-url	Enter the source file in url format. The source file is a valid Dell Networking release image. Image validation is automatic.
target-url	Enter the local target file in url format.
boot-image	Enter the keyword boot-image to designate this copy command as a streamline update.
synchronize-rpm	Enter the keyword synchronize-rpm to copy the new image file to the peer RPM.
external	Enter the keyword external to designate the target device on the peer RPM as external flash (instead of the default internal flash). Default: Internal Flash

Defaults

No default behavior

Command Modes

CONFIGURATION

Command History

Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced

Usage Information

In this streamline copy command, the source image is copied to the primary RPM and then, if specified, to the standby RPM. After the copy is complete, the new image file path on each RPM is automatically configured as the primary image path for the next boot. The current system image (the one from which the RPM booted) is automatically configured as the secondary image path.



Note: The keywords boot-image, synchronize-rpm, and external can be used on the Primary RPM only.

copy running-config startup-config



Copy running configuration to the startup configuration.

Syntax

copy running-config startup-config {duplicate}

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60.
Version 7.5.1.0	Introduced on C-Series
Version 6.3.1.0	Introduced

Usage Information

This command is useful for quickly making a changed configuration on one chassis available on external flash in order to move it to another chassis.

When you use the copy running-config startup-config duplicate command to copy the running configuration to the startup configuration, FTOS creates a backup file on the internal flash of the startup configuration.

delete

CES

Delete a file from the flash. Once deleted, files cannot be restored.

Syntax

delete flash-url [no-confirm]

Parameters

flash-url	Enter the following location and keywords:	
	• For a file or directory on the internal Flash, enter flash:// followed by the filename or directory name.	
	• For a file or directory on the external Flash, enter Slot0:// followed by the filename or directory name.	
no-confirm	(OPTIONAL) Enter the keyword no-confirm to specify that FTOS does not require user input for each file prior to deletion.	

Command Modes

EXEC Privilege

Command History

dir

[C][E][S]

Display the files in a filesystem. The default is the current directory.

Syntax

dir [filename | directory name:]

Parameters

filename | directory name:

(OPTIONAL) Enter one of the following:

- For a file or directory on the internal Flash, enter flash:// followed by the filename or directory name.
- For a file or directory on the external Flash, enter **slot0://** followed by the filename or directory name:

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

E-Series original Command

Example

Command Example dir for the Internal Flash

FTOS#dir Directory of flash: 6478482 May 13 101 16:54:34 E1200.BIN flash: 64077824 bytes total (57454592 bytes free) FTOS#

Related Commands

cd

Change working directory.

download alt-boot-image

CE

Download an alternate boot image to the chassis.

Syntax

download alt-boot-image file-url

Command Modes

EXEC Privilege

Command **History**

Version 7.7.1.0	Removed from E-Series and C-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

Starting with FTOS 7.7.1.0, the functions of this command are incorporated into the **upgrade** command.

For software upgrade details, see the FTOS Release Notes.

Related **Commands**

upgrade (E-Series version)	Upgrade the bootflash or boot selector versions.
upgrade (C-Series version)	Upgrade the bootflash or boot selector versions.

download alt-full-image

E Download an alternate FTOS image to the chassis.

Syntax download alt-full-image file-url

Command Modes EXEC Privilege

Command History

Version 7.7.1.0 Removed form E-Series

Version 6.5.1.0 Introduced

Usage Information Starting with FTOS 7.7.1.0, the functions of this command are incorporated into the **upgrade** command.

For software upgrade details, see the FTOS Release Notes.

Related Commands

upgrade (E-Series version) Upgrade the bootflash or boot selector versions

download alt-system-image

Download an alternate system image (not the boot flash or boot selector image) to the chassis.

Syntax download alt-system-image file-url

Command Modes EXEC Privilege

Command History

Version 7.7.1.0 Removed from E-Series

Version 6.5.1.0 Introduced

Usage Information Starting with FTOS 7.7.1.0, the functions of this command are incorporated into the **upgrade** command.

For software upgrade details, see the FTOS Release Notes.

Related Commands

upgrade (E-Series version) Upgrade the bootflash or boot selector versions

format (C-Series and E-Series)

Erase all existing files and reformat a filesystem. Once the filesystem is formatted, files cannot be restored.

Syntax format filesystem: [dosFs1.0 | dosFs2.0]

Parameters

filesystem: Enter one of the following:

• To reformat the internal Flash, enter **flash**:

To reformat the external Flash, enter **slot0**:

dosFs1.0	Enter the keyword dosFs1.0 to format in DOS 1.0 (the default)	
dosFs2.0	Enter the keyword dosFs2.0 to format in DOS 2.0	

Default DOS 1.0 (dosFs1.0)

Command Modes EXEC Privilege

Command History

Version 7.5.1.0	Introduced on C-Series
E-Series original Cor	nmand

Usage Information

When you format flash:

- 1 The startup-config is erased.
- 2 All cacheboot data files are erased and you must reconfigure cacheboot to regain it.
- 3 All generated SSH keys are erased and you must recreate them.
- All archived configuration files are erased.
- 5 All trace logs, crash logs, core dumps, and call-home logs are erased.
- In-service Process patches are erased.

After reformatting is complete, three empty directories are automatically created on flash: CRASH_LOG_DIR, TRACE_LOG_DIR and NVTRACE_LOG_DIR.

Note: Version option is available on LC-ED-RPM only. LC-EE3-RPM, LC-EF-RPM, and LC-EF3-RPM supports DOS 2.0 only.

Related **Commands**

show file	Display contents of a text file in the local filesystem.
show file-systems	Display information about the file systems on the system.

format flash (S-Series)

Erase all existing files and reformat the filesystem in the internal flash memory. Once the filesystem is formatted, files cannot be restored.

Syntax format flash:

Default flash memory

Command Modes EXEC Privilege

> Command History

Version 7.8.1.0 Introduced on S-Series

Usage Information

You must include the colon (:) when entering this command.

Caution: This command deletes all files, including the startup configuration file. So, after executing this command, consider saving the running config as the startup config (use the write memory command or copy run start).

Related Commands

copy	Copy the current configuration to either the startup-configuration file or the terminal.
show file	Display contents of a text file in the local filesystem.
show file-systems	Display information about the file systems on the system.

format flash (S60)

(S60)

Erase all existing files and reformat the filesystem in the internal flash memory or the USB drive. Once the filesystem is formatted, files cannot be restored.

Syntax

format [flash: | usbflash:]

Parameters

flash:	Reformat the filesystem in the internal flash memory
usbflash:	Reformat the filesystem in the connected USB drive memory

Default

flash memory

Command Modes

EXEC Privilege

Command History

oduced on the S60.
oduced on the S60.

Usage Information

You must include the colon (:) when entering this command.

Caution: This command deletes all files, including the startup configuration file. So, after executing this command, consider saving the running config as the startup config (use the **write memory** command or **copy run start**).

logging coredump

CES

Enable coredump.

Syntax

logging coredump {cp | linecard {number | all} | rps | stack-unit {id | all}}

Disable coredump using the command no logging coredump {cp | linecard {number | all} | rps}

Parameters

ср	Enable coredump for the CP.
linecard	Enable coredump for a linecard.
rps	Enable coredump for RP 1 and 2.
stack-unit	Enable coredump for the stack-unit.
	Range: S60 0-11
	All other S-Series 0-7

Defaults

The kernel coredump is enabled by default for RP 1 and 2 on E-Series. The kernel coredump for CP and application coredump are disabled on all systems by default.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Restructured command to accommodate coredumps for CP. Introduced on C-Series and S-Series
Version 6.5.1.0	Application coredump naming convention enhanced to include application.
Version 6.1.1.0	Introduced

Usage Information

The Kernel core dump can be large and may take up to 5 to 30 minutes to upload. FTOS does not overwrite application coredumps so you should delete them as necessary to conserve space on the flash; if the flash is out of memory, the coredump is aborted. On the S-Series, if the FTP server is not reachable, the application coredump is aborted. FTOS completes the coredump process and wait until the upload is complete before rebooting the system.

Related Commands

logging coredump server	Designate a sever to upload kernel core-dumps.
logging coredump server	Designate a sever to uproad kerner core-dumps.

logging coredump server

CES

Designate a server to upload coredumps.

Syntax

logging coredump server address username name password [type] password

Disable logging coredumps to a server using the command no logging coredump server address username name password [type] password

Parameters

address	Enter the server IP address in dotted decimal format (A.B.C.D) or hostname.	
name	Enter a username to access the target server.	
type	 Enter the password type: Enter 0 to enter an unencrypted password. Enter 7 to enter a password that has already been encrypted using a Type 7 hashing algorithm. 	
password	Enter a password to access the target server.	

Defaults

Crash kernel files are uploaded to flash by default.

Command Modes

CONFIGURATION

Command History

Version 7.7.1.0	Restructured command to accommodate coredumps for CP. Introduced on C-Series and S-Series.
Version 6.1.1.0	Introduced

Usage Information

Since flash space may be limited, using this command ensures your entire crash kernel files are uploaded successfully and completely.



Note: You must disable logging coredump before you designate a new server destination for your coredumps.

Related Commands

logging coredump	Disable the kernel coredump	
------------------	-----------------------------	--

pwd

[C][E][S]

Display the current working directory.

Syntax

pwd

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1 Introduced on the S60. Version 7.5.1.0 Introduced on C-Series E-Series original Command

Example

Command Example: pwd

FTOS#pwd flash: FTOS#

Related **Commands**

cd Change directory.

rename

CES

Rename a file in the local file system.

Syntax

rename url url

Parameters

url Enter the following keywords and a filename: For a file on the internal Flash, enter **flash://** followed by the filename. For a file on the external Flash, enter **slot0://** followed by the filename.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

restore factory-defaults



Restore factory defaults.

Syntax

restore factory-defaults stack-unit {0-11 | all} {clear-all | nvram}

Parameters

fac	tory-defaults	Return the system to its factory default mode.	
0-1	1	Enter this keyword to restore only the mentioned stack-unit.	
all		Enter this keyword to restore all units in the stack.	

clear-all	Enter this keyword to reset the NvRAM and to delete the system startup configuration.
nvram	Enter this keyword to reset the NvRAM only.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.9	Introduced on the S60
Version 8.3.5.4	Introduced on the S55
Version 8.3.17.1	Supported on M I/O Aggregator

Usage Information

Restoring factory defaults deletes the existing startup configuration and all persistent settings (stacking, fanout, etc.).

Dell Networking recommends backing up the startup configuration before using this command.

When restoring all S4810 units in a stack, all the S4810 units in the stack are placed into stand-alone mode.

When restoring a single S4810 unit in a stack, that S4810 unit is placed in stand-alone mode. No other units in the stack are affected.

When S55 and S60 units in a stack are restored, the S55 and S60 units will still form a stack.

After the restore is complete, the units power cycle immediately.



Caution: There is no undo for this command

Example

Figure 3-1. restore factory-defaults (all units in a stack) Command Example

```
FTOS#restore factory-defaults stack-unit all clear-all
      Warning - Restoring factory defaults will delete the existing
      persistent settings (stacking, fanout, etc.)
      After restoration the unit(s) will be powercycled immediately.
      Proceed with caution !
                    ****************
Proceed with factory settings? Confirm [yes/no]:yes
 - Restore status --
Unit Nvram Config
 0 Success Success
     Success Success
 1
     Not present
     Not present
     Not present
     Not present
     Not present
     Not present
     Not present
    Not present
   Not present
Power-cycling the unit(s)
FTOS#
```

Figure 3-2. restore factory-defaults (single unit in a stack) Command Example

Figure 3-3. restore factory-defaults (NvRAM only, all units in a stack) Command Example

```
FTOS#restore factory-defaults stack-unit all nvram
    * Warning - Restoring factory defaults will delete the existing
    * persistent settings (stacking, fanout, etc.)
* After restoration the unit(s) will be powercycled immediately.
       Proceed with caution !
Proceed with factory settings? Confirm [yes/no]:yes
-- Restore status --
Unit Nvram Config
  0 Success
  1
     Success
     Success
     Not present
  4
     Not present
     Not present
     Not present
     Not present
  8
     Not present
  9
     Not present
10
    Not present
11 Not present
Power-cycling the unit(s)
FTOS#
```

Figure 3-4. restore factory-defaults (NvRAM only, single unit in a stack) Command **Example**

```
FTOS#restore factory-defaults stack-unit 1nvram
    *******************
    * Warning - Restoring factory defaults will delete the existing
   * persistent settings (stacking, fanout, etc.)

* After restoration the unit(s) will be powercycled immediately.
    * Proceed with caution !
Proceed with factory settings? Confirm [yes/no]:yes
 - Restore status --
Unit Nvram Config
1Success
Power-cycling the unit(s).
FTOS#
```

restore fpga-image

Copy the backup C-Series FPGA image to the primary FPGA image.

Syntax restore fpga-image {rpm | linecard} number

Parameters

rpm	Enter rpm to upgrade an RPM FPGA.	
linecard	Enter linecard to upgrade a line card FPGA.	
number	Enter the line card or RPM slot number.	
	C-Series Line Card Range: 0-7, RPM Range: 0-1	

Defaults

None.

Command Mode

EXEC Privilege

Command **History**

Version 7.7.1.0	Renamed keyword primary-fpga-flash to fpga-image.
Version 7.5.1.0	Introduced on C-Series

Example Command example: restore fpga-image

FTOS#restore fpga-image linecard 4 Current FPGA information in the system: FPGA Name Current Version New Version Card LC4 48 Port 1G LCM FPGA A: 3.6 ********************** * Warning - Upgrading FPGA is inherently risky and should * only be attempted when necessary. A failure at this upgrade may cause a board RMA. Proceed with caution ! Restore fpga image for linecard 4 [yes/no]: yes $\ensuremath{\mathsf{FPGA}}$ restore in progress. Please do NOT power off the card. Upgrade result : Linecard 4 FPGA restore successful.

Usage Information

Reset the card using the **power-cycle** option after restoring the FPGA command.

Related **Commands**

Reset a card.

show boot system



Displays information about boot images currently configured on the system.

Syntax show boot system {all | linecard [slot | all] | rpm | stack-unit [0-11 | all]}

Parameters

all	Enter this keyword to display boot image information for all linecards and rpms.
linecard	Enter this keyword to display boot image information for the specified linecard(s) on the system.
rpm	Enter this keyword to display boot image information for all rpms on the system.
stack-unit	Enter this keyword to display boot image information for one or all the S60 units.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on C-Series and E-Series

Example

```
FTOS#show boot system all
Current system image information in the system:
_____
Type
               Boot Type
                               Α
CP
      DOWNLOAD BOOT invalid invalid

DOWNLOAD BOOT invalid invalid

DOWNLOAD BOOT invalid invalid
RP1
RP2
linecard {\tt 0} is not present.
                                                            invalid
6.5.1.8
invalid
invalid
linecard 1 DOWNLOAD BOOT invalid
linecard 2 DOWNLOAD BOOT 4.7.5.387
linecard 3 DOWNLOAD BOOT invalid linecard 4 DOWNLOAD BOOT invalid
linecard 5 is not present.
Peer RPM:
               Boot Type
Type
      DOWNLOAD BOOT invalid
DOWNLOAD BOOT invalid
                                                             invalid
RP1
                                                             invalid
RP2
                DOWNLOAD BOOT invalid
                                                             invalid
```

show bootvar

CE [S60]

Display the variable settings for the system boot parameters.

Syntax

show bootvar

Command Modes EXEC Privilege

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Example Command Output example: **show bootvar**

```
FTOS#show bootvar
PRIMARY IMAGE FILE = ftp://box:password@10.31.1.205//home/5.3.1/5.3.1.0/FTOS-ED-RPM1-5.3.1.0.bin
SECONDARY IMAGE FILE = variable does not exist
DEFAULT IMAGE FILE = flash://FTOS-ED-5.3.1.0.bin
LOCAL CONFIG FILE = variable does not exist
PRIMARY HOST CONFIG FILE = variable does not exist SECONDARY HOST CONFIG FILE = variable does not exist PRIMARY NETWORK CONFIG FILE = variable does not exist
SECONDARY NETWORK CONFIG FILE = variable does not exist
CURRENT IMAGE FILE = ftp://box:password@10.31.1.205//home/5.3.1/5.3.1.0/FTOS-ED-RPM1-5.3.1.0.bin CURRENT CONFIG FILE 1 = flash://startup-config CURRENT CONFIG FILE 2 = variable does not exist CONFIG LOAD PREFERENCE = local first
BOOT INTERFACE GATEWAY IP ADDRESS = variable does not exist
FTOS#
```

Related Commands

boot config	Set the location of configuration files on local devices.	
boot host	Set the location of configuration files from the remote host.	
boot network	Set the location of configuration files from a remote network.	
boot system (S60)	Set the location of FTOS image files.	
boot system gateway	Specify the IP address of the default next-hop gateway for the management subnet.	

show file

CES

Display contents of a text file in the local filesystem.

Syntax

show file filesystem

Parameters

filesystem	Enter one of the following:	
	•	flash: for the internal Flash
	•	slot0: for the external Flash

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0 Introduced on C-Series		
E-Series original Command		

Example

Command output example (Partial): show file

```
FTOS#show file flash://startup-config  
!
boot system rpm0 primary ftp://test:server@10.16.1.144//home/images/
E1200_405-3.1.2b1.86.bin
boot system rpm0 secondary flash://FTOS-ED-6.1.1.0.bin
boot system rpm0 default ftp://:@/\
!
redundancy auto-synchronize persistent-data
redundancy primary rpm0
!
hostname E1200-20
!
enable password 7 94849d8482d5c3
!
username test password 7 93e1e7e2ef
!
enable restricted 7 948a9d848cd5c3
!
protocol spanning-tree 0
bridge-priority 8192
rapid-root-failover enable
!
interface GigabitEthernet 0/0
no ip address
shutdown
```

Related Commands

format (C-Series and E-Series)

Erase all existing files and reformat a filesystem on the E-Series or C-Series platform.

format flash (S-Series)	Erase all existing files and reformat the filesystem in the internal flash memory on and S-Series.
show file-systems	Display information about the file systems on the system.

show file-systems

CES Display information about the file systems on the system.

Syntax show file-systems

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

Example

Command Output example: show file-system

```
FTOS#show file-systems
     Size(b)
                Free(b)
                           Feature
                                        Туре
                                              Flags Prefixes
    63938560
                51646464 dosFs2.0
                                        MMC
                                                 rw
                                                     flash:
    63938560
                18092032 dosFs1.0
                                        MMC
                                                 rw slot0:
                                    network
                                                 rw
                                                    ftp:
                                    network
                                                 rw tftp:
                                    network
                                                 rw
                                                     scp:
FTOS#
```

show file-systems Command Output Fields

Field	Description	
size(b)	Lists the size in bytes of the storage location. If the location is remote, no size is listed.	
Free(b)	Lists the available size in bytes of the storage location. If the location is remote, no size is listed.	
Feature	Displays the formatted DOS version of the device.	
Туре	Displays the type of storage. If the location is remote, the word network is listed.	
Flags	Displays the access available to the storage location. The following letters indicate the level of access: • r = read access • w = write access	
Prefixes	Displays the name of the storage location.	

Related Commands

format (C-Series and E-Series)	Erase all existing files and reformat a filesystem.
format flash (S-Series)	Erase all existing files and reformat the filesystem in the internal flash memory.

show file	Display contents of a text file in the local filesystem.
show sfm	Display the current SFM status.

show linecard

CE

View the current linecard status.

Syntax

show linecard [number | all | boot-information]

Parameters

number	Enter a number to view information on that linecard. Range: 0 to 6.	
all	(OPTIONAL) Enter the keyword all to view a table with information on all present linecards.	
boot-information	(OPTIONAL) Enter the keyword boot-information to view cache boot information of all line cards in table format.	

Command Modes

EXEC Privilege

Command History

Version 7.5.1.0	Introduced on C-Series
E-Series original C	mmand

Example

Command output example (E-Series): show linecard boot-information

show os-version



Display the release and software image version information of the image file specified or, optionally, the image loaded on the RPM (C-Series and E-Series only).

Syntax

show os-version [file-url]

Parameters

file-url (OPTIONAL) Enter the following location keywords and information: For a file on the internal Flash, enter **flash://** followed by the filename. For a file on an FTP server, enter ftp://user:password@hostip/filepath For a file on the external Flash, enter **slot0://** followed by the filename. For a file on a TFTP server, enter tftp://hostip/filepath Note: ftp and tftp are the only S-Series options.

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series original C	ommand	

Usage Information



Note: A filepath that contains a dot (.) is not supported.

Example

Command output example (E-Series): show os-version

LEASE IMAGE INFOR	MATION :			
Platform	Version	Size	Rele	aseTime
-series: EF	7.5.1.0	27676168	Aug 15 2007	10:06:21
RGET IMAGE INFORM	ATION :			
Type	Version		Tarqet	checksum
runtime	7.5.1.0	contro	ol processor	passed
runtime	7.5.1.0	rout	e processor	passed
runtime	7.5.1.0	terasca	le linecard	passed
boot flash	2.4.1.1	contro	ol processor	passed
boot flash	2.4.1.1		e processor	passed
boot flash	2.3.1.3		le linecard	passed
oot selector	2.4.1.1	contro	ol processor	passed
	2.4.1.1		e processor	passed
oot selector			le linecard	passed

Example Command output example (C-Series): **show os-version**

ELEASE IMAGE INFOF	RMATION :			
Platform	Version	Size	Rele	aseTime
C-series: CB	7.5.1.0	23734363	Aug 18 2007	11:49:51
RGET IMAGE INFORM	MATION :			
 Туре	Version		Target	checksum
runtime	7.5.1.0	control	processor	passed
runtime	7.5.1.0		linecard	passed
boot flash	2.7.0.1	control	processor	passed
boot flash	1.0.0.40		linecard	passed
ooot selector	2.7.0.1	control	processor	passed
ooot selector	1.0.0.40		linecard	passed
PGA IMAGE INFORMAT	TION :			
Card	Version	Release	Date	
Primary RPM	4.1	May 02	2007	
Secondary RPM		May 02		
LC0	3.2			
LC5	3.2			
LC6	2.2	May 02		

show running-config

CES Display the current configuration and display changes from the default values.

Syntax show running-config [entity] [configured] [status]

Parameters

entity

(OPTIONAL) Enter one of the keywords listed below to display that entity's current (non-default) configuration. Note that, if nothing is configured for that entity, nothing is displayed and the prompt returns:

- aaa for the current AAA configuration
- acl for the current ACL configuration
- **arp** for the current static ARP configuration
- as-path for the current AS-path configuration
- **bgp** for the current BGP configuration
- boot for the current boot configuration
- **cam-profile** for the current CAM profile in the configuration.
- **class-map** for the current class-map configuration
- **community-list** for the current community-list configuration
- **fefd** for the current FEFD configuration
- **ftp** for the current FTP configuration
- **fvrp** for the current FVRP configuration
- **host** for the current host configuration
- hardware-monitor for hardware-monitor action-on-error settings
- **igmp** for the current IGMP configuration
- **interface** for the current interface configuration
- isis for the current ISIS configuration
- line for the current line configuration
- **load-balance** for the current port-channel load-balance configuration
- **logging** for the current logging configuration

	 mac for the current MAC ACL configuration
	 mac-address-table for the current MAC configuration
	• management-route for the current Management port forwarding configuration
	• mroute for the current Mroutes configuration
	• ntp f or the current NTP configuration
	 ospf for the current OSPF configuration
	• pim f or the current PIM configuration
	• policy-map-input for the current input policy map configuration
	• policy-map-output for the current output policy map configuration
	 prefix-list for the current prefix-list configuration
	 privilege for the current privilege configuration
	 radius for the current RADIUS configuration
	 redirect-list for the current redirect-list configuration
	 redundancy for the current RPM redundancy configuration
	 resolve for the current DNS configuration
	• rip for the current RIP configuration
	 route-map for the current route map configuration
	• snmp for the current SNMP configuration
	• spanning-tree for the current spanning tree configuration
	• static for the current static route configuration
	• tacacs+ for the current TACACS+ configuration
	• tftp for the current TFTP configuration
	 trace-group for the current trace-group configuration
	 trace-list for the current trace-list configuration
	 users for the current users configuration
	 wred-profile for the current wred-profile configuration
configured	(OPTIONAL) Enter the keyword configuration to display line card interfaces with non-default configurations only.
status	(OPTIONAL) Enter the keyword status to display the checksum for the running configuration and the start-up configuration.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Added hardware-monitor option
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Expanded to include last configuration change and start-up last updated (date and time) and who made the change
Version 6.5.4.0	Added status option

Example Command output example (partial): **show running-config**

```
FTOS#show running-config
Current Configuration ...
! Version 7.4.1.0
! Last configuration change at Tue Apr 10 17:43:38 2007 by admin
! Startup-config last updated at Thu Mar 29 02:35:08 2007 by default
!
boot system rpm0 primary flash://FTOS-EF-7.4.1.0.bin
boot system rpm0 secondary flash://FTOS-EF-6.3.1.2.bin
boot system rpm0 default flash://FTOS-EF-6.5.1.8.bin
!
```

Example Command output example: show running-config

```
FTOS#show running-config status
running-config checksum 0xB4B9BF03
startup-config checksum 0x8803620F
FTOS#
```

Usage Information

The **status** option enables you to display the size and checksum of the running configuration and the startup configuration.

show sfm

CE

View the current SFM status.

Syntax

show sfm [number[brief] | all]

Parameters

number	Enter a number to view information on that SFM.
	Range: 0 to 8.
all	(OPTIONAL) Enter the keyword all to view a table with information on all present SFMs.
brief	(OPTIONAL) Enter the keyword brief to view a list with SFM status.
	Note: The brief option is not available on C-Series.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.8	Updated to support PPID on the S60
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

E-Series Example

Command output example (Partial) on E-Series: show sfm

```
FTOS#show sfm
 Switch Fabric State: up
Switch Mode: SFM3
 -- SFM card 0 --
Status : active (Older version of SFM for Exascale)
Card Type : SFM3 - Switch Fabric Module
Up Time : 18 hr, 40 min
Last Restart : remote-off
Temperature : 42C
Power Status : AC
 Serial Number : VC074300030
Vendor Id : 04

Date Code : 01402006

Country Code : 01
 Piece Part ID : CN-0RVY43-75412-123-0030
 PPID Revision: 003
 Service Tag : SVCTG00
Expr Svc Code : 628 458 860 16
FPGA
                : 0x0.0.3
Booting from : EEPROMO
Status : active (Older version of SFM for Exascale)
Card Type : SFM3 - Switch Fabric Module
Up Time : 18 hr, 40 min
Last Restart : remote-off
Temperature : 42C
Power Status : AC
Serial Number : VC07/4300000
Serial Number : VC074300032
Part Number : 7520020001 Rev 03
Vendor Id : 04
Date Code : 01402006
Country Code : 01
Piece Part ID : CN-0RVY43-75412-82B-0456
PPID Revision : 1B2
Service Tag : SVCTG01
Expr Svc Code: 628 458 860 17
FPGA : 0x0.0.3
Booting from : EEPROMO
   ------ output truncated -----!
```

Command output example: show sfm all

```
FTOS#show sfm all
Switch Fabric State: up
Switch Mode: SFM3
-- Switch Fabric Modules --
Slot Status
                  (Older version of SFM for Exascale)
(Older version of SFM for Exascale)
(Older version of SFM for Exascale)
 0 active
     active
  2
                               (Older version of SFM for Exascale)
      active
  4 not present
FTOS#
```

Table 3-1. show sfm Command Output Fields

Field	Description
Switch Fabric State:	States that the Switch Fabric is up (8 SFMs are online and operating).
Status	Displays the SFM's active status.
Card Type	States the type of SFM.

Table 3-1. show sfm Command Output Fields

Field	Description
Up Time	Displays the number of hours and minutes since the RPM's last reboot.
Temperature	Displays the temperature of the RPM. Minor alarm status if temperature is over 65° C.
Power Status	Displays power status: absent, down, or up
Serial Num	Displays the line card serial number.
Part Num	Displays the line card part number.
Vendor ID	Displays an internal code, which specifies the manufacturing vendor.
Date Code	Displays the line card's manufacturing date.
Country Code	Displays the country of origin. 01 = USA

show startup-config

CES

Display the startup configuration.

Syntax show startup-config

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Expanded to include last configuration change and start-up last updated (date and time) and who made the change.

Example Command output example (partial): **show startup-config**

```
FTOS#show startup-config

! Version 7.4.1.0
! Last configuration change at Thu Mar 29 02:16:07 2007 by default
! Startup-config last updated at Thu Mar 29 02:35:08 2007 by default
!
boot system rpm0 primary flash://FTOS-EF-7.4.1.0.bin
boot system rpm0 secondary flash://FTOS-EF-6.3.1.2.bin
boot system rpm0 default flash://FTOS-EF-6.5.1.8.bin
!
...
```

Related Commands

show running-config	Display current (running) configuration.	

show version

CESZ

Display the current FTOS version information on the system.

(S55) (S60)

54810

Syntax show version

Command Modes EXEC Privilege

Command History

Version 9.0.0.0	Introduced on Z9000.
Version 8.3.12.0	Introduced on S4810.
Version 7.6.1.0	Introduced on S-Series.
Version 7.5.1.0	Introduced on C-Series.

E-Series original Command

Example (E-Series)

```
FTOS#show version
```

Dell Force10 Networks Real Time Operating System SoftwareDe

Dell Force10 Operating System Version: 1.0

Dell Force10 Application Software Version: 5.3.1.0

Copyright (c) 1999-2004 by Dell Force10 Networks, Inc.

Build Time: Sun May 9 00:57:03 PT 2004

Build Path: /local/local0/Release/5-4-1/SW/Bsp/Diag Dell Force10 uptime is 1 days, 3 hours, 16 minutes

System image file is "/home/5.3.1/5.3.1.0/FTOS-ED-RPM1-5.3.1.0.bin"

Chassis Type: E1200

Control Processor: IBM PowerPC 405GP (Rev D) with 268435456 bytes of memory. Route Processor 1: IBM PowerPC 405GP (Rev D) with 536870912 bytes of memory. Route Processor 2: IBM PowerPC 405GP (Rev D) with 536870912 bytes of memory.

128K bytes of non-volatile configuration memory.

- 1 Route Processor Module
- 9 Switch Fabric Module
- 1 24-port GE line card with SFP optics (EE)
- 1 12-port GE Flex line card with SFP optics (EE)
- 1 2-port OC48c line card with SR optics (EC)
- 2 24-port GE line card with SX optics (EB)
- 1 2-port 10GE WAN PHY line card with 10Km (1310nm) optics (EE)
- 1 12-port GE Flex line card with SFP optics (EC)
- 1 2-port 10GE LAN PHY line card with 10Km (1310nm) optics (ED)
- 1 12-port OC12c/3c PoS line card with IR optics (EC)
- 1 24-port GE line card with SFP optics (ED)
- 1 FastEthernet/IEEE 802.3 interface(s)
- 120 GigabitEthernet/IEEE 802.3 interface(s)
- 14 SONET network interface(s)
- 4 Ten GigabitEthernet/IEEE 802.3 interface(s)

FTOS#

Example (S-Series)

FTOS#show version

Dell Force10 Networks Real Time Operating System Software

Dell Force10 Operating System Version: 1.0

Dell Force10 Application Software Version: E7-8-1-13

Copyright (c) 1999-2008 by Dell Force10 Networks, Inc.

Build Time: Mon Nov 24 18:59:27 2008

Build Path: /local/local/sw/build/build2/Release/7-8-1/SW/SRC

Dell Force10 uptime is 1 minute(s)

```
System Type: S50V
                   Control Processor: MPC8451E with 252739584 bytes of memory.
                   32M bytes of boot flash memory.
                     1 48-port E/FE/GE with POE (SB)
                    48 GigabitEthernet/IEEE 802.3 interface(s)
                     4 Ten GigabitEthernet/IEEE 802.3 interface(s)
                   FTOS#
Example
                   FTOS#
(S4810)
                   FTOS#show version
                   Dell Force10 Real Time Operating System Software
                   Dell Force10 Operating System Version: 1.0
                   Dell Force10 Application Software Version: Z9K-ICC-PRIM-SYNC-8-3-11-173
                   Copyright (c) 1999-2012 by Dell Inc. All Rights Reserved.
                   Build Time: Mon Jul 16 22:19:01 PDT 2012
                   Build Path: /local/local/build/build15/8.3.12.0/SW/SRC/Radius
                   FTOS uptime is 1 minute(s)
                   System image file is "s4810-14"
                   System Type: S4810
                   Control Processor: Freescale QorIQ P2020 with 2147483648 bytes of memory.
                   128M bytes of boot flash memory.
                     1 52-port GE/TE/FG (SE)
                    52 Ten GigabitEthernet/IEEE 802.3 interface(s)
                   FTOS#
                   FTOS#
                   FTOS#
                   FTOS#config t
                   FTOS(conf)#int te 0/5
                   FTOS(conf-if-te-0/5)#no shut
                   FTOS(conf-if-te-0/5)#
                   FTOS(conf-if-te-0/5)#
                   FTOS (conf-if-te-0/5)#
                   FTOS(conf-if-te-0/5)#ipv6 nd prefix FEC0::/10
                   FTOS (conf-if-te-0/5)#
                   FTOS(conf-if-te-0/5)#show conf
                   interface TenGigabitEthernet 0/5
                    ip address 78.21.1.3/24
                    ipv6 nd prefix fec0::/10
                    flowcontrol rx on tx on
                    no shutdown
                   FTOS(conf-if-te-0/5)#
                   FTOS#
```

Example (Z9000)

```
st-pet-z9k-6#show version
Dell Force10 Real Time Operating System Software
Dell Force10 Operating System Version: 2.1
Dell Force10 Application Software Version: 9.0(0.0)
Copyright (c) 1999-2012 by Dell Inc. All Rights Reserved.
Build Time: Mon Oct 22 00:52:30 PDT 2012
Build Path: /sites/sjc/work/build/buildSpaces/build04/E9-0-0/SW/SRC
st-pet-z9k-6 uptime is 23 hour(s), 23 minute(s)
System image file is "system://A"
System Type: Z9000 Control Processor: Intel Jasper Forest with 3474911232 bytes of memory.
8G bytes of boot flash memory.
   1 32-port TE/FG (ZB)
 24 Ten GigabitEthernet/IEEE 802.3 interface(s)
 26 Forty GigabitEthernet/IEEE 802.3 interface(s)
```

Table 3-2. show version Command Fields

Lines beginning with	Description
Dell Force10 Network	Name of the operating system
Dell Force10 Operating	OS version number
Dell Force10 Application	Software version
Copyright (c)	Copyright information
Build Time	Software build's date stamp
Build Path	Location of the software build files loaded on the system
Dell Force10 uptime is	Amount of time the system has been up
System image	Image file name
Chassis Type:	Chassis type (E1200, E600, E600i, E300, C300, C150)
Control Processor:	Control processor information and amount of memory on processor.
Route Processor 1:	E-Series route processor 1 information and the amount of memory on that processor.
Route Processor 2:	E-Series route processor 2 information and the amount of memory on that processor.
128K bytes	Amount and type of memory on system.
1 Route Processor	Hardware configuration of the system, including the number and type of physical interfaces available.

upgrade (E-Series version)

[E] Upgrade the bootflash, boot selector, or system image on a processor.

Syntax

upgrade {bootflash-image | bootselector-image | system-image} {all | linecard linecard-slot | rpm} {booted | file-url}

Parameters

bootflash-image	Enter the keyword bootflash-image to upgrade the bootflash image.
bootselector-image	Enter the keyword bootselector-image to upgrade the boot selector image.
	Use with TAC supervision only.
system-image	Enter the keyword system-image to upgrade the cache boot image.
all	Enter the keyword all to upgrade the bootflash/boot selector image on all processors in the E-Series. This keyword does not upgrade the bootflash on the standby RPM.
linecard linecard-slot	Enter the keyword linecard followed by the slot number to change the bootflash image on a specific line card.
	E-Series Range: 0 to 13 on the E1200; 0 to 6 for the E600; 0 to 5 on the E300
rpm	Enter the keyword rpm to upgrade the bootflash/boot selector image on all processors on the RPM.
booted	Enter this keyword to upgrade using the image packed with the currently running FTOS image.
file-url	Enter the following location keywords and information to upgrade using an FTOS image other than the one currently running:
	Enter the transfer method and file location:
	flash://filename
	ftp://userid:password@hostip/filepath
	slot0://filename
	tftp://hostip/filepath

Defaults

No configuration or default values

Command Modes

EXEC Privilege

Command History

Version 7.7.1.0	Removed alt-bootflash-image, alt-bootselector-image, alt-system-image options, rp1, rp2, and cp options.
E-Series original Co	ommand

Usage Information

A system message appears stating the Bootflash upgrade status. Reload the system to boot from the upgraded boot images.

Once the URL is specified, the same downloaded image can be used for upgrading an individual RPM, line cards, SFM FPGA, and system-image for cache-boot without specifying the *file-url* again using the command **upgrade** {bootflash-image | bootselector-image | system-image} {all | linecard linecard-slot | rpm}. After 20 minutes, the cached memory is released and returned for general use, but the URL is maintained and you do not have to specify it for subsequent upgrades.

Related Commands

upgrade fpga-image (E-Series)	Upgrade the FPGA version in the specified E-Series SFM.
boot system (S60)	Display configured boot image information

upgrade (C-Series version) Upgrade the bootflash or boot selector image on a processor.

Syntax

upgrade {bootflash-image | bootselector-image | system-image} {all | linecard {number | all} | rpm} [booted | file-url | repair]

Parameters

bootflash-image	Enter the keyword bootflash-image to upgrade the bootflash image.
bootselector-image	Enter the keyword bootselector-image to upgrade the boot selector image. Use with TAC supervision only.
system-image	Enter the keyword system-image to upgrade the system image. Use with TAC supervision only.
all	Enter the keyword all to upgrade the bootflash or boot selector image on all processors. This keyword does not upgrade the bootflash on the standby RPM.
	Enter the keyword all after the keyword linecard to upgrade the bootflash or boot selector image on all linecards.
linecard number	Enter the keyword linecard followed by the line card slot number. Range: E1200, E1200i AC/DC: 0-13 E600, E600i: 0-6 E300: 0-5 C300: 0-7 C150: 0-3
rpm	Enter the keyword rpm to upgrade the system image of a selector image on all processors on the RPM.
repair	Enter this keyword to upgrade a line card newly inserted into an already upgraded chassis. This option is only available with the system-image keyword.
booted	Upgrade the bootflash or bootselector image using the currently running FTOS image.
file-url	Enter the following location keywords and information to upgrade using an FTOS image other than the one currently running:
	 To specify an FTOS image on the internal flash, enter flash:// file-path/filename.
	 To specify an FTOS image on an FTP server, enter ftp:// user:password@hostip/filepath
	 To specify an FTOS image on the external flash on the primary RPM, slot0://file-path/filename
	 To copy a file on a TFTP server, enter tftp://hostip/filepath/ filename

Defaults

FTOS uses the boot flash image that was packed with it if no URL is specified.

Command Modes

EXEC Privilege

Command **History**

Version 7.7.1.0	Introduced system-image option
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

A system message appears stating the Bootflash upgrade status. Reload the system to boot from the upgraded boot images.

Once the URL is specified, the same downloaded image can be used for upgrading an individual RPM, line cards, SFM FPGA, and system-image for cache-boot without specifying the *file-url* again using the command **upgrade** {bootflash-image | bootselector-image | system-image} {all | linecard linecard-slot | rpm}. After 20 minutes, the cached memory is released and returned for general use, but the URL is maintained and you do not have to specify it for subsequent upgrades.

Related Commands

upgrade fpga-image (E-Series)	Upgrade the FPGA version in the specified E-Series SFM.
boot system (S60)	Display configured boot image information

upgrade (S-Series management unit)

Upgrade the bootflash image or system image of the S-Series management unit.

Syntax upgrade {boot | system} {ftp: | scp: | tftp: | flash: {A: |B:} | stack-unit | usbflash:} file-url

Parameters

boot	Enter this keyword to change the boot image.	
system	Enter this keyword to change the system image.	
ftp:	After entering this keyword you can either follow it with the location of the source file in this form: //userid:password@hostip/filepath, or press Enter to launch a prompt sequence.	
scp:	After entering this keyword you can either follow it with the location of the source file in this form: //userid:password@hostip/filepath, or press Enter to launch a prompt sequence.	
tftp:	After entering this keyword you can either follow it with the location of the source file in this form: //hostlocation/filepath, or press Enter to launch a prompt sequence.	
flash:	After entering this keyword you can either follow it with the location of the source file in this form: <i>flash//filepath</i> ,or press Enter to launch a prompt sequence.	
	S60 only	
A: B:	Enter the partition to upgrade from the flash.	
	S60 only	
stack-unit:	After entering this keyword to synch the image to the stack-unit.	
usbflash:	After entering this keyword you can either follow it with the location of the source file in this form: <i>usbflash://filepath</i> , or press Enter to launch a prompt sequence. S60 only	

Defaults

No configuration or default values

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60
Version 7.7.1.0	Added support for TFTP and SCP.
Version 7.6.1.0	Introduced on S-Series

Usage Information

You must reload FTOS after executing this command. Use the command upgrade system stack-unit (S-Series stack member) on page 242 to copy FTOS from the management unit to one or more stack members.

```
FTOS#upgrade system ?
                      Copy from remote file system (ftp://userid:password@hostip/filepath) Copy from remote file system (scp://userid:password@hostip/filepath)
ftp:
scp:
tftp: Copy from remote file system (tftp://hostip/filepath) FTOS#$pgrade system ftp://username:password@10.11.1.1/FTOS-SB-7.7.1.0.bin
Erasing Sseries ImageUpgrade Table of Contents, please wait
12946259 bytes successfully copied
FTOS#reload
```

upgrade fpga-image (E-Series)

 \mathbb{E} Upgrade the FPGA version in the specified E-Series SFM and automatically initiate an automatic reset to complete the version upgrade.

Syntax

upgrade fpga-image {sfm} {**all** | *id*} [booted | flash:// | ftp: |slot0: | tftp]

Parameters

sfm	Enter the keyword sfm to upgrade the FPGA on the SFMs.	
rpm	Enter the keyword rpm to upgrade all processors on the RPM.	
all	Enter the keyword all to upgrade the FPGA on all the SFMs.	
id	Enter the keyword id to upgrade the FPGA on all a specific SFM.	
Enter the path to the upgrade source. Entering <cr> updates the FPGA from the flash.</cr>		

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.1.0	Added rpm option
Version 7.5.1.0	Introduced on E-Series

Example

Command example: upgrade sfm autoreset

```
FTOS#upgrade sfm 1 autoreset
SFM1: upgrade in progress
SFM1: upgrade complete
SFM1 is active. Resetting it might temporarily impact traffic.
Proceed with reset [confirm yes/no]: yes
FTOS#
```

Related Commands

show sfm	Display the SFM status.
upgrade (E-Series version)	Upgrade the E-Series.

.Usage Information

On E-Series ExaScale, you cannot upgrade SFMs using this command when Cache Boot is configured. If you attempt an upgrade, you must reload the chassis to recover.

upgrade_fpga-image (C-Series)

C Upgrade the primary FPGA image.

Country consumed forms income (and

Syntax upgrade fpga-image {rpm $\{number \mid all\} \mid linecard \{number \mid all\} \mid system-fpga \mid link-fpga \mid all\} \{booted \mid file-url\}$

Parameters

rpm number	Enter rpm followed by the RPM slot number to upgrade an RPM FPGA	
•	Range: 0-1	
linecard number	Enter linecard followed by the line card slot number to upgrade a linecard FPGA.	
	Range: 0-7 on the C300, 0-3 on the C150	
all	Enter the keyword all to upgrade all RPM and linecard FPGAs. Enter the keyword all after the keyword rpm to upgrade all FPGAs on all RPMs.	
	Enter the keyword all after the keyword linecard to upgrade all FPGAs on all linecards.	
system-fpga	(OPTIONAL) Enter system-fpga to upgrade only the system FPGA on a fiber line card. Contact the Dell Networking TAC before using this keyword.	
link-fpga	(OPTIONAL) Enter link-fpga to upgrade only the link FPGA on a fiber line card. Contact the Dell Networking TAC before using this keyword.	
booted	Upgrade the FPGA image using the currently running FTOS image.	
file-url	Enter the following location keywords and information to upgrade the FPGA using an FTOS image other than the one currently running:	
	 To specify an FTOS image on the internal flash, enter flash:// file-path/filename. 	
	 To specify an FTOS image on an FTP server, enter ftp:// user:password@hostip/filepath 	
	 To specify an FTOS image on the external flash on the primary RPM, slot0://file-path/filename 	
	 To copy a file on a TFTP server, enter tftp://hostip/filepath/ filename 	

Defaults

None.

Command Mode

EXEC Privilege

Command History

Version 7.7.1.0	Renamed the primary-fpga-flash keyword to fpga-image . Added support for upgrading using a remote FTOS image.
Version 7.6.1.0	Added support for the all keyword
Version 7.5.1.0	Introduced on C-Series

Example Command example: upgrade fpga-image

```
.
FTOS#conf
FTOS(conf)# upgrade primary-fpga-flash rpm
Proceed to upgrade primary fpga flash for rpm 0 [confirm yes/no]: yes
FTOS#
```

Usage Information

Reset the card using the **power-cycle** option after restoring the FPGA command.

Related Commands

reset	Reset a line card or RPM.
restore fpga-image	This command copies the backup FPGA image to the primary FPGA image.

upgrade fpga-image (S60)

(S60)

Upgrade the FPGA version on the S60.

Syntax upgrade fpga-image stack-unit { 0-11} booted

Parameters

stack-unit	Enter the keyword stack-unit to upgrade the FPGA on the specified S60 chassis.	
booted	Upgrade the FPGA image using the currently running FTOS image.	

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1 Introduced on the S60

Example

Command example: upgrade fpga-image

```
FTOS#upgrade fpga-image stack-unit 0 booted
Current FPGA information in the system:
_____
                        FPGA Name Current Version New Version
 Card
UnitO
                 S60 SYSTEM FPGA
   * Warning - Upgrading FPGA is inherently risky and should
   \star only be attempted when necessary. A failure at this upgrade may
   * cause a board RMA. Proceed with caution! *
Upgrade fpga image for stack-unit 0 [yes/no]: yes
FPGA upgrade in progress. Please do NOT power off the card.
11111111111111111111
Upgrade result :
Unit 0 FPGA upgrade successful. Power cycle the stack-unit to complete the
upgrade.
FTOS#
```

Control and Monitoring

Overview

This chapter contains the following commands to configure and monitor the system, including Telnet, FTP, and TFTP as they apply to platforms C E S.

Commands

audible cut-off	show command-history
banner exec	show command-tree
banner login	show console lp
banner motd	show cpu-traffic-stats
cam-audit linecard	show debugging
clear alarms	show environment (C-Series and E-Series)
clear command history	show environment (S-Series)
clear line	show inventory (C-Series and E-Series)
configure	show inventory (S-Series)
debug cpu-traffic-stats	show linecard
debug ftpserver	show linecard boot-information
disable	show memory (C-Series and E-Series)
do	show memory (S-Series)
enable	show processes cpu (C-Series and E-Series)
enable xfp-power-updates	show processes cpu (S-Series)
end	show processes ipc flow-control
epoch	show processes memory (C-Series and E-Series)
exec-banner	show processes memory (S-Series)
exec-timeout	show rpm
exit	show software ifm
ftp-server topdir	show switch links
ftp-server username	show system (S-Series)
hostname	show tech-support (C-Series and E-Series)
ip ftp password	show tech-support (S-Series)

ip ftp source-interface	show chassis
ip ftp username	ssh-peer-rpm
ip telnet server enable	ssh-peer-stack-unit
ip telnet source-interface	telnet
ip tftp source-interface	telnet-peer-stack-unit
line	telnet-peer-stack-unit
linecard	terminal length
module power-off	terminal xml
motd-banner	traceroute
ping	undebug all
power-off	util-threshold cpu (C- and E-Series)
power-on	util-threshold cpu (S-Series)
reload	util-threshold mem (C- and E-Series)
reset	util-threshold mem (S-Series)
rpm <slot> location-led</slot>	upload trace-log
send	virtual-ip
service timestamps	write
show alarms	

audible cut-off

Turn off an audible alarm.

Syntax audible cut-off

Defaults Not configured.

Command Modes EXEC Privilege

banner exec

CES Configure a message that is displayed when a user enters the EXEC mode.

Syntax banner exec c line c

To delete a banner, enter **no banner exec**.

Parameters

С	Enter the keywords banner exec , and then enter a character delineator, represented her by the letter c , and press ENTER.	
line	Enter a text string for your banner message ending the message with your delineator.	
	In the example below, the delineator is a percent character (%); the banner message is "testing, testing".	

Defaults No banner is displayed.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

Optionally, use the **banner exec** command to create a text string that is displayed when the user accesses the EXEC mode. The **exec-banner** command toggles that display.

Example

```
FTOS(conf)#banner exec ?
LINE
                        c banner-text c, where 'c' is a delimiting character
FTOS(conf)#banner exec %
Enter TEXT message. End with the character '%'.
This is the banner%
FTOS (conf) #end
FTOS#exit
4d21h5m: %RPMO-P:CP %SEC-5-LOGOUT: Exec session is terminated for user on line
This is the banner
FTOS con0 now available
Press RETURN to get started.
4d21h6m: %RPMO-P:CP %SEC-5-LOGIN SUCCESS: Login successful for user on line
console
This is the banner
FTOS>
```

Related **Commands**

banner login	Sets a banner for login connections to the system.
banner motd	Sets a Message of the Day banner.
exec-banner	Enable the display of a text string when the user enters the EXEC mode.
line	Enable and configure console and virtual terminal lines to the system.

banner login

CES

Set a banner to be displayed when logging on to the system.

Syntax

banner login {keyboard-interactive | no keyboard-interactive} [$c \ line \ c$]

Enter **no banner login** to delete the banner text.

Enter no banner login keyboard-interactive to automatically go to the banner message prompt (does not require a carriage return).

Parameters

keyboard-interactive	Enter this keyword to require a carriage return (CR) to get the message banner
	prompt.

С	Enter a delineator character to specify the limits of the text banner. In Figure 4-1, the % character is the delineator character.
line	Enter a text string for your text banner message ending the message with your delineator.
	In the example in Figure 4-1, the delineator is a percent character (%).
	Ranges:
	• maximum of 50 lines
	• up to 255 characters per line

Defaults

No banner is configured and the CR is required when creating a banner.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced keyboard-interactive keyword
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0 Introduced on C-Series	
E-Series original Command	

Usage Information

A login banner message is displayed only in EXEC Privilege mode after entering the **enable** command followed by the password. These banners are not displayed to users in EXEC mode.

Related Commands

banner exec	Sets a banner to be displayed when you enter EXEC Privilege mode.
banner motd	Sets a Message of the Day banner.

Example

Figure 4-1. Command Example: banner login

```
FTOS(conf) #banner login ?
                         Press enter key to get prompt c banner-text c, where 'c' is a delimiting character
keyboard-interactive
LINE
FTOS(conf) #no banner login ?
                          Prompt will be displayed by default
keyboard-interactive
<cr>
FTOS(conf) #banner login keyboard-interactive
Enter TEXT message.
                      End with the character '%'.
This is the banner%
FTOS (conf) #end
FTOS#exit
13d21h9m: %RPMO-P:CP %SEC-5-LOGOUT: Exec session is terminated for user on line
This is the banner
FTOS con0 now available
Press RETURN to get started.
13d21h10m: %RPM0-P:CP %SEC-5-LOGIN_SUCCESS: Login successful for user on line
console
This is the banner
FTOS>
```

banner motd

CES

Set a Message of the Day (MOTD) banner.

Syntax

banner motd c line c

To delete a Message of the Day banner, enter **no banner motd**.

Parameters

С	Enter a delineator character to specify the limits of the text banner. In the above figures, the % character is the delineator character.
line	Enter a text string for your message of the day banner message ending the message with your delineator.
	In the example figures above, the delineator is a percent character (%).

Defaults

No banner is configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0 Introduced on C-Series	
E-Series original Command	

Usage Information

A MOTD banner message is displayed only in EXEC Privilege mode after entering the **enable** command followed by the password. These banners are not displayed to users in EXEC (non-privilege)

Related Commands

banner exec	Sets a banner to be displayed when you enter the EXEC Privilege mode.
banner login	Sets a banner to be displayed after successful login to the system.

cam-audit linecard

Enable audit of the IPv4 forwarding table on all line cards.

Syntax

cam-audit linecard all ipv4-fib interval time-in-minutes

To disable audit, use the no cam-audit linecard all ipv4-fib command

Parameters

all	Enter the keyword all to enable CAM audit on all line cards.
ipv4-fib	Enter the keyword ipv4-fib to designate the CAM audit on the IPv4 forwarding entries.
interval time-in-minutes	Enter the keyword interval followed by the frequency in minutes of the CAM audit.
	Range: 5 to 1440 minutes (24 hours)
	Default: 60 minutes

Defaults

Disabled

Command Modes CONFIGURATION

Command History

Version 7.4.1.0 Introduced on E-Series

Usage Information Enables periodic audits of software and hardware copies of the IPv4 forwarding table.

clear alarms

C E S Clear alarms on the system.

Syntax clear alarms

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information This command clear alarms that are no longer active. If an alarm situation is still active, it is seen in the system output.

clear command history

C E S Clear the command history log.

Syntax clear command history

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Related Commands

show command-history Display a buffered log of all commands entered by all users along with a time stamp.

clear line

CES Reset a terminal line.

Syntax clear line { line-number | aux 0 | console 0 | vty number}

Parameters

line-number	Enter a number for one of the 12 terminal lines on the system.
	Range: 0 to 11.
aux 0	Enter the keywords aux 0 to reset the Auxiliary port.
	Note: This option is supported on E-Series only.
console 0	Enter the keyword console 0 to reset the Console port.
vty number	Enter the keyword vty followed by a number to clear a Terminal line.
	Range: 0 to 9

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

configure

CES

Enter the CONFIGURATION mode from the EXEC Privilege mode.

Syntax

configure [terminal]

Parameters

terminal	(OPTIONAL) Enter the keyword terminal to specify that you are configuring from the
	terminal.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Example

Figure 4-2. Command Example: configure

FTOS#configure FTOS (conf)#

debug cpu-traffic-stats

CES Enable the collection of CPU traffic statistics.

Syntax debug cpu-traffic-stats

To disable the debugging, execute the **no debug cpu-traffic-stats** command.

Defaults Disabled

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

This command enables (and disables) the collection of CPU traffic statistics from the time this command is executed (not from system boot). However, excessive traffic received by a CPU will automatically trigger (turn on) the collection of CPU traffic statics. The following message is an indication that collection of CPU traffic is automatically turned on. Use the show cpu-traffic-stats to view the traffic statistics.

Excessive traffic is received by CPU and traffic will be rate controlled



Note: This command must be enabled before the show cpu-traffic-stats command will display traffic statistics. Dell Networking recommends that you disable debugging (**no debug cpu-traffic-stats**) once troubleshooting is complete.

Related Commands

show cpu-traffic-stats Display cpu traffic statistics

debug ftpserver

CES

View transactions during an FTP session when a user is logged into the FTP server.

Syntax

debug ftpserver

To stop debugging, enter **no debug ftpserver**.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

disable

CE

Return to the EXEC mode.

Syntax

disable [level]

Parameters

level	(OPTIONAL) Enter a number for a privilege level of the FTOS.
	Range: 0 to 15.
	Default: 1

Defaults

1

Command Modes

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
, 6 151511 0111110	ma obacca on E series Emission
Version 7.6.1.0	Introduced on S-Series
version 7.0.1.0	introduced on 5-series
Version 7.5.1.0	Introduced on C-Series
version 7.3.1.0	introduced on C-Series
E-Series original Command	
E-Series original C	command

do



Allows the execution of most EXEC-level commands from all CONFIGURATION levels without returning to the EXEC level.

Syntax

do command

Parameters

	E / EVECT 1	
command	Enter an EXEC-level command.	
00		

Defaults

No default behavior

Command Modes

CONFIGURATION

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced on E-Series

Usage Information

The following commands are *not* supported by the **do** command:

- enable
- disable
- exit
- config

Example

Figure 4-3. Command Example: do

```
FTOS(conf-if-te-5/0)#do clear counters
Clear counters on all interfaces [confirm]
FTOS (conf-if-te-5/0) # FTOS (conf-if-te-5/0) #do clear logging Clear logging buffer [confirm]
FTOS(conf-if-te-5/0)#
FTOS(conf-if-te-5/0)#do reload
System configuration has been modified. Save? [yes/no]: n \,
Proceed with reload [confirm yes/no]: n
FTOS(conf-if-te-5/0)#
```

enable

CES

Enter the EXEC Privilege mode or any other privilege level configured. After entering this command, you may need to enter a password.

Syntax

enable [level]

Parameters

level	(OPTIONAL) Enter a number for a privilege level of FTOS.
	Range: 0 to 15.
	Default: 15

Defaults

15

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

Users entering the EXEC Privilege mode or any other configured privilege level can access configuration commands. To protect against unauthorized access, use the enable password command to configure a password for the **enable** command at a specific privilege level. If no privilege level is specified, the default is privilege level 15.

Related Commands

enable password Configure a password for the enable command and to access a privilege level.

enable xfp-power-updates

CES

Enable XFP power updates for SNMP.

Syntax

enable xfp-power-updates interval seconds

To disable XFP power updates, use the **no enable xfp-power-updates** command.

Parameters

interval seconds	Enter the keyword interval followed by the polling interval in seconds.
	Range: 120 to 6000 seconds
	Default: 300 seconds (5 minutes)

Defaults

Disabled

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

The chassis MIB contain the entry chSysXfpRecvPower in the chSysPortTable table. Periodically, IFA polls the XFP power for each of the ports, and sends the values to IFM where it is cached. The default interval for the polling is 300 seconds (5 minutes). Use this command to enable the polling and to configure the polling frequency.

end

CES

Return to the EXEC Privilege mode from other command modes (for example, the CONFIGURATION or ROUTER OSPF modes).

Syntax

end

Command Modes

CONFIGURATION, SPANNING TREE, MULTIPLE SPANNING TREE, LINE, INTERFACE, TRACE-LIST, VRRP, ACCESS-LIST, PREFIX-LIST, AS-PATH ACL, COMMUNITY-LIST, ROUTER OSPF, ROUTER RIP, ROUTER ISIS, ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Related **Commands**

exit	Return to the lower command mode.	

epoch

 \mathbb{E}

Set the epoch scheduling time for the chassis.

Syntax

epoch {2.4 | 3.2 | 10.4}

To return to the default setting, enter **no epoch**.

Parameters

2.4	Enter the keyword 2.4 to set the epoch to 2.4 micro-seconds and lower the latency.
	This option is available on the E600i and E1200i E-Series ExaScale systems only.
3.2	Enter the keyword 3.2 to set the epoch to 3.2 micro-seconds and lower the latency.
	This option is available on the E600/E600i and E1200/E1200i only. ExaScale does not supports this setting with FTOS 8.3.1.0 and later.
10.4	Enter the keyword 10.4 to set the epoch to 10.4 micro-seconds.
	This is the default setting and is available on the E300, E600/E600i, and E1200.

Defaults

10.4

Command Modes

CONFIGURATION

Command History

Version 8.3.1.0	Added 2.4 micro-seconds option. ExaScale supports only 10.4 microseconds and 2.4 microseconds with FTOS 8.3.1.0 and later.
Version 8.1.1.2	Introduced on E-Series ExaScale E600i

Version 8.1.1.0	Introduced on E-Series ExaScale E1200i
Version 6.2.1.1	Support for E300 introduced (10.4 only)
Version 6.1.1.0	Values changed as described above

Usage Information

You save the configuration and reload the chassis for the changes to the **epoch** command setting to take affect

When using 10 SFMs in an ExaScale chassis, the 10.4 and 2.4 settings are both linerate. Additionally, the 2.4 setting has a lower latency.

When using 9 SFMs in an ExaScale chassis, the 10.4 setting is linerate; the 2.4 setting reduces throughput. Dell Networking recommends using the 10.4 setting when the system has 9 SFMs.

Using 8 SFMs in an ExaScale chassis reduces throughput at any epoch setting.



Note: The E300 supports only the 10.4 epoch setting. The E-Series TeraScale E600/E600i and the E1200/E1200i systems support the 10.4 and the 3.2 epoch settings.



Note: For E-Series ExaScale, the 2.4 setting is supported on FTOS version 8.3.1.0 and later. The 10.4 setting is supported on all ExaScale FTOS versions. The 3.2 setting is only supported on FTOS versions 8.2.1.0 and earlier.

exec-banner

CES

Enable the display of a text string when the user enters the EXEC mode.

Syntax exec-banner

To disable the banner on terminal lines, enter **no exec-banner**.

Defaults

Enabled on all lines (if configured, the banner appears).

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage

Optionally, use the **banner exec** command to create a text string that is displayed when the user accesses the EXEC mode. This command toggles that display.

Related Commands

banner exec	Configure a banner to display when entering the EXEC mode.
line	Enable and configure console and virtual terminal lines to the system.

exec-timeout

CES

Set a time interval the system will wait for input on a line before disconnecting the session.

Syntax

exec-timeout minutes [seconds]

To return to default settings, enter **no exec-timeout**.

Parameters

minutes	Enter the number of minutes of inactivity on the system before disconnecting the current session. Range: 0 to 35791 Default: 10 minutes for console line; 30 minutes for VTY line.
seconds	(OPTIONAL) Enter the number of seconds Range: 0 to 2147483 Default: 0 seconds

Defaults

10 minutes for console line; 30 minutes for VTY lines; 0 seconds

Command Modes

LINE

Command History

	Version 8.3.3.1	Introduced on the S60.
	Version 7.6.1.0	Introduced on S-Series
	Version 7.5.1.0	Introduced on C-Series
E-Series original Command		nmand

Usage Information

To remove the time interval, enter **exec-timeout 0 0**.

Example

Figure 4-4. FTOS time-out display

FTOS con0 is now available Press RETURN to get started.

exit



Return to the lower command mode.

Syntax

exit

Command Modes

EXEC Privilege, CONFIGURATION, LINE, INTERFACE, TRACE-LIST, PROTOCOL GVRP, SPANNING TREE, MULTIPLE SPANNING TREE, MAC ACCESS LIST, ACCESS-LIST, AS-PATH ACL, COMMUNITY-LIST, PREFIX-LIST, ROUTER OSPF, ROUTER RIP, ROUTER ISIS, ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
E-Series original C	ommand

Related Commands

end Return to the EXEC Privilege command mode.

ftp-server enable

CES Enable FTP server functions on the system.

Syntax ftp-server enable

To disable FTP server on the system, enter **no ftp-server enable**.

Defaults Disabled.

Command Modes CONFIGURATION

Command History

	Version 8.3.3.1	Introduced on the S60.
	Version 8.1.1.0	Introduced on E-Series ExaScale
	Version 7.6.1.0	Introduced on S-Series
	Version 7.5.1.0	Introduced on C-Series
E-Series original Command		mmand

Example Figure 4-5. Example of Logging on to an FTP Server

```
morpheus% ftp 10.31.1.111
Connected to 10.31.1.111.
220 FTOS (1.0) FTP server ready
Name (10.31.1.111:dch): dch
331 Password required
Password:
230 User logged in
ftp> pwd
257 Current directory is "flash:"
ftp> dir
200 Port set okay
150 Opening ASCII mode data connection
                                  name
 size
              date time
    512
           Jul-20-2004 18:15:00
                                  tgtimg
    512
           Jul-20-2004 18:15:00
                                  diagnostic
           Jul-20-2004 18:15:00
    512
                                  other
           Jul-20-2004 18:15:00
    512
                                  tgt
226 Transfer complete
329 bytes received in 0.018 seconds (17.95 Kbytes/s)
ftp>
```

Related Commands

ftp-server topdir	Set the directory to be used for incoming FTP connections to the E-Series.
ftp-server username	Set a username and password for incoming FTP connections to the E-Series.

ftp-server topdir

CES Specify the top-level directory to be accessed when an incoming FTP connection request is made.

Syntax ftp-server topdir directory

To return to the default settings, enter no ftp-server topdir.

Parameters

directory Enter the directory path.

Defaults The internal flash is the default directory.

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information After you enable FTP server functions with the ftp-server enable command, Dell Networking recommends that you specify a top-level directory path. Without a top-level directory path specified, the FTOS directs users to the flash directory when they log in to the FTP server.

Related Commands

ftp-server enable	Enables FTP server functions on the E-Series.
ftp-server username	Set a username and password for incoming FTP connections to the E-Series.

ftp-server username

CES Create a user name and associated password for incoming FTP server sessions.

Syntax ftp-server username username password [encryption-type] password

To delete a user name and its password, use the **no ftp-server username** username command.

Parameters

username	Enter a text string up to 40 characters long as the user name.
password password	Enter the keyword password followed by a string up to 40 characters long as the password.
	Without specifying an encryption type, the password is unencrypted.
encryption-type	(OPTIONAL) After the keyword password enter one of the following numbers:
	 0 (zero) for an unecrypted (clear text) password 7 (seven) for hidden text password.

Defaults Not enabled.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

hostname

CES

Set the host name of the system.

Syntax

hostname name

To delete a hostname assigned, enter **no hostname**.

Parameters

name Enter a text string, up to 32 characters long.

Defaults

FTOS

Command Modes

CONFIGURATION

Command History

Version 8.3.3.9	Default changed to FTOS.
Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

The hostname is used in the prompt.

ip ftp password

CES

Specify a password for outgoing FTP connections.

Syntax

ip ftp password [encryption-type] password

To remove a password and return to the default setting, use the **no ip ftp password** [password] command.

Parameters

encryption-type	(OPTIONAL) Enter one of the following numbers:
	• 0 (zero) for an unecrypted (clear text) password
	 7 (seven) for hidden text password
password	Enter a string up to 40 characters as the password.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

The password is listed in the configuration file; you can view the password by entering the **show** running-config ftp command.

The password configured by the ip ftp password command is used when you use the ftp: parameter in the copy command.

Related **Commands**

copy	Copy files.
ip ftp username	Set the user name for FTP sessions.

ip ftp source-interface

CES

Specify an interface's IP address as the source IP address for FTP connections.

Syntax

ip ftp source-interface interface

To delete an interface, use the **no ip ftp source-interface** interface command.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword **loopback** followed by a number from zero (0) to 16383.
- For a Port Channel interface, enter the keyword **port-channel** followed by a number:

C-Series and S-Series: 1-128

E-Series: 1 to 255 for TeraScale and ExaScale

- For SONET interface types, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a VLAN interface, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults

The IP address on the system that is closest to the Telnet address is used in the outgoing packets.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Increased number of VLANs on ExaScale to 4094 (was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series

Version 7.5.	1.0 Introduced on C-Series
E-Series original Command	
сору	Copy files from and to the switch.

Related Commands

ip ftp username

CES Assign a user name for outgoing FTP connection requests.

Syntax ip ftp username username

To return to anonymous FTP connections, use the **no ip ftp username** [username] command.

Parameters

username Enter a text string as the user name up to 40 characters long.

Defaults No user name is configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information You must also configure a password with the ip ftp password command.

Related Commands

ip ftp password Set the password for FTP connections.

ip telnet server enable

CES Enable the Telnet server on the switch.

Syntax ip telnet server enable

To disable the Telnet server, execute the **no ip telnet server enable** command.

Defaults Enabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced on E-Series

ip telnet source-interface

CES

Set an interface's IP address as the source address in outgoing packets for Telnet sessions.

Syntax

ip telnet source-interface interface

To return to the default setting, use the **no ip telnet source-interface** [interface] command.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword **loopback** followed by a number from zero (0) to 16383.
- For the SONET interfaces, enter the keyword **sonet** followed by slot/port information.
- For a Port Channel, enter the keyword **port-channel** followed by a number:

C-Series and S-Series: 1-128

E-Series: 1 to 255 for TeraScale and ExaScale

- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For VLAN interface, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults

The IP address on the system that is closest to the Telnet address is used in the outgoing packets.

Command Modes

CONFIGURATION

Command **History**

Introduced on the S60.
Increased number of VLANs on ExaScale to 4094 (was 2094)
Introduced on E-Series ExaScale
Support added for S-Series
Introduced on C-Series
ommand

Related Commands

telnet Telnet to another device.	
----------------------------------	--

ip tftp source-interface

[C][E][S]

Assign an interface's IP address in outgoing packets for TFTP traffic.

Syntax

ip tftp source-interface interface

To return to the default setting, use the **no ip tftp source-interface** interface command.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword loopback followed by a number from zero (0) to 16383.
- For a Port Channel, enter the keyword **port-channel** followed by a number:

C-Series and S-Series: 1-128

E-Series: 1 to 255 for TeraScale and ExaScale

- For the SONET interfaces, enter the keyword **sonet** followed by slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a VLAN interface, enter the keyword vlan followed by a number from 1 to 4094.

Defaults

The IP address on the system that is closest to the Telnet address is used in the outgoing packets.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Increased number of VLANs on ExaScale to 4094 (was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Cor	mmand

line



Enable and configure console and virtual terminal lines to the system. This command accesses LINE mode, where you can set the access conditions for the designated line.

Syntax

line {aux 0 | console 0 | vty number [end-number]}

Parameters

aux 0	Enter the keyword aux 0 to configure the auxiliary terminal connection. Note: This option is supported on E-Series only.
console 0	Enter the keyword console 0 to configure the console port. The console option for the S-Series is <0-0>.
vty number	Enter the keyword vty followed by a number from 0 to 9 to configure a virtual terminal line for Telnet sessions. The system supports 10 Telnet sessions.
end-number	(OPTIONAL) Enter a number from 1 to 9 as the last virtual terminal line to configure. You can configure multiple lines at one time.

Defaults

Not configured

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

You cannot delete a terminal connection.

Related Commands

access-class	Restrict incoming connections to a particular IP address in an IP access control list (ACL).
password	Specify a password for users on terminal lines.
show linecard	Display the line card(s) status.

linecard

CE

Pre-configure a line card in a currently empty slot of the system or a different line card type for the slot.

Syntax

linecard number card-type

To delete a card setting, use the **no linecard** *number* command.

Parameters

number	Enter the number of the slot.
	C-Series Range: 0-7
	E-Series Range: 0 to 13 on a E1200/E1200i, 0 to 6 on a E600/E6001, and 0 to 5 on a
	E300.
card-type	Enter the line card ID (see the Supported Hardware section in the Release Notes).

Defaults

Not configured

Command Modes

CONFIGURATION

Command **History**

Version 8.1.1.2	Introduced on E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale E1200i
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

Use this command only for empty slots or a slot where you have hot-swapped a different line card type. Before inserting a card of a different type into the pre-configured slot, execute the no linecard number command. The following screenshot shows the current supported C-Series line cards, along with their "card types" (card-type IDs).

Figure 4-6. Command Example: show linecard on Empty C300 Slot

```
FTOS#show linecard 3
   Line card 11 --
Status
             : not present
FTOS#linecard 3 ?
E46TB 36-port GE 10/100/1000Base-T with RJ45 - 8-port FE/GE with SFP - 2-port 10GE
E46VB 36-port GE 10/100/1000Base-T with RJ45 and PoE - 8-port FE/GE with SFP -
2-port 10GE with SFP+
E48PB 48-port FE/GE line card with SFP optics (CB)
E48TB 48-port GE 10/100/1000Base-T line card with RJ45 interfaces (CB)
E48VB 48-port GE 10/100/1000Base-T line card with RJ45 interfaces and PoE (CB)
EX4PB 4-port 10GE LAN PHY line card with XFP optics (CB)
EX8PB 8-port 10GE LAN PHY line card with XFP optics (CB)
FTOS#linecard 3 EX4PB
FTOS#show linecard 3
-- Line card 11 --
             : not present
Status
Required Type : EX4PB - 4-port 10GE LAN PHY line card with XFP optics (CB)
FTOS#
```



Note: It is advisable to shut down interfaces on a line card that you are hot-swapping.

Related Commands

show linecard Display the line card(s) status.

module power-off

Turn off power to a line card at next reboot.

Syntax module power-off linecard number

To remove the command from the running configuration, use the **no module power-off linecard** *number* command.

Parameters

linecard number	Enter the keyword line card followed by the line card slot number
	C-Series Range: 0-7
	E-Series Range: 0 to 13 on a E1200/1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a
	E300.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.1.1.2	Introduced on E-Series ExaScale E600i	
Version 8.1.1.0	Introduced on E-Series ExaScale E1200i	
Version 7.5.1.0	Introduced on C-Series	
E-Series original C	E-Series original Command	

motd-banner

CES

Enable a Message of the Day (MOTD) banner to appear when you log in to the system.

Syntax

motd-banner

To disable the MOTD banner, enter no motd-banner.

Defaults

Enabled on all lines.

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	



Test connectivity between the system and another device by sending echo requests and waiting for replies.

Syntax

ping [vrf <id>] [host | ip-address | ipv6-address] [count {number | continuous}] [datagram-size] [timeout] $[source\ (ip\ src\ ipv4\ -address)\ /\ interface]$ [tos] $[df\ -bit\ (y/n)]$ $[validate\ -reply(y/n)]$ [pattern]pattern] [sweep-min-size] [sweep-max-size] [sweep-interval] [ointerface (ip src-ipv4-address) | *interface*]

Parameter

(OPTIONAL) E-Series Only : Enter the VRF Instance name of the device to which you are testing connectivity.
(OPTIONAL) Enter the host name of the devices to which you are testing connectivity.
(OPTIONAL) Enter the IPv4 address of the device to which you are testing connectivity. The address must be in the dotted decimal format.
(OPTIONAL) E-Series only Enter the IPv6 address, in the X:X:X:X format, to which you are testing connectivity.
Note: The :: notation specifies successive hexadecimal fields of zeros
Enter the number of echo packets to be sent.
number: 1- 2147483647
Continuous: transmit echo request continuously
Default: 5
Enter the ICMP datagram size.
Range: 36 - 15360 bytes
Default: 100
Enter the interval to wait for an echo reply before timing out.
Range: 0 -3600 seconds
Default: 2 seconds

source	 (IPv4 only) Enter the IPv4 source ip address or the source interface. Enter the IP address in A.B.C.D format For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet
	For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet
	For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet
	followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel, enter the keyword port-channel followed by a number:
	C-Series and S-Series: 1-128
	E-Series: 1 to 255 for TeraScale and ExaScale
	• E-Series only For the SONET interfaces, enter the keyword sonet followed by slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN interface, enter the keyword vlan followed by a number from 1 to 4094.
tos	(IPv4 only) Enter the type of service required.
	Range: 0-255
	Default: 0
df-bit	(IPv4 only) Enter Y or N for the "don't fragment" bit in IPv4 header
	N: Do not set the "don't fragment" bit
	Y: Do set "don't fragment" bit
	Default is No.
validate-reply	(IPv4 only) Enter Y or N for reply validation.
,	N: Do not validate reply data
	Y: Do validate reply data
	Default is No.
pattern pattern	(IPv4 only) Enter the IPv4 data pattern.
,	Range: 0-FFFF
	Default: 0xABCD
sweep-min-size	Enter the minimum size of datagram in sweep range.
	Range: 52-15359 bytes
sweep-max-size	Enter the maximum size of datagram in sweep range.
onoop max 0,20	Range: 53-15359 bytes
sweep-interval	Enter the incremental value for sweep size.
Sweep interval	1-15308 seconds
ointerface	(IPv4 only) Enter the outgoing interface for multicast packets.
Ulliteriace	Enter the IP address in A.B.C.D format
	For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet
	followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel, enter the keyword port-channel followed by a number:
	C-Series and S-Series: 1-128
	E-Series: 1 to 255 for TeraScale and ExaScale
	• E-Series only For the SONET interfaces, enter the keyword sonet followed by slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	J 1

Defaults See parameters above.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced extended ping options.
Version 8.2.1.0	Introduced on E-Series ExaScale (IPv6)
Version 8.1.1.0	Introduced on E-Series ExaScale (IPv4)
Version 7.9.1.0	Introduced VRF
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced support for C-Series
Version 7.4.1.0	Added support for IPv6 address on E-Series

Usage Information

When you enter the **ping** command without specifying an IP/IPv6 address (Extended Ping), you are prompted for a target IP/IPv6 address, a repeat count, a datagram size (up to 1500 bytes), a timeout in seconds, and for Extended Commands. See Appendix A, ICMP Message Types for information on the ICMP message codes that return from a ping command.

Figure 4-7. Command Example: ping (IPv4)

```
FTOS#ping 172.31.1.255
Type Ctrl-C to abort.
Sending 5, 100-byte ICMP Echos to 172.31.1.255, timeout is 2 seconds:
Reply to request 1 from 172.31.1.208
Reply to request 1 from 172.31.1.216
                                          0 ms
                                             0 ms
                                            16 ms
Reply to request 1 from 172.31.1.205
Reply to request 5 from 172.31.1.209
                                             0 ms
Reply to request 5 from 172.31.1.66
                                             0 ms
Reply to request 5 from 172.31.1.87
FTOS#
```

Figure 4-8. Command Example: ping (IPv6)

```
FTOS#ping 100::1
Type Ctrl-C to abort.
Sending 5, 100-byte ICMP Echos to 100::1, timeout is 2 seconds:
Success rate is 100.0 percent (5/5), round-trip min/avg/max = 0/0/0 (ms)
FTOS#
```

power-off

CE

Turn off power to a selected line card or the standby (extra) Switch Fabric Module (SFM).

Syntax

power-off {linecard number | sfm sfm-slot-id}

Parameters

linecard number	Enter the keyword linecard and a number for the line card slot number.
	C-Series Range: 0-7
	E-Series Range: 0 to 13 on a E1200/E1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.
sfm sfm-slot-id	Enter the keyword sfm by the slot number of the SFM to which you want to turn off power. Note: This option is supported on E-Series only.

Defaults

Disabled

Command Modes

EXEC Privilege

Command History

Version 8.1.1.2	Introduced on E-Series ExaScale E600i	
Version 8.1.1.0	Introduced on E-Series ExaScale E1200i	
Version 7.5.1.0	Introduced on C-Series	
E-Series original C	E-Series original Command	

Related Commands

power-on	Power on a line card or standby SFM.	

power-on

CE

Turn on power to a line card or the standby (extra) Switch Fabric Module (SFM).

Syntax

power-on {linecard number | sfm sfm-slot-id}

Parameters

linecard number	Enter the keyword linecard and a number for the line card slot number.	
	C-Series Range: 0-7	
	E-Series Range: 0 to 13 on a E1200/E1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.	
sfm standby	Enter the keyword sfm followed by the slot number of the SFM to power on.	
	Note: This option is supported on E-Series only.	

Defaults

Disabled

Command Modes

EXEC Privilege

Command History

Version 8.1.1.2	Introduced on E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale E1200i
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Related Commands

Power off a line card or standby SFM. power-off

reload

CES

Reboot FTOS.

Syntax

reload

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

Usage Information

If there is a change in the configuration, FTOS will prompt you to save the new configuration. Or you can save your running configuration with the **copy running-config** command.

Refer to Chapter 8, Bare Metal Provisioning for information related to the BMP reload options.

Related Commands

reset	Reset a line card, RPM, or a failed SFM (TeraScale and ExaScale).	
reset stack-unit	Reset any designated stack member except the management unit	
reload-type	Configure a switch to reload in normal mode or as a DHCP client with all ports configured for Layer 3 traffic.	

reset

CE

Reset a line card, RPM, or a failed SFM (TeraScale only).

Syntax

reset {linecard number [hard | power-cycle] | rpm number [hard | power-cycle] | sfm slot number}

Parameters

linecard <i>number</i> Enter the keyword linecard and a number for the line card slot number.		
	(Optional) Add the keyword hard or power-cycle (power-cycle is C-Series only) to power cycle the line card.	
	C-Series Range: 0-7	
	E-Series Range: 0 to 13 on E1200/E1200i, 0 to 6 on E600/E600i, and 0 to 5 on E300	
hard	Enter the keyword hard to power cycle the line card.	
power-cycle	Enter the keyword power-cycle after upgrading a C-Series FPGA to cause the FPGA to be reprogrammed based on the contents of the FPGA PROM. Note: This option is supported on C-Series only.	

rpm number	Enter the keyword rpm followed by a number for the RPM slot number.	
	(Optional) Add the keyword hard or power-cycle (C-Series only) to power cycle the RPM.	
	Range: 0 to 1	
sfm slot number	Enter the keyword sfm followed by the failed or powered-off SFM slot number. Note: Supported on E-Series only	

Defaults

Disabled.

Command Modes

EXEC Privilege

Command History

Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

Usage Information

The command **reset** without any options is a soft reset, which means FTOS boots the line card from its runtime image. The **hard** option reloads the FTOS image on the line card. Use the **power-cycle** after upgrading an FPGA.

When a soft reset is issued on a line card (**reset linecard** *number*), FTOS boots the line card from its runtime image. Only when you enter **reset linecard** *number* **hard** is the software image reloaded on the line card.

Related Commands

reload	Reboots the system.	
restore fpga-image	Copy the backup C-Series FPGA image to the primary FPGA image.	

rpm <slot> location-led



Toggle the location LED on/off on the E-Series ExaScale RPM (LC-EH-RPM).

Syntax

rpm slot number location-led [on | off]

Parameters

rpm slot number	Enter the slot number
	E1200i: 0-13
	E600i: 0-6
on off	Toggles the LED on the RPM on or off.

Defaults

OFF

Command Modes

EXEC

Command History

Version 8.2.1.0	Introduced on the E-Series ExaScale	

Usage Information

The LED setting is not saved through power cycles.

send

C E S

Send messages to one or all terminal line users.

Syntax

send [*] | [*line*] | [**aux**] | [**console**] | [**vty**]

Parameters

*	Enter the asterisk character * to send a message to all tty lines.	
line	Send a message to a specific line.	
	Range: 0 to 11	
aux	Enter the keyword aux to send a message to an Auxiliary line.	
	Note: This option is supported on E-Series only.	
console	Enter the keyword console to send a message to the Primary terminal line.	
vty	Enter the keyword vty to send a message to the Virtual terminal	

Defaults

No default behavior or values

Command Modes

EXEC

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.5.1.0	Introduced on E-Series

Usage Information

Messages can contain an unlimited number of lines, however each line is limited to 255 characters. To move to the next line, use the <CR>. To send the message use CTR-Z, to abort a message use CTR-C.

service timestamps

CES

Add time stamps to debug and log messages. This command adds either the uptime or the current time and date.

Syntax

service timestamps [debug | log] [datetime [localtime] [msec] [show-timezone] | uptime] To disable timestamping, use the **no service timestamps** [debug | log] command.

Parameters

debug	(OPTIONAL) Enter the keyword debug to add timestamps to debug messages.
log	(OPTIONAL) Enter the keyword log to add timestamps to log messages with severity 0 to 6.
datetime	(OPTIONAL) Enter the keyword datetime to have the current time and date added to the message.
localtime	(OPTIONAL) Enter the keyword localtime to include the localtime in the timestamp.
msec	(OPTIONAL) Enter the keyword msec to include milliseconds in the timestamp.
show-timezone	(OPTIONAL) Enter the keyword show-timezone to include the time zone information in the timestamp.
uptime	(OPTIONAL) Enter the keyword uptime to have the timestamp based on time elapsed since system reboot.

Defaults N

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information

If you do not specify parameters and enter **service timestamps**, it appears as **service timestamps debug uptime** in the running-configuration.

Use the show running-config command to view the current options set for the service timestamps command.

show alarms

CES

View alarms for the RPM, SFMs, line cards and fan trays.

Syntax

show alarms [threshold]

Parameters

threshold	(OPTIONAL) Enter the keyword threshold to display the temperature thresholds set for
	the line cards, RPM, and SFMs.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

E-Series Example

Figure 4-9. Command Example: show alarms on E-Series

```
FTOS# show alarms
-- Minor Alarms --
Alarm Type
                                                   Duration
RPM 0 PEM A failed or rmvd 7 hr, 37 min SFM 0 PEM A failed or rmvd 7 hr, 37 min SFM 1 PEM A failed or rmvd 7 hr, 37 min
SFM 2 PEM A failed or rmvd
                                                    7 hr, 37 min
                                                    7 hr, 37 min
SFM 3 PEM A failed or rmvd
                                                    7 hr, 37 min
7 hr, 37 min
SFM 4 PEM A failed or rmvd
SFM 5 PEM A failed or rmvd
SFM 6 PEM A failed or rmvd 7 hr, 36 min line card 1 PEM A failed or rmvd 7 hr, 36 min line card 4 PEM A failed or rmvd 7 hr, 36 min 7 hr, 35 min
SFM 6 PEM A failed or rmvd
-- Major Alarms --
                                                   Duration
Alarm Type
No major alarms
FTOS#
```

show chassis

View the configuration and status of modules in the system. Use this command to determine the chassis mode.

Syntax

show chassis [brief]

Parameters

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Example Figure 4-10. Command Example: show chassis brief on E-Series

```
FTOS#show chassis brief
Chassis Type : E1200
Chassis Mode : TeraScale
Chassis Epoch : 3.2 micro-seconds
-- Line cards --
Slot Status
                                                   NxtBoot
                                                                                ReqTyp CurTyp Version
                                                                                                                                                               Ports
             not present
            not present
              not present
            not present
             not present
            not present
     5
     6
             not present
             not present
     8
            not present not present
     9
  10 not present
                                                    online E48PF
                                                                                                     E48PF 6.1.1.0
              online
                                                                                                                                                                48
  11
  12
              not present
                                                                                 E48PF
  13
              not present
                                                                                 E48PF
 -- Route Processor Modules --
Slot Status
                                       NxtBoot Version
    0 active online 6.1.1.0
     1 not present
Switch Fabric State: up
-- Switch Fabric Modules --
Slot Status
                                            ______
            active
             active
              active
             active
              active
     5
             active
              active
              active
            active
-- Power Entry Modules --
Bay Status
    0 up
     1
              up
-- Fan Status
Tray Status Temp Volt Speed
                                                                                                                                    PEMO PEM1 Fan1 Fan2 Fan3
          up < 50C 12-16V low/2100-2700 RPM up up up up < 50C 12-16V low/2100-2700 RPM up up up up < 50C 12-16V low/2100-2700 RPM up up up < 50C 12-16V low/2100-2700 RPM up up up < 50C 12-16V low/2100-2700 RPM up up up < 50C 16-20V med/2700-3200 RPM up up < 50C 16-20V med/2700-3200 RPM up up < 50C 16-20V med/2700-3200 RPM
______
  0
  1
                                                                                                                                                                       up
                                                                                                                                                                                       up
                                                                                                                                                                                                       up
                                                                                                                                               up up up up up up up up up up up up up
  2
                                                                                                                                                                                                       up
  3
                                                                                                                                                                                                        up
  4
                                                                                                                                                                                                        up
                                                     12-16V low/2100-2700 RPM
                                < 50C
  5
             up
                                                                                                                                   up
                                                                                                                                                                                                        up
```

Related Commands

show linecard	View line card status
show rpm	View Route Processor Module status.
show sfm	View Switch Fabric Module status.

show command-history

CES Display a buffered log of all commands entered by all users along with a time stamp.

Syntax show command-history

Defaults None.

Command Mode EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

One trace log message is generated for each command. No password information is saved to this file. A command-history trace log is saved to a file upon an RPM failover. This file can be analyzed by the Dell Networking TAC to help identify the root cause of an RPM failover.

Example

Figure 4-11. Command Example: show command-history

```
FTOS#show command-history
[11/20\ 15:47:22]: 	ext{CMD-}(\hat{	ext{CLI}}): [	ext{service password-encryption}] by default from console to the console of t
[11/20 15:47:22]: CMD-(CLI):[service password-encryption hostname FTOS]by default
from console

    Repeated 3 times.

[11/20 15:47:23]: CMD-(CLI):[service timestamps log datetime]by default from
console
[11/20 15:47:23]: CMD-(CLI): [hostname FTOS] by default from console
[11/20 15:47:23]: CMD-(CLI):[enable password 7 *****] by default from console
[11/20 15:47:23]: CMD-(CLI): [username admin password 7 ******] by default from
console
[11/20 15:47:23]: CMD-(CLI):[enable restricted 7 ******]by default from console
[11/20 15:47:23]: CMD-(CLI):[protocol spanning-tree rstp] by default from console
[11/20 15:47:23]: CMD-(CLI):[protocol spanning-tree pvst]by default from console
[11/20 15:47:23]: CMD-(CLI): [no disable] by default from console
[11/20 15:47:23]: CMD-(CLI):[interface gigabitethernet 0/1]by default from console
[11/20 15:47:23]: CMD-(CLI): [ip address 1.1.1.1 /24] by default from console
[11/20 15:47:23]: CMD-(CLI):[ip access-group abc in]by default from console
[11/20 15:47:23]: CMD-(CLI): [no shutdown] by default from console
[11/20 15:47:23]: CMD-(CLI):[interface gigabitethernet 0/2]by default from console
[11/20 15:47:23]: CMD-(CLI): [no ip address] by default from console
[11/20 15:47:23]: CMD-(CLI):[shutdown]by default from console
[11/20 15:47:23]: CMD-(CLI):[interface gigabitethernet 0/3]by default from console
[11/20 15:47:23]: CMD-(CLI):[ip address 5.5.5.1 /24]by default from console
[11/20 15:47:23]: CMD-(CLI): [no shutdown] by default from console
[11/20 15:47:23]: CMD-(CLI):[interface gigabitethernet 0/4]by default from console
[11/20 15:47:23]: CMD-(CLI): [no ip address] by default from console
[11/20 15:47:23]: CMD-(CLI):[shutdown]by default from console
[11/20 15:47:23]: CMD-(CLI):[interface gigabitethernet 0/5]by default from console
[11/20 15:47:23]: CMD-(CLI): [no ip address] by default from console
[11/20 15:47:23]: CMD-(CLI):[shutdown]by default from console
[11/20 21:17:35]: CMD-(CLI):[line console 0]by default from console
[11/20 21:17:36]: CMD-(CLI):[exec-timeout 0]by default from console
[11/20 21:17:36]: CMD-(CLI):[exit]by default from console
[11/20 21:19:25]: CMD-(CLI):[show command-history]by default from console
FTOS#
```

Related **Commands**

clear command history

Clear the command history log.

show command-tree

CES

Display the entire CLI command tree, and optionally, display the utilization count for each commands and its options.

Syntax

show command-tree [count | no]

Parameters

count	Display the command tree with a usage counter for each command.
no	Display all of the commands that may be preceded by the keyword no , which is the keyword used to remove a command from the running-configuration.

Defaults

None

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced

Usage Information

Reload the system to reset the command-tree counters.

Example

FTOS#show command-tree count

Enable privilege mode: enable

enable command usage:3 option usage: 0
exit command usage:1

show command-tree command usage:9

show command-tree command usage:9
count option usage: 3

show version command usage:1

Global configuration mode:

aaa authentication enable command usage:1

WORD option usage: 1
default option usage: 0
enable option usage: 0
line option usage: 0
none option usage: 0
radius option usage: 1
tacacs+ option usage: 0

show console lp

View the buffered boot-up log of a line card.

Syntax show console lp number

Parameters

number Enter the line card slot number. Range: 0-7 for the C300 Range: 0-13 for the E1200 Range: 0-6 for the E600 Range: 0-5 for the E300

Defaults None

Command Mode EXEC

EXEC Privilege

Command **History**

Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Usage Information



Caution: Use this command only when you are working directly with a technical support representative to troubleshoot a problem. Do not use this command unless a technical support representative instructs you to do so.

show cpu-traffic-stats CES View the CPU traff

Syntax

View the CPU traffic statistics.

show cpu-traffic-stats [port number | all | cp | linecard {all | slot# } | rp1 | rp2]

Parameters

port number	(OPTIONAL) Enter the port number to display traffic statistics on that port only.	
	Range: 1 to 1568	
all	(OPTIONAL) Enter the keyword all to display traffic statistics on all the interfaces receiving traffic, sorted based on traffic.	
ср	(OPTIONAL) Enter the keyword cp to display traffic statistics on the specified CPU.	
	Note: This option is supported on E-Series only.	
linecard	(OPTIONAL) Enter the keyword linecard followed by either all or the slot number to display traffic statistics on the designated line card.	
	Note: This option is supported on C-Series only.	
rp1	(OPTIONAL) Enter the keyword rp1 to display traffic statistics on the RP1.	
	Note: This option is supported on E-Series only.	
rp2	(OPTIONAL) Enter the keyword rp2 to display traffic statistics on the RP2.	
-	Note: This option is supported on E-Series only.	

Defaults all

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

E-Series Example

Figure 4-12. Command Example: show cpu-traffic-stats on the E-Series

```
FTOS#show cpu-traffic-stats
Processor : CP
   Received 100% traffic on GigabitEthernet 8/2
                                                           Total packets:100
       LLC:0, SNAP:0, IP:100, ARP:0, other:0
Unicast:100, Multicast:0, Broadcast:0
Processor: RP1
   Received 62% traffic on GigabitEthernet 8/2
                                                          Total packets:500
        LLC:0, SNAP:0, IP:500, ARP:0, other:0
       Unicast:500, Multicast:0, Broadcast:0
   Received 37% traffic on GigabitEthernet 8/1
                                                          Total packets:300
       LLC:0, SNAP:0, IP:300, ARP:0, other:0
Unicast:300, Multicast:0, Broadcast:0
Processor: RP2
   No CPU traffic statistics.
FTOS#
```

Usage Information

Traffic statistics are sorted on a per-interface basis; the interface receiving the most traffic is displayed first. All CPU and port information is displayed unless a specific port or CPU is specified. Traffic information is displayed for router ports only; not for management interfaces. The traffic statistics are collected only after the debug cpu-traffic-stats command is executed; not from the system bootup.



Note: After debugging is complete, use the no debug cpu-traffic-stats command to shut off traffic statistics collection.

Related Commands

debug cpu-traffic-stats

Enable CPU traffic statistics for debugging

show debugging

CES

View a list of all enabled debugging processes.

Syntax

show debugging

Command Mode

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

Example Figure 4-13. Command Example: show debugging

```
FTOS#show debug
Generic IP:
  IP packet debugging is on for
    ManagementEthernet 0/0
    Port-channel 1-2
    Port-channel 5
    GigabitEthernet 4/0-3,5-6,10-11,20
    GigabitEthernet 5/0-1,5-6,10-11,15,17,19,21
  ICMP packet debugging is on for
    GigabitEthernet 5/0,2,4,6,8,10,12,14,16
FTOS#
```

show environment (C-Series and E-Series)

CE View the system component status (for example, temperature, voltage).

Syntax show environment [all | fan | linecard | linecard-voltage | PEM | RPM | SFM]

Parameters

all	Enter the keyword all to view all components.	
fan	Enter the keyword fan to view information on the fans. The output of this command is chassis dependent. See Figure 4-10, Figure 4-11, and Figure 4-12 for a comparison of output.	
linecard	Enter the keyword linecard to view only information on line cards	
linecard-voltage	Enter the keyword linecard-voltage to view line card voltage information.	
PEM	Enter the keyword pem to view only information on power entry modules.	
RPM	Enter the keyword rpm to view only information on RPMs.	
SFM	Enter the keyword sfm to view only information on SFMs.	
	Note: This option is supported on E-Series only.	

Command Modes

EXEC

EXEC Privilege

Command History

Version8.3.3.8	Updated to support PPID on the S60	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.8.1.0	Added temperature information for C-Series fans	
Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

Usage Information

Fan speed is controlled by temperatures measured at the sensor located on the fan itself. The fan temperatures shown with this command may not accurately reflect the temperature and fan speed. Refer to your hardware installation guide for fan speed and temperature information.

Examples

Figure 4-14. Command Example: show environment

```
FTOS#show environment
-- Fan Status --
                   Fan2 Fan3 Serial Num
Status Temp Fan1
      32C 6000 RPM 6000 RPM 7500 RPM FX000040889
-- Power Supplies --
Bay Status
 0 absent
     uρ
     up
     up
   Line Card Environment Status
Slot Status
            Temp Voltage
 0 not present
    online 66C ok not present online 59C ok online 64C ok
                     ok
ok
 4
    not present online 59C ok
 5
 6
-- RPM Environment Status --
Slot Status Temp Voltage
 0 active 36C ok
 1
    not present
-- SFM Environment Status --
FTOS#
```

Figure 4-15. Command Example: show environment fan

show environment (S-Series)

S View S-Series system component status (for example, temperature, voltage).

Syntax show environment [all | fan | stack-unit unit-id | pem | thermal-sensor]

Parameters

all	Enter the keyword all to view all components.	
fan	Enter the keyword fan to view information on the fans. The output of this command is chassis dependent.	
stack-unit unit-id	Enter the keyword stack-unit followed by the <i>unit-id</i> to display information on a specific stack member. Unit ID range:	
	S60 : 0-11 all other S-Series: 0-7	

pem	Enter the keyword pem to view only information on power entry modules.
thermal-sensor	Enter the keyword thermal-sensor to view only information on the thermal
	sensors.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	The output of the show environment fan command for S-Series is changed to display fan speeds instead of just showing the fan status as up or down.
Version 7.6.1.0	Introduced for S-Series. S-Series options and output differ from the C-Series/E-Series version.

Example

Figure 4-16. Command Example: show environment on the S60

```
FTOS#show environment
-- Fan Status --
-- Fan Status -- Status Temp Fan1 Fan2 Fan3 Serial Num Version
 up 32C 6000 RPM 6000 RPM 7500 RPM FX000040889 3.2
-- Power Supplies --
Bay Status
 0 absent
  1
     up
  2 up
  3
     up
-- Line Card Environment Status --
Slot Status Temp Voltage
 0 not present
 o not present

online 66C ok

not present

online 59C ok

online 64C ok

not present

online 59C ok
-- RPM Environment Status --
Slot Status Temp Voltage
     not present
  0 active
1 not present
-- SFM Environment Status --
FTOS#
```

Example

Figure 4-17. Command Example: show environment fan

```
FTOS#show environment fan
-- Fan Status --
Status Temp Fan1 Fan2 Fan3 Serial Num Version
 up 32C 6000 RPM 6000 RPM 6000 RPM FX000040889 3.2
```

Example

Figure 4-18. Command Example: show environment pem

```
FTOS#show environment pem

-- Power Supplies --
Unit Bay Status Type
------
0 0 up AC
0 1 absent
```

Example

Figure 4-19. Command Example: show environment stack-unit

```
FTOS#show environment stack-unit 0

-- Unit Environment Status --
Unit Status Temp Voltage

0* online 49C ok

* Management Unit
```

Example

Figure 4-20. Command Example: show environment thermal-sensor

show inventory (C-Series and E-Series)

CE

Display the chassis type, components (including media), FTOS version including hardware identification numbers and configured protocols.

Syntax

show inventory [media s/of]

Parameters

media slot	(OPTIONAL) Enter the keyword media followed by the slot number.	
	C-Series Range: 0-7	
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300	

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command History

Usage Information

The **show inventory media** command provides some details about installed pluggable media (SFP, XFP), as shown in Figure 4-23. Use the show interfaces command to get more details about installed pluggable media.

The display output might include a double asterisk (**) next to the SFMs, for example:

```
0004875
0004889
                              7490007411
7490007411
```

The double asterisk generally indicates the SFM's frequency capabilities, indicating either that they are operating at 125 MHz or that the frequency capability, which is stored in an EPROM, cannot be determined.

If there are no fiber ports in the line card, then just the header under show inventory media will be displayed. If there are fiber ports but no optics inserted, then the output will display "Media not present or accessible".

C300 Example

Figure 4-21. Example output of show inventory for C300 (C-Series)

```
FTOS# show inventory
Chassis Type : C300
Chassis Mode : 1.0
Software Version : FTOS-EF-7.6.1.0
                                  Serial Number Part Number Revision
            ______
  C300 TY000001400 7520029999 04
3 LC-CB-GE-48T FX000020075 7520036700 01
0 LC-CB-RPM 0060361 7520029300 02
0 CC-C-1200W-AC N/A N/A N/A
1 CC-C-1200W-AC N/A N/A N/A N/A
                                                                            N/A
   0 CC-C300-FAN
 * - standby
Software Protocol Configured
OSPF
FTOS#
```

E-Series Example Figure 4-22. Example output of show inventory for E-Series

```
FTOS#show inventory
Chassis Type
                 : E600i
Chassis Mode
Software Version : E8-4-1-317
                                                                                    Rev Svc Tag Exprs Svc Code
                        Serial Number Part Number Rev Piece Part ID
                        TY000002693
                                        7520023900 03
                                                           US-0RVY43-76991-82B-0456 1B2 SVCTGCH
                                                                                                   628 458 864 65
                                                                                    N/A N/A
N/A N/A
     LC-EH-10GE-10S
                        FX000049121
                                        7520042807
                                                      03
                                                           N/A
                                                                                                   N/A
     LC-PIC0
                        FX000049647
                                        7490105800
                                                     01
                                                          N/A
                                                                                                   N/A
     LC-PIC1
                        FX000049650
                                        7490105800
                                                     01
                                                           N/A
                                                                                     N/A
                                                                                          N/A
                                                     A
01
     LC-EJ-10GE-10S
                        FX000097669
                                        7520047602
                                                           N/A
                                                                                     N/A
                                                                                          N/A
                                                                                                   N/A
     LC-PIC0
                                        7490105800
                                                                                          N/A
                        FX000047055
                                                           N/A
                                                                                     N/A
                                                                                                   N/A
     LC-PIC1
                        FX000048680
                                        7490105800
                                                                                          N/A
                                                                                          N/A
N/A
     LC-EH-GE-90M
                        FX000046835
                                        7520041702
                                                     01
                                                           N/A
                                                                                     N/A
                                                                                                   N/A
     LC-PICO
                        FX000046905
                                        7490102401
                                                      02
                                                           N/A
                                                                                     N/A
                                                                                                   N/A
     LC-EH-GE-90M
                        FX000044725
                                        7520041702
                                                                                     N/A
     T.C-PTC0
                        FX000044256
                                        7490102401
                                                     02
                                                           N/A
                                                                                     N/A
                                                                                          N/A
                                                                                                   N/A
     LC-EH-RPM
                                                                                          N/A
                        FX000056234
                                        7520043401
                                                                                     N/A
                                                           N/A
                                                                                                   N/A
     CC-E-SFM3
CC-E-SFM3
                        VC074300030
                                        7520020001
                                                           CN-0RVY43-75412-123-0030 003
                                                                                          SVCTG00
                                                                                                   628 458 860 16
                                                           CN-0RVY43-75412-82B-0456 1B2
                                                                                          SVCTG01
                        VC074300032
                                        7520020001
                                                     03
                                                                                                   628 458 860 17
     CC-E-SFM3
                        VC074300032
                                                           CN-0RVY43-75412-82B-0456 1B2
                                                                                          SVCTG02
                                                                                                   628 458 860 18
                                        7520020001
     CC-E-SFM3
CC-E600-2500W-AC
                        0068166
                                        7520020001
                                                     03
                                                           N/A
                                                                                     N/A
                                                                                          N/A
                                                                                                   N/A
                        VC074300032
                                                           N/A
                                        7520026400
                                                     0.2
                                                                                     N/A
                                                                                         N/A
                                                                                                   N/A
     CC-E600-2500W-AC
                        VC074300087
                                        7520026400
                                                           N/A
                                                                                     N/A
                                                                                         N/A
    CC-E600-2500W-AC
CC-E600-FAN
                        VC073700046
                                        7520026400
                                                     02
                                                           N/A
                                                                                     N/A
                                                                                         N/A
                                                                                                   N/A
                        FX000040889
                                        N/A
                                                     N/A
                                                          N/A
                                                                                     N/A
                                                                                       /A N/A
N/A N/A
                                                                                                   N/A
     slot0:
                            110613B1304M2737
                                                 - HDX 2.15 N/A
                                                                                                     N/A
 * - standby
Software Protocol Configured
  BGP
  MCAST
  OSPF
  PTM
  SNMP
```

Example Figure 4-23. Example output of show inventory media slot (partial)

```
FTOS#show inventory media 3
Slot Port Type Media Serial Number F10Qualified
...
3 11 SFP 1000BASE-SX U9600L0 Yes
...
```

Example Figure 4-24. Example Output of show inventory media

FTOS#	show inve	entory med	lia		
Slot	Port	Туре	Media	Serial Number	F10Qualified
1	0		Media not pre	esent or accessible	
1	1		Media not pre	esent or accessible	
1	2		Media not pre	esent or accessible	
1	3		Media not pre	esent or accessible	
1	4		Media not pre	esent or accessible	
1	5	SFP+	10GBASE-SF	AM70PXW	Yes
1	6		Media not pre	esent or accessible	
1	7		Media not pre	esent or accessible	
1	8	SFP+	10GBASE-SF	AM70W84	Yes
1	9		Media not pre	esent or accessible	
3	0		Media not pre	esent or accessible	
3	1		Media not pre	esent or accessible	
3	2		Media not pre	esent or accessible	
3	3		Media not pre	esent or accessible	
3	4		Media not pre	esent or accessible	
3	5		Media not pre	esent or accessible	
3	6		Media not pre	esent or accessible	
3	7			esent or accessible	
3	8			esent or accessible	

Related Commands

show interfaces	Display a specific interface configuration.
show interfaces transceiver	Display the physical status and operational status of an installed transceiver. The output also displays the transceiver's serial number.

show inventory (S-Series)

S Display the S-Series switch type, components (including media), FTOS version including hardware identification numbers and configured protocols.

Syntax show inventory [media slot]

Parameters

media slot (OPTIONAL) Enter the keyword **media** followed by the stack ID of the stack member for which you want to display pluggable media inventory.

Defaults No default behavior or values

Command Modes CONFIGURATION

Command History

Version 8.3.3.8	Updated to support PPID on the S60.		
Version 8.3.3.1	Introduced on the S60.		
Version 7.6.1.0	Introduced this version of the command for S-Series. S-Series output differs from E-Series.		

Usage

If there are no fiber ports in the unit, then just the header under **show inventory media** will be displayed. If there are fiber ports but no optics inserted, then the output will display "Media not present or accessible". Example 1

Figure 4-25. Example output of show inventory for S-Series

```
FTOS>show inventory
System Type : S4810
System Mode : 1.0
Software Version : 8.3.12.0
Unit Type Serial Number Part Number Rev Piece Part ID Rev Svc Tag Exprs Svc Code
* - Management Unit
Software Protocol Configured
 iscsi
 LLDP
 MCAST
 OSPF
 SNMP
```

Example 2 Figure 4-26. Example Output of show inventory media (S-Series)(partial)

	show inv Port	rentory med Type	lia ? Media	Serial Number	F10Qualified
0	0	SFP	1000BASE-SX	P681WK0	Yes
0	1	SFP	1000BASE-SX	PGF3T36	Yes
0	2	SFP	1000BASE-SX	PGF420E	Yes
0	3	SFP	1000BASE-SX	P118HQ2	Yes
0	4	SFP	1000BASE-SX	PGF4244	Yes
0	5	SFP	1000BASE-SX	P5N1BN6	Yes
0	6	SFP	1000BASE-SX	P7529KV	Yes
0	7	SFP	1000BASE-SX	PGC514G	Yes
0	8	SFP	1000BASE-SX	PLE71GD	Yes
0	9	SFP	1000BASE-SX	PLE71N0	Yes
0	10	SFP	1000BASE-SX	PLE71M7	Yes
0	11	SFP	1000BASE-SX	PLE71LL	Yes
0	12	SFP	1000BASE-SX	B320210110	Yes
0	13	SFP	1000BASE-SX	B322237357	Yes
0	14	SFP	1000BASE-SX	P118PGB	Yes
0	15	SFP	1000BASE-SX	PGF425R	Yes
0	16	SFP	1000BASE-SX	PLE71MF	Yes
0	17	SFP	1000BASE-SX	AMEH367	Yes
0	18	SFP	1000BASE-SX	PLE71LZ	Yes
0	19	SFP	1000BASE-SX	PGA531L	Yes
0	20	SFP	1000BASE-SX	PLE71M8	Yes
0	21	SFP	1000BASE-SX	PGC51EM	Yes
0	22	SFP	1000BASE-SX	PLP32BP	Yes
0	23	SFP	1000BASE-SX	AJHG367	Yes
0	24	SFP	1000BASE-SX	P11BWUJ	Yes
0	25	SFP	1000BASE-SX	P741RVM	Yes
0	26	SFP	1000BASE-SX	PGF3T9H	Yes
0	27	SFP	1000BASE-SX	PGC51ZE	Yes
0	28	SFP	1000BASE-SX	PGC525W	Yes
!	out	put trunca	ated!		

Related Commands

show interfaces	interface configuration.
show interfaces transceiver	Display the physical status and operational status of an installed transceiver. The output also displays the transceiver's serial number.

show linecard

© E Display the line card(s) status.

Syntax show linecard [number [brief] | all]

Parameters

number	(OPTIONAL) Enter a slot number to view information on the line card in that slot.		
	C-Series Range: 0-7		
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600, and 0 to 5 on a E300.		
all	(OPTIONAL) Enter the keyword all to view a table with information on all present line cards.		
brief	(OPTIONAL) Enter the keyword brief to view an abbreviated list of line card information.		

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.8	Updated to support PPID on the S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
E-Series original C	Command

E-Series Example

Figure 4-27. Command Example: show linecard on E-Series

```
-- Line card 0 --
Status
                                          : not present
 -- Line card 1 --
                                  : online
                                              : online
Next Boot
Required Type : EXW10SH - 10-port 10GE LAN/WAN PHY line card with
 SFP+ options 10M CAM (EH)
Current Type : EXW10SH - 10-port 10GE LAN/WAN PHY line card with
 SFP+ options 10M CAM (EH)
Hardware Rev : Base - 1.4 PPO - 02 PP1 - 02
Num Ports
                                             : 10
The state of the s
                                                                                                    B: 2.9.2.0E0 [booted]
Temperature : 65C
Power Status : AC
 Voltage
                                             : ok
Serial Number : FX000049121
 Part Number : 7520042807 Rev 03
                                         : 04
: 01212010
Vendor Id
Date Code
 Country Code
                                              : 01
Piece Part ID : N/A
PPID Revision : N/A
 Service Tag
                                           : N/A
 Expr Svc Code : N/A
 Last Restart : soft reset
Auto Reboot
                                            : enabled
 -- Line card 2 --
Status
                                  : not present
 -- Line card 3 --
Status : online
Next Boot : online
 Required Type : EXW10SJ - 10-port 10GE LAN/WAN PHY line card with
  !----- output truncated -----!
```

C-Series Example

Figure 4-28. Command Example: show linecard on C-Series

```
FTOS#show linecard 11
-- Line card 11 --
              : online
Status
Next Boot
                  : online
Required Type : E48PF - 48-port GE line card with SFP optics (EF)
Current Type : E48PF - 48-port GE line card with SFP optics (EF)
Hardware Rev : Base - 1.0 PPO - n/a PP1 - n/a
Num Ports : 48
Up Time
                  : 12 hr, 37 min
FTOS Version : 6.2.1.x
Jumbo Capable : yes
Boot Flash : A: 2.0.3.4 B: 2.0.3.4 [booted]
memory Size : 268435456 bytes
Temperature : 49C
Power Status : PEMO: absent or down
                                                 PEM1: up
Voltage
                  : ok
Serial Number :
Part Number
                                   Rev
Vendor Id
Date Code
Country Code :
FTOS#
```

Table 4-1 list the definitions of the fields shown in Figure 4-27.

Table 4-1. Descriptions for show linecard output

Field	Description		
Line card	Displays the line card slot number (only listed in show linecard all command output).		
Status	Displays the line card's status.		
Next Boot	Displays whether the line card is to be brought online at the next system reload.		
Required Type	Displays the line card type configured for the slot. The Required Type and Current Type must match. Use the linecard command to reconfigure the line card type if they do not match.		
Current Type	Displays the line card type installed in the slot. The Required Type and Current Type must match. Use the linecard command to reconfigure the line card type if they do not match.		
Hardware Rev	Displays the chip set revision.		
Num Ports	Displays the number of ports in the line card.		
Up Time	Displays the number of hours and minutes the card is online.		
FTOS Version	Displays the operating software version.		
Jumbo Capable	Displays Yes or No indicating if the line card can support Jumbo frames.		
Boot Flash Ver	Displays the two possible Bootflash versions. The [Booted] keyword next to the version states which version was used at system boot.		
Memory Size	List the memory of the line card processor.		
Temperature	Displays the temperature of the line card. Minor alarm status if temperature is over 65° C.		
Power Status	Lists the type of power modules used in the chassis: • AC = AC power supply • DC = DC Power Entry Module (PEM)		
Voltage	Displays OK if the line voltage is within range.		
Serial Number	Displays the line card serial number.		
Part Num	Displays the line card part number.		
Vendor ID	Displays an internal code, which specifies the manufacturing vendor.		
Date Code	Displays the line card's manufacturing date.		

Figure 4-29. Command Example: show linecard brief

```
FTOS#show linecard 11 brief

-- Line card 11 --
Status : online
Next Boot : online
Required Type : E48PF - 48-port GE line card with SFP optics (EF)
Current Type : E48PF - 48-port GE line card with SFP optics (EF)
Hardware Rev : Base - 1.0 PP0 - n/a PP1 - n/a
Num Ports : 48
Up Time : 11 hr, 24 min
FTOS Version : 6.1.1.0
Jumbo Capable : yes
FTOS#
```

Related Commands

linecard	Pre-configure a line card in a currently empty slot of the system or a different line card type for the slot.
show interfaces linecard	Display information on all interfaces on a specific line card.
show chassis	View information on all elements of the system.
show rpm	View information on the RPM.
show sfm	View information on the SFM.

show linecard boot-information

 \mathbb{E} View the line card status and boot information.

Syntax show linecard boot-information

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.8	Updated to support PPID on the S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 6.5.1.4	Introduced on E-Series

Figure 4-30. Command Example: show linecard boot-information Example

FTOS#show linecard boot-information Booted from Cache Boot boot # Status CurType number flash boot online EXW10SH FX000049121 8-4-1-317 8-4-1-317 A: 8-4-1-213 B: A: 2.9.1.1c B: 2.9.2.0E0 [b] A: 2.9.1.1 [b] B: 2.9.1.1 A: 2.9.1.1 B: 2.9.1.1 [b] online EXW10SJ FX000097669 8-4-1-317 8-4-1-317 online E90MH FX000046835 8-4-1-317 8-4-1-317 A: 8-4-1-305 B: invalid A: 8-4-1-213 B: invalid online E90MH FX000044725 8-4-1-317 8-4-1-317 A: 8-4-1-213 B: invalid A: 2.9.1.1 [b] B: 2.9.1.1 FTOS#

Table 4-2 defines the fields in Figure 4-30.

Table 4-2. Descriptions for show linecard boot-information output

Field	Description		
#	Displays the line card slot numbers, beginning with slot 0. The number of slots listed is dependent on your chassis:		
	E-Series: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.		
Status	Indicates if a line card is online, offline, or booting. If a line card is not detected in the slot, a hyphen (-) is displayed.		
CurType	Displays the line card identification number, for example EXW4PF.		
Serial number	Displays the line card serial number.		
Booted from	Indicates whether the line card cache booted or system booted. In addition, the image with which the line card booted is also displayed. If the line card cache booted, then the output is A: or B: followed by the image in the flash partition (A: 6.5.1.4 or B: 6.5.1.4). If the line card system booted, then display is the current FTOS version number (6.5.1.4).		
Next boot	Indicates if the next line card boot is a cache boot or system boot and which image will be used in the boot.		
Cache boot	Displays the system image in cache boot flash partition A: and B: for the line card. If the cache boot does not contain a valid image, "invalid" is displayed.		
Boot flash	Displays the two possible Boot flash versions. The [b] next to the version number is the current boot flash, that is the image used in the last boot.		

Usage Information

The display area of this command uses the maximum 80 character length. If your display area is not set to 80 characters, the display will wrap.

Related Commands

show linecard	View the line card status
upgrade (E-Series version)	Upgrade the boot flash, boot selector, or system image
download alt-boot-image	Download an alternate boot image to the chassis
download alt-full-image	Download an alternate FTOS image to the chassis
download alt-system-image	Download an alternate system image to the chassis

show memory (C-Series and E-Series)

[C][E]View current memory usage on the system.

Syntax show memory [cp | lp slot-number | rp1 | rp2]

Parameters

ср	(OPTIONAL) Enter the keyword CP to view information on the Control Processor on the RPM.
Ip slot-number	(OPTIONAL) Enter the keyword p and the slot number to view information on the line-card processor in that slot. C-Series Range: 0-7 E-Series Range: 0 to 13 on a E1200/E1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a
	E300.
rp1	(OPTIONAL) Enter the keyword rp1 to view information on Route Processor 1 on the RPM.
	Note: This option is supported on the E-Series only.
rp2	(OPTIONAL) Enter the keyword rp2 to view information on Route Processor 2 on the RPM.
	Note: This option is supported on the E-Series only.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 7.5.1.0	Introduced on C-Series	
E-Series original C	ommand	

Usage Information

The output for show memory displays the memory usage of LP part (sysdlp) of the system. The Sysdlp is an aggregate task that handles all the tasks running on C-Series' and E-Series' LP.

In FTOS Release 7.4.1.0 and higher, the total counter size (for all 3 CPUs) in show memory (C-Series and E-Series) and show processes memory (C-Series and E-Series) will differ based on which FTOS processes are counted.

- In the show memory (C-Series and E-Series) display output, the memory size is equal to the size of the application processes.
- In the show processes memory (C-Series and E-Series) display output, the memory size is equal to the size of the application processes *plus* the size of the system processes.

E-Series Example

Figure 4-31. Command Example: show memory on E-Series

	TT~ a d / la \		T /l- \	T = === = = (la)
otal(b)	Used(b)	Free(b)	Lowest(b)	Largest(b)
	64837834		387805590	371426976
Statistic	s On RP1 Proce	ssor		
=======	=========	====		
otal(b)	Used(b)	Free(b)	Lowest(b)	Largest(b)
29145600	4079544	625066056	625066056	0
Statistic	s On RP2 Proces	ssor		
		====		
otal(b)	Used(b)	Free(b)	Lowest(b)	Largest (b)
10209568	47294716	462914852	462617968	446275376

Table 4-3 defines the fields displayed in Figure 4-31.

Table 4-3. Descriptions for show memory output

Field	Description
Lowest	Displays the memory usage the system went to in the lifetime of the system. Indirectly, it indicates the maximum usage in the lifetime of the system: Total minus Lowest.
Largest	The current largest available. This relates to block size and is not related to the amount of memory on the system.

show memory (S-Series)

S View current memory usage on the S-Series switch.

Syntax show memory [stack-unit id]

Parameters

stack-unit id	(OPTIONAL) Enter the keyword stack-unit followed by the stack unit ID of the S-Series stack member to display memory information on the designated stack member.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced this version of the command for the S-Series

Usage Information

The output for show memory displays the memory usage of LP part (sysdlp) of the system. The Sysdlp is an aggregate task that handles all the tasks running on the S-Series' CPU.

Example

Figure 4-32. Command Example: show memory on S-Series

show processes cpu (C-Series and E-Series)

CE View CPU usage information based on processes running in the system.

Syntax show processes cpu [cp | rp1 | rp2] [lp [linecard-number [1-99] | all | summary]

Parameters

ср	(OPTIONAL) Enter the keyword cp to view CPU usage of the Control Processor.
rp1	(OPTIONAL) Enter the keyword rp1 to view CPU usage of the Route Processor 1.
	Note: This option is supported on the E-Series only.
rp2	(OPTIONAL) Enter the keyword rp2 to view CPU usage of the Route Processor 2.
	Note: This option is supported on the E-Series only.
Ip linecard [1-99]	(OPTIONAL) Enter the keyword lp followed by the line card number to display the CPU usage of that line card.
	The optional 1-99 variable sets the number of tasks to display in order of the highest CPU usage in the past five (5) seconds.
lp all	(OPTIONAL) Enter the keyword Ip all to view CPU utilization on all active line cards.
Ip summary	(OPTIONAL) Enter the keyword lp summary to view a summary of the line card CPU utilization.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Modified: Added the lp all option
Version 6.5.1.0	Modified: The granularity of the output for rp1 and rp2 is changed. The the output is now at the process level, so process-specific statistics are displayed.

Example 1 Figure 4-33. Command Example: show processes cpu (Partial)

	processes cpu Statistics On (CP Proces	sor					
=====			===					
CDII utiliz	ation for five	aeconda.	4%/2%, one	minute. 2%	· five m	inutes.	つ シ	
PID	Runtime (ms)	Invoked	uSecs	5Sec	, live "	5Min	TTY	Process
0xd02e4e8	1498633	89918	16666	3.00%			0	KP
0xd9d4c70	0	0	0	0.00%	0.00%	0.00%	0	tLogTask
0xd9cd200	0	0	0	0.00%	0.00%	0.00%	0	soc dpc
0xd9bf588	0	0	0	0.00%	0.00%	0.00%	0	- TARL
0xd9bd2f8	0	0	0	0.00%	0.00%	0.00%	0	tBCMlink
0xd9bb0e0	700	42	16666	0.00%	0.00%	0.00%	0	tBcmTask
0xd9798d0	106683	6401	16666	0.00%	0.00%	0.00%	0	tNetTask
0xd3368a0	0	0	0	0.00%	0.00%	0.00%	0	tWdbTask
0xd3329b0	166	10	16600	0.00%	0.00%	0.00%	0	tWdtTask
0xd32a8c8	102500	6150	16666	0.00%	0.00%	0.00%	0	tme
0xd16b1d8	12050	723	16666	0.00%	0.00%	0.00%	0	ipc
0xd1680c8	33	2	16500	0.00%	0.00%	0.00%	0	irc
0xd156008	116	7	16571	0.00%	0.00%	0.00%	0	RpmAvailMgr
0xd153ab0	216	13	16615	0.00%	0.00%	0.00%	0	ev
\-more-								

Example 2 Figure 4-34. Command Example: show processes cpu rp1

	FTOS#show	processes cpu	rp1						
	CPU utiliz	ation for five	seconds:	0%/0%; one		five m	inutes:	0%	
	PID	Runtime (ms)	Invoked	uSecs	5Sec	1Min	5Min	TTY	Process
	0x0000007c	60	6	10000	0.00%	0.00%	0.00%	0	ospf
	0x00000077	460	46	10000	0.00%	0.00%	0.00%	0	dsm
	0x00000074	100	10	10000	0.00%	0.00%	0.00%	0	ipm1
	0x0000006e	180	18	10000	0.00%	0.00%	0.00%	0	rtm
	0x0000006b	100	10	10000	0.00%	0.00%	0.00%	0	rip
	0x00000068	120	12	10000	0.00%	0.00%	0.00%	0	acl
	0x00000064	690	69	10000	0.00%	0.00%	0.00%	0	sysd1
	0x00000062	20	2	10000	0.00%	0.00%	0.00%	0	sysmon
	0x00000024	880	88	10000	0.00%	0.00%	0.00%	0	sshd
	0x00000022	0	0	0	0.00%	0.00%	0.00%	0	inetd
	0x00000020	2580	258	10000	0.00%	0.00%	0.00%	0	mount mfs
	0x00000013	0	0	0	0.00%	0.00%	0.00%	0	mount mfs
	0x0000006	80	8	10000	0.00%	0.00%	0.00%	0	- sh
ı	0x0000005	30	3	10000	0.00%	0.00%	0.00%	0	aiodoned
	0x00000004	840	84	10000	0.00%	0.00%	0.00%	0	ioflush
	0x0000003	250	25	10000	0.00%	0.00%	0.00%	0	reaper
	0x00000002	0	0	0	0.00%	0.00%	0.00%	0	pagedaemon
	0x0000001	160	16	10000	0.00%	0.00%	0.00%	0	init
	0x0000000	700	70	10000	0.00%	0.00%	0.00%	0	swapper
/	0x00000088	260	26	10000	0.00%	0.00%	0.00%	0	bgp
/									31 /

Example 3 Figure 4-35. Command Example: show processes cpu rp2

TOS#show	processes cp	ı rp2						
PU utiliz	ation for fiv	ve seconds:	0%/0%; one	minute: 0	%; five m	inutes:	0%	
ID	Runtime(ms)	Invoked	uSecs	5Sec	1Min	5Min	TTY	Proces
x00000090	140	14	10000	0.00%	0.00%	0.00%	0	vrr
x0000008d	120	12	10000	0.00%	0.00%	0.00%	0	fvr
x00000088	360	36	10000	0.00%	0.00%	0.00%	0	xst
x00000084	60	6	10000	0.00%	0.00%	0.00%	0	spa
x00000083	180	18	10000	0.00%	0.00%	0.00%	0	pi
x00000080	80	8	10000	0.00%	0.00%	0.00%	0	igm
x0000007b	130	13	10000	0.00%	0.00%	0.00%	0	ipm
x00000078	700	70	10000	0.00%	0.00%	0.00%	0	mrt
x00000074	100	10	10000	0.00%	0.00%	0.00%	0	12mg
x00000070	80	8	10000	0.00%	0.00%	0.00%	0	12p
x0000006c	80	8	10000	0.00%	0.00%	0.00%	0	arp
x00000068	60	6	10000	0.00%	0.00%	0.00%	0	acl
x00000064	750	75	10000	0.00%	0.00%	0.00%	0	sysd
x00000062	0	0	0	0.00%	0.00%	0.00%	0	sysmo
x00000024	880	88	10000	0.00%	0.00%	0.00%	0	ssh
x00000022	0	0	0	0.00%	0.00%	0.00%	0	inet
x00000020	2250	225	10000	0.00%	0.00%	0.00%	0	mount mf
x00000013	0	0	0	0.00%	0.00%	0.00%	0	mount mf
x00000006	100	10	10000	0.00%	0.00%	0.00%	0	_ s
x00000005	0	0	0	0.00%	0.00%	0.00%	0	aiodone
x00000004	960	96	10000	0.00%	0.00%	0.00%	0	ioflus
x0000003	140	14	10000	0.00%	0.00%	0.00%	0	reape
x00000002	0	0	0	0.00%	0.00%	0.00%	0	pagedaemo
x0000001	160	16	10000	0.00%	0.00%	0.00%	0	ini
x00000000	700	70	10000	0.00%	0.00%	0.00%	0	swappe
x00000098	140	14	10000	0.00%	0.00%	0.00%	0	msd

Usage Information

The CPU utilization for the last five seconds as shown in Figure 4-33 is 4%/2%. The first number (4%) is the CPU utilization for the last five seconds. The second number (2%) indicates the percent of CPU time spent at the interrupt level.

show processes cpu (S-Series)

Display CPU usage information based on processes running in an S-Series.

Syntax

show processes cpu [management-unit 1-99 [details] | stack-unit id | summary | ipc | memory [stack-unit id]]

Parameters

management-unit 1-99 [details]	(OPTIONAL) Display processes running in the control processor. The 1-99 variable sets the number of tasks to display in order of the highest CPU usage in the past five (5) seconds. Add the details keyword to display all running processes (except sysdlp). See Example 3.
stack-unit id	(OPTIONAL) Enter the keyword stack-unit followed by the stack member ID.
	As an option of show processes cpu , this option displays CPU usage for the designated stack member. See Example 2.
	Or, as an option of memory , this option limits the output of memory statistics to the designated stack member. See Example 5.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
summary	(OPTIONAL) Enter the keyword summary to view a summary view of CPU usage for all members of the stack. See Example 1.
ipc	(OPTIONAL) Enter the keyword ipc to display inter-process communication statistics.
memory	(OPTIONAL) Enter the keyword memory to display memory statistics. See Example 4.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Modified: Added management-unit [details] keywords.
Version 7.6.1.0	Introduced for S-Series

Example 1

Figure 4-36. Command Example: show processes cpu summary on S-Series

```
FTOS#show processes cpu summary
CPU utilization 5Sec 1Min 5Min
Unit0 0% 0% 0%
CPU utilization 5Sec 1Min 5Min
Unit1* 1% 0% 0%
Unit2 0% 0% 0%
Unit3 0% 0% 0%
* Mgmt Unit
```

Example 2 Figure 4-37. Command Example: show processes cpu management-unit on S-Series

CDII			19 / 09 -		100 5		0.9	
	ation for five						es: 2% TTY	
PID	Runtime(ms)	Invoked	us	ecs 5	Sec 1M	TII PMTII	TTY	
Process	0.0	0	10000	0 000	0 000	0 000	0	
272	20	2	10000	0.00%	0.00%	0.00%	0	
topoDPC 271	0	0	0	0 00%	0 00%	0.00%	0	
	U	U	U	0.00%	0.006	0.00%	U	
bcmNHOP 270	0	0	0	0 00%	0 00%	0.00%	0	
bcmDISC	U	U	U	0.00%	0.006	0.00%	U	
269	0	0	0	0 00%	0 00%	0.00%	0	
bcmATP-RX	U	U	U	0.00%	0.00%	0.00%	U	
268	0	0	0	0 00%	0 00%	0.00%	0	
bcmATP-TX	U	U	U	0.00%	0.00%	0.00%	U	
267	30	3	10000	0.00%	0 00%	0.00%	0	
bcmSTACK	30	3	10000	0.00%	0.00%	0.00%	U	
266	200	38	10000	0 00%	0 00%	0.08% 0		
bcmRX	380	30	10000	0.00%	0.00%	0.00%		
265	30	3	10000	0 00%	0 00%	0.00%	0	
bcmLINK.0	30	3	10000	0.00%	0.00%	0.00%	U	
264	0	0	0	0 00%		0.00%	0	
bcmXGS3Asyı	-	U	U	0.00%	0.00%	0.00%	U	
263	0	0	0	0 00%	0 00%	0.00% 0		
bcmTX	U	U	U	0.00%	0.00%	0.00%		
262	160	16	10000	0 00%	0 00%	0.00%	0	
bcmCNTR.0	160	10	10000	0.00%	0.00%	0.00%	U	
260	0	0	0	0 008	0 00%	0.00%	0	
bcmDPC	U	U	U	0.00%	0.00%	0.00%	U	
	10690	1069	10000	0 00% 1	0 00%	2 07% 0		
sysd	10690	1069	10000	0.00% 1	0.00%	2.976 0		
	2380	238	10000	0 00%	0 00%	0 509	0	
kfldintr	2300	230	10000	0.00%	0.006	0.50%	U	
58	30	3	10000	0 000	nne n	00° 0		
sh	30	3	10000 (0.00%	.00% 0	.00% 0		
36	50	_	10000	0 00%	0 00%	0 00%	0 13 5	ς.
	output truncat			0.006	0.00%	0.00%	0 13 5	٠.

Example 3 Figure 4-38. Command Example: show processes cpu stack-unit on S-Series

FTOS#show processes cpu stack-unit 0 CPU Statistics On Unit0 Processor CPU utilization for five seconds: 0%/0%; one minute: 0%; five minutes: 0% PID Runtime(ms) Invoked uSecs 5Sec 1Min 5Min TTY Process 52 8260 826 10000 0.00% 0.00% 0.22% sysd 124 1160 116 10000 0.00% 0.00% 0.12% 0 KernLrnAgMv 116 70 7 10000 0.00% 0.00% 0.00% xstp 5 10000 0.00% 0.00% 0.00% 109 50 0 span 108 60 10000 0.00% 0.00% 0.00% 6 pim 70 103 10000 0.00% 0.00% 0.00% 0 igmp 100 70 7 10000 0.00% 0.00% 0.00% 0 mrtm 96 70 7 10000 0.00% 0.00% 0.00% 0 12mgr 100 10 10000 0.00% 0.00% 0.00% 92 0 12pm 3.0 3 10000 0.00% 0.00% 0.00% 86 Ω arpm 83 40 4 10000 0.00% 0.00% 0.00% 0 ospf 80 100 10 10000 0.00% 0.00% 0.00% 0 dsm 0.00% 74 60 6 10000 0.00% 0.00% Ω rtm 70 30 3 10000 0.00% 0.00% 0.00% Ω rip 68 120 12 10000 0.00% 0.00% 0.00% 0 ipm1 64 70 7 10000 0.00% 0.00% 0.00% 0 acl 63 30 3 10000 0.00% 0.00% 0.00% bcmLINK.1 290 29 10000 0.00% 0.00% 0.00% bcmCNTR.1 50 10000 0.00% 0.00% 0.00% 0 61 bcmRX 4 10000 0.00% 0.00% 0.00% bcmLINK.0 0.00% 0.00% 0.00% bcmXGS3AsyncTX 58 0 0 0.00% 0.00% 0.00% bcmTX 340 10000 0.00% 0.00% 0.00% bcmCNTR.0 0 0 0 0.00% 0.00% 0.00% 55 bcmDPC 10000 117 60 6 0.00% 0.00% 0.00% 0 frrp 28 0 0 0 0.00% 0.00% 0.00% inetd 450 45 10000 0.00% 0.00% 0.00% 0 21 mount mfs 10000 0.00% 0.00% 0.00% 18 130 13 0 mount_mfs 11 Ω Ω Ω 0.00% 0.00% 0.00% 0 syslogd 3 10000 30 0.00% 0.00% 0.00% 0 sh 10 1 10000 0.00% 0.00% 0.00% 0 aiodoned 0 0 0 0.00% 0.00% 0.00% 0 ioflush 3 20 2 10000 0.00% 0.00% 0.00% 0 reaper 0 0 0.00% 0.00% 0.00% pagedaemon 0 0 0 0.00% 0.00% 0.00% init

Example 4 Figure 4-39. Command Example: show processes memory on S-Series

	FTOS#show proce	esses memory					
Start							
124 KernLrnAgMv	ctart				0/10/2007 02	.11.17]	
124 KernLrnAgMv	CurrentUsed:	130596864, Curre	ntFree:	29634560	9/19/2007 03:	11:1/]	
1124 KernLrnAgMv	SharedUsed :	14261872, Share	dFree :	6709672			
124 KernLrnAgMv	PID Process	ResSize	Size	Allocs	Frees	Max	
117 frrp	current 124 KernLrnAgN						
116 xstp 7585792 1536000 551812 49692 518684 502120	117 frrp	5677056	217088	87650	0	87650	
109 span	116 xstp	7585792	1536000	551812	49692	518684	
55386 108 pim 5869568 720896 12300 0 12300 103 igmp 5513216 327680 18236 16564 18236 1672 100 mrtm 6905856 516096 72846 0 72846 72846 96 12mgr 6107136 491520 254858 115948 172038 138910 92 12pm 5607424 221184 667578 579740 120966 87838 86 arpm 5353472 208896 54528 16564 54528 87838 86 arpm 5353472 208896 54528 16564 54528 87964 83 ospf 4210688 475136 0 0 0 0 80 dsm 6057984 552960 22838 0 22838 22838 74 rtm 6311936 577536 574792 298152 376024 276640 70 rip 5001216 249856 528 0 528 68 ipml 5292032 339968 67224 0 67224 573224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 0 63 bcmLINK.0 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 66 bcmLINK.0 140410880 0 0 0 0 0 0 0 67 bcmCNTR.1 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 68 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		E700024	221104	EE20 <i>6</i>	0	EE206	
108 pim		3709624	221104	33366	U	55566	
103 igmp	108 pim	5869568	720896	12300	0	12300	
100 mrtm 6905856 516096 72846 0 72846 72846 96 12mgr 6107136 491520 254858 115948 172038 138910 92 12pm 5607424 221184 667578 579740 120966 187838 86 arpm 5353472 208896 54528 16564 54528 1839964 83 ospf 4210688 475136 0 0 0 0 0 80 dsm 6057984 552960 22838 0 22838 22838 74 rtm 6311936 577536 574792 298152 376024 276640 70 rip 5001216 249856 528 0 528 68 ipm1 5292032 339968 67224 0 67224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 0 65 bcmCNTR.1 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	103 igmp	5513216	327680	18236	16564	18236	
96 l2mgr 6107136 491520 254858 115948 172038 138910	100 mrtm	6905856	516096	72846	0	72846	
92 l2pm	96 l2mgr	6107136	491520	254858	115948	172038	
86 arpm 5353472 208896 54528 16564 54528 37964 83 ospf 4210688 475136 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	92 12pm	5607424	221184	667578	579740	120966	
83 ospf 4210688 475136 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	86 arpm	5353472	208896	54528	16564	54528	
80 dsm 6057984 552960 22838 0 22838 74 rtm 6311936 577536 574792 298152 376024 276640 70 rip 5001216 249856 528 0 528 68 ipm1 5292032 339968 67224 0 67224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 57 bcmCNTR.1 140410880 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 0 59 bcmSGS3AsyncTX 140410880 0 0 0 0 0 0 0 50 bcmDPC 140410880 0 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0 0	83 ospf	4210688	475136	0	0	0	
74 rtm 6311936 577536 574792 298152 376024 276640 70 rip 5001216 249856 528 0 528 68 ipm1 5292032 339968 67224 0 67224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 58 bcmDPC 140410880 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0 0	80 dsm	6057984	552960	22838	0	22838	
70 rip 5001216 249856 528 0 528 68 ipm1 5292032 339968 67224 0 67224 64 acl 5607424 544768 140086 66256 123522 73830	74 rtm	6311936	577536	574792 2	298152 376	024 2766	4 0
68 ipm1 5292032 339968 67224 0 67224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 59 bcmXGS3AsyncTX 140410880 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 69 bcmXGS3AsyncTX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 60 bcmCNTR.0 140410880 0 0 0 0 0 0 0 61 bcmCNTR.0 140410880 0 0 0 0 0 0 0 62 sysd 44650496 22876160 3930856 1358248 2589172 67 bcmCNTR.0 140410880 0 0 0 0 0 0 0 68 bcmTX 140410880 0 0 0 0 0 0 0 0 69 bcmLINK.0 140410880 0 0 0 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0							
67224 64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 59 bcmXGS3AsyncTX 140410880 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0							
64 acl 5607424 544768 140086 66256 123522 73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 62 bcmCNTR.1 140410880 0 0 0 0 0 0 61 bcmRX 140410880 0 0 0 0 0 0 60 bcmLINK.0 140410880 0 0 0 0 0 0 0 59 bcmXGSS3AsyncTX 140410880 0 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 0 65 bcmCNTR.0 140410880 0 0 0 0 0 0 65 bcmDPC 140410880 0 0 0 0 0 0 0 65 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0		5292032	339968	67224	0	67224	
73830 63 bcmLINK.1 40410880 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		5607424	544768	140086	66256	123522	
0 60 bcmLINK.0 140410880 0 0 0 0 0 0 59 bcmXGS3AsyncTX 140410880 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	73830			110000	00250	10,700	
0 60 bcmLINK.0 140410880 0 0 0 0 0 0 59 bcmXGS3AsyncTX 140410880 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	63 bcmLINK.1	40410880	0	0		-	C
0 60 bcmLINK.0 140410880 0 0 0 0 0 0 59 bcmXGS3AsyncTX 140410880 0 0 0 0 0 58 bcmTX 140410880 0 0 0 0 0 57 bcmCNTR.0 140410880 0 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	62 bcmCNTR.1	140410880	0	0			(
0 57 bcmCNTR.0 140410880 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	61 bcmRX	140410880	0	Ο	0	0	
0 57 bcmCNTR.0 140410880 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0) .co h	140410000	0	0	0	0	,
0 57 bcmCNTR.0 140410880 0 0 0 0 0 55 bcmDPC 140410880 0 0 0 0 0 52 sysd 44650496 22876160 3930856 1358248 2589172 2572608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	60 DCIILLINK.U	140410880	0	U	-	-	
57 bcmCNTR.0 140410880 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	58 bcmTX	140410880	0	0			,
25/2608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	57 bcmCNTR.0	140410880	0	0	0	0	C
25/2608 28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	55 bcmDPC	140410880	0	0	0	0	
28 inetd 876544 69632 0 0 0 0 21 mount_mfs 22642688 1953792 0 0 0	52 sysd 2572608	44650496	22876160	3930856	1358248	2589172	
21 mount_mfs 22642688 1953792 0 0 0	28 inetd 0				0	0	
	21 mount_mfs	22642688	1953792	0	0	0	

Example 5 Figure 4-40. Command Example: show processes memory stack-unit on S-Series

	stics On Unit (
start Total : 160 CurrentUsed: 130 SharedUsed : 14	0231424, MaxUse 0560000, Currer 4261872, Shared	ed : 1 ntFree: dFree :	130596864 [09, 29671424 6709672	/19/2007 03:	11:17]
PID Process Current	ResSize	Size	Allocs	Frees	Max
124 KernLrnAgMv 0	140410880	0	0	0	0
	5677056	217088	87650	0	87650
116 xstp 502120	7585792	1536000	551812	49692	518684
	5709824	221184	55386	0	55386
108 pim 12300	5869568	720896	12300	0	12300
103 igmp 1672	5513216	327680	18236	16564	18236
	6905856	516096	72846	0	72846
	6107136	491520	254858	115948	172038
92 12pm 87838	5607424	221184	667578	579740	120966
86 arpm 37964	5353472	208896	54528	16564	54528
83 ospf	4210688	475136	0	0	0
80 dsm 22838	6057984	552960	22838	0	22838
74 rtm 276640	6311936	577536	574792	298152	376024
70 rip 528	5001216	249856	528	0	528
	5292032	339968	67224	0	67224

Related Commands

show hardware layer2 acl	Display Layer 2 ACL data for the selected stack member and stack member port-pipe.
show hardware layer3	Display Layer 3 ACL or QoS data for the selected stack member and stack member port-pipe.
show hardware stack-unit	Display the data plane or management plane input and output statistics of the designated component of the designated stack member.
show hardware system-flow	Display Layer 3 ACL or QoS data for the selected stack member and stack member port-pipe.
show interfaces stack-unit	Display information on all interfaces on a specific S-Series stack member.
show processes memory (S-Series)	Display CPU usage information based on processes running in an S-Series

show processes ipc flow-control

CES Display the Single Window Protocol Queue (SWPQ) statistics.

Syntax show processes ipc flow-control [cp | rp1 | rp2 | lp linecard-number]

Parameters

ср	(OPTIONAL) Enter the keyword cp to view the Control Processor's SWPQ statistics.
rp1	(OPTIONAL) Enter the keyword rp1 to view the Control Processor's SWPQ statistics on Route Processor 1.*
rp2	(OPTIONAL) Enter the keyword rp2 to view the Control Processor's SWPQ statistics on Route Processor 2.*
Ip linecard-number	(OPTIONAL) Enter the keyword Ip followed by the line card number to view the Control Processor's SWPQ statistics on the specified line card.*

^{*} In the **S-Series**, this command supports only the **cp** keyword, not the **rp1**, **rp2**, and **lp** options. See Figure 4-45.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Example 1 Figure 4-41. Command Example: show processes ipc flow-control from C-Series

	on CP Processor											
TxProcess	RxProcess	Cur		High	Time	Retr		Msg		Ack A		ſax
		Len		Mark	Out	ies		Sent		Rcvd R		etra
	RTMO 0		0	0	0		0		0	10	10	
ACL0	DIFFSERV0	0		0	0	0		0		0	10	1
ACL0	IGMP0	0		0	0	0		0		0	10	1
ACL0	PIMO	0		0	0	0		0		0	10	1
ACL0	ACL20	0		1	0	0		2		2	50	5
CFG0	CFGDATASYNC0	0		2	0	0		7		7	255	25
DHCP0	ACL0	0		1	0	0		9		9	25	2
DHCP0	IFMGR0	0		0	0	0		0		0	25	2
RTM0	ARPMGR0	0		1	0	0		1		1	136	13
ACL20	IGMP0	0		0	0	0		0		0	50	5
LACP0	IFMGR0	0		2	0	0		4		4	25	2
ARPMGR0	MRTM0	0		0	0	0		0		0	100	10
ACL20	PIM0	0		0	0	0		0		0	50	5
MACMGR0	ACL0	0		1	0	0		1		1	25	2
CLASSMGR0	ARPMGR0	0		0	0	0		0		0	100	10
IFMGR0	IPMGR2	0		6	0	0		44		44	8	

Example 2 Figure 4-42. Command Example: show processes ipc flow-control rp from E-Series

Statistics of	on CP Processor								
TxProcess	RxProcess	Cur	High	Time	Retr	Msg	Ack Av	al M	lax
		Len	Mark	Out	ies	Sent	Rcvd Re	etra R	etr
DHCP0	ACL0	0	1	0	0	6	6	25	
DHCP0	IFMGR0	0	0	0	0	0	0	25	
IFMGR0	FEFD0	0	3	0	0	27	27	8	
IFMGR0	IPMGR0	0	6	0	0	44	44	8	
IFMGR0	SNMP0	0	1	0	0	16	16	8	
IFMGR0	SFL CP0	0	4	0	0	31	31	8	
IFMGR0	EVENTTERMLOG0	0	1	0	0	6	6	8	
IFMGR0	PORTMIRRO	0	0	0	0	0	0	8	
IFMGR0	DHCP0	0	1	0	0	6	6	8	
IFMGR0	TCLASSMGR0	0	2	0	0	13	13	8	
IFMGR0	VRRP0	0	3	0	0	25	25	8	
IFMGR0	MRTM0	0	2	0	0	21	21	8	
TCLASSMGR0	ARPMGR0	0	0	0	0	0	0	100	1
IFMGR0	IPMGR2	0	6	0	0	44	44	8	

Table 4-4 list the definitions of the fields shown in Figure 4-41 and Figure 4-42.

Table 4-4. Description of show processes ipc flow-control cp output

Field	Description
Source QID /Tx Process	Source Service Identifier
Destination QID/Rx Process	Destination Service Identifier
Cur Len	Current number of messages enqueued
High Mark	Highest number of packets in the queue at any point of time
#of to / Timeout	Timeout count
#of Retr /Retries	Number of retransmissions
#msg Sent/Msg Sent/	Number of messages sent
#msg Ackd/Ack Rcvd	Number of messages acknowledged
Retr /Available Retra	Number of retries left
Total/ Max Retra	Number of retries allowed

Example 2 Figure 4-43. Command Example: show processes ipc flow-control rp

FTOS# show processes ipc	flov	v-cont	rol	rp2				
[qid] Source->Dest					#msg Sent	#msg Ackd	Retr	total
[1] unknown2->unknown2	0	0	0	0	0	0	3	3
[2] 12pm0->spanMgr0	0	2	0	0	2298	2298	25	25
[3] fvrp0->macMgr0	0	0	0	0	0	0	25	25
[4] 12pm0->fvrp0	0	2	0	0	1905	1905	25	25
[5] fvrp0->l2pm0	0	0	0	0	0	0	25	25
[6] stp0->12pm0	0	0	0	0	0	0	25	25
[7] spanMgr0->macMgr0	0	0	0	0	0	0	25	25
[8] spanMgr0->ipMgr0	0	0	0	0	0	0	25	25
FTOS#								

Example 3 Figure 4-44. Command Example: show processes ipc flow-control lp

TxProcess	RxProcess	Cur	High	Time	Retries	Msg	Ack	Aval	Max
		Len	Mark	Out		Sent	Rcvd	Retra	Retr
ACL AGENT10	PIM0	0	0	0	0	0	0	20	2
ACL AGENT10	PIM0	0	0	0	0	0	0	20	2
FRRPAGT10	FRRP0	0	0	0	0	0	0	30	3
IFAGT10	IFMGR0	0	1	0	0	1	1	8	
PDMACAGENT10	MACMGR 0	0	0	0	0	0	0	25	2

Example 4 Figure 4-45. Command Example: show processes ipc flow-control on S-Series

TxProcess	RxProcess	Cur	High	Time	Retr	Msq	Ack	Aval	ľ
		Len	Mark	Out	ies	Sent		Retra	
ACL0	RTM0	0	0	0	0	0	0	10	
ACL0	DIFFSERV0	0	0	0	0	0	0	10	
ACL0	IGMP0	0	0	0	0	0	0	10	
ACL0	PIM0	0	0	0	0	0	0	10	
LACP0	IFMGR0	0	0	0	0	0	0	25	
RTM0	ARPMGR0	0	0	0	0	0	0	136	-
MACMGR0	ACL0	0	0	0	0	0	0	25	
ARPMGR0	MRTM0	0	0	0	0	0	0	100	
DHCP0	ACL0	0	1	0	0	1	1	25	
DHCP0	IFMGR0	0	0	0	0	0	0	25	
L2PM0	SPANMGR0	0	2	0	0	14	14	25	
ARPMGR0	FIBAGT0	0	1	0	0	1	1	100	1
SPANMGR0	MACMGR0	0	0	0	0	0	0	25	
SPANMGR0	IPMGR0	0	0	0	0	0	0	25	
SPANMGR0	L2PM0	0	0	0	0	0	0	25	
STP0	L2PM0	0	0	0	0	0	0	25	
RTM0	FIBAGT0	0	2	0	0	4	4	255	2
L2PM0	STP0	0	5	0	0	5	5	25	
ACL_AGENT0		0	0	0	0	0	0	20	
ACL_AGENT0	PIM0	0	0	0	0	0	0	20	
FRRP0	L2PM0	0	0	0	0	0	0	25	
L2PM0	FRRP0	0	1	0	0	13	13	25	
ACL0	ACL_AGENT0	0	4	0	0	7	7	90	
ACL0	MACAGENT0	0	0	0	0	0	0	90	
IFMGR0		0	1	0	0	1	1	8	
IFMGR0	SNMP0	0	1	0	0	1	1	8	
IFMGR0	IPMGR0	0	7	0	0	9	9	8	
IFMGR0	DIFFSERV0	0	2	0	0	3	3	8	
DIFFSERV0	ACL AGENTO	0	0	0	0	0	0	100	1

Usage Information The Single Window Protocol (SWP) provides flow control-based reliable communication between the sending and receiving software tasks.

Important Points to Remember

- A sending task enqueues messages into the SWP queue3 for a receiving task and waits for an acknowledgement.
- If no response is received within a defined period of time, the SWP timeout mechanism resubmits the message at the head of the FIFO queue.
- After retrying a defined number of times, the following timeout message is generated:

SWP-2-NOMORETIMEOUT

• In the display output in Figure 4-45, a retry (Retries) value of zero indicates that the SWP mechanism reached the maximum number of retransmissions without an acknowledgement.

show processes memory (C-Series and E-Series)

[C][E]View memory usage information based on processes running in the system.

Syntax

show processes memory [cp | lp slot-number {lp all | lp summary} | rp1 | rp2]

Parameters

ср	(OPTIONAL) Enter the keyword cp to view memory usage of the Control Processor.
Ip slot-number	(OPTIONAL) Enter the keyword Ip and the slot number to view information on the line-card processor in that slot.
	C-Series Range: 0-7
	E-Series Range: 0 to 13 on a E1200/E1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.
lp all	(OPTIONAL) Enter the keyword Ip all to view CP memory usage on all active line cards.
Ip summary	(OPTIONAL) Enter the keyword lp summary to view a summary of the line card CP memory usage.
rp1	(OPTIONAL) Enter the keyword rp1 to view memory usage of the Route Processor 1.
	Note: This option is supported on the E-Series only.
rp2	(OPTIONAL) Enter the keyword rp2 to view memory usage of the Route Processor 2.
	Note: This option is supported on the E-Series only.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.1.1.2	Introduced on E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale E1200i
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Added Ip all and Ip summary options
Version 6.5.1.0	For rp1 and rp2 only, the output displays memory consumption of all the processes including a summary (see Figure 4-47 and Figure 4-48.

Usage Information

The output for show process memory displays the memory usage statistics running on CP part (sysd) of the system. The Sysd is an aggregate task that handles all the tasks running on C-Series' and E-Series' CP.

In FTOS Release 7.4.1.0 and higher, the total counter size (for all 3 CPUs) in **show memory** and **show processes memory** will differ based on which FTOS processes are counted.

- In the show memory (C-Series and E-Series) display output, the memory size is equal to the size of the application processes.
- In the show processes memory (C-Series and E-Series) display output, the memory size is equal to the size of the application processes *plus* the size of the system processes.

Example Figure 4-46. Command Example: show processes memory (partial)

	cesses memory tatistics On CP	Processor (byt	es)		
=======	0.01.04		===	C40F20CC Character	
				64873866, Current	
		TotalFreed		CurrentHolding	
tRootTask	39083408	1395840	38143920	37687568	
tARL	64	0	64	64	
tBcmTask	256	0	256	256	
tPortmapd	18560	0	18560	18560	
tShell	3440	0	3440	3440	
tPingTmo0	0	1088	0	0	
tExcTask	0	592864	0	0	
tme	4002494	192	4002302	4002302	
ipc	34060	192	34060	33868	
irc	943436	0	943436	943436	
RpmAvailMgr	9376	32	9344	9344	
ev	133188	0	133188	133188	
evterm	26752	0	26752	26752	
evhdlr	2528	8064	2528	0	
dlm	7556256	7366960	1239104	189296	
dla	416	0	416	416	
tsm	15136	0	15136	15136	
fmq	766560	0	766560	766560	
fileProc	416	0	416	416	
sysAdmTsk	42028	0	42028	42028	

Example Figure 4-47. Command Example: show processes memory rp1

FTOS#	show proce	esses memory 1	rp1				
Curre	entUsed:	954650624, Ma 114135040, Ct 7849096, Sh	rrentFree:	840515584	/8/2006 15:1	L:42]	
PID	Process	ResSiz	e Size	Allocs	Frees	Max	Current
124	ospf	321536	0 425984	0	0	0	0
119	dsm	774963	2 1859584	797026	0	797026	797026
114	ipm1	382156	8 229376	297324	0	297324	297324
112	rtm	472268	8 421888	925008	0	925008	925008
107	rip	373145	6 253952	198216	0	198216	198216
104	acl	473497	6 430080	1127524	0	1127524	1127524
100	sysd1	1163673	6 2019328	965798	0	965798	965798
98	sysmon	52838	4 94208	0	0	0	0
36	sshd	128614	4 430080	0	0	0	0
34	inetd	66355			0	0	0
	mount_mfs	4239769	6 2514944	0	0	0	0
_	mount_mfs	36454		0	0	0	0
-	sh	44646		0	0	0	0
_	aiodoned	7652966	4 0	0	0	0	0
4	ioflush	7652966		0	0	0	0
	reaper	7652966		0	0	0	0
	pagedaemon			0	0	0	0
1	init	13926		0	0	0	0
0	swapper	7652966	4 0	0	0	0	0

Example Figure 4-48. Command Example: show processes memory rp2

FTOS#show proc	esses memory rp2					
Total : CurrentUsed: SharedUsed :	953700352, MaxUs 149417984, Curre 7847200, Share	ntFree:	804282368	/2006 12:33	:6]	
PID Process	ResSize	Size	Allocs	Frees	Max	Current
145 vrrp	3870720	266240	297324	0	297324	297324
141 fvrp	4472832	204800	797010	0	797010	797010
138 xstp	10764288	7155712	367534	0	367534	367534
133 span	4136960	167936	565810	0	565810	565810
132 pim	6664192	516096	2812528	0	2812528	2812528
128 igmp	4112384	344064	627684	0	627684	627684
124 ipm2	3923968	237568	363396	0	363396	363396
120 mrtm	25567232	593920	697790	0	697790	697790
116 l2mgr	4579328	520192	830098	0	830098	830098
112 l2pm	3874816	225280	367446	32948	367446	334498
108 arpm	3702784	208896	268420	0	268420	268420
104 acl2	3485696	94208	132144	0	132144	132144
100 sysd2	11657216	1679360	998834	0	998834	998834
98 sysmon	528384	94208	0	0	0	0
36 sshd	1286144	430080	0	0	0	0
34 inetd	663552	98304	0	0	0	0
32 mount mfs	41791488	2514944	0	0	0	0
19 mount mfs	364544	2449408	0	0	0	0
6 sh	446464	737280	0	0	0	0
5 aiodoned	76967936	0	0	0	0	0
4 ioflush	76967936	0	0	0	0	0
3 reaper	76967936	0	0	0	0	0
2 pagedaemo		0	0	0	0	0
1 init	139264	2375680	0	0	0	0
0 swapper	76967936	0	0	0	0	0
FTOS#						

Table 4-5 defines the fields that appear in the **show processes memory** output.

Table 4-5. Descriptions of show processes memory rp1/rp2 output

Field	Description
Total:	Total system memory available
MaxUsed:	Total maximum memory used ever (history indicated with time stamp)
CurrentUsed:	Total memory currently in use
CurrentFree:	Total system memory available
SharedUsed:	Total used shared memory
SharedFree:	Total free shared memory
PID	Process ID
Process	Process Name
ResSize	Actual resident size of the process in memory
Size	Process test, stack, and data size
Allocs	Total dynamic memory allocated
Frees	Total dynamic memory freed
Max	Maximum dynamic memory allocated
Current	Current dynamic memory in use

show processes memory (S-Series)

Display memory usage information based on processes running in the S-Series system.

$\textbf{Syntax} \qquad \textbf{show processes memory } \{ \textbf{management-unit} \mid \textbf{stack unit} \; \{ \textit{0--7} \mid \textbf{all} \mid \textbf{summary} \} \}$

Parameters

management-unit	Enter the keyword management-unit for CPU memory usage of the stack management unit.	
stack unit 0-7	Enter the keyword stack unit followed by a stack unit ID of the member unit for which to display memory usage on the forwarding processor.	
all	Enter the keyword all for detailed memory usage on all stack members.	
summary	Enter the keyword summary for a brief summary of memory availability and usage on all stack members.	

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Modified: Added management-unit option
Version 7.6.1.0	Introduced on S-Series

Usage Information

The output for show process memory displays the memory usage statistics running on CP part (sysd) of the system. The Sysd is an aggregate task that handles all the tasks running on S-Series' CP.

For S-Series, the output of **show memory** and this command will differ based on which FTOS processes are counted.

- In the **show memory** display output, the memory size is equal to the size of the application processes.
- In the output of this command, the memory size is equal to the size of the application processes *plus* the size of the system processes.

Example Figure 4-49. Command Example: show processes memory on S-Series

tal: 2684	35456, MaxUsed:	2420244, Currer	ntUsed: 242	0244, CurrentFree:
6015212				
TaskName	TotalAllocated	TotalFreed	MaxHeld	CurrentHolding
tme	435406	397536	54434	37870
ipc	16652	0	16652	16652
timerMgr	33304	0	33304	33304
sysAdmTsk	33216	0	33216	33216
tFib4	1943960	0	1943960	1943960
aclAgent	90770	16564	74206	74206
ifagt 1	21318	16564	21318	4754
dsagt	6504	0	6504	6504
MacAgent	269778	0	269778	269778

Example Figure 4-50. Command Example: show processes memory management-unit

FTOS#show proces	ses management-	unit				
Total : 1 CurrentUsed: SharedUsed :	.51937024, MaxUs 98848768, Curre 13007848, Share	ed : 1 ntFree: dFree :	.11800320 [2/2 53088256 7963696	25/2008 4:18	:53]	
PID Process	ResSize	Size	Allocs	Frees	Max	Current
337 KernLrnAgMv	117927936	0	0	0	0	0
331 vrrp 323 frrp 322 xstp 321 pim	5189632	217030	50572	0	50572	50572
323 frrp	5206016	241664	369238	0	369238	369238
322 xstp	7430144	2928640	38328	0	38328	38328
321 pim	5267456	823296	62168	0	62168	62168
314 igmp	4960256	380928	18588	16564	18588	2024
313 mrtm	6742016	1130496	72758	0	72758	72758
308 l2mgr	5607424	552960	735214	380972	619266	354242
301 l2pm	5001216	167936	1429522	1176044	286606	253478
298 arpm	4628480	217088	71092	33128	71092	37964
294 ospf	5468160	503808	724204	662560	78208	61644
288 dsm	6778880	1159168	39490	16564	39490	22926
287 rtm	5713920	602112	442280	198768	376024	243512
	4562944	258048	528	0	528	528
281 lacp	4673536	266240	221060	0	221060	221060
277 ipm1	4837376	380928	83788	0	83788	83788
273 acl	5005312	512000	239564	149076	123616	90488
272 topoDPC	117927936	0	0	0	0	0
271 bcmNHOP	117927936	0	0	0	0	0
270 bcmDISC	117927936	0	0	0	0	0
269 bcmATP-RX	117927936	0	0	0	0	0
268 bcmATP-TX	117927936	0	0	0	0	0
267 bcmSTACK	117927936	0	0	0	0	0
266 bcmRX	117927936	0	0	0	0	0
265 bcmLINK.0	117927936	0	0	0	0	0
(! out	put truncated -		!			
! out	put truncated -		!			

Table 4-6 defines the fields that appear in the **show processes memory** output.

Table 4-6. Descriptions of show processes memory output

Field	Description
Total:	Total system memory available
MaxUsed:	Total maximum memory used ever (history indicated with time stamp)
CurrentUsed:	Total memory currently in use
CurrentFree:	Total system memory available
SharedUsed:	Total used shared memory
SharedFree:	Total free shared memory
PID	Process ID
Process	Process Name
ResSize	Actual resident size of the process in memory
Size	Process test, stack, and data size
Allocs	Total dynamic memory allocated
Frees	Total dynamic memory freed
Max	Maximum dynamic memory allocated
Current	Current dynamic memory in use

show processes switch-utilization

E Show switch fabric utilization.

Syntax show processes switch-utilization

Command Mode EXEC

EXEC Privilege

Command History

Version 8.1.1.0 Introduced on E-Series ExaScale
E-Series original Command

Example Figure 4-51. Command Example: show processes switch-utilization

FTOS#show processes switch-utilization

Switch fabric utilization 5Sec 1Min 5Min

3% 3% 3%

Usage Information An asterisk (*) in the output indicates a legacy card that is not support by the **show processes switch-utilization** command.

show rpm

Show the current RPM status.

Syntax show rpm [number [brief] | all]

Parameters

number	(OPTIONAL) Enter either zero (0) or 1 for the RPM.
all	(OPTIONAL) Enter the keyword all to view a table with information on all present RPMs.
brief	(OPTIONAL) Enter the keyword brief to view an abbreviated list of RPM information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.8	Updated to support PPID on the S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

E-Series Example Figure 4-52. Command Example: show rpm on E-Series

```
FTOS#show rpm
 -- RPM card 0 --
Status : active
Next Boot : online
 Card Type
                          : RPM - Route Processor Module (LC-EH-RPM)
Hardware Rev : 3.1
Num Ports : 1
Up Time : 18 hr, 48 min
Last Restart : reset by user
FTOS Version : 8-4-1-317
Jumbo Capable : yes
CP Boot Flash : A: 2.5.1.0 [booted] B: 2.5.1.0
RP1 Boot Flash: A: 2.5.1.0 [booted] B: 2.5.1.0 RP2 Boot Flash: A: 2.5.1.0 [booted] B: 2.5.1.0
RP2 Boot Flash: A: 2.5.1.0 [boo CP Mem Size : 1073741824 bytes RP1 Mem Size : 1073741824 bytes RP2 Mem Size : 1073741824 bytes MMC Mem Size : 3566329856 bytes External MMC : 128180224 bytes USB Mem Size : n/a Temperature : 36C Power Status : AC
 Voltage
Voltage : ok
Serial Number : FX000056234
Part Number : 7520043401 Rev 05
Vendor Id : 04
Date Code : 01072010
Country Code : 01
 Piece Part ID : N/A
PPID Revision : N/A
Service Tag
                        : N/A
Expr Svc Code : N/A
 -- RPM card 1 --
 Status
                        : not present
FTOS#
```

Table 4-7 defines the fields displayed in Figure 4-52.

Table 4-7. Descriptions of show rpm output

Field	Description			
Status	Displays the RPM's status.			
Next Boot	Displays whether the RPM is to be brought online at the next system reload.			
Card Type	Displays the RPM catalog number.			
Hardware Rev	Displays the E-Series chipset hardware revision level: 1.0 (non-Jumbo); 1.5 (Jumbo-enabled); 2.0 (or above is TeraScale).			
Num Ports	Displays the number of active ports.			
Up Time	Displays the number of hours and minutes since the RPM's last reboot.			
Last Restart	States the reason for the last RPM reboot.			
	C-Series possible values:			
	"normal power-cycle" (reset power-cycle command)			
	• "reset by master" (peer RPM reset by master RPM)			
	• "over temperature shutdown"			
	• "power supply failed"			
	E-Series possible values:			
	"normal power-cycle" (insufficient power, normal power cycle)			
	"reset by user" (automatic failover, software reload of both RPMs, or master RPM resetting peer)			
	"force-failover" (redundancy force-failover command)			

Table 4-7. Descriptions of show rpm output

Field	Description
FTOS Version	Displays the operating software version.
Jumbo Capable	Displays a Yes or No indicating if the RPM is capable of sending and receiving Jumbo frames.
	This field does not indicate if the chassis is in Jumbo mode; for that determination, use the show chassis brief command.
CP Boot Flash	Displays the two possible Boot Flash versions for the Control Processor. The [Booted] keyword next to the version states which version was used at system boot.
RP1 Boot Flash	Displays the two possible Boot Flash versions for the Routing Processor 1. The [Booted] keyword next to the version states which version was used at system boot.
RP2 Boot Flash	Displays the two possible Boot Flash versions for the Routing Processor 2. The [Booted] keyword next to the version states which version was used at system boot.
CP Mem Size	Displays the memory of the Control Processor.
RP1 Mem Size	Displays the memory of the Routing Processor 1.
PR2 Mem Size	Displays the memory of the Routing Processor 2.
Temperature	Displays the temperature of the RPM.
	Minor alarm status if temperature is over 65° C.
Power Status	Lists the status of the power modules in the chassis.
Voltage	Displays the power rails for the line card.
Serial Num	Displays the line card serial number.
Part Num	Displays the line card part number.
Vendor ID	Displays an internal code, which specifies the manufacturing vendor.
Date Code	Displays the line card's manufacturing date.
Country Code	Displays the country of origin. 01 = USA

Related Commands

show chassis	View information on all elements of the system.
show linecard	View information on a line card.
show sfm	View information on the SFM.

show software ifm

Display interface management (IFM) data.

Syntax

 $\textbf{show software ifm } \{\textbf{clients} \ [\textbf{summary}] \ | \ \textbf{ifagt} \ \textit{number} \ | \ \textbf{ifcb} \ \textit{interface} \ | \ \textbf{stack-unit} \ \textit{unit-ID} \ | \ \\$ trace-flags}

Parameters

clients	Enter the keyword clients to display IFM client information.
summary	(OPTIONAL) Enter the keyword summary to display brief information about IFM clients.
ifagt number	Enter the keyword ifagt followed by the number of an interface agent to display software pipe and IPC statistics.
ifcb interface	Enter the keyword ifcb followed by one of the following interface IDs followed by the slot/port information to display interface control block information for that interface:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet .
	 For a Port Channel interface, enter the keyword port-channel. (Range: 1–128)
	 For a 10G Ethernet interface, enter the keyword TenGigabitEthernet.
	C-Series options also include:
	fastethernet for a Fast Ethernet interface
	• loopback for a Loopback interface
	managementethernet for a Management Ethernet interface
	• null for a Null interface
	• vlan for a VLAN interface (Range: 1–4094, 1-2094 for ExaScale)
stack-unit unit-ID	Enter the keyword stack-unit followed by the stack member number to display IFM information for that unit.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
	Note: This option is only available on S-Series.
trace-flags	Enter the keyword trace-flags to display IFM information for internal trace flags.

Defaults

None

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced for C-Series and S-Series

S-Series Example

Figure 4-53. Command Example: show software ifm clients summary on S-Series

```
FTOS#show software ifm clients summary
ClntType
         Inst
                  svcMask
                             subSvcMask
                                          {\tt tlvSvcMask}
                                                       tlvSubSvc swp
IPM
                0x00000000 0x00000000 0x90ff71f3 0x021e0e81 31
RTM
                0x00000000 0x00000000 0x800010ff 0x01930000
         0
VRRP
         0
                0x00000000 0x00000000 0x803330f3 0x00400000
L2PM
                0x00000000 0x00000000 0x87ff79ff 0x0e032200 45
         0
ACL
         0
                0x00000000 0x00000000 0x867f50c3 0x000f0218
OSPF
                0x00000dfa 0x00400098 0x00000000 0x00000000
         0
PIM
         0
                0x000000f3 0x00030000 0x00000000 0x00000000
IGMP
                0x000e027f 0x00000000 0x00000000 0x00000000
         0
                0x00000000 0x00000000 0x800302c0 0x00000002
SNMP
         0
EVTTERM
                0x00000000 0x00000000 0x800002c0 0x00000000
         0
                0x00000000 0x00000200 0x81f7103f 0x00000000 38
MRTM
         0
DSM
                0x00000000 0x00000000 0x80771003 0x00000000 32
         0
LACP
         0
                0x00000000 0x00000000 0x8000383f 0x00000000 35
DHCP
         0
                0x00000000 0x00000000 0x800000c2 0x0000c000
V6RAD
                0
Unidentified Client0
                         0x006e0002 0x00000000 0x00000000 0x00000000 0
FTOS#
```

show switch links

C View the switch fabric backplane or internal status.

Syntax show switch links {backplane | internal}

Parameters

backplane	Enter the keyword backplane to view a table with information on the link status of the switch fabric backplane for both SFMs.
internal	Enter the keyword internal to view a table with information on the internal status of the switch fabric modules.

Defaults

None

Command Modes EXEC

Command History

Version 7.5.1.0 Introduced on C-Series

Example

Figure 4-54. Command Example: show switch links backplane

```
FTOS# show switch links backplane
Switch fabric backplane link status:
                    SFM0 Links Status
                                                     SFM1 Links Status
LC SlotID
            Port0 | Port1 | Port2 | Port3 | Port4 | Port5 | Port6 |
Port.7
  0
                                                   down
                                                           down
            up
                    up
                            uρ
                                    uρ
                                           down
                                                                   down
  1
            not present
   2
            not present
            not present
            not present
            not present
            up
                    up
                                           down
                                                   down
                                                           down
                                                                   down
            not present
up - Both ends of the link are up
down - Both ends of the link are down
up / down - SFM side up and LC side down
down / up - SFM side down and LC side up
FTOS#
```

show system (S-Series)

Display the current status of all stack members or a specific member.

Syntax show system [brief | stack-unit unit-id | stack-ports { status | topology}]

Parameters

brief	(OPTIONAL) Enter the keyword brief to view an abbreviated list of system information.
stack-unit unit-id	(OPTIONAL) Enter the keyword Stack-unit followed by the stack member ID for information on that stack member. Unit ID range: S60 : 0-11 all other S-Series : 0-7
stack-ports status topology	(OPTIONAL) Enter the keyword stack-ports for information on the status or topology of the S60 stack ports. Note: THis option applies to the S60 only.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Modified output: Boot Flash field will display code level for boot code 2.8.1.1 and newer, while older boot codes are displayed as "Present".
Version 7.7.1.0	Modified output: Added Master Priority field.
Version 7.6.1.0	Introduced for S-Series switches

Usage

Figure 4-57 shows the output from the **show system brief** command.

Figure 4-56 shows the output from the **show system stack-unit** command on a non-S60 system.

Figure 4-57 shows the output from the **show system stack-unit** command on an S60.

Example Figure 4-55. Command Example: show system brief

ocack	MAC : 0:1:	eo:uo:4:/	U					
	tack Info UnitType			ReqTyp	CurTy	p	Version	Ports
1 2 3 4 5	Member Standby Mgmt Member Member Member Member Member	online online not pre not pre not pre not pre	esent esent esent esent	S50V S50V	S50V S50V		7.7.1.0 7.7.1.0	
	odule Info Module No			Module Ty	pe	Ports	3	
1	0 1 0			S50-01-10 S50-01-24 S50-01-10 S50-01-24				
	ower Suppli Bay Sta		Туре					
1 1 2 2	0 up 1 ab 0 up 1 ab	sent sent	AC AC					
Unit	an Status TrayStatu	s Fan0						
1	up up	up	up	up	up	up	up	

Example Figure 4-56. Command Example: show system stack-unit

```
FTOS#show system stack-unit 0
       Unit 0 --
Unit Type : Management Unit
Status : online
Next Boot : online
Required Type : S4810 - 52-port GE/TE/FG (SE)
Current Type : S4810 - 52-port GE/TE/FG (SE)
 Master priority : 0
Hardware Rev : 3.0
Num Ports : 64
Up Time : 3 day, 21 hr, 37 min
FTOS Version : 8.3.12.0
Jumbo Capable : yes
Jumbo Capable : yes
POE Capable : no
FIPS Mode : disabled
Boot Flash : 1.2.0.0
Memory Size : 2147483648 bytes
Temperature : 55C
Voltage : ok
Serial Number : HADL111220134
Part Number : 7590009601 Rev A
Vendor Id : 07
Date Code : 01122011
Country Code : 02
Piece Part ID : N/A
PPID Revision : N/A
Service Tag : N/A
Service Tag : N/A
Expr Svc Code : N/A
 Auto Reboot
                                : disabled
 Burned In MAC : 00:01:e8:8a:e1:ab
                                : 3
 No Of MACs
-- Power Supplies --
Unit Bay Status Type FanStatus
                         up AC up absent
    0 0 up
0 1 absent
 -- Fan Status --
 Unit Bay TrayStatus Fan0 Speed Fan1 Speed
   0 0
0 1

        up
        up
        11280
        up
        11520

        up
        up
        11520
        up
        11280

 FTOS#
```

Example Figure 4-57. Command Example: show system stack-unit (S60)

```
FTOS#show system stack-unit 0
 -- Unit 0 --
                    : Management Unit
Unit Type
Status
                     : online
Next Boot : online
Required Type : S60 - 48-port E/FE/GE (SC)
Current Type : S60 - 48-port E/FE/GE (SC)
Master priority : 0
Hardware Rev : 2.0
Num Ports : 52
Up Time : 2 hr, 16 min
FTOS Version
                     : 1-2-0-205
Jumbo Capable : yes
Jumbo Capable : yes
POE Capable : no
Boot Flash : 1.0.0.2
Memory Size : 2147483648 bytes
Temperature : 50C
Voltage : ok
Serial Number : 7520044101 Rev 02
Vendor Id : 11
Date Code : 01192010
Country Code : 01
Last Restart Auto Reboot : disabled
Burned In MAC : 00:01:e8:81:e1:b9
Burned In MAC : 00:01:e8:81:e1:b9
No Of MACs
                      : 3
 -- Module 0 --
Status
                   : not present
 -- Module 1 --
Status
                    : not present
 -- Power Supplies --
Unit Bay Status
 _____
  0 0 up
0 1 up
                                     AC
 -- Fan Status --
Unit Bay TrayStatus Fan0 Speed Fan1 Speed Fan2
                           up 7200 up 7200
                                           7200
                                                                 7200
                                                                                       7200
        1
                up
                                up
                                                      up
                                                                            up
Speed in RPM
 FTOS#
```

Related Commands

show version	Display the FTOS version.
show processes memory (S-Series)	Display memory usage based on running processes.
show system stack-ports	Display information about the stack ports on all switches in the S-Series stack.
show hardware stack-unit	Display the data plane and management plane input and output statistics of a particular stack member.
stack-unit priority	Configure the ability of an S-Series switch to become the management unit of a stack.

show tech-support (C-Series and E-Series)

CE Display, or save to a file, a collection of data from other show commands, the information necessary

for Dell Networking technical support to perform troubleshooting.

Syntax

show tech-support [linecard 0-6 | page] | {display | except | find | grep | no-more | save}

Parameters

linecard 0-6	(OPTIONAL) Enter the keyword linecard followed by the linecard number to view information relating to a specific linecard.		
page	(OPTIONAL) Enter the keyword page to view 24 lines of text at a time. Press the SPACE BAR to view the next 24 lines. Press the ENTER key to view the next line of text.		
display, except, find, grep, no-more	If you use the pipe command (), then enter one of these keywords to filter command output. Refer to Chapter 2, CLI Basics for details on filtering commands.		
save	Enter the save keyword (following the pipe) to save the command output.		
	flash:	Save to local flash drive (flash://filename (max 20 chars))	
	slot0: Save to local file system (slot0://filename (max 20 chars))		

Command Modes

EXEC Privilege

Command History

Version 7.8.1.0	Introduced save to file options
Version 7.5.1.0	Introduced on C-Series
Version 6.5.4.0	Show clock included in display on E-Series

C-Series Example

Figure 4-58. Command Example: show tech-support (partial) on C-Series

```
FTOS#show tech-support page
      ----- show version ------
Dell Force10 Networks Real Time Operating System Software
Dell Force10 Operating System Version: 1.0
Dell Force10 Application Software Version: FTOS 7.5.1.0
Copyright (c) 1999-2007 by Dell, Inc.
Build Time: Tue Sep 12 15:39:17 IST 2006
Build Path: /sites/maa/work/sw//C-SERIES/SW/SRC
FTOS uptime is 18 minutes
System image file is "/work/sw/IMAGES/Chassis/C300-ODC-2/FTOS-CS.bin"
Chassis Type: C300
Control Processor: IBM PowerPC 750FX (Rev D2.2) with 1073741824 bytes of memory.
128K bytes of non-volatile configuration memory.
  1 Route Processor/Switch Fabric Module
  2 48-port GE 10/100/1000Base-T line card with RJ45 interface (CB)
  1 FastEthernet/IEEE 802.3 interface(s)
 96 GigabitEthernet/IEEE 802.3 interface(s)
                 ----- show HA information -----
-- RPM Status --
 RPM Slot ID:
                        0
Primary
 RPM Redundancy Role:
                          Active
CS-1-1-317
 RPM State:
 RPM SW Version:
 Link to Peer:
                             Down
 Peer RPM:
                             not present
-- RPM Redundancy Configuration --
 Primary RPM:
                   rpm0
                            Full
Hot Failover
Disabled
3 times in 60 minutes
 Auto Data Sync:
 Auto reboot RPM:
Auto fail
 Auto failover limit:
 ..more----
```

E-Series Example

Figure 4-59. Command Example: show tech-support save (partial) on E-Series

```
FTOS#show tech-support ?
linecard
                          Line card
                         Page through output
page
                         Pipe through a command
FTOS#show tech-support linecard 3 |
                         Display additional information
display
                         Show only text that does not match a pattern
except
find
                         Search for the first occurrence of a pattern
                         Show only text that matches a pattern
grep
                         Don't paginate output
no-more
save
                         Save output to a file
FTOS#show tech-support linecard 3 | save ?
flash: Save to local file system (flash://filename (max 20 chars) slot0: Save to local file system (slot0://filename (max 20 chars)
FTOS#show tech-support linecard 3 | save flash://LauraSave
Start saving show command report ......
FTOS#dir
Directory of flash:
    drwx
                32768
                        Jan 01 1980 00:00:00 +00:00
     drwx
                 512 Aug 22 2008 14:21:13 +00:00
  3
     drwx
                 8192
                        Mar 30 1919 10:31:04 +00:00 TRACE_LOG_DIR
     drwx
                 8192
                        Mar 30 1919 10:31:04 +00:00 CRASH_LOG_DIR
     drwx
  5
                 8192
                        Mar 30 1919 10:31:04 +00:00 NVTRACE_LOG_DIR
                 8192
                        Mar 30 1919 10:31:04 +00:00 CORE_DUMP_DIR
     drwx
     d---
                 8192
                        Mar 30 1919 10:31:04 +00:00 ADMIN DIR
           33059550
  8
     -rwx
                       Jul 11 2007 17:49:46 +00:00 FTOS-\overline{E}F-7.4.2.0.bin
  9
                 8192
                        Jan 01 1980 00:18:28 +00:00 diag
    drwx
 10
            29555751
                        May 12 2008 17:29:42 +00:00 FTOS-EF-4.7.6.0.bin
            27959813
                        Apr 04 2008 15:05:12 +00:00 FTOS-EF-7.5.1.0.bin
     -rwx
 12
                      May 12 2008 17:24:36 +00:00 config051508
     -rwx
            29922288
     -rwx
                        Jan 11 2008 14:58:36 +00:00 FTOS-EF-7.6.1.0.bin
     -rwx
                        Aug 22 2008 14:18:56 +00:00 startup-config
                 6497
 15
     -rwx
                 5832
                        Jul 25 2008 11:13:36 +00:00 startup-config.bak
            29947358
                        Jul 25 2008 11:04:26 +00:00 FTOS-EF-7.6.1.2.bin
 16
     -rwx
              10375
                       Aug 25 2008 10:55:18 +00:00 LauraSave
     -rwx
flash: 520962048 bytes total (40189952 bytes free)
FTOS#
```

Usage Information

Without the linecard or page option, the command output is continuous, use CNTL-z to interrupt the command output.

The **save** option works with other filtering commands. This allows you to save specific information of a show command. The **save** entry should always be the last option.

For example: FTOS#show tech-support |grep regular-expression |except regular-expression | find regular-expression | save flash://result

This display output is an accumulation of the same information that is displayed when you execute one of the following **show** commands:

- show cam-profile
- show cam-ipv4flow
- show chassis
- show clock
- show environment
- show file-system
- show interface
- show inventory

- show ip management-route
- · show ip protocols
- show ip route summary
- show processes cpu
- show processes memory
- show redundancy
- show rpm
- show running-conf
- show sfm
- show version

Related Commands

show version	Display the FTOS version.
show linecard	Display the line card(s) status.
show environment (C-Series and E-Series)	Display system component status.
show processes memory (C-Series and E-Series)	Display memory usage based on running processes.

show tech-support (S-Series)

Display a collection of data from other **show** commands, necessary for Dell Networking technical support to perform troubleshooting on S-Series switches.

Syntax show tech-support [stack-unit unit-id | page]

Parameters

stack-unit	(OPTIONAL) Enter the keyword stack-unit to view CPU memory usage for the stack member designated by <i>unit-id</i> .		
	Unit ID range:		
	S60 : 0-11		
	all other S-Series: 0-7		
page	(OPTIONAL) Enter the keyword page to view 24 lines of text at a time.		
	Press the SPACE BAR to view the next 24 lines.		
	Press the ENTER key to view the next line of text.		
	When using the pipe command (), enter one of these keywords to filter command output. Refer to Chapter 2, CLI Basics for details on filtering commands.		
save	Enter the save keyword to save the command output.		
	flash: Save to local flash drive (flash://filename (max 20 chars))		

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced save to file options
Version 7.6.1.0	Expanded to support S-Series switches

S-Series **Examples**

Figure 4-60. Command Example: show tech-support save (partial) on S-Series

```
FTOS#show tech-support ?
page
                           Page through output
stack-unit
                          Unit Number
                          Pipe through a command
cr>
FTOS#show tech-support stack-unit 1 ?
                          Pipe through a command
FTOS#show tech-support stack-unit 1 | ?
                          Show only text that does not match a pattern
except
                          Search for the first occurrence of a pattern
grep
                          Show only text that matches a pattern
                          Don't paginate output
no-more
save
                          Save output to a file
FTOS#show tech-support stack-unit 1 | save ?
                        Save to local file system (flash://filename (max 20 chars) )
FTOS#show tech-support stack-unit 1 | save flash://LauraSave
Start saving show command report .....
FTOS#
FTOS#dir
Directory of flash:
                         Jan 01 1980 00:00:00 +00:00
Jul 13 1996 02:38:06 +00:00
    drw-
                16384
                1536
  2 drwx
  3 d---
                  512
                        Nov 20 2007 15:46:44 +00:00 ADMIN_DIR
                 7124
                         Jul 13 1996 02:33:04 +00:00 startup-config
     - rw-
                         Feb 14 2008 22:01:16 +00:00 startup-config.oldChassis May 17 1996 04:10:54 +00:00 startup-config.bak
  5
     - ww-
                 3303
  6
     - rw-
                 6561
                        May 29 1996 10:35:42 +00:00 test.cfg
Jul 15 1996 23:11:14 +00:00 LauraSave
               6539
  7 -rw-
     -rw-
  8
                  276
flash: 3104256 bytes total (3072512 bytes free)
FTOS#
```

Figure 4-61. Command Example: show tech-support (partial) on S-Series

```
FTOS#show tech-support stack-unit 0
                                 -- show version
Dell Force10 Networks Real Time Operating System Software
Dell Force10 Operating System Version: 1.0
Dell Force10 Application Software Version: FTOS 7.6.1.0
Copyright (c) 1999-2007 by Dell, Inc
Build Time: Tue Sep 12 15:39:17 IST 2006
Build Path: /sites/maa/work/sw/purushothaman/cser-latest/depot/main/Dev/Cyclone/
FTOS uptime is 18 minutes
System Type: S50N
Control Processor: MPC8451E with 255545344 bytes of memory.
32M bytes of Boot-Flash memory.
  1 48-port E/FE/GE (SB)
48 GigabitEthernet/IEEE 802.3 interface(s)
 4 Ten GigabitEthernet/IEEE 802.3 interface(s)
                                  -- show clock
12:03:01.695 UTC Wed Nov 21 2007
                  ----- show running-config ------
Current Configuration ..
! Version E_MAIN4.7.5.414
! Last confiquration change at Wed Nov 21 11:42:19 2007 by default
service timestamps log datetime
hostname FTOS
enable password 7 xxxxxxxx
username admin password 7 xxxxxxxx
enable restricted 7 xxxxxxxx
interface GigabitEthernet 0/1
no ip address
 shutdown
interface GigabitEthernet 0/2
no ip address
 shutdown
           --- output truncated -----!
```

Usage Information

Without the **page or stack-unit** option, the command output is continuous, use **Ctrl-z** to interrupt the command output.

The **save** option works with other filtering commands. This allows you to save specific information of a show command. The **save** entry should always be the last option.

For example: FTOS# $show\ tech-support\ |$ grep $regular-expression\ |$ except $regular-expression\ |$ find $regular-expression\ |$ save flash://result

This display output is an accumulation of the same information that is displayed when you execute one of the following **show** commands:

- show cam
- show clock
- · show environment
- show file
- show interfaces
- show inventory
- show ip protocols
- show ip route summary
- show processes cpu
- show processes memory
- show redundancy
- show running-conf
- show version

Related Commands

show version	Display the FTOS version.		
show system (S-Series)	Display the current switch status.		
show environment (S-Series)	Display system component status.		
show processes memory (S-Series)	Display memory usage based on running processes.		

ssh-peer-rpm

Open an SSH connection to the peer RPM.

Syntax ssh-peer-rpm [-I *username*]

Parameters

-I username	(OPTIONAL) Enter the keyword -I followed by your user name.	
	Default: The user name associated with the terminal	

Defaults Not configured.

Command Modes EXEC

ALC

EXEC Privilege

Command History

Version 8.1.	1.0 Introd	Introduced on E-Series ExaScale	
Version 7.5.	1.0 Introd	luced on C-Series	
Version 6.3.	1.0 Introd	luced on E-Series	

Usage Information

This command is not available when the peer RPMs are running different FTOS releases.

ssh-peer-stack-unit

[S60]

Open an SSH connection to the peer RPM.

Syntax

ssh-peer-stack-unit [-I username]

Parameters

-I username (OPTIONAL) Enter the keyword -I followed by your user name. Default: The user name associated with the terminal

Defaults

Not configured.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.4 Introduced on S60

telnet

CES

Connect through Telnet to a server.

Syntax

telnet { host | ip-address | ipv6-address prefix-length | vrf vrf instance name } [/source-interface]

Parameters

host	Enter the name of a server.	
ip-address	Enter the IPv4 address in dotted decimal format of the server.	
ipv6-address prefix-length	Enter the IPv6 address in the X:X:X: X format followed by the prefix length in the /X format.	
	Range: /0 to /128	
	Note: The :: notation specifies successive hexadecimal fields of zeros	

vrf instance	(Optional) E-Series Only: Enter the keyword vrf followed by the VRF Instance
	name.
source-interface	(OPTIONAL) Enter the keywords /source-interface followed by the interface information to include the interface's IP address.
	Enter the following keywords and slot/port or number information:
	 For a 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Loopback interface, enter the keyword loopback followed by a number from zero (0) to 16383.
	• For the Null interface, enter the keyword null followed by 0.
	• For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale
	 For SONET interface types, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN interface, enter the keyword vlan followed by a number from 1 to 4094.

Defaults

Not configured.

Command Modes

EXEC

EXEC Privilege

Command History

-	
Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale (IPv6)
	Increased number of VLANs on ExaScale to 4094 (was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale (IPv4)
Version 7.9.1.0	Introduced VRF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and added support for IPv6 address on E-Series only

telnet-peer-rpm

Öpen a Telnet connection to the peer RPM.

Syntax telnet-peer-rpm

Defaults Not configured.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

Opening a telnet connection from the Standby RPM to an Active RPM follows the authentication procedure configured in the chassis. However, opening a telnet connection from the Active RPM into the Standby RPM requires local authentication.

Configuring an ACL on a VTY line will block a Telnet session using the telnet-peer-rpm command in the standby to active RPM direction only. Such an ACL will not block an internal Telnet session in the active RPM to standby RPM direction.

telnet-peer-stack-unit

Open a Telnet connection to the peer stack unit. [S60]

Syntax telnet-peer-stack-unit

Defaults Not configured.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.4 Introduced on S60

terminal length

CES Configure the number of lines displayed on the terminal screen.

Syntax terminal length screen-length

To return to the default values, enter **terminal no length**.

Parameters

screen-length	Enter a number of lines. Entering zero will cause the terminal to display without pausing.
	Range: 0 to 512.
	Default: 24 lines.

Defaults 24 lines

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series	
E-Series original Command		

terminal xml

© E Enable XML mode in Telnet and SSH client sessions.

Syntax terminal xml

To exit the XML mode, enter **terminal no xml**.

Defaults Disabled

Command Modes EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on C-Series
Version 6.5.1.0	Introduced for E-Series

Usage Information

This command enables the XML input mode where you can either cut and paste XML requests or enter the XML requests line-by-line. For more information on using the XML feature, refer to the XML chapter in the FTOS Configuration Guide.

traceroute

CES

View a packet's path to a specific device.

Syntax

traceroute { host | vrf instance | ip-address | ipv6-address}

Parameters

host	Enter the name of device.	
vrf instance	(Optional) E-Series Onl y: Enter the keyword vrf followed by the VRF Instance name.	
ip-address	Enter the IP address of the device in dotted decimal format.	
ipv6-address	Enter the IPv6 address, in the x:x:x: format, to which you are testing connectivity.	
	Note: The :: notation specifies successive hexadecimal fields of zeros	

Defaults

Timeout = 5 seconds; Probe count = 3; 30 hops max; 40 byte packet size; UDP port = 33434

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale with IPv6
Version 8.1.1.0	Introduced on E-Series ExaScale (IPv4 only)
Version 7.9.1.0	Introduced VRF.

Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Added support for IPv6 address on E-Series
E-Series original Command	

Usage Information

When you enter the **traceroute** command without specifying an IP address (Extended Traceroute), you are prompted for a target and source IP address, timeout in seconds (default is 5), a probe count (default is 3), minimum TTL (default is 1), maximum TTL (default is 30), and port number (default is 33434). To keep the default setting for those parameters, press the ENTER key.

For IPv6, you are prompted for a minimum hop count (default is 1) and a maximum hop count (default is 64).

Example Figure 4-62. Command Example: traceroute (IPv4)

```
FTOS#traceroute www.force10networks.com
Translating "www.force10networks.com"...domain server (10.11.0.1) [OK]
Type Ctrl-C to abort.
Tracing the route to www.forcelOnetworks.com (10.11.84.18), 30 hops max, 40 byte packets
                     Probe1 Probe2 Probe3 001.000 ms 001.000 ms 002.000 ms
TTL Hostname
  1 10.11.199.190
  2 gwegress-sjc-02.forcelOnetworks.com (10.11.30.126) 005.000 ms 001.000 ms 001.000 ms
   fw-sjc-01.forcelOnetworks.com (10.11.127.254) 000.000 ms 000.000 ms 000.000 ms
    www.forcelOnetworks.com (10.11.84.18) 000.000 ms 000.000 ms 000.000 ms
FTOS#
```

Figure 4-63 contains examples of the IPv6 traceroute command with both a compressed IPv6 address and uncompressed address.

Example Figure 4-63. Command Example: traceroute (IPv6)

```
FTOS#traceroute 100::1
Type Ctrl-C to abort.
______
Tracing the route to 100::1, 64 hops max, 60 byte packets
                   Probe1 Probe2 Probe3
Hops Hostname
                   000.000 ms 000.000 ms 000.000 ms
 1 100::1
FTOS#traceroute 3ffe:501:ffff:100:201:e8ff:fe00:4c8b
Type Ctrl-C to abort.
Tracing the route to 3ffe:501:ffff:100:201:e8ff:fe00:4c8b, 64 hops max, 60 byte packets
 ops Hostname Probe1 Probe2 Probe3
Hops Hostname
 1 3ffe:501:ffff:100:201:e8ff:fe00:4c8b
                    000.000 ms 000.000 ms 000.000 ms
FTOS#
```

Related Commands

ping	Test connectivity to a device.	
1 0	·	

undebug all

C E S Disable all debug operations on the system.

Syntax undebug all

Defaults No default behavior or values

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

upload trace-log

Upload trace log files from the three CPUs (cp, rp1, and rp2)

Syntax upload trace-log {cp {cmd-history | hw-trace | sw-trace}| rp1 {cmd-history | hw-trace | sw-trace}| rp2 {cmd-history | hw-trace | sw-trace}}

Parameters

cp rp1 rp2	Enter the keyword cp rp1 rp2 to upload the trace log from that CPU.
cmd-history	(OPTIONAL) Enter the keyword cmd-history to upload the CPU's command history.
hw-trace	(OPTIONAL) Enter the keyword hw-trace to upload the CPU's hardware trace.
sw-trace	(OPTIONAL) Enter the keyword sw-trace to upload the CPU's software trace.

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series and expanded to support command history, hardware trace, and software trace logs
Version 6.1.1.0	Introduced on E-Series

Usage Information The log information is uploaded to flash:/TRACE_LOG_DIR

util-threshold cpu (C- and E-Series)

Configure the high or low CPU utilization thresholds for SNMP traps. [C][E]

Syntax util-threshold cpu {5sec | 1min | 5min } {rp1 | rp2 | cp | lp slot-id | all } {high {0-100}} | {low [0-100}}

To return to the default settings, use the **no util-threshold cpu** command syntax.

Parameters

Indicate the length of time in which the cpu has been busy. сри

utilization

5sec 1min

time

5min

processor type

Indicate the type of processor to be used to configure the CPU utilization information.

rp1 = route processor1

rp2 = route processor2

cp = control processor

lp **slot-id** = the line card slot-id

all = use all of the processors to configure the CPU utilization information.

utilization threshold in % Indicate the high or low values for the CPU utilization thresholds in percentage format.

• high. Range: 0 - 100 • low. Range: 0 - 100

Note: A threshold level of 0 will disable the syslog and SNMP trap.

Example util-threshold cpu 5sec cp high 50

In this example, the low threshold value is not specified so it will take the value set for the high threshold value. In all other instances, the low threshold value must be equal to or less than that of the high threshold value.

Defaults

High CPU utilization threshold: 1min = 85%, 5min = 80% Low CPU utilization threshold: 1min = 75%, 5min = 70%

Command Modes

CONFIG

Command **History**

Version 8.4.2.3	Introduced on C-Series, S25 and S50
Version 8.4.2.0	Introduced on E-Series TeraScale
Version 8.4.1.0	Introduced on E-Series ExaScale

Usage Information

When the total CPU utilization exceeds the configured threshold for a given time, a threshold notification is sent as a SNMP trap. If a low threshold value is not specified, the low threshold value is set to the same value as the high threshold value. The system will generate a SYSLOG and SNMP Trap each time the configured threshold is crossed.

Note: The 5sec util-threshold cpu command is disabled by default on all platforms. To enable the command, enter util-threshold cpu 5sec all high {value greater than zero}. To disable the SYSLOG and traps for the 5sec cpu utilization thresholds, enter util-threshold cpu 5sec all high 0 or no util-threshold cpu 5sec {rp1 | rp2 | cp | lp slot-id | all }

util-threshold cpu (S-Series)

S (S55)

Configure the high or low CPU utilization thresholds for SNMP traps.

(S60)

Syntax

util-threshold cpu {5sec | 1min | 5min} {Management-unit | standby | stack-unit unit-number | all} {high {0-100}| {low [0-100}}}

To return to the default setting, enter **no util-threshold cpu**.

Parameters

cpu utilization time

Enter the keyword that indicates the amount of threshold time to configure the CPU utilization thresholds.

- 5sec
- 1min
- 5min

unit

Indicate the unit where you want to configure the CPU utilization thresholds.

- Management-unit
- standby
- stack-unit *unit-number* = select the number of the unit in the stack
- all = use all of the units to configure the cpu utilization information.

utilization threshold in % Indicate the high or low values for the CPU utilization threshold in percentage format.

high. Range: 0 - 100 low. Range: 0 - 100

Note: A threshold level of 0 will disable the syslog and SNMP trap.

Defaults

High threshold cpu default = 92%Low threshold cpu default = 82%

Command Modes

CONFIG

Command **History**

Version 8.3.3.8	Introduced on S60.
Version 8.3.5.3	Introduced on S55.
Version 8.4.2.2	Introduced on C-Series, S25 and S50.
Version 8.4.2.0	Introduced on E-Series TeraScale.
Version 8.4.1.0	Introduced on E-Series ExaScale.

Usage Information

When the total CPU utilization exceeds the configured threshold for a given time, a threshold notification is sent as a SNMP trap. If a low threshold value is not specified, the low threshold value is set to the same value as the high threshold value. The system will generate a SYSLOG and SNMP Trap each time the configured threshold is crossed.

util-threshold mem (C- and E-Series)

[C][E]Configure the high or low memory utilization thresholds for SNMP traps.

util-threshold mem {rp1 | rp2 | cp | lp slot-id | all} {high {0-100} | {low [0-100}} **Syntax**

To return to the default setting, use the **no util-threshold mem** command syntax.

Parameters

Indicate the type of processor that will be used to configure the memory processor type

utilization information.

rp1 = route processor1

rp2 = route processor2

cp = control processor

lp **slot-id** = the line card slot-id

all = use all of the processors to configure the memory utilization information.

utilization threshold in %

Indicate the high or low values for the memory utilization threshold in

percentage format.

high. Range: 0 - 100

low. Range: 0 - 100

Note: A threshold level of 0 will disable the syslog and SNMP trap.

Defaults High threshold default = 92%

Low threshold default = 82%

Command Modes CONFIG

Command History

Version 8.4.2.2	Introduced on C-Series, S25 and S50
Version 8.4.2.0	Introduced on E-Series TeraScale
Version 8.4.1.0	Introduced on E-Series ExaScale

Usage Information

When the total memory utilization exceeds the configured threshold for a given time, a threshold notification is sent as a SNMP trap. If a low threshold value is not specified, the low threshold value is set to the same value as the high threshold value.

To return the memory thresholds to the default values, enter no util-threshold mem rp1 | rp2 | cp | lp number | all

util-threshold mem (S-Series)

S (S55)

Configure the high or low memory utilization thresholds for SNMP traps.

(S60)

Syntax

util-threshold mem {Management-unit | standby | stack-unit unit-number | all} {high {0-100} | {low [0-100}}}

To return to the default setting, enter the **no util-threshold mem** command syntax.

Parameters

unit Indicate the unit where you want to configure the memory utilization thresholds.

- · Management-unit
- standby
- stack-unit *unit-number* = select the number of the unit in the stack
- all = use all of the units to configure the memory utilization information.

utilization threshold in % Indicate the high or low values for the memory utilization in percentage format.

high. Range: 0 - 100low. Range: 0 - 100

Note: A threshold level of 0 will disable the syslog and SNMP trap.

Defaults High threshold default = 92%

Low threshold default = 82%

Command Modes CONFIG

Command History

Version 8.3.3.8	Introduced on S60.
Version 8.3.5.3	Introduced on S55.
Version 8.4.2.2	Introduced on C-Series, S25 and S50
Version 8.4.2.0	Introduced on E-Series TeraScale
Version 8.4.1.0	Introduced on E-Series ExaScale

Usage Information

When the total memory utilization exceeds the configured threshold for a given time, a threshold notification is sent as a SNMP trap. If a low threshold value is not specified, the low threshold value is set to the same value as the high threshold value.

virtual-ip

Configure a virtual IP for the active management interface.

Syntax

virtual-ip ip address

To return to the default, use the **no virtual-ip** *ip address* command.

Parameters

ip address	Enter the IP address of the active management interface in a dotted decimal format
	(A.B.C.D.)

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command **History**

	Version 8.1.1.0
	Version 7.5.1.0
	E-Series original C
E-Series original Command	

Related Commands

ip address	Assign a primary and secondary IP address to the interface.	

write



Copy the current configuration to either the startup-configuration file or the terminal.

Syntax

write {memory | terminal}

Parameters

memory	Enter the keyword memory to copy the current running configuration to the startup configuration file. This command is similar to the copy running-config startup-config command.
terminal	Enter the keyword terminal to copy the current running configuration to the terminal. This command is similar to the show running-config command.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series original Command	

Related **Commands**

save	Save configurations created in uBoot.	

Usage Information

The **write memory** command saves the running-configuration to the file labeled startup-configuration. When using a LOCAL CONFIG FILE other than the startup-config not named "startup-configuration" (for example, you used a specific file during the boot config command) the running-config is not saved to that file; use the **copy** command to save any running-configuration changes to that local file.

802.1ag

Overview

802.1ag is available only on platform: S

Commands

This chapter contains the following commands:

- ccm disable
- ccm transmit-interval
- clear ethernet cfm traceroute-cache
- database hold-time
- disable
- domain
- ethernet cfm
- ethernet cfm mep
- ethernet cfm mip
- mep cross-check
- mep cross-check enable
- mep cross-check start-delay
- ping ethernet
- show ethernet cfm domain
- show ethernet cfm maintenance-points local
- show ethernet cfm maintenance-points remote
- show ethernet cfm mipdb
- show ethernet cfm statistics
- show ethernet cfm port-statistics
- show ethernet cfm traceroute-cache
- service
- traceroute cache hold-time
- traceroute cache size
- traceroute ethernet

ccm disable

S Disable CCM.

Syntax ccm disable

Enter **no ccm disable** to enable CCM.

Defaults Disabled

Command Modes ECFM DOMAIN

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced on S-Series	

ccm transmit-interval

Configure the transmit interval (mandatory). The interval specified applies to all MEPs in the domain.

Syntax ccm transmit-interval seconds

Parameters

seconds Enter a transmit interval.
Range: 1,10,60,600

Defaults 10 seconds

> Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

clear ethernet cfm traceroute-cache

S Delete all Link Trace Cache entries.

Syntax clear ethernet cfm traceroute-cache

Defaults None

Command Modes EXEC Privilege

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

database hold-time

Set the amount of time that data from a missing MEP is kept in the Continuity Check Database.

Syntax database hold-time minutes

Parameters Enter a hold-time. minutes

Range: 100-65535 minutes

Defaults 100 minutes

Command Modes ECFM DOMAIN

> Command **History**

Version 8.3.3.1 Introduced on the S60. Version 8.3.1.0 Introduced on S-Series

disable

Disable Ethernet CFM without stopping the CFM process. S

Syntax disable

Defaults Disabled

Command Modes ETHERNET CFM

> Command History

Version 8.3.3.1 Introduced on the S60. Version 8.3.1.0 Introduced on S-Series

domain

(S) Create maintenance domain.

Syntax domain name md-level number

Parameters

name	Name the maintenance domain.
md-level number	Enter a maintenance domain level.
	Range: 0-7

Defaults None

Command Modes ETHERNET CFM

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

ethernet cfm

Spawn the CFM process. No CFM configuration is allowed until the CFM process is spawned.

Syntax ethernet cfm

Defaults Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

ethernet cfm mep

S Create an MEP.

Syntax ethernet cfm mep {up-mep | down-mep} domain {name | level} ma-name name mepid mep-id

Parameters

[up-mep down-mep]	Specify whether the MEP is up or down facing.
	Up-MEP : monitors the forwarding path internal to an bridge on the customer or provider edge; on Dell Networking systems the internal forwarding path is effectively the switch fabric and forwarding engine.
	Down-MEP : monitors the forwarding path external another bridge.
domain [name level]	Enter this keyword followed by the domain name or domain level.
ma-name name	Enter this keyword followed by the name of the maintenance association.
mepid mep-id	Enter an MEP ID.
	Range: 1-8191

Defaults None

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

ethernet cfm mip

S Create an MIP.

Syntax ethernet cfm mip domain {name | level} ma-name name

Parameters

domain [name level]	Enter this keyword followed by the domain name or domain level.
ma-name name	Enter this keyword followed by the name of the maintenance association.

Defaults None

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced on S-Series	

mep cross-check

Enable cross-checking for an MEP.

Syntax mep cross-check mep-id

Parameters

Enter the MEP ID mep-id Range: 1-8191

Defaults None

Command Modes ECFM DOMAIN

> Command **History**

Version 8.3.3.1 Introduced on the S60. Version 8.3.1.0 Introduced on S-Series

mep cross-check enable

(S) Enable cross-checking.

Syntax mep cross-check enable {port | vlan-id}

Parameters

port	Down service with no VLAN association.
vlan-id	Enter the VLAN to apply the cross-check.

Defaults None

Command Modes ECFM DOMAIN

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

mep cross-check start-delay

Configure the amount of time the system waits for a remote MEP to come up before the cross-check operation is started.

Syntax mep cross-check start-delay number

Parameters

start-delay number	Enter a start-delay in seconds.
	Range: 3-100 seconds

Defaults 3 ccms

Command Modes ETHE

ETHERNET CFM

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

ping ethernet

(S)

Send a Loopback message.

Syntax

ping ethernet domain [name | level] ma-name ma-name remote {dest-mep-id | mac-addr mac-address} source {src-mep-id | port interface}

Parameters

name level	Enter the domain name or level.
ma-name ma-name	Enter the keyword followed by the maintenance association name.
dest-mep-id	Enter the MEP ID that will be the target of the ping.
mac-addr mac-address	Enter the keyword followed by the MAC address that will be the target of the ping.
src-mep-id	Enter the MEP ID that will originate the ping.
port interface	Enter the keyword followed by the interface that will originate the ping.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

show ethernet cfm domain

S Display maintenance domain information.

Syntax

show ethernet cfm domain [name | level | brief]

Parameters

name level	Enter the maintenance domain name or level.
brief	Enter this keyword to display a summary output.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

Example FTOS# show ethernet cfm domain

Domain Name: customer

Level: 7

Total Service: 1

Services

X-CHK Status CC-Int MA-Name VLAN

 My_MA 200 10s enabled

Domain Name: My_Domain

Level: 6

Total Service: 1

Services

VLAN CC-Int X-CHK Status MA-Name

Your_MA 100 10s enabled

show ethernet cfm maintenance-points local

Display configured MEPs and MIPs. (S)

Syntax show ethernet cfm maintenance-points local [mep | mip]

Parameters

mep	Enter this keyword to display configured MEPs.
mip	Enter this keyword to display configured MIPs.

Defaults None

Command Modes EXEC Privilege

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

Example

FTOS#show ethernet cfm maintenance-points local mip

MPID	Domain Name MA Name	Level VLAN	Type Dir	Port MAC	CCM-Status
0	service1 My_MA	4 3333	MIP DOWN	Gi 0/5 00:01:e8:0b:c6:36	Disabled
0	servicel Your MA	4 3333	MIP UP	Gi 0/5 00:01:e8:0b:c6:36	Disabled

show ethernet cfm maintenance-points remote

Display the MEP Database.

Syntax show ethernet cfm maintenance-points remote detail [active | domain { level | name} | expired | waiting]

Parameters

active	Enter this keyword to display only the MEPs in active state.
domain [name level]	Enter this keyword followed by the domain name or domain level.

expired	Enter this keyword to view MEP entries that have expired due to connectivity failure.
waiting	Enter this keyword to display MEP entries waiting for response.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

Example

FTOS#show ethernet cfm maintenance-points remote detail

MAC Address: 00:01:e8:58:68:78

Domain Name: cfm0 MA Name: test0 Level: 7 VLAN: 10 MP ID: 900

Sender Chassis ID: FTOS MEP Interface status: Up MEP Port status: Forwarding

Receive RDI: FALSE MP Status: Active

show ethernet cfm mipdb

S Display the MIP Database.

Syntax show ethernet cfm mipdb

Defaults None

Command Modes EXEC Privilege

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

show ethernet cfm statistics

S Display MEP statistics.

Syntax show ethernet cfm statistics [domain {name | level} vlan-id vlan-id mpid mpid]

Parameters

domain	Enter this keyword to display statistics for a particular domain.		
name level	Enter the domain name or level.		
vlan-id vlan-id	Enter this keyword followed by a VLAN ID.		
mpid mpid	Enter this keyword followed by a maintenance point ID.		

Defaults

None

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced on S-Series	•

Example

```
FTOS# show ethernet cfm statistics
```

Domain Name: Customer Domain Level: 7 MA Name: My_MA MPID: 300

> CCMs: Transmitted: 1503 RcvdSeqErrors: LTRs: Unexpected Rcvd: LBRs: Received: 0 Rcvd Out Of Order: Received Bad MSDU: Transmitted:

show ethernet cfm port-statistics

Display CFM statistics by port. (S)

Syntax show ethernet cfm port-statistics [interface type slot/port]

Parameters

interface type	Enter this keyword followed by the interface type.
slot/port	Enter the slot and port numbers for the port.

Defaults None

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced on S-Series

Example

```
FTOS#show ethernet cfm port-statistics interface gigabitethernet 0/5
Port statistics for port: Gi 0/5
_____
```

RX Statistics Total CFM Pkts 75394 CCM Pkts 75394 LBM Pkts 0 LTM Pkts 0 LBR Pkts 0 LTR Pkts 0 Bad CFM Pkts 0 CFM Pkts Discarded 0 CFM Pkts forwarded 102417 TX Statistics Total CFM Pkts 10303 CCM Pkts 0 LBM Pkts 0 LTM Pkts 3 LBR Pkts 0 LTR Pkts 0

show ethernet cfm traceroute-cache

Display the Link Trace Cache.

0

Syntax show ethernet cfm traceroute-cache

Defaults None

Command Modes EXEC Privilege

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

Example FTOS#show ethernet cfm traceroute-cache

Traceroute to 00:01:e8:52:4a:f8 on Domain Customer2, Level 7, MA name Test2 with VLAN

2

Hops Host IngressMAC Ingr Action Relay Action Next Host Egress MAC Egress Action FWD Status

4 00:00:00:01:e8:53:4a:f8 00:01:e8:52:4a:f8 IngOK RlyHit 00:00:00:01:e8:52:4a:f8 Terminal MEP

service

S Create maintenance association.

Syntax service name vlan vlan-id

Parameters

name Enter a maintenance association name.

vlan vlan-id Enter this keyword followed by the VLAN ID.

Range: 1-4094

Defaults None

Command Modes ECFM DOMAIN

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced on S-Series

traceroute cache hold-time

Set the amount of time a trace result is cached.

Syntax traceroute cache hold-time minutes

Parameters minutes Enter a hold-time.

Range: 10-65535 minutes

Defaults 100 minutes

Command Modes ETHERNET CFM

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced on S-Series	

traceroute cache size

Set the size of the Link Trace Cache.

Syntax traceroute cache size entries

Parameters

entries Enter the number of entries the Link Trace Cache can hold. Range: 1 - 4095 entries

Defaults 100 entries

Command Modes ETHERNET CFM

> Command **History**

Version 8.3.3.1 Introduced on the S60. Version 8.3.1.0 Introduced on S-Series

traceroute ethernet

Send a Linktrace message to an MEP. (S)

Syntax traceroute ethernet domain [name | level] ma-name ma-name remote {mep-id | mac-addr

mac-address}

Parameters

domain name level	Enter the keyword followed by the domain name or level.
ma-name ma-name	Enter the keyword followed by the maintenance association name.
mepid mep-id	Enter the MEP ID that will be the trace target.
mac-addr mac-address	Enter the MAC address of the trace target.

Defaults None

Command Modes EXEC Privilege

> Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced on S-Series	

Access Control Lists (ACL)

Overview

Access Control Lists (ACLs) are supported on platforms [C] [E] [S]

FTOS supports the following types of Access Control List (ACL), IP prefix list, and route map:

- Commands Common to all ACL Types
- Common IP ACL Commands
- Standard IP ACL Commands
- **Extended IP ACL Commands**
- Common MAC Access List Commands
- Standard MAC ACL Commands
- Extended MAC ACL Commands
- **IP Prefix List Commands**
- **Route Map Commands**
- **AS-Path Commands**
- **IP Community List Commands**



Commands Common to all ACL Types

The following commands are available within each ACL mode and do not have mode-specific options. Some commands may use similar names, but require different options to support the different ACL types (for example, deny).

- description
- remark
- show config

description

CES Configure a short text string describing the ACL.

Syntax description text

To delete the ACL description, enter **no description**.

Parameters

text Enter a text string up to 80 characters long.

Defaults

Not enabled.

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

CONFIGURATION-EXTENDED-ACCESS-LIST

CONFIGURATION-MAC ACCESS LIST-STANDARD

CONFIGURATION-MAC ACCESS LIST-EXTENDED

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

remark

CES

Enter a description for an ACL entry.

Syntax

remark [remark-number] [description]

To delete the description, use the **no remark** [remark number] command. Note that it is not necessary to include the remark description that you are deleting.

Parameters

remark-number	Enter the remark number. Note that the same sequence number can be used for the remark and an ACL rule. Range: 0 to 4294967290
description	Enter a description of up to 80 characters.

Defaults

Not configured

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

CONFIGURATION-EXTENDED-ACCESS-LIST

CONFIGURATION-MAC ACCESS LIST-STANDARD

CONFIGURATION-MAC ACCESS LIST-EXTENDED

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.4.1.0	Introduced for E-Series

Usage Information

The **remark** command is available in each ACL mode. You can configure up to 4294967290 remarks in a given ACL.

The following example shows the use of the remark command twice within the CONFIGURATION-STANDARD-ACCESS-LIST mode. Here, the same sequence number was used for the remark and for an associated ACL rule. The remark will precede the rule in the running-config because it is assumed that the remark is for the rule with the same sequence number, or the group of rules that follow the remark.

Example

Figure 6-1. Command Example: remark

```
FTOS(config-std-nacl)#remark 10 Deny rest of the traffic FTOS(config-std-nacl)#remark 5 Permit traffic from XYZ Inc.
FTOS (config-std-nacl) #show config
ip access-list standard test
remark 5 Permit traffic from XYZ Inc.
seq 5 permit 1.1.1.0/24
remark 10 Deny rest of the traffic
seq 10 Deny any
FTOS (config-std-nacl)#
```

Related **Commands**

show config

Display the current ACL configuration.

show config

CES

Display the current ACL configuration.

Syntax

show config

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

CONFIGURATION-EXTENDED-ACCESS-LIST

CONFIGURATION-MAC ACCESS LIST-STANDARD

CONFIGURATION-MAC ACCESS LIST-EXTENDED

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Example

Figure 6-2. Command Example: show config

```
FTOS(config-ext-nacl)#show conf
ip access-list extended patches
FTOS (config-ext-nacl)#
```

Common IP ACL Commands

The following commands are available within both IP ACL modes (Standard and Extended) and do not have mode-specific options. When an access-list (ACL) is created without any rule and then applied to an interface, ACL behavior reflects an implicit permit.

C and S (non-S60) platforms support Ingress IP ACLs only.

The [\$60] supports both Ingress and Egress IP ACLs.

The following commands allow you to clear, display, and assign IP ACL configurations.

- access-class
- clear counters ip access-group
- ip access-group
- ip control-plane egress-filter
- show ip accounting access-list



Note: See also Commands Common to all ACL Types.

access-class

CES

Apply a standard ACL to a terminal line.

Syntax

access-class access-list-name

To remove an ACL, use the **no access-class** access-list-name command.

Parameters

access-list-name	Enter the name of a configured Standard ACL, up to 140 characters.

Defaults

Not configured.

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced

clear counters ip access-group

CES

Erase all counters maintained for access lists.

Syntax

clear counters ip access-group [access-list-name]

Parameters

Command Modes

EXEC Privilege

access-list-name

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced

(OPTIONAL) Enter the name of a configured access-list, up to 140 characters.

ip access-group

CES

Assign an IP access list (IP ACL) to an interface.

Syntax

ip access-group access-list-name {in | out} [implicit-permit] [vlan vlan-id]

To delete an IP access-group configuration, use the **no ip access-group** access-list-name $\{in \mid out\}$ [implicit-permit] [vlan vlan-id] command.

Parameters

access-list-name	Enter the name of a configured access list, up to 140 characters.
in	Enter the keyword in to apply the ACL to incoming traffic.
out	Enter the keyword out to apply the ACL to outgoing traffic.
	Note: Available only on 12-port 1-Gigabit Ethernet FLEX line card. Refer to your line card documentation for specifications. Not available on S-Series.
implicit-permit	(OPTIONAL) Enter the keyword implicit-permit to change the default action of the ACL from implicit-deny to implicit-permit (that is, if the traffic does not match the filters in the ACL, the traffic is permitted instead of dropped).
vlan vlan-id	(OPTIONAL) Enter the keyword vian followed by the ID numbers of the VLANs.
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)

Defaults

Not enabled.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced

Usage Information

You can assign one ACL (standard or extended ACL) to an interface.



Note: This command is supported on the loopback interfaces of EE3, and EF series RPMs. It is *not* supported on loopback interfaces ED series RPM, or on C-Series or S-Series loopback interfaces.

When you apply an ACL that filters IGMP traffic, all IGMP traffic is redirected to the CPUs and soft-forwarded, if required, in the following scenarios:

- on a Layer 2 interface if a Layer 3 ACL is applied to the interface.
- on a Layer 3 port or on a Layer 2/Layer 3 port

Related Commands

ip access-list standard	Configure a standard ACL.
ip access-list extended	Configure an extended ACL.

ip control-plane egress-filter

(S60)

Enable egress Layer 3 ACL lookup for IPv4 CPU traffic

Syntax ip control-plane egress-filter

Defaults Not enabled.

Command Modes EX

EXEC Privilege

Command History

Version 8.3.3.4 Introduced on the S60.

show ip accounting access-list

CES

Display the IP access-lists created on the switch and the sequence of filters.

Syntax show ip accounting {access-list access-list-name | cam_count} interface interface

Parameters

access-list-name	Enter the name of the ACL to be displayed.
cam_count	List the count of the CAM rules for this ACL.
interface interface	Enter the keyword interface followed by the interface type and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced

Example

Figure 6-3. Command Example: show ip accounting access-lists

```
FTOS#show ip accounting access FILTER1 interface gig 1/6
Extended IP access list FILTER1
seq 5 deny ip any 191.1.0.0 /16 count (0x00 packets) seq 10 deny ip any 191.2.0.0 /16 order 4 seq 15 deny ip any 191.3.0.0 /16 seq 20 deny ip any 191.4.0.0 /16 seq 25 deny ip any 191.5.0.0 /16
```

Table 6-1 defines the information in Figure 6-3.

Table 6-1. show ip accounting access-lists Command Example Field

Field	Description
"Extended IP"	Displays the name of the IP ACL.
"seq 5"	Displays the filter. If the keywords count or byte were configured in the filter, the number of packets or bytes processed by the filter is displayed at the end of the line.
"order 4"	Displays the QoS order of priority for the ACL entry.

Standard IP ACL Commands

When an ACL is created without any rule and then applied to an interface, ACL behavior reflects an implicit permit.

C and S platforms (except the S60) support Ingress IP ACLs only.

The [\$60] supports both Ingress and Egress IP ACLs.

The commands needed to configure a Standard IP ACL are:

- ip access-list standard
- permit
- resequence access-list
- resequence prefix-list ipv4



Note: See also Commands Common to all ACL Types and Common IP ACL Commands.

deny

CES

Configure a filter to drop packets with a certain IP address.

Syntax

deny {source [mask] | any | host ip-address} [count [byte] | log] [dscp value] [order]
[monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** { source [mask] | **any | host** ip-address} command.

Parameters

source	Enter the IP address in dotted decimal format of the network from which the packet was sent.	
mask	(OPTIONAL) Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous (discontiguous).	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address only.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.	
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.	
order	(OPTIONAL) Enter the keyword order to specify the QoS order of priority for the ACL entry.	
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)	
	Default: If the order keyword is not used, the ACLs have the lowest order by default(255).	
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .	
fragments	Enter the keyword fragments to use ACLs to control packet fragments.	

Defaults

Not configured.

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.1.0	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the FTOS Configuration Guide for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The monitor option is relevant in the context of flow-based monitoring only. See the Chapter 28, Port Monitoring.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related **Commands**

ip access-list standard	Configure a standard ACL.
permit	Configure a permit filter.

ip access-list standard

CES

Create a standard IP access list (IP ACL) to filter based on IP address.

Syntax

ip access-list standard access-list-name

To delete an access list, use the **no ip access-list standard** access-list-name command.

Parameters

access-list-name	Enter a string up to 140 characters long as the ACL name.
------------------	---

Defaults

All IP access lists contain an implicit "deny any," that is, if no match occurs, the packet is dropped.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.1.0	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

FTOS supports one ingress and one egress IP ACL per interface.

Prior to 7.8.1.0, names are up to 16 characters long.

The number of entries allowed per ACL is hardware-dependent. Refer to your line card documentation for detailed specification on entries allowed per ACL.

Example

Figure 6-4. Command Example: ip access-list standard

FTOS(conf)#ip access-list standard TestList FTOS(config-std-nacl)#

Related Commands

ip access-list extended	Create an extended access list.
show config	Display the current configuration.

permit

CES

Configure a filter to permit packets from a specific source IP address to leave the switch.

Syntax

permit {source [mask] | any | host ip-address} [count [byte] | log] [dscp value] [order]
[monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit** { source [mask] | **any | host** ip-address} command.

Parameters

source	Enter the IP address in dotted decimal format of the network from which the packet was sent.	
mask	(OPTIONAL) Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address or hostname.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.	
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.	
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)	
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).	
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.	

Defaults

Not configured.

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the FTOS Configuration Guide for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The monitor option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related **Commands**

deny	Assign a IP ACL filter to deny IP packets.
ip access-list standard	Create a standard ACL.

resequence access-list

CES

Re-assign sequence numbers to entries of an existing access-list.

Syntax

resequence access-list {ipv4 | ipv6 | mac} {access-list-name StartingSeqNum *Step-to-Increment*}

Parameters

ipv4 ipv6 mac	Enter the keyword ipv4 , or mac to identify the access list type to resequence.	
access-list-name	Enter the name of a configured IP access list.	
StartingSeqNum	Enter the starting sequence number to resequence.	
	Range: 0 - 4294967290	
Step-to-Increment	Enter the step to increment the sequence number.	
	Range: 1 - 4294967290	

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Introduced on E-Series ExaScale (IPv6)	
Version 8.1.1.0	Introduced on E-Series ExaScale (IPv4)	
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
Version 7.4.1.0	Introduced	

Usage Information

When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing access-list.

Related Commands

resequence prefix-list ipv4 Resequence a prefix list

resequence prefix-list ipv4

CES

Re-assign sequence numbers to entries of an existing prefix list.

Syntax

resequence prefix-list ipv4 { prefix-list-name StartingSeqNum Step-to-increment}

Parameters

prefix-list-name	Enter the name of configured prefix list, up to 140 characters long.	
StartingSeqNum	Enter the starting sequence number to resequence.	
	Range: 0 – 65535	
Step-to-Increment	Enter the step to increment the sequence number.	
	Range: 1 – 65535	

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Introduced

Usage Information

When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing prefix list.

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

resequence access-list	Resequence an access-list	
------------------------	---------------------------	--

seq

CES

Assign a sequence number to a deny or permit filter in an IP access list while creating the filter.

Syntax

seq sequence-number {deny | permit} { source [mask] | any | host ip-address}} [count [byte] | log] [dscp value] [order] [monitor] [fragments]

To delete a filter, use the **no seq** sequence-number command.

Parameters

sequence-number	Enter a number from 0 to 4294967290.
deny	Enter the keyword deny to configure a filter to drop packets meeting this condition.
permit	Enter the keyword permit to configure a filter to forward packets meeting this criteria.
source	Enter a IP address in dotted decimal format of the network from which the packet was received.
mask	(OPTIONAL) Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.
any	Enter the keyword any to specify that all routes are subject to the filter.
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address or hostname.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.
order	(OPTIONAL) Enter the keyword order to specify the QoS order for the ACL entry.
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.
fragments	Enter the keyword fragments to use ACLs to control packet fragments.

Defaults

Not configured

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale

Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **monitor** option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.

The **order** option is relevant in the context of the Policy QoS feature only. The following applies:

- The **seq** *sequence-number* is applicable only in an ACL group.
- The order option works across ACL groups that have been applied on an interface via QoS policy framework.
- The **order** option takes precedence over the **seq** *sequence-number*.
- If sequence-number is **not** configured, then rules with the same order value are ordered according to their configuration order.
- If the sequence-number is configured, then the sequence-number is used as a tie breaker for rules with the same order.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related Commands

deny	Configure a filter to drop packets.
permit	Configure a filter to forward packets.
seq	Assign a sequence number to a deny or permit filter in an IP access list while creating the filter.

Extended IP ACL Commands

When an ACL is created without any rule and then applied to an interface, ACL behavior reflects an implicit permit.

The following commands configure extended IP ACLs, which in addition to the IP address also examine the packet's protocol type.

and platforms (except the S60) support Ingress IP ACLs only.

The S60 supports both Ingress and Egress IP ACLs.

- deny
- deny arp
- deny ether-type
- deny icmp
- deny tcp
- deny udp
- ip access-list extended
- permit
- permit arp
- permit ether-type
- permit icmp
- permit tcp
- permit udp
- resequence access-list
- resequence prefix-list ipv4
- seq arp
- seq ether-type
- seq



Note: See also Commands Common to all ACL Types and Common IP ACL Commands.

deny



Configure a filter that drops IP packets meeting the filter criteria.

Syntax

deny { ip | ip-protocol-number } { source mask | any | host ip-address } { destination mask | any | host ip-address} [count [byte] | log] [dscp value] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** {**ip** | *ip-protocol-number*} { source mask | **any** | **host** *ip-address*} { destination mask | any | host ip-address | command.

Parameters

ip	Enter the keyword ip to configure a generic IP access list. The keyword ip specifies that the access list will deny all IP protocols.
ip-protocol-number	Enter a number from 0 to 255 to deny based on the protocol identified in the IP protocol header.
source	Enter the IP address of the network or host from which the packets were sent.
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.
any	Enter the keyword any to specify that all routes are subject to the filter.
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.
destination	Enter the IP address of the network or host to which the packets are sent.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.
fragments	Enter the keyword fragments to use ACLs to control packet fragments.

Defaults

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

The monitor option is relevant in the context of flow-based monitoring only. See the Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related **Commands**

deny tcp	Assign a filter to deny TCP packets.
deny udp	Assign a filter to deny UDP packets.
ip access-list extended	Create an extended ACL.

deny arp



Configure an egress filter that drops ARP packets on egress ACL supported line cards (see your line card documentation).

Syntax

deny arp { destination-mac-address mac-address-mask | any } vlan vlan-id { ip-address | any | opcode code-number} [count [byte] | log] [order] [monitor]

To remove this filter, use one of the following:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny arp** { destination-mac-address mac-address-mask | any } vlan vlan-id { ip-address | any | opcode code-number} command.

destination-mac-address	Enter a MAC address and mask in the nn:nn:nn:nn:nn format.
mac-address-mask	For the MAC address mask, specify which bits in the MAC address must match.
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
any	Enter the keyword any to match and drop any ARP traffic on the interface.
vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN.
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)
	To filter all VLAN traffic specify VLAN 1.
ip-address	Enter an IP address in dotted decimal format (A.B.C.D) as the target IP address of the ARP.
opcode code-number	Enter the keyword opcode followed by the number of the ARP opcode.
	Range: 1 to 23.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
_	

byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added monitor option
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

The **monitor** option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

You cannot include IP, TCP or UDP (Layer 3) filters in an ACL configured with ARP or Ether-type (Layer 2) filters. Apply Layer 2 ACLs (ARP and Ether-type) to Layer 2 interfaces only.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

deny ether-type

Configure an egress filter that drops specified types of Ethernet packets on egress ACL supported line cards (see your line card documentation).

Syntax

deny ether-type protocol-type-number {destination-mac-address mac-address-mask | **any**} **vlan** vlan-id {source-mac-address mac-address-mask | **any**} [**count** [**byte**] | **log**] [**order**] [**monitor**]

To remove this filter, use one of the following:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny ether-type** protocol-type-number { destination-mac-address mac-address-mask | any} vlan vlan-id { source-mac-address mac-address-mask | any} command.

Parameters

protocol-type-number	Enter a number from 600 to FFFF as the specific Ethernet type traffic to drop.
destination-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of
any	00:00:00:00:00:00 only allows entries that match exactly. Enter the keyword any to match and drop specific Ethernet traffic on the interface.
vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN. Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094) To filter all VLAN traffic specify VLAN 1.
source-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00:00 only allows entries that match exactly.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry. Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority) Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .

Defaults

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command **History**

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale

Version 7.4.1.0	Added monitor option
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **monitor** option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.

You cannot include IP, TCP or UDP (Layer 3) filters in an ACL configured with ARP or Ether-type (Layer 2) filters. Apply Layer 2 ACLs (ARP and Ether-type) to Layer 2 interfaces only.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

deny icmp



Configure a filter to drop all or specific ICMP messages.

Syntax

deny icmp { source mask | any | host ip-address} { destination mask | any | host ip-address}
[dscp] [message-type] [count [byte] | log] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny icmp** {source mask | any | host ip-address} {destination mask | any | host ip-address} command.

source	Enter the IP address of the network or host from which the packets were sent.	
mask	Enter a network mask in /prefix format ($/x$) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any Enter the keyword any to specify that all routes are subject to the filter.		
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.	
destination	Enter the IP address of the network or host to which the packets are sent.	
dscp	Enter this keyword to deny a packet based on DSCP value. Range: 0-63	
message-type	(OPTIONAL) Enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type (ICMP message types are listed in Table 6-2).	
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.	

order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.		
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)		
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).		
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .		
fragments	Enter the keyword fragments to use ACLs to control packet fragments.		

Not configured

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the FTOS Configuration Guide for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The monitor option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Table 6-2 lists the keywords displayed in the CLI help and their corresponding ICMP Message Type Name.

Table 6-2. ICMP Message Type Keywords

Keyword	ICMP Message Type Name
administratively-prohibited	Administratively prohibited
alternate-address	Alternate host address
conversion-error	Datagram conversion error
dod-host-prohibited	Host prohibited
dod-net-prohibited	Net prohibited
echo	Echo
echo-reply	Echo reply

Table 6-2. ICMP Message Type Keywords

Keyword	ICMP Message Type Name
general-parameter-problem	Parameter problem
host-isolated	Host isolated
host-precedence-unreachable	Host unreachable for precedence
host-redirect	Host redirect
host-tos-redirect	Host redirect for TOS
host-tos-unreachable	Host unreachable for TOS
host-unknown	Host unknown
host-unreachable	Host unreachable
information-reply	Information replies
information-request	Information requests
mask-reply	Mask replies
mask-request	Mask requests
mobile-redirect	Mobile host redirect
net-redirect	Network redirect
net-tos-redirect	Network redirect for TOS
net-tos-unreachable	Network unreachable for TOS
net-unreachable	Network unreachable
network-unknown	Network unknown
no-room-for-option	Parameter required but no room
option-missing	Parameter required but not present
packet-too-big	Fragmentation needed and DF set
parameter-problem	All parameter problems
port-unreachable	Port unreachable
precedence-unreachable	Precedence cutoff
protocol-unreachable	Protocol unreachable
reassembly-timeout	Reassembly timeout
redirect	All redirects
router-advertisement	Router discovery advertisements
router-solicitation	Router discovery solicitations
source-quench	Source quenches
source-route-failed	Source route failed
time-exceeded	All time exceeded
timestamp-reply	Timestamp replies
timestamp-request	Timestamp requests
traceroute	Traceroute
ttl-exceeded	TTL exceeded
unreachable	All unreachable

deny tcp

Configure a filter that drops TCP packets meeting the filter criteria.

Syntax

deny tcp {source mask | **any** | **host** ip-address} [bit] [operator port [port]] { destination mask | any | host ip-address} [dscp] [bit] [operator port [port]] [count [byte] | log] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny tcp** {source mask | any | host ip-address} { destination mask | any | host *ip-address*} command.

source	Enter the IP address of the network or host from which the packets were sent.	
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.	
dscp	Enter this keyword to deny a packet based on DSCP value.	
•	Range: 0-63	
bit	Enter a flag or combination of bits:	
	ack: acknowledgement field	
	fin: finish (no more data from the user)	
	psh: push function	
	rst: reset the connection	
	syn: synchronize sequence numbers	
	urg: urgent field	
operator	(OPTIONAL) Enter one of the following logical operand:	
	• eq = equal to	
	• neq = not equal to	
	• gt = greater than	
	• $\mathbf{lt} = \text{less than}$	
	• range = inclusive range of ports (you must specify two ports for the <i>port</i> command parameter.	
port port	Enter the application layer port number. Enter two port numbers if using the range logical operand.	
	Range: 0 to 65535.	
	The following list includes some common TCP port numbers:	
	• 23 = Telnet	
	• 20 and 21 = FTP	
	• $25 = SMTP$	
	• 169 = SNMP	
destination	Enter the IP address of the network or host to which the packets are sent.	
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	

log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.		
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.		
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)		
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).		
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.		
fragments	Enter the keyword fragments to use ACLs to control packet fragments.		

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option. Deprecated established keyword.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

The **monitor** option is relevant in the context of flow-based monitoring only. See Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (**gt**, **lt**, **range**) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port **range 4000 - 8000** uses 8 entries in the CAM:

Rule#	Data	Mask	From	To	#Covered
1 2 3 4 5 6	0000111110100000 0000111111000000 0001000000	1111111111100000 11111111111100000 11111000000	4000 4032 4096 6144	4031 4095 6143 7167 7679 7935 7999	32 64 2048 1024 512 256 64
8	0001111101000000	11111111111111111	8000	8000	1

Total Ports: 4001

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	Data	Mask	From	To	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

deny	Assign a filter to deny IP traffic.
deny udp	Assign a filter to deny UDP traffic.

deny udp

Configure a filter to drop UDP packets meeting the filter criteria.

Syntax

deny udp {source mask | any | host ip-address} [operator port [port]] { destination mask | any | host ip-address} [dscp] [operator port [port]] [count [byte] | log] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny udp** { source mask | any | host ip-address} { destination mask | any | host ip-address} command.

source	Enter the IP address of the network or host from which the packets were sent.	
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.	
dscp	Enter this keyword to deny a packet based on DSCP value. Range: 0-63	

operator (OPTIONAL) Enter one of the following logical operand:			
	• eq = equal to		
	• neq = not equal to		
	• gt = greater than		
	• $\mathbf{lt} = \text{less than}$		
	• range = inclusive range of ports		
port port	(OPTIONAL) Enter the application layer port number. Enter two port numbers if using the range logical operand.		
	Range: 0 to 65535		
destination	Enter the IP address of the network or host to which the packets are sent.		
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.		
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.		
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.		
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.		
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.		
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)		
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).		
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .		
fragments	Enter the keyword fragments to use ACLs to control packet fragments.		

Not configured

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

The **monitor** option is relevant in the context of flow-based monitoring only. See the Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (gt, It, range) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port range 4000 - 8000 will use 8 entries in the CAM:

Rule#	Data	Mask	From	То	#Covered
1 2 3 4 5 6 7 8	0000111111000000 00010000000000000 00011000000	1111111111100000 1111111111100000 11111000000		4031 4095 6143 7167 7679 7935 7999 8000	32 64 2048 1024 512 256 64

Total Ports: 4001

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	Data	Mask	From	To	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related **Commands**

deny	Assign a deny filter for IP traffic.
deny tcp	Assign a deny filter for TCP traffic.

ip access-list extended

CES Name (or select) an extended IP access list (IP ACL) based on IP addresses or protocols.

Syntax ip access-list extended access-list-name

To delete an access list, use the **no ip access-list extended** access-list-name command.

Parameters access-list-name Enter a string up to 140 characters long as the access list name.

Defaults All access lists contain an implicit "deny any"; that is, if no match occurs, the packet is dropped.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

The number of entries allowed per ACL is hardware-dependent. Refer to your line card documentation for detailed specification on entries allowed per ACL.

Prior to 7.8.1.0, names are up to 16 characters long.

Example

Figure 6-5. Command Example: ip access-list extended

```
FTOS(conf)#ip access-list extended TESTListEXTEND
FTOS(config-ext-nacl)#
```

Related Commands

ip access-list standard	Configure a standard IP access list.
show config	Display the current configuration.

permit



Configure a filter to pass IP packets meeting the filter criteria.

Syntax

permit {ip | ip-protocol-number} { source mask | any | host ip-address} { destination mask | any |
host ip-address} [count [byte] | log] [dscp value] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** {**ip** | *ip-protocol-number*} { source mask | **any** | **host** *ip-address*} { destination mask | **any** | **host** *ip-address*} command.

ip	Enter the keyword ip to configure a generic IP access list. The keyword ip specifies that the access list will permit all IP protocols.	
ip-protocol-number	Enter a number from 0 to 255 to permit based on the protocol identified in the IP protocol header.	
source	Enter the IP address of the network or host from which the packets were sent.	
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.	
destination	Enter the IP address of the network or host to which the packets are sent.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	

byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.		
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.		
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.		
order	(OPTIONAL) Enter the keyword order to specify the QoS order of priority for the ACL entry.		
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)		
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).		
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.		
fragments	Enter the keyword fragments to use ACLs to control packet fragments.		

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the FTOS Configuration Guide for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the count byte options, only bytes are incremented.

The **monitor** option is relevant in the context of flow-based monitoring only. See the Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related Commands

ip access-list extended	Create an extended ACL.	

permit tcp	Assign a permit filter for TCP packets.
permit udp	Assign a permit filter for UDP packets.

permit arp



Configure a filter that forwards ARP packets meeting this criteria. This command is supported only on 12-port GE line cards with SFP optics; refer to your line card documentation for specifications.

Syntax

permit arp { destination-mac-address mac-address-mask | any } vlan vlan-id { ip-address | any |
 opcode code-number} [count [byte] | log] [order] [monitor] [fragments]

To remove this filter, use one of the following:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit arp** { destination-mac-address mac-address-mask | **any**} **vlan** vlan-id { ip-address | **any** | **opcode** code-number} command.

destination-mac-address	Enter a MAC address and mask in the nn:nn:nn:nn format.			
mac-address-mask	For the MAC address mask, specify which bits in the MAC address must match.			
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.			
any	Enter the keyword any to match and drop any ARP traffic on the interface.			
vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN.			
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)			
	To filter all VLAN traffic specify VLAN 1.			
ip-address	Enter an IP address in dotted decimal format (A.B.C.D) as the target IP address of the ARP.			
opcode code-number	Enter the keyword opcode followed by the number of the ARP opcode.			
	Range: 1 to 16.			
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.			
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.			
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.			
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.			
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)			
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).			
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the			
	traffic that you want to monitor and the ACL in which you are creating the			
	rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS</i>			
	Configuration Guide.			
fragments	Enter the keyword fragments to use ACLs to control packet fragments.			

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the FTOS Configuration Guide for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The monitor option is relevant in the context of flow-based monitoring only. See the Chapter 28, Port Monitoring.

You cannot include IP, TCP or UDP filters in an ACL configured with ARP filters.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

permit ether-type



Configure a filter that allows traffic with specified types of Ethernet packets. This command is supported only on 12-port GE line cards with SFP optics; refer to your line card documentation for specifications.

Syntax

permit ether-type protocol-type-number { destination-mac-address mac-address-mask | any } vlan vlan-id {source-mac-address mac-address-mask | any } [count [byte] | log] [order] [monitor]

To remove this filter, use one of the following:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit ether-type** protocol-type-number { destination-mac-address mac-address-mask | any | vlan vlan-id { source-mac-address mac-address-mask | any } command.

protocol-type-number	Enter a number from 600 to FFF as the specific Ethernet type traffic to drop.	
destination-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.	
any	Enter the keyword any to match and drop specific Ethernet traffic on the interface.	

vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN. Renger 1 to 4004, 1,2004 for EveScale (converted IDs 1,4004)			
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)			
	To filter all VLAN traffic specify VLAN 1.			
source-mac-address	Enter a MAC address and mask in the nn:nn:nn:nn:nn format.			
mac-address-mask	For the MAC address mask, specify which bits in the MAC address must match.			
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.			
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.			
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.			
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.			
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.			
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)			
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).			
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rul will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.			

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added monitor option
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.

You cannot include IP, TCP or UDP filters in an ACL configured with ARP filters.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

permit icmp

Configure a filter to allow all or specific ICMP messages.

Syntax

permit icmp { source mask | any | host ip-address} { destination mask | any | host ip-address} [dscp] [message-type] [count [byte] | log] [order] [monitor] [fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit icmp** { source mask | any | host ip-address} { destination mask | any | host ip-address} command.

Parameters

source	Enter the IP address of the network or host from which the packets were sent.			
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.			
any	Enter the keyword any to specify that all routes are subject to the filter.			
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.			
destination	Enter the IP address of the network or host to which the packets are sent.			
dscp	Enter this keyword to deny a packet based on DSCP value. Range: 0-63			
message-type	(OPTIONAL) Enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type (ICMP message types are listed in Table 6-2).			
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code			
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.			
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.			
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.			
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry. Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)			
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).			
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.			
fragments	Enter the keyword fragments to use ACLs to control packet fragments.			

Defaults

Not configured

Command Modes

CONFIGURATION-STANDARD-ACCESS-LIST

Command **History**

Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the "Quality of Service" chapter of the *FTOS Configuration Guide* for more information.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

permit tcp

Configure a filter to pass TCP packets meeting the filter criteria.

Syntax

permit tcp { source mask | any | host ip-address} [bit] [operator port [port]] { destination mask |
any | host ip-address} [bit] [dscp] [operator port [port]] [count [byte] | log] [order] [monitor]
[fragments]

To remove this filter, you have two choices:

- Use the no seq sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit tcp** {source mask | any | host ip-address} {destination mask | any | host ip-address} command.

source	Enter the IP address of the network or host from which the packets were sent.				
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.				
any	Enter the keyword any to specify that all routes are subject to the filter.				
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.				
bit	Enter a flag or combination of bits:				
	ack: acknowledgement field				
	fin : finish (no more data from the user)				
	psh: push function				
	rst: reset the connection				
	syn: synchronize sequence numbers				
	urg: urgent field				
dscp	Enter this keyword to deny a packet based on DSCP value.				
	Range: 0-63				
operator	(OPTIONAL) Enter one of the following logical operand:				
	• eq = equal to				
	• neq = not equal to				
	• gt = greater than				
	• $\mathbf{lt} = \text{less than}$				
	• range = inclusive range of ports (you must specify two port for the <i>port</i> parameter.)				

port port	Enter the application layer port number. Enter two port numbers if using the range logical operand.			
	Range: 0 to 65535.			
	The following list includes some common TCP port numbers:			
	23 = Telnet			
	20 and 21 = FTP			
	25 = SMTP			
	169 = SNMP			
destination	Enter the IP address of the network or host to which the packets are sent.			
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.			
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.			
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.			
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.			
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.			
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)			
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).			
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .			
fragments	Enter the keyword fragments to use ACLs to control packet fragments.			

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option. Deprecated established keyword.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The order option is relevant in the context of the Policy QoS feature only. See the Quality of Service chapter of the FTOS Configuration Guide for more information.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (**gt**, **lt**, **range**) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port range 4000 - 8000 uses 8 entries in the CAM:

Rule#	Data	Mask	From	То	#Covered
1 2 3 4 5 6 7 8	0000111111000000 00010000000000000 00011000000	1111111111100000 11111111111000000 11111000000		4031 4095 6143 7167 7679 7935 7999 8000	32 64 2048 1024 512 256 64

Total Ports: 4001

But an ACL rule with TCP port **lt 1023** takes only one entry in the CAM:

Rule#	Data	Mask	From	То	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

ip access-list extended	Create an extended ACL.
permit	Assign a permit filter for IP packets.
permit udp	Assign a permit filter for UDP packets.

permit udp



Configure a filter to pass UDP packets meeting the filter criteria.

Syntax

permit udp {source mask | any | host ip-address} [operator port [port]] { destination mask | any |
host ip-address} [dscp] [operator port [port]] [count [byte] | log] [order] [monitor]
[fragments]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit udp** { source mask | any | host ip-address} { destination mask | any | host ip-address} command.

Parameters

source	Enter the IP address of the network or host from which the packets were sent.	
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.	
dscp	Enter this keyword to deny a packet based on DSCP value. Range: 0-63	
operator	 (OPTIONAL) Enter one of the following logical operand: eq = equal to neq = not equal to gt = greater than lt = less than range = inclusive range of ports (you must specify two ports for the <i>port</i> parameter.) 	
port port	(OPTIONAL) Enter the application layer port number. Enter two port numbers if using the range logical operand. Range: 0 to 65535	
destination	Enter the IP address of the network or host to which the packets are sent.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log.	
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry. Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority) Default: If the order keyword is not used, the ACLs have the lowest order by default (255).	
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .	
fragments	Enter the keyword fragments to use ACLs to control packet fragments.	

Defaults

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added dscp keyword.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option.
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **order** option is relevant in the context of the Policy QoS feature only. See the Quality of Service chapter of the *FTOS Configuration Guide* for more information.

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The C-Series and S-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (**gt**, **lt**, **range**) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port range 4000 - 8000 uses 8 entries in the CAM:

Rule#	Data	Mask	From	То	#Covered
1 2 3 4 5 6 7 8	0000111111000000 00010000000000000 00011000000	1111111111100000 11111111111000000 11111000000	6144 7168 7680	4031 4095 6143 7167 7679 7935 7999 8000	32 64 2048 1024 512 256 64

Total Ports: 4001

But an ACL rule with TCP port **lt 1023** takes only one entry in the CAM:

Rule#	Data	Mask	From	То	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

ip access-list extended	Configure an extended ACL.
permit	Assign a permit filter for IP packets.
permit tcp	Assign a permit filter for TCP packets.

resequence access-list

CESRe-assign sequence numbers to entries of an existing access-list.

Syntax resequence access-list {ipv4 | mac} {access-list-name StartingSeqNum Step-to-Increment}

Parameters

ipv4 mac	Enter the keyword ipv4 , or mac to identify the access list type to resequence.
access-list-name	Enter the name of a configured IP access list, up to 140 characters.
StartingSeqNum	Enter the starting sequence number to resequence. Range: 0 - 4294967290
Step-to-Increment	Enter the step to increment the sequence number. Range: 1 - 4294967290

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Introduced for E-Series

Usage Information When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing access-list.

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

resequence prefix-list ipv4	Reseguence a prefix list	
resequence prefix-fist ipv+	Resequence a prenz nst	

resequence prefix-list ipv4

CES Re-assign sequence numbers to entries of an existing prefix list.

resequence prefix-list ipv4 { prefix-list-name StartingSeqNum Step-to-increment}

Parameters

Syntax

prefix-list-name	Enter the name of configured prefix list, up to 140 characters long.
StartingSeqNum	Enter the starting sequence number to resequence.
	Range: 0 – 65535
Step-to-Increment	Enter the step to increment the sequence number.
	Range: 1 – 65535

Defaults No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Introduced for E-Series

Usage Information

When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing prefix list.

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

resequence access-list Resequence an access-list	

seq arp



Configure an egress filter with a sequence number that filters ARP packets meeting this criteria. This command is supported only on 12-port GE line cards with SFP optics; refer to your line card documentation for specifications.

Syntax

seq sequence-number {deny | permit} arp {destination-mac-address mac-address-mask | any}
vlan vlan-id {ip-address | any | opcode code-number} [count [byte] | log] [order] [monitor]

To remove this filter, use the **no seq** sequence-number command.

sequence-number	Enter a number from 0 to 4294967290.
deny	Enter the keyword deny to drop all traffic meeting the filter criteria.
permit	Enter the keyword permit to forward all traffic meeting the filter criteria.
destination-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must
	match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
any	Enter the keyword any to match and drop any ARP traffic on the interface.
vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN.
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)
	To filter all VLAN traffic specify VLAN 1.
ip-address	Enter an IP address in dotted decimal format (A.B.C.D) as the target IP address of the ARP.
opcode code-number	Enter the keyword opcode followed by the number of the ARP opcode.
	Range: 1 to 16.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.

byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added monitor option
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **order** option is relevant in the context of the Policy QoS feature only. The following applies:

- The **seq** sequence-number is applicable only in an ACL group.
- The order option works across ACL groups that have been applied on an interface via QoS policy framework.
- The **order** option takes precedence over the **seq** *sequence-number*.
- If sequence-number is not configured, then rules with the same order value are ordered according to their configuration order.
- If the sequence-number is configured, then the sequence-number is used as a tie breaker for rules with the same order.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

You cannot include IP, TCP or UDP (Layer 3) filters in an ACL configured with ARP or Ether-type (Layer 2) filters. Apply Layer 2 ACLs to interfaces in Layer 2 mode.

seq ether-type

Configure an egress filter with a specific sequence number that filters traffic with specified types of Ethernet packets. This command is supported only on 12-port GE line cards with SFP optics; refer to your line card documentation for specifications.

Syntax

seq sequence-number {deny | permit} ether-type protocol-type-number
{destination-mac-address mac-address-mask | any} vlan vlan-id {source-mac-address
mac-address-mask | any} [count [byte] | log] [order] [monitor]

To remove this filter, use the **no seq** *sequence-number* command.

sequence-number	Enter a number from 0 to 4294967290.
deny	Enter the keyword deny to drop all traffic meeting the filter criteria.
permit	Enter the keyword permit to forward all traffic meeting the filter criteria.
protocol-type-number	Enter a number from 600 to FFFF as the specific Ethernet type traffic to drop.
destination-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff:ff:ff:ff:ff:ff:ff:ff
	allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
any	Enter the keyword any to match and drop specific Ethernet traffic on the interface.
vlan vlan-id	Enter the keyword vlan followed by the VLAN ID to filter traffic associated with a specific VLAN.
	Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094) To filter all VLAN traffic specify VLAN 1.
source-mac-address mac-address-mask	Enter a MAC address and mask in the nn:nn:nn:nn:nn format. For the MAC address mask, specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to have the information kept in an ACL log file.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry. Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority) Default: If the order keyword is not used, the ACLs have the lowest order
	by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .

Not configured.

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Added monitor option
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **order** option is relevant in the context of the Policy QoS feature only. The following applies:

- The **seq** sequence-number is applicable only in an ACL group.
- The **order** option works across ACL groups that have been applied on an interface via QoS policy framework.
- The **order** option takes precedence over the **seq** sequence-number.
- If sequence-number is not configured, then rules with the same order value are ordered according to their configuration order.
- If the sequence-number is configured, then the sequence-number is used as a tie breaker for rules with the same order.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

You cannot include IP, TCP or UDP (Layer 3) filters in an ACL configured with ARP or Ether-type (Layer 2) filters. Apply Layer 2 filters to interfaces in Layer 2 mode.

seq



Assign a sequence number to a deny or permit filter in an extended IP access list while creating the filter.

Syntax

seq sequence-number {deny | permit} {ip-protocol-number | icmp | ip | tcp | udp} {source mask | any | host ip-address} {destination mask | any | host ip-address} [operator port [port]] [count [byte] | log] [dscp value] [order] [monitor] [fragments]

To delete a filter, use the **no seq** sequence-number command.

sequence-number	Enter a number from 0 to 4294967290.
deny	Enter the keyword deny to configure a filter to drop packets meeting this condition.
permit	Enter the keyword permit to configure a filter to forward packets meeting this criteria.
ip-protocol-number	Enter a number from 0 to 255 to filter based on the protocol identified in the IP protocol header.
icmp	Enter the keyword icmp to configure an ICMP access list filter.

ip	Enter the keyword ip to configure a generic IP access list. The keyword ip specifies that the access list will permit all IP protocols.
tcp	Enter the keyword tcp to configure a TCP access list filter.
udp	Enter the keyword udp to configure a UDP access list filter.
source	Enter the IP address of the network or host from which the packets were sent.
mask	Enter a network mask in /prefix format (/x) or A.B.C.D. The mask, when specified in A.B.C.D format, may be either contiguous or non-contiguous.
any	Enter the keyword any to specify that all routes are subject to the filter.
host ip-address	Enter the keyword host followed by the IP address to specify a host IP address.
operator	(OPTIONAL) Enter one of the following logical operands:
	• eq = equal to
	• neq = not equal to
	• gt = greater than
	• $\mathbf{lt} = \text{less than}$
	• range = inclusive range of ports (you must specify two ports for the <i>port</i> parameter.)
port port	(OPTIONAL) Enter the application layer port number. Enter two port numbers if using the range logical operand.
	Range: 0 to 65535
	The following list includes some common TCP port numbers:
	• 23 = Telnet
	• 20 and $21 = FTP$
	• 25 = SMTP
	• 169 = SNMP
destination	Enter the IP address of the network or host to which the packets are sent.
message-type	(OPTIONAL) Enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type (ICMP message types are listed in Table 6-2).
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.
dscp	(OPTIONAL) Enter the keyword dcsp to match to the IP DCSCP values.
order	(OPTIONAL) Enter the keyword order to specify the QoS priority for the ACL entry.
	Range: 0-254 (where 0 is the highest priority and 254 is the lowest; lower order numbers have a higher priority)
	Default: If the order keyword is not used, the ACLs have the lowest order by default (255).
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .
fragments	Enter the keyword fragments to use ACLs to control packet fragments.
	1 0 4

Not configured

Command Modes

CONFIGURATION-EXTENDED-ACCESS-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Add DSCP value for ACL matching.
Version 8.2.1.0	Allows ACL control of fragmented packets for IP (Layer 3) ACLs.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 7.4.1.0	Added support for non-contiguous mask and added the monitor option. Deprecated established keyword
Version 6.5.10	Expanded to include the optional QoS order priority for the ACL entry.

Usage Information

The **monitor** option is relevant in the context of the flow-based monitoring feature only. See Chapter 28, Port Monitoring.

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

The **order** option is relevant in the context of the Policy QoS feature only. The following applies:

- The **seq** sequence-number is applicable only in an ACL group.
- The order option works across ACL groups that have been applied on an interface via QoS policy framework.
- The **order** option takes precedence over the **seq** sequence-number.
- If sequence-number is not configured, then rules with the same order value are ordered according to their configuration order.
- If the sequence-number is configured, then the sequence-number is used as a tie breaker for rules with the same order.

If the sequence-number is configured, then the sequence-number is used as a tie breaker for rules with the same order.



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Related **Commands**

deny	Configure a filter to drop packets.
permit	Configure a filter to forward packets.

Common MAC Access List Commands

The following commands are available within both MAC ACL modes (Standard and Extended) and do not have mode-specific options.

© and S platforms (except the S60) support Ingress MAC ACLs only.

The [\$60] supports both Ingress and Egress MAC ACLs.

The following commands allow you to clear, display and assign MAC ACL configurations.

- clear counters mac access-group
- mac access-group
- · show mac accounting access-list

clear counters mac access-group

C E S Clear counters for all or a specific MAC ACL.

Syntax clear counters mac access-group [mac-list-name]

Parameters

mac-list-name	(OPTIONAL) Enter the name of a configured MAC access list.	

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

mac access-group

CES

Apply a MAC ACL to traffic entering or exiting an interface.

Syntax

mac access-group access-list-name {in [vlan vlan-range] | out}

To delete a MAC access-group, use the **no mac access-group** *mac-list-name* command.

Parameters

access-list-name	Enter the name of a configured MAC access list, up to 140 characters.
vlan vlan-range	(OPTIONAL) Enter the keyword vian followed a range of VLANs. Note that this option is available only with the in keyword option. Range: 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094)
in	Enter the keyword in to configure the ACL to filter incoming traffic.
out	Enter the keyword out to configure the ACL to filter outgoing traffic. Not available on S-Series.

Defaults

No default behavior or configuration

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

You can assign one ACL (standard or extended) to an interface.

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

mac access-list standard	Configure a standard MAC ACL.
mac access-list extended	Configure an extended MAC ACL.

show mac accounting access-list

CES

Display MAC access list configurations and counters (if configured).

Syntax

show mac accounting access-list access-list-name interface interface in out

Parameters

access-list-name	Enter the name of a configured MAC ACL, up to 140 characters.
interface interface	Enter the keyword interface followed by the one of the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
in out	Identify whether ACL is applied ay Ingress (in) or egress (out) side.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series

Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 6-6. Command Example: show mac accounting access-list

```
FTOS#show mac accounting access-list mac-ext interface po 1
Extended mac access-list mac-ext on GigabitEthernet 0/11
seq 5 permit host
                    00:00:00:00:00:11 host
                                            00:00:00:00:00:19
                                                               count (393794576 packets)
        deny host
                   00:00:00:00:00:21 host 00:00:00:00:29 count (89076777 packets)
 seq 10
        deny host
deny host
 seq 15
                    00:00:00:00:00:31 host
                                           00:00:00:00:00:39
                                                               count (0 packets)
 seq 20
                                                               count (0 packets)
                    00:00:00:00:00:41 host
                                            00:00:00:00:00:49
 seq 25
        permit any any count (0 packets)
Extended mac access-list mac-ext on GigabitEthernet 0/12
                    00:00:00:00:00:11 host 00:00:00:00:00:19 count (57589834 packets)
 seq 5
       permit host
                                            00:00:00:00:00:29 count (393143077 packets)
 seq 10
        deny host
                    00:00:00:00:00:21 host
                                                               count (0 packets)
 seq 15
         deny host
                    00:00:00:00:00:31 host
                                            00:00:00:00:00:39
 seq 20
        deny host
                    00:00:00:00:00:41 host
                                            00:00:00:00:00:49
                                                               count (0 packets)
 seq 25
        permit any any count (0 packets)
FTOS#
```

Related Commands

show mac accounting destination Display destination counters for Layer 2 traffic (available on physical interfaces only).

Standard MAC ACL Commands

When an access-list is created without any rule and then applied to an interface, ACL behavior reflects implicit permit.

[C] and [S] platforms (except the S60 system) support Ingress MAC ACLs only.

The S60 supports both Ingress and Egress MAC ACLs.

The following commands configure standard MAC ACLs:

- deny
- mac access-list standard
- permit
- seq



Note: See also Commands Common to all ACL Types and Common MAC Access List Commands.

deny

Configure a filter to drop packets with a the MAC address specified.

Syntax

deny {any | mac-source-address [mac-source-address-mask]} [count [byte]] [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** {any | mac-source-address mac-source-address-mask} command.

Parameters

any	Enter the keyword any to specify that all traffic is subject to the filter.
mac-source-address	Enter a MAC address in nn:nn:nn:nn:nn format.
mac-source-address-mask	(OPTIONAL) Specify which bits in the MAC address must match. If no mask is specified, a mask of 00:00:00:00:00:00 is applied (in other words, the filter allows only MAC addresses that match).
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.

Defaults

Not enabled.

Command Modes

CONFIGURATION-MAC ACCESS LIST-STANDARD

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added monitor option
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the log entry and at what rate, the CP may become busy as it has to log these packets' details.

Related **Commands**

permit	Configure a MAC address filter to pass packets.
seq	Configure a MAC address filter with a specified sequence number.

mac access-list standard



Name a new or existing MAC access control list (MAC ACL) and enter the MAC ACCESS LIST mode to configure a standard MAC ACL. See Commands Common to all ACL Types and Common MAC Access List Commands.

Syntax

mac access-list standard mac-list-name

To delete a MAC access list, use the **no mac access-list standard** mac-list-name command.

Parameters

mac-list-name	Enter a text string as the name of the standard MAC access list (140 character maximum).

Defaults

Not configured

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

FTOS supports one ingress and one egress MAC ACL per interface.

Prior to 7.8.1.0, names are up to 16 characters long.

The number of entries allowed per ACL is hardware-dependent. Refer to your line card documentation for detailed specification on entries allowed per ACL.

C-Series and S-Series support ingress ACLs only.

Example

Figure 6-7. Command Example: mac-access-list standard

```
FTOS(conf)#mac-access-list access-list standard TestMAC
FTOS(config-std-macl)#?
deny
                        Specify packets to reject
description
                        List description
exit
                        Exit from access-list configuration mode
                        Negate a command or set its defaults
no
permit
                        Specify packets to forward
                        Specify access-list entry remark
remark
                        Sequence numbers
sea
                        Show Standard ACL configuration
```

permit

CES

Configure a filter to forward packets from a specific source MAC address.

Syntax

permit {any | mac-source-address [mac-source-address-mask]} [count [byte]] | [log]
[monitor]

To remove this filter, you have two choices:

- Use the no seq sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit** {any | mac-source-address mac-source-address-mask} command.

Parameters

any	Enter the keyword any to forward all packets received with a MAC address.
mac-source-address	Enter a MAC address in nn:nn:nn:nn:nn format.

mac-source-address-mask	(OPTIONAL) Specify which bits in the MAC address must match. If no mask is specified, a mask of 00:00:00:00:00:00 is applied (in other words, the filter allows only MAC addresses that match).
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.

Defaults

Not configured.

Command Modes

CONFIGURATION-MAC ACCESS LIST-STANDARD

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the log option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

Related Commands

deny	Configure a MAC ACL filter to drop packets.
seq	Configure a MAC ACL filter with a specified sequence number.

seq



Assign a sequence number to a deny or permit filter in a MAC access list while creating the filter.

Syntax

seq sequence-number { deny | permit} { any | mac-source-address [mac-source-address-mask]} [count [byte]] [log] [monitor]

To remove this filter, use the **no seq** *sequence-number* command.

Parameters

sequence-number	Enter a number between 0 and 65535.
deny	Enter the keyword deny to configure a filter to drop packets meeting this condition.
permit	Enter the keyword permit to configure a filter to forward packets meeting this criteria.

any	Enter the keyword any to filter all packets.
mac-source-address	Enter a MAC address in nn:nn:nn:nn:nn format.
mac-source-address-mask	(OPTIONAL) Specify which bits in the MAC address must match. If no mask is specified, a mask of 00:00:00:00:00 is applied (in other words, the filter allows only MAC addresses that match).
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.

Defaults

Not configured.

Command Modes

CONFIGURATION-MAC ACCESS LIST-STANDARD

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added monitor option
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

Related Commands

deny	Configure a filter to drop packets.
permit	Configure a filter to forward packets.

Extended MAC ACL Commands

When an access-list is created without any rule and then applied to an interface, ACL behavior reflects implicit permit.

and platforms (except the S60 system) support Ingress MAC ACLs only.

The S60 supports both Ingress and Egress MAC ACLs.

The following commands configure Extended MAC ACLs.

- deny
- mac access-list extended
- permit
- seq



Note: See also Commands Common to all ACL Types and Common MAC Access List Commands.

deny

Configure a filter to drop packets that match the filter criteria.

Syntax

deny {any | host mac-address | mac-source-address mac-source-address-mask} {any | host mac-address | mac-destination-address mac-destination-address-mask} [ethertype-operator] [count [byte]] [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** {any | host mac-address | mac-source-address mac-source-address-mask} {any | host mac-address | mac-destination-address mac-destination-address-mask} command.

Parameters

any	Enter the keyword any to drop all packets.
host mac-address	Enter the keyword host followed by a MAC address to drop packets with that host address.
mac-source-address	Enter the source MAC address in nn:nn:nn:nn:nn:nn format.
mac-source-address-mask	Specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00:00 only allows entries that match exactly.
mac-destination-address	Enter the destination MAC address and mask in nn:nn:nn:nn:nn format.
mac-destination-address-mask	Specify which bits in the MAC address must match. The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.

ethertype operator	(OPTIONAL) To filter based on protocol type, enter one of the following Ethertypes:
	• ev2 - is the Ethernet II frame format.
	• IIc - is the IEEE 802.3 frame format.
	• snap - is the IEEE 802.3 SNAP frame format.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the FTOS Configuration Guide.

Defaults

Not configured.

Command Modes

CONFIGURATION-MAC ACCESS LIST-EXTENDED

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added monitor option
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

Related Commands

permit	Configure a filter to forward based on MAC addresses.
seq	Configure a filter with specific sequence numbers.

mac access-list extended

CES

Name a new or existing extended MAC access control list (extended MAC ACL).

Syntax

mac access-list extended access-list-name

To delete a MAC access list, use the **no mac access-list extended** access-list-name command.

Parameters

access-list-name	Enter a text string as the MAC access list name, up to 140 characters.

Defaults

No default configuration

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The number of entries allowed per ACL is hardware-dependent. Refer to your line card documentation for detailed specification on entries allowed per ACL.

Prior to 7.8.1.0, names are up to 16 characters long.

Example

Figure 6-8. Command Example: mac-access-list extended

```
FTOS(conf)#mac-access-list access-list extended TestMATExt
FTOS(config-ext-macl) #remark 5 IPv4
FTOS(config-ext-macl)#seq 10 permit any any ev2 eq 800 count bytes
FTOS (config-ext-macl) #remark 15 ARP
FTOS (config-ext-macl) #seq 20 permit any any ev2 eq 806 count bytes
FTOS (config-ext-macl) #remark 25 IPv6
FTOS(config-ext-macl)#seq 30 permit any any ev2 eq 86dd count bytes FTOS(config-ext-macl)#seq 40 permit any any count bytes
FTOS(config-ext-macl)#exit
FTOS(conf)#do show mac accounting access-list snickers interface g0/47 in
Extended mac access-list snickers on GigabitEthernet 0/47
seq 10 permit any any ev2 eq 800 count bytes (559851886 packets 191402152148
bvtes)
        permit any any ev2 eq 806 count bytes (74481486 packets 5031686754
seq 20
bytes)
seq 30 permit any any ev2 eq 86dd count bytes (7751519 packets 797843521 bytes)
```

Related **Commands**

mac access-list standard	Configure a standard MAC access list.
show mac accounting access-list	Display MAC access list configurations and counters (if configured).

permit



Configure a filter to pass packets matching the criteria specified.

Syntax

permit {any | host mac-address | mac-source-address mac-source-address-mask} {any | host mac-address | mac-destination-address mac-destination-address-mask | [ethertype operator] [count [byte]] | [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit** { **any** | **host** *mac-address* | *mac-source-address* mac-source-address-mask} {any | mac-destination-address mac-destination-address-mask} command.

Parameters

any	Enter the keyword any to forward all packets.
host	Enter the keyword host followed by a MAC address to
	forward packets with that host address.
mac-source-address	Enter the source MAC address in nn:nn:nn:nn:nn:nn format.
mac-source-address-mask	Specify which bits in the MAC address must be matched.
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00:00 only allows entries that match exactly.
mac-destination-address	Enter the destination MAC address and mask in nn:nn:nn:nn:nn format.
mac-destination-address-mask	Specify which bits in the MAC address must be matched.
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00:00 only allows entries that match exactly.
ethertype operator	(OPTIONAL) To filter based on protocol type, enter one of the following Ethertypes:
	• ev2 - is the Ethernet II frame format.
	• IIc - is the IEEE 802.3 frame format.
	• snap - is the IEEE 802.3 SNAP frame format.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitore interface. For details, see the section "Flow-based Monitoring in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .

Defaults

Not configured.

Command Modes

CONFIGURATION-MAC ACCESS LIST-EXTENDED

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added monitor option
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

Related Commands

deny	Configure a filter to drop traffic based on the MAC address.
seq	Configure a filter with specific sequence numbers.

seq

CES

Configure a filter with a specific sequence number.

Syntax

seq sequence-number {deny | permit} {any | host mac-address | mac-source-address mac-source-address-mask} {any | host mac-address | mac-destination-address mac-destination-address-mask} [ethertype operator] [count [byte]] [log] [monitor]

To delete a filter, use the **no seq** sequence-number command.

Parameters

sequence-number	Enter a number as the filter sequence number.
	Range: zero (0) to 65535.
deny	Enter the keyword deny to drop any traffic matching this filter.
permit	Enter the keyword permit to forward any traffic matching this filter.
any	Enter the keyword any to filter all packets.
host mac-address	Enter the keyword host followed by a MAC address to filter packets with that host address.
mac-source-address	Enter the source MAC address in nn:nn:nn:nn:nn:nn format.
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
mac-source-address-mask	Specify which bits in the MAC address must be matched.
mac-destination-address	Enter the destination MAC address and mask in nn:nn:nn:nn:nn:nn format.
mac-destination-address-mask	Specify which bits in the MAC address must be matched.
	The MAC ACL supports an inverse mask, therefore, a mask of ff:ff:ff:ff:ff:ff allows entries that do not match and a mask of 00:00:00:00:00:00 only allows entries that match exactly.
ethertype operator	(OPTIONAL) To filter based on protocol type, enter one of the following Ethertypes:
	• ev2 - is the Ethernet II frame format.
	• IIc - is the IEEE 802.3 frame format.
	• snap - is the IEEE 802.3 SNAP frame format.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL, E-Series only) Enter the keyword log to log the packets.
monitor	(OPTIONAL) Enter the keyword monitor when the rule is describing the traffic that you want to monitor and the ACL in which you are creating the rule will be applied to the monitored interface. For details, see the section "Flow-based Monitoring" in the Port Monitoring chapter of the <i>FTOS Configuration Guide</i> .

Defaults

Not configured

Command Modes

CONFIGURATION-MAC ACCESS LIST-STANDARD

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added monitor option
pre-Version 6.1.1.0	Introduced for E-Series



Note: When ACL logging and byte counters are configured simultaneously, byte counters may display an incorrect value. Configure packet counters with logging instead.

Usage Information

When you use the **log** option, CP processor logs details about the packets that match. Depending on how many packets match the **log** entry and at what rate, the CP may become busy as it has to log these packets' details.

Related Commands

deny	Configure a filter to drop traffic.
permit	Configure a filter to forward traffic.

IP Prefix List Commands

When an access-list is created without any rule and then applied to an interface, ACL behavior reflects implicit permit.

Use these commands to configure or enable IP prefix lists.

- clear ip prefix-list
- deny
- ip prefix-list
- permit
- seq
- show config
- show ip prefix-list detail
- show ip prefix-list summary

clear ip prefix-list

CES

Reset the number of times traffic met the conditions ("hit" counters) of the configured prefix lists.

Syntax

clear ip prefix-list [prefix-name]

Parameters

prefix-name	(OPTIONAL) Enter the name of the configured prefix list to clear only counters for that
	prefix list, up to 140 characters long.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Default

Clears "hit" counters for all prefix lists unless a prefix list is specified.

Related Commands

ip prefix-list Configure a prefix list.

deny

[C][E][S]

Configure a filter to drop packets meeting the criteria specified.

Syntax

deny *ip-prefix* [**ge** *min-prefix-length*] [**le** *max-prefix-length*]

To delete a drop filter, use the **no deny** *ip-prefix* command.

Parameters

ip-prefix	Specify an IP prefix in the network/length format. For example, 35.0.0.0/8 means match the first 8 bits of address 35.0.0.0.
ge min-prefix-length	(OPTIONAL) Enter the keyword ge followed by the minimum prefix length, which is a number from zero (0) to 32.
le max-prefix-length	(OPTIONAL) Enter the keyword le followed by the maximum prefix length, which is a number from zero (0) to 32.

Defaults

Not configured.

Command Modes

PREFIX-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Sequence numbers for this filter are automatically assigned starting at sequence number 5.

If the options \mathbf{ge} or \mathbf{le} are not used, only packets with an exact match to the prefix are filtered.

Related Commands

permit	Configure a filter to pass packets.
seq	Configure a drop or permit filter with a specified sequence number.

ip prefix-list

CES

Enter the PREFIX-LIST mode and configure a prefix list.

Syntax

ip prefix-list prefix-name

To delete a prefix list, use the **no ip prefix-list** *prefix-name* command.

Parameters

prefix-name	Enter a string up to 16 characters long as the name of the prefix list, up to 140 characters
	long.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Prefix lists redistribute OSPF and RIP routes meeting specific criteria. For related RIP commands supported on C-Series and E-Series, see Chapter 32, Router Information Protocol (RIP). For related OSPF commands supported on all three platforms, see Chapter 25, Open Shortest Path First (OSPFv2 and OSPFv3).

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

show ip route list	Display IP routes in an IP prefix list.
show ip prefix-list summary	Display a summary of the configured prefix lists.

permit

CES

Configure a filter that passes packets meeting the criteria specified.

Syntax

permit ip-prefix [ge min-prefix-length] [le max-prefix-length]

To delete a forward filter, use the **no permit** *ip-prefix* command.

Parameters

ip-prefix	Specify an IP prefix in the network/length format. For example, 35.0.0.0/8 means match the first 8 bits of address 35.0.0.0.
ge min-prefix-length	(OPTIONAL) Enter the keyword ge followed by the minimum prefix length, which is a number from zero (0) to 32.
le max-prefix-length	(OPTIONAL) Enter the keyword le followed by the maximum prefix length, which is a number from zero (0) to 32.

Command Modes

PREFIX-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Sequence numbers for this filter are automatically assigned starting at sequence number 5.

If the options **ge** or **le** are not used, only packets with an exact match to the prefix are filtered.

Related Commands

deny	Configure a filter to drop packets.
seq	Configure a drop or permit filter with a specified sequence number.

seq



Assign a sequence number to a deny or permit filter in a prefix list while configuring the filter.

Syntax

seq sequence-number {deny | permit} {any} | [ip-prefix /nn {ge min-prefix-length} {le max-prefix-length}] | [bitmask number]

To delete a specific filter, use the **no seq** sequence-number {deny | permit} {any} | [ip-prefix {ge *min-prefix-length*} { **le** *max-prefix-length*}] | [**bitmask** *number*].

Parameters

Enter a number.
Range: 1 to 4294967294.
Enter the keyword deny to configure a filter to drop packets meeting this condition.
Enter the keyword permit to configure a filter to forward packets meeting this condition.
(OPTIONAL) Enter the keyword any to match any packets.
(OPTIONAL) Specify an IP prefix in the network/length format. For example, 35.0.0.0/8 means match the first 8 bits of address 35.0.0.0.
(OPTIONAL) Enter the keyword ge followed by the minimum prefix length, which is a number from zero (0) to 32.
(OPTIONAL) Enter the keyword le followed by the maximum prefix length, which is a number from zero (0) to 32.
Enter the keyword bitmask followed by a bitmask number in dotted decimal format.

Defaults

Not configured.

Command Modes

PREFIX-LIST

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series

Version 7.5.1.0	Added support for C-Series
Version 6.3.1.0	Added bitmask option

Usage Information

If the options **ge** or **le** are not used, only packets with an exact match to the prefix are filtered.

Related Commands

deny	Configure a filter to drop packets.
permit	Configure a filter to pass packets.

show config

CES

Display the current PREFIX-LIST configurations.

Syntax show config

Command Modes PREFIX-LIST

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-9. Command Example: show config

```
FTOS(conf-nprefixl)#show config
!
ip prefix-list snickers
FTOS(conf-nprefixl)#
```

show ip prefix-list detail

Display details of the configured prefix lists.

Syntax show ip prefix-list detail [prefix-name]

Parameters

prefix-name	(OPTIONAL) Enter a text string as the name of the prefix list, up to 140 characters.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to
	16 characters long.
Version 7.6.1.0	Support added for S-Series

Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-10. Command Example: show ip prefix-list detail

```
FTOS#show ip prefix-list detail
Prefix-list with the last deletion/insertion: filter_ospf
ip prefix-list filter_in:
count: 3, range entries: 3, sequences: 5 - 10
seq 5 deny 1.102.0.0/16 le 32 (hit count: 0)
seq 6 deny 2.1.0.0/16 ge 23 (hit count: 0)
seq 10 permit 0.0.0.0/0 le 32 (hit count: 0)
ip prefix-list filter_ospf:
count: 4, range entries: 1, sequences: 5 - 10 seq 5 deny 100.100.1.0/24 (hit count: 5) seq 6 deny 200.200.1.0/24 (hit count: 1) seq 7 deny 200.200.2.0/24 (hit count: 1)
        seq 10 permit 0.0.0.0/0 le 32 (hit count: 132)
FTOS#
```

show ip prefix-list summary

Display a summary of the configured prefix lists. CES

Syntax show ip prefix-list summary [prefix-name]

Parameters

prefix-name	(OPTIONAL) Enter a text string as the name of the prefix list, up to 140 characters long.
-------------	---

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 6-11. Command Example: show ip prefix-list summary

```
FTOS#show ip prefix summary
Prefix-list with the last deletion/insertion: test
ip prefix-list test:
count: 3, range entries: 1, sequences: 5 - 15
ip prefix-list test1:
count: 2, range entries: 2, sequences: 5 - 10
ip prefix-list test2:
count: 1, range entries: 1, sequences: 5 - 5
ip prefix-list test3:
count: 1, range entries: 1, sequences: 5 - 5
ip prefix-list test4:
count: 1, range entries: 1, sequences: 5 - 5
ip prefix-list test5:
count: 1, range entries: 1, sequences: 5 - 5
ip prefix-list test6:
count: 1, range entries: 1, sequences: 5 - 5
FTOS#
```

Route Map Commands

When an access-list is created without any rule and then applied to an interface, ACL behavior reflects implicit permit.

The following commands allow you to configure route maps and their redistribution criteria.

- continue
- description
- · match as-path
- match community
- match interface
- match ip address
- match ip next-hop
- match ip route-source
- match metric
- match origin
- match route-type
- match tag
- route-map
- set as-path
- set automatic-tag
- set comm-list delete
- set community
- set level
- set local-preference
- set metric
- set metric-type
- set next-hop
- set origin
- set tag
- set weight

- show config
- show route-map

continue

CES

Configure a route-map to go to a route-map entry with a higher sequence number.

Syntax

continue [sequence-number]

To remove the continue clause, use the **no continue** [sequence-number] command.

Parameters

sequence-number	(OPTIONAL) Enter the route map sequence number.
	Range: 1 - 65535
	Default: no sequence number

Defaults

Not Configured

Command Modes

ROUTE-MAP

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Introduced

Usage Information

The **continue** feature allows movement from one route-map entry to a specific route-map entry (the **sequence number**). If the sequence number is not specified, the **continue** feature simply moves to the next sequence number (also known as an implied continue). If a match clause exists, the continue feature executes only after a successful match occurs. If there are no successful matches, **continue** is ignored.

Match clause with Continue clause

The **continue** feature can exist without a match clause. A continue clause without a match clause executes and jumps to the specified route-map entry.

With a match clause and a continue clause, the match clause executes first and the continue clause next in a specified route map entry. The continue clause launches only after a successful match. The behavior is:

- A successful match with a continue clause—the route map executes the set clauses and then goes to the specified route map entry upon execution of the continue clause.
- If the next route map entry contains a continue clause, the route map will execute the continue clause if a successful match occurs.
- If the next route map entry does not contain a continue clause, the route map evaluates normally. If a match does not does not occur, the route map does not continue and will fall through to the next sequence number, if one exists.

Set clause with Continue clause

If the route-map entry contains sets with the continue clause, then set actions is performed first followed by the continue clause jump to the specified route map entry.

- If a set actions occurs in the first route map entry and then the same set action occurs with a different value in a subsequent route map entry, the last set of actions overrides the previous set of actions with the same **set** command.
- If **set community additive** and **set as-path prepend** are configure, the communities and AS numbers are pre-pended.

Related Commands

set community	Specify a COMMUNITY attribute
set as-path	Configure a filter to modify the AS path

description

CES

Add a description to this route map.

Syntax

description { description}

To remove the description, use the **no description** { description} command.

Parameters

description Enter a description to identify the route map (80 characters maximum).

Defaults

No default behavior or values

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 7.7.1.0	Introduced

Related Commands

route-map	Enable a route map	

match as-path

CES

Configure a filter to match routes that have a certain AS number in their BGP path.

Syntax

match as-path as-path-name

To delete a match AS path filter, use the **no match as-path** as-path-name command.

Parameters

as-path-name Enter the name of an established AS-PATH ACL, up to 140 characters.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

set as-path Add information to the BGP AS_PATH attribute	.
--	----------

match community

CES Configure a filter to match routes that have a certain COMMUNITY attribute in their BGP path.

match community community-list-name [exact] **Syntax**

To delete a community match filter, use the **no match community** command.

Parameters

community-list-name	Enter the name of a configured community list.
exact	(OPTIONAL) Enter the keywords exact to process only those routes with this community list name.

Defaults Not configured.

Command Modes

ROUTE-MAP

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

ip community-list	Configure an Community Access list.
set community	Specify a COMMUNITY attribute.
neighbor send-community	Send COMMUNITY attribute to peer or peer group.

match interface

CES Configure a filter to match routes whose next hop is on the interface specified.

Syntax match interface interface

To remove a match, use the **no match interface** interface command.

Parameters

interface Enter the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/ port information.
- For the loopback interface, enter the keyword loopback followed by a number from zero (0) to 16383.
- For a Port Channel interface, enter the keyword **port-channel** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale and ExaScale.

- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For a VLAN, enter the keyword vlan followed by a number from 1 to 4094, 1-2094 for ExaScale (can used IDs 1-4094).

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

match ip address	Redistribute routes that match an IP address.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match metric	Redistribute routes that match a specific metric.
match route-type	Redistribute routes that match a route type.
match tag	Redistribute routes that match a specific tag.

match ip address

CES

Configure a filter to match routes based on IP addresses specified in an access list.

Syntax

match ip address prefix-list-name

To delete a match, use the **no match ip address** *prefix-list-name* command.

Parameters

prefix-list-name Enter the name of configured prefix list, up to 140 characters.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

match interface	Redistribute routes that match the next-hop interface.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match metric	Redistribute routes that match a specific metric.
match route-type	Redistribute routes that match a route type.
match tag	Redistribute routes that match a specific tag.

match ip next-hop

CES

Configure a filter to match based on the next-hop IP addresses specified in an IP access list or IP prefix list.

Syntax match ip next-hop {access-list | prefix-list prefix-list-name}

To delete a match, use the **no match ip next-hop** { access-list-name | **prefix-list** prefix-list-name} command.

Parameters

access-list-name	Enter the name of a configured IP access list, up to 140 characters.
prefix-list prefix-list-name	Enter the keywords prefix-list followed by the name of configured prefix list.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

match interface	Redistribute routes that match the next-hop interface.
match ip address	Redistribute routes that match an IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match metric	Redistribute routes that match a specific metric.

match route-type	Redistribute routes that match a route type.
match tag	Redistribute routes that match a specific tag.

match ip route-source

CES

Configure a filter to match based on the routes advertised by routes specified in IP access lists or IP prefix lists.

Syntax

match ip route-source { access-list | prefix-list prefix-list-name}

To delete a match, use the **no match ip route-source** { access-list | **prefix-list** prefix-list-name} command.

Parameters

access-list-name	Enter the name of a configured IP access list, up to 140 characters.
prefix-list prefix-list-name	Enter the keywords prefix-list followed by the name of configured prefix list, up 10 140 characters.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

match interface	Redistribute routes that match the next-hop interface.
match ip address	Redistribute routes that match an IP address.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match metric	Redistribute routes that match a specific metric.
match route-type	Redistribute routes that match a route type.
match tag	Redistribute routes that match a specific tag.

match metric

CES

Configure a filter to match on a specified value.

Syntax

match metric metric-value

To delete a value, use the **no match metric** [metric-value] command.

Parameters

metric-value	Enter a value to match.
	Range: zero (0) to 4294967295.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related **Commands**

match interface	Redistribute routes that match the next-hop interface.
match ip address	Redistribute routes that match an IP address.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match route-type	Redistribute routes that match a route type.
match tag	Redistribute routes that match a specific tag.

match origin

CES

Configure a filter to match routes based on the value found in the BGP path ORIGIN attribute.

Syntax

match origin {egp | igp | incomplete}

To disable matching filter, use the **no match origin** {**igp** | **egp** | **incomplete**} command.

Parameters

egp	Enter the keyword egp to match routes originating outside the AS.
igp	Enter the keyword igp to match routes originating within the same AS.
incomplete	Enter the keyword incomplete to match routes with incomplete routing information.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

match route-type

CES

Configure a filter to match routes based on the how the route is defined.

Syntax

match route-type {external [type-1 | type-2] | internal | level-1 | level-2 | local}

To delete a match, use the no match route-type {local | internal | external [type-1 | type-2] | level-1 | level-2 | command.

Parameters

external [type-1 type-2]	Enter the keyword external followed by either type-1 or type-2 to match only on OSPF Type 1 routes or OSPF Type 2 routes.
internal	Enter the keyword internal to match only on routes generated within OSPF areas.
level-1	Enter the keyword level-1 to match IS-IS Level 1 routes.
level-2	Enter the keyword level-2 to match IS-IS Level 2 routes.
local	Enter the keyword local to match only on routes generated within the switch.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

match interface	Redistribute routes that match the next-hop interface.
match ip address	Redistribute routes that match an IP address.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match metric	Redistribute routes that match a specific metric.
match tag	Redistribute routes that match a tag.

match tag

CES

Configure a filter to redistribute only routes that match a specified tag value.

Syntax

match tag tag-value

To remove a match, use the **no match tag** command.

Parameters

tag-value	Enter a value as the tag on which to match.
	Range: zero (0) to 4294967295.

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related **Commands**

match interface	Redistribute routes that match the next-hop interface.
match ip address	Redistribute routes that match an IP address.
match ip next-hop	Redistribute routes that match the next-hop IP address.
match ip route-source	Redistribute routes that match routes advertised by other routers.
match metric	Redistribute routes that match a specific metric.
match route-type	Redistribute routes that match a route type.

route-map



Enable a route map statement and configure its action and sequence number. This command also places you in the ROUTE-MAP mode.

Syntax

route-map map-name [permit | deny] [sequence-number]

To delete a route map, use the **no route-map** map-name [**permit** | **deny**] [sequence-number] command.

Parameters

map-name	Enter a text string of up to 140 characters to name the route map for easy identification.
permit	(OPTIONAL) Enter the keyword permit to set the route map default as permit. If no keyword is specified, the default is permit .
deny	(OPTIONAL) Enter the keyword deny to set the route map default as deny.
sequence-number	(OPTIONAL) Enter a number to identify the route map for editing and sequencing with other route maps. You are prompted for a sequence number if there are multiple instances of the route map. Range: 1 to 65535.

Defaults

Not configured

If no keyword (permit or deny) is defined for the route map, the permit action is the default.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-12. Command Example: route-map

FTOS(conf) #route-map dempsey FTOS(config-route-map)#

Usage Information

Use caution when you delete route maps because if you do not specify a sequence number, all route maps with the same *map-name* are deleted when you use **no route-map** *map-name* command.

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

show config Display the current configuration.

set as-path

CES

Configure a filter to modify the AS path for BGP routes.

Syntax

set as-path prepend as-number [... as-number]

To remove an AS-Path setting, use the **no set as-path** {prepend as-number | tag} command.

Parameters

prepend as-number

Enter the keyword prepend followed by up to eight AS numbers to be inserted into the BGP path information.

Range: 1 to 65535

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

You can prepend up to eight AS numbers to a BGP route.

This command influences best path selection in BGP by inserting a tag or AS number into the AS_PATH attribute.

Related Commands

match as-path	Redistribute routes that match an AS-PATH attribute.
ip as-path access-list	Configure an AS-PATH access list.
neighbor filter-list	Configure a BGP filter based on the AS-PATH attribute.
show ip community-lists	Display configured IP Community access lists.

set automatic-tag

CES

Configure a filter to automatically compute the tag value of the route.

Syntax

set automatic-tag

To return to the default, enter no set automatic-tag.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

set level	Specify the OSPF area for route redistribution.
set metric	Specify the metric value assigned to redistributed routes.
set metric-type	Specify the metric type assigned to redistributed routes.
set tag	Specify the tag assigned to redistributed routes.

set comm-list delete



Configure a filter to remove the specified community list from the BGP route's COMMUNITY attribute.

Syntax set comm-list community-list-name delete

To insert the community list into the COMMUNITY attribute, use the no set comm-list community-list-name delete command.

Parameters

community-list-name	Enter the name of an established Community list, up to 140 characters.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The community list used in the **set comm-list delete** command must be configured so that each filter contains only one community. For example, the filter deny 100:12 is acceptable, but the filter deny 120:13 140:33 results in an error.

If the set comm-list delete command and the set community command are configured in the same route map sequence, then the deletion command (set comm-list delete) is processed before the insertion command (set community).

Prior to 7.8.1.0, names are up to 16 characters long.

Related Commands

|--|

match community	Redistribute routes that match the COMMUNITY attribute.
set community	Specify a COMMUNITY attribute.

set community

CES

Allows you to assign a BGP COMMUNITY attribute.

Syntax

set community { community-number | local-as | no-advertise | no-export | none } [additive]

To delete a BGP COMMUNITY attribute assignment, use the **no set community** { community-number | local-as | no-advertise | no-export | none } command.

Parameters

community-number	Enter the community number in AA:NN format where AA is the AS number (2 bytes) and NN is a value specific to that autonomous system.
local-AS	Enter the keywords local-AS to drop all routes with the COMMUNITY attribute of NO_EXPORT_SUBCONFED. All routes with the NO_EXPORT_SUBCONFED (0xFFFFFF03) community attribute must not be advertised to external BGP peers.
no-advertise	Enter the keywords no-advertise to drop all routes containing the well-known community attribute of NO_ADVERTISE. All routes with the NO_ADVERTISE (0xFFFFFF02) community attribute must not be advertised to other BGP peers.
no-export	Enter the keywords no-export to drop all routes containing the well-known community attribute of NO_EXPORT. All routes with the NO_EXPORT (0xFFFFFF01) community attribute must not be advertised outside a BGP confederation boundary.
none	Enter the keywords none to remove the community attribute from routes meeting the route map criteria.
additive	(OPTIONAL) Enter the keyword additive add the communities to already existing communities.

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

ip community-list	Configure a Community access list.
match community	Redistribute routes that match a BGP COMMUNITY attribute.
neighbor send-community	Assign the COMMUNITY attribute.
show ip bgp community	Display BGP community groups.
show ip community-lists	Display configured Community access lists.

set level

CES

Configure a filter to specify the IS-IS level or OSPF area to which matched routes are redistributed.

Syntax

set level {backbone | level-1 | level-1-2 | level-2 | stub-area}

To remove a set level condition, use the no set level {backbone | level-1 | level-1-2 | level-2 | stub-area } command.

Parameters

backbone	Enter the keyword backbone to redistribute matched routes to the OSPF backbone area (area 0.0.0.0).
level-1	Enter the keyword level-1 to redistribute matched routes to IS-IS Level 1.
level-1-2	Enter the keyword level-1-2 to redistribute matched routes to IS-IS Level 1 and Level 2.
level-2	Enter the keyword level-2 to redistribute matched routes to IS-IS Level 2.
stub-area	Enter the keyword stub to redistributed matched routes to OSPF stub areas.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related **Commands**

set automatic-tag	Compute the tag value of the route.
set metric	Specify the metric value assigned to redistributed routes.
set metric-type	Specify the metric type assigned to redistributed routes.
set tag	Specify the tag assigned to redistributed routes.

set local-preference

Configure a filter to set the BGP LOCAL_PREF attribute for routers within the local autonomous system.

Syntax

set local-preference value

To delete a BGP LOCAL_PREF attribute, enter **no set local-preference**.

Parameters

value	Enter a number as the LOCAL_PREF attribute value.
	Range: 0 to 4294967295

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The **set local-preference** command changes the LOCAL_PREF attribute for routes meeting the route map criteria. To change the LOCAL_PREF for all routes, use the **bgp default local-preference** command.

Related Commands

bgp default local-preference Change default LOCAL_PREF attribute for all routes.

set metric

CES

Configure a filter to assign a new metric to redistributed routes.

Syntax

set metric [+ | -] metric-value

To delete a setting, enter **no set metric**.

Parameters

+	(OPTIONAL) Enter + to add a metric-value to the redistributed routes.
-	(OPTIONAL) Enter - to subtract a metric-value from the redistributed routes.
metric-value	Enter a number as the new metric value.
	Range: zero (0) to 4294967295

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

set automatic-tag	Compute the tag value of the route.
set level	Specify the OSPF area for route redistribution.
set metric-type	Specify the route type assigned to redistributed routes.
set tag	Specify the tag assigned to redistributed routes.

set metric-type

Configure a filter to assign a new route type for routes redistributed to OSPF.

Syntax set metric-type {internal | external | type-1 | type-2}

To delete a setting, enter **no set metric-type**.

Parameters

internal	Enter the keyword internal to assign the Interior Gateway Protocol metric of the next hop as the route's BGP MULTI_EXIT_DES (MED) value.
external	Enter the keyword external to assign the IS-IS external metric.
type-1	Enter the keyword type-1 to assign the OSPF Type 1 metric.
type-2	Enter the keyword type-2 to assign the OSPF Type 2 metric.

Defaults Not configured.

Command Modes ROUTE-MAP

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Implemented internal keyword
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

set automatic-tag	Compute the tag value of the route.
set level	Specify the OSPF area for route redistribution.
set metric	Specify the metric value assigned to redistributed routes.
set tag	Specify the tag assigned to redistributed routes.

set next-hop

Parameters

Defaults

CES Configure a filter to specify an IP address as the next hop.

Syntax set next-hop ip-address

ip-address

Not configured.

To delete the setting, use the **no set next-hop** *ip-address* command.

Specify an IP address in dotted decimal format.

Command Modes ROUTE-MAP

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series

Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

If the **set next-hop** command is configured, its configuration takes precedence over the **neighbor next-hop-self** command in the ROUTER BGP mode.

If you configure the **set next-hop** command with the interface's (either Loopback or physical) IP address, the software declares the route unreachable.

Related Commands

match ip next-hop	Redistribute routes that match the next-hop IP address.
neighbor next-hop-self	Configure the routers as the next hop for a BGP neighbor.

set origin

CES

Configure a filter to manipulate the BGP ORIGIN attribute.

Syntax

set origin {igp | egp | incomplete}

To delete an ORIGIN attribute setting, enter **no set origin**.

Parameters

egp	Enter the keyword egp to set routes originating from outside the local AS.
igp	Enter the keyword igp to set routes originating within the same AS.
incomplete	Enter the keyword incomplete to set routes with incomplete routing information.

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

set tag

CES

Configure a filter to specify a tag for redistributed routes.

Syntax

set tag tag-value

To delete a setting, enter **no set tag**.

Parameters

tag-value	Enter a number as the tag.
	Range: zero (0) to 4294967295.

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series
set automatic-tag	Compute the tag value of the route.

Related Commands

set automatic-tag	Compute the tag value of the route.
set level	Specify the OSPF area for route redistribution.
set metric	Specify the metric value assigned to redistributed routes.
set metric-type	Specify the route type assigned to redistributed routes.

set weight

CES

Configure a filter to add a non-RFC compliant attribute to the BGP route to assist with route selection.

Syntax

set weight weight

To delete a weight specification, use the **no set weight** weight command.

Parameters

weight	Enter a number as the weight to be used by the route meeting the route map specification.
	Routes with a higher weight are preferred when there are multiple routes to the same destination.
	Range: 0 to 65535
	Default: router-originated = 32768 ; all other routes = 0

Defaults

router-originated = 32768; all other routes = 0

Command Modes

ROUTE-MAP

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

If you do not use the set weight command, router-originated paths have a weight attribute of 32768 and all other paths have a weight attribute of zero.

show config

CES

Display the current route map configuration.

Syntax

show config

Command Modes

ROUTE-MAP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-13. Command Example: show config

```
FTOS(config-route-map)#show config
!
route-map hopper permit 10
FTOS(config-route-map)#
```

show route-map

CES

Display the current route map configurations.

Syntax

show route-map [map-name]

Parameters

map-name	(OPTIONAL) Enter the name of a configured route map, up to 140 characters.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-14. Command Example: show route-map

```
FTOS#show route-map
route-map firpo, permit, sequence 10
Match clauses:
Set clauses:
tag 34
FTOS#
```

Related Commands

|--|

AS-Path Commands

This feature is supported on E-Series only, as indicated by this character under each command heading:

The following commands configure AS-Path ACLs.

- ip as-path access-list
- permit
- show config
- show ip as-path-access-lists

deny

(E)Create a filter to drop routes that match the route's AS-PATH attribute. Use regular expressions to identify which routes are affected by the filter.

Syntax deny as-regular-expression

To remove this filter, use the **no deny** as-regular-expression command.

Parameters

as-regular-expression

Enter a regular expression to match BGP AS-PATH attributes.

Use one or a combination of the following:

- . = (period) matches on any single character, including white space
- * = (asterisk) matches on sequences in a pattern (zero or more sequences)
- + = (plus sign) matches on sequences in a pattern (one or more sequences)
- ? = (question mark) matches sequences in a pattern (0 or 1 sequences). You must enter an escape sequence (CNTL+v) prior to entering the ? regular expression.
- [] = (brackets) matches a range of single-character patterns.
- ^ = (caret) matches the beginning of the input string. (If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.)
- \$ = (dollar sign) matches the end of the output string.
- _ = (underscore) matches a comma (,), left brace ({), right brace (}), left parenthesis, right parenthesis, the beginning of the input string, the end of the input string, or a space.
- = (pipe) matches either character.

Defaults

Not configured

Command Modes

AS-PATH ACL

Usage Information

The regular expression must match part of the ASCII-text in the AS-PATH attribute of the BGP route.

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

ip as-path access-list

Enter the AS-PATH ACL mode and configure an access control list based on the BGP AS_PATH attribute.

Syntax ip as-path access-list as-path-name

To delete an AS-PATH ACL, use the **no ip as-path access-list** as-path-name command.

Parameters

as-path-name Enter the access-list name, up to 140 characters.

Defaults Not configured

Command Modes CONFIGURATION

Example Figure 6-15. Command Example: ip as-path access-list

FTOS(conf)#ip as-path access-list TestPath
FTOS(config-as-path)#

Usage Information Use the match as-path or neighbor filter-list commands to apply the AS-PATH ACL to BGP

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
pre-Version 6.1.1.0	Introduced for E-Series
match as-path	Match on routes contain a specific AS-PATH.
neighbor filter-list	Configure filter based on AS-PATH information.

Related Commands

[E]

permit

Create a filter to forward BGP routes that match the route's AS-PATH attributes. Use regular
expressions to identify which routes are affected by this filter.

Syntax permit as-regular-expression

To remove this filter, use the **no permit** as-regular-expression command.

as-regular-expression

Enter a regular expression to match BGP AS-PATH attributes.

Use one or a combination of the following:

- . = (period) matches on any single character, including white space
- * = (asterisk) matches on sequences in a pattern (zero or more sequences)
- + = (plus sign) matches on sequences in a pattern (one or more sequences)
- ? = (question mark) matches sequences in a pattern (0 or 1 sequences). You must enter an escape sequence (CNTL+v) prior to entering the ? regular expression.
- [] = (brackets) matches a range of single-character patterns.
- $^{\wedge}$ = (caret) matches the beginning of the input string. (If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.)
- \$ = (dollar sign) matches the end of the output string.
- _ = (underscore) matches a comma (,), left brace ({), right brace (}), left parenthesis, right parenthesis, the beginning of the input string, the end of the input string, or a space.
- | = (pipe) matches either character.

Defaults

Not configured

Command Modes

AS-PATH ACL

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

show config

Display the current configuration.

Syntax

show config

Command Mode

AS-PATH ACL

Command History

1			

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-16. Command Example: show config (AS-PATH ACL)

```
FTOS(config-as-path)#show config
ip as-path access-list snickers
deny .3
FTOS (config-as-path)#
```

show ip as-path-access-lists

Display the all AS-PATH access lists configured on the E-Series.

Syntax

show ip as-path-access-lists

Command Modes EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 6-17. Command Example: show ip as-path-access-lists

```
FTOS#show ip as-path-access-lists
ip as-path access-list 1
   permit ^$
   permit ^\(.*\)$
   deny .*
ip as-path access-list 91
   permit ^$
   deny .*
   permit ^\(.*\)$
FTOS#
```

IP Community List Commands

IP Community List commands are supported on E-Series only, as indicated by this character under each command heading: **E**

The commands in this section are.

- deny
- ip community-list
- permit
- show config
- show ip community-lists

deny

E Create a filter to drop routes matching a BGP COMMUNITY number.

Syntax

deny { community-number | local-AS | no-advertise | no-export | quote-regexp regular-expressions-list | regexp regular-expression}

To delete a description, enter **no deny** { community-number | local-AS | no-advertise | no-export | quote-regexp regular-expressions-list | regexp regular-expression}.

Parameters

community-number	Enter the community number in AA:NN format where AA is the AS number (2 bytes) and NN is a value specific to that autonomous system.
local-AS	Enter the keywords local-AS to drop all routes with the COMMUNITY attribute of NO_EXPORT_SUBCONFED.
	All routes with the NO_EXPORT_SUBCONFED (0xFFFFFF03) community attribute must not be advertised to external BGP peers.

no-advertise	Enter the keywords no-advertise to drop all routes containing the well-known community attribute of NO_ADVERTISE.
	All routes with the NO_ADVERTISE (0xFFFFFF02) community attribute must not be advertised to other BGP peers.
no-export	Enter the keywords no-export to drop all routes containing the well-known community attribute of NO_EXPORT.
	All routes with the NO_EXPORT (0xFFFFFF01) community attribute must not be advertised outside a BGP confederation boundary.
regexp regular-expression	Enter the keyword regexp followed by a regular expression. Use one or a combination of the following:
	• . = (period) matches on any single character, including white space
	• * = (asterisk) matches on sequences in a pattern (zero or more sequences)
	• += (plus sign) matches on sequences in a pattern (one or more sequences)
	• ? = (question mark) matches sequences in a pattern (0 or 1 sequences). You must enter an escape sequence (CNTL+v) prior to entering the ? regular expression.
	• [] = (brackets) matches a range of single-character patterns.
	• ^ = (caret) matches the beginning of the input string. (If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.)
	• \$ = (dollar sign) matches the end of the output string.
	• _ = (underscore) matches a comma (,), left brace ({), right brace (}), left parenthesis, right parenthesis, the beginning of the input string, the end of the input string, or a space.
	• = (pipe) matches either character.

Defaults

Not configured.

Command Modes

COMMUNITY-LIST

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

ip community-list

E Enter COMMUNITY-LIST mode and create an IP community-list for BGP.

Syntax ip community-list comm-list-name

To delete a community-list, use the **no ip community-list** comm-list-name command.

Parameters

Enter a text string as the name of the community-list, up to 140 characters. comm-list-name

Command Modes CONFIGURATION

Example Figure 6-18. Command Example: ip community-list

FTOS(conf)#ip community-list TestComList FTOS (config-community-list) #

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
pre-Version 6.1.1.0	Introduced for E-Series

permit

E Configure a filter to forward routes that match the route's COMMUNITY attribute.

Syntax permit {community-number | local-AS | no-advertise | no-export | quote-regexp regular-expressions-list | regexp regular-expression}

To remove this filter, use the **no permit** { community-number | local-AS | no-advertise | no-export | quote-regexp regular-expressions-list | regexp regular-expression} command.

Parameters

community-number	Enter the community number in AA:NN format where AA is the AS number (2 bytes) and NN is a value specific to that autonomous system.
local-AS	Enter the keywords local-AS to drop all routes with the COMMUNITY attribute of NO_EXPORT_SUBCONFED.
	All routes with the NO_EXPORT_SUBCONFED (0xFFFFFF03) community attribute must not be advertised to external BGP peers.
no-advertise	Enter the keywords no-advertise to drop all routes containing the well-known community attribute of NO_ADVERTISE.
	All routes with the NO_ADVERTISE (0xFFFFFF02) community attribute must not be advertised to other BGP peers.
no-export	Enter the keywords no-export to drop all routes containing the well-known community attribute of NO_EXPORT.
	All routes with the NO_EXPORT (0xFFFFFF01) community attribute must not be advertised outside a BGP confederation boundary.
regexp regular-expression	Enter the keyword regexp followed by a regular expression. Use one or a combination of the following:
	• . = (period) matches on any single character, including white space
	• * = (asterisk) matches on sequences in a pattern (zero or more sequences)
	• += (plus sign) matches on sequences in a pattern (one or more sequences)
	• ? = (question mark) matches sequences in a pattern (0 or 1 sequences). You must enter an escape sequence (CNTL+v) prior to entering the ? regular expression.
	• [] = (brackets) matches a range of single-character patterns.
	• ^ = (caret) matches the beginning of the input string. (If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.)
	• \$ = (dollar sign) matches the end of the output string.
	• _ = (underscore) matches a comma (,), left brace ({), right brace (}), left parenthesis, right parenthesis, the beginning of the input string, the end of the input string, or a space.
	• = (pipe) matches either character.

Defaults

Not configured

Command Modes

COMMUNITY-LIST

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

show config

Display the non-default information in the current configuration.

show config **Syntax**

Command Mode COMMUNITY-LIST

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

Figure 6-19. Command Example: show config (COMMUNITY-LIST **Example**

```
FTOS(config-std-community-list)#show config
ip community-list standard patches
deny 45:1
permit no-export
FTOS(config-std-community-list)#
```

show ip community-lists

 \mathbb{E} Display configured IP community lists in alphabetic order.

show ip community-lists [name] Syntax

Parameters

name	(OPTIONAL) Enter the name of the standard or extended IP community list, up to 140
	characters.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 6-20. Command Example: show ip community-lists

```
FTOS#show ip community-lists
ip community-list standard 1
deny 701:20
deny 702:20
deny 703:20
deny 705:20
deny 705:20
deny 705:20
deny 705:20
deny 705:21
deny 701:112
deny 702:112
deny 702:112
deny 703:112
deny 704:112
deny 705:112
deny 705:666
deny 702:666
deny 702:666
deny 703:666
deny 704:666
deny 705:666
deny 705:666
deny 705:666
fros#
```

Border Gateway Protocol IPv4(BGPv4)

Overview

BGPv4 is supported as shown in the following table.

FTOS version	Platform support	
8.3.3.1	S60	S60
8.1.1.0	E-Series ExaScale	Ex
7.8.1.0	S-Series	S
7.7.1.0.	C-Series	C
pre-7.7.1.0	E-Series TeraScale	ET

For detailed information on configuring BGP, refer to the BGP chapter in the FTOS Configuration Guide.

This chapter contains the following sections:

- **BGPv4** Commands
- **MBGP Commands**
- BGP Extended Communities (RFC 4360)

BGPv4 Commands

Border Gateway Protocol (BGP) is an external gateway protocol that transmits interdomain routing information within and between Autonomous Systems (AS). BGP version 4 (BGPv4) supports Classless InterDomain Routing (CIDR) and the aggregation of routes and AS paths. Basically, two routers (called neighbors or peers) exchange information including full routing tables and periodically send messages to update those routing tables.



Note: FTOS Version 7.7.1 supports 2-Byte (16-bit) and 4-Byte (32-bit) format for Autonomous System Numbers (ASNs), where the 2-Byte format is 1-65535, the 4-Byte format is 1-4294967295.

Note: FTOS Version 8.3.1.0 supports Dotted format as well as the Traditional Plain format for AS Numbers. The dot format is displayed when using the **show ip bgp** commands. To determine the comparable dot format for an ASN from a traditional format, use **ASN/65536**. **ASN%65536**.

For more information about using the 2 or 4-Byte format, refer to the FTOS Configuration Guide.

The following commands enable you to configure and enable BGP.

- address-family
- aggregate-address
- bgp always-compare-med
- bgp asnotation
- bgp bestpath as-path ignore
- bgp bestpath med confed
- bgp bestpath med missing-as-best
- bgp bestpath router-id ignore
- bgp client-to-client reflection
- bgp cluster-id
- bgp confederation identifier
- bgp confederation peers
- bgp dampening
- bgp default local-preference
- bgp enforce-first-as
- bgp fast-external-fallover
- bgp four-octet-as-support
- bgp graceful-restart
- bgp log-neighbor-changes
- bgp non-deterministic-med
- bgp recursive-bgp-next-hop
- bgp regex-eval-optz-disable
- bgp router-id
- bgp soft-reconfig-backup
- capture bgp-pdu neighbor
- capture bgp-pdu max-buffer-size
- clear ip bgp
- clear ip bgp dampening
- clear ip bgp flap-statistics

- debug ip bgp
- debug ip bgp dampening
- debug ip bgp events
- debug ip bgp keepalives
- debug ip bgp notifications
- debug ip bgp soft-reconfiguration
- debug ip bgp updates
- default-metric
- description
- distance bgp
- maximum-paths
- neighbor activate
- neighbor advertisement-interval
- neighbor advertisement-start
- neighbor allowas-in
- neighbor default-originate
- neighbor description
- neighbor distribute-list
- neighbor ebgp-multihop
- neighbor fall-over
- neighbor filter-list
- neighbor graceful-restart
- neighbor local-as
- neighbor maximum-prefix
- neighbor next-hop-self
- neighbor password
- neighbor peer-group (assigning peers)
- neighbor peer-group (creating group)
- neighbor peer-group passive
- neighbor remote-as
- neighbor remove-private-as
- neighbor route-map
- neighbor route-reflector-client
- neighbor send-community
- neighbor shutdown
- neighbor soft-reconfiguration inbound
- neighbor timers
- neighbor update-source
- neighbor weight
- network
- network backdoor
- redistribute
- redistribute isis
- redistribute ospf
- router bgp
- show capture bgp-pdu neighbor

- show config
- show ip bgp
- show ip bgp cluster-list
- show ip bgp community
- show ip bgp community-list
- show ip bgp dampened-paths
- show ip bgp detail
- show ip bgp extcommunity-list
- show ip bgp filter-list
- show ip bgp flap-statistics
- show ip bgp inconsistent-as
- show ip bgp neighbors
- show ip bgp next-hop
- show ip bgp paths
- show ip bgp paths as-path
- show ip bgp paths community
- show ip bgp peer-group
- show ip bgp regexp
- show ip bgp summary
- show running-config bgp
- timers bgp

address-family

[C] [E] S Enable the IPv4 multicast or the IPv6 address family.

Syntax address-family [ipv4 multicast| ipv6unicast]

Parameters

ipv4 multicast	Enter BGPv4 multicast mode.
ipv6 unicast	Enter BGPv6 mode.

Defaults

Not configured.

Command Modes

ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 6.5.1.0	Introduced	

aggregate-address

CES

Summarize a range of prefixes to minimize the number of entries in the routing table.

Syntax

aggregate-address ip-address mask [advertise-map map-name] [as-set] [attribute-map map-name] [summary-only] [suppress-map map-name]

ip-address mask	Enter the IP address and mask of the route to be the aggregate address. Enter the IP address in dotted decimal format (A.B.C.D) and mask in /prefix format ($/x$).
advertise-map map-name	(OPTIONAL) Enter the keywords advertise-map followed by the name of a configured route map to set filters for advertising an aggregate route.
as-set	(OPTIONAL) Enter the keyword as-set to generate path attribute information and include it in the aggregate. AS_SET includes AS_PATH and community information from the routes included in the aggregated route.
attribute-map map-name	(OPTIONAL) Enter the keywords attribute-map followed by the name of a configured route map to modify attributes of the aggregate, excluding AS_PATH and NEXT_HOP attributes.
summary-only	(OPTIONAL) Enter the keyword summary-only to advertise only the aggregate address. Specific routes will not be advertised.
suppress-map map-name	(OPTIONAL) Enter the keywords suppress-map followed by the name of a configured route map to identify which more-specific routes in the aggregate are suppressed.

Defaults

Not configured.

Command Modes

ROUTER BGP ADDRESS FAMILY

ROUTER BGP ADDRESS FAMILY IPv6

Usage Information

At least one of the routes included in the aggregate address must be in the BGP routing table for the configured aggregate to become active.

Do not add the **as-set** parameter to the aggregate, if routes within the aggregate are constantly changing as the aggregate will flap to keep track of the changes in the AS_PATH.

In route maps used in the **suppress-map** parameter, routes meeting the **deny** clause are not suppress; in other words, they are allowed. The opposite is true: routes meeting the **permit** clause are suppressed.

If the route is injected via the network command, that route will still appear in the routing table if the summary-only parameter is configured in the aggregate-address command.

The summary-only parameter suppresses all advertisements. If you want to suppress advertisements to only specific neighbors, use the neighbor distribute-list command.

In the show ip bgp command, aggregates contain an 'a' in the first column and routes suppressed by the aggregate contain an 's' in the first column.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp always-compare-med

Enables you to enable comparison of the MULTI_EXIT_DISC (MED) attributes in the paths from

different external ASs.

Syntax bgp always-compare-med

Version 8.3.3.1

To disable comparison of MED, enter **no bgp always-compare-med**.

Defaults Disabled (that is, the software only compares MEDs from neighbors within the same AS).

Command Modes ROUTER BGP

Usage Any update without a MED attribute is the least preferred route

Information

If you enable this command, use the clear ip bgp * command to recompute the best path.

Command

Version 8.2.1.0 Introduced command

Version 7.7.1.0 Introduced support on C-Series

bgp asnotation

History

[C] [E] [S] Enables you to implement a method for AS Number representation in the CLI.

Introduced on the S60.

Syntax bgp asnotation [asplain | asdot+ | asdot]

To disable a dot or dot+ representation and return to ASPLAIN, enter **no bgp asnotation**.

Defaults asplain

Command Modes ROUTER BGP

Usage You must enable bgp four-octet-as-support before enabling this feature. If you disable four-octect-support after using dot or dot+ format, the AS Numbers revert to asplain text.

When you apply an asnotation, it is reflected in the running-configuration. If you change the notation

type, the running-config is updated dynamically and the new notation is shown.

Related Commands

Command

History

bgp four-octet-as-support Enable 4-byte support for the BGP process

Version 8 3 3 1 Introduced on the S60

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced Dynamic Application of AS Notation changes

Version 8.2.1.0 Introduced

Example Figure 7-1. Dynamic changes of the bgp asnotation command in the running config

```
FTOS(conf)#router bgp 1
FTOS(conf-router_bgp)#bgp asnotation asdot
FTOS(conf-router bgp)#ex
FTOS(conf)#do show run | grep bgp
router bgp 1
bqp four-octet-as-support
bgp asnotation asdot
FTOS(conf) #router bgp 1
FTOS(conf-router bgp) #bgp asnotation asdot+
FTOS(conf-router bgp)#ex
FTOS(conf)#do show run | grep bgp
router bqp 1
bgp four-octet-as-support
bgp asnotation asdot+
FTOS(conf) #router bgp 1
FTOS(conf-router bgp) #bgp asnotation asplain
FTOS(conf-router_bgp)#ex
FTOS(conf)#do show run | grep bgp
router bgp 1
bgp four-octet-as-support
FTOS(conf)#
```

bgp bestpath as-path ignore

[C][E][S]Ignore the AS PATH in BGP best path calculations.

Syntax bgp bestpath as-path ignore

To return to the default, enter **no bgp bestpath as-path ignore**.

Defaults Disabled (that is, the software considers the AS_PATH when choosing a route as best).

Command Modes ROUTER BGP

> Usage Information

If you enable this command, use the clear ip bgp * command to recompute the best path.

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

bgp bestpath med confed

Enable MULTI_EXIT_DISC (MED) attribute comparison on paths learned from BGP confederations.

Syntax bgp bestpath med confed To disable MED comparison on BGP confederation paths, enter no bgp bestpath med confed.

Defaults Disabled

Command Modes ROUTER BGP

Usage Information The software compares the MEDs only if the path contains no external autonomous system numbers. If you enable this command, use the clear ip bgp * command to recompute the best path.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp bestpath med missing-as-best

During path selection, indicate preference to paths with missing MED (MULTI_EXIT_DISC) over those paths with an advertised MED attribute.

Syntax bgp bestpath med missing-as-best

To return to the default selection, use the **no bgp bestpath med missing-as-best** command.

Defaults Disabled

Command Modes ROUTER BGP

Usage Information The MED is a 4-byte unsigned integer value and the default behavior is to assume a missing MED as 4294967295. This command causes a missing MED to be treated as 0. During the path selection, paths with a lower MED are preferred over those with a higher MED.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 6.3.1.0	Introduced

bgp bestpath router-id ignore

Do not compare router-id information for external paths during best path selection.

Syntax bgp bestpath router-id ignore

To return to the default selection, use the **no bgp bestpath router-id ignore** command.

Defaults Disabled

Command Modes ROUTER BGP

Usage Configuring this option will retain the current best-path. When sessions are subsequently reset, the oldest received path will be chosen as the best-path.

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced

bgp client-to-client reflection

Enables you to enable route reflection between clients in a cluster.

Syntax bgp client-to-client reflection

bgp cluster-id

Version 7.8.1.0

Version 7.7.1.0

To disable client-to-client reflection, enter **no bgp client-to-client reflection**.

Defaults Enabled when a route reflector is configured.

Command Modes ROUTER BGP

> Usage Route reflection to clients is not necessary if all client routers are fully meshed. Information

Related Commands

> Command History

neighbor route-reflector-client		Configure a route reflector and clients.
Version 8.3.3.1	Introduced of	on the S60.

Assign ID to a BGP cluster with two or more route reflectors.

bgp cluster-id Assign a cluster ID to a BGP cluster with more than one route reflector.

Introduced support on S-Series

Introduced support on C-Series

Syntax bgp cluster-id { *ip-address* | *number*}

To delete a cluster ID, use the **no bgp cluster-id** { *ip-address* | *number*} command.

Parameters

ip-address	Enter an IP address as the route reflector cluster ID.
number	Enter a route reflector cluster ID as a number from 1 to 4294967295.

Defaults Not configured.

Command Modes ROUTER BGP

> Usage Information

When a BGP cluster contains only one route reflector, the cluster ID is the route reflector's router ID. For redundancy, a BGP cluster may contain two or more route reflectors and you assign a cluster ID with the bgp cluster-id command. Without a cluster ID, the route reflector cannot recognize route updates from the other route reflectors within the cluster.

The default format for displaying the cluster-id is dotted decimal, but if you enter the cluster-id as an integer, it will be displayed as an integer.

Related Commands

bgp client-to-client reflection	Enable route reflection between route reflector and clients.	
neighbor route-reflector-client	Configure a route reflector and clients.	
show ip bgp cluster-list	View paths with a cluster ID.	
Version 8.3.3.1 Introduced of	on the S60.	

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp confederation identifier



Configure an identifier for a BGP confederation.

Syntax

bgp confederation identifier as-number

To delete a BGP confederation identifier, use the **no bgp confederation identifier** as-number command.

Parameters

as-number	Enter the AS number.	
	Range: 0-65535 (2-Byte) or	
	1-4294967295 (4-Byte) <i>or</i>	
	0.1-65535.65535 (Dotted format)	

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

You must configure your system to accept 4-Byte formats before entering a 4-Byte AS Number. All the routers in the Confederation must be 4 or 2-Byte identified routers. You cannot mix them.

The autonomous systems configured in this command are visible to the EBGP neighbors. Each autonomous system is fully meshed and contains a few connections to other autonomous systems. The next hop, MED, and local preference information is preserved throughout the confederation.

FTOS accepts confederation EBGP peers without a LOCAL_PREF attribute. The software sends AS_CONFED_SET and accepts AS_CONFED_SET and AS_CONF_SEQ.

Related Commands

bgp four-octet-as-	support Enable 4-Byte support for the BGP process.
Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
	Added support for 4-Byte format

Command History

bgp confederation peers

CES

Specify the Autonomous Systems (ASs) that belong to the BGP confederation.

Syntax

bgp confederation peers as-number [...as-number]

To return to the default, enter **no bgp confederation peers**.

Parameters

as-number	Enter the AS number.
	Range: 0-65535 (2-Byte) or
	1-4294967295 (4-Byte) <i>or</i>
	0.1-65535.65535 (Dotted format)
as-number	(OPTIONAL) Enter up to 16 confederation numbers.
	Range: 0-65535 (2-Byte) <i>or</i>
	1-4294967295 (4-Byte) <i>or</i>
	0.1-65535.65535 (Dotted format)

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

All the routers in the Confederation must be 4 or 2 byte identified routers. You cannot mix them.

The Autonomous Systems configured in this command are visible to the EBGP neighbors. Each Autonomous System is fully meshed and contains a few connections to other Autonomous Systems.

After specifying autonomous systems numbers for the BGP confederation, recycle the peers to update their configuration.

Related **Commands**

bgp confederation identifier	Configure a confederation ID.
bgp four-octet-as-support	Enable 4-byte support for the BGP process.

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series Added support for 4-byte format

bgp dampening

Enable BGP route dampening and configure the dampening parameters.

Syntax

bgp dampening [half-life reuse suppress max-suppress-time] [route-map map-name]

To disable route dampening, use the **no bgp dampening** [half-life reuse suppress max-suppress-time] [route-map map-name] command.

half-life	(OPTIONAL) Enter the number of minutes after which the Penalty is decreased. After the router assigns a Penalty of 1024 to a route, the Penalty is
	decreased by half after the half-life period expires.
	Range: 1 to 45.
	Default: 15 minutes
reuse	(OPTIONAL) Enter a number as the reuse value, which is compared to the flapping route's Penalty value. If the Penalty value is less than the reuse value, the flapping route is once again advertised (or no longer suppressed). Range: 1 to 20000.
	Default: 750
suppress	(OPTIONAL) Enter a number as the suppress value, which is compared to the flapping route's Penalty value. If the Penalty value is greater than the suppress value, the flapping route is no longer advertised (that is, it is suppressed).
	Range: 1 to 20000.
	Default: 2000
max-suppress-time	(OPTIONAL) Enter the maximum number of minutes a route can be suppressed. The default is four times the half-life value.
	Range: 1 to 255.
	Default: 60 minutes.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.
	Only match commands in the configured route map are supported.

Defaults

Disabled.

Command Modes

ROUTER-BGP-ADDRESS FAMILY

Usage Information

If you enter bgp dampening, the default values for half-life, reuse, suppress, and max-suppress-time are applied. The parameters are position-dependent, therefore, if you configure one parameter, you must configure the parameters in the order they appear in the CLI.

Related Commands

Command History

show ip bgp dampened-paths		View the BGP paths	S	
Version 8.3.3.1	Introduced o	n the S60.		
Version 7.8.1.0	Introduced s	upport on S-Series		
Version 7.7.1.0	Introduced si	upport on C-Series		

bgp default local-preference

CES

Change the default local preference value for routes exchanged between internal BGP peers.

Syntax

bgp default local-preference value

To return to the default value, enter **no bgp default local-preference**.

value	Enter a number to assign to routes as the degree of preference for those routes. When routes are compared, the higher the degree of preference or local preference value, the more the route is preferred.
	Range: 0 to 4294967295
	Default: 100

Defaults 100

Command Modes ROUTER BGP

> Usage Information

The bgp default local-preference command setting is applied by all routers within the AS. To set the local preference for a specific route, use the set local-preference command in the ROUTE-MAP mode.

Related **Commands**

Command **History**

set local-preference	Assign a local preference value for a specific route.	
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced on C-Series	

bgp enforce-first-as

CES

Disable (or enable) enforce-first-as check for updates received from EBGP peers.

Syntax bgp enforce-first-as

To turn off the default, use the **no bgp enforce-first-as** command.

Defaults Enabled

Command Modes ROUTER BGP

> Usage Information

This is enabled by default, that is for all updates received from EBGP peers, BGP ensures that the first AS of the first AS segment is always the AS of the peer. If not, the update is dropped and a counter is incremented. Use the show ip bgp neighbors command to view the "failed enforce-first-as check counter.

If enforce-first-as is disabled, it can be viewed via the show ip protocols command.

Related Commands

Command History

show ip bgp neighb	ors View the information exchanged by BGP neighbors
show ip protocols	View Information on routing protocols.
Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support for C-Series
Version 7.4.1.0	Introduced

bgp fast-external-fallover

Enable the fast external fallover feature, which immediately resets the BGP session if a link to a

directly connected external peer fails.

Syntax bgp fast-external-fallover

To disable fast external fallover, enter **no bgp fast-external-fallover**.

Defaults Enabled.

Command Modes ROUTER BGP

Usage Information The bgp fast-external-fallover command appears in the show config command output.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support for C-Series

bgp four-octet-as-support

CES Enable 4-byte support for the BGP process.

Syntax bgp four-octet-as-support

To disable fast external fallover, enter **no bgp four-octet-as-support**.

Defaults Disabled (supports 2-Byte format)

Command Modes ROUTER BGP

Usage Information Routers supporting 4-Byte ASNs advertise that function in the OPEN message. The behavior of a 4-Byte router will be slightly different depending on whether it is speaking to a 2-Byte router or a

4-Byte router.

When creating Confederations, all the routers in the Confederation must be 4 or 2 byte identified routers. You cannot mix them.

Where the 2-Byte format is 1-65535, the 4-Byte format is 1-4294967295. Both formats are accepted, and the advertisements will reflect the entered format.

For more information about using the 2 or 4-Byte format, refer to the FTOS Configuration Guide.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced command
	Introduced support on C-Series

bgp graceful-restart

Enable graceful restart on a BGP neighbor, a BGP node, or designate a local router to support graceful restart as a receiver only.

Syntax

bgp graceful-restart [restart-time seconds] [stale-path-time seconds] [role receiver-only]

To return to the default, enter the **no bgp graceful-restart** command.

Parameters

restart-time seconds	Enter the keyword restart-time followed by the maximum number of seconds needed to restart and bring-up all the peers.
	Range: 1 to 3600 seconds
	Default: 120 seconds
stale-path-time seconds	Enter the keyword stale-path-time followed by the maximum number of seconds to wait before restarting a peer's stale paths. Default: 360 seconds.
role receiver-only	Enter the keyword role receiver-only to designate the local router to support graceful restart as a receiver only.

Defaults

as above

Command Modes

ROUTER-BGP

Usage Information

This feature is advertised to BGP neighbors through a capability advertisement. In receiver only mode, BGP saves the advertised routes of peers that support this capability when they restart.

BGP graceful restart is active only when the neighbor becomes established. Otherwise it is disabled. Graceful-restart applies to all neighbors with established adjacency.

Command History

Version 8.3.3.4	Introduced on S60
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp log-neighbor-changes

CES

Enable logging of BGP neighbor resets.

Syntax

bgp log-neighbor-changes

To disable logging, enter **no bgp log-neighbor-changes**.

Defaults

Enabled.

Command Modes

ROUTER BGP

Usage Information

Use the show logging command in the EXEC mode to view BGP neighbor resets.

The bgp log-neighbor-changes command appears in the show config command output.

Related Commands

View logging settings and system messages logged to the system. show logging

Command History

Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

bgp non-deterministic-med

C E S Compare MEDs of paths from different Autonomous Systems.

Syntax bgp non-deterministic-med

To return to the default, enter **no bgp non-deterministic-med**.

Defaults Disabled (that is, paths/routes for the same destination but from different ASs will not have their MEDs

compared).

Command Modes ROUTER BGP

Usage Information In non-deterministic mode, paths are compared in the order in which they arrive. This method can lead to FTOS choosing different best paths from a set of paths, depending on the order in which they are received from the neighbors since MED may or may not get compared between adjacent paths. In deterministic mode (**no bgp non-deterministic-med**), FTOS compares MED between adjacent paths within an AS group since all paths in the AS group are from the same AS.

When you change the path selection from deterministic to non-deterministic, the path selection for existing paths remains deterministic until you enter clear ip bgp command to clear existing paths.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp recursive-bgp-next-hop

CES Enable next-hop resolution through other routes learned by BGP.

Syntax bgp recursive-bgp-next-hop

To disable next-hop resolution, use the **no bgp recursive-bgp-next-hop** command.

Defaults Enabled

Command Modes ROUTER BGP

Usage Information This command is a *knob* to disable BGP next-hop resolution via BGP learned routes. During the next-hop resolution, only the *first* route that the next-hop resolves through is verified for the route's protocol source and is checked if the route is learned from BGP or not.

The **clear ip bgp** command is required for this command to take effect and to keep the BGP database consistent. Execute the **clear ip bgp** command right after executing this command.

Related Commands

clear ip bgp	Description.	
--------------	--------------	--

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.2.1.0	Introduced

bgp regex-eval-optz-disable

CES Disables the Regex Performance engine that optimizes complex regular expression with BGP.

Syntax bgp regex-eval-optz-disable

To re-enable optimization engine, use the **no bgp regex-eval-optz-disable** command.

Defaults Enabled by default

Command Modes ROUTER BGP (conf-router_bgp)

Usage Information

BGP uses regular expressions (regex) to filter route information. In particular, the use of regular expressions to filter routes based on AS-PATHs and communities is quite common. In a large scale configuration, filtering millions of routes based on regular expressions can be quite CPU intensive, as a regular expression evaluation involves generation and evaluation of complex finite state machines.

BGP policies, containing regular expressions to match as-path and communities, tend to use a lot of CPU processing time, which in turn affects the BGP routing convergence. Additionally, the show bgp commands, which are filtered through regular expressions, use up CPU cycles particularly with large databases. The Regex Engine Performance Enhancement feature optimizes the CPU usage by caching and reusing regular expression evaluation results. This caching and reuse may be at the expensive of RP1 processor memory.

Related Commands

Со	mm	and	
	His	tory	

show ip protocols	View information on all routing protocols enabled and active on the E-Series.	
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
Version 7.6.1.0	Introduced	

Example Figure 7-2. Command Example: no bgp regex-eval-optz-disable

FTOS(conf-router_bgp)#no bgp regex-eval-optz-disable FTOS(conf-router bgp)#do show ip protocols
Routing Protocol is "ospf 22222"
Router ID is 2.2.2.2 Routing for Networks Area 51 10.10.10.0/00 Routing Protocol is "bgp 1" Cluster Id is set to 10.10.10.0 Router Id is set to 10.10.10.0 Fast-external-fallover enabled Regular expression evaluation optimization enabled Capable of ROUTE REFRESH For Address Family IPv4 Unicast BGP table version is 0, main routing table version 0 Distance: external 20 internal 200 local 200 FTOS(conf-router bgp)#

bgp router-id

CES

Assign a user-given ID to a BGP router.

Syntax bgp router-id ip-address

To delete a user-assigned IP address, enter **no bgp router-id**.

Parameters

ip-address Enter an IP address in dotted decimal format to reset only that BGP neighbor.

Defaults

The router ID is the highest IP address of the Loopback interface or, if no Loopback interfaces are configured, the highest IP address of a physical interface on the router.

Command Modes ROUTER BGP

Usage Information Peering sessions are reset when you change the router ID of a BGP router.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp soft-reconfig-backup

CES

Use this command *only* when route-refresh is *not* negotiated to avoid the peer from resending messages.

Syntax bgp soft-reconfig-backup

To return to the default setting, use the **no bgp soft-reconfig-backup** command.

Defaults Off

Command Modes ROUTER BGP

Usage Information

When soft-reconfiguration is enabled for a neighbor and the **clear ip bgp soft in** is executed, the update database stored in the router is replayed and updates are reevaluated. With this command, the replay and update process is triggered only if route-refresh request is not negotiated with the peer. If the request is indeed negotiated (upon execution of clear ip bgp soft in), then BGP sends a route-refresh request to the neighbor and receives all of the peer's updates.



Note: This command is supported in BGP Router Configuration mode for IPv4 Unicast address only.

Related **Commands**

Command **History**

clear ip bgp soft in	Activate inbound policies without resetting the BGP TCP session.	
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
Version 7.2.1.0	Introduced	

capture bgp-pdu neighbor

Enable capture of an IPv4 BGP neighbor packet.

Syntax

capture bgp-pdu neighbor ipv4-address direction {both | rx | tx}

To disable capture of the IPv4 BGP neighbor packet, use the no capture bgp-pdu neighbor ipv4-address command.

Parameters

ipv4-address	Enter the IPv4 address of the target BGP neighbor.
direction {both rx tx}	Enter the keyword direction and a direction— either rx for inbound, tx for outbound, or both .

Defaults

Not configured.

Command Modes

EXEC Privilege

capture bgp-pdu max-buffer-size

Related Commands

show capture bgp-pdu neighbor	Display BGP packet capture information	
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
Version 7.5.1.0	Introduced	

Specify a size for the capture buffer.

Command History

capture bgp-pdu max-buffer-size

Set the size of the BGP packet capture buffer. This buffer size pertains to both IPv4 and IPv6 addresses.

Syntax capture bgp-pdu max-buffer-size 100-102400000

Parameters 100-102400000 Enter a size for the capture buffer.

Defaults 40960000 bytes.

Command Modes EXEC Privilege

Related Commands

capture bgp-pdu neighbor	Enable capture of an IPv4 BGP neighbor packet.
capture bgp-pdu neighbor	Enable capture of an IPv6 BGP neighbor packet.
show capture bgp-pdu neighbor	Display BGP packet capture information for an IPv6 address on the E-Series.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.5.1.0	Introduced

clear ip bgp

CES

Reset BGP sessions on the E-Series. The soft parameter (BGP Soft Reconfiguration) clears the policies without resetting the TCP connection.

Syntax clear ip bgp * | as-number | ip-address [flap-statistics | soft [in | out]]

Parameters

Enter an asterisk (*) to reset all BGP sessions.
Enter the AS number to reset all neighbors belonging to that AS.
Range: 0-65535 (2-Byte) or
1-4294967295 (4-Byte) <i>or</i>
0.1-65535.65535 (Dotted format)
Enter an IP address in dotted decimal format to reset all prefixes from that neighbor.
(OPTIONAL) Enter the keyword flap-statistics to reset the flap statistics on all prefixes from that neighbor.
(OPTIONAL) Enter the keyword soft to configure and activate policies without resetting the BGP TCP session, that is, BGP Soft Reconfiguration.
Note: If you enter clear ip bgp <i>ip-address</i> soft , both inbound and outbound policies are reset.
(OPTIONAL) Enter the keyword in to activate only inbound policies.
(OPTIONAL) Enter the keyword out to activate only outbound policies.

Command Modes

EXEC Privilege

Related **Commands**

Command **History**

bgp recursive-bgp-	next-hop	Disable next-hop resolution through other routes learned by BGP
bgp soft-reconfig-backup		Turn on BGP Soft Reconfiguration
Version 8.3.3.1	Introduc	ed on the S60.
Version 7.8.1.0	Introduced support on S-Series	

clear ip bgp peer-group

Reset a peer-group's BGP sessions.

Version 7.7.1.0

Version 6.5.1.0

Syntax clear ip bgp peer-group peer-group-name

Parameters peer-group-name Enter the peer group name to reset the BGP sessions within that peer group.

Expanded to include the as-number option

Introduced support on C-Series

Command Modes EXEC Privilege

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

clear ip bgp dampening

CES Clear information on route dampening and return suppressed route to active state.

Syntax clear ip bgp dampening [ip-address mask]

Parameters ip-address mask (OPTIONAL) Enter an IP address in dotted decimal format and the prefix mask in slash format (/x) to clear dampening information only that BGP neighbor.

Command Modes EXEC Privilege

> **Usage** After you enter this command, the software deletes history routes and returns suppressed routes to Information active state.

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

clear ip bgp flap-statistics

Clear BGP flap statistics, which includes number of flaps and the time of the last flap.

Syntax

clear ip bgp flap-statistics [ip-address mask | **filter-list** as-path-name | **regexp** regular-expression]

Parameters

ip-address mask	(OPTIONAL) Enter an IP address in dotted decimal format and the prefix mask in slash format (/x) to reset only that prefix.		
filter-list as-path-name	(OPTIONAL) Enter the keyword filter-list followed by the name of a configured AS-PATH list.		
regexp regular-expression	(OPTIONAL) Enter the keyword regexp followed by regular expressions. Use one or a combination of the following:		
	• .= (period) any single character (including a white space)		
	• * = (asterisk) the sequences in a pattern (0 or more sequences)		
	• += (plus) the sequences in a pattern (1 or more sequences)		
	• ? = (question mark) sequences in a pattern (either 0 or 1 sequences). You must enter an escape sequence (CTRL+v) prior to entering the ? regular expression.		
	• [] = (brackets) a range of single-character patterns.		
	• () = (parenthesis) groups a series of pattern elements to a single element		
	• { } = (braces) minimum and the maximum match count		
	 ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified. 		
	• \$ = (dollar sign) the end of the output string.		

Command Modes

EXEC Privilege

Usage Information

If you enter clear ip bgp flap-statistics without any parameters, all statistics are cleared.

Related Commands

show debugging		View enabled debugging operations.
show ip bgp flap-s	tatistics	View BGP flap statistics.
undebug all		Disable all debugging operations.
Version 8.3.3.1	Introduced on	the S60.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp

Display all information on BGP, including BGP events, keepalives, notifications, and updates.

Syntax debug ip bgp [ip-address | peer-group peer-group-name] [in | out]

To disable all BGP debugging, enter **no debug ip bgp**.

ip-address	Enter the IP address of the neighbor in dotted decimal format.	
peer-group peer-group-name	Enter the keyword peer-group followed by the name of the peer group.	
in	(OPTIONAL) Enter the keyword in to view only information on inbound BGP routes.	
out	(OPTIONAL) Enter the keyword out to view only information on outbound BGP routes.	

Command Modes

EXEC Privilege

Usage Information

To view information on both incoming and outgoing routes, do not include the in and out parameters in the debugging command. The in and out parameters cancel each other; for example, if you enter debug ip bgp in and then enter debug ip bgp out, you will not see information on the incoming routes.

Entering a no debug ip bgp command removes all configured debug commands for BGP.

Related Commands

debug ip bgp events	View information about BGP events.
debug ip bgp keepalives	View information about BGP keepalives.
debug ip bgp notifications	View information about BGP notifications.
debug ip bgp updates	View information about BGP updates.
show debugging	View enabled debugging operations.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp dampening

CES

Display information on routes being dampened.

Syntax

debug ip bgp dampening [in | out]

To disable debugging, enter **no debug ip bgp dampening**.

Parameters

in	(OPTIONAL) Enter the keyword in to view only inbound dampened routes.
out	(OPTIONAL) Enter the keyword out to view only outbound dampened routes.

Command Modes

EXEC Privilege

Usage Information

Enter no debug ip bgp command to remove all configured debug commands for BGP.

Related **Commands**

show debugging	View enabled debugging operations.
show ip bgp dampened-paths	View BGP dampened routes.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp events

Display information on local BGP state changes and other BGP events.

Syntax debug ip bgp [ip-address | peer-group peer-group-name] events [in | out]

To disable debugging, use the **no debug ip bgp** [*ip-address* | **peer-group** *peer-group-name*] **events** command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group peer-group-name	(OPTIONAL) Enter the keyword peer-group followed by the name of the peer group.
in	(OPTIONAL) Enter the keyword in to view only events on inbound BGP messages.
out	(OPTIONAL) Enter the keyword out to view only events on outbound BGP messages.

Command Modes

EXEC Privilege

Usage Information

Enter no debug ip bgp command to remove all configured debug commands for BGP.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp keepalives

CES

Display information about BGP keepalive messages.

Syntax

debug ip bgp [ip-address | peer-group peer-group-name] keepalives [in | out]

To disable debugging, use the **no debug ip bgp** [ip-address | peer-group peer-group-name] keepalives [$in \mid out$] command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group peer-group-name	(OPTIONAL) Enter the keyword peer-group followed by the name of the peer group.
in	(OPTIONAL) Enter the keyword in to view only inbound keepalive messages.
out	(OPTIONAL) Enter the keyword out to view only outbound keepalive messages.

Command Modes

EXEC Privilege

Usage Information Enter no debug ip bgp command to remove all configured debug commands for BGP.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp notifications

CESEnables you to view information about BGP notifications received from neighbors.

Syntax debug ip bgp [ip-address | peer-group peer-group-name] notifications [in | out]

> To disable debugging, use the **no debug ip bgp** [ip-address | **peer-group** peer-group-name] notifications [in | out] command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group peer-group-name	(OPTIONAL) Enter the keyword peer-group followed by the name of the peer group.
in	(OPTIONAL) Enter the keyword in to view BGP notifications received from neighbors.
out	(OPTIONAL) Enter the keyword out to view BGP notifications sent to neighbors.

Command Modes

EXEC Privilege

Usage Information Enter no debug ip bgp command to remove all configured debug commands for BGP.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

debug ip bgp soft-reconfiguration

CES

Enable soft-reconfiguration debug.

Syntax

debug ip bgp { *ip-address* | *peer-group-name*} **soft-reconfiguration**

To disable, use the **no debug ip bgp** { *ip-address* | *peer-group-name*} **soft-reconfiguration** command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group to disable or enable all routers within the peer group.

Defaults

Disabled

Command Modes

EXEC Privilege

Usage Information

This command turns on BGP soft-reconfiguration inbound debugging. If no neighbor is specified, debug is turned on for all neighbors.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.2.1.0	Introduced

debug ip bgp updates

CES

Enables you to view information about BGP updates.

Syntax

debug ip bgp updates [in | out | prefix-list prefix-list-name]

To disable debugging, use the **no debug ip bgp** [*ip-address* | **peer-group** *peer-group-name*] **updates** [**in** | **out**] command.

Parameters

in	(OPTIONAL) Enter the keyword in to view only BGP updates received from neighbors.
out	(OPTIONAL) Enter the keyword out to view only BGP updates sent to neighbors.
prefix-list prefix-list-name	(OPTIONAL) Enter the keyword prefix-list followed by the name of an established prefix list. If the prefix list is not configured, the default is <i>permit</i> (to allow all routes).
ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group to disable or enable all routers within the peer group.

Command Modes

EXEC Privilege

Usage Information

Enter no debug ip bgp command to remove all configured debug commands for BGP.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1	Introduced support on C-Series

default-metric

CES

Enables you to change the metrics of redistributed routes to locally originated routes. Use this command with the redistribute command.

Syntax

default-metric number

To return to the default setting, enter **no default-metric**.

number	Enter a number as the metric to be assigned to routes from other protocols.
	Range: 1 to 4294967295.

Defaults

Command Modes ROUTER BGP

> Usage Information

The default-metric command in BGP sets the value of the BGP MULTI_EXIT_DISC (MED) attribute for redistributed routes only.

Related Commands

bgp always-compare-med	Enable comparison of all BGP MED attributes.
redistribute	Redistribute routes from other routing protocols into BGP.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

description

CES Enter a description of the BGP routing protocol

Syntax description { description}

To remove the description, use the **no description** { description} command.

Parameters

description	Enter a description to identify the BGP protocol (80 characters maximum).	
-------------	---	--

Defaults

No default behavior or values

Command Modes

ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
pre-7.7.1.0	Introduced

Related Commands

router bgp	Enter ROUTER mode on the switch.	

distance bgp

CES Configure three administrative distances for routes.

Syntax distance bgp external-distance internal-distance local-distance

To return to default values, enter **no distance bgp**.

external-distance	Enter a number to assign to routes learned from a neighbor external to the AS.
	Range: 1 to 255.
	Default: 20
internal-distance	Enter a number to assign to routes learned from a router within the AS.
	Range: 1 to 255.
	Default: 200
local-distance	Enter a number to assign to routes learned from networks listed in the network command.
	Range: 1 to 255.
	Default: 200

Defaults

external-distance = 20; internal-distance = 200; local-distance = 200.

Command Modes

ROUTER BGP



Caution: Dell Networking recommends that you do not change the administrative distance of internal routes. Changing the administrative distances may cause routing table inconsistencies.

Usage Information

The higher the administrative distance assigned to a route means that your confidence in that route is low. Routes assigned an administrative distance of 255 are not installed in the routing table. Routes from confederations are treated as internal BGP routes.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

maximum-paths

CES

Configure the maximum number of parallel routes (multipath support) BGP supports.

Syntax

maximum-paths {ebgp | ibgp} number

To return to the default values, enter **no maximum-paths**.

Parameters

ebgp	Enter the keyword ebgp to enable multipath support for External BGP routes.
ibgp	Enter the keyword ibgp to enable multipath support for Internal BGP routes.
number	Enter a number as the maximum number of parallel paths.
	Range: 1 to 16
	Default: 1

Defaults

1

Command Modes

ROUTER BGP

Usage Information

If you enable this command, use the clear ip bgp * command to recompute the best path.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor activate

CES

This command allows the specified neighbor/peer group to be enabled for the current AFI/SAFI (Address Family Identifier/Subsequent Address Family Identifier).

Syntax

neighbor [ip-address | peer-group-name] **activate**

To disable, use the **no neighbor** [ip-address | peer-group-name] activate command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group
activate	Enter the keyword activate to enable the neighbor/peer group in the new AFI/SAFI.

Defaults

Disabled

Command Modes

CONFIGURATION-ROUTER-BGP-ADDRESS FAMILY

Usage Information By default, when a neighbor/peer group configuration is created in the Router BGP context, it is enabled for the IPv4/Unicast AFI/SAFI. By using activate in the new context, the neighbor/peer group is enabled for AFI/SAFI.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor advertisement-interval

CES

Set the advertisement interval between BGP neighbors or within a BGP peer group.

Syntax

neighbor {ip-address | peer-group-name} advertisement-interval seconds

To return to the default value, use the **no neighbor** { *ip-address* | *peer-group-name*} advertisement-interval command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to set the advertisement interval for all routers in the peer group.
seconds	Enter a number as the time interval, in seconds, between BGP advertisements.
	Range: 0 to 600 seconds.
	Default: 5 seconds for internal BGP peers; 30 seconds for external BGP peers.

Defaults

seconds = 5 seconds (internal peers); seconds = 30 seconds (external peers)

Command Modes ROI

ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor advertisement-start

CES

Set the minimum interval before starting to send BGP routing updates.

Syntax

neighbor {ip-address} advertisement-start seconds

To return to the default value, use the **no neighbor** { *ip-address*} **advertisement-start** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
seconds	Enter a number as the time interval, in seconds, before BGP route updates are sent.
	Range: 0 to 3600 seconds.

Defaults

none

Command Modes

ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor allowas-in

CES

Set the number of times an AS number can occur in the AS path

Syntax

neighbor {ip-address | peer-group-name} allowas-in number

To return to the default value, use the **no neighbor** { *ip-address* | *peer-group-name*} **allowas-in** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to set the advertisement interval for all routers in the peer group.
number	Enter a number of times to allow this neighbor ID to use the AS path.
	Range: 1 to 10.

Defaults

Not configured.

Command Modes

ROUTER BGP

Related Commands

bgp four-octet-as-support Enable 4-Byte support for the BGP process.	
--	--

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced on C-Series and E-Series

neighbor default-originate

CES

Inject the default route to a BGP peer or neighbor.

Syntax

neighbor {ip-address | peer-group-name} default-originate [route-map map-name]

To remove a default route, use the **no neighbor** { ip-address | peer-group-name } **default-originate** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to set the default route of all routers in that peer group.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information If you apply a route map to a BGP peer or neighbor with the neighbor default-originate command configured, the software does not apply the set filters in the route map to that BGP peer or neighbor.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor description

CES

Assign a character string describing the neighbor or group of neighbors (peer group).

Syntax

neighbor {ip-address | peer-group-name} description text

To delete a description, use the **no neighbor** { *ip-address* | *peer-group-name*} **description** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.
text	Enter a continuous text string up to 80 characters.

Defaults

Not configured.

Command Modes

ROUTER BGP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor distribute-list

CES

Distribute BGP information via an established prefix list.

Syntax

neighbor {ip-address | peer-group-name} **distribute-list** prefix-list-name {**in** | **out**}

To delete a neighbor distribution list, use the **no neighbor** {*ip-address* | *peer-group-name*} **distribute-list** *prefix-list-name* {**in** | **out**} command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to apply the distribute list filter to all routers in the peer group.
prefix-list-name	Enter the name of an established prefix list.
	If the prefix list is not configured, the default is permit (to allow all routes).
in	Enter the keyword in to distribute only inbound traffic.
out	Enter the keyword out to distribute only outbound traffic.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information Other BGP filtering commands include: neighbor filter-list, ip as-path access-list, and neighbor route-map.

Related Commands

ip as-path access-list	Configure IP AS-Path ACL.
neighbor filter-list	Assign a AS-PATH list to a neighbor or peer group.
neighbor route-map	Assign a route map to a neighbor or peer group.
neighbor route-map	Assign a route map to a neighbor or peer group.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor ebgp-multihop

CES

Attempt and accept BGP connections to external peers on networks that are not directly connected.

Syntax

neighbor {ip-address | peer-group-name} ebgp-multihop [ttl]

To disallow and disconnect connections, use the **no neighbor** { *ip-address* | *peer-group-name*} **ebgp-multihop** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.
ttl	(OPTIONAL) Enter the number of hops as the Time to Live (ttl) value.
	Range: 1 to 255.
	Default: 255

Defaults Disabled.

Command Modes ROUTER BGP

Usage Information To prevent loops, the neighbor ebgp-multihop command will not install default routes of the multihop peer. Networks not directly connected are not considered valid for best path selection.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor fall-over

E C S Enable or disable fast fall-over for BGP neighbors.

show ip bgp neighbors

Syntax neighbor { ipv4-address | peer-group-name} fall-over

To disable, use the **no neighbor** { *ipv4-address* | *peer-group-name*} **fall-over** command.

Parameters

ipv4-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.

Defaults Disabled

Command Modes ROUTER BGP

Usage Information When fall-over is enabled, BGP keeps track of IP or IPv6 reachability to the peer remote address and the peer local address. Whenever either address becomes unreachable (i.e, no active route exists in the routing table for peer IP or IPv6 destination/local address), BGP brings down the session with the peer.

Display information on the BGP neighbors

Related Commands

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.4.1.0	Introduced

neighbor filter-list

CES

Configure a BGP filter based on the AS-PATH attribute.

Syntax

neighbor {ip-address | peer-group-name} filter-list as-path-name {in | out}

To delete a BGP filter, use the **no neighbor** { *ip-address* | *peer-group-name*} **filter-list** as-path-name { **in** | **out**} command.

Parameters

ip-address	ddress Enter the IP address of the neighbor in dotted decimal format.	
peer-group-name Enter the name of the peer group to apply the filter to all routers peer group.		
as-path-name	Enter the name of an established AS-PATH access list (up to 140 characters). If the AS-PATH access list is not configured, the default is permit (allow	
	routes).	
in	Enter the keyword in to filter inbound BGP routes.	
out	Enter the keyword out to filter outbound BGP routes.	

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information Use the ip as-path access-list command syntax in the CONFIGURATION mode to enter the AS-PATH ACL mode and configure AS-PATH filters to deny or permit BGP routes based on information in their AS-PATH attribute.

Related Commands

	ip as-path access-	list Enter AS-PATH ACL mode and configure AS-PATH filters.
_	Version 8.3.3.1	Introduced on the S60.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, ACL names are up to 16 characters long.
Version 7.7.1.0	Introduced support on C-Series

neighbor graceful-restart

CES

Enable graceful restart on a BGP neighbor.

Syntax

neighbor {ip-address | peer-group-name} **graceful-restart** [restart-time seconds] [stale-path-time seconds] [role receiver-only]

To return to the default, enter the **no bgp graceful-restart** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to apply the filter to all routers in the
	peer group.

restart-time seconds	Enter the keyword restart-time followed by the maximum number of seconds needed to restart and bring-up all the peers.
	Range: 1 to 3600 seconds
	Default: 120 seconds
stale-path-time seconds	Enter the keyword stale-path-time followed by the maximum number of seconds to wait before restarting a peer's stale paths.
	Default: 360 seconds.
role receiver-only	Enter the keyword role receiver-only to designate the local router to support graceful restart as a receiver only.

Defaults

as above

Command Modes

ROUTER BGP

Usage Information This feature is advertised to BGP neighbors through a capability advertisement. In receiver only mode, BGP saves the advertised routes of peers that support this capability when they restart.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor local-as

CES

Configure Internal BGP (IBGP) routers to accept external routes from neighbors with a local AS number in the AS number path

Syntax

neighbor { *ip-address* | *peer-group-name*} **local-as** *as-number* [no-prepend]

To return to the default value, use the **no neighbor** { *ip-address* | *peer-group-name*} **local-as** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.	
peer-group-name	Enter the name of the peer group to set the advertisement interval for all routers in the peer group.	
as-number	Enter the AS number to reset all neighbors belonging to that AS.	
	Range: 0-65535 (2-Byte) or	
	1-4294967295 (4-Byte) <i>or</i>	
	0.1-65535.65535 (Dotted format)	
no prepend	Specifies that local AS values are not prepended to announcements from the neighbor.	

Defaults

Not configured.

Command Modes

ROUTER BGP

Related Commands

bgp four-octet-as-support	Enable 4-Byte support for the BGP process.	

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced command
	Introduced support on C-Series

neighbor maximum-prefix

CES

Control the number of network prefixes received.

Syntax

neighbor {ip-address | peer-group-name} **maximum-prefix** maximum [threshold] [warning-only]

To return to the default values, use the **no neighbor** { *ip-address* | *peer-group-name*} **maximum-prefix** *maximum* command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.	
peer-group-name	Enter the name of the peer group.	
maximum	Enter a number as the maximum number of prefixes allowed for this BGP router. Range: 1 to 4294967295.	
threshold	(OPTIONAL) Enter a number to be used as a percentage of the <i>maximum</i> value. When the number of prefixes reaches this percentage of the <i>maximum</i> value, the E-Series software sends a message.	
	Range: 1 to 100 percent.	
	Default: 75	
warning-only	(OPTIONAL) Enter the keyword warning-only to set the router to send a log message when the maximum value is reached. If this parameter is not set, the router stops peering when the maximum number of prefixes is reached.	

Defaults

threshold = 75

Command Modes

ROUTER BGP

Usage Information

If the neighbor maximum-prefix is configured and the neighbor receives more prefixes than allowed by the neighbor maximum-prefix command configuration, the neighbor goes down and the show ip bgp summary command displays (prfxd) in the State/PfxRcd column for that neighbor. The neighbor remains down until you enter the clear ip bgp command for the neighbor or the peer group to which the neighbor belongs or you enter neighbor shutdown and neighbor no shutdown commands.

Related Commands

show ip bgp sun	nmary	Displays the current BGP configuration.
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

Command History

neighbor next-hop-self

[C][E][S]

Enables you to configure the router as the next hop for a BGP neighbor. (This command is used for IBGP).

Syntax

neighbor { *ip-address* | *peer-group-name*} **next-hop-self**

To return to the default setting, use the **no neighbor** { *ip-address* | *peer-group-name*} **next-hop-self** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.

Defaults

Disabled.

Command Modes

ROUTER BGP

Usage Information If the set next-hop command in the ROUTE-MAP mode is configured, its configuration takes precedence over the neighbor next-hop-self command.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor password

CES

Enable Message Digest 5 (MD5) authentication on the TCP connection between two neighbors.

Syntax

neighbor { *ip-address* | *peer-group-name*} **password** [*encryption-type*] *password*

To delete a password, use the **no neighbor** { *ip-address* | *peer-group-name*} **password** command.

Parameters

ip-address	Enter the IP address of the router to be included in the peer group.
peer-group-name	Enter the name of a configured peer group.
encryption-type	(OPTIONAL) Enter 7 as the encryption type for the <i>password</i> entered. 7 means that the password is encrypted and hidden.
password	Enter a text string up to 80 characters long. The first character of the <i>password</i> must be a letter.
	You cannot use spaces in the password.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

Configure the same password on both BGP peers or a connection does not occur. When you configure MD5 authentication between two BGP peers, each segment of the TCP connection between them is verified and the MD5 digest is checked on every segment sent on the TCP connection.

Configuring a password for a neighbor will cause an existing session to be torn down and a new one established.

If you specify a BGP peer group by using the *peer-group-name* parameter, all the members of the peer group will inherit the characteristic configured with this command.

If you configure a password on one neighbor, but you have not configured a password for the neighboring router, the following message appears on the console while the routers attempt to establish a BGP session between them:

```
%RPM0-P:RP1 %KERN-6-INT: No BGP MD5 from [peer's IP address]
:179 to [local router's IP address]:65524
```

Also, if you configure different passwords on the two routers, the following message appears on the console:

%RPM0-P:RP1 %KERN-6-INT: BGP MD5 password mismatch from
[peer's IP address] : 11502 to [local router's IP address] :179

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor peer-group (assigning peers)

CES

Enables you to assign one peer to a existing peer group.

Syntax

neighbor ip-address peer-group peer-group-name

To delete a peer from a peer group, use the **no neighbor** *ip-address* **peer-group** *peer-group-name* command.

Parameters

ip-address	Enter the IP address of the router to be included in the peer group.
peer-group-name	Enter the name of a configured peer group.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

You can assign up to 256 peers to one peer group.

When you add a peer to a peer group, it inherits all the peer group's configured parameters. A peer cannot become part of a peer group if any of the following commands are configured on the peer:

- neighbor advertisement-interval
- neighbor distribute-list out
- neighbor filter-list out
- neighbor next-hop-self
- neighbor route-map out
- neighbor route-reflector-client
- neighbor send-community

A neighbor may keep its configuration after it was added to a peer group if the neighbor's configuration is more specific than the peer group's, and the neighbor's configuration does not affect outgoing updates.

A peer group must exist before you add a peer to it. If the peer group is disabled (shutdown) the peers within the group are also disabled (shutdown).

Related **Commands**

clear ip bgp	Resets BGP sessions.
neighbor peer-group (creating group)	Create a peer group.
show ip bgp peer-group	View BGP peers.
show ip bgp neighbors	View BGP neighbors configurations.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor peer-group (creating group)

CES Enables you to create a peer group and assign it a name.

Syntax neighbor peer-group-name peer-group

To delete a peer group, use the **no neighbor** peer-group-name **peer-group** command.

Parameters

Enter a text string up to 16 characters long as the name of the peer group. peer-group-name

Defaults Not configured.

Command Modes ROUTER BGP

> Usage Information

When a peer group is created, it is disabled (shut mode).

Related **Commands**

neighbor peer-group (assigning peers)	Assign routers to a peer group.
neighbor remote-as	Assign a indirectly connected AS to a neighbor or peer group.
neighbor shutdown	Disable a peer or peer group.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor peer-group passive

[C][E][S]

Enable passive peering on a BGP peer group, that is, the peer group does not send an OPEN message, but will respond to one.

Syntax neighbor peer-group-name peer-group passive To delete a passive peer-group, use the **no neighbor** *peer-group-name* **peer-group passive** command.

Parameters

peer-group-name Enter a text string up to 16 characters long as the name of the peer group.

Defaults N

Not configured.

Command Modes

ROUTER BGP

Usage Information After you configure a peer group as passive, you must assign it a subnet using the neighbor soft-reconfiguration inbound command.

Related Commands

neignbor soft-reconfiguration inbound	Assign a subnet to a dynamicany-configured BGP neignbor.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor remote-as

CES

Create and specify the remote peer to the BGP neighbor.

Syntax

neighbor { *ip-address* | *peer-group-name* } **remote-as** *number*

To delete a remote AS entry, use the **no neighbor** { *ip-address* | *peer-group-name*} **remote-as** *number* command.

Parameters

ip-address	Enter the IP address of the neighbor to enter the remote AS in its routing table.	
peer-group-name	Enter the name of the peer group to enter the remote AS into routing tables of all routers within the peer group.	
number	Enter a number of the AS.	
	Range: 0-65535 (2-Byte) or 1-4294967295 (4-Byte)	

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information You must configure your system to accept 4-Byte formats before entering a 4-Byte AS Number. If the *number* parameter is the same as the AS number used in the <u>router bgp</u> command, the remote AS entry in the neighbor is considered an internal BGP peer entry.

This command creates a peer and the newly created peer is disabled (shutdown).

Related Commands

router bgp		Enter the ROUTER BGP mode and configure routes in an AS.
bgp four-octet-as-su	ıpport	Enable 4-Byte support for the BGP process.
Version 8.3.3.1	Introduced o	n the S60

Command History

Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
	Added 4-Byte support.	

neighbor remove-private-as

CES Remove private AS numbers from the AS-PATH of outgoing updates.

Syntax neighbor {ip-address | peer-group-name} remove-private-as

> To return to the default, use the **no neighbor** {ip-address | peer-group-name} **remove-private-as** command.

Parameters

ip-address	Enter the IP address of the neighbor to remove the private AS numbers.
peer-group-name	Enter the name of the peer group to remove the private AS numbers

Defaults Disabled (that is, private AS number are not removed).

Command Modes ROUTER BGP

Usage Information

Applies to EBGP neighbors only.

You must configure your system to accept 4-Byte formats before entering a 4-Byte AS Number.

If the AS-PATH contains both public and private AS number or contains AS numbers of an EBGP neighbor, the private AS numbers are not removed.

If a confederation contains private AS numbers in its AS-PATH, the software removes the private AS numbers only if they follow the confederation numbers in the AS path.

Private AS numbers are 64512 to 65535 (2-Byte).

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
	Added 4-Byte support.

neighbor route-map

Apply an established route map to either incoming or outbound routes of a BGP neighbor or peer group.

Syntax neighbor {ip-address | peer-group-name} route-map map-name {in | out}

> To remove the route map, use the **no neighbor** { *ip-address* | *peer-group-name*} **route-map** map-name {in | out} command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.
map-name	Enter the name of an established route map.
	If the Route map is not configured, the default is deny (to drop all routes).
in	Enter the keyword in to filter inbound routes.
out	Enter the keyword out to filter outbound routes.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

When you apply a route map to outbound routes, only routes that match at least one section of the route map are permitted.

If you identify a peer group by name, the peers in that peer group inherit the characteristics in the Route map used in this command. If you identify a peer by IP address, the Route map overwrites either the inbound or outbound policies on that peer.

Command History

_	Version 8.3.3.1	Introduced on the S60.
	Version 7.8.1.0	Introduced support on S-Series
	Version 7.7.1.0	Introduced support on C-Series

neighbor route-reflector-client

CES

Configure a neighbor as a member of a route reflector cluster.

Syntax

neighbor { *ip-address* | *peer-group-name*} **route-reflector-client**

To indicate that the neighbor is not a route reflector client or to delete a route reflector configuration, use the **no neighbor** {*ip-address* | *peer-group-name*} **route-reflector-client** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group.
	All routers in the peer group receive routes from a route reflector.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

The first time you enter this command it configures the neighbor as a route reflector and members of the route-reflector cluster. Internal BGP (IBGP) speakers do not need to be fully meshed if you configure a route reflector.

When all clients of a route reflector are disabled, the neighbor is no longer a route reflector.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor send-community

[C][E][S]

Send a COMMUNITY attribute to a BGP neighbor or peer group. A COMMUNITY attribute indicates that all routes with that attribute belong to the same community grouping.

Syntax

neighbor { ip-address | peer-group-name } **send-community**

To disable sending a COMMUNITY attribute, use the **no neighbor** { *ip-address* | *peer-group-name*} send-community command.

Parameters

ip-address	Enter the IP address of the peer router in dotted decimal format.
peer-group-name	Enter the name of the peer group to send a COMMUNITY attribute to all routers within the peer group.

Defaults

Not configured and COMMUNITY attributes are not sent to neighbors.

Command Modes

ROUTER BGP

Usage Information

To configure a COMMUNITY attribute, use the set community command in the ROUTE-MAP mode.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor shutdown

CES

Disable a BGP neighbor or peer group.

Syntax

neighbor {ip-address | peer-group-name} shutdown

To enable a disabled neighbor or peer group, use the **neighbor** { *ip-address* | *peer-group-name*} **no** shutdown command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to disable or enable all routers within the peer
	group.

Defaults

Enabled (that is, BGP neighbors and peer groups are disabled.)

Command Modes

ROUTER BGP

Usage Information Peers that are enabled within a peer group are disabled when their peer group is disabled.

The neighbor shutdown command terminates all BGP sessions on the BGP neighbor or BGP peer group. Use this command with caution as it terminates the specified BGP sessions. When a neighbor or peer group is shutdown, use the show ip bgp summary command to confirm its status.

Related **Commands**

show ip bgp summary	Displays the current BGP configuration.
show ip bgp neighbors	Displays the current BGP neighbors.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor soft-reconfiguration inbound

CES

Enable soft-reconfiguration for BGP.

Syntax

neighbor {ip-address | peer-group-name} soft-reconfiguration inbound

To disable, use the **no neighbor** { *ip-address* | *peer-group-name*} **soft-reconfiguration inbound** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.	
peer-group-name	Enter the name of the peer group to disable or enable all routers within the peer group.	

Defaults

Disabled

Command Modes

ROUTER BGP

Usage Information

This command enables soft-reconfiguration for the BGP neighbor specified. BGP will store all the updates received by the neighbor but will not reset the peer-session.



Caution: Inbound update storage is a memory-intensive operation. The entire BGP update database from the neighbor is stored in memory *regardless* of the inbound policy results applied on the neighbor.



show ip bgp neighbors

Note: This command is supported in BGP Router Configuration mode for IPv4 Unicast address only.

Related Commands

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.4.1.0	Introduced

Display routes received by a neighbor

neighbor subnet

CES

Enable passive peering so that the members of the peer group are dynamic

Syntax

neighbor peer-group-name subnet subnet-number mask

To remove passive peering, use the **no neighbor** *peer-group-name* **subnet** *subnet-number mask* command.

Davamatava		
Parameters	subnet-number	Enter a subnet number in dotted decimal format (A.B.C.D.) as the allowable range of addresses included in the Peer group.
		To allow all addresses, enter 0.0.0.0/0.
	mask	Enter a prefix mask in / prefix-length format (/x).
Defaults	Not configured.	
Command Modes	ROUTER BGP	
Command History	Version 7.8.1.0	Introduced support on S-Series
,	Version 7.7.1.0	Introduced support on C-Series

neighbor timers

CES

Set keepalive and hold time timers for a BGP neighbor or a peer group.

Syntax

neighbor { ip-address | peer-group-name} **timers** keepalive holdtime

To return to the default values, use the **no neighbor** { *ip-address* | *peer-group-name*} **timers** command.

Parameters

ip-address	Enter the IP address of the peer router in dotted decimal format.	
peer-group-name	Enter the name of the peer group to set the timers for all routers within the peer group.	
keepalive	Enter a number for the time interval, in seconds, between keepalive messages sent to the neighbor routers. Range: 1 to 65535 Default: 60 seconds	
holdtime	Enter a number for the time interval, in seconds, between the last keepalive message and declaring the router dead. Range: 3 to 65535 Default: 180 seconds	

Defaults

keepalive = 60 seconds; holdtime = 180 seconds.

Command Modes

ROUTER BGP

Usage Information

Timer values configured with the neighbor timers command override the timer values configured with the any other command.

When two neighbors, configured with different keepalive and holdtime values, negotiate for new values, the resulting values will be as follows:

- the lower of the holdtime values is the new holdtime value, and
- whichever is the lower value; one-third of the new holdtime value, or the configured keepalive value is the new keepalive value.

Command History

Version 8.3.3.1	Introduced on the S60.	

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor update-source

CES

Enable the E-Series software to use Loopback interfaces for TCP connections for BGP sessions.

Syntax

neighbor {ip-address | peer-group-name} update-source interface

To use the closest interface, use the **no neighbor** { *ip-address* | *peer-group-name*} **update-source** *interface* command.

Parameters

ip-address	Enter the IP address of the peer router in dotted decimal format.	
peer-group-name	Enter the name of the peer group to disable all routers within the peer group.	
interface	Enter the keyword loopback followed by a number of the loopback interface.	
	Range: 0 to 16383.	

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information Loopback interfaces are up constantly and the BGP session may need one interface constantly up to stabilize the session. The neighbor update-source command is not necessary for directly connected internal BGP sessions.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

neighbor weight

CES

Assign a weight to the neighbor connection, which is used to determine the best path.

Syntax

neighbor {ip-address | peer-group-name} weight weight

To remove a weight value, use the **no neighbor** { *ip-address* | *peer-group-name*} **weight** command.

Parameters

ip-address	Enter the IP address of the peer router in dotted decimal format.	
peer-group-name	Enter the name of the peer group to disable all routers within the peer group.	
weight	Enter a number as the weight.	
	Range: 0 to 65535	
	Default: 0	

Defaults

0

Command Modes

ROUTER BGP

Usage Information

In the FTOS best path selection process, the path with the highest weight value is preferred.



Note: Reset the neighbor connection (clear ip bgp * command) to apply the weight to the connection and recompute the best path.

If the set weight command is configured in a route map applied to this neighbor, the weight set in that command overrides the weight set in the neighbor weight command.

Related **Commands**

Command History

set weight	Assign a weight to all paths meeting the route map criteria.	
Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

network



Specify the networks for the BGP process and enter them in the BGP routing table.

Syntax

network *ip-address mask* [**route-map** *map-name*]

To remove a network, use the **no network** *ip-address mask* [route-map map-name] command.

Parameters

ip-address	Enter an IP address in dotted decimal format of the network.		
mask	Enter the mask of the IP address in the slash prefix length format (for example, /24).		
	The mask appears in command outputs in dotted decimal format (A.B.C.D).		
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of an established route map. Only the following ROUTE-MAP mode commands are supported: • match ip address • set community • set local-preference • set metric • set next-hop • set origin • set weight If the route map is not configured, the default is deny (to drop all routes).		

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

FTOS software resolves the network address configured by the network command with the routes in the main routing table to ensure that the networks are reachable via non-BGP routes and non-default routes.

Related **Commands**

redistribute	Redistribute routes into BGP.	

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

network backdoor

CES

Specify this IGP route as the preferred route.

Syntax

network ip-address mask backdoor

To remove a network, use the **no network** *ip-address mask* **backdoor** command.

Parameters

ip-address	Enter an IP address in dotted decimal format of the network.
mask	Enter the mask of the IP address in the slash prefix length format (for example, /24).
	The mask appears in command outputs in dotted decimal format (A.B.C.D).

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information Though FTOS does not generate a route due to backdoor config, there is an option for injecting/sourcing a local route in presence of network backdoor config on a learned route.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

redistribute

CES

Redistribute routes into BGP.

Syntax

redistribute {connected | static} [route-map map-name]

To disable redistribution, use the **no redistribution** {connected | static} command.

Parameters

connected	Enter the keyword connected to redistribute routes from physically connected
	interfaces.

static	Enter the keyword static to redistribute manually configured routes. These routes are treated as incomplete routes.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of an established route map. Only the following ROUTE-MAP mode commands are supported:
	 match ip address set community set local-preference
	set metricset next-hopset origin
	 set weight set weight If the route map is not configured, the default is deny (to drop all routes).

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

With FTOS version 8.3.1.0 and later, the redistribute command can be used to advertise the IGP cost as the MED on redistributed routes. When the route-map is set with metric-type internal and applied outbound to an EBGP peer/peer-group, the advertised routes corresponding to those peer/peer-group will have IGP cost set as MED.

If you do not configure default-metric command, in addition to the redistribute command, or there is no route map to set the metric, the metric for redistributed static and connected is "0".

To redistribute the default route (0.0.0.0/0) configure the neighbor default-originate command.

Related Commands

Command **History**

neighbor default-or	iginate Inject the default route.
Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced ability to substitute IGP cost for MED when a peer/peer-group outbound route-map is set as internal.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

redistribute isis

(E)

Redistribute IS-IS routes into BGP.

Syntax

redistribute isis [WORD] [level-1| level-1-2 | level-2] [metric metric-value] [route-map map-name]

To return to the default values, enter the **no redistribute isis** [WORD] [level-1| level-1-2 | level-2] [metric metric-value] [route-map map-name] command.

Parameters

WORD	ISO routing area tag
level-1	(OPTIONAL) Enter the keyword level-1 to independently redistributed into Level 1 routes only.
level-1-2	(OPTIONAL) Enter the keyword level-1-2 to independently redistributed into Level 1 and Level 2 routes. This is the default.
level-2	(OPTIONAL) Enter the keyword level-2 to independently redistributed into Level 2 routes only
metric metric-value	(OPTIONAL) Enter the keyword metric followed by the metric value used for the redistributed route. Use a metric value that is consistent with the destination protocol.
	Range: 0 to 16777215
	Default: 0
route-map map-name	Enter the keyword route-map followed by the map name that is an identifier for a configured route map.
	The route map should filter imported routes from the source routing protocol to the current routing protocol.
	If you do not specify a <i>map-name</i> , all routes are redistributed. If you specify a keyword, but fail to list route map tags, no routes will be imported.

Defaults

level-1-2

Command Modes

ROUTER BGP

Example

Figure 7-3. Command Example: redistribute isis

```
FTOS(conf) #router bgp 1
FTOS(conf-router_bgp) #redistribute isis level-1 metric 44 route-map rmap-is2bgp
FTOS(conf-router_bgp) #show running-config bgp
!
router bgp 1
redistribute isis level-1 metric 44 route-map rmap-is2bgp
```

Usage Information

With FTOS version 8.3.1.0 and later, the redistribute command can be used to advertise the IGP cost as the MED on redistributed routes. When the route-map is set with metric-type internal and applied outbound to an EBGP peer/peer-group, the advertised routes corresponding to those peer/peer-group will have IGP cost set as MED.

IS-IS to BGP redistribution supports matching of **level-1** or **level-2** routes or all routes (default). More advanced match options can be performed using route maps. The metric value of redistributed routes can be set by the redistribution command.

Command History

Version 8.3.1.0	Introduced ability to substitute IGP cost for MED when a peer/peer-group outbound route-map is set as internal.
Version 6.3.1.0	Introduced

redistribute ospf

CES

Redistribute OSPF routes into BGP.

Syntax

redistribute ospf *process-id* [[match external {1 | 2}] [match internal]] [route-map map-name]

To stop redistribution of OSPF routes, use the **no redistribute ospf** *process-id* command.

Parameters

process-id	Enter the number of the OSPF process.
	Range: 1 to 65535
match external {1 2}	(OPTIONAL) Enter the keywords match external to redistribute OSPF external routes. You can specify 1 or 2 to redistribute those routes only.
match internal	(OPTIONAL) Enter the keywords match internal to redistribute OSPF internal routes only.
route-map map-name	(OPTIONAL) Enter the keywords route-map followed by the name of a configured Route map.

Defaults

Not configured.

Command Modes

ROUTER BGP

Usage Information

With FTOS version 8.3.1.0 and later, the redistribute command can be used to advertise the IGP cost as the MED on redistributed routes. When the route-map is set with metric-type internal and applied outbound to an EBGP peer/peer-group, the advertised routes corresponding to those peer/peer-group will have IGP cost set as MED.

When you enter redistribute isis process-id command without any other parameters, FTOS redistributes all OSPF internal routes, external type 1 routes, and external type 2 routes. This feature is not supported by an RFC.

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced ability to substitute IGP cost for MED when a peer/peer-group outbound route-map is set as internal.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

router bgp

CES

Enter ROUTER BGP mode to configure and enable BGP.

Syntax

router bgp as-number

To disable BGP, use the **no router bgp** as-number command.

Parameters

as-number	Enter the AS number.
	Range: 1 to 65535 (2-Byte) or 1-4294967295 (4-Byte) or
	0.1-65535.65535 (Dotted format)

Defaults

Not enabled.

Command Modes

CONFIGURATION

Example Figure 7-4. Command Example: router bgp

FTOS(conf) #router bgp 3 FTOS(conf-router_bgp)#

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

Usage Information

At least one interface must be in Layer 3 mode for the router bgp command to be accepted. If no interfaces are enabled for Layer 3, an error message appears: % Error: No router id configured.

show capture bgp-pdu neighbor

CES Display BGP packet capture information for an IPv4 address on the system.

Syntax show capture bgp-pdu neighbor ipv4-address

Parameters

ipv4-address Enter the IPv4 address (in dotted decimal format) of the BGP address to display packet information for that address.

Command Modes

EXEC Privilege

Example

Figure 7-5. Command Example: show capture bgp-pdu neighbor

```
FTOS(conf-router_bgp)#show capture bgp-pdu neighbor 20.20.20.2
Incoming packet capture enabled for BGP neighbor 20.20.20.2
Available buffer size 40958758, 26 packet(s) captured using 680 bytes
  PDU[1] : len 101, captured 00:34:51 ago
    ffffffff ffffffff ffffffff 00650100 00000013 00000000
00000000 419ef06c 00000000
    00000000 00000000 00000000 00000000 0181ale4 0181a25c 41af92c0
0000000 00000000 00000000
    00000000 00000001 0181ale4 0181a25c 41af9400 00000000
  PDU[2] : len 19, captured 00:34:51 ago
    fffffff fffffff fffffff fffffff 00130400
    U[3] : len 19, captured 00:34:51 ago ffffffff fffffff fffffff ffffffff
 [. . .]
Outgoing packet capture enabled for BGP neighbor 20.20.20.2
Available buffer size 40958758, 27 packet(s) captured using 562 bytes PDU[1]: len 41, captured 00:34:52 ago ffffffff ffffffff ffffffff ffffffff 00290104 000100b4 14141401
0c020a01 04000100 01020080
    00000000
  PDU[2] : len 19, captured 00:34:51 ago
    ffffffff ffffffff ffffffff ffffffff 00130400
            len 19, captured 00:34:50 ago
    fffffff fffffff fffffff fffffff 00130400
l...
FTOS#
```

Related Commands

capture bgp-pdu max-buffer-size

Specify a size for the capture buffer.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.5.1.0	Introduced

show config

CES View the current ROUTER BGP configuration.

Syntax show config

Command Modes ROUTER BGP

Example Figure 7-6. Command Example: show config

```
FTOS(conf-router_bgp)#show confi
router bgp 45
 neighbor suzanne peer-group
neighbor suzanne no shutdown
 neighbor sara peer-group
 neighbor sara shutdown
 neighbor 13.14.15.20 peer-group suzanne
neighbor 13.14.15.20 shutdown
 neighbor 123.34.55.123 peer-group suzanne neighbor 123.34.55.123 shutdown
FTOS (conf-router_bgp) #
```

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp

View the current BGP IPv4 routing table for the system.

Syntax show ip bgp [ipv4 unicast] [network [network-mask] [longer-prefixes]]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
network	(OPTIONAL) Enter the network address (in dotted decimal format) of the BGP network to view information only on that network.
network-mask	(OPTIONAL) Enter the network mask (in slash prefix format) of the BGP network address.
longer-prefixes	(OPTIONAL) Enter the keyword longer-prefixes to view all routes with a common prefix.

Command Modes EXEC

EXEC Privilege

Usage Information

When you enable **bgp non-deterministic-med** command, the **show ip bgp** command output for a BGP route does not list the INACTIVE reason.

Example Figure 7-7. Command Example: show ip bgp (Partial)

```
FTOS>show ip bgp
BGP table version is 847562, local router ID is 63.114.8.131
Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network
Origin codes: i - IGP, e - EGP, ? - incomplete
     Network
                             Next Hop
                                                      Metric
                                                                       LocPrf
                                                                                    Weight Path
     0.0.0.0/0
                              63.114.8.33
                                                                                          Λ
                                                                                              18508 i
                                                                                              18508 209 701 80 i
     3.0.0.0/8
                              63.114.8.33
                                                                                          Ω
*>
                              63.114.8.33
                                                                                              18508 701 80 i
*>
     3.3.0.0/16
                             0.0.0.0
                                                           22
                                                                                     32768
                              63.114.8.35
                                                                                          0
                                                                                              18508 ?
     4.0.0.0/8
                              63.114.8.33
                                                                                          0
                                                                                              18508 701 1 i
     4.2.49.12/30
                              63.114.8.33
                                                                                              18508 209 i
     4.17.250.0/24
                              63.114.8.33
                                                                                          0
                                                                                              18508 209 1239 13716 i
                              63.114.8.33
                                                                                              18508 701 1239 13716 i
     4.21.132.0/23
                              63.114.8.33
                                                                                          0
                                                                                              18508 209 6461 16422
                              63.114.8.33
                                                                                          0
                                                                                              18508 701 6461 16422 i
*>
     4.24.118.16/30
                              63.114.8.33
                                                                                              18508 209
     4.24.145.0/30
                              63.114.8.33
                                                                                              18508 209
    4.24.187.12/30
                              63.114.8.33
                                                                                              18508 209
                             63.114.8.33
                                                                                              18508 209
    4.24.202.0/30
     4.25.88.0/30
                              63.114.8.33
                                                                                              18508 209 3561 3908 i
*> 5.0.0.0/9
                             63.114.8.33
*> 5.0.0.0/10
                              63.114.8.33
                                                            0
                                                                                          0
                                                                                              18508 ?
    5.0.0.0/11
                              63.114.8.33
                                                                                              18508 ?
--More--
```

Table 7-1 defines the information displayed in Figure 7-7

Table 7-1. Command Example Fields: show ip bgp

Introduced support on C-Series

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Related Commands

show ip bgp com	nunity	View BGP communities.
neighbor maximu	m-prefix	Control number of network prefixes received.
Version 8.3.3.1	Introduced	on the S60.
Version 7.8.1.0	Introduced	support on S-Series

Command History

Version 7.7.1.0

show ip bgp cluster-list

View BGP neighbors in a specific cluster.

Syntax show ip bgp [ipv4 unicast] cluster-list [cluster-id]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
cluster-id	(OPTIONAL) Enter the cluster id in dotted decimal format.

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-8. Command Example: show ip bgp cluster-list (Partial)

```
FTOS#show ip bgp cluster-list
BGP table version is 64444683, local router ID is 120.1.1.1 Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n
 network
Origin codes: i - IGP, e - EGP, ? - incomplete
                         Next Hop
    Network
                                                           LocPrf Weight Path
                                               Metric
* I 10.10.10.1/32
                         192.68.16.1
                                                    0
                                                              100
                         192.68.16.1
                                                               100
                                                     0
*>I
                         192.68.16.1
                                                     0
                                                               100
                                                                           i
                         192.68.16.1
                                                    0
                                                               100
                         192.68.16.1
                                                                           i
                                                               100
 Ι
                                                    0
                                                                         0
                         192.68.16.1
                                                    0
                                                               100
 I 10.19.75.5/32
                                                               100
                         192.68.16.1
                                                    0
                         192.68.16.1
                                                    Ω
                                                               100
                                                                         0
*>I
                         192.68.16.1
                                                    0
                                                               100
* I
                         192.68.16.1
                                                    Ω
                                                               100
* I
                                                              100
                         192.68.16.1
                                                    Ω
                         192.68.16.1
                                                    0
                                                               100
* I 10.30.1.0/24
                         192.68.16.1
                                                    Ω
                                                               100
* I
                         192.68.16.1
                                                    0
                                                               100
                                                                         0
*>I
                         192.68.16.1
                                                    0
                                                               100
                                                                         0
* I
                         192.68.16.1
                                                    Ω
                                                               100
                                                                         0
  I
I
                         192.68.16.1
                                                    0
                                                               100
                                                                         0 ?
                                                                         0 ?
                         192.68.16.1
                                                               100
```

Table 7-2 defines the information displayed in Figure 7-8.

Table 7-2. show ip bgp cluster-list Command Fields

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp community

CES

View information on all routes with Community attributes or view specific BGP community groups.

Syntax

show ip bgp [ipv4 unicast] community [community-number] [local-as] [no-export] [no-advertise]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
community-number	Enter the community number in AA:NN format where AA is the AS number (2 bytes) and NN is a value specific to that autonomous system.
	You can specify up to eight community numbers to view information on those community groups.
local-AS	Enter the keywords local-AS to view all routes with the COMMUNITY attribute of NO_EXPORT_SUBCONFED.
	All routes with the NO_EXPORT_SUBCONFED (0xFFFFFF03) community attribute must not be advertised to external BGP peers.
no-advertise	Enter the keywords no-advertise to view all routes containing the well-known community attribute of NO_ADVERTISE. All routes with the NO_ADVERTISE (0xFFFFFF02) community attribute must not be advertised to other BGP peers.
no-export	Enter the keywords no-export to view all routes containing the well-known community attribute of NO_EXPORT.
	All routes with the NO_EXPORT (0xFFFFFF01) community attribute must not be advertised outside a BGP confederation boundary.

Command Modes

EXEC

EXEC Privilege

Usage Information To view the total number of COMMUNITY attributes found, use the show ip bgp summary command. The text line above the route table states the number of COMMUNITY attributes found.

Example Figure 7-9. Command Example: show ip bgp community (Partial)

```
FTOS>show ip bgp community
BGP table version is 3762622, local router ID is 63.114.8.48
Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network Origin codes: i - IGP, e - EGP, ? - incomplete
                          Next Hop
                                                Metric
                                                                LocPrf
                                                                          Weight Path
    Network
* i 3.0.0.0/8
                          205.171.0.16
                                                                                   209 701 80 i
*>i 4.2.49.12/30
                         205.171.0.16
                                                                                0 209 i
                                                                   100
* i 4.21.132.0/23
                          205.171.0.16
                                                                   100
                                                                                0 209 6461 16422 i
                         205.171.0.16
*>i 4.24.118.16/30
                                                                   100
                                                                                0 209 i
                          205.171.0.16
*>i 4.24.145.0/30
                                                                   100
                                                                                   209 i
                         205.171.0.16
*>i 4.24.187.12/30
                                                                   100
                                                                                0
                                                                                   209 i
*>i 4.24.202.0/30
                          205.171.0.16
                                                                   100
                                                                                0
                                                                                   209 i
                         205.171.0.16
*>i 4.25.88.0/30
                                                                   100
                                                                                0 209 3561 3908 i
                                                                               0 209 7170 1455 i
0 209 7170 1455 i
*>i 6.1.0.0/16
                          205.171.0.16
                                                                   100
                         205.171.0.16
*>i 6.2.0.0/22
                                                                   100
                         205.171.0.16
205.171.0.16
                                                                   100
*>i 6.3.0.0/18
                                                                               0 209 7170 1455
                                                                               0 209 7170 1455
*>i 6.4.0.0/16
                                                                   100
                        205.171.0.16
205.171.0.16
                                                                               0 209 7170 1455
0 209 7170 1455
*>i 6.5.0.0/19
                                                                   100
*>i 6.8.0.0/20
                                                                   100
                        205.171.0.16
205.171.0.16
*>i 6.9.0.0/20
                                                                   100
                                                                               0 209 7170 1455
                                                                                0 209 7170 1455
*>i 6.10.0.0/15
                                                                   100
*>i 6.14.0.0/15
                         205.171.0.16
                                                                   100
                                                                                0 209 7170 1455
*>i 6.133.0.0/21
                          205.171.0.16
                                                                   100
                                                                                0 209 7170 1455
*>i 6.151.0.0/16
                          205.171.0.16
                                                                   100
                                                                                0 209 7170 1455 i
--More--
```

The show ip bgp community command without any parameters lists BGP routes with at least one BGP community attribute and the output is the same as for the show ip bgp command output.

Table 7-3. Command Example Fields: show ip bgp community

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp community-list

CES View routes that are affected by a specific community list.

Syntax show ip bgp [ipv4 unicast] community-list community-list-name [exact-match]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
community-list-name	Enter the name of a configured IP community list. (max 16 chars)
exact-match	Enter the keyword for an exact match of the communities.

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-10. Command Example: show ip bgp community-list

```
FTOS#show ip bgp community-list pass
BGP table version is 0, local router ID is 10.101.15.13
Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network
Origin codes: i - IGP, e - EGP, ? - incomplete

Network
Next Hop
Metric
LocPrf
Weight Path
FTOS#
```

The show ip bgp community-list command without any parameters lists BGP routes matching the Community List and the output is the same as for the show ip bgp command output.

Table 7-4. Command Example Fields: show ip bgp community-list

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

show ip bgp dampened-paths

View BGP routes that are dampened (non-active).

Syntax show ip bgp [ipv4 unicast] dampened-paths

Command Modes EXEC

EXEC Privilege

Example Figure 7-11. Command Example: show ip bgp dampened-paths

```
FTOS>show ip bgp damp
BGP table version is 210708, local router ID is 63.114.8.2
Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network Origin codes: i - IGP, e - EGP, ? - incomplete
                                    From
                                                                               Path
FTOS>
```

Table 7-5 defines the information displayed in Figure 7-11.

Table 7-5. Command Example: show ip bgp dampened-paths

Field	Description
Network	Displays the network ID to which the route is dampened.
From	Displays the IP address of the neighbor advertising the dampened route.
Reuse	Displays the hour:minutes:seconds until the dampened route is available.
Path	Lists all the ASs the dampened route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp detail

CES Display BGP internal information for IPv4 Unicast address family.

Syntax show ip bgp [ipv4 unicast] detail

Defaults none

Command Modes EXEC

EXEC Privilege

Example Figure 7-12. Command Example: show ip bgp detail

```
R2#show ip bgp detail
Detail information for BGP Node
bgpNdP 0x41a17000 : NdTmrP 0x41a17000 : NdKATmrP 0x41a17014 : NdTics 74857 :
NhLocAS 1 : NdState 2 : NdRPMPrim 1 : NdListSoc 13
NdAuto 1 : NdEqCost 1 : NdSync 0 : NdDeforg 0
NdV6ListSoc 14 NdDefDid 0 : NdConfedId 0 : NdMedConfed 0 : NdMedMissVal -1 :
NdIgnrillid 0: NdRRC2C 1: NdClstId 33686273: NdPaTblP 0x41a19088
NdASPTblP 0x41a19090: NdCommTblP 0x41a19098: NhOptTransTblP 0x41a190a0:
NdRRClsTblP 0x41a190a8
NdPktPA 0 : NdLocCBP 0x41a6f000 : NdTmpPAP 0x419efc80 : NdTmpASPAP 0x41a25000 :
NdTmpCommP 0x41a25800
NdTmpRRClP 0x41a4b000 : NdTmpOptP 0x41a4b800 : NdTmpNHP
                                                                 : NdOrigPAP 0
NdOrgNHP 0: NdModPathP 0x419efcc0: NdModASPAP 0x41a4c000: NdModCommP 0x41a4c800
NdModOptP 0x41a4d000: NdModNHP: NdComSortBufP 0x41a19110: NdComSortHdP
0x41a19d04 : NdUpdAFMsk 0 : AFRstSet 0x41a1a298 : NHopDfrdHdP 0x41a1a3e0 :
NumNhDfrd 0 : CfgHdrAFMsk 1
AFChkNetTmrP 0x41ee705c :
                              AFRtDamp 0 : AlwysCmpMed 0 : LocrHld 10 : LocrRem 10 :
softReconfig 0x41a1a58c
DefMet 0 : AutoSumm 1 : NhopsP 0x41a0d100 : Starts 0 : Stops 0 : Opens 0
Closes 0 : Fails 0 : Fatals 0 : ConnExps 0 : HldExps 0 : KeepExps 0
RxOpens 0 : RxKeeps 0 : RxUpds 0 : RxNotifs 0 : TxNotifs 0
BadEvts 0 : SynFails 0 : RxeCodeP 0x41a1b6b8 : RxHdrCodeP 0x41a1b6d4 : RxOpCodeP
0x41a1b6e4
RxUpdCodeP 0x41a1b704 : TxEcodeP 0x41a1b734 : TxHdrcodeP 0x41a1b750 : TxOpCodeP
0x41a1b760
TxUpdCodeP 0x41a1b780 : TrEvt 0 : LocPref 100 : tmpPathP 0x41a1b7b8 : LogNbrChgs 1
RecursiveNH 1 : PqCfqId 0 : KeepAlive 0 : HldTime 0 : DioHdl 0 : AqqrValTmrP
UpdNetTmrP 0 : RedistTmrP 0x41ee7094 : PeerChgTmrP 0 : CleanRibTmrP 0x41ee7104
PeerUpdTmrP 0x41ee70cc : DfrdNHTmrP 0x41ee7174 : DfrdRtselTmrP 0x41ee713c :
FastExtFallover 1 : FastIntFallover 0 : Enforce1stAS 1
PeerIdBitsP 0x41967120 : softOutSz 16 : RibUpdCtxCBP 0
UpdPeerCtxCBP 0 : UpdPeerCtxAFI 0 : TcpioCtxCB 0 : RedistBlk 1
NextCBPurg 1101119536 : NumPeerToPurge 0 : PeerIBGPCnt 0 : NonDet 0 : DfrdPathSel 0 BGPRst 0 : NumGrCfg 1 : DfrdTmestmp 0 : SnmpTrps 0 : IgnrBestPthASP 0 RstOn 1 : RstMod 1 : RstRole 2 : AFFalgs 7 : RstInt 120 : MaxeorExtInt 361
FixedPartCrt 1 : VarParCrt 1
Packet Capture max allowed length 40960000 : current length 0
Peer Grp List
Nbr List
Confed Peer List
Address Family specific Information
AFIndex 0
NdSpFlag 0x41a190b0 : AFRttP 0x41a0d200 : NdRTMMkrP 0x41a19d28 : NdRTMAFTblVer 0 :
NdRibCtxAddr 1101110688
NdRibCtxAddrLen 255 : NdAFPrefix 0 : NdAfNLRIP 0 : NdAFNLRILen 0 : NdAFWPtrP 0 NdAFWLen 0 : NdAfNH : NdAFRedRttP 0x41a0d400 : NdRecCtxAdd 1101110868
NdRedCtxAddrLen 255 : NdAfRedMkrP 0x41a19e88 : AFAggRttP 0x41a0d600 : AfAggCtxAddr
1101111028 : AfAggrCtxAddrLen 255
AfNumAggrPfx 0 : AfNumAggrASSet 0 : AfNumSuppmap 0 : AfNumAggrValidPfx 0 :
AfMPathRttP 0x41a0d700
MpathCtxAddr 11011111140 : MpathCtxAddrlen 255 : AfEorSet 0x41a19f98 : NumDfrdPfx 0
AfActPeerHd 0x41a1a3a4 : AfExtDist 1101112312 : AfIntDist 200 : AfLocDist 200
AfNumRRc 0 : AfRR 0 : AfNetRttP 0x41a0d300 : AfNetCtxAddr 1101112392 :
AfNetCtxAddrlen 255
AfNwCtxAddr 1101112443 : AfNwCtxAddrlen 255 : AfNetBKDrRttP 0x41a0d500 :
AfNetBKDRCnt 0 : AfDampHLife 0
AfDampReuse 0 : AfDampSupp 0 : AfDampMaxHld 0 : AfDampCeiling 0 : AfDampRmapP
```

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.5.1.0	Introduced

show ip bgp extcommunity-list

View information on all routes with Extended Community attributes.

Syntax show ip bgp [ipv4 unicast] **extcommunity-list** [list name]

Parameters

ipv4 unicast (OPTIONAL) Enter the **ipv4 unicast** keywords to view information only related to ipv4 unicast routes. list name Enter the extended community list name you wish to view.

Command Modes EXEC

EXEC Privilege

Usage Information To view the total number of COMMUNITY attributes found, use the show ip bgp summary command. The text line above the route table states the number of COMMUNITY attributes found.

The show ip bgp community command without any parameters lists BGP routes with at least one BGP community attribute and the output is the same as for the show ip bgp command output.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp filter-list

CES View the routes that match the filter lists.

Syntax show ip bgp [ipv4 unicast] filter-list as-path-name

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
as-path-name	Enter the name of an AS-PATH.

Command Modes

EXEC

EXEC Privilege

Example Figure 7-13. Command Example: show ip bgp filter-list

```
FTOS#show ip bgp filter-list hello
BGP table version is 80227, local router ID is 120.1.1.1 Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed,
network
Origin codes: i - IGP, e - EGP, ? - incomplete
                                                            LocPrf Weight Path
    Network
                          Next Hop
                                                Metric
* I 6.1.5.0/24
                          192.100.11.2
                                                 20000
                                                               9999
                                                               9999
                                                 20000
                                                                          0 ?
                          192.100.8.2
* I
* I
                                                                          0 ?
  Ι
                          192.100.9.2
                                                 20000
                                                               9999
                                                               9999
                          192.100.10.2
                                                 20000
                                                                          0
*>I
                                                                          0 ?
                          6.1.5.1
                                                 20000
                                                               9999
                                                                          0 ?
                          6.1.6.1
                                                 20000
                                                               9999
                          6.1.20.1
                                                 20000
                                                               9999
* I 6.1.6.0/24
                          192.100.11.2
                                                 20000
                                                               9999
                                                                          0 ?
* I
* I
                          192.100.8.2
                                                 20000
                                                               9999
                                                                          0 ?
                          192.100.9.2
                                                 20000
                                                               9999
                                                                          0 ?
* I
                          192.100.10.2
                                                 20000
                                                               9999
                                                                          0 ?
                          6.1.5.1
                                                 20000
                                                               9999
                                                                          0 ?
                          6.1.6.1
                                                 20000
                                                               9999
                                                                          0
                          6.1.20.1
                                                 20000
                                                               9999
                                                                          0 ?
  I 6.1.20.0/24
                          192.100.11.2
                                                 20000
                                                               9999
                                                                          0 ?
                          192.100.8.2
                                                 20000
                                                               9999
                                                                          0 ?
* I
                          192.100.9.2
                                                 20000
                                                               9999
                                                                          0 ?
                          192.100.10.2
                                                 20000
                                                               9999
FTOS#
```

Table 7-6 defines the information displayed in Figure 7-13.

Table 7-6. Command Example Fields: show ip bgp filter-list

Field	Description
Path source codes	Lists the path sources shown to the right of the last AS number in the Path column:
	• i = internal route entry
	a = aggregate route entry
	• c = external confederation route entry
	• n = network route entry
	• r = redistributed route entry
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

show ip bgp flap-statistics

View flap statistics on BGP routes.

Syntax

show ip bgp [ipv4 unicast] flap-statistics [ip-address [mask]] [filter-list as-path-name] [regexp regular-expression]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
ip-address	(OPTIONAL) Enter the IP address (in dotted decimal format) of the BGP network to view information only on that network.
mask	(OPTIONAL) Enter the network mask (in slash prefix (/x) format) of the BGP network address.
filter-list as-path-name	(OPTIONAL) Enter the keyword filter-list followed by the name of a configured AS-PATH ACL.
regexp regular-expression	Enter a regular expression then use one or a combination of the following characters to match:
	• .= (period) any single character (including a white space)
	• *= (asterisk) the sequences in a pattern (0 or more sequences)
	• += (plus) the sequences in a pattern (1 or more sequences)
	• ? = (question mark) sequences in a pattern (either 0 or 1 sequences). You must enter an escape sequence (CTRL+v) prior to entering the ? regular expression.
	• [] = (brackets) a range of single-character patterns.
	• () = (parenthesis) groups a series of pattern elements to a single element
	• { } = (braces) minimum and the maximum match count
	• ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.
	• \$ = (dollar sign) the end of the output string.

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-14. Command Example: show ip bgp flap-statistics

```
FTOS>show ip bgp flap
BGP table version is 210851, local router ID is 63.114.8.2
Status codes: s suppressed, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network Origin codes: i - IGP, e - EGP, ? - incomplete
                                                            Flaps Duration Reuse
     Network
                                   From
                                                                                                 Path
FTOS>
```

Table 7-7 defines the information displayed in Figure 7-14.

Table 7-7. Command Example Fields: show ip bgp flap-statistics

Field	Description
Network	Displays the network ID to which the route is flapping.
From	Displays the IP address of the neighbor advertising the flapping route.
Flaps	Displays the number of times the route flapped.
Duration	Displays the hours:minutes:seconds since the route first flapped.
Reuse	Displays the hours:minutes:seconds until the flapped route is available.
Path	Lists all the ASs the flapping route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp inconsistent-as

CES

View routes with inconsistent originating Autonomous System (AS) numbers, that is, prefixes that are announced from the same neighbor AS but with a different AS-Path.

Syntax show ip bgp [ipv4 unicast] inconsistent-as

Command Modes EXEC

EXEC Privilege

Example Figure 7-15. Command Example: show ip bgp inconsistent-as (Partial)

TOS>show ip bgp inconsistent-as BGP table version is 280852, local router ID is 10.1.2.100 Status codes: s suppressed, d damped, h history, * valid, > best Path source: I - internal, c - confed-external, r - redistributed, n - network Origin codes: i - IGP, e - EGP, ? - incomplete LocPrf Weight Path Network Next Hop Metric 3.0.0.0/8 63.114.8.33 0 18508 209 7018 80 0 18508 209 7018 80 63.114.8.34 0 18508 209 7018 80 0 18508 701 80 63.114.8.60 63.114.8.33 3.18.135.0/24 0 18508 209 7018 63.114.8.60 63.114.8.34 0 18508 209 7018 0 18508 701 7018 0 18508 209 7018 63.114.8.33 63.114.8.33 4.0.0.0/8 63.114.8.60 0 18508 209 1 i 63.114.8.34 0 18508 209 1 63.114.8.33 0 18508 701 1 63.114.8.33 0 18508 209 1 i 0 18508 209 3549 6.0.0.0/20 63.114.8.60 63.114.8.34 0 18508 209 3549 i 63.114.8.33 0 18508 63.114.8.33 0 18508 209 3549 9.2.0.0/16 63.114.8.60 0 18508 209 701 63.114.8.34 0 18508 209 701 i

Table 7-8. Command Example Fields: show ip bgp inconsistent-as

Fields	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp neighbors

CES Enables you to view the information exchanged by BGP neighbors.

Syntax

show ip bgp [ipv4 unicast] neighbors [ip-address [advertised-routes | dampened-routes | detail | flap-statistics | routes | {received-routes [network [network-mask]]} | {denied-routes [network [network-mask]]}]

Parameters

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
ip-address	(OPTIONAL) Enter the IP address of the neighbor to view only BGP information exchanged with that neighbor.
advertised-routes	(OPTIONAL) Enter the keywords advertised-routes to view only the routes the neighbor sent.
dampened-routes	(OPTIONAL) Enter the keyword dampened-routes to view information on dampened routes from the BGP neighbor.
detail	(OPTIONAL) Enter the keyword detail to view neighbor-specific internal information for the IPv4 Unicast address family.
flap-statistics	(OPTIONAL) Enter the keyword flap-statistics to view flap statistics on the neighbor's routes.
routes	(OPTIONAL) Enter the keywords routes to view only the neighbor's feasible routes.
received-routes [network [network-mask]	(OPTIONAL) Enter the keywords received-routes followed by either the network address (in dotted decimal format) or the network mask (in slash prefix format) to view all information received from neighbors. Note: neighbor soft-reconfiguration inbound must be configured prior to viewing all the information received from the neighbors.
denied-routes [network [network-mask]	(OPTIONAL) Enter the keywords denied-routes followed by either the network address (in dotted decimal format) or the network mask (in slash prefix format) to view all information on routes denied via neighbor inbound filters.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.5.1.0	Added detail option and output now displays default MED value
Version 7.2.1.0	Added received and denied route options
Version 6.3.10	The output is changed to display the total number of advertised prefixes

Example 1 Figure 7-16. Command Example: show ip bgp neighbors (Partial)

```
FTOS#show ip bgp neighbors
BGP neighbor is 100.10.10.2, remote AS 200, external link
  BGP version 4, remote router ID 192.168.2.101
  BGP state ESTABLISHED, in this state for 00:16:12
  Last read 00:00:12, last write 00:00:03
  Hold time is 180, keepalive interval is 60 seconds
Received 1404 messages, 0 in queue
    3 opens, 1 notifications, 1394 updates
    6 keepalives, 0 route refresh requests
  Sent 48 messages, 0 in queue
    3 opens, 2 notifications, 0 updates
    43 keepalives, 0 route refresh requests
Minimum time between advertisement runs is 30 seconds
Minimum time before advertisements start is 0 seconds
  Capabilities received from neighbor for IPv4 Unicast :  \texttt{MULTIPROTO\_EXT(1)} 
    ROUTE REFRESH(2)
    CISCO_ROUTE_REFRESH(128)
  Capabilities advertised to neighbor for IPv4 Unicast :  \texttt{MULTIPROTO\_EXT}(\texttt{1}) 
    ROUTE_REFRESH(2)
    ROUTE REFRESH(2)
    GRACEFUL_RESTART (64)
    CISCO ROUTE REFRESH(128)
  Route map for incoming advertisements is test
  Maximum prefix set to 4 with threshold 75
  For address family: IPv4 Unicast
  BGP table version 34, neighbor version 34
  5 accepted prefixes consume 20 bytes
  Prefix advertised 0, denied 4, withdrawn 0
Prefixes accepted 1 (consume 4 bytes), withdrawn 0 by peer
  Prefixes advertised 0, rejected 0, withdrawn 0 from peer
  Connections established 2; dropped 1
  Last reset 00:18:21, due to Maximum prefix limit reached
  Notification History 'Connection Reset' Sent : 1 Recv: 0
Local host: 100.10.10.1, Local port: 179
Foreign host: 100.10.10.2, Foreign port: 47496
FTOS#
```

Example 2 Figure 7-17. Command Example: show ip bgp neighbors advertised-routes

```
FTOS>show ip bgp neighbors 192.14.1.5 advertised-routes
BGP table version is 74103, local router ID is 33.33.33.33
Status codes: s suppressed, S stale, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed,
n - network
Origin codes: i - IGP, e - EGP, ? - incomplete
                                           Metric LocPrf Weight Path
   Network
                     Next Hop
5000
5000
                                                              32768 ?
                                                              32768 ?
*>I 223.94.249.0/24 223.100.4.249 0
*>I 223.94.250.0/24 223.100.4.250 0
*>I 223.100.0.0/16 223.100.255.254
                                                       100
100
                                                                  0 ?
                                                                  0 ?
                                                         100
                                                                  0 ?
Total number of prefixes: 74102
```

Example 3 Figure 7-18. Command Example: show ip bgp neighbors received-routes

```
FTOS#show ip bgp neighbors 100.10.10.2 received-routes
BGP table version is 13, local router ID is 120.10.10.1
Status codes: s suppressed, S stale, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed n - network, D - denied, S - stale
Origin codes: i - IGP, e - EGP, ? - incomplete
                                                                                  LocPrf Weight Path
                                                                 Metric
      Network
                                  Next Hop
D 70.70.21.0/24 100.10.10.2
D 70.70.23.0/24 100.10.10.2
D 70.70.24.0/24 100.10.10.2
D 70.70.25.0/24 100.10.10.2
*> 70.70.26.0/24 100.10.10.2
*> 70.70.27.0/24 100.10.10.2
*> 70.70.28.0/24 100.10.10.2
*> 70.70.29.0/24 100.10.10.2
      70.70.21.0/24
                                                                                               0 100 200 ?
                                                                                      0
                                                                                          0
                                                                                                    0 100 200 ?
                                                                                                   0 100 200 ?
                                                                                         Ω
                                                                                         0
                                                                                                  0 100 200 ?
0 100 200 ?
                                                                                     0 0 100 200 ?
0 0 100 200 ?
0 0 100 200 ?
0 0 100 200 ?
0 0 100 200 ?
                                                                      0
0
0
FTOS#
```

Example 4 Figure 7-19. Command Example: show ip bgp neighbors denied-routes

```
FTOS#show ip bgp neighbors 100.10.10.2 denied-routes
4 denied paths using 205 bytes of memory
BGP table version is 34, local router ID is 100.10.10.2
Status codes: s suppressed, S stale, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed n - network, D - denied, S - stale
Origin codes: i - IGP, e - EGP, ? - incomplete
                                                                                LocPrf Weight Path
      Network
                                 Next Hop
                                                               Metric
     70.70.21.0/24 100.10.10.2
70.70.22.0/24 100.10.10.2
70.70.23.0/24 100.10.10.2
70.70.24.0/24 100.10.10.2
                                                                                       0 0 100 200 ?
0 0 100 200 ?
D
D
                                                                                       0
                                                                                                 0 100 200 ?
D
      70.70.24.0/24
                                 100.10.10.2
                                                                                       Ω
                                                                                                 0 100 200 ?
FTOS#
```

Table 7-9. Command Example Fields: show ip bgp neighbors

Lines beginning with	Description
BGP neighbor	Displays the BGP neighbor address and its AS number. The last phrase in the line indicates whether the link between the BGP router and its neighbor is an external or internal one. If they are located in the same AS, then the link is internal; otherwise the link is external.
BGP version	Displays the BGP version (always version 4) and the remote router ID.

Table 7-9. Command Example Fields: show ip bgp neighbors

Lines beginning with	Description
BGP state	Displays the neighbor's BGP state and the amount of time in hours:minutes:seconds it has been in that state.
Last read	This line displays the following information:
	last read is the time (hours:minutes:seconds) the router read a message from its neighbor
	hold time is the number of seconds configured between messages from its neighbor
	 keepalive interval is the number of seconds between keepalive messages to help ensure that the TCP session is still alive.
Received messages	This line displays the number of BGP messages received, the number of notifications (error messages) and the number of messages waiting in a queue for processing.
Sent messages	The line displays the number of BGP messages sent, the number of notifications (error messages) and the number of messages waiting in a queue for processing.
Received updates	This line displays the number of BGP updates received and sent.
Soft reconfiguration	This line indicates that soft reconfiguration inbound is configured.
Minimum time	Displays the minimum time, in seconds, between advertisements.
(list of inbound and outbound policies)	Displays the policy commands configured and the names of the Route map, AS-PATH ACL or Prefix list configured for the policy.
For address family:	Displays IPv4 Unicast as the address family.
BGP table version	Displays the which version of the primary BGP routing table the router and the neighbor are using.
accepted prefixes	Displays the number of network prefixes accepted by the router and the amount of memory used to process those prefixes.
Prefix advertised	Displays the number of network prefixes advertised, the number rejected and the number withdrawn from the BGP routing table.
Connections established	Displays the number of TCP connections established and dropped between the two peers to exchange BGP information.
Last reset	Displays the amount of time since the peering session was last reset. Also states if the peer resets the peering session. If the peering session was never reset, the word never is displayed.
Local host:	Displays the peering address of the local router and the TCP port number.
Foreign host:	Displays the peering address of the neighbor and the TCP port number.

Related Commands

show ip bgp	View the current BGP routing table.

show ip bgp next-hop

CES

View all next hops (via learned routes only) with current reachability and flap status. This command only displays one path, even if the next hop is reachable by multiple paths.

Syntax

show ip bgp next-hop

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-20. Command Example: show ip bgp next-hop

FTOS>show ip bg								
Next-hop	Via			RefCount	Cost	Flaps	Time Elapsed	
63.114.8.33	63.114.8.33,	Gi	12/22	240984	0	0	00:18:25	
63.114.8.34	63.114.8.34,	Gi	12/22	135152	0	0	00:18:13	
63.114.8.35	63.114.8.35,	Gi	12/22	1	0	0	00:18:07	
63.114.8.60	63.114.8.60,	Gi	12/22	135155	0	0	00:18:11	
FTOS>								

Table 7-10. Command Example Fields: show ip bgp next-hop

Field	Description
Next-hop	Displays the next-hop IP address.
Via	Displays the IP address and interface used to reach the next hop.
RefCount	Displays the number of BGP routes using this next hop.
Cost	Displays the cost associated with using this next hop.
Flaps	Displays the number of times the next hop has flapped.
Time Elapsed	Displays the time elapsed since the next hop was learned. If the route is down, then this field displays time elapsed since the route went down.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp paths

View all the BGP path attributes in the BGP database.

Syntax

show ip bgp paths [regexp regular-expression]

Parameters

regexp regular-expression

Enter a regular expression then use one or a combination of the following characters to match:

- . = (period) any single character (including a white space)
- * = (asterisk) the sequences in a pattern (0 or more sequences)
- + = (plus) the sequences in a pattern (1 or more sequences)
- ? = (question mark) sequences in a pattern (either 0 or 1 sequences).
 You must enter an escape sequence (CTRL+v) prior to entering the
 ? regular expression.
- [] = (brackets) a range of single-character patterns.
- () = (parenthesis) groups a series of pattern elements to a single element
- { } = (braces) minimum and the maximum match count
- ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.
- \$ = (dollar sign) the end of the output string.

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-21. Command Example: show ip bgp paths (Partial)

```
FTOS#show ip bgp path
Total 16 Paths
Address
               Hash Refcount Metric Path
0x1efe7e5c
                 15
                         10000
                                       32 ?
0x1efe7e1c
                 71
                                       23
                         10000
0x1efe7ddc
                127
                         10000
                                       22 ?
0x1efe7d9c
                183
                         10000
                                       43
0x1efe7d5c
                239
                         10000
                                       {102 103} ?
                                       42 ?
0x1efe7c9c
                283
                             6
0x1efe7b1c
                287
                           336 20000
0x1efe7d1c
                295
                         10000
                                       13 ?
0x1efe7c5c
                339
                                       {92 93} ?
                             6
                         10000
0x1efe7cdc
                                       ì2 ?
                351
                                       {82 83} ?
0x1efe7c1c
                395
                             6
0x1efe7bdc
                451
                             6
                                        {72 73} ?
0x1efe7b5c
                            78
                                    0
                491
0x1efe7adc
                883
                                 120
                                       i
                             2
0x1efe7e9c
                983
                         10000
                                       33 ?
                                    0
0x1efe7b9c
               1003
                                       i
FTOS#
```

Table 7-11. Command Example Fields: show ip bgp paths

Field	Description
Total	Displays the total number of BGP path attributes.
Address	Displays the internal address where the path attribute is stored.
Hash	Displays the hash bucket where the path attribute is stored.
Refcount	Displays the number of BGP routes using this path attribute.
Metric	Displays the MED attribute for this path attribute.
Path	Displays the AS path for the route, with the origin code for the route listed last. Numbers listed between braces {} are AS_SET information.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp paths as-path

View all unique AS-PATHs in the BGP database

Syntax show ip bgp paths as-path

Command Modes EXEC

EXEC Privilege

Example Figure 7-22. Command Example: show ip bgp paths as-path (Partial)

```
FTOS#show ip bgp paths as-path
Total 13 AS-Paths
             Hash Refcount AS-Path
Address
0x1ea3c1ec
               251
                           1 42
0x1ea3c25c
               251
                            1 22
0x1ea3c1b4
               507
                            1 13
                            1 33
1 {92 93}
1 {102 103}
0x1ea3c304
               507
0x1ea3c10c
               763
0x1ea3c144
               763
0x1ea3c17c
               763
                            1 32
1 {72 73}
1 {82 83}
0x1ea3c2cc
               763
0x1ea3c09c
               764
0x1ea3c0d4
               764
0x1ea3c224
              1019
                            1 43
                            1 23
0x1ea3c294
             1019
0x1ea3c02c
              1021
                            4
FTOS#
```

Table 7-12. Command Example Fields: show ip bgp paths community

Field	Description
Address	Displays the internal address where the path attribute is stored.
Hash	Displays the hash bucket where the path attribute is stored.
Refcount	Displays the number of BGP routes using these AS-Paths.
AS-Path	Displays the AS paths for this route, with the origin code for the route listed last. Numbers listed between braces {} are AS_SET information.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp paths community

View all unique COMMUNITY numbers in the BGP database. CES

Syntax show ip bgp paths community

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-23. Command Example: show ip bgp paths community (Partial)

```
E1200-BGP>show ip bgp paths community
Total 293 Communities
              Hash Refcount Community
Address
                          4 209:209 209:6059 209:31272 3908:900 19092:300
0x1ec88a5c
                3
                          4 209:209 209:3039 209:31272 3908:900 19092:300
0x1e0f10ec
               15
                          2 209:209 209:7193 209:21362 3908:900 19092:300
0x1c902234
               37
0x1f588cd4
               41
                         24 209:209 209:6253 209:21362 3908:900 19092:300
0x1e805884
               46
                          2 209:209 209:21226 286:777 286:3033 1899:3033
64675:21092
0x1e433f4c
               46
                          8 209:209 209:5097 209:21362 3908:900 19092:300
                        16 209:209 209:21226 286:40 286:777 286:3040 5606:40
0x1f173294
               48
12955:5606
0x1c9f8e24
                50
                          6 209:209 209:4069 209:21362 3908:900 19092:300
0x1c9f88e4
               53
                          4 209:209 209:3193 209:21362 3908:900 19092:300
0x1f58a944
                57
                          6 209:209 209:2073 209:21362 3908:900 19092:300
0x1ce6be44
               80
                          2 209:209 209:999 209:40832
0x1c6e2374
                80
                           2 209:777 209:41528
0x1f58ad6c
               82
                         46 209:209 209:41528
0x1c6e2064
                83
                          2 209:777 209:40832
0x1f588ecc
                85
                         570 209:209 209:40832
0x1f57cc0c
                98
                           2 209:209 209:21226 286:3031 13646:1044 13646:1124
13646:1154 13646:1164 13646:1184 13646:1194 13646:1204 13646:1214 13646:1224
13646:1234 13646:1244 13646:1254 13646:1264 13646:3000
0x1d65b2ac
              117
                          6 209:209 209:999 209:31272
0x1f5854ac
              119
                         18 209:209 209:21226 286:108 286:111 286:777 286:3033
517:5104
```

Table 7-13. Command Example Fields: show ip bgp paths community

Field	Description
Address	Displays the internal address where the path attribute is stored.
Hash	Displays the hash bucket where the path attribute is stored.
Refcount	Displays the number of BGP routes using these communities.
Community	Displays the community attributes in this BGP path.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp peer-group

CES Enables you to view information on the BGP peers in a peer group.

show ip bgp [ipv4 unicast] peer-group [peer-group-name [detail | summary]]

Parameters

Syntax

ipv4 unicast	(OPTIONAL) Enter the ipv4 unicast keywords to view information only related to ipv4 unicast routes.
peer-group-name	(OPTIONAL) Enter the name of a peer group to view information about that peer group only.

detail	(OPTIONAL) Enter the keyword detail to view detailed status information of the peers in that peer group.
summary	(OPTIONAL) Enter the keyword summary to view status information of the peers in that peer group. The output is the same as that found in show ip bgp summary command

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-24. Command Example: show ip bgp peer-group (Partial)

```
FTOS#show ip bgp peer-group
Peer-group RT-PEERS
Description: ***peering-with-RT***
BGP version 4
Minimum time between advertisement runs is 30 seconds
For address family: IPv4 Unicast
BGP neighbor is RT-PEERS
Number of peers in this group 20
Peer-group members (* - outbound optimized):
   12.1.1.2*
  12.1.1.3*
 12.1.1.4*
  12.1.1.5*
 12.1.1.6*
  12.2.1.2*
 12.2.1.3*
  12.2.1.4*
 12.2.1.5*
  12.2.1.6*
 12.3.1.2*
  12.3.1.3*
  12.3.1.4*
  12.3.1.5*
 12.3.1.6*
 12.4.1.2*
 12.4.1.4*
 12.4.1.5*
```

Table 7-14. Command Example Fields: show ip bgp peer-group

Line beginning with	Description
Peer-group	Displays the peer group's name.
Administratively shut	Displays the peer group's status if the peer group is not enabled. If the peer group is enabled, this line is not displayed.
BGP version	Displays the BGP version supported.
Minimum time	Displays the time interval between BGP advertisements.
For address family	Displays IPv4 Unicast as the address family.
BGP neighbor	Displays the name of the BGP neighbor.
Number of peers	Displays the number of peers currently configured for this peer group.
Peer-group members:	Lists the IP addresses of the peers in the peer group. If the address is outbound optimized, a * is displayed next to the IP address.

Related Commands

neighbor peer-group (assigning peers)	Assign peer to a peer-group.
neighbor peer-group (creating group)	Create a peer group.
show ip bgp peer-group (multicast)	View information on the BGP peers in a peer group.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.8.1.0	Introduced support on S-Series

show ip bgp regexp

Display the subset of BGP routing table matching the regular expressions specified.

Syntax show ip bgp regexp regular-expression [character]

Parameters

regular-expression [character]

Enter a regular expression then use one or a combination of the following characters to match:

- . = (period) any single character (including a white space)
- * = (asterisk) the sequences in a pattern (0 or more sequences)
- + = (plus) the sequences in a pattern (1 or more sequences)
- ? = (question mark) sequences in a pattern (either 0 or 1 sequences). You must enter an escape sequence (CTRL+v) prior to entering the ? regular expression.
- [] = (brackets) a range of single-character patterns.
- () = (parenthesis) groups a series of pattern elements to a single element
- { } = (braces) minimum and the maximum match count
- ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.
- \$ = (dollar sign) the end of the output string.

Command Modes

EXEC

EXEC Privilege

Example Figure 7-25. Command Example: show ip bgp regexp (Partial)

```
FTOS#show ip bgp regexp ^2914+
BGP table version is 3700481, local router ID is 63.114.8.35
Status codes: s suppressed, S stale, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network
Origin codes: i - IGP, e - EGP, ? - incomplete
                          Next Hop
                                                              LocPrf Weight Path
100 0 2914 1239 80 i
                                                  Metric
    Network
*>I 3.0.0.0/8
                                                               100
                          1.1.1.2
*>I 4.0.0.0/8
*>I 4.17.225.0/24
                                                        Ω
                                                                  100
                                                                            0 2914 3356 i
                          1.1.1.2
                                                              100
                         1.1.1.2
                                                     0
                                                                        0 2914 11853 11853 11853 11853 11853 6496
                                                              100
*>I 4.17.226.0/23
                        1.1.1.2
1.1.1.2
                                                     0
                                                                        0 2914 11853 11853 11853 11853 11853 6496
*>I 4.17.251.0/24
                                                     0
                                                              100
                                                                        0 2914 11853 11853 11853 11853 11853 6496
                                                                       0 2914 11853 11853 11853 11853 11853 6496
0 2914 701 6167 6167 6167 i
*>I 4.17.252.0/23
                        1.1.1.2
                                                     0
                                                              100
                                                                 100
*>I 4.19.2.0/23
                        1.1.1.2
1.1.1.2
1.1.1.2
                                                       0
*>I 4.19.16.0/23
                                                        0
                                                                  100
                                                                            0 2914 701 6167 6167 6167 i
*>I 4.21.80.0/22
                                                        0
                                                                  100
                                                                            0 2914 174 4200 16559 i
                         1.1.1.2
*>I 4.21.82.0/24
                                                       0
                                                                  100
                                                                            0 2914 174 4200 16559 i
*>I 4.21.252.0/23
                          1.1.1.2
                                                        0
                                                                  100
                                                                            0 2914 701 6389 8063 19198 i
                         1.1.1.2
*>I 4.23.180.0/24
                                                        0
                                                                 100
                                                                            0 2914 3561 6128 30576 i
*>I 4.36.200.0/21
                          1.1.1.2
                                                       0
                                                                  100
                                                                            0 2914 14742 11854 14135 i
*>I 4.67.64.0/22
                          1.1.1.2
                                                       0
                                                                 100
                                                                           0 2914 11608 19281 i
                                                                          0 2914 3491 29748 i
0 2914 701 668 i
*>I 4.78.32.0/21
                          1.1.1.2
                                                       0
                                                                  100
*>I 6.1.0.0/16
                          1.1.1.2
                                                        0
                                                                 100
*>I 6.2.0.0/22
                                                                  100
                                                                            0 2914 701 668 i
                          1.1.1.2
                                                                          0 2914 701 668 i
*>I 6.3.0.0/18
                          1.1.1.2
                                                                  100
```

Table 7-15. Command Example Fields: show ip bgp regexp

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then non-BGP routes exist in the router's routing table.
Metric	Displays the BGP router's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the AS paths the route passed through to reach the destination network.

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp summary

CES Enables you to view the status of all BGP connections.

Syntax show ip bgp [ipv4 unicast] summary

Command Modes EXEC

EXEC Privilege

Example Figure 7-26. Command Example: show ip bgp summary

```
FTOS#show ip bgp summary
BGP router identifier 120.10.10.1, local AS number 100
BGP table version is 34, main routing table version 34
9 network entrie(s) using 1372 bytes of memory
5 paths using 380 bytes of memory
4 denied paths using 164 bytes of memory

DCD BTB Over all using 385 bytes of memory
BGP-RIB over all using 385 bytes of memory
2 BGP path attribute entrie(s) using 168 bytes of memory 1 BGP AS-PATH entrie(s) using 39 bytes of memory
1 BGP community entrie(s) using 43 bytes of memory
2 neighbor(s) using 7232 bytes of memory
                                      MsgRcvd MsgSent
                                                                       TblVer InQ OutQ Up/Down State/Pfx
Neighbor
                           AS
                       200
100.10.10.2
                                               46
                                                             41
                                                                                 34
                                                                                          0
                                                                                                     0 00:14:33
120.10.10.2
                          300
                                               40
                                                              47
                                                                                34
                                                                                          0
                                                                                                    0 00:37:10
                                                                                                                                     0
FTOS#
```

Table 7-16. Command Example Fields: show ip bgp summary

Field	Description
BGP router identifier	Displays the local router ID and the AS number.
BGP table version	Displays the BGP table version and the main routing table version.
network entries	Displays the number of network entries and route paths and the amount of memory used to process those entries.
paths	Displays the number of paths and the amount of memory used.
denied paths	Displays the number of denied paths and the amount of memory used.
BGP path attribute entries	Displays the number of BGP path attributes and the amount of memory used to process them.
BGP AS-PATH entries	Displays the number of BGP AS_PATH attributes processed and the amount of memory used to process them.
BGP community entries	Displays the number of BGP COMMUNITY attributes processed and the amount of memory used to process them. The show ip bgp community command provides more details on the COMMUNITY attributes.
Dampening enabled	Displayed only when dampening is enabled. Displays the number of paths designated as history, dampened, or penalized.
Neighbor	Displays the BGP neighbor address.
AS	Displays the AS number of the neighbor.
MsgRcvd	Displays the number of BGP messages that neighbor received.
MsgSent	Displays the number of BGP messages that neighbor sent.
TblVer	Displays the version of the BGP table that was sent to that neighbor.
InQ	Displays the number of messages from that neighbor waiting to be processed.
OutQ	Displays the number of messages waiting to be sent to that neighbor. If a number appears in parentheses, the number represents the number of messages waiting to be sent to the peer group.

Table 7-16. Command Example Fields: show ip bgp summary

Field	Description
Up/Down	Displays the amount of time that the neighbor is in the Established stage.
	If the neighbor has never moved into the Established stage, the word never is displayed.
	The output format is:
	Time EstablishedDisplay Example
	< 1 day 00:12:23 (hours:minutes:seconds)
	< 1 week 1d21h (DaysHours)
	> 1 week 11w2d (WeeksDays)
State/Pfxrcd	If the neighbor is in Established stage, the number of network prefixes received.
	If a maximum limit was configured with the neighbor maximum-prefix command, (prfxd) appears in this column.
	If the neighbor is not in Established stage, the current stage is displayed (Idle, Connect, Active, OpenSent, OpenConfirm) When the peer is
	transitioning between states and clearing the routes received, the phrase
	(Purging) may appear in this column.
	If the neighbor is disabled, the phrase (Admin shut) appears in this column.

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show running-config bgp

CES Use this feature to display the current BGP configuration.

Syntax show running-config bgp

Defaults No default values or behavior

Command Modes EXEC Privilege

> Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

timers bgp

CES Adjust BGP Keep Alive and Hold Time timers.

Syntax timers bgp keepalive holdtime

To return to the default, enter **no timers bgp**.

keepalive	Enter a number for the time interval, in seconds, between keepalive messages sent to the neighbor routers.
	Range: 1 to 65535
	Default: 60 seconds
holdtime	Enter a number for the time interval, in seconds, between the last keepalive message and declaring the router dead.
	Range: 3 to 65535
Y 1 C 1: 1	Default: 180 seconds
No default values or	
ROUTER BGP	behavior

MBGP Commands

Parameters

Defaults

Command History

Command Modes

Multiprotocol BGP (MBGP) is an enhanced BGP that enables multicast routing policy throughout the Internet and connecting multicast topologies between BGP and autonomous systems (AS). FTOS MBGP is implemented as per IETF RFC 1858.

FTOS version 7.8.1.0 and later support MBGP for IPv6 on $\fbox{\ \ }$ $\fbox{\ \ }$ and $\fbox{\ \ }$ platforms.

Introduced on E-Series

FTOS version 7.8.1.0 and later support MBGP for IPv4 Multicast only on the S platform.

FTOS version 8.2.1.0 and later support MBGP on the E-Series ExaScale $\boxed{\mathbb{E}_{\bigotimes}}$ platform.

The MBGP commands are:

- address family ipv4 multicast (MBGP)
- aggregate-address
- bgp dampening

Version 7.6.1.0

- clear ip bgp ipv4 multicast
- clear ip bgp dampening
- clear ip bgp flap-statistics
- debug ip bgp dampening
- debug ip bgp dampening
- · debug ip bgp dampening
- debug ip bgp peer-group updates
- debug ip bgp updates
- distance bgp
- neighbor activate
- neighbor advertisement-interval
- neighbor default-originate

- neighbor distribute-list
- neighbor filter-list
- neighbor maximum-prefix
- neighbor next-hop-self
- neighbor remove-private-as
- neighbor route-map
- neighbor route-reflector-client
- network
- redistribute
- redistribute ospf
- show ip bgp ipv4 multicast
- show ip bgp cluster-list
- show ip bgp community
- show ip bgp community-list
- show ip bgp dampened-paths
- show ip bgp filter-list
- show ip bgp flap-statistics
- show ip bgp inconsistent-as
- show ip bgp ipv4 multicast neighbors
- show ip bgp peer-group
- show ip bgp summary

address family ipv4 multicast (MBGP)

CETS

This command changes the context to SAFI (Subsequent Address Family Identifier).

Syntax

address family ipv4 multicast

To remove SAFI context, use the **no address family ipv4 multicast** command.

Parameters

ipv4	Enter the keyword ipv4 to specify the address family as IPV4.
multicast	Enter the keyword multicast to specify multicast as SAFI.

Defaults

IPv4 Unicast

Command Modes

ROUTER BGP (conf-router_bgp)

Usage Information

All subsequent commands will apply to this address family once this command is executed. You can exit from this AFI/SAFI to the IPv4 Unicast (the default) family by entering exit and returning to the Router BGP context.

Command **History**

Version 7.8.1.0	Introduced support on S-Series for MBGP IPv4 Multicast
Version 7.7.1.0	Introduced support on C-Series

aggregate-address

CETS

Summarize a range of prefixes to minimize the number of entries in the routing table.

Syntax

aggregate-address ip-address mask [advertise-map map-name] [as-set] [attribute-map map-name] [summary-only] [suppress-map map-name]

Parameters

ip-address mask	Enter the IP address and mask of the route to be the aggregate address. Enter the IP address in dotted decimal format (A.B.C.D) and mask in / prefix format (x).
advertise-map map-name	(OPTIONAL) Enter the keywords advertise-map followed by the name of a configured route map to set filters for advertising an aggregate route.
as-set	(OPTIONAL) Enter the keyword as-set to generate path attribute information and include it in the aggregate.
	AS_SET includes AS_PATH and community information from the routes included in the aggregated route.
attribute-map map-name	(OPTIONAL) Enter the keywords attribute-map followed by the name of a configured route map to modify attributes of the aggregate, excluding AS_PATH and NEXT_HOP attributes.
summary-only	(OPTIONAL) Enter the keyword summary-only to advertise only the aggregate address. Specific routes will not be advertised.
suppress-map map-name	(OPTIONAL) Enter the keywords suppress-map followed by the name of a configured route map to identify which more-specific routes in the aggregate are suppressed.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

At least one of the routes included in the aggregate address must be in the BGP routing table for the configured aggregate to become active.

Do not add the **as-set** parameter to the aggregate. If routes within the aggregate are constantly changing, the aggregate will flap to keep track of the changes in the AS_PATH.

In route maps used in the **suppress-map** parameter, routes meeting the **deny** clause are not suppress; in other words, they are allowed. The opposite is true: routes meeting the **permit** clause are suppressed.

If the route is injected via the network command, that route will still appear in the routing table if the summary-only parameter is configured in the aggregate-address command.

The summary-only parameter suppresses all advertisements. If you want to suppress advertisements to only specific neighbors, use the neighbor distribute-list command.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

bgp dampening

CETS Enable MBGP route dampening.

> **Syntax bgp dampening** [half-life time] [route-map map-name]

> > To disable route dampening, use the **no bgp dampening** [half-life time] [route-map map-name] command.

Parameters

half-life time	(OPTIONAL) Enter the number of minutes after which the Penalty is decreased. After the router assigns a Penalty of 1024 to a route, the Penalty
	is decreased by half, after the half-life period expires.
	Range: 1 to 45.
	Default: 15 minutes
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.
	Only match commands in the configured route map are supported.

Defaults Disabled.

Command Modes ROUTER BGP Address Family (conf-router_bgp_af)

Command **History**

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

clear_ip bgp ipv4 multicast

CETS Reset MBGP sessions.

Syntax clear ip bgp ipv4 multicast * ip-address [dampening | flap-statistics] peer-group]

Parameters

*	Enter the character * to clear all peers.
ip-address	Enter an IP address in dotted decimal format to clear the prefixes from that neighbor.
dampening	(OPTIONAL) Enter the keyword dampening to clear route flap dampening information.
flap-statistics	(OPTIONAL) Enter the keyword flap-statistics to reset the flap statistics on all prefixes from that neighbor.
peer-group	(OPTIONAL) Enter the keyword peer-group to clear all members of a peer-group.

Command Modes

EXEC Privilege

Command **History**

Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

clear ip bgp dampening

C E S Clear information on route dampening.

Syntax clear ip bgp dampening ipv4 multicast network network-mask

Parameters

dampening	Enter the keyword dampening to clear route flap dampening information.
network	(OPTIONAL) Enter the network address in dotted decimal format (A.B.C.D).
network-mask	(OPTIONAL) Enter the network mask in slash prefix format (/x).

Command Modes

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series	

clear_ip bgp flap-statistics

Clear BGP flap statistics, which includes number of flaps and the time of the last flap.

Syntax clear ip bgp ipv4 multicast flap-statistics network | filter-list | regexp regexp

Parameters

Network	(OPTIONAL) Enter the network address to clear flap statistics in dotted decimal format (A.B.C.D).
filter-list list	(OPTIONAL) Enter the keyword filter-list followed by the name of a configured AS-PATH list (max 16 characters).
regexp regexp	(OPTIONAL) Enter the keyword regexp followed by regular expressions. Use one or a combination of the following:
	• . = (period) any single character (including a white space)
	• *= (asterisk) the sequences in a pattern (0 or more sequences)
	• += (plus) the sequences in a pattern (1 or more sequences)
	 ? = (question mark) sequences in a pattern (either 0 or 1 sequences). You must enter an escape sequence (CTRL+v) prior to entering the ? regular expression.
	• [] = (brackets) a range of single-character patterns.
	• () = (parenthesis) groups a series of pattern elements to a single element
	• { } = (braces) minimum and the maximum match count
	• ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.
	• \$ = (dollar sign) the end of the output string.

Command Modes

EXEC Privilege

Command History

Version 7.8.1.0 Introduced support on S-Series

Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

debug ip bgp dampening

CETS View information on routes being dampened.

Syntax debug ip bgp ipv4 multicast dampening

To disable debugging, enter no debug ip bgp ipv4 multicast dampening

Parameters

Command History

Command Modes

_	dampening	Enter the keyword dampening to clear route flap dampening information.
	EXEC Privilege	
	Version 7.8.1.0	Introduced support on S-Series
	Version 7.7.1.0	Introduced support on C-Series

Introduced IPv6 MGBP support for E-Series

debug ip bgp peer-group updates

Version 7.6.1.0

View information about BGP peer-group updates.

debug ip bgp peer-group peer-group-name updates [in | out]

To disable debugging, enter no debug ip bgp peer-group peer-group-name updates [in | out] command.

Parameters

peer-group peer-group-name	Enter the keyword peer-group followed by the name of the peer-group.
updates	Enter the keyword updates to view BGP update information.
in	(OPTIONAL) Enter the keyword in to view only BGP updates received from neighbors.
out	(OPTIONAL) Enter the keyword out to view only BGP updates sent to neighbors.

Command Modes

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

debug ip bgp updates

View information about BGP updates.

debug ip bgp updates [in | out]

To disable debugging, enter **no debug ip bgp updates** [in | out] command.

Parameters

updates	Enter the keyword updates to view BGP update information.
in	(OPTIONAL) Enter the keyword in to view only BGP updates received from neighbors.
out	(OPTIONAL) Enter the keyword out to view only BGP updates sent to neighbors.

Command Modes

EXEC Privilege

Defaults

Disabled.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

distance bgp



Define an administrative distance for routes.

Syntax

distance bgp external-distance internal-distance local-distance

To return to default values, enter **no distance bgp**.

Parameters

external-distance	Enter a number to assign to routes learned from a neighbor external to the AS. Range: 1 to 255. Default: 20
internal-distance	Enter a number to assign to routes learned from a router within the AS. Range: 1 to 255. Default: 200
local-distance	Enter a number to assign to routes learned from networks listed in the network command. Range: 1 to 255. Default: 200

Defaults

external-distance = 20; internal-distance = 200; local-distance = 200.

Command Modes

ROUTER BGP (conf-router_bgp_af)



Caution: Dell Networking recommends that you do not change the administrative distance of internal routes. Changing the administrative distances may cause routing table inconsistencies.

Usage Information

The higher the administrative distance assigned to a route means that your confidence in that route is low. Routes assigned an administrative distance of 255 are not installed in the routing table. Routes from confederations are treated as internal BGP routes.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor activate

This command allows the specified neighbor/peer group to be enabled for the current AFI/SAFI.

Syntax

neighbor [ip-address | peer-group-name] **activate**

To disable, use the **no neighbor** [ip-address | peer-group-name] activate command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group
activate	Enter the keyword activate to enable the neighbor/peer group in the new AFI/SAFI.

Defaults

Disabled

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

By default, when a neighbor/peer group configuration is created in the Router BGP context, it is enabled for the IPv4/Unicast AFI/SAFI. By using activate in the new context, the neighbor/peer group is enabled for AFI/SAFI.

Related **Commands**

Command **History**

address family ipv4 multicast (MBGP)		Changes the context to SAFI	
Version 7.8.1.0	Introduced support on S	S-Series	
Version 7.7.1.0	Introduced support on C	C-Series	
Version 7.6.1.0	Introduced IPv6 MGBP	support for E-Series	

neighbor advertisement-interval



Set the advertisement interval between BGP neighbors or within a BGP peer group.

Syntax

neighbor { ip-address | peer-group-name } **advertisement-interval** seconds

To return to the default value, use the **no neighbor** { *ip-address* | *peer-group-name*} advertisement-interval command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to set the advertisement interval for all routers in the peer group.
seconds	Enter a number as the time interval, in seconds, between BGP advertisements.
	Range: 0 to 600 seconds. Default: 5 seconds for internal BGP peers; 30 seconds for external BGP peers.

Defaults seconds = 5 seconds (internal peers); seconds = 30 seconds (external peers)

Command Modes ROUTER BGP Address Family (conf-router_bgp_af)

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor default-originate

CETS Inject the default route to a BGP peer or neighbor.

Syntax neighbor { ip-address | peer-group-name} default-originate [route-map map-name]

To remove a default route, use the **no neighbor** { *ip-address* | *peer-group-name*} **default-originate** command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to set the default route of all routers in that peer group.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.

Defaults Not configured.

Command Modes ROUTER BGP Address Family (conf-router_bgp_af)

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor distribute-list

Distribute BGP information via an established prefix list.

Syntax neighbor [ip-address | peer-group-name] distribute-list prefix-list-name [in | out]

To delete a neighbor distribution list, use the **no neighbor** [*ip-address* | *peer-group-name*] **distribute-list** *prefix-list-name* [**in** | **out**] command.

Parameters

CETS

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to apply the distribute list filter to all routers in the peer group.
prefix-list-name	Enter the name of an established prefix list. If the prefix list is not configured, the default is permit (to allow all routes).
in	Enter the keyword in to distribute only inbound traffic.
out	Enter the keyword out to distribute only outbound traffic.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information Other BGP filtering commands include: neighbor filter-list, ip as-path access-list, and neighbor

route-map.

Related **Commands**

ip as-path access-list	Configure IP AS-Path ACL.
neighbor filter-list	Assign a AS-PATH list to a neighbor or peer group.
neighbor route-map	Assign a route map to a neighbor or peer group.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor filter-list

CETS

Configure a BGP filter based on the AS-PATH attribute.

Syntax

neighbor [ip-address | peer-group-name] filter-list aspath access-list-name [in | out]

To delete a BGP filter, use the **no neighbor** [ip-address | peer-group-name] **filter-list aspath** access-list-name [in | out] command.

Parameters

ip-address	Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	Enter the name of the peer group to apply the filter to all routers in the peer group.
access-list-name	Enter the name of an established AS-PATH access list (up to 140 characters).
	If the AS-PATH access list is not configured, the default is permit (to allow routes).
in	Enter the keyword in to filter inbound BGP routes.
out	Enter the keyword out to filter outbound BGP routes.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

Use the ip as-path access-list command syntax in the CONFIGURATION mode to enter the AS-PATH ACL mode and configure AS-PATH filters to deny or permit BGP routes based on information in their AS-PATH attribute.

Related Commands

ip as-path access-list	Enter AS-PATH ACL mode and configure AS-PATH filters.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

Command History

neighbor maximum-prefix

CETS

Control the number of network prefixes received.

Syntax

neighbor *ip-address* | *peer-group-name* **maximum-prefix** *maximum* [threshold] [**warning-only**]

To return to the default values, use the **no neighbor** *ip-address* | *peer-group-name* **maximum-prefix** *maximum* command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group.
maximum	Enter a number as the maximum number of prefixes allowed for this BGP router. Range: 1 to 4294967295.
threshold	(OPTIONAL) Enter a number to be used as a percentage of the <i>maximum</i> value. When the number of prefixes reaches this percentage of the <i>maximum</i> value, FTOS sends a message.
	Range: 1 to 100 percent.
	Default: 75
warning-only	(OPTIONAL) Enter the keyword warning-only to set the router to send a log message when the maximum value is reached. If this parameter is not set, the router stops peering when the maximum number of prefixes is reached.

Defaults

threshold = 75

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor next-hop-self

CETS

Enables you to configure the router as the next hop for a BGP neighbor.

Syntax

neighbor *ip-address* | *peer-group-name* **next-hop-self**

To return to the default setting, use the **no neighbor** *ip-address* | *peer-group-name* **next-hop-self** command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group.

Defaults

Disabled.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information If the set next-hop command in the ROUTE-MAP mode is configured, its configuration takes precedence over the neighbor next-hop-self command.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor remove-private-as

Remove private AS numbers from the AS-PATH of outgoing updates.

Syntax

neighbor ip-address | peer-group-name remove-private-as

To return to the default, use the **no neighbor** ip-address | peer-group-name remove-private-as command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor to remove the private AS numbers.
peer-group-name	(OPTIONAL) Enter the name of the peer group to remove the private AS numbers

Defaults

Disabled (that is, private AS number are not removed).

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Command **History**

Version	7.8.1.0	Introduced support on S-Series
Version	7.7.1.0	Introduced support on C-Series
Version	7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor route-map



Apply an established route map to either incoming or outbound routes of a BGP neighbor or c peer group.

Syntax

neighbor [ip-address | peer-group-name] **route-map** map-name [in | out]

To remove the route map, use the **no neighbor** [ip-address | peer-group-name] **route-map** map-name [in | out] command.

Parameters

out	Enter the keyword out to filter outbound routes.
in	Enter the keyword in to filter inbound routes.
	If the Route map is not configured, the default is deny (to drop all routes).
map-name	Enter the name of an established route map.
peer-group-name	(OPTIONAL) Enter the name of the peer group.
ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

When you apply a route map to outbound routes, only routes that match at least one section of the route map are permitted.

If you identify a peer group by name, the peers in that peer group inherit the characteristics in the Route map used in this command. If you identify a peer by IP address, the Route map overwrites either the inbound or outbound policies on that peer.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

neighbor route-reflector-client



Configure a neighbor as a member of a route reflector cluster.

Syntax neighbor ip-address | peer-group-name route-reflector-client

To indicate that the neighbor is not a route reflector client or to delete a route reflector configuration, use the **no neighbor** *ip-address* | *peer-group-name* **route-reflector-client** command.

Parameters

ip-address	(OPTIONAL) Enter the IP address of the neighbor in dotted decimal format.
peer-group-name	(OPTIONAL) Enter the name of the peer group.
	All routers in the peer group receive routes from a route reflector.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

The first time you enter this command it configures the neighbor as a route reflector and members of the route-reflector cluster. Internal BGP (IBGP) speakers do not need to be fully meshed if you configure a route reflector.

When all clients of a route reflector are disabled, the neighbor is no longer a route reflector.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

network



Specify the networks for the BGP process and enter them in the BGP routing table.

Syntax

network *ip-address mask* [**route-map** *map-name*]

To remove a network, use the **no network** *ip-address mask* [route-map map-name] command.

Parameters

ip-address	Enter an IP address in dotted decimal format of the network.
mask	Enter the mask of the IP address in the slash prefix length format (for example, /24).
	The mask appears in command outputs in dotted decimal format (A.B.C.D).
route-map	(OPTIONAL) Enter the keyword route-map followed by the name of an established route
map-name	map.
	Only the following ROUTE-MAP mode commands are supported:
	match ip address
	• set community
	• set local-preference
	• set metric
	• set next-hop
	• set origin
	• set weight
	If the route map is not configured, the default is deny (to drop all routes).

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

FTOS resolves the network address configured by the network command with the routes in the main routing table to ensure that the networks are reachable via non-BGP routes and non-default routes.

Related Commands

Command	d
History	v

redistribute	Redistribute routes into BGP.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

redistribute



Redistribute routes into BGP.

Syntax

redistribute [connected | static] [route-map map-name]

To disable redistribution, use the **no redistribution** [connected | static] [route-map map-name] command.

Parameters

connected	Enter the keyword connected to redistribute routes from physically connected
	interfaces.

static	Enter the keyword static to redistribute manually configured routes.
	These routes are treated as incomplete routes.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of an established route map. Only the following ROUTE-MAP mode commands are supported:
	 match ip address set community set local-preference set metric set next-hop set origin set weight If the route map is not configured, the default is deny (to drop all routes).

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

If you do not configure default-metric command, in addition to the redistribute command, or there is no route map to set the metric, the metric for redistributed static and connected is "0".

To redistribute the default route (0.0.0.0/0) configure the neighbor default-originate command.

Inject the default route.

Related Commands

Command History

	-
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series



Redistribute OSPF routes into BGP.

neighbor default-originate

Syntax

redistribute ospf process-id [[match external $\{1 \mid 2\}$] [match internal]] [route-map map-name]

To stop redistribution of OSPF routes, use the **no redistribute ospf** *process-id* command.

Parameters

process-id	Enter the number of the OSPF process. Range: 1 to 65535
match external {1 2}	(OPTIONAL) Enter the keywords match external to redistribute OSPF external routes. You can specify 1 or 2 to redistribute those routes only.
match internal	(OPTIONAL) Enter the keywords match internal to redistribute OSPF internal routes only.
route-map map-name	(OPTIONAL) Enter the keywords route-map followed by the name of a configured Route map.

Defaults

Not configured.

Command Modes

ROUTER BGP Address Family (conf-router_bgp_af)

Usage Information

When you enter redistribute ospf process-id command without any other parameters, FTOS redistributes all OSPF internal routes, external type 1 routes, and external type 2 routes.

This feature is not supported by an RFC.

Command History

Version	n 7.8.1.0	Introduced support on S-Series
Version	n 7.7.1.0	Introduced support on C-Series
Version	n 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp ipv4 multicast

CETS

View the current MBGP routing table for the system.

Syntax

show ip bgp ipv4 multicast [detail | network [network-mask] [length]]

Parameters

detail	(OPTIONAL) Enter the keyword detail to display BGP internal information for the IPv4 Multicast address family.	
network	(OPTIONAL) Enter the network address (in dotted decimal format) of the BGP network to view information only on that network.	
network-mask	(OPTIONAL) Enter the network mask (in slash prefix format) of the BGP network address.	
longer-prefixes	(OPTIONAL) Enter the keyword longer-prefixes to view all routes with a common prefix.	

Command Modes

EXEC

EXEC Privilege

Example

Figure 7-27. Command Example: show ip bgp

```
FTOS#show ip bgp ipv4 multicast
BGP table version is 14, local router ID is 100.10.10.1
Status codes: s suppressed, S stale, d damped, h history, * valid, > best
Path source: I - internal, a - aggregate, c - confed-external, r - redistributed, n - network
Origin codes: i - IGP, e - EGP, ? - incomplete
                                                                 LocPrf Weight Path
    Network
                           Next Hop
                                                    Metric
*>I 25.1.0.0/16
                                                                 100 0 i
                           25.25.25.25
                                                          Ω
                                                                                0 ?
*>I 25.2.0.0/16
                           25.25.25.26
                                                          0
                                                                     100
*>I 25.3.0.0/16
                           211.1.1.165
                                                          Ω
                                                                     100
                                                                                0 ?
                          0.0.0.0
                                                                          32768 ?
*>r 144.1.0.0/16
                                                          0
*>r 144.2.0.0/16
                           100.10.10.10
                                                                           32768 ?
*>r 144.3.0.0/16
                           211.1.1.135
                                                          0
                                                                           32768 ?
*>n 145.1.0.0/16
                           0.0.0.0
                                                                           32768 i
FTOS#
```

Table 7-17. Command Example Fields: show ip bgp

Field	Description
Network	Displays the destination network prefix of each BGP route.
Next Hop	Displays the next hop address of the BGP router. If 0.0.0.0 is listed in this column, then local routes exist in the routing table.
Metric	Displays the BGP route's metric, if assigned.
LocPrf	Displays the BGP LOCAL_PREF attribute for the route.
Weight	Displays the route's weight
Path	Lists all the ASs the route passed through to reach the destination network.

Related Commands

Command History

snow ip ogp comm	unity view BGP communities.
Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

View DCD communities

Introduced support on S-Series

show ip bgp cluster-list

C E S View BGP neighbors in a specific cluster.

Version 7.8.1.0

Syntax show ip bgp ipv4 multicast cluster-list [cluster-id]

Parameters

cluster-id (OPTIONAL) Enter the cluster id in dotted decimal format.

Command Modes

EXEC

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp community

CES View information on all routes with Community attributes or view specific BGP community groups.

Syntax show ip bgp ipv4 multicast community [community-number] [local-as] [no-export] [no-advertise]

Parameters

community-number	Enter the community number in AA:NN format where AA is the AS number (2 bytes) and NN is a value specific to that autonomous system.
	You can specify up to eight community numbers to view information on those community groups.
local-AS	Enter the keywords local-AS to view all routes with the COMMUNITY attribute of NO_EXPORT_SUBCONFED.
	All routes with the NO_EXPORT_SUBCONFED (0xFFFFFF03) community attribute must not be advertised to external BGP peers.
no-advertise	Enter the keywords no-advertise to view all routes containing the well-known community attribute of NO_ADVERTISE.
	All routes with the NO_ADVERTISE (0xFFFFFF02) community attribute must not be advertised to other BGP peers.
no-export	Enter the keywords no-export to view all routes containing the well-known community attribute of NO_EXPORT.
	All routes with the NO_EXPORT (0xFFFFFF01) community attribute must not be advertised outside a BGP confederation boundary.

Command Modes

EXEC

EXEC Privilege

Usage Information

To view the total number of COMMUNITY attributes found, use the show ip bgp summary command. The text line above the route table states the number of COMMUNITY attributes found.

The show ip bgp community command without any parameters lists BGP routes with at least one BGP community attribute and the output is the same as for the show ip bgp command output.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp community-list

CETS View routes that are affected by a specific community list.

Syntax show ip bgp ipv4 multicast community-list community-list-name

Parameters	community-list-name	Enter the name of a configured IP community list.
Command Modes	EXEC	
	EXEC Privilege	

Command History

Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	

show ip bgp dampened-paths

CETS View BGP routes that are dampened (non-active).

Syntax show ip bgp ipv4 multicast dampened-paths

Command Modes EXEC

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp filter-list

CETS View the routes that match the filter lists.

Syntax show ip bgp ipv4 multicast filter-list as-path-name

Parameters as-path-name Enter the name of an AS-PATH.

Command Modes EXEC

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp flap-statistics

CETS View flap statistics on BGP routes.

Syntax show ip bgp ipv4 multicast flap-statistics [ip-address [mask]] [filter-list as-path-name] [regexp regular-expression]

Parameters

ip-address	(OPTIONAL) Enter the IP address (in dotted decimal format) of the BGP network to view information only on that network.
mask	(OPTIONAL) Enter the network mask (in slash prefix $(/x)$ format) of the BGP network address.

filter-list as-path-name	(OPTIONAL) Enter the keyword filter-list followed by the name of a configured AS-PATH ACL.
regexp regular-expression	Enter a regular expression then use one or a combination of the following characters to match:
	• . = (period) any single character (including a white space)
	• * = (asterisk) the sequences in a pattern (0 or more sequences)
	• += (plus) the sequences in a pattern (1 or more sequences)
	• ? = (question mark) sequences in a pattern (either 0 or 1 sequences). You must enter an escape sequence (CTRL+v) prior to entering the ? regular expression.
	• [] = (brackets) a range of single-character patterns.
	• () = (parenthesis) groups a series of pattern elements to a single element
	• { } = (braces) minimum and the maximum match count
	• ^ = (caret) the beginning of the input string. If the caret is used at the beginning of a sequence or range, it matches on everything BUT the characters specified.
	• \$ = (dollar sign) the end of the output string.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

show ip bgp inconsistent-as



View routes with inconsistent originating Autonomous System (AS) numbers, that is, prefixes that are announced from the same neighbor AS but with a different AS-Path.

show ip bgp ipv4 multicast inconsistent-as **Syntax**

Command Modes EXEC

EXEC Privilege

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series

show ip bgp ipv4 multicast neighbors © E T S Enables you to view the information exchanged by BGP neighbors.

CETS

Syntax

show ip bgp ipv4 multicast neighbors [ip-address [advertised-routes | dampened-routes | detail | flap-statistics | routes]]

Parameters

ip-address	(OPTIONAL) Enter the IP address, in either IPv4 or IPv6 format, of the neighbor to view only BGP information exchanged with that neighbor.
advertised-routes	(OPTIONAL) Enter the keywords advertised-routes to view only the routes the neighbor sent.
dampened-routes	(OPTIONAL) Enter the keyword dampened-routes to view information on dampened routes from the BGP neighbor.
detail	(OPTIONAL) Display detailed neighbor information.
flap-statistics	(OPTIONAL) Enter the keyword flap-statistics to view flap statistics on the neighbor's routes.
routes	(OPTIONAL) Enter the keywords routes to view only the neighbor's feasible routes.

Command Modes

EXEC

EXEC Privilege

Example Figure 7-28. Command Example: show ip bgp ipv4 multicast neighbors

```
FTOS#show ip bgp ipv4 multicast neighbors
BGP neighbor is 25.25.25.25, remote AS 6400, internal link
  BGP version 4, remote router ID 25.25.25.25
  BGP state ESTABLISHED, in this state for 00:02:18
  Last read 00:00:16, hold time is 180, keepalive interval is 60 seconds
Received 1404 messages, 0 in queue
    3 opens, 1 notifications, 1394 updates
  6 keepalives, 0 route refresh requests
Sent 48 messages, 0 in queue
    3 opens, 2 notifications, 0 updates
    43 keepalives, 0 route refresh requests
Minimum time between advertisement runs is 5 seconds
Minimum time before advertisements start is 0 seconds
  Capabilities received from neighbor for IPv4 unicast : MULTIPROTO EXT(1)
    ROUTE_REFRESH(2)
CISCO_ROUTE_REFRESH(128)
  Capabilities advertised to neighbor for IPv4 Multicast: MULTIPROTO_EXT(1)
    ROUTE_REFRESH(2)
    CISCO ROUTE REFRESH(128)
  Update source set to Loopback 0
  For address family: IPv4 Multicast
  BGP table version 14, neighbor version 14
  3 accepted prefixes consume 12 bytes
Prefixes accepted 1 (consume 4 bytes), withdrawn 0 by peer
  Prefixes advertised 0, rejected 0, withdrawn 0 from peer
Connections established 2; dropped 1
  Last reset 00:03:17, due to user reset
  Notification History
   'Connection Reset' Sent : 1 Recv: 0
Local host: 100.10.10.1, Local port: 179
Foreign host: 25.25.25.25, Foreign port: 2290
BGP neighbor is 211.1.1.129, remote AS 640, external link
  BGP version 4, remote router ID 0.0.0.0
  BGP state ACTIVE, in this state for 00:00:36
  Last read 00:00:41, hold time is 180, keepalive interval is 60 seconds
  Received 28 messages, 0 notifications, 0 in queue
  Sent 6 messages, 3 notifications, 0 in queue
  Received 18 updates, Sent 6 updates
  Route refresh request: received 0, sent 0
  Minimum time between advertisement runs is 30 seconds
  For address family: IPv4 Multicast BGP table version 14, neighbor version 0 \,
  0 accepted prefixes consume 0 bytes
  Prefix advertised 0, rejected 0, withdrawn 0
  Connections established 3; dropped 3
  Last reset 00:00:37, due to user reset
  Notification History
   'Connection Reset' Sent : 3 Recv: 0
  No active TCP connection
FTOS#
```

Table 7-18. Command Example Fields: show ip bgp ipv4 multicast neighbors

Lines beginning with	Description
BGP neighbor	Displays the BGP neighbor address and its AS number. The last phrase in the line indicates whether the link between the BGP router and its neighbor is an external or internal one. If they are located in the same AS, then the link is internal; otherwise the link is external.
BGP version	Displays the BGP version (always version 4) and the remote router ID.

Table 7-18. Command Example Fields: show ip bgp ipv4 multicast neighbors

Lines beginning with	Description
BGP state	Displays the neighbor's BGP state and the amount of time in hours:minutes:seconds it has been in that state.
Last read	This line displays the following information:
	• last read is the time (hours:minutes:seconds) the router read a message from its neighbor
	• hold time is the number of seconds configured between messages from its neighbor
	 keepalive interval is the number of seconds between keepalive messages to help ensure that the TCP session is still alive.
Received messages	This line displays the number of BGP messages received, the number of notifications (error messages) and the number of messages waiting in a queue for processing.
Sent messages	The line displays the number of BGP messages sent, the number of notifications (error messages) and the number of messages waiting in a queue for processing.
Received updates	This line displays the number of BGP updates received and sent.
Minimum time	Displays the minimum time, in seconds, between advertisements.
(list of inbound and outbound policies)	Displays the policy commands configured and the names of the Route map, AS-PATH ACL or Prefix list configured for the policy.
For address family:	Displays IPv4 Unicast as the address family.
BGP table version	Displays the which version of the primary BGP routing table the router and the neighbor are using.
accepted prefixes	Displays the number of network prefixes accepted by the router and the amount of memory used to process those prefixes.
Prefix advertised	Displays the number of network prefixes advertised, the number rejected and the number withdrawn from the BGP routing table.
Connections established	Displays the number of TCP connections established and dropped between the two peers to exchange BGP information.
Last reset	Displays the amount of time since the peering session was last reset. Also states if the peer resets the peering session.
	If the peering session was never reset, the word never is displayed.
Local host:	Displays the peering address of the local router and the TCP port number.
Foreign host:	Displays the peering address of the neighbor and the TCP port number.

Related Commands

Command History

show ip bgp	View the current BGP routing table.	
Version 7.8.1.0	Introduced support on S-Series	
Version 7.7.1.0	Introduced support on C-Series	
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series	

show ip bgp peer-group

CEIS Enables you to view information on the BGP peers in a peer group.

show ip bgp ipv4 multicast peer-group [peer-group-name [detail | summary]] Syntax

Parameters

peer-group-name	(OPTIONAL) Enter the name of a peer group to view information about that peer group only.
detail	(OPTIONAL) Enter the keyword detail to view detailed status information of the peers in that peer group.
summary	(OPTIONAL) Enter the keyword summary to view status information of the peers in that peer group. The output is the same as that found in show ip bgp summary command

Command Modes

EXEC

EXEC Privilege

Related **Commands**

neighbor peer-group (assigning peers)	Assign peer to a peer-group.
neighbor peer-group (creating group)	Create a peer group.
show ip bgp peer-group	View information on the BGP peers in a peer group.

Command **History**

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series
Version 7.5.1.0	Modified: added detail option

show ip bgp summary

CETS Enables you to view the status of all BGP connections.

Syntax show ip bgp ipv4 multicast summary

Command Modes EXEC

EXEC Privilege

Example Figure 7-29. Command Example: show ip bgp ipv4 multicast summary

FTOS#sho ip bgp ipv4 multicast summary
BGP router identifier 100.10.10.1, local AS number 6400
BGP table version is 14, main routing table version 14
7 network entrie(s) and 7 paths using 972 bytes of memory
2 BGP path attribute entrie(s) using 112 bytes of memory
1 BGP AS-PATH entrie(s) using 35 bytes of memory MsgRcvd MsgSent Neighbor AS TblVer InQ OutQ Up/Down State/Pfx 6400 9 25.25.25.25 21 14 0 00:02:04 0 00:00:21 Active 211.1.1.129 640 28 6 FTOS#

Table 7-19. Command Example Fields: show ip bgp ipv4 multicast summary

Field	Description
BGP router identifier	Displays the local router ID and the AS number.
BGP table version	Displays the BGP table version and the main routing table version.
network entries	Displays the number of network entries and route paths and the amount of memory used to process those entries.
BGP path attribute entries	Displays the number of BGP path attributes and the amount of memory used to process them.
BGP AS-PATH entries	Displays the number of BGP AS_PATH attributes processed and the amount of memory used to process them.
BGP community entries	Displays the number of BGP COMMUNITY attributes processed and the amount of memory used to process them. The show ip bgp community command provides more details on the COMMUNITY attributes.
Dampening enabled	Displayed only when dampening is enabled. Displays the number of paths designated as history, dampened, or penalized.
Neighbor	Displays the BGP neighbor address.
AS	Displays the AS number of the neighbor.
MsgRcvd	Displays the number of BGP messages that neighbor received.
MsgSent	Displays the number of BGP messages that neighbor sent.
TblVer	Displays the version of the BGP table that was sent to that neighbor.
InQ	Displays the number of messages from that neighbor waiting to be processed.
OutQ	Displays the number of messages waiting to be sent to that neighbor. If a number appears in parentheses, the number represents the number of messages waiting to be sent to the peer group.
Up/Down	Displays the amount of time (in hours:minutes:seconds) that the neighbor is in the Established stage. If the neighbor has never moved into the Established stage, the word never is
	displayed.
State/Pfx	If the neighbor is in Established stage, the number of network prefixes received.
	If a maximum limit was configured with the neighbor maximum-prefix command, (prfxd) appears in this column.
	If the neighbor is not in Established stage, the current stage is displayed (Idle, Connect, Active, OpenSent, OpenConfirm) When the peer is transitioning between states and clearing the routes received, the phrase (Purging) may appear in this column.
	If the neighbor is disabled, the phrase (Admin shut) appears in this column.

Command History

Version 7.8.1.0	Introduced support on S-Series
Version 7.7.1.0	Introduced support on C-Series
Version 7.6.1.0	Introduced IPv6 MGBP support for E-Series

BGP Extended Communities (RFC 4360)

BGP Extended Communities, as defined in RFC 4360, is an optional transitive BGP attribute. It provides two major advantages over Standard Communities:

- The range is extended from 4-octet (AA:NN) to 8-octet (Type:Value) to provide enough number communities.
- Communities are structured using a new "Type" field (1 or 2-octets), allowing you to provide granular control/filter routing information based on the type of extended communities.

The BGP Extended Community commands are:

- deny
- deny regex
- description
- ip extcommunity-list
- match extcommunity
- permit
- permit regex
- set extcommunity rt
- set extcommunity soo
- show ip bgp ipv4 extcommunity-list
- show ip bgp paths extcommunity
- show ip extcommunity-list
- show running-config extcommunity-list

deny



Use this feature to reject (deny) from the two types of extended communities, Route Origin (rt) or Site-of-Origin (soo).

Syntax

deny {rt | soo} {as4 ASN4:NN | ASN:NNNN | IPADDR:NN}

To remove (delete) the rule, use the **no deny** {rt | soo} {as4 ASN4:NN | ASN:NNNN | IPADDR:NN} command.

Parameters

rt	Enter the keyword rt to designate a Route Origin community
s00	Enter the keyword SOO to designate a Site-of-Origin community (also known as Route Origin).
as4 ASN4:NN	Enter the keyword as4 followed by the 4-octet AS specific extended community number in the format ASN4:NN (4-byte AS number:2-byte community value).
ASN:NNNN	Enter the 2-octet AS specific extended community number in the format ASN:NNNN (2-byte AS number:4-byte community value).
IPADDR:NN	Enter the IP address specific extended community in the format IPADDR:NN (4-byte IPv4 Unicast Address:2-byte community value)

Defaults

Not configured

Command Modes

CONFIGURATION (conf-ext-community-list)

Related Commands

permit	Configure to add (permit) rules
show ip extcommunity-list	Display the Extended Community list
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on E-Series

Command History

deny regex

CES

This features enables you to specify an extended communities to reject (deny) using a regular expressions (regex).

Syntax deny regex { regex}

To remove, use the **no deny regex** { *regex*} command.

Parameters

regex Enter a regular expression.

Defaults Not configured

Command Modes CONFIGURATION (conf-ext-community-list)

Usage Duplicate commands are silently accepted. **Information**

permit regex

Example Figure 7-30. Commands Example: deny regexp

FTOS(conf-ext-community-list)#deny regexp 123 FTOS(conf-ext-community-list)#

Related Commands

Command History

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

Permit a community using a regular expression

description

Use this feature to designate a meaningful description to the extended community.

Syntax description { line}

To remove the description, use the **no description** { *line*} command.

Parameters

line Enter a description (maximum 80 characters).

Defaults Not configured

Command Modes CONFIGURATION (conf-ext-community-list)

> Command History

Parameters

Defaults

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

Enter a community list name (maximum 16 characters).

ip extcommunity-list

Use this feature to enter the Extended Community-list mode.

Syntax ip extcommunity-list word

To exit from this mode, use the **exit** command.

word

Command Modes CONFIGURATION (conf-ext-community-list)

No defaults values or behavior

Usage This new mode will change the prompt. See the example below. Information

Example Figure 7-31. Command Example: ip extcommunity-list

> FTOS(conf)#ip extcommunity-list test FTOS (conf-ext-community-list) #

Command History

Parameters

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

match extcommunity

CES Use this feature to match an extended community in the Route Map mode.

Syntax match extcommunity { extended community list name}

extended community list name

To change the match, use the **no match extcommunity** { extended community list name}

command.

Defaults No defaults values or behavior

Command Modes ROUTE MAP (config-route-map)

> Usage Like standard communities, extended communities can be used in route-map to match the attribute. Information

Enter the name of the extended community list.

Example

Figure 7-32. Command Example: match extcommunity

FTOS(config-route-map) #match extcommunity Freedombird FTOS(config-route-map)#

Command History

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

permit

CES

Use this feature to add rules (permit) from the two types of extended communities, Route Origin (rt) or Site-of-Origin (soo).

Syntax

permit {rt | soo} {as4 ASN4:NN | ASN:NNNN | IPADDR:NN}

To change the rules, use the **no permit** {**rt** | **soo**} {**as4** *ASN4:NN* | *ASN:NNNN* | *IPADDR:NN*} command.

Parameters

rt	Enter the keyword rt to designate a Route Origin community
soo	Enter the keyword soo to designate a Site-of-Origin community (also known as Route Origin).
as4 ASN4:NN	Enter the keyword as4 followed by the 4-octet AS specific extended community number in the format ASN4:NN (4-byte AS number:2-byte community value).
ASN:NNNN	Enter the 2-octet AS specific extended community number in the format ASN:NNNN (2-byte AS number:4-byte community value).
IPADDR:NN	Enter the IP address specific extended community in the format IPADDR:NN (4-byte IPv4 Unicast Address:2-byte community value)

Defaults

Not Configured

Command Modes

CONFIGURATION (conf-ext-community-list)

Related Commands

Command History

deny	Configure to delete (deny) rules
show ip extcommunity-list	Display the Extended Community list
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on E-Series

permit regex

This features enables you specify an extended communities to forward (permit) using a regular expressions (regex).

Syntax

permit regex { regex}

To remove, use the **no permit regex** { *regex*} command.

Parameters

regex Enter a regular expression.

Defaults

Not configured

Command Modes

CONFIGURATION (conf-ext-community-list)

Usage Information

Duplicate commands are silently accepted.

Example

Figure 7-33. Command Example: permit regexp

FTOS(conf-ext-community-list)#permit regexp 123 FTOS(conf-ext-community-list)#

Related **Commands**

Command History

deny regex	Deny a community using a regular expression	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

set extcommunity rt

Use this feature to set Route Origin community attributes in Route Map.

Syntax

set extcommunity rt {as4 ASN4:NN [non-trans] | ASN:NNNN [non-trans] | IPADDR:NN [non-trans]} [additive]

To delete the Route Origin community, use the **no set extcommunity** command.

Parameters

as4 ASN4:NN	Enter the keyword as4 followed by the 4-octet AS specific extended community number in the format ASN4:NN (4-byte AS number:2-byte community value).
ASN:NNNN	Enter the 2-octet AS specific extended community number in the format ASN:NNNN (2-byte AS number:4-byte community value).
IPADDR:NN	Enter the IP address specific extended community in the format IPADDR:NN (4-byte IPv4 Unicast Address:2-byte community value)
additive	(OPTIONAL) Enter the keyword additive to add to the existing extended community.
non-trans	(OPTIONAL) Enter the keyword non-trans to indicate a non-transitive BGP extended community.

Defaults

No default values or behavior

Command Modes

ROUTE MAP (config-route-map)

Usage Information

If the set community **rt** and **soo** are in the same route-map entry, we can define the behavior as:

If **rt** option comes before **soo**, with or without **additive** option, then **soo** overrides the communities set by rt

- If rt options comes after soo, without the additive option, then rt overrides the communities set by soo
- If **rt** with **additive** option comes after **soo**, then **rt** adds the communities set by **soo**

Related Commands

Command History

set extcommunity soo	Set extended community site-of-origin in route-map.	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

set extcommunity soo

CES

Use this feature to set extended community site-of-origin in Route Map.

Syntax

set extcommunity soo {as4 ASN4:NN | ASN:NNNN | IPADDR:NN [non-trans]}

To delete the site-of-origin community, use the **no set extcommunity** command.

Parameters

as4 ASN4:NN	Enter the keyword as4 followed by the 4-octet AS specific extended community number in the format ASN4:NN (4-byte AS number:2-byte community value).
ASN:NNNN	Enter the 2-octet AS specific extended community number in the format ASN:NNNN (2-byte AS number:4-byte community value).
IPADDR:NN	Enter the IP address specific extended community in the format IPADDR:NN (4-byte IPv4 Unicast Address:2-byte community value)
non-trans	(OPTIONAL) Enter the keyword non-trans to indicate a non-transitive BGP extended community.

Defaults

No default behavior or values

Command Modes

ROUTE MAP (config-route-map)

Usage Information

If the set community **rt** and **soo** are in the same route-map entry, we can define the behavior as:

- If **rt** option comes before **soo**, with or without **additive** option, then **soo** overrides the communities set by **rt**
- If **rt** options comes after **soo**, without the **additive** option, then **rt** overrides the communities set by **soo**
- If rt with additive option comes after soo, then rt adds the communities set by soo

Related Commands

Command History

set extcommunity rt	Set extended community route origins via the route-map	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

show ip bgp ipv4 extcommunity-list

Use this feature to display IPv4 routes matching the extended community list name.

Syntax show ip bgp [ipv4 [multicast | unicast] | ipv6 unicast] extcommunity-list name

Parameters

multicast	Enter the keyword multicast to display the multicast route information.
unicast	Enter the keyword unicast to display the unicast route information.
ipv6 unicast	Enter the keywords ipv6 unicast to display the IPv6 unicast route information.
name	(OPTIONALLY) Enter the name of the extcommunity-list.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Usage Information

If there is a type or sub-type that is not well-known, it will be displayed as:

TTSS:XX:YYYY

Where TT is type, SS is sub-type displayed in hexadecimal format, XX:YYYY is the value divided into 2-byte and 4-byte values in decimal format. This format is consistent with other vendors.

For example, if the extended community has type 0x04, sub-type 0x05, value 0x20 00 00 00 10 00, it will be displayed as:

0x0405:8192:4096

Non-transitive extended communities are marked with an asterisk, as shown in the figure below.

Example

Figure 7-34. Command Example: show ip bgp ipv4 multicast extcommunity-list

```
FTOS#show ip bgp ipv4 multicast extcommunity-list
BGP routing table entry for 192.168.1.0/24, version 2
Paths: (1 available, table Default-IP-Routing-Table.)
Not advertised to any peer
Received from :
  100.100.1.2 (2.4.0.1) Best

AS_PATH : 200

Next-Hop : 100.100.1.2, Cost : 0
     Origin IGP, Metric 4294967295 (Default), LocalPref 100, Weight 0,
external
     Communities :
                          500:600
     300:400
     Extended Communities :
     RT:1111:4278080 SoO:35:4 SoO:36:50529043 SoO:38:50529045 SoO:0.0.0.2:33 SoO:506.62106:34
                                                                            SoO:37:50529044
                                                                            0x0303:254:11223*
FTOS#
```

Command History

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

show ip bgp paths extcommunity

Use this feature to display all BGP paths having extended community attributes.

Syntax show ip bgp paths extcommunity

Command Modes EXEC

EXEC Privilege

Example Figure 7-35. Command Example: show ip bgp paths community (Partial)

FTOS#show ip bgp paths extcommunity
Total 1 Extended Communities

Address Hash Refcount Extended Community

0x41d57024 12272 1 RT:7:200 SoO:5:300 SoO:0.0.0.3:1285

FTOS#

Table 7-20. Command Example Fields: show ip bgp paths community

Field	Description
Address	Displays the internal address where the path attribute is stored.
Hash	Displays the hash bucket where the path attribute is stored.
Refcount	Displays the number of BGP routes using these extended communities.
Community	Displays the extended community attributes in this BGP path.

Command History

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

show ip extcommunity-list

CES Display the IP extended community list.

Syntax show ip extcommunity-list [word]

word Enter the name of the extended community list you want to view.

Defaults Defaults.

Command Modes EXEC

Parameters

EXEC Privilege

Example Figure 7-36. Command Example: show ip extcommunity-list

```
FTOS#show ip extcommunity-list test
ip extcommunity-list test
deny RT:1234:12
permit regexp 123
deny regexp 234
deny regexp 123
FTOS#
```

Command History

Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

show running-config extcommunity-list

Use this feature to display the current configuration of the extended community lists. CES

Syntax show running-config extcommunity-list [word]

Parameters

word Enter the name of the extended community list you want to view.

Defaults No default values or behavior

Command Modes EXEC Privilege

Example Figure 7-37. Command Example: show running-config extcommunity-list

```
FTOS#show running-config extcommunity-list test
ip extcommunity-list test
  permit rt 65033:200
  deny soo 101.11.11.2:23
 permit rt as4 110212:340 deny regex ^(65001_)$
```

Command History

Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on E-Series

Bare Metal Provisioning

Overview

Bare Metal Provisioning version 2.0 is supported on the following platforms: [S55] (S60) (S4810) Z

In a data center network, Bare Metal Provisioning (BMP) automates the configuration and updating of switches, ensuring standard configurations across installed devices.

You can configure auto-configuration on a single switch or on multiple switches. BMP allows you to set up a group of switches with a minimum of effort, but is also useful for quick configuration of a single switch.

For additional information on BMP in an auto-configuration mode, refer to the Open Automation Guide.



Note: BMP 2.0 does not support stacking in this release.

BMP eases configuration by automating the following steps:

- Boot images and running configurations are specified in a DHCP server.
- Switch boots up in Layer 3 mode with interfaces already in no shutdown mode and only enabling some basic protocols to protect the switch and the network.
- The first port that receives the DHCP server response retains the IP address provided by the DHCP server during the BMP process. All other management and user ports are shut down.
- Files are automatically downloaded from a file server.
- After the BMP process is complete, the IP address is released and the configuration is applied by the switch.

Commands

- reload factory-default
- reload factory-default dhcp-client-mode
- reload factory-default dhcp-client-only-mode
- reload factory-default dhcp-server-mode
- reload-type

- show reload-type
- stop jump-start

reload factory-default



BMP 1.5 auto-configuration mode A: Reload the switch with the FTOS image stored in the local flash and apply the factory-default startup configuration. A temporary management IP address (192.168.0.1) is created.



Note: This command has been deprecated in FTOS software version 8.3.3.9.

Syntax reload factory-default

Defaults Loads the factory-default startup configuration file (see Example below).

Command Modes EXEC Privilege

Command History

Version 8.3.3.9	Deprecated command.
Version 8.3.5.0	Introduced on the S55.
Version 8.3.3.1	Introduced on the S60.

Usage Information

This is the reload mode when a new Dell Networking switch (without BMP) arrives. You can replace the temporary management IP address with a user-configured management IP address. The IP address 192.168.0.1 continues to be active for ten minutes. After ten minutes, a user-configured IP address is applied to the management interface.

Example

The factory-default startup configuration file is as follows:

```
interface range GigabitEthernet 0/0 - 47
no shutdown
switchport
interface range TenGigabitEthernet 0/48 - 51
no shutdown
switchport
interface ManagementEthernet 0/0
 ip address 192.168.0.1/24
no shutdown
ip telnet server enable
ip ssh server enable
protocol spanning-tree rstp
no disable
protocol lldp
no disable
 advertise dot1-tlv port-vlan-id
```

```
advertise dot3-tlv max-frame-size
advertise management-tlv system-description system-name
no disable
```

reload factory-default dhcp-client-mode

S55 S60

BMP 1.5 auto-configuration mode C: Reload a switch in DHCP-client mode with a specified FTOS image and a startup configuration file.



Note: This command has been deprecated in FTOS software version 8.3.3.9.

Syntax

reload factory-default dhcp-client-mode [honor-startup-config]

Parameters

honor-startup-config	Honor the startup configuration file stored in the local flash. If this
	option is not entered, retrieve the configuration file from the
	configured file server.

Defaults

This is the default reload mode when a new Dell Networking switch configured with BMP arrives. The switch contacts a DHCP server to download an FTOS image and configuration file. If no DHCP server responds, the system reloads in factory-default mode.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.9	Deprecated command.
Version 8.3.5.0	Introduced on the S55.
Version 8.3.3.1	Introduced on the S60.

reload factory-default dhcp-client-only-mode



BMP 1.5 auto-configuration mode D: Reload the switch in DHCP-client-only mode with a specified FTOS image and startup configuration file for a specified number of discovery attempts.



Note: This command has been deprecated in FTOS software version 8.3.3.9.

Syntax

reload factory-default dhcp-client-only-mode [retries] [honor-startup-config]

Parameters

retries	Enter the number of times that the switch attempts to reach a DHCP server. If no number of retries is entered, the switch continues to try to locate a DHCP server an infinite number of times and does not complete reloading. Range: 2 - 214748364 Default: Infinite number of retry attempts.
honor-startup-config	Honor the startup configuration file stored in the local flash. If this option is not entered, retrieve the configuration file from the configured file server.

Defaults

The switch reloads by attempting to contact a DHCP server to download the FTOS image and startup configuration file. By default, an infinite number of retries are attempted.

When a switch that is reloading in DHCP-client-only mode cannot reach a DHCP server and has a number of retries configured, the switch attempts to reach the DHCP server only the specified number of times. If a DHCP server cannot be reached within the configured number of retries, the switch reloads in factory-default mode.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.9	Deprecated command.
Version 8.3.5.0	Introduced on the S55.
Version 8.3.3.1	Introduced on the S60.

Usage Information

Important: Do not use Mode D unless the DHCP, DNS, and file servers are already configured. If the servers are not configured in the network, a switch endlessly attempts to discover the DHCP and other servers and does not complete the reload.

reload factory-default dhcp-server-mode

S55 S60

BMP 1.5 auto-configuration mode B: Reload the switch using the FTOS image stored in the local flash and apply the factory-default and DHCP server configurations. The switch boots up with a temporary management IP address (192.168.0.1/24) and functions as a DHCP server.



Note: This command has been deprecated in FTOS software version 8.3.3.9.

Syntax

reload factory-default dhcp-server-mode

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.3.9	Deprecated command.	
]Version 8.3.5.0	Introduced on the S55.	
Version 8.3.3.1	Introduced on the S60.	

Usage Information

You must replace the temporary management IP address within ten minutes with a user-configured, permanent management IP address in order to secure the switch. During the first ten minutes, after authentication is enabled, access to the switch does not require a password.

reload-type



Configure a switch to reload in normal mode or as a DHCP client with all ports configured for Layer 3 traffic.

Syntax

reload-type {normal-reload | jump-start [config-download {enable | disable}] [dhcp-timeout minutes]}

Parameters

normal-reload	The switch reloads in normal mode using the FTOS image and startup configuration file stored in the local flash.
jump-start	The switch reloads in JumpStart mode as a DHCP client.
config-download {enable disable}	(Optional) Configure whether the switch boots up using the configuration file downloaded from the DHCP/file servers (<i>enable</i>) OR if the downloaded file will be discarded and the startup configuration file stored in the local flash will be used (<i>disable</i>). Default: None
dhcp-timeout minutes	(Optional) Configure the DHCP timeout (in minutes) after which the JumpStart reload stops. Range: 1 to 50. Default: Infinite number of retries.

Defaults

A switch running BMP 2.0 reloads in JumpStart mode as a DHCP client with all ports configured for Layer 3 traffic.

Command Modes

EXEC Privilege

Command History

Version 8.3.5.3	Introduced on S55
Version 8.3.3.8	Introduced on S60
Version 8.3.11.4	Introduced on Z9000
Version 8.3.10.1	Introduced on S4810.

Usage Information

For an initial setup, the **config-download** parameter of the **reload-type** command is enabled. After the configuration file is successfully downloaded, the **config-download** parameter is automatically disabled. You can enable it again using the **reload-type** command.

After you set the auto-configuration mode (JumpStart or Normal reload) using the **reload-type** command, you must enter the **reload** command to reload the switch in the configured mode.

When a switch reloads in JumpStart mode, all ports, including the management port, are automatically configured as Layer 3 physical ports. The switch acts as a DHCP client on the ports for a user-configured time (*dhcp-timeout* option). You can reconfigure the default startup configuration and DHCP timeout values.

If a switch enters a loop while reloading in JumpStart mode because the switch continuously tries to contact a DHCP server and a DHCP server is not found, connect to the switch using the console terminal and enter the **stop jump-start** command to interrupt the reload and boot up in normal mode. The startup configuration is then loaded from the local flash on the switch and the auto-configuration mode is automatically changed to Normal reload.

Use the **reload-type** command in BMP 2.0 to toggle between Normal and JumpStart auto-configuration modes. The reload settings for the auto-configuration mode that you configure are stored in memory and retained for future reboots and BMP software upgrades. You can enter the **reload** command at any time to reload the switch in the last configured mode: Normal reload or JumpStart mode.

Related Commands

show reload-type	Display the current reload mode (Normal or jump-start mode)
stop jump-start	Stops the JumpStart process to prevent a loop if the DHCP server is not found.

show reload-type

S55 S60 **S4810 Z**

Display the currently configured reload mode.

Syntax show reload-type

Defaults None

Command Modes EXEC Privilege

Command History

Version 8.3.5.3	Introduced on S55
Version 8.3.3.8	Introduced on S60
Version 8.3.11.4	Introduced on Z9000
Version 8.3.10.1	Introduced on S4810.

Usage Information

Use the **show reload-type** command to check the currently configured auto-configuration mode (JumpStart or Normal reload) on a switch running BMP 2.0.

You can also use the **show bootvar** command to display the current reload mode for BMP 2.0 with the path of the FTOS image file retrieved from a DHCP server.

Example

FTOS#show reload-type

Reload-Type normal-reload [Next boot : normal-reload]

Related Commands

reload-type Configure the reload mode as normal or JumpStart.

stop jump-start

[S55] [S60] S4810 Z Stop the switch from reloading in JumpStart mode to prevent an infinite loop.

Syntax

stop jump-start

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.5.3	Introduced on S55
Version 8.3.3.8	Introduced on S60
Version 8.3.11.4	Introduced on Z9000
Version 8.3.10.1	Introduced on S4810.

Related Commands

reload-type

Configure the reload mode as normal or JumpStart.

Usage Information

Use the stop jump-start command from the console of a switch running BMP 2.0 if the switch enters a loop while reloading in JumpStart mode because it is continuously trying to contact a DHCP server and a DHCP server is not found. The stop jump-start command stops the switch from connecting to the DHCP server. After the stop jump-start command is used, the next default reload type will be a normal reload. This will be indicated in the show reload-type command.

Content Addressable Memory (CAM)

Overview

Content Addressable Memory (CAM) commands are supported C-Series, E-Series TeraScale and S-Series, as indicated by the symbols under each command heading:

This chapter includes information relating to the E-Series TeraScale platform. Refer to Chapter 11, "Content Addressable Memory (CAM) for ExaScale for information on the commands for the E-Series ExaScale platform.



Note: Not all CAM commands are supported on all platforms. Be sure to note the platform symbol when looking for a command.



Warning: If you are using these features for the first time, contact Dell Networking Technical Assistance Center (TAC) for guidance. For information on contacting Dell Networking TAC, visit the Dell Networking website at http://support.dell.com/force10

This chapter includes the following sections:

CAM Profile Commands

CAM Profile Commands

The CAM profiling feature enables you to partition the CAM to best suit your application. For

- Configure more Layer 2 FIB entries when the system is deployed as a switch.
- Configure more Layer 3 FIB entries when the system is deployed as a router.
- Configure more ACLs (when IPv6 is not employed).
- Hash MPLS packets based on source and destination IP addresses for LAGs.
- Hash based on bidirectional flow for LAGs.
- Optimize the VLAN ACL Group feature, which permits group VLANs for IP egress ACLs.

Important Points to Remember

- CAM Profiles are available on FTOS versions 6.3.1.1 and later for the E-Series TeraScale.
- FTOS versions 7.8.1.0 and later support CAM allocations on the C-Series and S-Series.
- All line cards within a single system must have the same CAM profile (including CAM sub-region configurations); this profile must match the system CAM profile (the profile on the primary RPM).
- FTOS automatically reconfigures the CAM profile on line cards and the secondary RPM to match the system CAM profile by saving the correct profile on the card and then rebooting it.
- The CAM configuration is applied to entire system when you use CONFIGURATION mode commands. You must save the running-configuration to affect the change.
- When budgeting your CAM allocations for ACLs and QoS configurations, remember that ACL
 and QoS rules might consume more than one CAM entry depending on complexity. For example,
 TCP and UDP rules with port range options might require more than one CAM entry.
- After you install a secondary RPM, copy the running-configuration to the startup-configuration so that the new RPM has the correct CAM profile.
- You MUST save your changes and reboot the system for CAM profiling or allocations to take effect.

The CAM Profiling commands are:

- · cam-acl
- cam-acl-egress
- cam-optimization
- cam-profile
- show cam-acl
- show cam-profile
- · show cam-usage
- test cam-usage

cam-acl

CS

Allocate CAM for IPv4 and IPv6 ACLs

Syntax

cam-acl {default | l2acl number ipv4acl number ipv6acl number, ipv4qos number l2qos number, l2pt number ipmacacl number ecfmacl number [vman-qos | vman-dual-qos number]

Parameters

default	Use the default CAM profile settings, and set the CAM as follows.
	L3 ACL (ipv4acl): 6
	L2 ACL(l2acl): 5
	IPv6 L3 ACL (ipv6acl): 0
	L3 QoS (ipv4qos): 1
	L2 QoS (12qos): 1
l2acl number ipv4acl number	Allocate space to each CAM region.
ipv6acl number, ipv4qos number	Enter the CAM profile name followed by the amount to be allotted.
l2qos number, l2pt number	The total space allocated must equal 13.
ipmacacl number ecfmacl number [vman-qos vman-dual-qos number	The ipv6acl range must be a factor of 2.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added ecfmacl, vman-qos, and vman-dual-qos keywords.
Version 8.2.1.0	Introduced on the S-Series
Version 7.8.1.0	Introduced on the C-Series

Usage Information

You must save the new CAM settings to the startup-config (write-mem or copy run start) then reload the system for the new settings to take effect.

The total amount of space allowed is 16 FP Blocks. System flow requires 3 blocks and these cannot be reallocated.

When configuring space for IPv6 ACLs, the total number of Blocks must equal 13.

Ranges for the CAM profiles are 1-10, except for the **ipv6acl** profile which is 0-10. The **ipv6acl** allocation must be a factor of 2 (2, 4, 6, 8, 10).

cam-acl-egress

[S60]

Allocate CAM for egress ACLs

Syntax

cam-acl-egress default | l2acl

Parameters

default	Reset egress CAM ACL entries to default settings.
l2acl number	Allocate space for Layer 2 egress ACL.
	Range: 1-4 FP blocks

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.4	Introduced on the S60.	
-----------------	------------------------	--

cam-optimization

Optimize CAM utilization for QoS Entries by minimizing require policy-map CAM space.

Syntax cam-optimization [qos]

Parameters Optimize CAM usage for Quality of Service (QoS)

Command Modes CONFIGURATION

Defaults Disabled

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.2.1.0 Introduced on the s-Series

Version 7.8.1.0 Introduced on the C-Series and S-Series

Usage Information When this command is enabled, if a Policy Map containing classification rules (ACL and/or dscp/ip-precedence rules) is applied to more than one physical interface on the same port pipe, only a single copy of the policy will be written (only 1 FP entry will be used).

Note that an ACL itself may still require more that a single FP entry, regardless of the number of interfaces. Refer to *IP Access Control Lists*, *Prefix Lists*, *and Route-map* in the *FTOS Configuration Guide* for complete discussion.

cam-profile

E Set the default CAM profile and the required microcode.

Syntax cam-profile profile microcode microcode

Parameters

profile

Choose one of the following CAM profiles:

- Enter the keyword **default** to specify the default CAM profile.
- Enter the keyword **eg-default** to specify the default CAM profile for EG (dual-CAM) line cards.
- Enter the keyword **ipv4-320k** to specify the CAM profile that provides 320K entries for the IPv4 Forwarding Information Base (FIB).
- Enter the keyword ipv4-egacl-16k to specify the CAM profile that provides 16K entries for egress ACLs.
- Enter the keyword **ipv6-extacl** to specify the CAM profile that provides IPv6 functionality.
- Enter the keyword **12-ipv4-inacl** to specify the CAM profile that provides 32K entries for ingress ACLs.
- Enter the keyword unified-default to specify the CAM profile that maintains the CAM allocations for the IPv6 and IPv4 FIB while allocating more CAM space for the Ingress and Egress Layer 2 ACL, and IPv4 ACL regions.
- Enter the keyword **ipv4-vrf** to specify the CAM profile that maintains the CAM allocations for the IPv4 FIB while allocating CAM space for VRF.
- Enter the keyword **ipv4-v6-vrf** to specify the CAM profile that maintains the CAM allocations for the IPv4 and IPv6FIB while allocating CAM space for VRF.
- Enter the keyword **ipv4-64k-ipv6** to specify the CAM profile that provides an alternate to ipv6-extacl that redistributes CAM space from the IPv4FIB to IPv4Flow and IPv6FIB.

microcode microcode

Choose a microcode based on the CAM profile you chose. Not all microcodes are available to be paired with a CAM profile.

- Enter the keyword **default** to select the microcode that distributes CAM space for a typical deployment.
- Enter the keyword lag-hash-align to select the microcode for applications that require the same hashing for bi-directional traffic.
- Enter the keyword **lag-hash-mpls** to select the microcode for hashing based on MPLS labels (up to five labels deep).
- Enter the keyword **ipv6-extacl** to select the microcode for IPv6.
- Enter the keyword **acl-group** to select the microcode for applications that need 16k egress IPv4 ACLs.
- Enter the keyword **ipv4-vrf** to select the microcode for IPv4 VRF applications.
- Enter the keyword **ipv4-v6-vrf** to select the microcode forIPv4 and IPv6 VRF applications.

Defaults

cam-profile default microcode default

Command Modes

CONFIGURATION

Command History

Version 8.2.1.0	Added support for ipv4-64k-ipv6 profile
Version 7.9.1.0	Added support for VRF protocols.
Version 7.5.1.0	Added the 12-ipv4-inacl CAM profile
Version 7.4.2.0	Added the unified-default CAM profile and lag-hash-align microcode
Version 7.4.1.0	Added the lag-hash-mpls microcode
Version 6.5.1.0	Added the eg-default and ipv4-320k CAM profiles
Version 6.3.1.0	Introduced on E-Series

Usage Information

You must save the running configuration using the command **copy running-config startup-config** after changing the CAM profile from CONFIGURATION mode. CAM profile changes take effect after the next chassis reboot.



Note: Do not use the ipv4-egacl-16 CAM profile for Layer 2 egress ACLs.



Note: Do not make any changes to the CAM profile after you change the profile to ipv4-320K and save the configuration until after you reload the chassis; any changes lead to unexpected behavior. After you reload the chassis, you may make changes to the IPv4 Flow partition.

show cam-acl

Display the details of the CAM profiles on the chassis and all line cards.

Syntax show cam-acl

Defaults None

Command Modes EXEC Privilege

Command History

Version 7.8.1.0 Introduced on C-Series

Usage Information The display reflects the settings implemented with the **cam-acl** command.

Example

Figure 9-1. Command Output: show cam-acl (default)

```
FTOS#show cam-acl
-- Chassis Cam ACL --
             Current Settings (in block sizes)
L2Acl
Ipv4Acl
                      6
Ipv6Acl
                      0
Ipv4Qos
                      1
L2Qos
-- Line card 4 --
           Current Settings (in block sizes)
L2Acl
                      5
                      6
Ipv4Acl
Ipv6Acl
                      0
Ipv4Qos
                      1
                      1
L2Qos
FTOS#
```

Figure 9-2. Command Output: show cam-acl (non-default)

```
FTOS#show cam-acl
-- Chassis Cam ACL --
Current Settings(in block sizes)

L2Acl : 2
Ipv4Acl : 2
Ipv6Acl : 4
Ipv4Qos : 2
L2Qos : 3
-- Line card 4 --
Current Settings(in block sizes)
L2Acl : 2
Ipv4Acl : 2
Ipv6Acl : 4
Ipv4Qos : 2
L2Qos : 3
                     4
2
3
FTOS#
```

show cam-profile

(E) Display the details of the CAM profiles on the chassis and all line cards.

Syntax show cam-profile [profile microcode | summary]

Parameters

profile (OPTIONAL) Choose a single CAM profile to display:

- Enter the keyword default to specify the default CAM profile.
- Enter the keyword eg-default to specify the default CAM profile for EG (dual-CAM) line cards.
- Enter the keyword ipv4-320k to specify the CAM profile that provides 320K entries for the IPv4 Forwarding Information Base (FIB).
- Enter the keyword **ipv4-egacl-16k** to specify the CAM profile that provides 16K entries for egress ACLs.
- Enter the keyword ipv6-extacl to specify the CAM profile that provides IPv6 functionality.
- Enter the keyword **12-ipv4-inacl** to specify the CAM profile that provides 32K entries for ingress ACLs.
- Enter the keyword unified-default to specify the CAM profile that maintains the CAM allocations for the IPv6 and IPv4 FIB while allocating more CAM space for the Ingress and Egress Layer 2 ACL, and IPv4 ACL regions.
- Enter the keyword ipv4-vrf to specify the CAM profile that maintains the CAM allocations for the IPv4 FIB while allocating CAM space for VRF.
- Enter the keyword **ipv4-v6-vrf** to specify the CAM profile that maintains the CAM allocations for the IPv4 and IPv6FIB while allocating CAM space for VRF.

microcode microcode

Choose the microcode to display. Not all microcodes are available to be paired with a CAM profile.

- Enter the keyword **default** to select the microcode that distributes CAM space for a typical deployment.
- Enter the keyword **lag-hash-align** to select the microcode for applications that require the same hashing for bi-directional traffic.
- Enter the keyword **lag-hash-mpls** to select the microcode for hashing based on MPLS labels (up to five labels deep).
- Enter the keyword **ipv6-extacl** to select the microcode for IPv6.
- Enter the keyword acl-group to select the microcode for applications that need 16k egress IPv4 ACLs.
- Enter the keyword **ipv4-vrf** to select the microcode for IPv4 VRF applications.
- Enter the keyword ipv4-v6-vrf to select the microcode forIPv4 and IPv6 VRF applications.
- Enter the keyword ipv4-64k-ipv6 to specify the CAM profile that provides an alternate to ipv6-extacl that redistributes CAM space from the IPv4FIB to IPv4Flow and IPv6FIB.

summary

(OPTIONAL) Enter this keyword to view a summary listing of the CAM profile and microcode on the chassis and all line cards.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.2.1.0	Added support for ipv4-64k-ipv6 profile
Version 7.9.1.0	Added support for VRF protocols.
Version 6.3.1.0	Introduced on E-Series

Usage Information

If the CAM profile has been changed, this command displays the current CAM profile setting in one column and in the other column displays the CAM profile and the microcode that will be configured for the chassis and all online line cards *after the next reboot*.

Example 1 Figure 9-3. Command Output: show cam-profile summary

```
FTOS#show cam-profile summary
-- Chassis CAM Profile --
: Current Settings : Next Boot
Profile Name : Default : Default
MicroCode Name : Default : Default
MicroCode Name : Default
                     : Current Settings : Next Boot
-- Line card 1 --
Profile Name : Default : Default MicroCode Name : Default : Default
                     : Current Settings : Next Boot
-- Line card 6 --
Profile Name : Default MicroCode Name : Default
                                             : Default
                                            : Default
FTOS#
```

Example 2 Figure 9-4. Command Output: show cam-profile

```
FTOS#show cam-profile
    -- Chassis Cam Profile --
: 18-Meg
-- Line card 0 --
CamSize : 18-Meg : Current Settings : Next Boot
Profile Name : DEFAULT : DEFAULT
L2FIB : 32K entries : 32K entries
L2ACL : 1K entries : 1K entries
IPv4FIB : 256K entries : 256K entries
IPv4ACL : 12K entries : 12K entries
IPv4ACL : 12K entries : 24K entries
EgL2ACL : 1K entries : 1K entries
EgL2ACL : 1K entries : 1K entries
EgIPv4ACL : 1K entries : 1K entries
EgIPv6ACL : 1K entries : 1K entries
IPv6FIB : 0 entries : 8K entries
IPv6FIB : 0 entries : 0 entries
IPv6Flow : 0 entries : 0 entries
EgIPv6ACL : 0 entries : Default
FTOS#
   -- Line card 0 --
```

show cam-usage

Display Layer 2, Layer 3, ACL, or all CAM usage statistics. [E]

Syntax show cam-usage [acl | router | switch]

Parameters

acl	(OPTIONAL) Enter this keyword to display Layer 2 and Layer 3 ACL CAM usage.
router	(OPTIONAL) Enter this keyword to display Layer 3 CAM usage.
switch	(OPTIONAL) Enter this keyword to display Layer 2 CAM usage.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 6.5.1.0 Introduced on E-Series

Example

Figure 9-5. Command Example: show cam-usage

	:		Total CAM	Used CAM	Available CAM
	======		=======	=======	
1	0	IN-L2 ACL	1008	320	688
ļ		IN-L2 FIB	32768	1132	31636
ļ		IN-L3 ACL	12288	2	12286
J		IN-L3 FIB	262141	14	262127
J		IN-L3-SysFlow	2878	45	2833
		IN-L3-TrcList	1024	0	1024
J		IN-L3-McastFib	9215	0	9215
J		IN-L3-Qos	8192	0	8192
		IN-L3-PBR	1024	0	1024
		IN-V6 ACL	0	0	0
J		IN-V6 FIB	0	0	0
J		IN-V6-SysFlow	0	0	0
		IN-V6-McastFib	0	0	0
		OUT-L2 ACL	1024	0	1024
J		OUT-L3 ACL	1024	0	1024
		OUT-V6 ACL	0	0	0
1	1	IN-L2 ACL	320	0	320
		IN-L2 FIB	32768	1136	31632
		IN-L3 ACL	12288	2	12286
İ	ĺ	IN-L3 FIB	262141	14	262127
į	İ	IN-L3-SysFlow	2878	44	2834

Example

Figure 9-6. Command Example: show cam-usage acl

inecard	Portpipe	CAM Partition	Total CAM	Used CAM	Available CAM
		==========	=========		=========
11	0	IN-L2 ACL	1008	0	1008
		IN-L3 ACL	12288	2	12286
		OUT-L2 ACL	1024	2	1022
	İ	OUT-L3 ACL	1024	0	1024

Example Figure 9-7. Command Example: show cam-usage router

FTOS#show cam-usage router Linecard | Portpipe | CAM Partition Total CAM Used CAM Available CAM ====== =========| -----_____ -----IN-L3 ACL 11 8192 8189 IN-L3 FIB 196607 196606 2878 IN-L3-SysFlow 0 2878 IN-L3-TrcList 0 1024 1024 IN-L3-McastFib 9215 0 9215 0 IN-L3-Oos 8192 8192 IN-L3-PBR 1024 0 1024 16384 OUT-L3 ACL 16384 0 IN-L3 ACL 11 1 3 8192 8189 196607 196606 TN-L3 FTB 1 IN-L3-SysFlow 2878 0 2878 IN-L3-TrcList 1024 0 1024 0 IN-L3-McastFib 9215 9215 IN-L3-Oos 8192 0 8192 IN-L3-PBR 1024 0 1024 OUT-L3 ACL 16384 16384 FTOS#

Example Figure 9-8. Command Example: show cam-usage switch

FTOS#show cam-usage switch Total CAM Linecard | Portpipe | CAM Partition Used CAM Available CAM _____ _____| 0 0 7152 11 IN-L2 ACL 7152 1081 IN-L2 FIB 32768 31687 0 OUT-L2 ACL 7152 0 Ω 7152 IN-L2 ACL IN-L2 FIB 0 11 1 32768 1081 31687 OUT-L2 ACL 0 Ω FTOS#

test cam-usage

Verify that enough CAM space is available for the IPv6 ACLs you have created. [C][E][S]

Syntax test cam-usage service-policy input input policy name linecard { number | all }

Parameters

policy-map name	Enter the name of the policy-map to verify.
number	Enter all to get information for all the linecards/stack-units, or enter the linecard/stack-unit <i>number</i> to get information for a specific card.
	Range: 0-6 for E-Series, 0-7 for C-Series, 0-11 for S60; 0-7 for all other S-Series

Defaults None

Command Modes EXEC Privilege

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced

Usage Information This command applies to both IPv4 and IPv6 CAM Profiles, but is best used when verifying QoS optimization for IPv6 ACLs.

QoS Optimization for IPv6 ACLs does not impact the CAM usage for applying a policy on a single (or the first of several) interfaces. It is most useful when a policy is applied across multiple interfaces; it can reduce the impact to CAM usage across subsequent interfaces.

Example The following examples show some sample output when using the **test cam-usage** command.

Figure 9-9. Command Example: test cam-usage (C-Series)




Table 9-1. Output Explanations: test cam-usage (C-Series)

Term	Explanation
Linecard	Lists the line card or linecards that are checked. Entering all shows the status for linecards in the chassis
Portpipe	Lists the portpipe (port-set) or port pipes (port-sets) that are checked. Entering all shows the status for linecards and port-pipes in the chassis.
CAM Partition	Shows the CAM profile of the CAM
Available CAM	Identifies the amount of CAM space remaining for that profile
Estimated CAM per Port	Estimates the amount of CAM space the listed policy will require.
Status	Indicates whether or not the policy will be allowed in the CAM

Figure 9-10. Command Example: test cam-usage (S-Series)

```
FTOS#test cam-usage service-policy input LauraIn stock-unit all
Stack-Unit | Portpipe | CAM Partition | Available CAM | Estimated CAM per Port | Status
______
      0 | 0 | IPv4Flow | 102 | 0 | Allowed
0 | 1 | IPv4Flow | 102 | 0 | Allowed
FTOS#
FTOS#test cam-usage service-policy input LauraIn stack-unit 0 port-set 1
Stack-Unit | Portpipe | CAM Partition | Available CAM | Estimated CAM per Port | Status
      0 | 1 | IPv4Flow |
                                      102
                                                            0 | Allowed
FTOS#
```

Table 9-2. Output Explanations: test cam-usage (S-Series)

Term	Explanation
Stack-Unit	Lists the stack unit or units that are checked. Entering all shows the status for all stacks.
Portpipe	Lists the portpipe (port-set) or port pipes (port-sets) that are checked. Entering all shows the status for linecards and port-pipes in the chassis.
CAM Partition	Shows the CAM profile of the CAM
Available CAM	Identifies the amount of CAM space remaining for that profile
Estimated CAM per Port	Estimates the amount of CAM space the listed policy will require.
Status	Indicates whether or not the policy will be allowed in the CAM

Dynamic Host Configuration Protocol (DHCP)

Overview

Dynamic Host Configuration Protocol (DHCP) is an application layer protocol that dynamically assigns IP addresses and other configuration parameters to network end-stations (hosts) based on configuration policies determined by network administrators.

- Commands to Configure the System to be a DHCP Server
- Commands to Configure Secure DHCP

Commands to Configure the System to be a DHCP Server

- clear ip dhcp
- debug ip dhcp server
- default-router
- disable
- dns-server
- domain-name
- excluded-address
- hardware-address
- ip dhcp relay information-option remote-id
- disable
- netbios-name-server
- netbios-node-type
- network
- pool
- show ip dhep binding
- show ip dhcp configuration
- show ip dhep conflict
- show ip dhcp server

clear ip dhcp

Reset DHCP counters.

Syntax clear ip dhcp [binding {address} | conflict | server statistics]

Parameters

binding	Enter this keyword to delete all entries in the binding table.
address	Enter the IP address to clear the binding entry for a single IP address.
conflict	Enter this keyword to delete all of the log entries created for IP address conflicts.
server statistics	Enter this keyword to clear all the server counter information.

Command Mode EXEC Privilege

Default None

Command History Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

Usage Information Entering <CR> after clear ip dhcp binding, clears all the IPs from the binding table.

debug ip dhcp server

C S Display FTOS debugging messages for DHCP.

Syntax debug ip dhcp server [events | packets]

Parameters

events	Enter this keyword to display DHCP state changes.
packet	Enter this keyword to display packet transmission/reception.

Command Mode EXEC Privilege

Default None

Command History Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

default-router

Assign a default gateway to clients based on address pool.

Syntax default-router address [address2...address8]

Parameters

address Enter the a list of routers that may be the default gateway for clients on the subnet. You may specify up to 8. List them in order of preference.

Command Mode DHCP < POOL>

> Default None

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

disable

Disable DHCP Server.

> DHCP Server is disabled by default. Enable the system to be a DHCP server using the no form of the disable command.

disable **Syntax**

Command Mode DHCP

> **Default** Disabled

Command **History**

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

dns-server

CS Assign a DNS server to clients based on address pool.

Syntax dns-server address [address2...address8]

Parameters Enter the a list of DNS servers that may service clients on the subnet. You may list up to 8 address servers, in order of preference.

Command Mode DHCP < POOL>

> **Default** None

Command Version 8.3.5.0 Introduced on the S55. **History**

Version 8.2.1.0 Introduced on C-Series and S-Series.

domain-name

CS Assign a domain to clients based on address pool.

Syntax domain-name name

Parameters Give a name to the group of addresses in a pool. name

Command Mode DHCP < POOL>

Default None

Command History

Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

excluded-address

Prevent the server from leasing an address or range of addresses in the pool.

Syntax excluded-address [address | low-address high-address]

Parameters

address	Enter a single address to be excluded from the pool.
low-address	Enter the lowest address in a range of addresses to be excluded from the pool.
high-address	Enter the highest address in a range of addresses to be excluded from the pool.

Command Mode DHCP

Default None

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

hardware-address

[C] S For manual configurations, specify the client hardware address.

Syntax hardware-address address

Parameters

address Enter the hardware address of the client.

Command Mode DHCP <POOL>

Default None

Command History Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

host

C S For manual (rather than automatic) configurations, assign a host to a single-address pool.

Syntax host address

Davamatana		
Parameters	address/mask	Enter the host IP address and subnet mask.
Command Mode	DHCP <pool></pool>	
Default	None	
0		
Command History	Version 8.3.5.0	Introduced on the S55.
,	Version 8.2.1.0	Introduced on C-Series and S-Series.

ip dhcp relay information-option remote-id

[S60][S4810]

Manually re-set the remote-id (MAC address) for Option 82.

Syntax ip dhcp relay information-option [remote-id {hostname | remote-id}]

Parameters

hostname	Set the hostname of the switch as the remote-id for Option 82.
remote-id	Configure the system to enable the remote-id (MAC address) for Option 82. Enter the name of the remote-id, maximum 64 characters.

Command Mode CONFIGURATION

> **Default** Disabled

Command **History**

Version 9.0.0.0	Introduced on the Z9000.
Version 8.3.7.0	Introduced on the S4810.
Version 8.3.5.3	Introduced on the S55.
Version 8.3.3.8	Introduced on the S60.
Version 8.2.1.0	Introduced on C-Series and S-Series (S25/S50).

Usage Information

Option 82 is comprised of two sub-options, circuit id and remote id. Remote id uses the MAC address of the relay information which adds Option 82 to identify the host sending the message. Use the ip dhcp relay information-option remote-id command to change the default remote-id value of the switch.

lease

 $\mathbb{C}[\mathbb{S}]$

Specify a lease time for the addresses in a pool.

Syntax

lease { days [hours] [minutes] | infinite}

Parameters

days	Enter the number of days of the lease. Range: 0-31
hours	Enter the number of hours of the lease.
	Range: 0-23

<i>minutes</i> Enter the number of minutes of the lease.	
	Range: 0-59
infinite	Specify that the lease never expires.

Command Mode

DHCP < POOL>

Default

24 hours

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

netbios-name-server

CS

Specify the NetBIOS Windows Internet Naming Service (WINS) name servers, in order of preference, that are available to Microsoft Dynamic Host Configuration Protocol (DHCP) clients.

Syntax

netbios-name-server address [address2...address8]

Parameters

address	Enter the address of the NETBIOS name server. You may enter up to 8, in order of
	preference.

Command Mode

DHCP <POOL>

Default

None

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

netbios-node-type

Specify the NetBIOS node type for a Microsoft DHCP client. Dell Networking recommends specifying clients as hybrid.

Syntax

netbios-node-type type

Parameters

type	Enter the NETBIOS node type.
	Broadcast: Enter the keyword b-node.
	Hybrid: Enter the keyword h-node.
	Mixed: Enter the keyword m-node.
	Peer-to-peer: Enter the keyword p-node.

Command Mode

DHCP < POOL>

Default

Hybrid

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.2.1.0	Introduced on C-Series and S-Series.

network

CS Specify the range of addresses in an address pool.

network network / prefix-length **Syntax**

Parameters

network/ Specify a range of addresses. prefix-length Prefix-length Range: 17-31

Command Mode DHCP <POOL>

> **Default** None

Command **History**

Version 8.3.5.0 Introduced on the S55. Version 8.2.1.0 Introduced on C-Series and S-Series.

pool

Create an address pool

Syntax pool name

Parameters

name Enter the address pool's identifying name

Command Mode DHCP

> **Default** None

Command History

Version 8.3.5.0 Introduced on the S55. Version 8.2.1.0 Introduced on C-Series and S-Series.

show ip dhcp binding

Display the DHCP binding table.

Syntax show ip dhcp binding

Command Mode EXEC Privilege

> **Default** None

Command History

Version 8.3.5.0 Introduced on the S55. Version 8.2.1.0 Introduced on C-Series and S-Series.

show ip dhcp configuration

C S Display the DHCP configuration.

Syntax show ip dhcp configuration [global | pool name]

Parameters

pool name

Display the configuration for a DHCP pool.

global Display the DHCP configuration for the entire system.

Command Mode EXEC Privilege

Default None

Command

History

Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

show ip dhcp conflict

Display the address conflict log.

Syntax show ip dhcp conflict address

Parameters Display a particular conflict log entry.

Command Mode EXEC Privilege

Default None

Command History

Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

show ip dhcp server

Display the DHCP server statistics.

Syntax show ip dhcp server statistics

Command Mode EXEC Privilege

Default None

Command History Version 8.3.5.0 Introduced on the S55.

Version 8.2.1.0 Introduced on C-Series and S-Series.

Commands to Configure Secure DHCP

DHCP as defined by RFC 2131 provides no authentication or security mechanisms. Secure DHCP is a suite of features that protects networks that use dynamic address allocation from spoofing and attacks.

- arp inspection
- arp inspection-trust
- clear ip dhcp snooping
- ip dhcp snooping
- ip dhcp snooping database
- ip dhcp snooping binding
- ip dhcp snooping database renew
- ip dhep snooping trust
- ip dhcp source-address-validation
- ip dhcp snooping vlan
- ip dhcp relay
- ip dhcp snooping verify mac-address
- show ip dhcp snooping

arp inspection

CES Enable Dynamic Arp Inspection (DAI) on a VLAN.

Syntax arp inspection

Command Modes INTERFACE VLAN

> **Default** Disabled

Command History

Version 8.3.5.0	Introduced on the S55.	
Version 8.3.1.0	Introduced on E-Series.	
Version 8.2.1.0	Introduced on C-Series and S-Series	

Related **Commands**

arp inspection-trust	Specify a port as trusted so that ARP frames are not validated against
	the binding table.

arp inspection-trust

CES Specify a port as trusted so that ARP frames are not validated against the binding table.

Syntax arp inspection-trust

Command Modes INTERFACE

INTERFACE PORT-CHANNEL

Default Disabled

Command

History

Version 8.3.5.0 Introduced on the S55.

Version 8.3.1.0 Introduced on E-Series.

Version 8.2.1.0 Introduced on C-Series and S-Series

Related Commands

arp inspection Enable Dynamic ARP Inspection on a VLAN.

clear ip dhcp snooping

CES Clear the DHCP binding table.

Syntax clear ip dhcp snooping binding

Command Modes EXEC Privilege

Default None

Command History Version 8.3.5.0 Introduced on the S55.

Version 8.3.1.0 Introduced on E-Series.

Version 7.8.1.0 Introduced on C-Series and S-Series

Related Commands

show ip dhcp snooping Display the contents of the DHCP binding table.

ip dhcp snooping

CES Enable DHCP Snooping globally.

Syntax [no] ip dhcp snooping

Command Modes CONFIGURATION

Default Disabled

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 8.2.1.0	Introduced on C-Series and S-Series for Layer 2 interfaces.
Version 7.8.1.0	Introduced on C-Series and S-Series on Layer 3 interfaces.

Usage Information

When enabled, no learning takes place until snooping is enabled on a VLAN. Upon disabling DHCP Snooping the binding table is deleted, and Option 82, IP Source Guard, and Dynamic ARP Inspection are disabled.

Introduced in FTOS version 7.8.1.0, DHCP Snooping was available for Layer 3 only and dependent on DHCP Relay Agent (ip helper-address). FTOS version 8.2.1.0 extends DHCP Snooping to Layer 2, and you do not have to enable relay agent to snoop on Layer 2 interfaces.

Related Commands

ip dhcp snooping vlan Enable DHCP Snooping on one or more VLANs.

ip dhcp snooping database

Delay writing the binding table for a specified time.

ip dhcp snooping database write-delay minutes **Syntax**

Parameters Range: 5-21600 minutes

Command Modes CONFIGURATION

> **Default** None

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 7.8.1.0	Introduced on C-Series and S-Series

ip dhcp snooping binding

CES Create a static entry in the DHCP binding table.

Syntax [no] ip dhcp snooping binding mac address vlan-id ip ip-address interface type slot/ port lease number

Parameters

mac address	Enter the keyword mac followed by the MAC address of the host to which the server is leasing the IP address.
vlan-id vlan-id	Enter the keyword vlan-id followed by the VLAN to which the host belongs.
	Range: 2-4094
ip ip-address	Enter the keyword ip followed by the IP address that the server is leasing.
interface type	Enter the keyword interface followed by the type of interface to which the host is connected.
	• For an 10/100 Ethernet interface, enter the keyword fastethernet .
	• For a Gigabit Ethernet interface, enter the keyword gigabitethernet .
	• For a SONET interface, enter the keyword sonet .
	• For a Ten Gigabit Ethernet interface, enter the keyword
	tengigabitethernet.
slot/port	Enter the slot and port number of the interface.
lease number	Enter the keyword lease followed by the amount of time the IP address will be
	leased.
	Range: 1-4294967295

Command Modes EXEC

EXEC Privilege

Default None Command

History _____

Version 8.3.5.0	Introduced on the S55.	
Version 8.3.1.0	Introduced on E-Series.	
Version 7.8.1.0	Introduced on C-Series and S-Series	

Related Commands

show ip dhcp snooping Display the contents of the DHCP binding table.

ip dhcp snooping database renew

CES Renew the binding table.

Syntax ip dhcp snooping database renew

Command Modes EXEC

EXEC Privilege

Default None

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 7.8.1.0	Introduced on C-Series and S-Series

ip dhcp snooping trust

CES Configure an interface as trusted.

Syntax [no] ip dhcp snooping trust

Command Modes INTERFACE

Default Untrusted

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 7.8.1.0	Introduced on C-Series and S-Series

ip dhcp source-address-validation

CES Enable IP Source Guard.

Syntax [no] ip dhcp source-address-validation [ipmac]

Parameters ipmac Enable IP+MAC Source Address Validation (Not available on E-Series).

Command Modes INTERFACE

Default Disabled

Command **History**

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 8.2.1.0	Added keyword ipmac .
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

You must allocate at least one FP block to ipmacacl before you can enable IP+MAC Source Address Validation.

- Use the command cam-acl 12acl from CONFIGURATION mode
- 2 Save the running-config to the startup-config
- 3 Reload the system.

ip dhcp snooping vlan

Enable DHCP Snooping on one or more VLANs.

Syntax [no] ip dhcp snooping vlan name

Parameters Enter the name of a VLAN on which to enable DHCP Snooping. name

Command Modes CONFIGURATION

> **Default** Disabled

Command **History**

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information When enabled the system begins creating entries in the binding table for the specified VLAN(s). Note that learning only happens if there is a trusted port in the VLAN.

Related Commands

ip dhcp snooping trust Configure an interface as trusted.

ip dhcp relay

Enable Option 82. CES

> ip dhcp relay information-option [trust-downstream] **Syntax**

Parameters trust-downstream Configure the system to trust Option 82 when it is received from the previous-hop router.

Command Modes CONFIGURATION Default

Disabled

Command History

Version 8.3.5.0	Introduced on the S55.
Version 8.3.1.0	Introduced on E-Series.
Version 7.8.1.0	Introduced on C-Series and S-Series

show ip dhcp snooping

CĖS

Display the contents of the DHCP binding table or display the interfaces configured with IP Source Guard.

Syntax

show ip dhcp snooping [binding | source-address-validation]

Parameters

binding	Display the binding table.
source-address-validation	Display the interfaces configured with IP Source Guard.

Command Modes

EXEC

EXEC Privilege

Default

None

Command History

Version 8.3.5.0	Introduced on the S55.	
Version 8.3.1.0	Introduced on E-Series.	
Version 7.8.1.0	Introduced on C-Series and S-Series	

Clear the contents of the DHCP binding table.

Related Commands

ip dhcp snooping verify mac-address

clear ip dhcp snooping

CES

Validate a DHCP packet's source hardware address against the client hardware address field (CHADDR) in the payload.

Syntax

[no] ip dhcp snooping verify mac-address

Command Modes

CONFIGURATION

Default

Disabled

Command History

Version 8.3.5.0	Introduced on the S55.	
Version 8.3.1.0	Introduced on E-Series.	
Version 8.2.1.0	Introduced on C-Series and S-Series	

Force10 Resilient Ring Protocol (FRRP)

Overview

Force 10 Resilient Ring Protocol (FRRP) is supported on platforms [C][E][S]

FRRP is a proprietary protocol for that offers fast convergence in a Layer 2 network without having to run the Spanning Tree Protocol. The Resilient Ring Protocol is an efficient protocol that transmits a high-speed token across a ring to verify the link status. All the intelligence is contained in the master node with practically no intelligence required of the transit mode.

Commands

The FRRP commands are:

- clear frrp
- debug frrp
- description
- disable
- interface
- member-vlan
- mode
- protocol frrp
- show frrp
- timer

Important Points to Remember

- FRRP is media- and speed-independent.
- FRRP is a Dell Networking proprietary protocol that does not interoperate with any other vendor.
- Spanning Tree must be disabled on both primary and secondary interfaces before Resilient Ring protocol is enabled.
- A VLAN configured as control VLAN for a ring cannot be configured as control or member VLAN for any other ring.
- Member VLANs across multiple rings are not supported in Master nodes.
- If multiple rings share one or more member VLANs, they cannot share any links between them.
- Each ring can have only one Master node; all others are Transit nodes.

clear frrp

CES

Clear the FRRP statistics counters.

Syntax

clear frrp [ring-id]

Parameters

ring-id (Optional) Enter the ring identification number.

Range: 1 to 255

Defaults

No default values or behavior

Command Modes


EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.5.1.0	Introduced

Example

Figure 11-1. clear frrp Command Examples



Usage Information

Executing this command, without the optional *ring-id*, will clear statistics counters on all the available rings. FTOS requires a command line confirmation before the command is executed. This commands clears the following counters:

- hello Rx and Tx counters
- Topology change Rx and Tx counters
- The number of state change counters

Related Commands

show frrp

Display the Resilient Ring Protocol configuration

debug frrp

Enable FRRP debugging.

Syntax

debug frrp {event | packet | detail} [ring-id] [count number]

To disable debugging, use the **no debug frrp** {event | packet | detail} { ring-id} [count number] command.

Parameters

event	Enter the keyword event to display debug information related to ring protocol transitions.
packet	Enter the keyword packet to display brief debug information related to control packets.
detail	Enter the keyword detail to display detailed debug information related to the entire ring protocol packets.
ring-id	(Optional) Enter the ring identification number. Range: 1 to 255
count number	Enter the keyword count followed by the number of debug outputs. Range: 1 to 65534

Defaults

Disabled

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

Usage Information

Since the Resilient Ring Protocol can potentially transmit 20 packets per interface, debug information must be restricted.

description CES

Enter an identifying description of the ring.

Syntax

description Word

To remove the ring description, use the **no description** [*Word*] command.

Parameters

Word	Enter a description of the ring.
	Maximum: 255 characters

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

disable

CES

Disable the Resilient Ring Protocol.

Syntax

disable

To enable the Resilient Ring Protocol, use the **no disable** command.

Defaults

Disabled

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

interface

CES

Configure the primary, secondary, and control-vlan interfaces.

Syntax

interface { primary interface secondary interface control-vlan vlan-id}

To return to the default, use the **no interface** { **primary** *interface* **secondary** *interface* **control-vlan** *vlan-id*} command.

Parameters

primary interface

Enter the keyword **primary** to configure the primary interface followed by one of the following interfaces and slot/port information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For Port Channel interface types, enter the keyword **port-channel** followed by a number from 1 to 255.
- For a SONET interface, enter the keyword sonet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.

secondary interface

Enter the keyword **secondary** to configure the secondary interface followed by one of the following interfaces and slot/port information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Port Channel interface types, enter the keyword **port-channel** followed by a number from 1 to 255.
- For a SONET interface, enter the keyword sonet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

control-vlan	١
vlan-id	

Enter the keyword **control-vlan** followed by the VLAN ID. Range: 1 to 4094

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1

Introduced on the S60.

Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

Usage Information

This command causes the Ring Manager to take ownership of these two ports after the configuration is validated by the IFM. Ownership is relinquished for a port only when the interface does not play a part in any control VLAN, that is, the interface does not belong to any ring.

Related Commands

bio with property and resiment range from guitation information	show frrp	Display the Resilient Ring Protocol configuration information
---	-----------	---

member-vlan

CES

Specify the member VLAN identification numbers.

Syntax member-vlan{ vlan-range}

To return to the default, use the **no member-vlan**[vlan-range] command.

Parameters

vlan-range	Enter the member VLANs using comma separated VLAN IDs, a range of VLAN IDs, a single VLAN ID, or a combination. For example:
	Comma separated: 3, 4, 6
	Range: 5-10
	Combination: 3, 4, 5-10, 8

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

mode

CES

Set the Master or Transit mode of the ring.

Syntax

mode {master | transit}

To reset the mode, use the **no mode** { **master** | **transit**} command.

Parameters

master	Enter the keyword master to set the Ring node to Master mode.
transit	Enter the keyword transit to set the Ring node to Transit mode.

Defaults

Mode None

Command Modes

CONFIGURATION (conf-frrp)

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

protocol frrp

CES

Enter the Resilient Ring Protocol and designate a ring identification.

Syntax

protocol frrp { ring-id}

To exit the ring protocol, use the **no protocol frrp** { *ring-id*} command.

Parameters

ring-id Enter the ring identification number.
Range: 1 to 255

Defaults

No default values or behavior

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Introduced for the C-Series	
Version 7.4.1.0	Introduced	

Usage Information This command places you into the Resilient Ring Protocol. After executing this command, the command line prompt changes to conf-frrp.

show frrp

CES

Display the Resilient Ring Protocol configuration.

Syntax

show frrp [ring-id [summary]] | [summary]

Parameters

ring-id	Enter the ring identification number. Range: 1 to 255
summary	(OPTIONAL) Enter the keyword summary to view just a summarized version of the Ring configuration.

Defaults

No default values or behavior

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced for the C-Series
Version 7.4.1.0	Introduced

Example 1 Figure 11-2. show frrp summary Command Example

. FTOS#show frrp summary Ring-ID State Mode Ctrl Vlan Member Vlans 11-20, 25,27-30 UP Master 2 UP 31 31 Transit 40-41 50 Down Transit. 32 FTOS#

Example 2 Figure 11-3. show frrp ring-id Command Example

FTOS#show frrp 1 Ring protocol 1 is in Master mode Ring Protocol Interface: Primary: GigabitEthernet 0/16 State: Forwarding Secondary: Port-channel 100 State: Blocking Control Vlan: 1 Ring protocol Timers: Hello-Interval 50 msec Dead-Interval 150 msec Ring Master's MAC Address is 00:01:e8:13:a3:19 Topology Change Statistics: Tx:110 Rx:45 Hello Statistics: Tx:13028 Rx:12348 Number of state Changes: 34 Member Vlans: 1000-1009 FTOS#

Example 3 Figure 11-4. show frrp ring-id summary Command Example

FTOS#show	frrp 2 summ	ary			
Ring-ID	State	Mode	Ctrl_Vlan	Member_Vlans	
2 FTOS#	Up	Master	2	11-20, 25, 27-30	

Related Commands

protocol frrp

Enter the Resilient Ring Protocol and designate a ring identification

timer

CES

Set the hello or dead interval for the Ring control packets.

Syntax

timer {hello-interval milliseconds}| {dead-interval milliseconds}

To remove the timer, use the **no timer** {hello-interval [milliseconds]}| {dead-interval milliseconds} command.

Parameters		
Farameters	hello-interval milliseconds	Enter the keyword hello-interval followed by the time, in milliseconds, to set the hello interval of the control packets. The milliseconds must be enter in increments of 50 milliseconds, for example 50, 100, 150 and so on. If an invalid value is enter, an error message is generated.
		Range: 50 to 2000ms
		Default: 500 ms
	dead-interval milliseconds	Enter the keyword dead-interval followed by the time, in milliseconds, to set the dead interval of the control packets.
		Range: 50 to 6000ms
		Default: 1500ms
		Note: The configured dead interval should be at least three times the hello interval
Defaults	Default as shown	
Command Modes	CONFIGURATIO	ON (conf-frrp)
Command		
History	Version 8.3.3.1	Introduced on the S60.
•	Version 8.2.1.0	Introduced for the C-Series
		

Version 7.4.1.0

Introduced

The hello interval is the interval at which ring frames are generated from the primary interface of the master node. The dead interval is the time that elapses before a timeout occurs.

GARP VLAN Registration (GVRP)

Overview

GARP VLAN Registration (GVRP) is supported on platforms [C][E][S]

Commands

The GVRP commands are:

- clear gvrp statistics
- bpdu-destination-mac-address
- debug gvrp
- disable
- garp timers
- gvrp enable
- gvrp registration
- protocol gvrp
- show config
- show garp timers
- show gvrp
- show gvrp statistics on page 27

The GARP (Generic Attribute Registration Protocol) mechanism allows the configuration of a GARP participant to propagate through a network quickly. A GARP participant registers or de-registers its attributes with other participants by making or withdrawing declarations of attributes. At the same time, based on received declarations or withdrawals, GARP handles attributes of other participants.

GVRP enables a device to propagate local VLAN registration information to other participant devices and dynamically update the VLAN registration information from other devices. The registration information updates local databases regarding active VLAN members and through which port the VLANs can be reached.

GVRP ensures that all participants on a bridged LAN maintain the same VLAN registration information. The VLAN registration information propagated by GVRP include both manually configured local static entries and dynamic entries from other devices.

GVRP participants have the following components:

- The GVRP application
- GARP Information Propagation (GIP)
- GARP Information Declaration (GID)

Important Points to Remember

- GVRP is supported on Layer 2 ports only.
- All VLAN ports added by GVRP are tagged.
- GVRP is supported on untagged ports belonging to a default VLAN, and tagged ports.
- GVRP cannot be enabled on untagged ports belonging to a non-default VLAN unless native VLAN is turned on.
- GVRP requires end stations with dynamic access NICs.
- Based on updates from GVRP-enabled devices, GVRP allows the system to dynamically create a port-based VLAN (unspecified) with a specific VLAN ID and a specific port.
- On a port-by-port basis, GVRP allows the system to learn about GVRP updates to an existing port-based VLAN with that VLAN ID and IEEE 802.1Q tagging.
- GVRP allows the system to send dynamic GVRP updates about your existing port-based VLAN.
- GVRP updates are not sent to any blocked Spanning Tree Protocol (STP) ports. GVRP operates only on ports that are in the forwarding state.
- GVRP operates only on ports that are in the STP forwarding state. If GVRP is enabled, a port that changes to the STP forwarding state automatically begins to participate in GVRP. A port that changes to an STP state other than forwarding no longer participates in GVRP.
- VLANs created dynamically with GVRP exist only as long as a GVRP-enabled device is sending
 updates. If the devices no longer send updates, or GVRP is disabled, or the system is rebooted, all
 dynamic VLANs are removed.
- GVRP manages the active topology, not non-topological data such as VLAN protocols. If a local
 bridge needs to classify and analyze packets by VLAN protocols, you must manually configure
 protocol-based VLANs, and simply rely on GVRP for VLAN updates. But if the local bridge
 needs to know only how to reach a given VLAN, then GVRP provides all necessary information.
- The VLAN topologies that GVRP learns are treated differently from VLANs that are statically
 configured. The GVRP dynamic updates are not saved in NVRAM, while static updates are saved
 in NVRAM. When GVRP is disabled, the system deletes all VLAN interfaces that were learned
 through GVRP and leaves unchanged all VLANs that were manually configured.

clear gvrp statistics

C E S Clear GVRP statistics on an interface.

Syntax clear gvrp statistics interface interface

Parameters

interface interface

Enter the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Port Channel interface, enter the keyword port-channel followed by the Port Channel number:

C-Series and S-Series Range: 1-128

E-Series Range: 1-255 for TeraScale

 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

No default values or behavior

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on C, E, and S-Series	
show gvrp statistics	Display the GVRP statistics	•

Related Commands

debug gvrp

Enable debugging on GVRP.

Syntax

debug gvrp {config | events | pdu}

To disable debugging, use the **no debug gvrp** {config | events | pdu} command.

Parameters

config	Enter the keyword config to enable debugging on the GVRP configuration.
event	Enter the keyword event to enable debugging on the JOIN/LEAVE events.
pdu	Enter the keyword pdu followed one of the following Interface keywords and slot/port or number information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by the Port Channel number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Disabled

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on C, E, and S-Series	

disable

CES

Globally disable GVRP.

Syntax

disable

To re-enable GVRP, use the **no disable** command.

Defaults

Enabled

Command Modes

CONFIGURATION-GVRP

Command History

Version 8.3.3.1	Introduced on the S60.		
Version 7.6.1.0	Introduced on C, E, and S-Series		
gvrp enable	Enable GVRP on physical interfaces and LAGs.		
protocol gvrp	Access GVRP protocol		

Related Commands

garp timers



Set the intervals (in milliseconds) for sending GARP messages.

Syntax

garp timers { join | leave | leave-all}

To return to the previous setting, use the **no garp timers {join | leave | leave-all}** command.

Parameters

join	Enter the keyword join followed by the number of milliseconds to configure the join time.		
	Range: 100-2147483647 milliseconds		
	Default: 200 milliseconds		
	Note: Designate the milliseconds in multiples of 100		
leave	Enter the keyword leave followed by the number of milliseconds to configure the leave time.		
	Range: 100-2147483647 milliseconds		
	Default: 600 milliseconds		
	Note: Designate the milliseconds in multiples of 100		
leave-all	Enter the keyword leave-all followed by the number of milliseconds to configure the leave-all time.		
	Range: 100-2147483647 milliseconds		
	Default: 1000 milliseconds		
	Note: Designate the milliseconds in multiples of 100		

Defaults

Default as above

Command Modes

CONFIGURATION-GVRP

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on C, E, and S-Series

Usage Information

Join Timer—Join messages announce the willingness to register some attributes with other participants. Each GARP application entity sends a Join message twice, for reliability, and uses a join timer to set the sending interval.

Leave Timer—Leave announces the willingness to de-register with other participants. Together with the Join, Leave messages help GARP participants complete attribute reregistration and de-registration. Leave Timer starts upon receipt of a **leave** message sent for de-registering some attribute information. If a **join** message is *not* received before the **leave** time expires, the GARP application entity removes the attribute information as requested.

Leave All Timer—The Leave All Timer starts when a GARP application entity starts. When this timer expires, the entity sends a leave-all message so that other entities can re-register their attribute information. Then, the leave-all time begins again.

Related Commands

Display the current GARP times show garp timers

gvrp enable

CES

Enable GVRP on physical interfaces and LAGs.

Syntax gvrp enable

To disable GVRP on the interface, use the **no gvrp enable** command.

Defaults Disabled

Command Modes CONFIGURATION-INTERFACE

> Command **History**

Version 8.3.3.1 Introduced on the S60. Version 7.6.1.0 Introduced on C, E, and S-Series

Related **Commands**

disable Globally disable GVRP.

gvrp registration

CES

Configure the GVRP register type.

Syntax gvrp registration {fixed | normal | forbidden}

To return to the default, use the **gvrp register normal** command.

Parameters

fixed	Enter the keyword fixed followed by the VLAN range in a comma separated VLAN ID set.
normal	Enter the keyword normal followed by the VLAN range in a comma separated VLAN ID set.
	This is the default
forbidden	Enter the keyword forbidden followed by the VLAN range in a comma separated VLAN ID set.

Defaults Default registration is **normal**

Command Modes CONFIGURATION-INTERFACE

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on C, E, and S-Series

Usage Information

The **fixed** registration prevents an interface, configured via the command line to belong to a VLAN (static configuration), from being un-configured when it receives a Leave message. Therefore, the registration mode on that interface is fixed.

The **normal** registration is the default registration. The port's membership in the VLANs depends on GVRP. The interface becomes a member of VLANs after learning about the VLAN through GVRP. If the VLAN is removed from the port that sends GVRP advertisements to this device, then the port will stop being a member of the VLAN.

The **forbidden** is used when you do not want the interface to advertise or learn about VLANs through GVRP.

Related Commands

show gvrp Display the GVRP configuration including the registration

protocol gvrp

CES

Access GVRP protocol — (config-gvrp)#.

Syntax protocol gvrp

Defaults Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on the S60.

Version 7.6.1.0 Introduced on C, E, and S-Series

Related Commands

disable Globally disable GVRP.

show config

CES

Display the global GVRP configuration.

Syntax show config

Command Modes CONFIGURATION-GVRP

Command History

Version 8.3.3.1 Introduced on the S60.

Version 7.6.1.0 Introduced on C, E, and S-Series

gvrp enable Enable GVRP on physical interfaces and LAGs.

protocol gvrp Access GVRP protocol.

Related Commands

show garp timers

Display the GARP timer settings for sending GARP messages. CES

Syntax show garp timers

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on C, E, and S-Series

Example Figure 12-1. show garp timers Command Example

FTOS#show garp timers GARP Timers Value (milliseconds) Join Timer 200 Leave Timer 600 LeaveAll Timer 10000 FTOS#

Related **Commands**

Set the intervals (in milliseconds) for sending GARP messages. garp timers

show gvrp

Display the GVRP configuration.

Syntax show gvrp [brief | interface]

Parameters

brief	(OPTIONAL) Enter the keyword brief to display a brief summary of the GVRP configuration.
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by the Port Channel number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version7.6.1.0	Introduced on C, E, and S-Series

Example

Figure 12-2. show gvrp brief Command Example

R3#show gvrp b GVRP Feature i	orief s currently enabled.		
Port	GVRP Status	Edge-Port	
Gi 3/0	Disabled	No	
Gi 3/1	Disabled	No	
Gi 3/2	Enabled	No	
Gi 3/3	Disabled	No	
Gi 3/4	Disabled	No	
Gi 3/5	Disabled	No	
Gi 3/6	Disabled	No	
Gi 3/7	Disabled	No	
Gi 3/8	Disabled	No	
R3#show gvrp b	orief		

Usage Information

If no ports are GVRP participants, the message output changes from:

GVRP Participants running on <port_list>

to

GVRP Participants running on no ports

Related Commands

show gvrp statistics Display the GVRP statistics

show gvrp statistics

CES

Display the GVRP configuration statistics.

Syntax show gvrp statistics {interface interface | summary}

Parameters

interface interface	Enter the keyword interface followed by one of the interface keywords and slot/port or number information:
	• For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel interface, enter the keyword port-channel followed by the Port Channel number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
summary	Enter the keyword summary to display just a summary of the GVRP statistics.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on C, E, and S-Series

Example

Figure 12-3. show gvrp statistics Command Example

```
FTOS#show gvrp statistics int gi 1/0
Join Empty Received: 0
Join In Received: 0
Empty Received: 0
LeaveIn Received: 0
Leave Empty Received: 0
Leave All Received: 40
Join Empty Transmitted: 156
Join In Transmitted: 0
Empty Transmitted: 0
Leave In Transmitted: 0
Leave Empty Transmitted: 0
Leave All Transmitted: 41
Invalid Messages/Attributes skipped: 0
Failed Registrations: 0
FTOS#
```

Usage Information

Invalid messages/attributes skipped can occur in the following cases:

- The incoming GVRP PDU has an incorrect length.
- "End of PDU" was reached before the complete attribute could be parsed.
- The Attribute Type of the attribute that was being parsed was not the GVRP VID Attribute Type
- The attribute that was being parsed had an invalid attribute length.
- The attribute that was being parsed had an invalid GARP event.
- The attribute that was being parsed had an invalid VLAN ID. The valid range is 1 4095.

A failed registration can occur for the following reasons:

- Join requests were received on a port that was blocked from learning dynamic VLANs (GVRP Blocking state).
- An entry for a new GVRP VLAN could not be created in the GVRP database.

Related Commands

show gvrp	Display the GVRP configuration

Internet Group Management Protocol (IGMP)

Overview

The platforms on which a command is supported is indicated by the character — [E] for the E-Series, [C] for the C-Series, and [S] for the S-Series — that appears below each command heading.

This chapter contains the following sections:

- **IGMP Commands**
- **IGMP Snooping Commands**

IGMP Commands

FTOS supports IGMPv1/v2/v3 and is compliant with RFC-3376.

Important Points to Remember

- FTOS supports PIM-SM and PIM-SSM include and exclude modes.
- IGMPv2 is the default version of IGMP on interfaces. IGMPv3 can be configured on interfaces, and is backward compatible with IGMPv2.
- The maximum number of interfaces supported is 512 on the E-Series. On the C-Series and S-Series 31 interfaces are supported.
- **Note:** The S60 supports up to 95 interfaces.
- Maximum number of groups supported no hard limit
- IGMPv3 router interoperability with IGMPv2 and IGMPv1 routers on the same subnet is not supported.
- An administrative command (**ip igmp version**) is added to manually set the IGMP version.
- All commands, previously used for IGMPv2, are compatible with IGMPv3.

The commands include:

- clear ip igmp groups
- debug ip igmp
- ip igmp access-group
- ip igmp group-join-limit
- ip igmp immediate-leave
- ip igmp last-member-query-interval

- ip igmp querier-timeout
- ip igmp query-interval
- ip igmp query-max-resp-time
- ip igmp ssm-map
- ip igmp static-group
- ip igmp version
- show ip igmp groups
- show ip igmp interface
- show ip igmp ssm-map

clear ip igmp groups

C E S Clear entries from the group cache table.

Syntax clear ip igmp groups [group-address | interface]

Parameters

group-address	(OPTIONAL) Enter the IP multicast group address in dotted decimal format.
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	• For an 100/1000 Base-T Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information.
	• For a 1-Gigabit Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword tengigabitethernet followed by the slot/port information.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series legacy command		

Usage Information

IGMP commands accept only non-VLAN interfaces—specifying VLAN will not yield a results.



Note: The S60 supports up to 95 interfaces.

debug ip igmp

CES

Enable debugging of IGMP packets.

Syntax

debug ip igmp [group address | interface]

To disable IGMP debugging, enter **no debug ip igmp** [group address | interface]. To disable all debugging, enter **undebug all**.

Parameters

group-address	(OPTIONAL) Enter the IP multicast group address in dotted decimal format.	
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:	
	Enter one of the following keywords and slot/port or number information:	
	 For a 1-Gigabit Ethernet interfale, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 32 for EtherScale, 1 to 255 for TeraScale	
	 For SONET interfaces, enter the keyword sonet followed by the slot/port information. This keyword is only available on E-Series and C-Series. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
	 Enter the keyword backup to view the backup interface for this interface. 	

Defaults Disabled

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series legacy command		

Usage Information

IGMP commands accept only non-VLAN interfaces—specifying VLAN will not yield a results. This command displays packets for IGMP and IGMP Snooping.



Note: The S60 supports up to 95 interfaces.

ip igmp access-group

CES

Use this feature to specify access control for packets.

Syntax ip igmp access-group access-list

To remove the feature, use the **no ip igmp access-group** access-list command.

Parameters

access-list	Enter the name of the extended ACL (16 characters maximum).

Defaults

Not configured

Command Modes

INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.6.1.0	Introduced on E-Series

Usage Information

The access list accepted is an extended ACL. This feature is used to block IGMP reports from hosts, on a per-interface basis; based on the group address and source address specified in the access list.

ip igmp group-join-limit

Use this feature to limit the number of IGMP groups that can be joined in a second.

Syntax ip igmp group-join-limit number

Range: 1 to 10000

Defaults No default values or behavior

Command Modes CONFIGURATION (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.6.1.0	Introduced on E-Series

ip igmp immediate-leave

CES Enable IGMP immediate leave.

Syntax ip igmp immediate-leave [group-list prefix-list-name]

To disable ip igmp immediate leave, use the **no ip igmp immediate-leave** command.

Parameters

group-list *prefix-list-name* Enter the keyword **group-list** followed by a string up to 16 characters long of the *prefix-list-name*.

Defaults Not configured

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
E-Series legacy command		

Usage Information

Querier normally send a certain number of group specific queries when a leave message is received, for a group, prior to deleting a group from the membership database. There may be situations in which immediate deletion of a group from the membership database is required. This command provides a way to achieve the immediate deletion. In addition, this command provides a way to enable immediate-leave processing for specified groups.

ip igmp last-member-query-interval

CES

Change the last member query interval, which is the Max Response Time inserted into Group-Specific Queries sent in response to Leave Group messages. This interval is also the interval between Group-Specific Query messages.

Syntax

ip igmp last-member-query-interval milliseconds

To return to the default value, enter **no ip igmp last-member-query-interval**.

Parameters

milliseconds	Enter the number of milliseconds as the interval.
	Default: 1000 milliseconds
	Range: 100 to 65535

Defaults

1000 milliseconds

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
E-Series legacy command		

ip igmp querier-timeout



Change the interval that must pass before a multicast router decides that there is no longer another multicast router that should be the querier.

Syntax

ip igmp querier-timeout seconds

To return to the default value, enter **no ip igmp querier-timeout**.

Parameters

seconds	Enter the number of seconds the router must wait to become the new querier.
	Default: 125 seconds
	Range: 60 to 300

Defaults

125 seconds

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on S-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
Version 7.5.1.0	Introduced on C-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
E-Series legacy command	

ip igmp query-interval

Change the transmission frequency of IGMP general queries sent by the Querier.

Syntax ip igmp query-interval seconds

To return to the default values, enter no ip igmp query-interval.

Parameters

seconds Enter the number of seconds between queries sent out.

Default: 60 seconds

Range: 1 to 18000

Defaults 60 seconds

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on S-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
Version 7.5.1.0	Introduced on C-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
E-Series legacy command	

ip igmp query-max-resp-time

Set the maximum query response time advertised in general queries.

Syntax ip igmp query-max-resp-time seconds

To return to the default values, enter **no ip igmp query-max-resp-time**.

Parameters

seconds Enter the number of seconds for the maximum response time.

Default: 10 seconds

Range: 1 to 25

Defaults 10 seconds

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on S-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
Version 7.5.1.0	Introduced on C-Series in Interface VLAN mode only to enable that system to act as an IGMP Proxy Querier.
E-Series legacy command	

ip igmp ssm-map

Use a statically configured list to translate (*,G) memberships to (S,G) memberships.

Syntax ip igmp ssm-map std-access-list source-address

Undo this configuration, that is, remove SSM map (S,G) states and replace them with (*,G) states using the command **ip igmp ssm-map** std-access-list source-address command.

Parameters

std-access-list	Specify the standard IP access list that contains the mapping rules for multicast groups.
source-address	Specify the multicast source address to which the groups are mapped.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.7.1.0	Introduced on E-Series

Usage Information

Mapping applies to both v1 and v2 IGMP joins; any updates to the ACL are reflected in the IGMP groups. You may not use extended access lists with this command. When a static SSM map is configured and the router cannot find any matching access lists, the router continues to accept (*,G) groups.

Related Commands

ip access-list standard	Create a standard access list to filter based on IP address.

ip igmp static-group

CES Configure an IGMP static group.

Syntax

ip igmp static-group {group address [exclude [source address]] | [include {source address}]}

To delete a static address, use the **no ip igmp static-group** { group address [exclude [source address]] | [include { source address}]} command.

Parameters

group address	Enter the group address in dotted decimal format (A.B.C.D)	
exclude source address	(OPTIONAL) Enter the keyword exclude followed by the source address, in dotted decimal format (A.B.C.D), for which a static entry needs to be added.	
include source address	(OPTIONAL) Enter the keyword include followed by the source address, in dotted decimal format (A.B.C.D), for which a static entry needs to be added.	
	Note: A group in include mode must have at least one source address defined.	

Defaults

No default values or behavior

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series

Version 7.7.1.0	Introduced on C-Series
Version 7.5.1.0	Expanded to support the exclude and include options
E-Series legacy command	

Usage Information

A group in the **include** mode should have at least one source address defined. In **exclude** mode if no source address is specified, FTOS implicitly assumes all sources are included. If neither **include** or **exclude** is specified, FTOS implicitly assumes a IGMPv2 static join.

Command Limitations

- Only one mode (**include** or **exclude**) is permitted per multicast group per interface. To configure another mode, all sources belonging to the original mode must be unconfigured.
- If a static configuration is present and a packet for the same group arrives on an interface, the dynamic entry will completely overwrite all the static configuration for the group.

Related Commands

show ip igmp groups	Display IGMP group information	
1 0 1 0 1	1 7 6 1	

ip igmp version

Manually set the version of the router to IGMPv2 or IGMPv3.

Syntax ip igmp version {2 | 3}

Parameters

2	Enter the number 2 to set the IGMP version number to IGMPv2.
3	Enter the number 3 to set the IGMP version number to IGMPv3.

Defaults 2 (that is IGMPv2)

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.5.1.0	Introduced for E-Series

show ip igmp groups

CES View the IGMP groups.

Syntax show ip igmp groups [group-address [detail] | detail | interface [group-address [detail]]]

Parameters

group-address	(OPTIONAL) Enter the group address in dotted decimal format to view information on that group only.	
interface	(OPTIONAL) Enter the interface type and slot/port information:	
	 For a 100/1000 Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information. 	
	 For a 1-Gigabit Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information. 	
	 For a port-channel interface, enter the keyword port-channel followed by the port-channel number. 	
	 For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383. 	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword tengigabitethernet followed by the slot/port information. 	
	 For a VLAN interface enter the keyword vlan followed by a number from 1 to 4094. 	
detail	(OPTIONAL) Enter the keyword detail to display the IGMPv3 source information.	

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series and on C-Series	
Version 7.5.1.0	Expanded to support the detail option.	
E-Series legacy co	mmand	

Usage Information

This command displays the IGMP database including configured entries for either all groups on all interfaces, or all groups on specific interfaces, or specific groups on specific interfaces.



Note: The S60 supports up to 95 interfaces.

Example

Figure 13-1. show ip igmp groups Command Example

FTOS#show ip igmp groups
IGMP Connected Group Membership Group Address 224.0.1.40 Expires Last Reporter 00:02:08 10.87.7.5 Interface Uptime GigabitEthernet 13/6 09:45:23 FTOS#

Table 13-1. show ip igmp groups Command Example Fields

Field	Description	
Group Address	Lists the multicast address for the IGMP group.	
Interface	ists the interface type, slot and port number.	
Uptime	Displays the amount of time the group has been operational.	
Expires	Displays the amount of time until the entry expires.	
Last Reporter	Displays the IP address of the last host to be a member of the IGMP group	

show ip igmp interface

CES View information on the interfaces participating in IGMP.

Syntax show ip igmp interface [interface]

Parameters

interface

(OPTIONAL) Enter the interface type and slot/port information:

- For a 100/1000 Ethernet interface, enter the keyword **gigabitethernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **gigabitethernet** followed by the slot/port information.
- For a port-channel interface, enter the keyword port-channel followed by the port-channel number.
- For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **tengigabitethernet** followed by the slot/port information.
- For a VLAN interface enter the keyword vlan followed by a number from 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

-			
	Version 8.3.3.1	Introduced on the S60.	
_	10151511 5151511	marodated on the Boot	
	Version 7.6.1.0	Introduced on S-Series	
_			
	Version 7.5.1.0	Introduced on C-Series	
_			
	E-Series legacy con	mmand	

Usage Information

IGMP commands accept only non-VLAN interfaces—specifying VLAN will not yield a results.



Note: The S60 supports up to 95 interfaces.

Example

Figure 13-2. show ip igmp interface Command Example

```
TOS#show ip igmp interface
GigabitEthernet 0/0 is down, line protocol is down
  Internet protocol processing disabled
GigabitEthernet 0/5 is down, line protocol is down
  Internet protocol processing disabled
GigabitEthernet 0/6 is down, line protocol is down
  Internet protocol processing disabled
GigabitEthernet 0/7 is up, line protocol is down
Internet protocol processing disabled
GigabitEthernet 7/9 is up, line protocol is up
Internet address is 10.87.5.250/24
  IGMP is enabled on interface
  IGMP query interval is 60 seconds
  IGMP querier timeout is 120 seconds
  IGMP max query response time is 10 seconds
  IGMP last member query response interval is 1000 ms IGMP activity: 0 joins, 0 leaves
  IGMP querying router is 10.87.5.250 (this system)
  IGMP version is 2
```

show ip igmp ssm-map

CES	Display is a list of groups that are currently in the IGMP group table and contain SSM mapped sources.		
Syntax	show ip igmp	ssm-map [group]	
Parameters	group	(OPTIONAL) Enter the multicast group address in the form A.B.C.D to display the list of sources to which this group is mapped.	
Command Modes	EXEC EXEC Privilege		
Command History	Version 8.3.3.1 Version 7.8.1.0 Version 7.7.1.0	Introduced on the S60. Introduced on C-Series and S-Series Introduced on E-Series	
Related Commands	ip igmp	Use a statically configured list to translate (*,G) memberships to (S,G) memberships.	

IGMP Snooping Commands

ssm-map

FTOS supports IGMP Snooping version 2 and 3 on all Dell Networking systems:

- ip igmp snooping enable
- ip igmp snooping fast-leave
- ip igmp snooping flood
- ip igmp snooping last-member-query-interval
- ip igmp snooping mrouter
- ip igmp snooping querier
- show ip igmp snooping mrouter

Important Points to Remember for IGMP Snooping

- FTOS supports version 1, version 2, and version 3 hosts.
- FTOS IGMP snooping implementation is based on IP multicast address (not based on Layer 2 multicast mac-address) and the IGMP snooping entries are in Layer 3 flow table not in Layer 2 FIB.
- FTOS IGMP snooping implementation is based on draft-ietf-magma-snoop-10.
- FTOS supports IGMP snooping on JUMBO enabled cards.
- IGMP snooping is not enabled by default on the switch.
- A maximum of 1800 groups and 600 VLAN are supported.
- IGMP snooping is not supported on default VLAN interface.
- IGMP snooping is not supported over VLAN-Stack-enabled VLAN interfaces (you must disable IGMP snooping on a VLAN interface before configuring VLAN-Stack-related commands).
- IGMP snooping does not react to Layer 2 topology changes triggered by STP.

IGMP snooping reacts to Layer 2 topology changes triggered by MSTP by sending a general query on the interface that comes in FWD state.

Important Points to Remember for IGMP Querier

- The IGMP snooping Querier supports version 2.
- You must configure an IP address to the VLAN interface for IGMP snooping Querier to begin. The IGMP snooping Querier disables itself when a VLAN IP address is cleared, and then it restarts itself when an IP address is re-assigned to the VLAN interface.
- When enabled, IGMP snooping Querier will not start if there is a statically configured multicast router interface in the VLAN.
- When enabled, IGMP snooping Querier starts after one query interval in case no IGMP general query (with IP SA lower than its VLAN IP address) is received on any of its VLAN members.
- When enabled, IGMP snooping Querier periodically sends general queries with an IP source address of the VLAN interface. If it receives a general query on any of its VLAN member, it will check the IP source address of the incoming frame.

If the IP SA in the incoming IGMP general query frame is lower than the IP address of the VLAN interface, then the switch disables its IGMP snooping Ouerier functionality.

If the IP SA of the incoming IGMP general query is higher than the VLAN IP address, the switch will continue to work as an IGMP snooping Querier.

ip igmp snooping enable



Enable IGMP snooping on all or a single VLAN. This is the master on/off switch to enable IGMP snooping.

ip igmp snooping enable **Syntax**

To disable IGMP snooping, enter **no ip igmp snooping enable** command.

Defaults Disabled

Command Modes CONFIGURATION

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy co	mmand

Usage Information

You must enter this command to enable IGMP snooping. When enabled from CONFIGURATION mode, IGMP snooping is enabled on all VLAN interfaces (except default VLAN).



Note: You must execute the **no shutdown** command on the VLAN interface for IGMP Snooping to function.

Related Commands

no shutdown	Activate an interface	

ip igmp snooping fast-leave

Enable IGMP snooping fast leave for this VLAN. [C][E][S]

Syntax ip igmp snooping fast-leave

To disable IGMP snooping fast leave, use the **no igmp snooping fast-leave** command.

Defaults Not configured

Command Modes INTERFACE VLAN—(conf-if-vl-n)

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy co	mmand

Usage Information

Queriers normally send a certain number of queries when a leave message is received prior to deleting a group from the membership database. There may be situations in which *fast* deletion of a group is required. When IGMP fast leave processing is enabled, the switch will remove an interface from the multicast group as soon as it detects an IGMP version 2 leave message on the interface.

ip igmp snooping flood CES This command contro

This command controls the flooding behavior of unregistered multicast data packets. On the E-Series, when flooding is enabled (the default), unregistered multicast data traffic is flooded to all ports in a VLAN. When flooding is disabled, unregistered multicast data traffic is forwarded to *only* multicast router ports, both static and dynamic, in a VLAN. If there is no multicast router port in a VLAN, then unregistered multicast data traffic is dropped. On the

C-Series and S-Series, unregistered multicast data traffic is dropped when flooding is disabled; they do not forward the packets to multicast router ports. On the C-Series and S-Series, Layer 3 multicast must be disabled (**no ip multicast-routing**) in order to disable Layer 2 multicast flooding.

Syntax ip igmp snooping flood

Defaults Enabled

Command Modes CONFIGURATION

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Introduced on the C-Series and S-Series.	
Version 7.7.1.1	Introduced on E-Series.	

ip igmp snooping last-member-query-interval

CES

The last member query interval is the "maximum response time" inserted into Group-Specific queries sent in response to Group-Leave messages. This interval is also the interval between successive Group-Specific Query messages. Use this command to change the last member query interval.

Syntax

ip igmp snooping last-member-query-interval milliseconds

To return to the default value, enter no ip igmp snooping last-member-query-interval.

Parameters

milliseconds Enter the interval in milliseconds.

Default: 1000 milliseconds

Range: 100 to 65535

Defaults

1000 milliseconds

Command Modes

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy co	ommand

ip igmp snooping mrouter

CES

Statically configure a VLAN member port as a multicast router interface.

Syntax

ip igmp snooping mrouter interface interface

To delete a specific multicast router interface, use the **no igmp snooping mrouter interface** *interface* command.

Parameters

interface interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For a Port Channel interface, enter the keyword port-channel followed by a number:

C-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale

Defaults

Not configured

Command Modes

INTERFACE VLAN—(conf-if-vl-*n*)

Version 8.3.3.1	Introduced on the S60.	
Version 7.6.1.0	Introduced on S-Series	

Version 7.5.1.0	Introduced on C-Series
E-Series legacy co	mmand

Usage Information

FTOS provides the capability of statically configuring interface to which a multicast router is attached. To configure a static connection to the multicast router, enter the ip igmp snooping mrouter interface command in the VLAN context. The interface to the router must be a part of the VLAN where you are entering the command.



Note: The S60 supports up to 95 interfaces.

ip igmp snooping querier

CES Enable IGMP querier processing for the VLAN interface.

Syntax ip igmp snooping querier

> To disable IGMP querier processing for the VLAN interface, enter no ip igmp snooping querier command.

Defaults Not configured

Command Modes INTERFACE VLAN—(conf-if-vl-*n*)

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy command	

Usage Information

This command enables the IGMP switch to send General Queries periodically. This is useful when there is no multicast router present in the VLAN because the multicast traffic does not need to be routed. An IP address must be assigned to the VLAN interface for the switch to act as a querier for this VLAN.

show ip igmp snooping mrouter

Display multicast router interfaces.

show ip igmp snooping mrouter [vlan number] Syntax

Parameters vlan number Enter the keyword vlan followed by the vlan number.

Range: 1-4094

Command Modes EXEC

EXEC Privilege

Version 8.3.3.1	Introduced on the S60
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0 Introduced on C-Series

E-Series legacy command

Example

Figure 13-3. show ip igmp snooping mrouter Command Example

FTOS#show ip igmp snooping mrouter Interface Router Ports Vlan 2 Gi 13/3, Po 1 FTOS#

Related Commands

show ip igmp groups

Use this IGMP command to view groups

Interfaces

Overview

This chapter defines interface commands and is divided into the following sections:

- **Basic Interface Commands**
- Port Channel Commands
- **UDP** Broadcast

The symbols (C) (E) (S) under command headings indicate which Dell Networking platforms — C-Series, E-Series, or S-Series, respectively — support the command.

Although all interfaces are supported on E-Series ExaScale, some interface functionality is supported on E-Series ExaScale ex with FTOS 8.2.1.0. and later. When this is the case that is noted in the command history.

Basic Interface Commands

The following commands are for physical, Loopback, and Null interfaces:

- auto-mdix
- clear counters
- clear dampening
- cx4-cable-length
- dampening
- description
- disable-on-sfm-failure
- duplex (Management)
- duplex (10/100 Interfaces)
- flowcontrol
- interface
- interface loopback
- interface ManagementEthernet
- interface null
- interface range
- interface range macro (define)
- interface range macro name
- interface vlan
- ipg (10 Gigabit Ethernet interfaces)

- keepalive
- Ifs enable
- link debounce-timer
- monitor
- mtu
- · negotiation auto
- portmode hybrid
- rate-interval
- show config
- show config (from INTERFACE RANGE mode)
- show interfaces
- show interfaces configured
- show interfaces dampening
- · show interfaces description
- show interfaces linecard
- show interfaces phy
- · show interfaces stack-unit
- show interfaces status
- show interfaces switchport
- show interfaces transceiver
- show range
- shutdown
- speed (for 10/100/1000 interfaces)
- speed (Management interface)
- stack-unit module
- switchport
- wanport

auto-mdix





Enable Auto-MDIX on copper ports.

Syntax [no] auto-mdix

Defaults Enabled

Command Modes INTERFACE

Command History

Version 8.3.5.3	Introduced on the S55.	
Version 8.3.3.3	Introduced on the S60.	

Usage Information

With Auto-MDIX enabled, you can connect two network devices irrespective of the cable type (straight-through or crossover) and the MDI mode of the peer device. When Auto-MDIX is disabled at both ends, the copper ports behave as MDI. In this case, you need a crossover cable to connect the port to another MDI port, or a straight-through cable to connect the port to a MDIX port. The link will not come up when wrong cables are used.

clear counters

CES

Clear the counters used in the **show interfaces** commands for all VRRP groups, VLANs, and physical interfaces, or selected ones.

Syntax

clear counters [interface] [vrrp [vrid] | learning-limit]

Parameters

interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383.
	• For a port channel interface, enter the keyword port-channel followed by the number of the port channel:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale
	• For the management interface on the RPM, enter the keyword ManagementEthernet followed by slot/port information. The slot range is 0-1, and the port range is 0.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
vrrp vrid	(OPTIONAL) Enter the keyword Vrrp to clear statistics for all VRRP groups configured. Enter a number from 1 to 255 as the <i>Vrid</i> .
learning-limit	(OPTIONAL) Enter the keyword learning-limit to clear unknown source address (SA) drop counters when MAC learning limit is configured on the interface.
	Note: This option is not supported on the S-Series, as the MAC learning limit is not supported

Defaults

Without an interface specified, the command clears all interface counters.

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior to release supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.5.1.0	Updated definition of the learning-limit option for clarity.
	·

Example

Figure 14-1. clear counters Command Example

FTOS#clear counters Clear counters on all interfaces [confirm]

Related **Commands**

mac learning-limit	Allow aging of MACs even though a learning-limit is configured or disallow station move on learnt MACs.
show interfaces	Displays information on the interfaces.

clear dampening

Clear the dampening counters on all the interfaces or just the specified interface.

Syntax clear dampening [interface]

Parameters

interface	(Optional) Enter one of the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a port channel interface, enter the keyword port-channel followed by a number:
	C-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Without a specific interface specified, the command clears all interface dampening counters

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

FTOS#clear dampening gigabitethernet 1/2 Clear dampening counters on Gi 1/2 [confirm] y FTOS#

Related Commands

show interfaces dampening	Display interface dampening information.
dampening	Configure dampening on an interface.

cx4-cable-length

Configure the length of the cable to be connected to the selected CX4 port.

Syntax [no] cx4-cable-length {long | medium | short}

Parameters

long medium short	Enter the keyword that matches the cable length to be used at the selected port: short = For 1-meter and 3-meter cable lengths
	medium = For 5-meter cable length long = For 10-meter and 15-meter cable lengths

Defaults medium

Mode Interface

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series

Usage Information

This command only works on ports that the system recognizes as CX4 ports. So, for example, Figure 14-2 shows an attempt to configure an XFP port in an S25P with the command after inserting a CX4 converter into the port:



Note: When using a long CX4 cable between the C-Series and the S-Series, configure the cable using the **cx4-cable-length short** command only to avoid any errors.

Example

Figure 14-2. Example of Unsuccessful CX4 Cable Length Configuration

```
FTOS#show interfaces tengigabitethernet 0/26 | grep "XFP type"
Pluggable media present, XFP type is 10GBASE-CX4
FTOS(conf-if-te-0/26)#cx4-cable-length short
% Error: Unsupported command.
FTOS (conf-if-te-0/26) #cx4-cable-length medium
% Error: Unsupported command.
FTOS(conf-if-te-0/26)#cx4-cable-length long
% Error: Unsupported command.
FTOS(conf-if-te-0/26)#
```

Figure 14-3 shows a successful CX4 cable length configuration.

Example

Figure 14-3. Example of CX4 Cable Length Configuration

```
FTOS (config) #interface tengigabitethernet 0/52
FTOS (conf-if-0/52) #cx4-cable-length long
FTOS (conf-if-0/52) #show config
interface TenGigabitEthernet 0/51
 no ip address
 cx4-cable-length long
 shutdown
FTOS(conf-if-0/52)#exit
FTOS(config)#
```

For details on using XFP ports with CX4 cables, see your S-Series hardware guide.

Related **Commands**

show config

Display the configuration of the selected interface.

dampening

CES

Configure dampening on an interface.

Syntax

dampening [[[[half-life] [reuse-threshold]] [suppress-threshold]] [max-suppress-time]]

To disable dampening, use the **no dampening** [[[[half-life] [reuse-threshold]] [suppress-threshold]] [max-suppress-time]] command syntax.

Parameters

half-life	Enter the number of seconds after which the penalty is decreased. The
	penalty is decreased by half after the half-life period expires.
	Range: 1 to 30 seconds
	Default: 5 seconds
reuse-threshold	Enter a number as the reuse threshold, the penalty value below which the interface state is changed to "up".
	Range: 1 to 20000
	Default: 750
suppress-threshold	Enter a number as the suppress threshold, the penalty value above which the interface state is changed to "error disabled".
	Range: 1 to 20000
	Default: 2500
max-suppress-time	Enter the maximum number for which a route can be suppressed. The default is four times the half-life value.
	Range: 1 to 86400
	Default: 20 seconds

Defaults

Disabled

Command Modes

INTERFACE (conf-if-)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

```
FTOS(conf-if-gi-3/2)#dampening 20 800 4500 120
FTOS(conf-if-gi-3/2)#
```

Usage Information

With each flap, FTOS penalizes the interface by assigning a penalty (1024) that decays exponentially depending on the configured half-life. Once the accumulated penalty exceeds the suppress threshold value, the interface is moved to the error-disabled state. This interface state is deemed as "down" by all static/dynamic Layer 2 and Layer 3 protocols. The penalty is exponentially decayed based on the half-life timer. Once the penalty decays below the reuse threshold, the interface is enabled. The configured parameters should follow:

- suppress-threshold should be greater than reuse-threshold
- max-suppress-time should be at least 4 times half-life



Note: Dampening cannot be applied on an interface that is monitoring traffic for other interfaces.

Related Commands

clear dampening	Clear the dampening counters on all the interfaces or just the specified interface.
show interfaces dampening	Display interface dampening information.

description

CES

Assign a descriptive text string to the interface.

Syntax

description desc_text

To delete a description, enter **no description**.

Parameters

Enter a text string up to 240 characters long. desc_text

Defaults

No description is defined.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Modified for E-Series: Revised from 78 to 240 characters.

Usage Information

Entering a text string after the description command overwrites any previous text string configured as the description. The shutdown and description commands are the only commands that you can configure on an interface that is a member of a port channel. Use the show interfaces description command to display descriptions configured for each interface.

Related **Commands**

show interfaces description Display description field of interfaces.
--

disable-on-sfm-failure

Disable select ports on E300 systems when a single SFM is available.

Syntax disable-on-sfm-failure

To delete a description, enter **no disable-on-sfm-failure**.

Defaults Port is not disabled

Command Modes INTERFACE

> Command History

Version 7.7.1.0 Introduced on E300 systems only

Usage Information

When an E300 system boots up and a single SFM is active this configuration, any ports configured with this feature will be shut down. If an SFM fails (or is removed) in an E300 system with two SFM, ports configured with this feature will be shut down. All other ports are treated normally.

When a second SFM is installed or replaced, all ports are booted up and treated as normally. This feature does not take affect until a single SFM is active in the E300 system.

duplex (Management)

Set the mode of the Management interface.

Syntax duplex {half | full}

To return to the default setting, enter **no duplex**.

Parameters

half	Enter the keyword half to set the Management interface to transmit only in one direction.
full	Enter the keyword full to set the Management interface to transmit in both directions.

Defaults Not configured

Command Modes INTERFACE

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Documentation modified—added Management to distinguish from duplex (10/100 Interfaces)

Usage Information

This command applies only to the Management interface on the RPMs.

Related Commands

interface ManagementEthernet	Configure the Management port on the system (either the Primary or Standby RPM).
duplex (Management)	Set the mode of the Management interface.
management route	Configure a static route that points to the Management interface or a forwarding router.
speed (Management interface)	Set the speed on the Management interface.

duplex (10/100 Interfaces)

CES

Configure duplex mode on any physical interfaces where the speed is set to 10/100.Syntax

duplex {half | full}

To return to the default setting, enter **no duplex**.

Parameters

half	Enter the keyword half to set the physical interface to transmit only in one direction.
full	Enter the keyword full to set the physical interface to transmit in both directions.

Defaults

Not configured

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Introduced

Usage Information

This command applies to any physical interface with speed set to 10/100.



Note: Starting with FTOS 7.8.1.0, when a copper SFP2 module with catalog number GP-SFP2-1T is used in the S25P model of the S-Series, its speed can be manually set with the **speed** command. When the speed is set to 10 or 100 Mbps, the **duplex** command can also be executed.

Related **Commands**

speed (for 10/100/1000 interfaces)	Set the speed on the Base-T Ethernet interface.
negotiation auto	Enable or disable auto-negotiation on an interface.

flowcontrol



Control how the system responds to and generates 802.3x pause frames on 1Gig and 10Gig line cards.

Syntax

flowcontrol rx {off | on} tx {off | on} threshold $\{<1-2047><1-2013><1-2013>\}$

The **threshold** keyword is supported on C-Series and S-Series only.

To return to the default, use the **no flowcontrol rx {off | on} tx {off | on} threshold** command.

Parameters

rx on	Enter the keywords rx on to process the received flow control frames on this port. This is the default value for the receive side.
rx off	Enter the keywords rx off to ignore the received flow control frames on this port.
tx on	Enter the keywords tx on to send control frames from this port to the connected device when a higher rate of traffic is received. This is the default value on the send side.
tx off	Enter the keywords tx off so that flow control frames are not sent from this port to the connected device when a higher rate of traffic is received.
threshold (C-Series and S-Series only)	When tx on is configured, you can set the threshold values for: Number of flow-control packet pointers: 1-2047 (default = 75) Flow-control buffer threshold in KB: 1-2013 (default = 49KB) Flow-control discard threshold in KB: 1-2013 (default = 75KB)

Defaults

C-Series: rx off tx off

E-Series: rx on tx on

S-Series (S25/S50): rx off tx off

S60: rx on

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60, rx only.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 6.5.1.9 and 7.4.1.0	Introduced on E-Series
Version 7.8.1.0	Introduced on C-Series and S-Series with thresholds

Usage Information

The globally assigned 48-bit Multicast address 01-80-C2-00-00-01 is used to send and receive pause frames. To allow full duplex flow control, stations implementing the pause operation instruct the MAC to enable reception of frames with a destination address equal to this multicast address.

The pause:

- Starts when *either* the packet pointer or the buffer threshold is met (whichever is met first). When the discard threshold is met, packets are dropped.
- Ends when *both* the packet pointer and the buffer threshold fall below 50% of the threshold settings.

The *discard threshold* defines when the interface starts dropping the packet on the interface. This may be necessary when a connected device does not honor the flow control frame sent by the S-Series. The discard threshold should be larger than the *buffer threshold* so that the buffer holds at least hold at least 3 packets.



Note: The S60 supports only the **rx** control option. The S60 does not transmit pause frames.

Important Points to Remember

- Do not enable **tx** pause when buffer carving is enabled. Consult Dell Networking TAC for information and assistance.
- Asymmetric flow control (**rx on tx off** or **rx off tx on**) setting for the interface port less than 100 Mb/s speed is not permitted. The following error is returned:

Can't configure Asymmetric flowcontrol when speed <1G, configignored $\,$

• The only configuration applicable to half duplex ports is **rx off tx off**. The following error is returned:

Can't configure flowcontrol when half duplex is configure, config ignored

Half duplex cannot be configured when the flow control configuration is on (default is rx on tx on). The following error is returned:

Can't configure half duplex when flowcontrol is on, configignored



Note: The flow control must be off (**rx off tx off**) before configuring the half duplex.

Speeds less than 1 Gig cannot be configured when the asymmetric flow control configuration is on. The following error is returned:

Can't configure speed <1G when Asymmetric flowcontrol is on, config ignored

- FTOS only supports **rx on tx on** and **rx off tx off** for speeds less than 1 Gig (Symmetric).
- On the C-Series and S-Series systems, the flow-control sender and receiver must be on the same port-pipe. Flow control is not supported across different port-pipes on the C-Series or S-Series system.

Example Figure 14-4. show running config (partial)

```
FTOS(conf-if-gi-0/1)#show config
interface GigabitEthernet 0/1
no ip address
switchport
no negotiation auto
flowcontrol rx off tx on
no shutdown
```

The table below displays how FTOS negotiates the flow control values between two Dell Networking chassis connected back-to-back using 1G copper ports.

Table 14-1. Negotiated Flow Control Values

Configured				Negotiated			
LocRxConf	LocTxConf	RemoteRxConf	RemoteTxConf	LocNegRx	LocNegTx	RemNegRx	RemNegTx
off	off	off	off	off	off	off	off
		off	on	off	off	off	off
		on	off	off	off	off	off
		on	on	off	off	off	off
						•	
off	on	off	off	off	off	off	off
		off	on	off	off	off	off
		on	off	off	on	on	off
		on	on	off	off	off	off
						•	
on	off	off	off	off	off	off	off
		off	on	on	off	off	on
		on	off	on	on	on	on
		on	on	on	on	on	on
	'	'	'	'	,		'
on	on	off	off	off	off	off	off
		off	on	off	off	off	off
		on	off	on	on	on	on
		on	on	on	on	on	on

Related Commands

show running-config	Display the flow configuration parameters (non-default values only).
show interfaces	Display the negotiated flow control parameters.

interface

CES

Configure a physical interface on the switch.

Syntax

interface interface

Parameters

interface	Enter one of the following keywords and slot/port or number information:
	 For 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For SONET interfaces, enter the keyword sonet followed by the slot/port information.
	For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet

followed by the slot/port information.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Introduced

Example

Figure 14-5. interface Command Example

```
FTOS(conf)#interface gig 0/0
FTOS(conf-if-gi-0/0)#exit#
```

Usage Information

You cannot delete a physical interface.

By default, physical interfaces are disabled (shutdown) and are in Layer 3 mode. To place an interface in mode, ensure that the interface's configuration does not contain an IP address and enter the switchport command.

Related Commands

interface loopback	Configure a Loopback interface.
interface null	Configure a Null interface.
interface port-channel	Configure a port channel.
interface sonet	Configure a SONET interface.
interface vlan	Configure a VLAN.
show interfaces	Display interface configuration.
-	·

interface loopback

CES Configure a Loopback interface.

Syntax interface loopback number

To remove a loopback interface, use the **no interface loopback** *number* command.

Parameters

number Enter a number as the interface number. Range: 0 to 16383.

Defaults Not configured.

Command Modes CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Introduced

Example Figure 14-6. interface loopback Command Example

FTOS(conf)#interface loopback 1655 FTOS (conf-if-lo-1655)#

Related Commands

interface	Configure a physical interface.
interface null	Configure a Null interface.
interface port-channel	Configure a port channel.
interface vlan	Configure a VLAN.

interface ManagementEthernet

CE (\$60)

interface ManagementEthernet slot/port

Parameters

Syntax

slot/port Enter the keyword **ManagementEthernet** followed by slot number (0-1) and port number zero (0).

Configure the Management port on the system (either the Primary or Standby RPM).

Defaults Not configured.

Command Modes CONFIGURATION

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced for C-Series
Version 6.4.1.0	Introduced for E-Series

Example Figure 14-7. interface ManagementEthernet Command Example

FTOS(conf)#interface managementethernet 0/0
FTOS(conf-if-ma-0/0)#

Usage Information

You cannot delete a Management port.

The Management port is enabled by default (no shutdown). Use the ip address command to assign an IP address to the Management port.

If two RPMs are installed in your system, use the show redundancy command to display which RPM is the Primary RPM.

Related Commands

management route	Configure a static route that points to the Management interface or a forwarding router.	
duplex (Management)	Clear FIB entries on a specified line card.	
speed (Management interface)	Clear FIB entries on a specified line card.	

interface null

CES

Configure a Null interface on the switch.

Syntax

interface null number

Parameters

	number E	Enter zero (0) as the Null interface number.
--	----------	--

Defaults

Not configured; number = 0

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Introduced

Example

Figure 14-8. interface null Command Example

FTOS(conf)#interface null 0
FTOS(conf-if-nu-0)#

Usage Information

You cannot delete the Null interface. The only configuration command possible in a Null interface is ip unreachables.

Related Commands

interface	Configure a physical interface.
interface loopback	Configure a Loopback interface.
interface port-channel	Configure a port channel.

interface vlan	Configure a VLAN.
ip unreachables	Enable generation of ICMP unreachable messages.

interface range



This command permits configuration of a range of interfaces to which subsequent commands are applied (bulk configuration). Using the interface range command, identical commands can be entered for a range of interface.

Syntax

interface range interface, interface, ...

Parameters

interface, interface, ...

Enter the keyword **interface range** and one of the interfaces — slot/port, port-channel or VLAN number. Select the range of interfaces for bulk configuration. You can enter up to six comma separated ranges—spaces are **not** required between the commas. Comma-separated ranges can include VLANs, port-channels and physical interfaces.

- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a port channel interface, enter the keyword **port-channel** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale and ExaScale

- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a VLAN, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults

This command has no default behavior or values.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior releases supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

When creating an interface range, interfaces appear in the order they are entered; they are not sorted. The command verifies that interfaces are present (physical) or configured (logical). Important things to remember:

- Bulk configuration is created if at least one interface is valid.
- Non-existing interfaces are excluded from the bulk configuration with a warning message (Figure 14-9).
- The interface range prompt includes interface types with slot/port information for valid interfaces. The prompt allows for a maximum of 32 characters. If the bulk configuration exceeds 32 characters, it is represented by an ellipsis (...).

- When the interface range prompt has multiple port ranges, the smaller port range is excluded from the prompt (Figure 14-10).
- If overlapping port ranges are specified, the port range is extended to the smallest start port and the biggest end port (Figure 14-11).

Example Figure 14-9. Bulk Configuration Warning Message

```
FTOS(conf)#interface range so 2/0 - 1 , te 10/0 , gi 3/0 , fa 0/0 % Warning: Non-existing ports (not configured) are ignored by interface-range
```

Example Figure 14-10. Interface Range prompt with Multiple Ports

```
FTOS(conf)#interface range gi 2/0 - 23 , gi 2/1 - 10
FTOS(conf-if-range-gi-2/0-23#
```

Example Figure 14-11. Interface Range prompt Overlapping Port Ranges

```
FTOS(conf)#interface range gi 2/1 - 11 , gi 2/1 - 23
FTOS(conf-if-range-gi-2/1-23#
```

Only VLAN and port-channel interfaces created using the interface vlan and interface port-channel commands can be used in the **interface range** command.

Use the show running-config command to display the VLAN and port-channel interfaces. VLAN or port-channel interfaces that are not displayed in the show running-config command can not be used with the bulk configuration feature of the **interface range** command. You cannot create virtual interfaces (VLAN, Port-channel) using the **interface range** command.



Note: If a range has VLAN, physical, port-channel, and SONET interfaces, only commands related to physical interfaces can be bulk configured. To configure commands specific to VLAN, port-channel or SONET, only those respective interfaces should be configured in a particular range.

Figure 14-12 is an example of a single range bulk configuration.

Example Figure 14-12. Single Range Bulk Configuration

```
FTOS(config)# interface range gigabitethernet 5/1 - 23
FTOS(config-if-range)# no shutdown
FTOS(config-if-range)#
```

Figure 14-13 shows how to use commas to add different interface types to the range enabling all Gigabit Ethernet interfaces in the range 5/1 to 5/23 and both Ten Gigabit Ethernet interfaces 1/1 and 1/2.

Example Figure 14-13. Multiple Range Bulk Configuration Gigabit Ethernet and Ten Gigabit Ethernet

```
FTOS(config-if)# interface range gigabitethernet 5/1 - 23, tengigabitethernet 1/1 - 2
FTOS(config-if-range)# no shutdown
FTOS(config-if-range)#
```

Figure 14-14 shows how to use commas to add SONET, VLAN, and port-channel interfaces to the range.

Example

Figure 14-14. Multiple Range Bulk Configuration with SONET, VLAN, and port channel

```
FTOS(config-if)# interface range gigabitethernet 5/1 - 23, tengigabitethernet 1/1 - 2, Vlan 2 - 100 , Port 1 - 25
FTOS(config-if-range)# no shutdown
FTOS(config-if-range)#
```

Related Commands

interface port-channel	Configure a port channel group.	
interface vlan	Configure a VLAN interface.	
show config (from INTERFACE RANGE mode)	Show the bulk configuration interfaces.	
show range	Show the bulk configuration ranges.	
interface range macro (define)	Define a macro for an interface-range.	

interface range macro (define)

CES

Defines a macro for an interface range and then saves the macro in the running configuration.

Syntax

define interface range macro name interface, interface, ...

Parameters

name	Enter up to 16 characters for the macro name.
interface, Enter the interface keyword (see below) and one of the interfaces slot/port, portinterface, or VLAN numbers. Select the range of interfaces for bulk configuration. You can to six comma separated ranges—spaces are not required between the commas. Comma-separated ranges can include VLANs, port-channels and physical interfaces.	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a port channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.

Defaults

This command has no default behavior or value

Command Modes

CONFIGURATION

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior releases supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced

Example Figure 14-15. define interface-range macro Command Example

FTOS(config)# define interface-range test tengigabitethernet 0/0 - 3 , gigabitethernet 5/0 - 47 , gigabitethernet 13/0 - 89

FTOS# show running-config | grep define define interface-range test tengigabitethernet 0/0 - 3 , gigabitethernet 5/0 - 47 , gigabitethernet 13/0 - 89

FTOS(config)#interface range macro test

FTOS(config-if-range-te-0/0-3,gi-5/0-47,gi-13/0-89)#

Usage Information

Figure 14-15 is an example of how to define an interface range macro named *test*. Execute the **show running-config** command to display the macro definition. Applying the macro is shown in Figure 14-17.

Related Commands

interface range	Configure a range of command (bulk configuration)
interface range macro name	Run an interface range macro.

interface range macro name

Run the interface-range macro to automatically configure the pre-defined range of interfaces.

Syntax interface range macro name

Parameters

name Enter the name of an existing macro.

Defaults

This command has no default behavior or value

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced

Usage Information

Figure 14-16 runs the macro named *test* that was defined in Figure 14-15.

Example

Figure 14-16. interface-range macro Command Example

```
FTOS(config)#interface range macro test
FTOS(config-if-range-te-0/0-3,gi-5/0-47,gi-13/0-89)#
FTOS
```

Related Commands

interface range	Configure a range of command (bulk configuration)
interface range macro (define)	Define a macro for an interface range (bulk configuration)

interface vlan

CES

Configure a VLAN. You can configure up to 4094 VLANs.

Syntax

interface vlan vlan-id

To delete a VLAN, use the **no interface vlan** *vlan-id* command.

Parameters

vlan-id	Enter a number as the VLAN Identifier.
	Range: 1 to 4094.

Defaults

Not configured, except for the Default VLAN, which is configured as VLAN 1.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior releases supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Example

Figure 14-17. interface vlan Command Example

```
FTOS(conf)#int vlan 3
FTOS(conf-if-v1-3)#
```

Usage Information

For more information on VLANs and the commands to configure them, refer to Virtual LAN (VLAN) Commands.

FTP, TFTP, and SNMP operations are not supported on a VLAN. MAC ACLs are not supported in VLANs. IP ACLs are supported. See Chapter 6, Access Control Lists (ACL).

Related Commands

interface	Configure a physical interface.
interface loopback	Configure a loopback interface.
interface null	Configure a null interface.
interface port-channel	Configure a port channel group.
show vlan	Display the current VLAN configuration on the switch.
shutdown	Disable/Enable the VLAN.
tagged	Add a Layer 2 interface to a VLAN as a tagged interface.
untagged	Add a Layer 2 interface to a VLAN as an untagged interface.

ipg (10 Gigabit Ethernet interfaces)

Set the Inter-packet Gap for traffic on 10 Gigabit Ethernet interface.

Syntax ipg {ieee-802.3ae | shrink}

To return to the default of averaging the IPG, enter **no ipg** { **shrink** | **ieee-802.3ae** }

Parameters

ieee-802.3ae	Enter the keyword ieee-802.3ae to set the IPG to 12 (12-15) bytes (packet size dependent)
shrink	Enter the keyword shrink to set the IPG to 8 (8-11) bytes (packet size dependent).

Defaults

averaging the IPG

Command Modes

INTERFACE

Command History

pre-Version 6.1.1.0 Introduced for E-Series

Usage Information For 10 Gigabit Ethernet interfaces only.

IPG equals 96 bits times from end of the previous packet to start of the pre-amble of the next packet.

keepalive

CES

On SONET interfaces, send keepalive packets periodically to keep an interface alive when it is not transmitting data.

Syntax

keepalive [seconds]

To stop sending SONET keepalive packets, enter **no keepalive**.

Parameters

seconds	(OPTIONAL) For SONET interfaces with PPP encapsulation enabled, enter the number of seconds between keepalive packets.
	Range: 0 to 23767
	Default: 10 seconds

Defaults

Enabled

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.2	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

When you configure **keepalive**, the system sends a self-addressed packet out of the configured interface to verify that the far end of a WAN link is up. When you configure **no keepalive**, the system does not send keepalive packets and so the local end of a WAN link remains up even if the remote end is down.

Ifs enable

Enable Link Fault Signaling (LFS) on 10 Gigabit Ethernet interfaces only.

Syntax Ifs enable

To disable LFS, enter no lfs enable.

Defaults Enabled.

Command Modes INTERFACE (10 Gigabit Ethernet interfaces only)

> Command History

Introduced for E-Series pre-Version 6.1.1.0

Usage Information If there is a failure on the link, FTOS brings down the interface. The interface will stay down until the link failure signal stops.



Note: On TeraScale line cards, LFS is always enabled by default.

link debounce-timer

Assign the debounce time for link change notification on this interface.

Syntax link debounce [milliseconds]

Parameters

milliseconds Enter the time to delay link status change notification on this interface.

Range: 100-5000 ms

Default for copper is 3100 ms Default for fiber is 100 ms

Command Modes INTERFACE

> Command History

Version 8.2.1.0 Introduced on E-Series ExaScale Version 7.6.1.0 Introduced on E-Series

Usage Information Changes do not affect any ongoing debounces. The timer changes take affect from the next debounce onward.

monitor

CES

Monitor counters on a single interface or all interfaces on a line card. The screen is refreshed every 5 seconds and the CLI prompt disappears.

Syntax monitor interface [interface]

To disable monitoring and return to the CLI prompt, press the q key.

Parameters

interface (OPTIONAL) Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For the management port, enter the keyword **managementethernet** followed by the slot (0-1) and the port (0).
- For SONET interface types, enter the keyword sonet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
pre-Version 6.2.1.0	Introduced for E-Series	

Usage Information

The delta column displays changes since the last screen refresh.

Example

Figure 14-18. monitor Command Example of a Single Interface

systest-3 Monitor time: 00	0:00:06 Refresh	Intvl.: 2s	Time: 03:26:26
Interface: Gi 0/3, Enabled,	Link is Up, Line	speed is 1000	Mbit
Traffic statistics:	Current	Rate	Delta
Input bytes:	9069828	43 Bps	86
Output bytes:	606915800	43 Bps	86
Input packets:	54001	0 pps	1
Output packets:	9401589	0 pps	1
64B packets:	67	0 pps	0
Over 64B packets:	49166	0 pps	1
Over 127B packets:	350	0 pps	0
Over 255B packets:	1351	0 pps	0
Over 511B packets:	286	0 pps	0
Over 1023B packets:	2781	0 pps	0
Error statistics:			
Input underruns:	0	0 pps	0
Input giants:	0	0 pps	0
Input throttles:	0	0 pps	0
Input CRC:	0	0 pps	0
Input IP checksum:	0	0 pps	0
Input overrun:	0	0 pps	0
Output underruns:	0	0 pps	0
Output throttles:	0	0 pps	0
m - Change mode		c - Clea	r screen
1 - Page up		a - Page	
T - Increase refresh : q - Quit	interval		ease refresh interval

Figure 14-19. monitor Command Example of All Interfaces on a Line Card

systest-3	Monitor	time: 00:01:31	Dafasah Tatal Os	m' 00 54 44	`
Tntonfogo		cime: 00.01.51	Refresh Intvi.: 25	Time: 03:54:14	
	Link	In Packets	[delta]	Out Packets	
[delta]	_	_	_		_
	Down	0	0	0	0
	Down	0	0	0	0
Gi 0/2	Up	61512	52	66160	42
Gi 0/3	Up	63086	20	9405888	24
Gi 0/4	Up	14697471418	2661481	13392989657	
2661385					
Gi 0/5	Up	3759	3	161959604	832816
Gi 0/6	Up	4070	3	8680346	5
Gi 0/7	Up	61934	34	138734357	72
Gi 0/8	Up	61427	1	59960	1
Gi 0/9	Up	62039	53	104239232	3
Gi 0/10	Up	17740044091	372	7373849244	79
Gi 0/11	Up	18182889225	44	7184747584	138
Gi 0/12	Up	18182682056	0	3682	1
Gi 0/13	Up	18182681434	43	6592378911	144
Gi 0/14	Up	61349	55	86281941	15
Gi 0/15	Up	59808	58	62060	27
Gi 0/16	Up	59889	1	61616	1
Gi 0/17	Up	0	0	14950126	81293
Gi 0/18	Up	0	0	0	0
Gi 0/19	Down	0	0	0	0
Gi 0/20	Up	62734	54	62766	18
Gi 0/21	Up	60198	9	200899	9
Gi 0/22	Ūр	17304741100	3157554	10102508511	
1114221					
Gi 0/23	Uр	17304769659	3139507	7133354895	
523329	_				
m - (Change mod	de	c - Cle	ar screen	
b - I	Display by	/tes		play pkts/bytes per	sec
1 - F	Page up		a - Pag	e down	
T - J	Increase i	refresh interval	t - Dec	rease refresh interv	<i>r</i> al
\ q - Q	Quit				

Table 14-2. monitor Command Menu Options

Key	Description
systest-3	Displays the host name assigned to the system.
monitor time	Displays the amount of time since the monitor command was entered.
time	Displays the amount of time the chassis is up (since last reboot).
m	Change the view from a single interface to all interfaces on the line card or visa-versa.
С	Refresh the view.
b	Change the counters displayed from Packets on the interface to Bytes.
r	Change the [delta] column from change in the number of packets/bytes in the last interval to rate per second.
1	Change the view to next interface on the line card, or if in the line card mode, the next line card in the chassis.
a	Change the view to the previous interface on the line card, or if the line card mode, the previous line card in the chassis.
Т	Increase the screen refresh rate.
t	Decrease the screen refresh rate.
q	Return to the CLI prompt.

mtu

CES

Set the maximum Link MTU (frame size) for an Ethernet interface.

Syntax

mtu value

To return to the default MTU value, enter **no mtu**.

Parameters

value	Enter a maximum frame size in bytes.
	Range: 594 to 9252
	Default: 1554

Defaults

1554

Command Modes

INTERFACE

Command History

Version 8.3.3.4	Introduced on S-Series
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

If the packet includes a Layer 2 header, the difference between the link MTU and IP MTU (**ip mtu** command) must be enough bytes to include the Layer 2 header:

- On C-Series, the IP MTU will get adjusted automatically when the Layer 2 MTU is configured with the mtu command.
- On the E-Series, you must compensate for a Layer 2 header when configuring IP MTU and link MTU on an Ethernet interface. Use the **ip mtu** command.

When you enter the **no mtu** command, FTOS reduces the IP MTU value to 1536 bytes. On the E-Series, to return the IP MTU value to the default, enter **no ip mtu**.

Link MTU and IP MTU considerations for port channels and VLANs are as follows.

port channels:

- All members must have the same link MTU value and the same IP MTU value.
- The port channel link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the channel members.

Example: if the members have a link MTU of 2100 and an IP MTU 2000, the port channel's MTU values cannot be higher than 2100 for link MTU or 2000 bytes for IP MTU.

VLANs:

- All members of a VLAN must have same IP MTU value.
- Members can have different Link MTU values. Tagged members must have a link MTU 4 bytes higher than untagged members to account for the packet tag.
- The VLAN link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the VLAN members.

Example

The VLAN contains tagged members with Link MTU of 1522 and IP MTU of 1500 and untagged members with Link MTU of 1518 and IP MTU of 1500. The VLAN's Link MTU cannot be higher than 1518 bytes and its IP MTU cannot be higher than 1500 bytes.

Table 14-3. Difference between Link MTU and IP MTU

Layer 2 Overhead	Link MTU and IP MTU Delta
Ethernet (untagged)	18 bytes
VLAN Tag	22 bytes
Untagged Packet with VLAN-Stack Header	22 bytes
Tagged Packet with VLAN-Stack Header	26 bytes

negotiation auto

CES

Enable auto-negotiation on an interface.

Syntax negotiation auto

To disable auto-negotiation, enter **no negotiation auto**.

Defaults Enabled.

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

This command is available on C-Series and S-Series 10/100/1000 Base-T Ethernet interfaces, and on TeraScale 10/100/1000 Base-T Ethernet line cards.

The **no negotiation auto** command is only available if you first manually set the speed of a port to 10Mbits or 100Mbits.

The negotiation auto command provides a mode option for configuring an individual port to forced-master/forced slave once auto-negotiation is enabled



Note: The **mode** option is not available on non-10/100/1000 Base-T Ethernet line cards.

Figure 14-20. negotiation auto Master/Slave Example

```
FTOS(conf)# int gi 0/0
FTOS(conf-if) #neg auto
FTOS (conf-if-autoneg)# ?
                         Exit from configuration mode
end
exit
                         Exit from autoneg configuration mode
                         Specify autoneg mode
mode
                         Negate a command or set its defaults
no
show
                         Show autoneg configuration information
FTOS (conf-if-autoneg) #mode ?
forced-master
                         Force port to master mode
forced-slave
                         Force port to slave mode
FTOS (conf-if-autoneg) #
```

If the **mode** option is not used, the default setting is slave. If you do not configure **forced-master** or **forced slave** on a port, the port negotiates to either a master or a slave state. Port status is one of the following:

- Forced-master
- · Force-slave
- Master
- Slave
- Auto-neg Error—typically indicates that both ends of the node are configured with forced-master
 or forced-slave.



Caution: Ensure that one end of your node is configured as forced-master and one is configured as forced-slave. If both are configured the same (that is forced-master or forced-slave), the show interfaces command will flap between an auto-neg-error and forced-master/slave states

You can display master/slave settings with the **show interfaces** command.

Figure 14-21. Display Auto-negotiation Master/Slave Setting (partial)

```
FTOS#show interfaces configured
GigabitEthernet 13/18 is up, line protocol is up
Hardware is Force10Eth, address is 00:01:e8:05:f7:fc
Current address is 00:01:e8:05:f7:fc
Interface index is 474791997
Internet address is 1.1.1.1/24
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit, Mode full duplex, Master
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interfaces" counters 00:12:42
Queueing strategy: fifo
Input Statistics:
...
```

Both sides of the link must have auto-negotiation enabled or disabled for the link to come up.

The following table details the possible speed and auto-negotiation combinations for a line between two 10/100/1000 Base-T Ethernet interfaces.

Table 14-4. Auto-negotiation and Link Speed Combinations

Port 0	Port 1	Link Status between Port 1 and Port 2
auto-negotiation enabled* speed 1000 or auto	auto-negotiation enabled* speed 1000 or auto	Up at 1000 Mb/s
auto-negotiation enabled speed 100	auto-negotiation enabled speed 100	Up at 100 Mb/s
auto-negotiation disabled speed 100	auto-negotiation disabled speed 100	Up at 100 Mb/s
auto-negotiation disabled speed 100	auto-negotiation enabled speed 100	Down

Table 14-4. Auto-negotiation and Link Speed Combinations

Port 0	Port 1	Link Status between Port 1 and Port 2
auto-negotiation enabled* speed 1000 or auto	auto-negotiation disabled speed 100	Down

^{*} You cannot disable auto-negotiation when the speed is set to 1000 or auto.

Related Commands

speed (for 10/100/1000 interfaces) Set the link speed to 10, 100, 1000 or auto-negotiate the speed.

portmode hybrid



Set a physical port or port-channel to accept both tagged and untagged frames. A port configured this way is identified as a hybrid port in report displays.

Syntax portmode hybrid

To return a port to accept either tagged or untagged frames (non-hybrid), use the **no portmode** hybrid command.

Defaults

non-hybrid

Command Modes

INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on E-Series and S-Series
Version 7.5.1.0	Introduced on C-Series only

Example

Figure 14-22. portmode hybrid configuration example

```
FTOS(conf)#interface gi 7/0
FTOS (conf-if-gi-7/0) #portmode hybrid
FTOS (conf-if-gi-7/0) #interface vlan 10
FTOS(conf-if-vl-10) #untagged gi 7/0
FTOS(conf-if-vl-10)#interface vlan 20
FTOS(conf-if-vl-20)#tagged gi 7/0
FTOS(conf-if-v1-20)#
```

Usage Information

The figure above sets a port as hybrid, makes the port a tagged member of VLAN 20, and an untagged member of VLAN 10, which becomes the native VLAN of the port. The port will now accept:

- untagged frames and classify them as VLAN 10 frames
- VLAN 20 tagged frames

The next figure is an example show output with "Hybrid" as the newly added value for 802.1QTagged. The options for this field are:

- True—port is tagged
- False—port is untagged
- Hybrid—port accepts both tagged and untagged frames

Example

Figure 14-23. Display the Tagged Hybrid Interface

```
FTOS(conf-if-v1-20)#do show interfaces switchport
Name: GigabitEthernet 7/0
802.1QTagged: Hybrid
Vlan membership:
Vlan 10, Vlan 20
Native VlanId: 10
FTOS(conf-if-v1-20)#
```

The figure below is an example unconfiguration of the hybrid port using the **no portmode hybrid** command.



Note: You must remove all other configurations on the port before you can remove the hybrid configuration from the port.

Example

Figure 14-24. Unconfigure the hybrid port

```
FTOS (conf-if-vl-20) #interface vlan 10
FTOS (conf-if-vl-10) #no untagged gi 7/0
FTOS (conf-if-vl-10) #interface vlan 20
FTOS (conf-if-vl-20) #no tagged gi 7/0
FTOS (conf-if-vl-20) #interface gi 7/0
FTOS (conf-if-vl-20) #no portmode hybrid
FTOS (conf-if-vl-20) #
```

Related Commands

show interfaces switchport	Display the configuration of switchport (Layer 2) interfaces on the switch.	
switchport	Place the interface in a Layer 2 mode.	
vlan-stack trunk	Specify an interface as a trunk port to the Stackable VLAN network.	

rate-interval

CES

Configure the traffic sampling interval on the selected interface.

Syntax

rate-interval seconds

Parameters

seconds	Enter the number of seconds for which to collect traffic data.	
	Range: 30 to 299 seconds	
	Note: Since polling occurs every 15 seconds, the number of seconds designated here will round to the multiple of 15 seconds lower than the entered value. For example, if 44 seconds is designated it will round to 30; 45 to 59 seconds will round to 45, and so forth.	

Defaults

299 seconds

Command Modes

INTERFACE

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced

Usage Information

The configured rate interval is displayed, along with the collected traffic data, in the output of **show** interfaces commands.

Related **Commands**

show interfaces Display information on physical and virtual interfaces.

show config

Display the interface configuration.

Syntax

show config

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Example

Figure 14-25. show config Command Example for the INTERFACE Mode

```
FTOS(conf-if) #show conf
interface GigabitEthernet 1/7
no ip address
switchport
no shutdown
FTOS (conf-if)#
```

show config (from INTERFACE RANGE mode)

CES

Display the bulk configured interfaces (interface range).

Syntax

show config

Command Modes

CONFIGURATION INTERFACE (conf-if-range)

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced on E-Series

Example

Figure 14-26. show config (Bulk Configuration) Command Example

```
FTOS(conf)#interface range gigabitethernet 1/1 - 2
FTOS(conf-if-range-gi-1/1-2)#show config
!
interface GigabitEthernet 1/1
no ip address
switchport
no shutdown
!
interface GigabitEthernet 1/2
no ip address
switchport
no shutdown
FTOS(conf-if-range-gi-1/1-2)#
```

show interfaces

CES

Display information on a specific physical interface or virtual interface.

Syntax

show interfaces interface

Parameters

interface

Enter one of the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383.
- For the management interface on an RPM, enter the keyword **ManagementEthernet** followed by the slot/port information. The slot range is 0-1 and the port range is 0.
- For a Null interface, enter the keywords null 0.
- For a port channel interface, enter the keyword **port-channel** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale and ExaScale

- For a SONET interface, enter the keyword **sonet** followed by the slot/port.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For a VLAN interface, enter the keyword vlan followed by a number from 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60. SFP and SFP+ optics power detail is included the S60.
Version 8.2.1.2	Include SFP and SFP+ optics power detail in E-Series and C-Series output.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior releases supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Output expanded to include SFP+ media in C-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Version 6.4.1.0	Changed organization of display output
Version 6.3.1.0	Added Pluggable Media Type field in E-Series TeraScale output

Usage

Use this **show interfaces** command for details on a specific interface. Use the **show interfaces linecard** command for details on all interfaces on the designated line card.

Example Figure 14-27. show interfaces Command Example for 10G Port (E-Series)

```
FTOS#show interfaces tengigabitethernet 2/0
TenGigabitEthernet 2/0 is up, line protocol is up
Hardware is Force10Eth, address is 00:01:e8:05:f7:3a
Interface index is 100990998
Internet address is 213.121.22.45/28
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 10000 Mbit
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interfaces" counters 02:31:45
Queueing strategy: fifo
Input Statistics:
      0 packets, 0 bytes
Input 0 IP Packets, 0 Vlans 0 MPLS
      O 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 symbol errors, 0 runts, 0 giants, 0 throttles
0 CRC, 0 IP Checksum, 0 overrun, 0 discarded
Output Statistics:
       1 packets, 64 bytes, 0 underruns
      0 Multicasts, 2 Broadcasts, 0 Unicasts
0 IP Packets, 0 Vlans, 0 MPLS
0 throttles, 0 discarded
Rate info (interval 299 seconds):
      Input 00.00 Mbits/sec,
                                                 0 packets/sec, 0.00% of line-rate
       Output 00.00 Mbits/sec,
                                                 0 packets/sec, 0.00% of line-rate
Time since last interface status change: 00:00:27
```

Table 14-5. Lines in show interfaces Command Example

Line	Description
TenGigabitEthernet 2/0	Displays the interface's type, slot/port, and administrative and line protocol status.
Hardware is	Displays the interface's hardware information and its assigned MAC address.
Interface index	Displays the interface index number used by SNMP to identify the interface.
Internet address	States whether an IP address is assigned to the interface. If one is, that address is displayed.
MTU 1554	Displays link and IP MTU information. If the chassis is in Jumbo mode, this number can range from 576 to 9252.
LineSpeed	Displays the interface's line speed.
ARP type:	Displays the ARP type and the ARP timeout value for the interface.
Last clearing	Displays the time when the show interfaces counters where cleared.
Queuing strategy	States the packet queuing strategy. FIFO means first in first out.

Table 14-5. Lines in show interfaces Command Example (continued)

Line	Description
Input Statistics:	Displays all the input statistics including: Number of packets and bytes into the interface Number of packets with IP headers, VLAN tagged headers and MPLS headers Note: The sum of the number of packets may not be as expected since a VLAN tagged IP packet counts as both a VLAN packet and an IP packet. Packet size and the number of those packets inbound to the interface
	 Number of symbol errors, runts, giants, and throttles packets: runts = number of packets that are less than 64B giants = packets that are greater than the MTU size throttles = packets containing PAUSE frames Number of CRC, IP Checksum, overrun, and discarded packets: CRC = packets with CRC/FCS errors IP Checksum = packets with IP Checksum errors overrun = number of packets discarded due to FIFO overrun conditions discarded = the sum of input symbol errors, runts, giants, CRC, IP Checksum, and overrun packets discarded without any processing
Output Statistics:	 Displays output statistics sent out of the interface including: Number of packets, bytes and underruns out of the interface packets = total number of packets bytes = total number of bytes underruns = number of packets with FIFO underrun conditions Number of Multicast, Broadcast and Unicast packets: Multicasts = number of MAC multicast packets Broadcasts = number of MAC broadcast packets Unicasts = number of MAC unicast packets Number of IP, VLAN and MPLs packets: IP Packets = number of IP packets Vlans = number of VLAN tagged packets MPLS = number of MPLS packets (found on a LSR interface) Number of throttles and discards packets: throttles = packets containing PAUSE frames discarded = number of packets discarded without any processing
Rate information	Estimate of the input and output traffic rate over a designated interval (30 to 299 seconds). Traffic rate is displayed in bits, packets per second, and percent of line rate.
Time since	Elapsed time since the last interface status change (hh:mm:ss format).

Figure 14-28. show interfaces Command Example for 10G (TeraScale) Example

```
FTOS#show interfaces tengigabitethernet 0/0
TenGigabitEthernet 3/0 is up, line protocol is up
Hardware is Force10Eth, address is 00:01:e8:41:77:c5
    Current address is 00:01:e8:41:77:c5
Pluggable media present, XFP type is 10GBASE-SR
Medium is MultiRate, Wavelength is 850.00nm
XFP receive power reading is -2.4834
Interface index is 134545468
Port will not be disabled on partial SFM failure MTU 9252 bytes, IP MTU 9234 bytes
LineSpeed 10000 Mbit
Flowcontrol rx on tx on ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 00:15:14
Queueing strategy: fifo
Input Statistics:
     4410013700 packets, 282240876800 bytes
      0 Vlans
      4410013700\ 64\text{-byte pkts},\ 0 over 64\text{-byte pkts},\ 0 over 127-byte pkts
      0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 0 Broadcasts
     0 runts, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
      857732 packets, 54894848 bytes, 0 underruns
      857732 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
      0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
      24 Multicasts, 0 Broadcasts, 857708 Unicasts
      0 Vlans, 0 throttles, 0 discarded, 0 collisions, 4409143619 wredDrops
Rate info (interval 30 seconds):
      Input 00.00 Mbits/sec,
                                            0 packets/sec, 0.00% of line-rate
      Output 00.00 Mbits/sec,
                                            0 packets/sec, 0.00% of line-rate
Time since last interface status change: 00:12:14
FTOS#
```

Table 14-6. Fields in show interfaces Command Example (TeraScale)

Line	Description
TenGigabitEthernet 0/0	Interface type, slot/port and administrative and line protocol status.
Hardware is	Interface hardware information, assigned MAC address, and current address.
Pluggable media present	 Present pluggable media wavelength, type, and rate. The error scenarios are: Wavelength, Non-qualified — FTOS ID is not present, but wavelength information is available from XFP or SFP serial data Wavelength, F10 unknown— FTOS ID is present, but not able to determine the optics type Unknown, Non-qualified— if wavelength is reading error, and F10 ID is not present Dell Networking allows unsupported SFP and XFP transceivers to be used, but FTOS might not be able to retrieve some data about them. In that case, typically when the output of this field is "Pluggable media present, Media type is unknown", the Medium and the XFP/SFP receive power reading data might not be present in the output.
Interface index	Displays the interface index number used by SNMP to identify the interface.
Internet address	States whether an IP address is assigned to the interface. If one is, that address is displayed.
MTU 1554	Displays link and IP MTU information.
LineSpeed	Displays the interface's line speed, duplex mode, and Slave
ARP type:	Displays the ARP type and the ARP timeout value for the interface.
Last clearing	Displays the time when the show interfaces counters where cleared.

Table 14-6. Fields in show interfaces Command Example (TeraScale)

Line	Description
Queuing strategy	States the packet queuing strategy. FIFO means first in first out.
Input Statistics:	Displays all the input statistics including: Number of packets and bytes into the interface Number of packets with VLAN tagged headers Packet size and the number of those packets inbound to the interface Number of Multicast and Broadcast packets: Multicasts = number of MAC multicast packets Broadcasts = number of MAC broadcast packets Number of runts, giants, and throttles packets: runts = number of packets that are less than 64B giants = packets that are greater than the MTU size throttles = packets containing PAUSE frames Number of CRC, overrun, and discarded packets: CRC = packets with CRC/FCS errors overrun = number of packets discarded due to FIFO overrun conditions discarded = the sum of runts, giants, CRC, and overrun packets discarded without any processing
Output Statistics:	 Displays output statistics sent out the interface including: Number of packets, bytes and underruns out of the interface Packet size and the number of those packets outbound to the interface Number of Multicast, Broadcast and Unicast packets:
Rate information	Estimate of the input and output traffic rate over a designated interval (30 to 299 seconds) Traffic rate is displayed in bits, packets per second, and percent of line rate.
Time since	Elapsed time since the last interface status change (hh:mm:ss format).

Figure 14-29. show interfaces Command Example for 1G SFP Interface Example

```
FTOS#show interfaces gigabitethernet 2/0
GigabitEthernet 2/0 is up, line protocol is down
Hardware is Force10Eth, address is 00:01:e8:41:77:95
    Current address is 00:01:e8:41:77:95
Pluggable media present, SFP type is 1000BASE-SX
    Wavelength is 850nm
Interface index is 100974648
Port will not be disabled on partial SFM failure
Internet address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit
Flowcontrol rx on tx on
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 1w0d5h
Queueing strategy: fifo
Input Statistics:
     0 packets, 0 bytes
     0 Vlans
     0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
     0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
     0 Multicasts, 0 Broadcasts
     0 runts, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
     0 packets, 0 bytes, 0 underruns
     0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
     0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
     0 Multicasts, 0 Broadcasts, 0 Unicasts
     0 Vlans, 0 throttles, 0 discarded, 0 collisions, 0 wreddrops
Rate info (interval 299 seconds):
     Input 00.00 Mbits/sec,
                                       0 packets/sec, 0.00% of line-rate
     Output 00.00 Mbits/sec,
                                       0 packets/sec, 0.00% of line-rate
Time since last interface status change: 1w0d5h
FTOS#
```

Example Figure 14-30. show interfaces Command Example for 10G SFP+ Interface in C-Series

```
FTOS#show interfaces tengigabitethernet 0/44
TenGigabitEthernet 0/44 is down, line protocol is down
Hardware is Force10Eth, address is 00:01:e8:32:44:26
    Current address is 00:01:e8:32:44:26
Pluggable media present, SFP+ type is 10GBASE-CU5M
   Medium is MultiRate
Interface index is 45417732
FTOS#
```

Usage Information

On the C-Series and S-Series, the interface counter "over 1023-byte pkts" does not increment for packets in the range 9216 > x < 1023.

Related **Commands**

show interfaces configured	Display any interface with a non-default configuration.
show interfaces linecard	Display information on all interfaces on a specific line card.
show interfaces phy	
show interfaces rate	Display information of either rate limiting or rate policing on the interface.
show interfaces switchport	Display Layer 2 information about the interfaces.
show inventory (C-Series and E-Series)	Display the chassis type, components (including media), FTOS version including hardware identification numbers and configured protocols.
show inventory (S-Series)	Display the S-Series switch type, components (including media), FTOS version including hardware identification numbers and configured protocols.
show ip interface	Display Layer 3 information about the interfaces.

show linecard	Display the line card(s) status.
show range	Display all interfaces configured using the interface range command.

show interfaces configured

CES

Display any interface with a non-default configuration.

Syntax

show interfaces configured

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.1.0	Changed organization of display output

Example

Figure 14-31. show interfaces configured Command Output

```
FTOS#show interfaces configured
GigabitEthernet 13/18 is up, line protocol is up
Hardware is Force10Eth, address is 00:01:e8:05:f7:fc
     Current address is 00:01:e8:05:f7:fc
Interface index is 474791997
Internet address is 1.1.1.1/24
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit, Mode full duplex, Master ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interfaces" counters 00:12:42
Queueing strategy: fifo
Input Statistics:
     10 packets, 10000 bytes 0 Vlans
      0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
      0 over 255-byte pkts, 10 over 511-byte pkts, 0 over 1023-byte pkts
     0 Multicasts, 0 Broadcasts
0 runts, 0 giants, 0 throttles
     0 CRC, 0 overrun, 0 discarded
Output Statistics:
      1 packets, 64 bytes, 0 underruns
     1 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
0 Multicasts, 1 Broadcasts, 0 Unicasts
      0 Vlans, 0 throttles, 0 discarded, 0 collisions
Rate info (interval 299 seconds):
                                            0 packets/sec, 0.00% of line-rate
      Input 00.00 Mbits/sec,
                                            0 packets/sec, 0.00% of line-rate
     Output 00.00 Mbits/sec,
Time since last interface status change: 00:04:59
FTOS#
```

Related Commands

show interfaces

Display information on a specific physical interface or virtual interface.

show interfaces dampening

CES

Display interface dampening information.

Syntax

show interfaces dampening [[interface] [summary] [detail]]

Parameters

interface	(Optional) Enter one of the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a port channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	• E-Series Range: 1 to 255 for TeraScale and ExaScale
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
summary	(OPTIONAL) Enter the keyword summary to display the current summary of dampening data, including the number of interfaces configured and the number of interfaces suppressed, if any.
detail	(OPTIONAL) Enter the keyword detail to display detailed interface dampening data.

Defaults

No default values or behavior

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced

Example

Figure 14-32. show interfaces dampening Command Example

FTOS#show in	nterfaces	dampening					
Interface	Supp State	Flaps	Penalty	Half-Life	Reuse	Suppress	Max-Sup
Gi 3/2	Uр	0	0	20	800	4500	120
Gi 3/10	Ūр	0	0	5	750	2500	20
FTOS#							

Related Commands

dampening	Configure dampening on an interface
show interfaces	Display information on a specific physical interface or virtual interface.
show interfaces configured	Display any interface with a non-default configuration.

show interfaces debounce

[E] Display information on interfaces with debounce timer configured.

Syntax

show interfaces debounce interface

Parameters

Enter one of the following keywords and slot/port or number information:
For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

interface

Command History

Related Commands

Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on E-Series
show interfaces	Display information on a specific physical interface or virtual interface.

show interfaces description

CES

Display the descriptions configured on the interface.

Syntax

show interfaces [interface] description

Parameters

interface

Enter one of the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword loopback followed by a number from 0 to 16383.
- For the management interface on the RPM, enter the keyword **ManagementEthernet** followed by the slot/port information. The slot range is 0-1 and the port range is 0.
- For the Null interface, enter the keywords null 0.
- For a port channel interface, enter the keyword **port-channel** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale and ExaScale

- For SONET interfaces, enter the keyword **sonet** followed by the slot/port.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For VLAN interfaces, enter the keyword **vlan** followed by a number from 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale. Prior releases supported 2094.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 14-33. show interfaces description Command Example

```
FTOS>
Interface
                                       Protocol
                        OK? Status
                                                    Description
                                                    ***connected-to-host***
GigabitEthernet 4/17
                        NO admin down down
                            admin down down
                                                    ***connected-to-Tom***
GigabitEthernet 4/18
                        NO
                            admin down down
                                                    ***connected-to-marketing***
GigabitEthernet 4/19
                        NO
                                                    ***connected-to-Bill***
GigabitEthernet 4/20
                        NO admin down down
GigabitEthernet 4/21
                                      down
                                                  ***connected-to-Radius-Server***
                       NO up
                        NO admin down down
                                                   ***connected-to-Web-Server***
GigabitEthernet 4/22
                                                    ***connected-to-PC-client***
                            admin down down
GigabitEthernet 4/23
                        NO
TenGigabitEthernet 6/0
                            admin down down
                        NO
GigabitEthernet 8/0
                        YES up
                                       up
GigabitEthernet 8/1
                        YES up
                                       up
GigabitEthernet 8/2
                        YES up
                                       иp
GigabitEthernet 8/3
                        YES up
                                       up
GigabitEthernet 8/4
                        YES up
                                       up
GigabitEthernet 8/5
                        YES up
                                       up
GigabitEthernet 8/6
                        YES up
                                       up
GigabitEthernet 8/7
                        YES up
                                       up
GigabitEthernet 8/8
                        YES up
                                       up
GigabitEthernet 8/9
                        YES up
                                       up
GigabitEthernet 8/10
                        YES up
                                       up
GigabitEthernet 8/11
                        YES up
                                       up
FTOS>
```

Table 14-7. show interfaces description Command Example Fields

Field	Description
Interface	Displays type of interface and associated slot and port number.
OK?	Indicates if the hardware is functioning properly.
Status	States whether the interface is enabled (up) or disabled (administratively down).
Protocol	States whether IP is enabled (up) or disabled (down) on the interface.
Description	Displays the description (if any) manually configured for the interface.

Related **Commands**

show interfaces	Display information on a specific physical interface or virtual interface.

show interfaces linecard

© E Display information on all interfaces on a specific line card.

Syntax show interfaces linecard slot-number

Parameters

slot-number	Enter a number for the line card slot.
	C-Series Range: 0-7 for C300; 0-3 for C150
	E-Series Range: 0 to 13 on the E1200/1200i, 0 to 6 on the E600/600i, 0 to 5 on the E300

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.2	Introduced support on E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage

Figure 14-34 shows a line card that has an XFP interface. The type, medium, wavelength, and receive power details are displayed. When a device that is not certified by Dell Networking is inserted, it might work, but its details might not be readable by FTOS and not displayed here.

Example

Figure 14-34. show interfaces linecard Command Example (in C150)

```
FTOS#show interfaces linecard 0
TenGigabitEthernet 0/0 is down, line protocol is down
Hardware is Force10Eth, address is 00:01:e8:51:b2:d4
    Current address is 00:01:e8:51:b2:d4
Pluggable media present, XFP type is 10GBASE-SR
Medium is MultiRate, Wavelength is 850.00nm
XFP receive power reading is -2.3538 Interface index is 33883138
Internet address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 10000 Mbit
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 20:16:29
Queueing strategy: fifo
Input Statistics:
      0 packets, 0 bytes
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
      0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
      0 Multicasts, 0 Broadcasts
      0 runts, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
      0 packets, 0 bytes, 0 underruns
      0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
--More--
```

Related Commands

show interfaces	Display information on a specific physical interface or virtual interface.

show interfaces phy

CES Display auto-negotiation and link partner information.

Syntax show interfaces gigabitethernet slot/port phy

Parameters

gigabitethernet Enter the keyword **gigabitethernet** followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 6.5.4.0	Introduced on E-Series

Example

Figure 14-35. show interfaces gigabitethernet phy Command Example (Partial)

```
FTOS#show int gigabitethernet 1/0 phy
Mode Control:
   SpeedSelection:
   AutoNeg:
   Loopback:
                                   False
                                   False
   PowerDown:
                                   False
   Isolate:
   DuplexMode:
                                   Full
Mode Status:
   AutoNegComplete:
                                   False
   RemoteFault:
                                   False
   LinkStatus:
                                   False
   JabberDetect:
                                   False
AutoNegotation Advertise: 100MegFullDplx:
                                   True
   100MegHalfDplx:
10MegFullDplx:
                                   True
                                   False
   10MegHalfDplx:
                                   True
   Asym Pause:
                                   False
   Sym Pause:
                                   False
AutoNegotiation Remote Partner's Ability:
   100MegFullDplx:
                                   False
   100MegHalfDplx:
                                   False
   10MegFullDplx:
                                   False
   10MegHalfDplx:
                                   False
   Asym Pause:
                                   False
   Sym Pause:
                                   False
AutoNegotiation Expansion:
   ParallelDetectionFault:
                                   False
```

Table 14-8. Lines in show interfaces gigabitethernet Command Example

Line	Description
Mode Control	Indicates if auto negotiation is enabled. If so, indicates the selected speed and duplex.
Mode Status	Displays auto negotiation fault information. When the interface completes auto negotiation successfully, the autoNegComplete field and the linkstatus field read "True."
AutoNegotiation Advertise	Displays the control words advertised by the local interface during negotiation. Duplex is either half or full. Asym- and Sym Pause is the types of flow control supported by the local interface.

Table 14-8. Lines in show interfaces gigabitethernet Command Example

Line	Description	
AutoNegotiation Remote Partner's Ability	Displays the control words advertised by the remote interface during negotiation. Duplex is either half or full. Asym- and Sym Pause is the types of flow control supported by the remote interface	
AutoNegotiation Expansion	ParallelDetectionFault is the handshaking scheme in which the link partner continuously transmit an "idle" data packet using the Fast Ethernet MLT-3 waveform. Equipment that does not support auto-negotiation must be configured to exactly match the mode of operation as the link partner or else no link can be established.	
1000Base-T Control	1000Base-T requires auto-negotiation. The IEEE Ethernet standard does not support setting a speed to 1000 Mbps with the speed command without auto-negotiation. E-Series line cards support both full-duplex and half-duplex 1000BaseT.	
Phy Specific Control	Values are:	
	0 - Manual MDI	
	1 - Manual MDIX	
	2 - N/A	
	3 - Auto MDI/MDIX	
Phy Specific Status	Displays PHY-specific status information. Cable length represents a rough estimate in meters:	
	0 - < 50 meters	
	1 - 50 - 80 meters	
	2 - 80 - 110 meters	
	3 - 110 - 140 meters	
	4 - 140 meters.	
	Link Status:	
	Up or Down	
	Speed:	
	Auto	
	1000MB	
	100MB	
	10MB	

Related Commands

1	D: 1 : 6 .: 'C 1 : 1: 4 6 .: 4 1: 4 6
show interfaces	Display information on a specific physical interface or virtual interface.

show interfaces stack-unit

S Display information on all interfaces on a specific S-Series stack member.

Syntax show interfaces stack-unit unit-number

Parameters

unit-number	Enter the stack member number
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced for S-Series only

Example

Figure 14-36. show interfaces status Command Example

```
FTOS#show interfaces stack-unit 0
GigabitEthernet 0/1 is down, line protocol is down
Hardware is Force10Eth, address is 00:01:e8:4c:f2:82
    Current address is 00:01:e8:4c:f2:82
Pluggable media not present
Interface index is 34129154
Internet address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed auto, Mode auto
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 3w0d17h
Queueing strategy: fifo
Input Statistics:
      0 packets, 0 bytes
      5144 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
      0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
      0 Multicasts, 0 Broadcasts
      0 runts, 0 giants, 0 throttles
0 CRC, 0 overrun, 0 discarded
Output Statistics:
      0 packets, 0 bytes, 0 underruns
0 64-byte pkts, 0 over 64-byte pkts, 0 over 127-byte pkts
0 over 255-byte pkts, 0 over 511-byte pkts, 0 over 1023-byte pkts
      0 Multicasts, 0 Broadcasts, 0 Unicasts 0 throttles, 0 discarded, 0 collisions
Rate info (interval 299 seconds):
                                            0 packets/sec, 0.00% of line-rate 0 packets/sec, 0.00% of line-rate
      Input 00.00 Mbits/sec,
      Output 00.00 Mbits/sec,
Time since last interface status change: 3w0d17h
GigabitEthernet 0/2 is down, line protocol is down
Hardware is Force10Eth, address is 00:01:e8:4c:f2:83
Current address is 00:01:e8:4c:f2:83
!-----!
```

Related Commands

show hardware stack-unit	Display data plane and management plane input/output statistics.
show interfaces	Display information on a specific physical interface or virtual interface.

show interfaces status

CES

Display a summary of interface information or specify a line card slot and interface to display status information on that specific interface only.

Syntax

show interfaces [interface | linecard slot-number] status

Parameters

interface	(OPTIONAL) Enter one of the following keywords and slot/port or number information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
linecard slot-number	(OPTIONAL) Enter the keyword linecard followed by the slot number.	
	C-Series Range: 0 to 7 for C300; 0–3 for C150	
	E-Series Range: 0 to 13 on the E1200, 0 to 6 on the E600, 0 to 5 on the E300	

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.5.1.0	Introduced on E-Series

Example

Figure 14-37. show interfaces status Command Example

Port	w interfaces Description		Speed	Duplex	Vlan
Gi 0/0	<u> </u>	qU	1000 Mbit		
Gi 0/1		Down	Auto	Auto	1
Gi 0/2		Down	Auto	Auto	1
Gi 0/3		Down	Auto	Auto	
Gi 0/4	Force10Port	Up	1000 Mbit	Auto	30-130
Gi 0/5		Down	Auto	Auto	
Gi 0/6		Down	Auto	Auto	
Gi 0/7		Up	1000 Mbit	Auto	1502,1504,1506-1508,1602
Gi 0/8		Down	Auto	Auto	
Gi 0/9		Down	Auto	Auto	
Gi 0/10		Down	Auto	Auto	
Gi 0/11		Down	Auto	Auto	
Gi 0/12		Down	Auto	Auto	
Gi 0/13		Down	Auto	Auto	
Gi 0/14		Down	Auto	Auto	
Gi 0/15		Down	Auto	Auto	
FTOS#					

Related Commands

show interfaces Display information on a specific physical interface or virtual interface.

show interfaces switchport

CES

Display only virtual and physical interfaces in Layer 2 mode. This command displays the Layer 2 mode interfaces' IEEE 802.1Q tag status and VLAN membership.

Syntax

show interfaces switchport [interface [linecard slot-number] | **stack-unit** unit-id]

Parameters

interface	Enter one of the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a port channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale
	 For SONET interfaces, enter the keyword sonet followed by the slot/port information. This keyword is only available on E-Series and C-Series.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• Enter the keyword backup to view the backup interface for this interface.
linecard slot-number	(OPTIONAL) Enter the keyword linecard followed by the slot number. This option is available only on E-Series and C-Series.
310t-Harriber	C-Series Range: 0-7 for C300; 0–3 for C150
	E-Series Range: 0 to 13 on the E1200, 0 to 6 on the E600, 0 to 5 on the E300
stack-unit	(OPTIONAL) Enter the keyword stack-unit followed by the stack member number.
unit-id	This option is available only on S-Series.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.6.1.0	Support added for hybrid port/native VLAN, introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
E-Series legacy command		

Example

Figure 14-38. show interfaces switchport Command Example

```
FTOS#show interfaces switchport
Name: GigabitEthernet 13/0
802.1QTagged: Hybrid
Vlan membership:
Vlan 2, Vlan
Native VlanId: 20
                      20
Name: GigabitEthernet 13/1 802.1QTagged: True
Vlan membership:
Vlan
Name: GigabitEthernet 13/2 802.1QTagged: True
Vlan membership:
Vlan
Name: GigabitEthernet 13/3
802.1QTagged: True
Vlan membership:
Vlan
--More--
```

Table 14-9. Items in show interfaces switchport Command Example

Items	Description
Name	Displays the interface's type, slot and port number.
802.1QTagged	Displays whether if the VLAN tagged ("True"), untagged ("False"), or hybrid ("Hybrid", which supports both untagged and tagged VLANs by port 13/0.
Vlan membership	Lists the VLANs to which the interface is a member. Starting with FTOS 7.6.1, this field can display native VLAN membership by port 13/0.

Related Commands

interface	Configure a physical interface on the switch.	
show ip interface	Displays Layer 3 information about the interfaces.	
show interfaces	Display information on a specific physical interface or virtual interface.	
show interfaces transceiver	Display the physical status and operational status of an installed transceiver. The output also displays the transceiver's serial number.	

show interfaces transceiver



Display the physical status and operational status of an installed transceiver. The output also displays the transceiver's serial number.

Syntax

show interfaces [gigabitethernet | tengigabitethernet] slot/port transceiver

Parameters

gigabitethernet	For a 10/100/1000 interface, enter the keyword gigabitethernet followed by the slot/port information.
tengigabitethernet	For a 10G interface, enter the keyword tengigabitethernet followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Output augmented with diagnostic data for pluggable media
Version 7.7.1.0	Removed three fields in output: Vendor Name, Vendor OUI, Vendor PN
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 6.5.4.0	Introduced on E-Series

Usage

See the figure below for an example screenshot, and see the following table or a description of the output fields.

For related commands, see the Related Commands section, below, and see the Debugging and Diagnostics chapter for your platform at the end of this book.

Example Figure 14-39. show interfaces gigabitethernet transceiver Command Example

```
FTOS#show interfaces gigabitethernet 1/0 transceiver
SFP is present.
SFP 0 Serial Base ID fields
SFP 0 Ld = 0x03

SFP 0 Ext Id = 0x04

SFP 0 Connector = 0x07
SFP 0 Vendor Rev = A
SFP 0 Laser Wavelength = 850 nm - 0x66
SFP 0 CheckCodeBase = 0x
SFP 0 Serial Extended ID fields
                             = 0x66
SFP 0 Options= 0x00 0x12
SFP 0 BR max= 0
SFP 0 BR min= 0
SFP 0 Vendor SN= P5N1ACE
SFP 0 Datecode
                            = 040528
SFP 0 CheckCodeExt
                           = 0x5b
SFP 1 Diagnostic Information
SFP 1 Rx Power measurement type
                                          = Average
_____
SFP 1 Temp High Alarm threshold
                                          = 95.000C
SFP 1 Voltage High Alarm threshold = 3.900V
SFP 1 Bias High Alarm threshold = 17.000m
SFP 1 TX Power High Alarm threshold = 0.631mW
                                          = 17.000mA
SFP 1 RX Power High Alarm threshold = 1.259mW
SFP 1 Temp Low Alarm threshold = -25.000C
SFP 1 Voltage Low Alarm threshold = 2.700V
                                         = 2.700V
= 1.000mA
SFP 1 Bias Low Alarm threshold
                                         = 0.067mW
= 0.010mW
SFP 1 TX Power Low Alarm threshold
SFP 1 RX Power Low Alarm threshold
SFP 1 Temp High Warning threshold = 90.000C
SFP 1 Voltage High Warning threshold = 3.700V
SFP 1 Bias High Warning threshold
                                          = 14.000 mA
SFP 1 TX Power High Warning threshold = 0.631mW
SFP 1 RX Power High Warning threshold = 0.794mW
                                       = -20.000C
= 2.900V
SFP 1 Temp Low Warning threshold
SFP 1 Voltage Low Warning threshold
SFP 1 Bias Low Warning threshold = 2.000mA
SFP 1 TX Power Low Warning threshold = 0.079mW
SFP 1 RX Power Low Warning threshold = 0.016mW
_____
SFP 1 Temperature
                                          = 39.930C
SFP 1 Voltage
                                          = 3.293V
SFP 1 Tx Bias Current
                                          = 6.894 \text{mA}
SFP 1 Tx Power
                                          = 0.328mW
SFP 1 Rx Power
                                          = 0.000mW
_____
SFP 1 Data Ready state Bar
                                          = False
                                          = True
SFP 1 Tx Fault state
SFP 1 Rx LOS state
                                          = False
SFP 1 Rate Select state
                                          = False
SFP 1 RS state
                                          = False
                                          = False
SFP 1 Tx Disable state
SFP 1 Temperature High Alarm Flag = False
-----
SFP 1 Voltage High Alarm Flag
SFP 1 Tx Bias High Alarm Flag
                                         = False
= False
SFP 1 Tx Power High Alarm Flag
SFP 1 Tx Power High Alarm Flag
SFP 1 Temperature Low Alarm Flag
SFP 1 Voltage Low Alarm Flag
SFP 1 Tx Bias Low Alarm Flag
                                         = False
= False
                                         = False
= False
SFP 1 Tx Bias Low Alarm Flag
SFP 1 Tx Power Low Alarm Flag
                                         = False
SFP 1 Rx Power Low Alarm Flag
                                          = True
!-----!
```

Table 14-10. Diagnostic Data in show interfaces transceiver

Line	Description
Rx Power measurement type	Output depends on the vendor, typically either "Average" or "OMA" (Receiver optical modulation amplitude).
Temp High Alarm threshold	Factory-defined setting, typically in Centigrade. Value differs between SFPs and SFP+.
Voltage High Alarm threshold	Displays the interface index number used by SNMP to identify the interface.
Bias High Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
TX Power High Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
RX Power High Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Temp Low Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Voltage Low Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Bias Low Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
TX Power Low Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
RX Power Low Alarm threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Temp High Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Voltage High Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Bias High Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
TX Power High Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
RX Power High Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Temp Low Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Voltage Low Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Bias Low Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
TX Power Low Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Power Low Warning threshold	Factory-defined setting. Value can differ between SFP and SFP+.
Temperature	Current temperature of the sfps.If this temperature crosses Temp High alarm/warning thresholds, then the temperature high alarm/warning flag is set to true.
Voltage	Current voltage of the sfps.If this voltage crosses voltage high alarm/warning thresholds, then the voltage high alarm/warning flag is set to true.
Tx Bias Current	Present Tx bias current of the SFP. If this crosses bias high alarm/warning thresholds, then the tx bias high alarm/warning flag is set to true. If it falls below the low alarm/warning thresholds, then the tx bias low alarm/warning flag is set to true.

Table 14-10. Diagnostic Data in show interfaces transceiver (continued)

Description
Present Tx power of the SFP. If this crosses Tx power alarm/warning thresholds, then the Tx power high alarm/warning flag is set to true. If it falls below the low alarm/warning thresholds, then the Tx power low alarm/warning flag is set to true.
Present Rx power of the SFP. This value is either average Rx power or OMA. This depends upon on the Rx Power measurement type displayed above. If this crosses Rx power alarm/warning thresholds, then the Rx power high alarm/warning flag is set to true. If it falls below the low alarm/warning thresholds, then the Rx power low alarm/warning flag is set to true.
This field indicates that the transceiver has achieved power up and data is ready. This is set to true if data is ready to be sent, false if data is being transmitted.
This is the digital state of the Rx_LOS output pin. This is set to true if the operating status is down.
This is the digital state of the Tx Fault output pin.
This is the digital state of the SFP rate_select input pin.
This is the reserved digital state of the pin AS(1) per SFF-8079 and RS(1) per SFF-8431.
If the admin status of the port is down then this flag will be set to true.
This can be either true/False and it depends on the Current Temperature value displayed above.
This can be either true or false, depending on the Current voltage value displayed above.
This can be either true or false, depending on the present Tx bias current value displayed above.
This can be either true or false, depending on the Current Tx power value displayed above.
This can be either true or false, depending on the Current Rx power value displayed above.
This can be either true or false, depending on the Current Temperature value displayed above.
This can be either true or false, depending on the Current voltage value displayed above.
This can be either true or false, depending on the Tx bias current value displayed above.
This can be either true or false, depending on the Current Tx power value displayed above.
This can be either true or false, depending on the Current Rx power value displayed above.
This can be either true or false, depending on the Current Temperature value displayed above.
This can be either true or false, depending on the Current voltage value displayed above.
This can be either true or false, depending on the Tx bias current value displayed above.

Table 14-10. Diagnostic Data in show interfaces transceiver (continued)

Line	Description
Tx Power High Warning Flag	This can be either true or false, depending on the Current Tx power value displayed above.
Rx Power High Warning Flag	This can be either true or false, depending on the Current Tx power value displayed above.
Temperature Low Warning Flag	This can be either true or false, depending on the Current Temperature value displayed above.
Voltage Low Warning Flag	This can be either true or false, depending on the Current voltage value displayed above.
Tx Bias Low Warning Flag	This can be either true or false, depending on the present Tx bias current value displayed above.
Tx Power Low Warning Flag	This can be either true or false, depending on the Current Tx power value displayed above.
Rx Power Low Warning Flag	This can be either true or false, depending on the Current Rx power value displayed above.

Related Commands

interface	Configure a physical interface on the switch.
show ip interface	Displays Layer 3 information about the interfaces.
show interfaces	Display information on a specific physical interface or virtual interface.
show inventory (C-Series and E-Series)	Display the chassis type, components (including media), FTOS version including hardware identification numbers and configured protocols.
show inventory (S-Series)	Display the S-Series switch type, components (including media), FTOS version including hardware identification numbers and configured protocols.

show range

CES

Display all interfaces configured using the interface range command.

Syntax

show range

Command Mode

INTERFACE RANGE (config-if-range)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support for 4093 VLANs on E-Series ExaScale
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.1.1.0	Introduced

Example

Figure 14-40. show range Command Example

```
FTOS(conf-if-range-so-2/0-1,fa-0/0)#show range interface sonet 2/0 - 1
interface fastethernet 0/0
FTOS(conf-if-range-so-2/0-1,fa-0/0)#
```

Related Commands

interface	Configure a physical interface on the switch.
show ip interface	Displays Layer 3 information about the interfaces.
show interfaces	Display information on a specific physical interface or virtual interface.

shutdown

CES

Disable an interface.

Syntax

shutdown

To activate an interface, enter **no shutdown**.

Defaults

The interface is disabled.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy command	

Usage Information

The shutdown command marks a physical interface as unavailable for traffic. To discover if an interface is disabled, use the show ip interface brief command. Disabled interfaces are listed as down.

Disabling a VLAN or a port channel causes different behavior. When a VLAN is disabled, the Layer 3 functions within that VLAN are disabled. Layer 2 traffic continues to flow. Entering the shutdown command on a port channel disables all traffic on the port channel and the individual interfaces within the port channel. To enable a port channel, you must enter no shutdown on the port channel interface and at least one interface within that port channel.

The shutdown and description commands are the only commands that you can configure on an interface that is a member of a port channel.

Related Commands

interface port-channel	Create a port channel interface.
interface vlan	Create a VLAN.
show ip interface	Displays the interface routing status. Add the keyword brief to display a table of interfaces and their status.

speed (for 10/100/1000 interfaces)

CES

Set the speed for 10/100/1000 Base-T Ethernet interfaces. Both sides of a link must be set to the same speed (10/100/1000) or to auto or the link may not come upSyntax

speed {10 | 100 | 1000 | auto}

To return to the default setting, use the **no speed** {10 | 100 | 1000} command.

Parameters

10	Enter the keyword 10 to set the interface's speed to 10 Mb/s. Note: This speed is not supported on the LC-EH-GE-50P or the LC-EJ-GE-50P card. If the command is entered for these interfaces, an error message appears.
100	Enter the keyword 100 to set the interface's speed to 10/100 Mb/s. Note: When this setting is enabled, only 100Base-FX optics are supported on the LC-EH-GE-50P or the LC-EJ-GE-50P card.
1000	Enter the keyword 1000 to set the interface's speed to 1000 Mb/s. (Auto-negotiation is enabled. See negotiation auto for more information) Note: When this setting is enabled, only 100oBase-FX optics are supported on the LC-EH-GE-50P or the LC-EJ-GE-50P card.
auto	Enter the keyword auto to set the interface to auto-negotiate its speed. (Auto-negotiation is enabled. See negotiation auto for more information)

Defaults

auto

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Supported on LC-EH-GE-50P or the LC-EJ-GE-50P cards
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy command	

Usage Information

This command is found on the 10/100/1000 Base-T Ethernet interfaces.

With speed 1000 configured on a copper interface, the speed is not auto-negotiated. The interface will operate only at 1000 Mbps.

With speed 100 configured on a copper interface, the speed is auto-negotiated. The interface will operate at 10 Mbps or at 100 Mbps.

When auto is enabled, the system performs and automatic discovery to determine the optics installed and configure the appropriate speed.

When you configure a speed for the 10/100/1000 interface, you should confirm negotiation auto command setting. Both sides of the link should have auto-negotiation either enabled or disabled. For speed settings of 1000 or auto, the software sets the link to auto-negotiation, and you cannot change that setting.



Note: Starting with FTOS 7.8.1.0, when a copper SFP2 module with catalog number GP-SFP2-1T is used in the S25P model of the S-Series, its speed can be manually set with the **speed** command. When the speed is set to 10 or 100 Mbps, the **duplex** command can also be executed.

Related Commands

duplex (10/100 Interfaces)	Configure duplex mode on physical interfaces with the speed set to 10/100.
negotiation auto	Enable or disable auto-negotiation on an interface.

speed (Management interface)

Set the speed for the Management interface.

Syntax speed {10 | 100 | auto}

To return to the default setting, use the **no speed** {10 | 100} command.

Parameters

10	Enter the keyword 10 to set the interface's speed to 10 Mb/s.	
100	Enter the keyword 100 to set the interface's speed to 100 Mb/s.	
auto	Enter the keyword auto to set the interface to auto-negotiate its speed.	

Defaults auto

Command Modes INTERFACE

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

This command is found on the Management interface only.

Related Commands

interface ManagementEthernet	Configure the Management port on the system (either the Primary or Standby RPM).
duplex (Management)	Set the mode of the Management interface.
management route	Configure a static route that points to the Management interface or a forwarding router.

stack-unit module

Pre-configure ports on 10G optical modules in optional slots to preserve configuration.

Syntax

stack-unit { stack-unit id} module { module id}

Parameters

stack-unit id	Enter the unit number of the stacked unit. Range: 0 - 11
module id	Enter the module id number of the optional slot.
	Range: 0 - 1

Defaults

None

Command Modes

Configuration

Command **History**

Usage Information

Pre-configuring the interfaces for the optical module preserves the configuration if/when an optical module is removed. The optional 10G optical module is automatically recognized and the interfaces are created when the module is inserted into the slot. However, if the system is not already configured for the interfaces, when the module is removed the interfaces and their configurations are removed as well.

switchport



Place the interface in Layer 2 mode.

Syntax

switchport [backup interface {gigabit | tengigabit} slot/port]

To remove the interface from Layer 2 mode and place it in Layer 3 mode, enter **no switchport**. If a switchport backup relationship exists, remove that relationship first.

To remove a switchport backup relationship created on this port, enter **no switchport backup** interface {gigabit | tengigabit} slotlport].

Parameters

backup interface	Use this option to configure a redundant Layer 2 link without using Spanning Tree. This keyword configures a backup port so that if the primary port fails the backup port changes to the up state. If the primary later comes up, it becomes the backup.
gigabit	Enter this keyword if the backup port is a 1G port.
tengigabit	Enter this keyword if the backup port is a 10G port.
slot l port	Specify the line card and port number of the backup port.

Defaults

Disabled (The interface is in Layer 3 mode.)

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.7.1.0	Added backup interface option.	

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

If an IP address or VRRP group is assigned to the interface, you cannot use the **switchport** command for that interface. To use the **switchport** command on an interface, only the **no ip address** and **no shutdown** statements must be listed in the **show config** for that command.

When you enable the **switchport** command, the interface is automatically added to the Default VLAN.

To use the **switchport backup interface** command on a port, first execute the **switchport** command on the port. For details, see the section Configuring Redundant Links in the Layer 2 chapter of the *FTOS Configuration Guide*.

Related Commands

interface port-channel	Create a port channel interface.
show interfaces switchport	Display information about switchport interfaces.

wanport

E

Enable the WAN mode on a TenGigabitEthernet interface.

Syntax

wanport

To disable the WAN Port, enter **no wanport**.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.1.1.2	Introduced on E-Series ExaScale
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

The port must be in a shutdown state to change from LAN mode to WAN mode and vice-versa as shown in the figure below.

For E-Series ExaScale systems, you must configure all the ports in a port-pipe to either WANPHY or non-WANPHY. They cannot be mixed on the same port-pipe.

Example

Figure 14-41. wanport Command with shutdown Command Example

```
interface TenGigabitEthernet 13/0
no ip address
no shutdown
FTOS(conf-if-te-13/0)#
FTOS(conf-if-te-13/0)#wanport
% Error: Port should be in shutdown mode, config ignored Te 13/0.
FTOS(conf-if-te-13/0)#
FTOS(conf-if-te-13/0)#shutdown
FTOS(conf-if-te-13/0)#
FTOS(conf-if-te-13/0)#wanport
FTOS(conf-if-te-13/0)#wanport
FTOS(conf-if-te-13/0)#
```

Related Commands

The following related commands are valid for E-Series only.

ais-shut	Send LAIS on shutdown
alarm-report	Enable reporting of a selected alarm
clock source	Configure a clock source
down-when-looped	Send a message when a loopback condition is detected
flag	Set flags to ensure interoperability
framing	Set framing type
keepalive	Enable keepalive
loopback	Troubleshoot a SONET loopback

Port Channel Commands

A Link Aggregation Group (LAG) is a group of links that appear to a MAC client as if they were a single link according to IEEE 802.3ad. In FTOS, a LAG is referred to as a Port Channel.

Table 14-11. Port Channel Limits

Platform	Maximum Port Channel IDs	Maximum Members per Port Channel
E-Series ExaScale	255	64
E-Series TeraScale	255	16
C-Series	128	8
S-Series	128	8

Because each port can be assigned to only one Port Channel, and each Port Channel must have at least one port, some of those nominally available Port Channels might have no function because they could have no members if there are not enough ports installed. In the S-Series, those ports could be provided by stack members.

The commands in this section are specific to Port Channel interfaces:

- channel-member
- group
- interface port-channel
- minimum-links
- port-channel failover-group
- show config
- show interfaces port-channel
- show port-channel-flow



Note: The FTOS implementation of LAG or Port Channel requires that you configure a LAG on both switches manually. For information on FTOS Link Aggregation Control Protocol (LACP) for dynamic LAGs, refer to Chapter 19, Link Aggregation Control Protocol (LACP).

For more information on configuring and using Port Channels, refer to the FTOS Configuration Guide.

channel-member

CES

Add an interface to the Port Channel, while in the INTERFACE PORTCHANNEL mode.

Syntax

channel-member interface

To delete an interface from a Port Channel, use the **no channel-member** interface command.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For a 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a SONET interface, enter the keyword sonet followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Not configured.

Command Modes

INTERFACE PORTCHANNEL

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

Use the interface port-channel command to access this command.

You cannot add an interface to a Port Channel if the interface contains an IP address in its configuration. Only the shutdown, description, mtu, and ip mtu commands can be configured on an interface if it is to be added to a Port Channel. The mtu and ip mtu commands are only available when the chassis is in Jumbo mode.

Link MTU and IP MTU considerations for Port Channels are:

- All members must have the same link MTU value and the same IP MTU value.
- The Port Channel link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the channel members.

Example: If the members have a link MTU of 2100 and an IP MTU 2000, the Port Channel's MTU values cannot be higher than 2100 for link MTU or 2000 bytes for IP MTU.

When an interface is removed from a Port Channel with the no channel-member command syntax, the interface reverts to its configuration prior to joining the Port Channel.

An interface can belong to only one Port Channel.

On the E-Series TeraScale, you can add up to 16 interfaces to a Port Channel; E-Series ExaScale can have up to 64. You can have eight interfaces per Port Channel on the C-Series and S-Series. The interfaces can be located on different line cards but must be the same physical type and speed (for example, all 1-Gigabit Ethernet interfaces). However, you can combine 100/1000 interfaces and GE interfaces in the same Port Channel.

If the Port Channel contains a mix of interfaces with 100 Mb/s speed and 1000 Mb/s speed, the software disables those interfaces whose speed does not match the speed of the first interface configured and enabled in the Port Channel. If that first interface goes down, the Port Channel does not change its designated speed; you must disable and re-enable the Port Channel or change the order of the channel members configuration to change the designated speed. Refer to the FTOS Configuration Guide for more information on Port Channels.

Related **Commands**

description	Assign a descriptive text string to the interface.
interface port-channel	Create a Port Channel interface.
shutdown	Disable/Enable the port channel.

group

CES

Group two LAGs in a supergroup ("fate-sharing group" or "failover group").

Syntax

group group_number port-channel number port-channel number

To remove an existing LAG supergroup, use the **no group** *group_number* command.

Parameters

group_number	Enter an integer from 1 to 32 that will uniquely identify this LAG fate-sharing group.
port-channel number	Enter the keyword port-channel followed by an existing LAG <i>number</i> . Enter this keyword/variable combination twice, identifying the two LAGs to be paired.

Defaults

No default values or behavior

Command Modes

PORT-CHANNEL FAILOVER-GROUP (conf-po-failover-grp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced for C-Series, E-Series, and S-Series

Example

```
FTOS(conf) #port-channel failover-group
FTOS(conf-po-failover-grp)#group 1 port-channel 1 port-channel 2 FTOS(conf-po-failover-grp)#
```

Related Commands

show interfaces port-channel	Display information on configured Port Channel groups.
port-channel failover-group	Access the PORT-CHANNEL FAILOVER-GROUP mode to configure a LAG failover group.

interface port-channel

CES

Create a Port Channel interface, which is a link aggregation group containing up to 16 physical interfaces on E-Series, eight physical interfaces on C-Series and S-Series.

Syntax

interface port-channel channel-number

To delete a Port Channel, use the **no interface port-channel** channel-number command.

Parameters

channel-number	Enter a number as the interface number.
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Example

Figure 14-42. interface port-channel Command Example

```
FTOS(conf)#int port-channel 2
FTOS(conf-if-po-2)#
```

Usage Information

Port Channel interfaces are logical interfaces and can be either in Layer 2 mode (by using the switchport command) or Layer 3 mode (by configuring an IP address). You can add a Port Channel in Layer 2 mode to a VLAN.

The shutdown, description, and name commands are the only commands that you can configure on an interface while it is a member of a Port Channel. To add a physical interface to a Port Channel, the interface can only have the shutdown, description, and name commands configured. The Port Channel's configuration is applied to the interfaces within the Port Channel.

A Port Channel can contain both 100/1000 interfaces and GE interfaces. Based on the first interface configured in the Port Channel and enabled, FTOS determines if the Port Channel uses 100 Mb/s or 1000 Mb/s as the common speed. Refer to channel-member for more information.

If the line card is in a Jumbo mode chassis, then the mtu and ip mtu commands can also be configured. The Link MTU and IP MTU values configured on the channel members must be greater than the Link MTU and IP MTU values configured on the Port Channel interface.



Note: In a Jumbo-enabled system, all members of a Port Channel must be configured with the same link MTU values and the same IP MTU values.

Related Commands

channel-member	Add a physical interface to the LAG.
interface	Configure a physical interface.
interface loopback	Configure a Loopback interface.
interface null	Configure a null interface.

interface vlan	Configure a VLAN.
shutdown	Disable/Enable the port channel.

minimum-links

CES

Configure the minimum number of links in a LAG (Port Channel) that must be in "oper up" status for the LAG to be also in "oper up" status.

Syntax

minimum-links number

Parameters

number	Enter the number of links in a LAG that must be in "oper up" status.
	Range: 1 to 16
	Default: 1

Defaults

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.0	Introduced for E-Series

Usage Information

If you use this command to configure the minimum number of links in a LAG that must be in "oper up" status, then the LAG must have at least that number of "oper up" links before it can be declared as up.

For example, if the required minimum is four, and only three are up, then the LAG will be considered down.

port-channel failover-group

CES

Access the PORT-CHANNEL FAILOVER-GROUP mode to configure a LAG failover group.

Syntax

port-channel failover-group

To remove all LAG failover groups, use the **no port-channel failover-group** command.

Defaults

No default values or behavior

Command Modes

CONFIGURATION

Command **History**

Versi	on 8.3.3.1	Introduced on the S60.
Versi	on 8.1.1.0	Introduced on E-Series ExaScale
Versi	on 7.6.1.0	Introduced for C-Series, E-Series, and S-Series

Usage Information

This feature groups two LAGs to work in tandem as a supergroup, so that, for example, if one LAG goes down, the other LAG is taken down automatically, providing an alternate path to reroute traffic, avoiding oversubscription on the other LAG. You can use both static and dynamic (LACP) LAGs to configure failover groups. For details, see the Port Channel chapter in the *FTOS Configuration Guide*.

Related Commands

group	Group two LAGs in a supergroup ("fate-sharing group").	
show interfaces port-channel	Display information on configured Port Channel groups.	

show config

CES

Display the current configuration of the selected LAG.

Syntax show config

Command Modes

INTERFACE PORTCHANNEL

Example

Figure 14-43. show config Command Sample Output for a Selected LAG

```
FTOS(conf-if-po-1)#show config
!
interface Port-channel 1
no ip address
shutdown
FTOS(conf-if-po-1)#
```

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

show interfaces port-channel

CES

Display information on configured Port Channel groups.

Syntax

show interfaces port-channel [channel-number] [brief]

Parameters

channel-number	(OPTIONAL) Enter the number of the port channel to display information on that port channel: C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 255 for TeraScale and ExaScale	
brief	(OPTIONAL) Enter the keyword brief to display only the port channel number, the state of the port channel, and the number of interfaces in the port channel.	

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale

Version 7.6.1.0	Introduced for S-Series; Modified to display LAG failover group status	
Version 7.5.1.0	Introduced for C-Series	
E-Series legacy command		

Figure 14-44. show interfaces port-channel Command Example **Example**

```
FTOS#show interfaces port-channel 20
Port-channel 20 is up, line protocol is up (Failover-group 1 is down)
Hardware address is 00:01:e8:01:46:fa
Port-channel is part of failover-group 1
Internet address is 1.1.120.1/24
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 2000 Mbit
Members in this channel: Gi 0/5 Gi 0/18
ARP type: ARPA, ARP timeout 04:00:00
Last clearing of "show interfaces" counters 00:00:00
Queueing strategy: fifo
      44507301 packets input, 3563070343 bytes
      Input 44506754 IP Packets, 0 Vlans 0 MPLS
41 64-byte pkts, 44502871 over 64-byte pkts, 249 over 127-byte pkts
      407 over 255-byte pkts, 3127 over 511-byte pkts, 606 over 1023-byte pkts
Received 0 input symbol errors, 0 runts, 0 giants, 0 throttles
      0 CRC, 0 IP Checksum, 0 overrun, 0 discarded
      1218120 packets output, 100745130 bytes, 0 underruns
      Output 5428 Multicasts, 4 Broadcasts, 1212688 Unicasts 1216142 IP Packets, 0 Vlans, 0 MPLS
0 throttles, 0 discarded Rate info (interval 299 sec):
      Input 01.50Mbits/sec,
                                       2433 packets/sec
      Output 00.02Mbits/sec,
                                            4 packets/sec
Time since last interface status change: 00:22:34
FTOS#
```

Table 14-12. show interfaces port-channel Command Example Fields

Field	Description	
Port-Channel 1	Displays the LAG's status. In the example, the status of the LAG's LAG fate-sharing group ("Failover-group") is listed.	
Hardware is	Displays the interface's hardware information and its assigned MAC address.	
Port-channel is part	Indicates whether the LAG is part of a LAG fate-sharing group ("Failover-group").	
Internet address	States whether an IP address is assigned to the interface. If one is, that address is displayed.	
MTU 1554	Displays link and IP MTU.	
LineSpeed	Displays the interface's line speed. For a port channel interface, it is the line speed of the interfaces in the port channel.	
Members in this Displays the interfaces belonging to this port channel.		
ARP type:	Displays the ARP type and the ARP timeout value for the interface.	
Last clearing	Displays the time when the show interfaces counters were cleared.	
Queueing strategy.	States the packet queuing strategy. FIFO means first in first out.	
packets input	Displays the number of packets and bytes into the interface.	
Input 0 IP packets	Displays the number of packets with IP headers, VLAN tagged headers and MPLS headers.	
	The number of packets may not add correctly because a VLAN tagged IP packet counts as both a VLAN packet and an IP packet.	

Table 14-12. show interfaces port-channel Command Example Fields (continued)

Field	Description
0 64-byte	Displays the size of packets and the number of those packets entering that interface. This information is displayed over two lines.
Received 0	Displays the type and number of errors or other specific packets received. This information is displayed over three lines.
Output 0	Displays the type and number of packets sent out the interface. This information is displayed over three lines.
Rate information	Displays the traffic rate information into and out of the interface. Traffic rate is displayed in bits and packets per second.
Time since	Displays the time since the last change in the configuration of this interface.

Figure 14-45. show interfaces port-channel brief Command Example

Table 14-13. show interfaces port-channel brief Command Example Fields

Field	Description	
LAG	Lists the port channel number.	
Mode	Lists the mode:	
	L3 - for Layer 3	
	• L2 - for Layer 2	
Status	Displays the status of the port channel.	
	• down - if the port channel is disabled (shutdown)	
	• up - if the port channel is enabled (no shutdown)	
Uptime	Displays the age of the port channel in hours:minutes:seconds.	
Ports	Lists the interfaces assigned to this port channel.	
(untitled) Displays the status of the physical interfaces (up or down).		
	In Layer 2 port channels, an * (asterisk) indicates which interface is the primary port of the port channel. The primary port sends out interface PDU.	
	In Layer 3 port channels, the primary port is not indicated.	

Related Commands

show lacp	Display the LACP matrix.	
-----------	--------------------------	--

show port-channel-flow

CES

Display an egress port in a given port-channel flow.

Syntax

show port-channel-flow outgoing-port-channel number incoming-interface interface {source-ip address destination-ip address} | {protocol number | icmp | tcp | udp} | {source-port number destination-port number} | {source-mac address destination-mac address}

Parameters

outgoing-port-channel number	Enter the keyword outgoing-port-channel followed by the number of the port channel to display flow information.
	• For a port channel interface, enter the keyword port-channel followed by a number:
	C-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale and ExaScale
incoming-interface interface	Enter the keyword incoming-interface followed by the interface type and slot/port or number information:
	• For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
source-ip address	Enter the keyword source-ip followed by the IP source address in IP address format.
destination-ip address	Enter the keyword destination-ip followed by the IP destination address in IP address format.
protocol <i>number</i> icmp tcp udp	On the E-Series only, enter the keyword protocol followed by one of the protocol type
Таар	keywords: tcp, udp, icmp or protocol number
	Note: The protocol number keyword applies to E-Series only.
source-port number	Enter the keyword source-port followed by the source port number
	Range: 1-65536
	Default: None
destination-port number	Enter the keyword destination-port followed by the destination port number.
	Range: 1-65536
	Default: None
source-mac address	Enter the keyword source-mac followed by the MAC source address in the nn:nn:nn:nn:nn format.
destination-mac address	Enter the keyword destination-mac followed by the MAC

Command Modes

EXEC

Usage Information

Since this command calculates based on a Layer 2 hash algorithm, use this command to display flows for switched Layer 2 packets, not for routed packets (use the show ip flow command to display routed packets).

The **show port-channel-flow** command returns the egress port identification in a given port-channel, if a valid flow is entered. A mismatched flow error occurs if MAC-based hashing is configured for a Layer 2 interface and the user is trying to display a Layer 3 flow.

The output will display three entries:

- Egress port for unfragmented packets.
- In the event of fragmented packets, egress port of the first fragment.
- In the event of fragmented packets, egress port of the subsequent fragments.

Example

show port-channel-flow outgoing-port-channel number incoming-interface interface source-mac address destination-mac address

- Load-balance is configured for MAC
- Load balance is configured for IP 4-tuple/2-tuple for the C-Series and S-Series
- A non-IP payload is going out of Layer 2 LAG interface that is a member of VLAN with an IP address.

Figure 14-46. show port-channel-flow Command for MAC Addresses

```
FTOS#show port-channel-flow outgoing-port-channel 1 incoming-interface gi 3/0 source-mac 00:00:50:00:00 destination-mac 00:00:a0:00:00:00

Egress Port for port-channel 1, for the given flow, is Te 13/01
```

Example On the E-Series only:

show port-channel-flow outgoing-port-channel *number* incoming-interface *interface* source-ip *address* destination-ip *address* {protocol *number* [icmp/tcp/udp]} {source-port *number* destination-port *number*}

- Load balance is configured for IP 5-tuple/3-tuple.
- An IP payload is going out of a Layer 2 LAG interface that is a member of a VLAN with an IP address.

```
FTOS#show port-channel-flow outgoing-port-channel 2 incoming-interface gi 3/0 source-ip 2.2.2.0 destination-ip 3.2.3.1 protocol tcp source-port 5 destination-port 6
```

```
Egress Port for port-channel 2, for the given flow: Unfragmented packet: Gi 1/6 Fragmented packets (first fragment): Gi 1/12 Fragmented packets (remaining fragments): Gi 1/12
```

Related Commands

load-balance (E-Series)

Balance traffic over E-Series port channel members.

UDP Broadcast

The User Datagram Protocol (UDP) broadcast feature is a software-based method to forward low throughput (not to exceed 200 pps) IP/UDP broadcast traffic arriving on a physical or VLAN interface.

Important Points to Remember

- This feature is available only on the E-Series platform, as noted by this symbol under each command heading: [E]
- This feature applies only to E-Series Layer 3 physical or VLAN interfaces.
- Routing Information Protocol (RIP) is not supported with the UDP Broadcast feature.
- If this feature is configured on an interface using ip udp-helper udp-port, then the command ip directed-broadcast becomes ineffective on that interface.
- The existing command show interface has been modified to display the configured broadcast address.

The commands for UDP Broadcast are:

- debug ip udp-helper
- ip udp-helper udp-port
- show ip udp-helper

debug ip udp-helper

(E) (S60)

Enable UDP debug and display the debug information on a console.

54810

Syntax debug ip udp-helper

To disable debug information, use the no debug ip udp-helper command.

Defaults Debug disabled

Command Modes **EXEC**

EXEC Privilege

Example FTOS#debug ip udp-helper UDP helper debugging is on

01:20:22: Pkt rcvd on Gi 5/0 with IP DA (Oxffffffff) will be sent on Gi 5/1 Gi 5/2 Vlan 3

01:44:54: Pkt rcvd on Gi 7/0 is handed over for DHCP processing.

Related Commands

Command History

ip udp-helper udp-port	Enable the UDP broadcast feature on an interface.
show ip udp-helper	Display the configured UDP helper(s) on all interfaces.
Version 8.3.3.9	Introduced on S60
Version 8.3.7.0	Introduced on S4810
Pre-version 8.3.7.0	Introduced on E-Series ExaScale

ip udp-helper udp-port



Enable the UDP broadcast feature on an interface either for all UDP ports or a specified list of UDP ports.

Syntax

ip udp-helper udp-port [udp-port-list]

To disable the UDP broadcast on a port, use the no ip udp-helper udp-port [udp-port-list] command.

Parameters

udp-port-list	(OPTIONAL) Enter up to 16 comma separated UDP port numbers.
	Note: If this option is not used, all UDP Ports are considered by default.

Defaults

No default behavior or values

Command Modes

INTERFACE (config-if)

Usage Information

If the ip helper-address command and ip udp-helper udp-port command are configured, the behavior is that the UDP broadcast traffic with port numbers 67/68 will be unicast relayed to the DHCP server per the ip helper-address configuration. This will occur regardless if the ip udp-helper udp-port command contains port numbers 67/68 or not.

If only the ip udp-helper udp-port command is configured, all the UDP broadcast traffic is flooded, including ports 67/68 traffic if those ports are part of the *udp-port-list*.

Command History

Version 8.3.3.9	Introduced on S60
Version 8.3.7.0	Introduced on S4810
Pre-version 8.3.7.0	Introduced on E-Series ExaScale
ip helper-address	Configure the destination broadcast or host address for DHCP server.
debug ip udp-helper	Enable debug and display the debug information on a console.
show ip udp-helper	Display the configured UDP helper(s) on all interfaces.

Related Commands

show ip udp-helper

E (\$60)

Display the configured UDP helper(s) on all interfaces.

[54810]

Syntax show ip udp-helper

Defaults No default configuration or values

Command Modes EXEC

> **Example** FTOS#show ip udp-helper

Port UDP port list

Gi 10/0 656, 658 Gi 10/1 All

Command **History**

Version 8.3.3.9	Introduced on S60
Version 8.3.7.0	Introduced on S4810
Pre-version 8.3.7.0	Introduced on E-Series ExaScale

Related Commands

debug ip udp-helper	Enable debug and display the debug information on a console.
ip udp-helper udp-port	Enable the UDP broadcast feature on an interface either for all UDP ports or a specified list of UDP ports.

IPv4 Routing

Overview

The characters that appear below command headings indicate support for the associated Dell Networking platform, as follows:

- C-Series: C
- E-Series: [E]
- S-Series: [S]

Commands

IPv4-related commands are described in this chapter. They are:

- arp
- arp learn-enable
- arp retries
- arp timeout
- clear arp-cache
- clear host
- clear ip fib linecard
- clear ip route
- clear tcp statistics
- debug arp
- debug ip dhcp
- debug ip icmp
- debug ip packet
- ip address
- ip directed-broadcast
- ip domain-list
- ip domain-lookup
- ip domain-name
- ip fib download-igp-only
- ip helper-address
- ip helper-address hop-count disable
- ip host
- ip max-frag-count
- ip mtu

- ip name-server
- ip proxy-arp
- ip redirects
- ip route
- ip source-route
- ip unreachables
- ip vlan-flooding
- load-balance (C-Series and S-Series)
- load-balance (E-Series)
- management route
- show arp
- show arp retries
- show hosts
- show ip cam linecard
- show ip cam stack-unit
- · show ip fib linecard
- show ip fib stack-unit
- show ip flow
- show ip interface
- show ip management-route
- show ip protocols
- show ip route
- show ip route list
- show ip route summary
- show ip traffic
- show protocol-termination-table
- show tcp statistics

arp



Use Address Resolution Protocol (ARP) to associate an IP address with a MAC address in the switch.

Syntax

arp vrf {vrf name} ip-address mac-address interface

To remove an ARP address, use the **no arp** *ip-address* command.

Parameters

vrf name	E-Series Only: Enter the VRF process identifier to tie the static route to the VRF
	process.
ip-address	Enter an IP address in dotted decimal format.

mac-address	Enter a MAC address in nnnn.nnnn format.
interface	Enter the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For the Management interface, enter the keyword ManagementEthernet followed by the slot/port information. The slot range is 0-1 and the port range is 0.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

You cannot use Class D or Class E IP addresses or zero IP address (0.0.0.0) when creating a static ARP. Zero MAC addresses (00:00:00:00:00:00) are also invalid.

Related Commands

clear a	p-cache	Clear dynamic ARP entries from the ARP table.
show a	rp	Display ARP table.

arp learn-enable

CES

Enable ARP learning via Gratuitous ARP.

Syntax

arp learn-enable

Defaults

Disabled

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.3.1.0	Introduced	

Usage Information

In FTOS versions prior to 8.3.1.0, if a gratuitous ARP is received some time after an ARP request is sent, only RP2 installs the ARP information. For example:

- At time t=0 FTOS sends an ARP request for IP A.B.C.D
- 2 At time t=1 FTOS receives an ARP request for IP A.B.C.D

3 At time t=2 FTOS installs an ARP entry for *A.B.C.D* only on RP2.

Beginning with version 8.3.1.0, when a Gratuitous ARP is received, FTOS installs an ARP entry on all 3 CPUs.

arp retries

CES

Set the number of ARP retries in case the system does not receive an ARP reply in response to an ARP

Syntax

arp retries number

Parameters

number	Enter the number of retries.
	Range: 5 to 20.
	Default: 5

Defaults

5

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced

Usage Information

Retries are 20 seconds apart.

Related Commands

show arp retries Display the configured number of ARP retries.

arp timeout

CES

Set the time interval for an ARP entry to remain in the ARP cache.

Syntax

arp timeout minutes

To return to the default value, enter **no arp timeout**.

Parameters

seconds	Enter the number of minutes.
	Range: 0 to 35790.
	Default: 240 minutes.

Defaults

240 minutes (4 hours)

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
show interfaces	Displays the ARP timeout value for all available interfaces.

Related Commands

clear arp-cache

Clear the dynamic ARP entries from a specific interface or optionally delete (no-refresh) ARP entries

clear arp-cache [vrf name | interface | ip ip-address] [no-refresh] **Syntax**

Parameters

vrf name	E-Series Only: Clear only the ARP cache entries tied to the VRF process.	
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	• For the Management interface, enter the keyword ManagementEthernet followed by the slot/port information. The slot range is 0-1 and the port range is 0.	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 255 for TeraScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.	
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.	
ip ip-address	(OPTIONAL) Enter the keyword ip followed by the IP address of the ARP entry you wish to clear.	
no-refresh	(OPTIONAL) Enter the keyword no-refresh to delete the ARP entry from CAM. Or use this option with <i>interface</i> or ip <i>ip-address</i> to specify which dynamic ARP entries you want to delete.	
	Note: Transit traffic may not be forwarded during the period when deleted ARP entries are resolved again and re-installed in CAM. Use this option with extreme caution.	

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

clear host

CES

Remove one or all dynamically learnt host table entries.

Syntax

clear host name

Parameters

name	Enter the name of the host to delete.
	Enter * to delete all host table entries.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

clear ip fib linecard

CES

Clear all Forwarding Information Base (fib) entries in the specified line card (use this command with caution, see <u>Usage Information below</u>)

Syntax

clear ip fib linecard slot-number | vrf vrf instance

Parameters

slot-number	Enter the number of the line card slot.
	C-Series and S-Series Range: 0-7
	E-Series Range: 0 to 13 on E12001200i, 0 to 6 on E600/E600i; 0 to 5 on E300
vrf instance	(Optional) E-Series Only : Clear only the FIB entries on the specified card associated with the VRF instance.

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.2	Introduced support on E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

Use this command to clear Layer 3 CAM inconsistencies.



Caution: Executing this command will cause traffic disruption.

Related Commands

show ip fib linecard	Show FIB entries.	

clear ip route

CES Clear one or all routes in the routing table.

Syntax clear ip route {* | ip-address mask | vrf vrf instance}

Parameters

*	Enter an asterisk (*) to clear all learned IP routes.	
ip-address mask	Enter a specific IP address and mask in dotted decimal format to clear that IP address from the routing table.	
vrf instance	(Optional) E-Series Only : Clear only the routes tied to the VRF instance.	

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

ip route	Assign an IP route to the switch.
show ip route	View the routing table.
show ip route summary	View a summary of the routing table.

clear tcp statistics

CES

Clear TCP counters.

Syntax

clear tcp statistics [all | cp | rp1 | rp2]

Note: These options are supported only on the E-Series.

Parameters

all	Enter the keyword all to clear all TCP statistics maintained on all switch processors.	
ср	(OPTIONAL) Enter the cp to clear only statistics from the Control Processor.	
rp1	(OPTIONAL) Enter the keyword rp1 to clear only the statistics from Route Processor 1.	
rp2	(OPTIONAL) Enter the keyword rp2 to clear only the statistics from Route Processor 2.	

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

debug arp

CES

View information on ARP transactions.

Syntax

debug arp [interface] [count value]

To stop debugging ARP transactions, enter **no debug arp**.

Parameters

interface	(OPTIONAL) Enter the following keywords and slot/port or number information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information. 	
	• For the Management interface, enter the keyword managementethernet followed by the slot/port information. The slot range is 0-1 and the port range is 0.	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 255 for TeraScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword tengigabitethernet followed by the slot/port information. 	
	• For a VLAN, enter the keyword vian followed by a number from 1 to 4094.	
count value	(OPTIONAL) Enter the keyword count followed by the count value.	
	Range: 1 to 65534	

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.3.1.0	Added the count option

Defaults

No default behavior or values

Usage Information

Use the **count** option to stop packets from flooding the user terminal when debugging is turned on.

debug ip dhcp

CES

Enable debug information for DHCP relay transactions and display the information on the console.

Syntax debug ip dhcp

To disable debug, use the **no debug ip dhcp** command.

Defaults Debug disabled

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.4.10	Introduced on E-Series

Example Figure 15-1. debug ip dhcp Command Example

```
FTOS#debug ip dhcp
00:12:21 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface 113.3.3.17 BOOTP
Request, hops = 0, XID = 0xbf05140f, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr = 0.0.0.0
00:12:21 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:8C to 14.4.4.2 00:12:26 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface 113.3.3.17 BOOTP
Request, hops = 0, XID = 0xbf05140f, secs = 5, hwaddr = 00:60:CF:20:7B:8C, giaddr = 0.0.0.00:12:26: %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:8C to 14.4.4.2
00:12:40 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface 113.3.3.17 BOOTP
Request, hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr = 0.0.0.0
00:12:40 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:8C to 14.4.4.2
00:12:42 : %RELAY-I-PACKET: BOOTP REPLY (Unicast) received at interface 14.4.4.1 BOOTP Reply,
hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr = 113.3.3.17
00:12:42: %RELAY-I-BOOTREPLY: Forwarded BOOTREPLY for 00:60:CF:20:7B:8C to 113.3.3.254
00:12:42 : %RELAY-I-PACKET: BOOTP REQUEST (Unicast) received at interface 113.3.3.17 BOOTP
Request, hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr = 0.0.0.0
00:12:42 : %RELAY-I-BOOTREQUEST: Forwarded BOOTREQUEST for 00:60:CF:20:7B:8C to 14.4.4.2
00:12:42 : %RELAY-I-PACKET: BOOTP REPLY (Unicast) received at interface 14.4.4.1 BOOTP Reply,
hops = 0, XID = 0xda4f9503, secs = 0, hwaddr = 00:60:CF:20:7B:8C, giaddr = 113.3.3.17
00:12:42: %RELAY-I-BOOTREPLY: Forwarded BOOTREPLY for 00:60:CF:20:7B:8C to 113.3.3.254
```

Related Commands

ip helper-address	Specify the destination broadcast or host address for DHCP server request.
ip helper-address hop-count disable	Disable hop-count increment for DHCP relay agent.

debug ip icmp

CESView information on the Internal Control Message Protocol (ICMP).

Syntax debug ip icmp [interface] [count value]

To disable debugging, use the **no debug ip icmp** command.

Parameters

(OPTIONAL) Enter the following keywords and slot/port or number information: For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. For the Management interface, enter the keyword ManagementEthernet followed by the slot/port information. The slot range is 0 and the port range is 0-1. For a Port Channel interface, enter the keyword port-channel followed by a number: C-Series and S-Series Range: 1-128 E-Series Range: 1 to 255 for TeraScale. For a SONET interface, enter the keyword sonet followed by the slot/port information. For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

count value

interface

(OPTIONAL) Enter the keyword **count** followed by the count value.

For VLAN, enter the keyword **vlan** followed by a number from 1 to 4094.

Range: 1 to 65534 Default: Infinity

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
Version 6.3.1.0	Added the count option	

Example

Figure 15-2. debug ip icmp Command Example (Partial)

```
ICMP: echo request rcvd from src 40.40.40.40
ICMP: src 40.40.40.40, dst 40.40.40, echo reply
ICMP: src 40.40.40.40, dst 40.40.40, echo reply
ICMP: echo request sent to dst 40.40.40.40
ICMP: echo request rcvd from src 40.40.40.40
ICMP: src 40.40.40.40, dst 40.40.40.40
ICMP: src 40.40.40.40, dst 40.40.40, echo reply
ICMP: src 40.40.40.40, dst 40.40.40.40, echo reply
ICMP: echo request sent to dst 40.40.40.40
```

Usage Information

Use the **count** option to stop packets from flooding the user terminal when debugging is turned on.

debug ip packet

CES

View a log of IP packets sent and received.

Syntax

debug ip packet [access-group name] [count value] [interface]

To disable debugging, use the **no debug ip packet** [access-group name] [count value] [interface] command.

Parameters

-	
access-group name	Enter the keyword access-group followed by the access list name (maximum 16 characters) to limit the debug output based on the defined rules in the ACL.
count value	(OPTIONAL) Enter the keyword count followed by the count value.
	Range: 1 to 65534
	Default: Infinity
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword gigabitethernet followed by the slot/port information.
	• For the management interface on the RPM, enter the keyword managementethernet followed by the slot/port information. The slot range is 0-1 and the port range is 0.
	• For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword tengigabitethernet followed by the slot/port information.
	 For a VLAN, enter the keyword vian followed by a number from 1 to 4094.

Command Mode

EXEC Privilege

Command History

Introduced on the S60.
Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)
Introduced on E-Series ExaScale
Added the access-group option
Introduced on S-Series
Introduced on C-Series
Added the count option

Example

Figure 15-3. debug ip packet Command Example (Partial)

```
IP: s=10.1.2.62 (local), d=10.1.2.206 (Ma 0/0), len 54, sending
TCP src=23, dst=40869, seq=2112994894, ack=606901739, win=8191 ACK PUSH IP: s=10.1.2.206 (Ma 0/0), d=10.1.2.62, len 40, rcvd
TCP src=0, dst=0, seq=0, ack=0, win=0

IP: s=10.1.2.62 (local), d=10.1.2.206 (Ma 0/0), len 226, sending
TCP src=23, dst=40869, seq=2112994896, ack=606901739, win=8192 ACK PUSH IP: s=10.1.2.216 (Ma 0/0), d=10.1.2.255, len 78, rcvd
    UDP src=0, dst=0
IP: s=10.1.2.62 (local), d=10.1.2.3 (Ma 0/0), len 1500, sending fragment
     IP Fragment, Ident = 4741, fragment offset = 0
    ICMP type=0, code=0
IP: s=10.1.2.62 (local), d=10.1.2.3 (Ma 0/0), len 1500, sending fragment
    IP Fragment, Ident = 4741, fragment offset = 1480
IP: s=40.40.40.40 (local), d=224.0.0.5 (Gi 4/11), len 64, sending broad/multicast
proto=89
IP: s=40.40.40.40 (local), d=224.0.0.6 (Gi 4/11), len 28, sending broad/multicast
proto=2
IP: s=0.0.0.0, d=30.30.30.30, len 100, unroutable
    ICMP type=8, code=0
IP: s=0.0.0.0, d=30.30.30.30, len 100, unroutable
    ICMP type=8, code=0
```

Table 15-1. debug ip packet Command Example Fields

Field	Description
s=	Lists the source address of the packet and the name of the interface (in parentheses) that received the packet.
d=	Lists the destination address of the packet and the name of the interface (in parentheses) through which the packet is being sent out on the network.
len	Displays the packet's length.
sending rcvd fragment sending broad/multicast proto unroutable	The last part of each line lists the status of the packet.
TCP src=	Displays the source and destination ports, the sequence number, the acknowledgement number, and the window size of the packets in that TCP packets.
UDP src=	Displays the source and destination ports for the UDP packets.
ICMP type=	Displays the ICMP type and code.
IP Fragment	States that it is a fragment and displays the unique number identifying the fragment (Ident) and the offset (in 8-byte units) of this fragment (fragment offset) from the beginning of original datagram.

Usage Information

Use the **count** option to stop packets from flooding the user terminal when debugging is turned on.

The **access-group** option supports only the equal to (**eq**) operator in TCP ACL rules. Port operators not equal to (**neq**), greater than (**gt**), less than (**lt**), or **range** are not supported in **access-group** option (see Figure 15-4). ARP packets (**arp**) and Ether-type (**ether-type**) are also not supported in **access-group** option. The entire rule is skipped to compose the filter.

The access-group option pertains to:

• IP Protocol Number

0 to 255

Internet Control Message Protocol* icmp

* but not the ICMP message type (0-255)

Any Internet Protocol ip

Transmission Control Protocol* tcp

* but not on the rst, syn, or urg bit User Datagram Protocol udp

In the case of ambiguous access control list rules, the debug ip packet access-control command will be disabled. A message appears identifying the error (see Figure 15-4).

Example Figure 15-4. debug ip packet access-group Command Errors

```
FTOS#debug ip packet access-group test
%Error: port operator GT not supported in access-list debug
%Error: port operator LT not supported in access-list debug
%Error: port operator RANGE not supported in access-list debug
%Error: port operator NEQ not supported in access-list debug
FTOS#00:10:45: %RPM0-P:CP %IPMGR-3-DEBUG_IP_PACKET_ACL_AMBIGUOUS_EXP: Ambiguous rules not
supported in access-list debug, access-list debugging is turned off
```

ip address

CES

Assign a primary and secondary IP address to the interface.

Syntax

ip address ip-address mask [secondary]

To delete an IP address from an interface, use the **no ip address** [ip-address] command.

Parameters

ip-address	Enter an IP address in dotted decimal format.
mask	Enter the mask of the IP address in slash prefix format (for example, /24).
secondary	(OPTIONAL) Enter the keyword secondary to designate the IP address as the secondary address.

Defaults

Not configured.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Usage Information

You must be in the INTERFACE mode before you add an IP address to an interface. Assign an IP address to an interface prior to entering the ROUTER OSPF mode.

ip directed-broadcast

C E S Enables the interface to receive directed broadcast packets.

Syntax ip directed-broadcast

To disable the interface from receiving directed broadcast packets, enter no ip directed-broadcast.

Defaults Disabled (that is, the interface does not receive directed broadcast packets)

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

ip domain-list

C) [E] [S] Configure names to complete unqualified host names.

Syntax ip domain-list name

To remove the name, use the **no ip domain-list** *name* command.

Parameters

name	Enter a domain name to be used to complete unqualified names (that is, incomplete
	domain names that cannot be resolved).

Defaults Disabled.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Usage Information

Configure the ip domain-list command up to 6 times to configure a list of possible domain names.

If both the ip domain-name and ip domain-list commands are configured, the software will try to resolve the name using the ip domain-name command. If the name is not resolved, the software goes through the list of names configured with the ip domain-list command to find a match.

Use the following steps to enable dynamic resolution of hosts:

- specify a domain name server with the ip name-server command.
- enable DNS with the ip domain-lookup command.

To view current bindings, use the **show hosts** command. To view DNS related configuration, use the **show running-config resolve** command.

Related **Commands**

Specify a DNS server. ip domain-name

ip domain-lookup

CES

Enable dynamic host-name to address resolution (that is, DNS).

Syntax

ip domain-lookup

To disable DNS lookup, use the **no ip domain-lookup**.

Defaults

Disabled.

Command Mode

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Usage Information To fully enable DNS, also specify one or more domain name servers with the ip name-server command.

FTOS does not support sending DNS queries over a VLAN. DNS queries are sent out all other interfaces, including the Management port.

To view current bindings, use the show hosts command.

Related **Commands**

ip name-server	Specify a DNS server.
show hosts	View current bindings.

ip domain-name

CES

Configure one domain name for the switch.

Syntax

ip domain-name name

To remove the domain name, enter **no ip domain-name**.

Parameters

name	Enter one domain name to be used to complete unqualified names (that is,
	incomplete domain names that cannot be resolved).

Defaults

Not configured.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Usage Information

You can only configure one domain name with the ip domain-name command. To configure more than one domain name, configure the ip domain-list command up to 6 times.

Use the following steps to enable dynamic resolution of hosts:

- specify a domain name server with the ip name-server command.
- enable DNS with the ip domain-lookup command.

To view current bindings, use the show hosts command.

Related Commands

ip domain-list	Configure additional names	
ib domain-list	Configure additional names.	
1	<i>8</i>	

ip fib download-igp-only

E

Configure the E-Series to download only IGP routes (for example, OSPF) on to line cards. When the command is configured or removed, it clears the routing table (similar to clear ip route command) and only IGP routes populate the table.

Syntax

ip fib download-igp-only [small-fib]

To return to default setting, use the **no ip fib download-igp-only [small-fib]** command.

Parameters

small-fib	(OPTIONAL) Enter the keyword small-fib to download a smaller FIB table. This option
	is useful on line cards with a limited FIB size.

Defaults

Disabled

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

ip helper-address



Specify the address of a DHCP server so that DHCP broadcast messages can be forwarded when the DHCP server is not on the same subnet as the client.

Syntax

ip helper-address ip-address | default-vrf

To remove a DHCP server address, enter **no ip helper-address**.

Parameters

ip-address Enter an IP address in dotted decimal format (A.B.C.D).	
default-vrf	(Optional) E-Series Only : Enter default-vrf for the DHCP server VRF is using.

Defaults

Not configured.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

You can add multiple DHCP servers by entering the ip helper-address command multiple times. If multiple servers are defined, an incoming request is sent simultaneously to all configured servers and the reply is forwarded to the DHCP client.

FTOS uses standard DHCP ports, that is UDP ports 67 (server) and 68 (client) for DHCP relay services. It listens on port 67 and if it receives a broadcast, the software converts it to unicast, and forwards to it to the DHCP-server with source port=68 and destination port=67.

The server replies with source port=67, destination port=67 and FTOS forwards to the client with source port=67, destination port=68.

ip helper-address hop-count disable

CES

Disable the hop-count increment for the DHCP relay agent.

Syntax

ip helper-address hop-count disable

To reenable the hop-count increment, use the **no ip helper-address hop-count disable** command.

Defaults

Enabled; the hops field in the DHCP message header is incremented by default

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.3.1.0	Introduced for E-Series

Usage Information

This command disables the incrementing of the hops field when boot requests are relayed to a DHCP server through FTOS. If the incoming boot request already has a non-zero hops field, the message will be relayed with the same value for hops. However, the message will be discarded if the hops field exceeds 16, to comply with the relay agent behavior specified in RFC 1542.

Related Commands

ip helper-address	Specify the destination broadcast or host address for DHCP server requests.	
show running-config Display the current configuration and changes from default values.		

ip host

CES

Assign a name and IP address to be used by the host-to-IP address mapping table.

Syntax

ip host name ip-address

To remove an IP host, use the **no ip host** name [ip-address] command.

Parameters

name Enter a text string to associate with one IP address.	
ip-address	Enter an IP address, in dotted decimal format, to be mapped to the name.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ip max-frag-count © E S Set the maxim

Set the maximum number of fragments allowed in one packet for packet re-assembly.

Syntax

ip max-frag-count count

To place no limit on the number of fragments allowed, enter **no ip max-frag-count**.

Parameters

count	Enter a number for the number of fragments allowed for re-assembly.
	Range: 2 to 256

Defaults

No limit is set on number of fragments allowed.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

To avoid Denial of Service (DOS) attacks, keep the number of fragments allowed for re-assembly low.

ip mtu

[E]

Set the IP MTU (frame size) of the packet transmitted by the RPM for the line card interface. If the packet must be fragmented, FTOS sets the size of the fragmented packets to the size specified in this command.

Syntax

ip mtu value

To return to the default IP MTU value, enter **no ip mtu**.

Parameters

value	Enter the maximum MTU size if the IP packet is fragmented.
	Default: 1500 bytes
	Range: 576 to 9234

Defaults

1500 bytes

Command Modes

INTERFACE (Gigabit Ethernet and 10 Gigabit Ethernet interfaces)

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

When you enter no mtu command, FTOS reduces the ip mtu value to 1536 bytes. To return the IP MTU value to the default, enter **no ip mtu**.

You must compensate for Layer 2 header when configuring link MTU on an Ethernet interface or FTOS may not fragment packets. If the packet includes a Layer 2 header, the difference between the link MTU and IP MTU (ip mtu command) must be enough bytes to include for the Layer 2 header.

Link MTU and IP MTU considerations for Port Channels and VLANs are as follows.

Port Channels:

All members must have the same link MTU value and the same IP MTU value.

The Port Channel link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the channel members.

Example: if the members have a link MTU of 2100 and an IP MTU 2000, the Port Channel's MTU values cannot be higher than 2100 for link MTU or 2000 bytes for IP MTU.

VLANs:

- All members of a VLAN must have same IP MTU value.
- Members can have different Link MTU values. Tagged members must have a link MTU 4 bytes higher than untagged members to account for the packet tag.
- The VLAN link MTU and IP MTU must be less than or equal to the link MTU and IP MTU values configured on the VLAN members.

Example: The VLAN contains tagged members with Link MTU of 1522 and IP MTU of 1500 and untagged members with Link MTU of 1518 and IP MTU of 1500. The VLAN's Link MTU cannot be higher than 1518 bytes and its IP MTU cannot be higher than 1500 bytes.

Table 15-2. Difference between Link MTU and IP MTU

Layer 2 Overhead	Difference between Link MTU and IP MTU
Ethernet (untagged)	18 bytes
VLAN Tag	22 bytes
Untagged Packet with VLAN-Stack Header	22 bytes
Tagged Packet with VLAN-Stack Header	26 bytes

Related Commands

mtu Set the link MTU for an Ethernet interface.

ip name-server

CES

Enter up to 6 IP addresses of name servers. The order you enter the addresses determines the order of their use.

Syntax

ip name-server ip-address [ip-address2...ip-address6]

To remove a name server, use the **no ip name-server** *ip-address* command.

Parameters

ip-address	Enter the IP address, in dotted decimal format, of the name server to be used.
ip-address2 ip-address6	(OPTIONAL) Enter up five more IP addresses, in dotted decimal format, of name servers to be used.
	Separate the IP addresses with a space.

Defaults

No name servers are configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

FTOS does not support sending DNS queries over a VLAN. DNS queries are sent out all other interfaces, including the Management port.

ip proxy-arp

CÉS

Enable Proxy ARP on an interface.

Syntax

ip proxy-arp

To disable Proxy ARP, enter **no ip proxy-arp**.

Defaults

Enabled.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.6.1.0	Added support for S-Series	
Version 7.5.1.0	Added support for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	
show ip interface	Displays the interface routing status and configuration.	

Related Commands

show ip interface	Displays the interface routing status and configuration.

ip redirects

Enable the interface to send ICMP redirect messages.

Syntax ip redirects

To return to default, enter **no ip redirects**.

Defaults Disabled

Command Modes INTERFACE

> Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

This command is available for physical interfaces and port-channel interfaces on the E-Series.



Note: This command is not supported on default VLAN (default vlan-id command).

ip route



Assign a static route to the switch.

Syntax

ip route vrf {vrf instance} destination mask {ip-address | interface [ip-address]} [distance] [permanent] [tag tag-value]

To delete a specific static route, use the **no ip route** destination mask { address | interface [ip-address]} command.

To delete all routes matching a certain route, use the **no ip route** destination mask command.

Parameters

vrf name	(OPTIONAL) E-Series Only : Enter the keyword vrf followed by the VRF Instances name to tie the static route to the VRF instance.	
destination	Enter the IP address in dotted decimal format of the destination device.	
mask	Enter the mask in slash prefix formation (/x) of the destination device's IP address.	
ip-address	Enter the IP address in dotted decimal format of the forwarding router.	

interface	Enter the following keywords and slot/port or number information:	
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.	
	 For a loopback interface, enter the keyword loopback followed by a number from zero (0) to 16383. 	
	• For the null interface, enter the keyword null followed by zero (0).	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 255 for TeraScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
	 For a VLAN, enter the keyword vlan followed by a number from 1 to 4094. 	
distance	(OPTIONAL) Enter a number as the distance metric assigned to the route.	
	Range: 1 to 255	
permanent	(OPTIONAL) Enter the keyword permanent to specify the route is not removed, even if the interface assigned to that route goes down. The route must be up initially install it in the routing table.	
	If you disable the interface with an IP address associated with the keyword permanent , the route disappears from the routing table.	
tag tag-value	(OPTIONAL) Enter the keyword tag followed by a number to assign to the route. Range: 1 to 4294967295	

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Using the following example of a static route:

ip route 33.33.33.0 /24 gigabitethernet 0/0 172.31.5.43

- The software installs a next hop that is not on the directly connected subnet but which recursively resolves to a next hop on the interface's configured subnet. In the example, if gig 0/0 has ip address on subnet 2.2.2.0 and if 172.31.5.43 recursively resolves to 2.2.2.0, FTOS installs the static route.
- When the interface goes down, FTOS withdraws the route.
- When the interface comes up, FTOS re-installs the route.
- When recursive resolution is "broken," FTOS withdraws the route.
- When recursive resolution is satisfied, FTOS re-installs the route.

Related **Commands**

View the switch routing table. show ip route

ip source-route

CES Enable FTOS to forward IP packets with source route information in the header.

Syntax ip source-route

To drop packets with source route information, enter **no ip route-source**.

Defaults Enabled.

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ip unreachables

Enable the generation of Internet Control Message Protocol (ICMP) unreachable messages.

Syntax ip unreachables

To disable the generation of ICMP messages, enter **no ip unreachables**.

Defaults Disabled

Command Modes INTERFACE

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced on E-Series

ip vlan-flooding

 \mathbb{E} Enable unicast data traffic flooding on VLAN member ports.

Syntax ip vlan-flooding

To disable, use the **no ip vlan-flooding** command.

Defaults disabled

Command Modes

CONFIGURATION

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Introduced on E-Series

Usage Information

By default this command is disabled. When enabled, all the Layer 3 unicast routed data traffic going through a VLAN member port is flooded across all the member ports of that VLAN. There might be some ARP table entries which are resolved through ARP packets which had Ethernet MAC SA different from MAC information inside the ARP packet. This unicast data traffic flooding occurs only for those packets which use these ARP entries.

load-balance (C-Series and S-Series)

CS

By default for C-Series and S-Series, FTOS uses an IP 4-tuple (IP SA, IP DA, Source Port, and Destination Port) to distribute IP traffic over members of a Port Channel as well as equal-cost paths. To designate another method to balance traffic over Port Channel members, use the load-balance command.

Syntax

load-balance {ip-selection [dest-ip | source-ip]} | {mac [dest-mac | source-dest-mac |
source-mac]} | {tcp-udp [enable]}

To return to the default setting (IP 4-tuple), use the **no** version of the command.

Parameters

ip-selection {dest-ip	Enter the keywords to distribute IP traffic based on the following criteria:
source-ip}	• dest-ip —Uses destination IP address and destination port fields to hash. The hashing mechanism returns a 3-bit index indicating which port the packet should be forwarded to.
	 source-ip—Uses source IP address and source port fields to hash. The hashing mechanism returns a 3-bit index indicating which port the packet should be forwarded to.
mac {dest-mac	Enter the keywords to distribute MAC traffic based on the following criteria:
source-dest-mac source-mac}	• dest-mac —Uses the destination MAC address, VLAN, Ethertype, source module ID and source port ID fields to hash. The hashing mechanism returns a 3-bit index indicating which port the packet should be forwarded to.
	• source-dest-mac —Uses the destination and source MAC address, VLAN, Ethertype, source module ID and source port ID fields to hash. The hashing mechanism returns a 3-bit index indicating which port the packet should be forwarded to.
	 source-mac—Uses the source MAC address, VLAN, Ethertype, source module ID and source port ID fields to hash. The hashing mechanism returns a 3-bit index indicating which port the packet should be forwarded to.
tcp-udp enable	Enter the keywords to distribute traffic based on the following:
	 enable—Takes the TCP/UDP source and destination ports into consideration when doing hash computations. (By default, this is enabled)

Defaults

IP 4-tuple (IP SA, IP DA, Source Port, Destination Port)

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Introduced on C-Series

Usage Information

By default, FTOS distributes incoming traffic based on a hash algorithm using the following criteria:

- IP source address
- IP destination address
- TCP/UDP source port
- TCP/UDP destination port

load-balance (E-Series)

(E)By default, for E-Series chassis, FTOS uses an IP 5-tuple to distribute IP traffic over members of a Port Channel as well as equal cost paths. To designate another method to balance traffic over Port Channel members, use the load-balance command.

Syntax load-balance [ip-selection 3-tuple | ip-selection packet-based] [mac]

To return to the default setting (IP 5-tuple), use one of the following commands:

- no load-balance ip-selection 3-tuple
- no load-balance ip-selection packet-based
- no load-balance mac

Parameters

ip-selection 3-tuple	Enter the keywords ip-selection 3-tuple to distribute IP traffic based on the following criteria:		
	• IP source address		
	IP destination address		
	IP Protocol type		
	Note: For IPV6, only the first 32 bits (LSB) of IP SA and IP DA are used for hash generation.		
ip-selection packet-based	Enter the keywords ip-selection packet-based to distribute IPV4 traffic based on the IP Identification field in the IPV4 header.		
	This option does <i>not</i> affect IPV6 traffic; that is, IPV6 traffic is not distributed when this command is executed.		
	Note: Hash-based load-balancing on MPLS does not work when packet-based hashing (load-balance ip-selection packet-based) is enabled.		
mac	Enter the keyword mac to distribute traffic based on the following:		
	MAC source address, and		
	MAC destination address.		

Defaults

IP 5-tuple (IP SA, IP DA, IP Protocol Type, Source Port and Destination Port)

Command Modes

CONFIGURATION

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 6.1.1.0	Introduced for E-Series

Usage Information

By default, FTOS distributes incoming traffic based on a hash algorithm using the following criteria:

- IP source address
- IP destination address
- IP Protocol type
- TCP/UDP source port
- TCP/UDP destination port



Note: For IPV6, only the first 32 bits (LSB) of IP Source Address and IP Destination Address are used for hash generation.

The table below lists the load balance command options and how the command combinations effect the distribution of traffic.

Table 15-3. Configurations of the load-balance Command

Configuration	Switched IP Traffic	Routed IP Traffic (IPV4 Only)	Switched Non-IP Traffic
Default (IP 5-tuple)	IP 5-tuple	IP 5-tuple	MAC based
ip-selection 3-tuple	IP 3-tuple	IP 3-tuple	MAC based
mac	MAC based	IP 5-tuple	MAC based
ip-selection 3-tuple and mac	MAC based	IP 3-tuple	MAC based
ip-selection packet-based	Packet based: IPV4 No distribution: IPV6	Packet based: IPV4	MAC based
ip-selection packet-based and mac	MAC based	Packet based: IPV4	MAC based

Related
Commands

ip address Change the algorithm used to distribute traffic on an E-Series chassis.

management route

CE S55

Configure a static route that points to the Management interface or a forwarding router.

(S60)

Syntax management route ip-address mask {forwarding-router-address | managementethernet}

To remove a static route, use the **no management route** *ip-address mask* { forwarding-router-address | managementethernet } command.

Parameters

ip-address mask	Enter an IP address (dotted decimal format) and mask (/prefix format) as the IP address for the Management interface.	
forwarding-router-address	Enter an IP address (dotted decimal format) of a forwarding router.	
managementethernet	Enter the keyword managementethernet for the Management interface on the Primary RPM.	

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.5.0	Introduced on S55.
Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

When a static route (or a protocol route) overlaps with Management static route, the static route (or a protocol route) is preferred over the Management Static route. Also, Management static routes and the Management Connected prefix are not reflected in the hardware routing tables.

Related Commands

interface ManagementEthernet	Configure the Management port on the system (either the Primary or Standby RPM).
duplex (Management)	Set the mode of the Management interface.
speed (Management interface)	Set the speed for the Management interface.

show arp



Display the ARP table.

Syntax

 $\textbf{show arp [vrf} \ \textit{vrf name}] [\textbf{interface interface} \ | \ \textbf{ip ip-address [mask]} \ | \ \textbf{macaddress mac-address} \\$ [mac-address mask]] [cpu {cp | rp1 | rp2}] [static | dynamic] [summary]

Parameters

vrf name	E-Series Only: Show only the ARP cache entries tied to the VRF process.		
сри	(OPTIONAL) Enter the keyword cpu with one of the following keywords to view ARP entries on that CPU:		
	• cp - view ARP entries on the control processer.		
	• rp1 - view ARP entries on Routing Processor 1.		
	• rp2 - view ARP entries on Routing Processor 2.		
interface interface	(OPTIONAL) Enter the following keywords and slot/port or number information:		
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.		
	 For the Management interface, enter the keyword managementethernet followed by the slot/port information. 		
	• For a Port Channel interface, enter the keyword port-channel followed by a number:		
	C-Series and S-Series Range: 1-128		
	E-Series Range: 1 to 255 for TeraScale.		
	• For a SONET interface, enter the keyword sonet followed by the slot/port information.		
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 		
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.		
ip ip-address mask	(OPTIONAL) Enter the keyword ip followed by an IP address in the dotted decimal format. Enter the optional IP address mask in the slash prefix format (/ x).		

macaddress mac-address mask	(OPTIONAL) Enter the keyword macaddress followed by a MAC address in nn:nn:nn:nn:nn:nn format. Enter the optional MAC address mask in nn:nn:nn:nn:nn format also.
static	(OPTIONAL) Enter the keyword static to view entries entered manually.
dynamic	(OPTIONAL) Enter the keyword dynamic to view dynamic entries.
summary	(OPTIONAL) Enter the keyword summary to view a summary of ARP entries.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Support 4094 VLANs on E-Series ExaScale (prior limit was 2094)
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.8.1.0	Augmented to display local ARP entries learned from private VLANs (PVLANs)
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The following figure shows two VLANs that are associated with a private VLAN (PVLAN) (see Chapter 29, Private VLAN (PVLAN)), a feature added for C-Series and S-Series in FTOS 7.8.1.0.

Example

Figure 15-5. show arp Command Example (Partial)

Protocol	Address	Age(min)	Hardware Address	Interface	VLAN	CP
Internet	192.2.1.254	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.253	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.252	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.251	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.250	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.251	1	00:00:c0:02:01:02	Gi 9/13	-	CP
nternet	192.2.1.250	1	00:00:c0:02:01:02	Gi 9/13	-	CP
internet	192.2.1.249	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.248	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.247	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.246	1	00:00:c0:02:01:02	Gi 9/13	-	CP
Internet	192.2.1.245	1	00:00:c0:02:01:02	Gi 9/13	-	CP

Figure 15-6. show arp Command Example with Private VLAN data




Figure 15-7. show arp cpu cp Command Example




Table 15-4. show arp Command Example Fields

Row Heading	Description
Protocol	Displays the protocol type.
Address	Displays the IP address of the ARP entry.
Age(min)	Displays the age in minutes of the ARP entry.
Hardware Address	Displays the MAC address associated with the ARP entry.
Interface	Displays the first two letters of the interfaces type and the slot/port associated with the ARP entry.
VLAN	Displays the VLAN ID, if any, associated with the ARP entry.
CPU	Lists which CPU the entries are stored on.

Figure 15-8. show arp summary Command Example

```
FTOS# show arp summary
Total Entries
              Static Entries Dynamic Entries CPU
83
                                               CP
FTOS
```

Table 15-5. show arp summary Command Example Fields

Row Heading	Description
Total Entries	Lists the total number of ARP entries in the ARP table.
Static Entries	Lists the total number of configured or static ARP entries.
Dynamic Entries	Lists the total number of learned or dynamic ARP entries.
CPU	Lists which CPU the entries are stored on.

Related Commands

ip local-proxy-arp	Enable/disable Layer 3 communication in secondary VLANs.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

show arp retries

CES

Display the configured number of ARP retries.

Syntax show arp retries

Command Modes EXEC

EXEC Privilege

Command History

Related Commands

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Introduced
arp retries	Set the number of ARP retries in case the system does not receive an ARP reply in response to an ARP request.

show hosts

CES

View the host table and DNS configuration.

Syntax show hosts

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 15-9. show hosts Command Example

```
FTOS#show hosts
Default domain is not set
Name/address lookup uses static mappings
Name servers are not set
                                                                     TTL
                                                  Flags
                                                                                       Type Address
Host
                                                                        ----

    (perm, OK) -
    IP
    2.2.2.2

    (perm, OK) -
    IP
    192.68.69.2

    (perm, OK) -
    IP
    192.68.99.2

    (perm, OK) -
    IP
    192.71.18.2

    (perm, OK) -
    IP
    192.71.23.1

ks
4200-1
1230-3
ZZr
Z10-3
FTOS#
```

Table 15-6. show hosts Command Example Fields

Field	Description	
Default domain	Displays the domain name (if configured).	
Name/address lookup	States if DNS is enabled on the system. If DNS is enabled, the Name/Address lookup is domain service. If DNS is not enabled, the Name/Address lookup is static mapping.	
Name servers are	Lists the name servers, if configured.	
Host	Displays the host name assigned to the IP address.	
Flags	Classifies the entry as one of the following: • perm - the entry was manually configured and will not time out • temp - the entry was learned and will time out after 72 hours of inactivity. Also included in the flag is an indication of the validity of the route: • ok - the entry is valid. • ex - the entry expired. • ?? - the entry is suspect.	
TTL	Displays the amount of time until the entry ages out of the cache. For dynamically learnt entries only.	
Туре	Displays IP as the type of entry.	
Address	Displays the IP address(es) assigned to the host.	

Related **Commands**

traceroute	View DNS resolution	
ip host	Configure a host.	

show ip cam linecard

[C][E]View CAM entries for a port pipe on a line card.

Syntax show ip cam linecard number port-set pipe-number [ip-address mask [longer-prefixes] | **index** *index-number* | **summary** | **vrf** *vrf instance*]

Parameters

number	Enter the number of the line card.
	Range: 0 to 13 on a E1200/1200i, 0 to 6 on a E600600i, and 0 to 5 on a E300.
pipe-number	Enter the number of the line card's port-pipe.
	Range: 0 to 1
ip-address mask	(OPTIONAL) Enter the IP address and mask of a route to CAM entries for that route
[longer-prefix]	only.
	Enter the keyword longer-prefixes to view routes with a common prefix.
index	(OPTIONAL) Enter the keyword index followed by the CAM index number.
index-number	Range: depends on CAM size
summary	(OPTIONAL) Enter the keyword summary to view a table listing route prefixes and the total number of routes that can be entered into the CAM.
vrf instance	(OPTIONAL) E-Series Only : Enter the keyword vrf following by the VRF Instance name to show CAM information as it applies to that VRF instance.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.2	E-Series ExaScale E600i supported
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 15-10. show ip cam Command Example on E-Series

5.5.5.2	_ E 	d 13 port	Next-Hop	-	VId	Mac-Addr		Port
6.6.6.2 5.5.5.2	 0			-	VId	Mac-Addr		Port
5.5.5.2	-	0 1 1	0.0.0.0	-				
	Λ			0	00:00:00	:00:00:00	 17c1	CP
	U	0 1 1	0.0.0.0	0	00:00:00:	:00:00:00	17c1	CP
4.4.4.2	0	0 1 1	0.0.0.0	0	00:00:00:	:00:00:00	17c1	CP
3.3.3.2	0	0 1 1	0.0.0.0	0	00:00:00	:00:00:00	17c1	CP
2.2.2.2	0	0 1 1	0.0.0.0	0	00:00:00:	:00:00:00	17c1	CP
6.6.6.0	0	0 1 1	0.0.0.0	6	00:00:00:	:00:00:00	17c5	RP2
5.5.5.0	0	0 1 1	0.0.0.0	5	00:00:00:	:00:00:00	17c5	RP2
4.4.4.0	0	0 1 1	0.0.0.0	4	00:00:00:	:00:00:00	17c5	RP2
3.3.3.0	0	0 1 1	0.0.0.0	3	00:00:00:	:00:00:00	17c5	RP2
2.2.2.0	0	0 1 1	0.0.0.0	2	00:00:00:	:00:00:00	17c5	RP2
0.0.0.0	0	0 1 1	0.0.0.0	0	00:00:00:	:00:00:00	17c5	RP2
	3.3.3.2 2.2.2.2 6.6.6.0 5.5.5.0 4.4.4.0 3.3.3.0 2.2.2.0	3.3.3.2 0 2.2.2.2 0 6.6.6.0 0 5.5.5.0 0 4.4.4.0 0 3.3.3.0 0 2.2.2.0 0	3.3.3.2 0 0 1 1 2.2.2.2 0 0 1 1 6.6.6.0 0 0 1 1 5.5.5.0 0 0 1 1 4.4.4.0 0 0 1 1 3.3.3.0 0 0 1 1 2.2.2.0 0 0 1 1	3.3.3.2 0 0 1 1 0.0.0.0 2.2.2.2 0 0 1 1 0.0.0.0 6.6.6.0 0 0 1 1 0.0.0.0 5.5.5.0 0 0 1 1 0.0.0.0 4.4.4.0 0 0 1 1 0.0.0.0 3.3.3.0 0 0 1 1 0.0.0.0 2.2.2.0 0 0 1 1 0.0.0.0	3.3.3.2 0 0 1 1 0.0.0.0 0 2.2.2.2 0 0 1 1 0.0.0.0 0 6.6.6.0 0 0 1 1 0.0.0.0 6 5.5.5.0 0 0 1 1 0.0.0.0 5 4.4.4.0 0 0 1 1 0.0.0.0 4 3.3.3.0 0 0 1 1 0.0.0.0 3 2.2.2.0 0 0 1 1 0.0.0.0 2	3.3.3.2 0 0 1 1 0.0.0.0 0 00:00:00:00:00:00:00:00:00:00:00:00:	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	3.3.3.2 0 0 1 1 0.0.0.0 0 00:00:00:00:00:00:00 17c1 2.2.2.2 0 0 1 1 0.0.0.0 0 00:00:00:00:00:00:00 17c1 6.6.6.0 0 0 1 1 0.0.0.0 6 00:00:00:00:00:00 17c5 5.5.5.0 0 0 1 1 0.0.0.0 5 00:00:00:00:00:00 17c5 4.4.4.0 0 0 1 1 0.0.0 4 00:00:00:00:00:00 17c5 3.3.3.0 0 0 1 1 0.0.0 3 00:00:00:00:00:00 17c5 2.2.2.0 0 0 1 1 0.0.0.0 2 00:00:00:00:00:00 17c5

Table 15-7. show ip cam Command Example Fields

Field	Description
Index	Displays the CAM index number of the entry.
Destination	Displays the destination route of the index.
EC	Displays the number of equal cost multipaths (ECMP) available for the default route for non-Jumbo line cards. Displays 0,1 when ECMP is more than 8, for Jumbo line cards.
CG	Displays 0.
V	Displays a 1 if the entry is valid and a 0 if the entry is for a line card with Catalog number beginning with LC-EF.

Table 15-7. show ip cam Command Example Fields (continued)

Field	Description
С	Displays the CPU bit. 1 indicates that a packet hitting this entry is forwarded to the CP or RP2, depending on
Next-Hop	Egress port. Displays the next hop IP address of the entry.
VId	Displays the VLAN ID. If the entry is 0, the entry is not part of a VLAN.
Mac Addr	Displays the next-hop router's MAC address.
Port	Displays the egress interface. Use the second half of the entry to determine the interface. For example, in the entry 17cl CP, the CP is the pertinent portion. CP = control processor
	RP2 = route processor 2
	Gi = Gigabit Ethernet interface
	So = SONET interface
	Te = 10 Gigabit Ethernet interface

Example Figure 15-11. show ip cam summary Command Example




Table 15-8. show ip cam summary Command Example Fields

Field	Description
Prefix Length	Displays the prefix-length or mask for the IP address configured on the linecard 0 port pipe 0.
Current Use	Displays the number of routes currently configured for the corresponding prefix or mask on the linecard 0 port pipe 0.
Initial Size	Displays the CAM size allocated by FTOS for the corresponding mask. The CAM size is adjusted by FTOS if the number of routes for the mask exceeds the initial allocation.

show ip cam stack-unit

S Display content-addressable memory (CAM) entries for an S-Series switch.

Syntax show ip cam stack-unit id port-set pipe-number [ip-address mask [longer-prefixes] | summary]

Parameters

id	Enter the stack-unit ID.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
pipe-number	Enter the number of the Port-Pipe number.
	S50n, S50V range: 0 to 1; S25N, S25P, S25V range: 0 to 0
ip-address mask [longer-prefix]	(OPTIONAL) Enter the IP address and mask of a route to CAM entries for that route only.
	Enter the keyword longer-prefixes to view routes with a common prefix.
summary	(OPTIONAL) Enter the keyword summary to view a table listing route prefixes and the total number routes which can be entered in to CAM.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Modified: Added support for up to seven stack members.
Version 7.6.1.0	Introduced on S-Series

Example

Figure 15-12. show ip cam stack-unit Command Example




Table 15-9. show ip cam Command Example Fields

Field	Description
Destination	Displays the destination route of the index.
EC	Displays the number of equal cost multipaths (ECMP) available for the default route for non-Jumbo line cards. Displays 0,1 when ECMP is more than 8, for Jumbo line cards.
CG	Displays 0.
V	Displays a 1 if the entry is valid and a 0 otherwise.
С	Displays the CPU bit. 1 indicates that a packet hitting this entry is forwarded to the control processor, depending on Egress port.
V Id	Displays the VLAN ID. If the entry is 0, the entry is not part of a VLAN.
Mac Addr	Displays the next-hop router's MAC address.
Port	Displays the egress interface. Use the second half of the entry to determine the interface. For example, in the entry 17cl CP, the CP is the pertinent portion. CP = control processor Gi = Gigabit Ethernet interface Te = 10 Gigabit Ethernet interface

show ip fib linecard

(C) (E) View all Forwarding Information Base (FIB) entries.

show ip fib linecard *slot-number* [**vrf** *vrf instance* | *ip-address/prefix-list* | **summary**]

Parameters

Syntax

vrf instance	(OPTIONAL) E-Series Only : Enter the keyword vrf followed by the VRF INstance name to show the FIB cache entries tied to that VRF instance.
slot-number	Enter the number of the line card slot.
	C-Series Range: 0-7
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, 0 to 5 on a E300
ip-address mask	(OPTIONAL) Enter the IP address of the network destination to view only information on that destination.
	You must enter the IP address is dotted decimal format (A.B.C.D). You must enter the mask in slash prefix format (/X).
longer-prefixes	(OPTIONAL) Enter the keyword longer-prefixes to view all routes with a common prefix.
summary	(OPTIONAL) Enter the keyword summary to view the total number of prefixes in the FIB.

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 15-13. show ip fib linecard Command Example

Destination	Gateway	First-Hop	Mac-Addr	Port	VId	Inde
3.0.0.0/8	via 100.10.10.10, So 2/8 via 101.10.10.10, So 2/9	100.10.10.10	00:01:e8:00:03:ff	So 2/8	0	60260
100.10.10.0/24	Direct, So 2/8	0.0.0.0	00:01:e8:00:03:ff	So 2/8	0	1114
100.10.10.1/32	via 127.0.0.1	127.0.0.1	00:00:00:00:00:00	CP	0	327
100.10.10.10/32	via 100.10.10.10, So 2/8	100.10.10.10	00:01:e8:00:03:ff	So 2/8	0	
101.10.10.0/24	Direct, So 2/9	0.0.0.0	00:00:00:00:00:00	RP2	0	1114
101.10.10.1/32	via 127.0.0.1	127.0.0.1	00:00:00:00:00:00	CP	0	327
101.10.10.10/32	via 101.10.10.10, So 2/9	101.10.10.10	00:01:e8:01:62:32	So 2/9	0	

Table 15-10. show ip fib linecard Command Example Fields

Field	Description
Destination	Lists the destination IP address.
Gateway	Displays either the word direct and an interface for a directly connected route or the remote IP address to be used to forward the traffic.
First-Hop	Displays the first hop IP address.
Mac-Addr	Displays the MAC address.
Port	Displays the egress-port information.
VId	Displays the VLAN ID. If no VLAN is assigned, zero (0) is listed.
Index	Displays the internal interface number.
EC	Displays the number of ECMP paths.

Related Commands

clear ip fib linecard Clear FIB entries on a specified line card.

show ip fib stack-unit

S View all Forwarding Information Base (FIB) entries.

Syntax show ip fib stack-unit *id* [*ip-address* [*mask*] [**longer-prefixes**] | **summary**]

Parameters

id	Enter the S-Series stack unit ID.Unit ID range:	
	S60 : 0-11	
	all other S-Series: 0-7	
ip-address mask	(OPTIONAL) Enter the IP address of the network destination to view only information on that destination.	
	Enter the IP address in dotted decimal format (A.B.C.D). You must enter the mask in slash prefix format (/X).	

longer-prefixes	(OPTIONAL) Enter the keyword longer-prefixes to view all routes with a common prefix.
summary	(OPTIONAL) Enter the keyword summary to view the total number of prefixes in the FIB.

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Modified: Added support for up to seven stack members.
Version 7.6.1.0	Introduced on S-Series

Example

Figure 15-14. show ip fib linecard Command Example




Table 15-11. show ip fib linecard Command Example Fields

Field	Description	
Destination	Lists the destination IP address.	
Gateway	Displays either the word Direct and an interface for a directly connected route or the remote IP address to be used to forward the traffic.	
First-Hop	Displays the first hop IP address.	
Mac-Addr	Displays the MAC address.	
Port	Displays the egress-port information.	
VId	Displays the VLAN ID. If no VLAN is assigned, zero (0) is listed.	
EC	Displays the number of ECMP paths.	

Related Commands

clear ip fib linecard	Clear FIB entries on a specified line card.	

show ip flow

CES

Show how a Layer 3 packet is forwarded when it arrives at a particular interface.

Syntax

show ip flow interface [vrf vrf instance] interface {source-ip address destination-ip address} {protocol number [tcp | udp] | icmp} {src-port number destination-port number}

Parameters

vrf instance	E-Series Only : Show only the L3 flow as they apply to that VRF process.	
interface interface	Enter the keyword interface followed by of the following interface keywords.	
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information. 	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a SONET interface, enter the keyword sonet followed by the slot port information. 	
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.	
	(OPTIONAL) Enter an in or out parameter in conjunction with the optional interface:	
source-ip address	Enter the keyword source-ip followed by the IP source address in IP address format.	
destination-ip address	Enter the keyword destination-ip followed by the IP destination address in IP address format.	
protocol number [tcp udp] icmp	E-Series only: Enter the keyword protocol followed by one of the protocol type	
	keywords: tcp, udp, icmp or protocol number	
src-port number	Enter the keyword src-port followed by the source port number.	
destination-port number	Enter the keyword destination-port followed by the destination port number.	

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

This command provides egress port information for a given IP flow. This is useful in identifying which interface the packet will follow in the case of Port-channel and Equal Cost Multi Paths. Use this command for routed packed only. For switched packets use the snow.port-channel-flow command

show ip flow does not compute the egress port information when **load-balance mac hashing** is also configured due to insufficient information (the egress MAC is not available).

S-Series produces the following error message:

%Error: Unable to read IP route table

C-Series produces the message:

%Error: FIB cannot compute the egress port with the current trunk hash setting.

Example Figure 15-15. Command Example show ip flow on E-Series

FTOS#show ip flow interface Gi 1/8 189.1.1.1 63.0.0.1 protocol tcp source-port 7898 destination-port 89%

flow: 189.1.1.1 63.0.0.1 protocol 6 7868 8976

Ingress interface: Gi 1/20
Egress interface: Gi 1/14 to 1.7.1.2 [CAM hit 103710] unfragmented packet
Gi 1/10 to 1.2.1.2 [CAM hit 103710] fragmented packet

show ip interface

CES

View IP-related information on all interfaces.

ameter		
	interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
		• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
		 For a Loopback interface, enter the keyword Loopback followed by a number from 0 to 16383.
		• For the Management interface, enter the keyword ManagementEthernet followed by zero (0).
		• For the Null interface, enter the keyword null followed by zero (0).
		 For a Port Channel interface, enter the keyword port-channel followed by a number:
		C-Series and S-Series Range: 1-128
		E-Series Range: 1 to 255 for TeraScale.
		 For a SONET interface, enter the keyword sonet followed by the slot/port information.
		 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
		 For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
	brief	(OPTIONAL) Enter the keyword brief to view a brief summary of the interfaces and whether an IP address is assigned.
	linecard slot-number	(OPTIONAL) Enter the keyword linecard followed by the number of the line card slot.
		C-Series Range: 0-7
		E-Series Range: 0 to 13 on a E1200/1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a E300
		Note: This keyword is not available on the S-Series.
	configuration	(OPTIONAL) Enter the keyword configuration to display the physical interfaces with non-default configurations only.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 8.1.1.2	Supported on E-Series ExaScale E600i	
Version 8.1.1.0	Introduced on E-Series ExaScale	

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 15-16. show ip interface Command Example

```
FTOS#show ip int te 0/0
TenGigabitEthernet 0/0 is down, line protocol is down
Internet address is not set
IP MTU is 1500 bytes
Inbound access list is not set
Proxy ARP is enabled
Split Horizon is enabled
Poison Reverse is disabled
ICMP redirects are not sent
ICMP unreachables are not sent
```

Table 15-12. show ip interface Command Example Items

Lines	Description	
TenGigabitEthernet 0/0	Displays the interface's type, slot/port and physical and line protocol status.	
Internet address	States whether an IP address is assigned to the interface. If one is, that address is displayed.	
IP MTU is	Displays IP MTU value.	
Inbound access	Displays the name of the any configured incoming access list. If none is configured, the phrase "not set" is displayed.	
Proxy ARP	States whether proxy ARP is enabled on the interface.	
Split horizon	States whether split horizon for RIP is enabled on the interface.	
Poison Reverse	States whether poison for RIP is enabled on the interface	
ICMP redirects	States if ICMP redirects are sent.	
ICMP unreachables	States if ICMP unreachable messages are sent.	

Figure 15-17. show ip interface brief Command Example (Partial)

FTOS#show ip int brief						`
Interface	IP-Address	OK?	${\tt Method}$	Status		Protocol
GigabitEthernet 1/0	unassigned	NO	Manual	administratively	down	down
GigabitEthernet 1/1	unassigned	NO	Manual	administratively	down	down
GigabitEthernet 1/2	unassigned	YES	Manual	up		up
GigabitEthernet 1/3	unassigned	YES	Manual	up		up
GigabitEthernet 1/4	unassigned	YES	Manual	up		up
GigabitEthernet 1/5	10.10.10.1	YES	Manual	up		up
GigabitEthernet 1/6	unassigned	NO	Manual	administratively	down	down

Table 15-13. show ip interface brief Column Headings

Field	Description
Interface	Displays type of interface and the associated slot and port number.
IP-Address	Displays the IP address for the interface, if configured.
Ok?	Indicates if the hardware is functioning properly.
Method	Displays Manual if the configuration is read from the saved configuration.
Status	States whether the interface is enabled (up) or disabled (administratively down).
Protocol	States whether IP is enabled (up) or disabled (down) on the interface.

show ip management-route

CE S55

View the IP addresses assigned to the Management interface.

(S60)

Syntax

show ip management-route [all | connected | summary | static]

Parameters

all	(OPTIONAL) Enter the keyword all to view all IP addresses assigned to all Management interfaces on the switch.
connected	(OPTIONAL) Enter the keyword connected to view only routes directly connected to the Management interface.
summary	(OPTIONAL) Enter the keyword summary to view a table listing the number of active and non-active routes and their sources.
static	(OPTIONAL) Enter the keyword static to view non-active routes also.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.5.0	Introduced on S55.
Version 8.3.3.1	Introduced on S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 15-18. show ip management route Command Example

FTOS#show ip management-route Destination Gateway State ManagementEthernet 0/0 10.1.2.4 10.1.2.0/24 Connected 172.16.1.0/24 Active FTOS#

show ip protocols

CES View information on all routing protocols enabled and active on the switch.

Syntax show ip protocols

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Regular evaluation optimization enabled/disabled added to display output
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 15-19. show ip protocols Command Example

```
FTOS#show ip protocols
Routing Protocol is "bgp 1"
Cluster Id is set to 20.20.20.3
Router Id is set to 20.20.20.3
Fast-external-fallover enabled
Regular expression evaluation optimization enabled
Capable of ROUTE REFRESH
For Address Family IPv4 Unicast
BGP table version is 0, main routing table version 0
Distance: external 20 internal 200 local 200
Neighbor(s):
Address: 20.20.20.2
Filter-list in: foo
Route-map in: foo
Weight: 0
Address: 5::6
Weight: 0
FTOS#
```

show ip route

CES View information, including how they were learned, about the IP routes on the switch.

Syntax show ip route [vrf [vrf name] hostname | ip-address [mask] [longer-prefixes] | list prefix-list | protocol [process-id | routing-tag] | all | connected | static | summary]

Parameter

vrf name	E-Series Only : Clear only the route entries tied to the VRF process.		
ip-address	(OPTIONAL) Specify a name of a device or the IP address of the device to view more detailed information about the route.		
mask	(OPTIONAL) Specify the network mask of the route. Use this parameter with the IP address parameter.		
longer-prefixes	(OPTIONAL) Enter the keyword longer-prefixes to view all routes with a common prefix.		
list prefix-list	(OPTIONAL) Enter the keyword list and the name of a configured prefix list. See show ip route list.		

protocol	(OPTIONAL) Enter the name of a routing protocol (bgp , isis , ospf , rip) or the keywords connected or static .		
	bgp, isis, ospf, rip are E-Series-only options.		
	If you enter bgp , you can include the BGP as-number. (E-Series only)		
	If you enter isis , you can include the ISIS <i>routing-tag</i> . (E-Series only)		
	If you enter ospf , you can include the OSPF <i>process-id</i> .		
process-id	(OPTIONAL) Specify that only OSPF routes with a certain process ID must be displayed.		
routing-tag	(OPTIONAL) Specify that only ISIS routes with a certain routing tag must be displayed.		
connected	(OPTIONAL) Enter the keyword connected to view only the directly connected routes.		
all	(OPTIONAL) Enter the keyword all to view both active and non-active routes.		
static	(OPTIONAL) Enter the keyword static to view only routes configured by the ip route command.		
summary	(OPTIONAL) Enter the keyword summary. See show ip route summary.		

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.9.1.0	Introduced VRF on the E-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 15-20. show ip route all Command Example

```
FTOS#show ip route all
Codes: C - connected, S - static, R - RIP
B - BGP, IN - internal BGP, EX - external BGP, LO - Locally Originated
O - OSPF, IA - OSPF inter area N1 - OSPF NSSA external type 1
N2 - OSPF NSSA external type 2, E1 - OSPF external type 1
E2 - OSPF external type 2, i - IS-IS, L1 - IS-IS level-1
L2 - IS-IS level-2, IA - IS-IS inter area, * - candidate default
> - non-active route + - summary route
Gateway of last resort is not set
             Destination
                                                                                                     Dist/Metric Last Change
                                               Gateway
                                                via 100.10.10.10, So 2/8 via 101.10.10.10, So 2/9
             3.0.0.0/8
                                                                                                          120/1 00:07:12
   R
             100.10.10.0/24
                                                Direct, So 2/8
                                                                                                                    0/0
                                                                                                                                 00:08:54
            100.10.10.0/24
101.10.10.0/24
                                                Direct, So 2/8
Direct, So 2/9
> R
                                                                                                                 120/0
                                                                                                                                   00:08:54
   C
                                                                                                                    0/0
                                                                                                                                   00:09:15
             101.10.10.0/24
> R
                                                Direct, So 2/9
                                                                                                                  120/0
                                                                                                                                   00:09:15
FTOS#
```

Example Figure 15-21. show ip route summary and show ip route static Command Examples

```
FTOS#show ip route summary
Route Source
                       Active Routes
                                     Non-active Routes
connected
static
                                      0
Total
Total 3 active route(s) using 612 bytes
R1_E600i>show ip route static ?
                    Pipe through a command
R1 E600i>show ip route static
     Destination Gateway
                                                Dist/Metric Last Change
    0.0.0.0/0
                                                 1/0 3d
                     -----
via 10.10.91.9, Gi 1/2
*S
                                                                3d2h
FTOS>
```

Table 15-14. show ip route all Command Example Fields

Field	Description		
(undefined)	Identifies the type of route:		
	• C = connected		
	• S = static		
	• R = RIP		
	• B = BGP		
	• IN = internal BGP		
	• EX = external BGP		
	• LO = Locally Originated		
	• O = OSPF		
	• IA = OSPF inter area		
	• N1 = OSPF NSSA external type 1		
	• N2 = OSPF NSSA external type 2		
	• E1 = OSPF external type 1		
	• E2 = OSPF external type 2		
	• i = IS-IS		
	• L1 = IS-IS level-1		
	• L2 = IS-IS level-2		
	• IA = IS-IS inter-area		
	• * = candidate default		
	• >= non-active route		
	• += summary routes		
Destination	Identifies the route's destination IP address.		
Gateway	Identifies whether the route is directly connected and on which interface the route is configured.		
Dist/Metric	Identifies if the route has a specified distance or metric.		
Last Change	Identifies when the route was last changed or configured.		

show ip route list

CES Display IP routes in an IP prefix list.

Syntax show ip route list prefix-list

Parameters

prefix-list	Enter the name	e of a configured	d prefix list.
-------------	----------------	-------------------	----------------

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related **Commands**

ip prefix-list	Enter the CONFIGURATION-IP PREFIX-LIST mode and configure a prefix list.
show ip prefix-list summary	Display a summary of the configured prefix lists.

Example

Figure 15-22. show ip route summary Command Example

```
FTOS#show ip route list test
Codes: C - connected, S - static, R - RIP,
B - BGP, IN - internal BGP, EX - external BGP, LO - Locally Originated,
O - OSPF, IA - OSPF inter area, N1 - OSPF NSSA external type 1,
N2 - OSPF NSSA external type 2, E1 - OSPF external type 1,
E2 - OSPF external type 2, i - IS-IS, L1 - IS-IS level-1,
L2 - IS-IS level-2, IA - IS-IS inter area, * - candidate default,
> - non-active route, + - summary route
Gateway of last resort is not set
               Destination
                                                                                                                      Dist/Metric Last Change
                                                      via 2.1.4.1, Gi 4/43
via 2.1.4.1, Gi 4/43
via 2.1.4.1, Gi 4/43
               2.1.0.0/24
                                                                                                                                   120/2
    R
               2.1.1.0/24
                                                                                                                                    120/2
                                                                                                                                                                3d1h
    R
               2.1.2.0/24
                                                                                                                                   120/1
                                                                                                                                                                3d0h
                                                       via 2.1.4.1, Gi 4/43
Direct, Gi 4/43
               2.1.3.0/24
                                                                                                                                                                3d1h
    R
                                                                                                                                    120/1
               2.1.4.0/24
                                                                                                                                        0/0
                                                                                                                                                                3d1h
```

show ip route summary

View a table summarizing the IP routes in the switch. CES

Syntax show ip route summary

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 15-23. show ip route summary Command Example

```
FTOS>show ip route summary

Route Source Active Routes Non-active Routes connected 17 0 static 3 0 0 ospf 100 1368 2 Inter-area: 762 Inter-area: 1 External-1: 600 External-2: 5 Total 1388 2

Total 1388 active route(s) using 222440 bytes Total 2 non-active route(s) using 128 bytes

FTOS>
```

Table 15-15. show ip route summary Column Headings

Column Heading	Description
Route Source	Identifies how the route is configured in FTOS.
Active Routes	Identifies the best route if a route is learned from two protocol sources.
Non-active Routes	Identifies the back-up routes when a route is learned by two different protocols. If the best route or active route goes down, the non-active route will become the best route.
ospf 100	If routing protocols (OSPF, RIP) are configured and routes are advertised, then information on those routes is displayed.
Total 1388 active	Displays the number of active and non-active routes and the memory usage of those routes. If there are no routes configured in the FTOS, this line does not appear.

Related Commands

show ip route Display information about the routes found in switch.

show ip traffic

CES

View IP, ICMP, UDP, TCP and ARP traffic statistics.

Syntax

show ip traffic [all | cp | rp1 | rp2]

Note: These options are supported only on the E-Series.

Parameters

all	(OPTIONAL) Enter the keyword all to view statistics from all processors.
	If you do not enter a keyword, you also view all statistics from all processors.
ср	(OPTIONAL) Enter the cp to view only statistics from the Control Processor.
rp1	(OPTIONAL) Enter the keyword rp1 to view only the statistics from Route Processor 1.
rp2	(OPTIONAL) Enter the keyword rp2 to view only the statistics from Route Processor 2.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series

Version 6.5.1.0	F10 Monitoring MIB available for ip traffic statistics
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 15-24. show ip traffic Command Example (partial)

```
FTOS#show ip traffic
Control Processor IP Traffic:
IP statistics:
 Rcvd: 23857 total, 23829 local destination
      0 format errors, 0 checksum errors, 0 bad hop count
     0 unknown protocol, 0 not a gateway
0 security failures, 0 bad options
 Frags: 0 reassembled, 0 timeouts, 0 too big
 0 fragmented, 0 couldn't fragment
Bcast: 28 received, 0 sent; Mcast: 0 received, 0 sent
Sent: 16048 generated, 0 forwarded
     21 encapsulation failed, 0 no route
ICMP statistics:
 Rcvd: 0 format errors, 0 checksum errors, 0 redirects, 0 unreachable 0 echo, 0 echo reply, 0 mask requests, 0 mask replies, 0 quench 0 parameter, 0 timestamp, 0 info request, 0 other Sent: 0 redirects, 0 unreachable, 0 echo, 0 echo reply
     O mask requests, O mask replies, O quench, O timestamp
O info reply, O time exceeded, O parameter problem
UDP statistics:
 Rcvd: 0 total, 0 checksum errors, 0 no port
      0 short packets, 0 bad length, 0 no port broadcasts, 0 socket full
 Sent: 0 total, 0 forwarded broadcasts
TCP statistics:
 Rcvd: 23829 total, 0 checksum errors, 0 no port
 Sent: 16048 total
ARP statistics:
Rcvd: 156 requests, 11 replies
Sent: 21 requests, 10 replies (0 proxy)
Routing Processor1 IP Traffic:
```

Table 15-16. show ip traffic output definitions

Keyword	Definition	
unknown protocol	No receiver for these packets. Counts those packets whose protocol type field is not recognized by FTOS.	
not a gateway	Packets can not be routed; host/network is unreachable.	
security failures	Counts the number of received unicast/multicast packets that could not be forwarded due to: route not found for unicast/multicast; ingress interfaces do not belong to the destination multicast group	
	destination in undeast group destination IP address belongs to reserved prefixes; host/network unreachable	
bad options	Unrecognized IP option on a received packet.	
Frags:	IP fragments received.	
reassembled	Number of IP fragments that were reassembled.	
timeouts	Number of times a timer expired on a reassembled queue.	
too big	Number of invalid IP fragments received.	
couldn't fragment	Number of packets that could not be fragmented and forwarded.	
encapsulation failed	Counts those packets which could not be forwarded due to ARP resolution failure. FTOS sends an arp request prior to forwarding an IP packet. If a reply is not received, FTOS repeats the request three times. These packets are counted in encapsulation failed.	
Rcvd:		

Table 15-16. show ip traffic output definitions

Keyword	Definition
short packets	The number of bytes in the packet are too small.
bad length	The length of the packet was not correct.
no port broadcasts	The incoming broadcast/multicast packet did not have any listener.
socket full	The applications buffer was full and the incoming packet had to be dropped.

Usage Information

The F10 Monitoring MIB provides access to the statistics described below.

Table 15-17. F10 Monitoring MIB

Command Display	Object	OIDs
IP statistics:		
Bcast:		
Received	f10BcastPktRecv	1.3.6.1.4.1.6027.3.3.5.1.1
Sent	f10BcastPktSent	1.3.6.1.4.1.6027.3.3.5.1.2
Mcast:		
Received	f10McastPktRecv	1.3.6.1.4.1.6027.3.3.5.1.3
Sent	f10McastPktSent	1.3.6.1.4.1.6027.3.3.5.1.4
ARP statistics:		
Rcvd:		
Request	f10ArpReqRecv	1.3.6.1.4.1.6027.3.3.5.2.1
Replies	f10ArpReplyRecv	1.3.6.1.4.1.6027.3.3.5.2.3
Sent:		
Request	f10ArpReqSent	1.3.6.1.4.1.6027.3.3.5.2.2
Replies	f10ArpReplySent	1.3.6.1.4.1.6027.3.3.5.2.4
Proxy	f10ArpProxySent	1.3.6.1.4.1.6027.3.3.5.2.5

show protocol-termination-table

[E] Display the IP Packet Termination Table (IPPTT).

Syntax show protocol-termination-table linecard number port-set port-pipe-number

Parameters

linecard number	Enter the keyword linecard followed by slot number of the line card. E-Series Range: 0 to 13 on a E1200/1200i, 0 to 6 on a E600/E600i, and 0 to 5 on a E300
port-set port-pipe-number	Enter the keyword port-set followed by the line card's Port-Pipe number. Range: 0 to 1

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.1.1.2	Introduced support for E-Series ExaScale E600i
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 6.4.1.0	Introduced

Example

Figure 15-25. show protocol-termination-table Command Output

ndex	Protocol	Src-Port	Dst-Port	Queue	DP 	Blk-Hole	VlanCPU	EgPort
)	ICMP	any	any	Q0	0	No	-	CP
	UDP	any	1812	Q7	6	No	_	CP
2	UDP	any	68	Q7	6	No	_	CP
3	UDP	any	67	Q7	6	No	_	CP
1	TCP	any	22	Q7	6	No	_	CP
5	TCP	22	any	Q7	6	No	_	CP
5	TCP	639	any	Q7	6	No	_	RP2
7	TCP	any	639	Q7	6	No	_	RP2
3	TCP	646	any	Q7	6	No	_	RP1
9	TCP	any	646	Õ7	6	No	_	RP1
10	UDP	646	any	Õ7	6	No	_	RP1
11	UDP	any	646	Õ7	6	No	_	RP1
12	TCP	23	any	Õ7	6	No	_	CP
13	TCP	any	23	Õ7	6	No	_	CP
14	UDP	any	123	Q7	6	No	_	CP
15	TCP	any	21	Õ7	6	No	_	CP
16	TCP	any	20	Õ7	6	No	_	CP
17	UDP	any	21	Õ7	6	No	_	CP
18	UDP	any	20	Õ7	6	No	_	CP
19	TCP	21	any	Õ7	6	No	_	CP
20	TCP	20	any	Õ7	6	No	_	CP
21	UDP	21	any	Õ7	6	No	_	CP
22	UDP	20	any	Õ7	6	No	_	CP
23	UDP	any	69	Õ7	6	No	_	CP
24	UDP	69	any	Õ7	6	No	_	CP
25	TCP	any	161	Q7	6	No	_	CP
26	TCP	161	any	Q7	6	No	_	CP
27	TCP	162	any	Õ7	6	No	_	CP
2.8	TCP	any	162	Q7	6	No	_	CP
29	UDP	any	161	07	6	No	_	CP
30	UDP	161	any	07	6	No	_	CP
31	UDP	any	162	Q7	6	No	_	CP
32	UDP	162	any	07	6	No	_	CP
33	PIM-SM	any	any	Q6	0	No	_	RP2
34	IGMP	any	any	Q7	6	No	_	RP2
35	OSPF	any	any	Q7	6	No	_	RP1
36	RSVP	any	any	07	6	No No	_	RP1
TOS#	100 41	arry	arry	۷,	J	110		ICI I

Usage Information

The IPPTT table is used for looking up forwarding information for IP control traffic destined to the router. For the listed control traffic types, IPPTT contains the information for the following:

- Which CPU to send the traffic (CP, RP1, or RP2)
- What QoS parameters to set

Related Commands

show tcp statistics

CES View information on TCP traffic through the switch.

Syntax show tcp statistics {all | cp | rp1 | rp2}

Parameters

all	Enter the keyword all to view all TCP information.
ср	Enter the keyword cp to view only TCP information from the Control Processor.
rp1	Enter the keyword rp1 to view only TCP statistics from Route Processor 1.
rp2	Enter the keyword rp2 to view only TCP statistics from Route Processor 2.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 6.4.1.0	Introduced

Example

Figure 15-26. show tcp statistics cp Command Example

```
FTOS#show tcp stat cp
Control Processor TCP:
Rcvd: 10585 Total, 0 no port
   O checksum error, O bad offset, O too short
329 packets (1263 bytes) in sequence
    17 dup packets (6 bytes)
    0 partially dup packets (0 bytes)
    7 out-of-order packets (0 bytes)
    0 packets ( 0 bytes) with data after window
    0 packets after close
    0 window probe packets, 41 window update packets
   41 dup ack packets, 0 ack packets with unsend data
   10184 ack packets (12439508 bytes)
Sent: 12007 Total, 0 urgent packets
   25 control packets (including 24 retransmitted) 11603 data packets (12439677 bytes)
   24 data packets (7638 bytes) retransmitted 355 ack only packets (41 delayed)
0 window probe packets, 0 window update packets
7 Connections initiated, 8 connections accepted, 15 connections established
14 Connections closed (including 0 dropped, 0 embryonic dropped)
20 Total rxmt timeout, 0 connections dropped in rxmt timeout
0 Keepalive timeout, 0 keepalive probe, \overline{\text{O}} Connections dropped in keepalive
FTOS#
```

Table 15-18. show tcp statistics cp Command Example Fields

Field	Description
Rcvd:	Displays the number and types of TCP packets received by the switch.
	Total = total packets received
	• no port = number of packets received with no designated port.
0 checksum error	Displays the number of packets received with the following:
	checksum errors
	bad offset to data
	• too short
329 packets	Displays the number of packets and bytes received in sequence.
17 dup	Displays the number of duplicate packets and bytes received.
0 partially	Displays the number of partially duplicated packets and bytes received.
7 out-of-order	Displays the number of packets and bytes received out of order.
0 packets with data after window	Displays the number of packets and bytes received that exceed the switch's window size.
0 packets after close	Displays the number of packet received after the TCP connection was closed.

Table 15-18. show tcp statistics cp Command Example Fields (continued)

Field	Description
0 window probe packets	Displays the number of window probe and update packets received.
41 dup ack	Displays the number of duplicate acknowledgement packets and acknowledgement packets with data received.
10184 ack	Displays the number of acknowledgement packets and bytes received.
Sent:	Displays the total number of TCP packets sent and the number of urgent packets sent.
25 control packets	Displays the number of control packets sent and the number retransmitted.
11603 data packets	Displays the number of data packets sent.
24 data packets retransmitted	Displays the number of data packets resent.
355 ack	Displays the number of acknowledgement packets sent and the number of packet delayed.
0 window probe	Displays the number of window probe and update packets sent.
7 Connections initiated	Displays the number of TCP connections initiated, accepted, and established.
14 Connections closed	Displays the number of TCP connections closed, dropped.
20 Total rxmt	Displays the number of times the switch tried to resend data and the number of connections dropped during the TCP retransmit timeout period.
0 Keepalive	Lists the number of keepalive packets in timeout, the number keepalive probes and the number of TCP connections dropped during keepalive.

IPv6 Access Control Lists (IPv6 ACLs)

Overview

IPv6 ACLs and IPv6 Route Map commands are supported on platforms [C][E][S]



- **IPv6 ACL Commands**
- IPv6 Route Map Commands



Note: For IPv4 ACL commands, see Chapter 6, Access Control Lists (ACL).

Important Points to Remember

- S-Series systems support Ingress IPv6 ACLs.
- The S60 supports both Ingress and Egress IPv6 ACLs.E-Series platforms require IPv6-ExtACL CAM profile to support IPv6 ACLs.
- C-Series platforms require manual CAM usage space allotment. Refer to cam-acl later in this document.
- Egress IPv6 ACL and IPv6 ACL on Loopback interface is not supported.
- Reference to an empty ACL will permit any traffic.
- ACLs are not applied to self-originated traffic (e.g. Control Protocol traffic not affected by IPv6 ACL since the routed bit is not set for Control Protocol traffic and for egress ACLs the routed bit must be set).
- The same access list name can be used for both IPv4 and IPv6 ACLs.
- Both IPv4 and IPv6 ACLs can be applied on an interface at the same time.
- IPv6 ACLs can be applied on physical interfaces and a logical interfaces (Port-channel/VLAN).
- Non-contiguous masks are not supported in source or destination addresses in IPv6 ACL entries.
- Since prefix mask is specified in /x format in IPv6 ACLs, inverse mask is not supported.

IPv6 ACL Commands

The following commands configure IPv6 ACLs:

- cam-acl
- clear counters ipv6 access-group
- deny
- deny icmp
- deny tcp
- deny udp

- ipv6 access-group
- ipv6 access-list
- permit
- permit icmp
- permit tcp
- permit udp
- remark
- resequence access-list
- resequence prefix-list ipv6
- seq
- show cam-acl
- show config
- show ipv6 accounting access-list
- show running-config acl
- test cam-usage

cam-acl

CS

Allocate space for IPv6 ACLs.

Syntax

cam-acl {default | 12acl 1-10 ipv4acl 1-10 ipv6acl 0-10 ipv4qos 1-10 l2qos 1-10}

Parameters

default	Use the default CAM profile settings, and set the CAM as follows.
	L3 ACL (ipv4acl): 6
	L2 ACL(l2acl) : 5
	IPv6 L3 ACL (ipv6acl): 0
	L3 QoS (ipv4qos): 1
	L2 QoS (l2qos): 1
l2acl 1-10 ipv4acl 1-10 ipv6acl 0-10 ipv4qos 1-10	Allocate space to support IPv6 ACLs. You must enter all of the profiles and a range.
I2qos 1-10	Enter the CAM profile name followed by the amount to be allotted.
	The total space allocated must equal 13.
	The ipv6acl range must be a factor of 2.

Command Modes

CONFIGURATION

Command History

Vei	rsion 8.3.3.1	Introduced on the S60.	
Vei	rsion 8.2.1.0	Introduced on the S-Series	
Vei	rsion 7.8.1.0	Introduced on the C-Series	

Usage Information

You must save the new CAM settings to the startup-config (**write-mem** or **copy run start**) then reload the system for the new settings to take effect.

The total amount of space allowed is 16 FP Blocks. System flow requires 3 blocks and these cannot be reallocated.

When configuring space for IPv6 ACLs, the total number of Blocks must equal 13.

Ranges for the CAM profiles are 1-10, except for the **ipv6acl** profile which is 0-10. The **ipv6acl** allocation must be a factor of 2 (2, 4, 6, 8, 10).

clear counters ipv6 access-group

CES

Erase all counters maintained for the IPv6 access lists.

Syntax

clear counters ipv6 access-group [access-list-name]

Parameters

access-list-name (OPTIONAL) Enter the name of a configured access-list, up to 140 characters.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

deny



Configure a filter that drops IPv6 packets that match the filter criteria.

Syntax

deny {ipv6-protocol-number | icmp | ipv6 | tcp | udp}

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny** { *ipv6-protocol-number* | **icmp** | **ipv6** | **tcp** | **udp**} command.

Parameters

ip-protocol-number	Enter an IPv6 protocol number.
	Range: 0 to 255
icmp	Enter the keyword icmp to deny Internet Control Message Protocol version 6.
ipv6	Enter the keyword ipv6 to deny any Internet Protocol version 6.
tcp	Enter the keyword tcp to deny the Transmission Control protocol.
udp	Enter the keyword udp to deny the User Datagram Protocol.

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0 Introduced support on the E-Series ExaScale	
---	--

Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

deny icmp



Configure a filter to drop all or specific ICMP messages.

Syntax

deny icmp {source address mask | any | host ipv6-address} { destination address | any | host ipv6-address} [message-type] [count [byte]] | [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny icmp** { source address mask | **any** | **host** ipv6-address} { destination address | **any** | **host** ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were sent in the X:X:X:X format followed by the prefix length in the /X format.	
	Range: /0 to /128	
	The :: notation specifies successive hexadecimal fields of zero.	
mask	Enter a network mask in /prefix format (/x).	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.	
	The :: notation specifies successive hexadecimal fields of zero	
destination address	Enter the IPv6 address of the network or host to which the packets are sent in the x:x:x:x format followed by the prefix length in the /x format.	
	Range: /0 to /128	
	The :: notation specifies successive hexadecimal fields of zero.	
message-type	On the E-Series, enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type.	
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL) Enter the keyword log to have the information kept in an ACL log file.	
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.	

Defaults

Not configured

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the count byte options, only bytes are incremented.

The following table lists the keywords displayed in the CLI help and their corresponding ICMP Message Type Name.

Table 16-1. ICMP Message Type Keywords

Keyword	ICMP Message Type Name
dest-unreachable	Destination unreachable
echo	Echo request (ping)
echo-reply	Echo reply
inverse-nd-na	Inverse neighbor discovery advertisement
inverse-nd-ns	Inverse neighbor discovery solicitation
log	Log matches against this entry
mobile-advertisement	Mobile prefix advertisement
mobile-solicitation	Mobile prefix solicitation
mrouter-advertisement	Multicast router advertisement
mrouter-solicitation	Multicast router solicitation
mrouter-termination	Multicast router termination
nd-na	Neighbor advertisement
nd-ns	Neighbor solicitation
packet-too-big	Packet is too big
parameter-problem	Parameter problems
redirect	Neighbor redirect
router-advertisement	Neighbor discovery router advertisement
router-renumbering	All routers renumbering
router-solicitation	Neighbor discovery router solicitation
time-exceeded	All time exceeded

deny tcp

CES

Configure a filter that drops TCP packets that match the filter criteria.

Syntax

deny tcp {source address mask | **any** | **host** ipv6-address} [operator port [port]] { destination address | any | host ipv6-address | [bit] [operator port [port]] [count [byte]] | [log] [monitor] To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny tcp** { source address mask | **any** | **host** ipv6-address} { destination address | **any** | **host** ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were sent in the x:x:x:x format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
mask	Enter a network mask in /prefix format (/x).
any	Enter the keyword any to specify that all routes are subject to the filter.
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x::x format.
	The :: notation specifies successive hexadecimal fields of zero
operator	(OPTIONAL) Enter one of the following logical operand:
	• eq = equal to
	• neq = not equal to
	• gt = greater than
	• $\mathbf{lt} = \text{less than}$
	• range = inclusive range of ports (you must specify two ports for the <i>port</i> command parameter.
port port	Enter the application layer port number. Enter two port numbers if using the range logical operand.
	Range: 0 to 65535.
	The following list includes some common TCP port numbers:
	• 23 = Telnet
	• 20 and 21 = FTP
	• 25 = SMTP
	• 169 = SNMP
destination address	Enter the IPv6 address of the network or host to which the packets are sent in
	the x:x:x: format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
bit	Enter a flag or combination of bits:
	ack: acknowledgement field
	fin: finish (no more data from the user)
	psh: push function
	rst: reset the connection
	syn: synchronize sequence numbers
	urg: urgent field
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
Ny to	(OT TIOTAL) Eliter the keyword byte to could bytes processed by the filter.

log	(OPTIONAL) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.	
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.	

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the count byte options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (gt, It, range) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port range 4000 - 8000 uses 8 entries in the CAM:

1 0000111110100000 1111111111111100000 4000 4031 32 2 0000111111000000 1111111111111000000 4032 4095 64 3 0001000000000000 1111110000000000 4096 6143 2048 4 000110000000000 111111000000000 6144 7167 1024 5 000111000000000 111111100000000 7168 7679 512 6 0001111000000000 1111111110000000 7936 7999 64 8 0001111100000000 11111111111111111 8000 8000 1	Rule#	Data	Mask	From	То	#Covered
0 000111110100000 111111111111111 8000 8000 1	3 4 5 6	0000111111000000 00010000000000000 00011000000	1111111111000000 1111100000000000 111111	4032 4096 6144 7168 7680 7936	4095 6143 7167 7679 7935	64 2048 1024 512 256

Total Ports: 4001

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	Data	Mask	From	То	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

deny	Assign a filter to deny IP traffic.	
deny udp	Assign a filter to deny UDP traffic.	

deny udp

CES

Configure a filter to drop UDP packets meeting the filter criteria.

Syntax

deny udp { source address mask | **any** | **host** ipv6-address} [operator port [port]] { destination address | **any** | **host** ipv6-address} [operator port [port]] [**count** [**byte**]] | [**log**] [**monitor**]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no deny udp** { source address mask | any | host ipv6-address } { destination address | any | host ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were sent in the x:x:x: format followed by the prefix length in the /x format.	
	Range: /0 to /128	
	The :: notation specifies successive hexadecimal fields of zero.	
mask	Enter a network mask in /prefix format (/x).	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.	
	The :: notation specifies successive hexadecimal fields of zero	
operator	(OPTIONAL) Enter one of the following logical operand:	
	• eq = equal to	
	• neq = not equal to	
	• gt = greater than	
	• $\mathbf{lt} = \text{less than}$	
	• range = inclusive range of ports	
port port	(OPTIONAL) Enter the application layer port number. Enter two port numbers if using the range logical operand. Range: 0 to 65535	
destination address	Enter the IPv6 address of the network or host to which the packets are sent in the x:x:x:x : format followed by the prefix length in the /x format.	
	Range: /0 to /128	
	The :: notation specifies successive hexadecimal fields of zero.	
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.	
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.	
log	(OPTIONAL) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.	
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.	

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the count byte options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (gt, It, range) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port **range 4000 - 8000** will use 8 entries in the CAM:

Rule#	Data	Mask	From	То	#Covered
1 2 3 4 5 6 7 8	00001111111000000 00010000000000000 00011000000	1111111111100000 11111111111000000 11111000000	4000 4032 4096 6144 7168 7680 7936 8000	4031 4095 6143 7167 7679 7935 7999 8000	32 64 2048 1024 512 256 64
Total	Ports: 4001				

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	I	Data	Mask	From	То	#Covered
1	0000000	000000000	1111110000000000	0	1023	1024
Total	Ports:	1024				

Related Commands

deny	Assign a deny filter for IP traffic.
deny tcp	Assign a deny filter for TCP traffic.

ipv6 access-group

CES

Assign an IPv6 access-group to an interface.

Syntax

ipv6 access-group access-list-name {in | out} [implicit-permit] [vlan range]

To delete an IPv6 access-group configuration, use the no ipv6 access-group access-list-name {in} [implicit-permit] [vlan range] command.

Parameters

access-list-name	Enter the name of a configured access list, up to 140 characters.
in out	Enter either the keyword in or out to apply the IPv6 ACL to incoming traffic (ingress) or outgoing traffic (egress).

implicit-permit	(OPTIONAL) Enter the keyword implicit-permit to change the default action of the IPv6 ACL from implicit-deny to implicit-permit (that is, if the traffic does not match the filters in the IPv6 ACL, the traffic is permitted instead of dropped).
vlan range	(OPTIONAL) Enter the keyword vian followed by the VLAN range in a comma separated format. Range: 1 to 4094

Defaults

Disabled

Command Modes

INTERFACE

Command History

Version 7.8.1.0	Introduced support on the C-Series
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

You can assign an IPv6 access group to a physical, LAG, or VLAN interface context.

Example

Figure 16-1. Command Example: ipv6 access-group

```
FTOS(conf-if-gi-9/0)#ipv6 access-group AclList1 in implicit-permit vlan 10-20

FTOS(conf-if-gi-9/0)#show config
!
interface GigabitEthernet 9/0
no ip address
ipv6 access-group AclList1 in implicit-permit Vlan 10-20
no shutdown
FTOSconf-if-gi-9/0)#
```

ipv6 access-list

C E S Configure an access list based on IPv6 addresses or protocols.

Syntax

ipv6 access-list access-list-name

To delete an access list, use the **no ipv6 access-list** access-list-name command.

Parameters

access-list-name Enter the as the access list name as a string, up to 140 characters.

Defaults

All access lists contain an implicit "deny any"; that is, if no match occurs, the packet is dropped.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced support on the S60.
Version 8.2.1.0	Introduced support on the E-Series ExaScale

Version 7.8.1.0	Introduced support on the C-Series
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The number of entries allowed per ACL is hardware-dependent. Refer to your line card documentation for detailed specification on entries allowed per ACL.

Related Commands

show config	View the current configuration.	
-------------	---------------------------------	--

permit



Select an IPv6 protocol number, ICMP, IPv6, TCP, or UDP to configure a filter that match the filter

Syntax

permit {ipv6-protocol-number | icmp | ipv6 | tcp | udp}

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit** { *ipv6-protocol-number* | **icmp** | **ipv6** | **tcp** | **udp** } command.

Parameters

ip-protocol-number	Enter an IPv6 protocol number. Range: 0 to 255
icmp	Enter the keyword icmp to filter Internet Control Message Protocol version 6.
ipv6	Enter the keyword ipv6 to filter any Internet Protocol version 6.
tcp	Enter the keyword tcp to filter the Transmission Control protocol.
udp Enter the keyword udp to filter the User Datagram Protocol.	

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.3.3.1	Introduced support on the S60.
Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

permit icmp

CES

Configure a filter to allow all or specific ICMP messages.

Syntax

permit icmp {source address mask | any | host ipv6-address} { destination address | any | host ipv6-address} [message-type] [count [byte]] | [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit icmp** { source address mask | **any** | **host** ipv6-address} { destination address | **any** | **host** ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were sent in the x:x:x::x format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
mask	Enter a network mask in /prefix format (/x).
any	Enter the keyword any to specify that all routes are subject to the filter.
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.
	The :: notation specifies successive hexadecimal fields of zero
destination address	Enter the IPv6 address of the network or host to which the packets are sent in the x:x:x: format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
message-type	(OPTIONAL) Enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type.
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL) Enter the keyword log to have the information kept in an ACL log file.
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.

Defaults

Not configured

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0 Introduced support on the E-Series	
	Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

permit tcp

CES

Configure a filter to pass TCP packets that match the filter criteria.

Syntax

permit tcp {source address mask | any | host ipv6-address} [operator port [port]] {destination address | any | host ipv6-address} [bit] [operator port [port]] [count [byte]] | [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit tcp** {source address mask | **any** | **host** ipv6-address} { destination address | any | host ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were sent in the x:x:x:x format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
mask	Enter a network mask in /prefix format (/x).
any	Enter the keyword any to specify that all routes are subject to the filter.
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.
	The :: notation specifies successive hexadecimal fields of zero
operator	(OPTIONAL) Enter one of the following logical operand:
	• eq = equal to
	• neq = not equal to
	• gt = greater than
	• $\mathbf{lt} = \text{less than}$
	• range = inclusive range of ports (you must specify two port for the <i>port</i> parameter.)
port port	Enter the application layer port number. Enter two port numbers if using the range logical operand.
	Range: 0 to 65535.
	The following list includes some common TCP port numbers:
	23 = Telnet
	20 and 21 = FTP
	25 = SMTP
	169 = SNMP
destination address	Enter the IPv6 address of the network or host to which the packets are sent in
	the X:X:X:X format followed by the prefix length in the /X format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.

bit	Enter a flag or combination of bits:
	ack: acknowledgement field
	fin: finish (no more data from the user)
	psh: push function
	rst: reset the connection
	syn: synchronize sequence numbers
	urg: urgent field
count	(OPTIONAL) Enter the keyword count to count packets processed by the
	filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL) Enter the keyword log to enter ACL matches in the log.
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series
	Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (**gt**, **lt**, **range**) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port range 4000 - 8000 uses 8 entries in the CAM:

Rule#	Data	Mask	From	То	#Covered
1 2 3 4 5 6 7	0000111110100000 0000111111000000 0001000000	1111111111100000 11111111111000000 11111000000	4000 4032 4096 6144	4031 4095 6143 7167 7679 7935 7999 8000	32 64 2048 1024 512 256 64

Total Ports: 4001

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	Data	Mask	From	То	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

permit	Assign a permit filter for IPv6 packets.
permit udp	Assign a permit filter for UDP packets.

permit udp



Configure a filter to pass UDP packets meeting the filter criteria.

Syntax

permit udp {source address mask | any | host ipv6-address } [operator port[port]] { destination address | any | host ipv6-address | [operator port [port]] [count [byte]] | [log] [monitor]

To remove this filter, you have two choices:

- Use the **no seq** sequence-number command syntax if you know the filter's sequence number or
- Use the **no permit udp** { source address mask | **any** | **host** ipv6-address} { destination address | any | host ipv6-address} command.

Parameters

source address	Enter the IPv6 address of the network or host from which the packets were s in the x:x:x:x format followed by the prefix length in the /x format.	
	Range: /0 to /128	
	The :: notation specifies successive hexadecimal fields of zero.	
mask	Enter a network mask in /prefix format (/x).	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.	
	The :: notation specifies successive hexadecimal fields of zero	

operator	(OPTIONAL) Enter one of the following logical operand:
	• eq = equal to
	• neq = not equal to
	• gt = greater than
	• $\mathbf{lt} = \text{less than}$
	• range = inclusive range of ports (you must specify two ports for the <i>port</i> parameter.)
port port	(OPTIONAL) Enter the application layer port number. Enter two port numbers if using the range logical operand.
	Range: 0 to 65535
destination address	Enter the IPv6 address of the network or host to which the packets are sent in
	the x:x:x::x format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL) Enter the keyword log to enter ACL matches in the log.
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring
	interface specified in the flow-based monitoring session along with the filter operation.

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

The C-Series cannot count both packets and bytes, so when you enter the **count byte** options, only bytes are incremented.

Most ACL rules require one entry in the CAM. However, rules with TCP and UDP port operators (**gt**, **lt**, **range**) may require more than one entry. The range of ports is configured in the CAM based on bitmask boundaries; the space required depends on exactly what ports are included in the range.

For example, an ACL rule with TCP port **range 4000 - 8000** uses 8 entries in the CAM:

Rule#	Data	Mask	From	To	#Covered
1 2 3 4 5 6	0000111110100000 0000111111000000 0001000000	1111111111100000 11111111111100000 11111000000	4000 4032 4096 6144	4031 4095 6143 7167 7679 7935 7999	32 64 2048 1024 512 256 64
8	0001111101000000	11111111111111111	8000	8000	1

Total Ports: 4001

But an ACL rule with TCP port lt 1023 takes only one entry in the CAM:

Rule#	Data	Mask	From	То	#Covered
1	0000000000000000	1111110000000000	0	1023	1024
Total	Ports: 1024				

Related Commands

permit	Assign a permit filter for IP packets.
permit tcp	Assign a permit filter for TCP packets.

remark

CES

Enter a description for an IPv6 ACL entry.

Syntax

remark remark number [description]

To delete the description, use the **no remark** remark number command (it is not necessary to include the remark description that you are deleting).

Parameters

remark number	Enter the remark number. Note that the same sequence number can be used for the remark and an ACL rule. Range: 0 to 4294967290
description	Enter a description of up to 80 characters.

Defaults

Not configured

Command Modes

ACCESS-LIST

_	Version 8.2.1.0	Introduced support on the E-Series ExaScale
_	Version 7.8.1.0	Introduced support on the C-Series
_	Version 7.4.1.0	Introduced support on the E-Series

Example Figure

Figure 16-2. Command Example: remark

```
FTOS(config-ipv6-acl) #remark 10 Remark for Entry # 10
FTOS(config-ipv6-acl) #show config
!
ipv6 access-list Acl1
description IPV6 Access-list
seq 5 permit ipv6 1111::2222/127 host 3333::1111 log count bytes
remark 10 Remark for Entry # 10
seq 10 permit icmp host 3333:: any mobile-advertisement log
seq 15 deny tcp any any rst
seq 20 permit udp any any gt 100 count
!FTOS(config-ipv6-acl)#
```

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

As shown in the example above, the same sequence number is used for the remark and an ACL rule. The remark will precede the rule in the running-configuration because it is assumed that the remark is for that rule or that group of rules that follow the remark. You can configure up to 4294967290 remarks in a given ACL.

Related Commands

show config	Display the current ACL configuration.	

resequence access-list

CES

Re-assign sequence numbers to entries of an existing access-list.

Syntax

resequence access-list {**ipv4** | **ipv6** | **mac**} {access-list-name StartingSeqNum Step-to-Increment}

Parameters

Enter the keyword ipv4 , ipv6 or mac to identify the access list type to resequence.
Enter the name of a configured IP access list, up to 140 characters.
Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Enter the starting sequence number to resequence.
Range: 0 - 4294967290
Enter the step to increment the sequence number.
Range: 1 - 4294967290

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing access-list.

Related **Commands**

resequence prefix-list ipv6 Resequence a prefix list

resequence prefix-list ipv6

CES

Re-assign sequence numbers to entries of an existing prefix list.

Syntax

resequence prefix-list ipv6 { prefix-list-name StartingSeqNum Step-to-increment}

Parameters

prefix-list-name	Enter the name of configured prefix list, up to 140 characters. Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
StartingSeqNum	Enter the starting sequence number to resequence. Range: 0 – 65535
Step-to-Increment	Enter the step to increment the sequence number. Range: 1 – 65535

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

When all sequence numbers have been exhausted, this feature permits re-assigning new sequence number to entries of an existing prefix list.

Related Commands

|--|

seq

CES

Assign a sequence number to a deny or permit filter in an IPv6 access list while creating the filter.

Syntax

seq sequence-number { deny | permit } { ipv6-protocol-number | icmp | ip | tcp | udp } { source address mask | any | host ipv6-address } { destination address | any | host ipv6-address } [operator port [port]] [count [byte]] | [log] [monitor]

To delete a filter, use the **no seq** sequence-number command.

Parameters

sequence-number	Enter a number from 0 to 4294967290.	
deny	Enter the keyword deny to configure a filter to drop packets meeting this condition.	
permit	Enter the keyword permit to configure a filter to forward packets meeting this criteria.	
ipv6-protocol-number	Enter an IPv6 protocol number. Range: 0 to 255	
icmp	Enter the keyword icmp to configure an Internet Control Message Protocol version 6 filter.	
ipv6	Enter the keyword ipv6 to configure any Internet Protocol version 6 filter.	
tcp	Enter the keyword tcp to configure a Transmission Control protocol filter.	
udp	Enter the keyword udp to configure a User Datagram Protocol filter.	
source address	Enter the IPv6 address of the network or host from which the packets were sent in the x:x:x:x format followed by the prefix length in the /x format.	
	Range: /0 to /128	
	The ∷ notation specifies successive hexadecimal fields of zero.	
mask	Enter a network mask in /prefix format (/x).	
any	Enter the keyword any to specify that all routes are subject to the filter.	
host ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x::x format.	
	The :: notation specifies successive hexadecimal fields of zero	
operator	(OPTIONAL) Enter one of the following logical operands:	
	• eq = equal to	
	• neq = not equal to	
	• gt = greater than	
	• It = less than	
	• range = inclusive range of ports (you must specify two ports for the <i>port</i> parameter.)	
port port	(OPTIONAL) Enter the application layer port number. Enter two port	
	numbers if using the range logical operand.	
	Range: 0 to 65535	
	The following list includes some common TCP port numbers:	
	• 23 = Telnet	
	• $20 \text{ and } 21 = \text{FTP}$	
	• $25 = SMTP$	
	• 169 = SNMP	

destination address	Enter the IPv6 address of the network or host to which the packets are sent in the x:x:x:x: format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zero.
message-type	(OPTIONAL) Enter an ICMP message type, either with the type (and code, if necessary) numbers or with the name of the message type.
	Range: 0 to 255 for ICMP type; 0 to 255 for ICMP code
count	(OPTIONAL) Enter the keyword count to count packets processed by the filter.
byte	(OPTIONAL) Enter the keyword byte to count bytes processed by the filter.
log	(OPTIONAL) Enter the keyword log to enter ACL matches in the log. Supported on Jumbo-enabled line cards only.
monitor	(OPTIONAL) Enter the keyword monitor to monitor traffic on the monitoring interface specified in the flow-based monitoring session along with the filter operation.

Defaults

Not configured.

Command Modes

ACCESS-LIST

Command **History**

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Added monitor option

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

Related Commands

deny	Configure a filter to drop packets.
permit	Configure a filter to forward packets.

show cam-acl

CS

Show space allocated for IPv6 ACLs.

Syntax

show cam-acl

Command Modes

EXEC

EXEC Privileged

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on the C-Series
cam-acl	Configure CAM profiles to support IPv6 ACLs

Related Commands

Examples

Figure 16-3. Command Example: show cam-acl (default profile)

```
FTOS#show cam-acl
-- Chassis Cam ACL --
          Current Settings(in block sizes)
: 5
. 6
L2Acl
Ipv4Acl
Ipv4Acl :
Ipv6Acl :
                     6
                     Ο
Ipv4Qos
                     1
L20os
-- Line card 4 --
         Current Settings(in block sizes)
L2Acl
                      6
Ipv4Acl
Ipv6Acl
                      0
Ipv4Qos
                      1
L2Qos
                      1
FTOS#show cam-acl
```

Figure 16-4. Command Example: show cam-acl (manually set profiles)

```
FTOS#show cam-acl
-- Chassis Cam ACL --
      Current Settings(in block sizes)
: 2
: 2
L2Acl
Ipv4Acl :
Ipv6Acl :
Ipv4Qos :
                      4
                      2
L2Qos
-- Line card 4 --
      Current Settings(in block sizes)
L2Acl
Ipv4Acl
                      2
Ipv6Acl
Ipv4Qos
                      2
L2Qos
FTOS#show cam-acl
```

show config

CES View the current IPv6 ACL configuration.

Syntax show config

Command Modes ACCESS-LIST

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series

Usage Information The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

Example Figure 16-5. Command Example: show config

```
FTOS(conf-ipv6-acl)#show config
ipv6 access-list Acl1
seq 5 permit ipv6 1111::2222/127 host 3333::1111 log count bytes seq 10 permit icmp host 3333:: any mobile-advertisement log seq 15 deny tcp any any rst seq 20 permit udp any any gt 100 count FTOS(conf-ipv6-acl)#
```

show ipv6 accounting access-list

View the IPv6 access-lists created on the E-Series and the sequence of filters.

show ipv6 accounting {access-list access-list-name | cam_count} interface interface Syntax

Parameters

access-list-name	Enter the name of the ACL to be displayed, up to 140 characters.	
cam_count	List the count of the CAM rules for this ACL.	
interface interface	Enter the keyword interface followed by the interface type and slot/port or number information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	• For a Port Channel interface, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale and ExaScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	

Command Modes EXEC

EXEC Privilege

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16
	characters long.
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

Example

Figure 16-6. Command Example: show ipv6 accounting access-lists

```
FTOS#show ipv6 accounting access-list
Ingress IPv6 access list AclList1 on GigabitEthernet 9/0
Total cam count 15
seq 10 permit icmp host 3333:: any mobile-advertisement log
seq 15 deny tcp any any rst
 seq 20 permit udp any any gt 101 count (0 packets)
FTOS#
```

Table 16-2. show ip accounting access-lists Command Example Field

Field	Description
"Ingress IPv6"	Displays the name of the IPv6 ACL, in this example "AclList1".
"seq 10"	Displays the filter. If the keywords count or byte were configured in the filter, the number of packets or bytes processed by the filter is displayed at the end of the line.

show running-config acl

CES Display the ACL running configuration.

Syntax show running-config acl

Command Modes EXEC

EXEC Privilege

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The S-Series supports Ingress IPv6 ACLs.

The S60 supports both Ingress and Egress IPv6 ACLs.

Example

Figure 16-7. Command Example: show running-config acl

```
FTOS#show running-config acl

ip access-list extended ext-acll

ip access-list standard std-acll

ipv6 access-list Acll
 description IPV6 Access-list
 seq 5 permit ipv6 1111::2222/127 host 3333::1111 log count bytes
 remark 10 Remark for Entry # 10
 seq 10 permit icmp host 3333:: any mobile-advertisement log
 seq 15 deny tcp any any rst
 seq 20 permit udp any any gt 100 count
!FTOS#
```

test cam-usage

Verify that enough ACL CAM space is available for the IPv6 ACLs you have created.

Syntax test cam-usage service-policy input input policy name linecard {number / all}

Parameters	policy-map name	Enter the name of the policy-map to verify.
	number	Enter all to get information for all the linecards, or enter the linecard <i>number</i> to get information for a specific card. Range : 0-6 for E-Series, 0-7 for C-Series
Defaults	None	

Command Modes EXEC Privilege

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and E-Series

Usage Information

This command applies to both IPv4 and IPv6 CAM Profiles, but is best used when verifying QoS optimization for IPv6 ACLs.

QoS Optimization for IPv6 ACLs does not impact the CAM usage for applying a policy on a single (or the first of several) interfaces. It is most useful when a policy is applied across multiple interfaces; it can reduce the impact to CAM usage across subsequent interfaces.

Example The following example shows the output shown when using the test cam-usage command.

Figure 16-8. Command Example: test cam-usage (C-Series)

TOS#test came	-usage service-policy inp	ut LauraMapTest linecard	al
inecard Po	rtpipe CAM Partition	Available CAM Estimate	d CAM per Port Status
2	1 IPv4Flow	232	0 Allowed
2	1 IPv6Flow	0	0 Allowed
4	0 IPv4Flow	232	0 Allowed
4	0 IPv6Flow	0	0 Allowed
TOS#test came	-usage service-policy inp	ut LauraMapTest linecard	4 Mort-set 0
inecard Po	rtpipe CAM Partition .	Available CAM Estimate	d CAM per Port Status
4	0 IPv4Flow	232	0 Allowed
	0 IPv6Flow	o İ	0 Allowed
4	0 TEAOLIOM	- 1	
4 TTOS#	0 1F40LTOM		
TOS#	m-usage service-policy in	put LauraMapTest linecar	d 2 (ort-set 1
TOS#		-	
TOS#	m-usage service-policy in	-	
TOS#	m-usage service-policy in rtpipe CAM Partition .	- Available CAM Estimate 	d CAM per Port Status

Table 16-3. Output Explanations: test cam-usage

Term	Explanation
Linecard	Lists the line card or line cards that are checked. Entering all shows the status for line cards in the chassis
Portpipe	Lists the portpipe (port-set) or port pipes (port-sets) that are checked. Entering all shows the status for line cards and port-pipes in the chassis.
CAM Partition	Shows the CAM profile of the CAM
Available CAM	Identifies the amount of CAM space remaining for that profile
Estimated CAM per Port	Estimates the amount of CAM space the listed policy will require.
Status	Indicates whether or not the policy will be allowed in the CAM

IPv6 Route Map Commands

The following commands allow you to configure route maps and their redistribution criteria.

- match ipv6 address
- match ipv6 next-hop
- match ipv6 route-source
- route-map
- set ipv6 next-hop
- · show config
- show route-map

match ipv6 address

Configure a filter to match routes based on IPv6 addresses specified in an access list.

Syntax match ipv6 address prefix-list-name

To delete a match, use the **no match ipv6 address** *prefix-list-name* command.

Parameters

prefix-list-name	Enter the name of IPv6 prefix list, up to 140 characters.

Defaults Not configured.

Command Modes ROUTE-MAP

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16
	characters long.
Version 7.4.1.0	Introduced support on the E-Series

Related Commands

match ipv6 next-hop	Redistribute routes that match the next-hop IP address.
match ipv6 route-source	Redistribute routes that match routes advertised by other routers.

match ipv6 next-hop

Configure a filter which matches based on the next-hop IPv6 addresses specified in the IPv6 prefix list.

Syntax match ipv6 next-hop prefix-list prefix-list-name

To delete a match, use the **no match ipv6 next-hop prefix-list** prefix-list-name command.

Parameters

prefix-list prefix-list-name	Enter the keywords prefix-list followed by the name of configured prefix
	list, up to 140 characters.

Defaults Not configured.

Command Modes ROUTE-MAP

> Command **History**

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.4.1.0	Introduced support on the E-Series

Related Commands

match ipv6 address	Redistribute routes that match an IP address.
match ipv6 route-source	Redistribute routes that match routes advertised by other routers.

match ipv6 route-source

 \mathbb{C} Configure a filter which matches based on the routes advertised in the IPv6 prefix lists.

match ipv6 route-source prefix-list prefix-list-name **Syntax**

To delete a match, use the **no match ipv6 route-source prefix-list** prefix-list-name command.

Parameters

prefix-list prefix-list-name	Enter the keywords prefix-list followed by the name of configured
	prefix list, up to 140 characters.

Defaults Not configured.

Command Modes ROUTE-MAP

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.4.1.0	Introduced support on the E-Series

Related Commands

match ipv6 address	Redistribute routes that match an IP address.
match ipv6 next-hop	Redistribute routes that match the next-hop IP address.

route-map

CE

Designate a IPv6 route map name and enter the ROUTE-MAP mode.

Syntax

route-map map-name

To delete a route map, use the **no route-map** *map-name* command.

Parameters

map-name Enter a text string to name the route map, up to 140 characters.

Defaults

Not configured

Command Modes

ROUTE-MAP

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16
	characters long.
Version 7.4.1.0	Introduced support on the E-Series

Example

Figure 16-9. Command Example: route-map

```
FTOS (conf) #route-map Rmap1

FTOS (config-route-map) #match ?
...
ip IP specific information
ipv6 IPv6 specific information
...
```

Related Commands

show config View the current configuration.

set ipv6 next-hop

CE

Configure a filter that specifies IPv6 address as the next hop.

Syntax

set ipv6 next-hop ipv6-address

To delete the setting, use the **no set ipv6 next-hop** *ipv6-address* command.

Parameters

ipv6-address Enter the IPv6 address in the **x:x:x:x**: format.

Note: The :: notation specifies successive hexadecimal fields of zeros

Defaults

Not configured.

Command Modes

ROUTE-MAP

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Usage Information

The set ipv6 next-hop command is the only way to set an IPv6 Next-Hop.

show config

View the current route map configuration.

Syntax show config

Command Modes ROUTE-MAP

Command History

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Example

Figure 16-10. Command Example: show config

```
FTOS(config-route-map)#show config
route-map Rmap1 permit 10 match ip address v4plist match ipv6 address plist1
 match ipv6 next-hop prefix-list plist2 match ipv6 route-source prefix-list plist3
 set next-hop 1.1.1.1
 set ipv6 next-hop 3333:2222::
FTOS (config-route-map) #
```

show route-map

View the current route map configurations.

Syntax show route-map

Command Modes EXEC

EXEC Privilege

Version 8.2.1.0	Introduced support on the E-Series ExaScale
Version 7.8.1.0	Introduced support on the C-Series
Version 7.4.1.0	Introduced support on the E-Series

Example F

Figure 16-11. Command Example: show route-map

```
FTOS#show route-map
!
route-map Rmap1, permit, sequence 10
Match clauses:
ip address: v4plist
ipv6 address: plist1
ipv6 next-hop prefix-lists: plist2
ipv6 route-source prefix-lists: plist3
Set clauses:
next-hop 1.1.1.1
ipv6 next-hop 3333:2222::
FTOS#
```

Related Commands

route-map

Configure a route map.

IPv6 Basics

Overview

IPv6 Basic Commands are supported on platforms C E and S as designated by the symbols beneath the commands

E-Series ExaScale supports IPv6 with FTOS 8.2.1.0 and later.



Note: The IPv6 basic commands are supported on all platforms. However, not all features are supported on all platforms. See the table in the FTOS Configuration guide to determine the FTOS version that supports which features and platforms.

Commands

The IPv6 commands in the chapter are:

- clear ipv6 fib
- clear ipv6 route
- ipv6 address
- ipv6 unicast-routing
- show ipv6 cam linecard
- show ipv6 cam stack-unit
- show ipv6 fib linecard
- show ipv6 fib stack-unit
- show ipv6 interface
- show ipv6 route
- trust ipv6-diffserv

clear ipv6 fib

CES Clear (refresh) all FIB entries on a line card.

Syntax clear ipv6 fib linecard slot

Parameters Enter the slot number to clear the FIB for a line card. slot

Command Mode EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced

clear ipv6 route

CES

Clear (refresh) all or a specific route from the IPv6 routing table.

Syntax

clear ipv6 route {* | ipv6-address prefix-length}

Parameters

*	Enter the * to clear (refresh) all routes from the IPv6 routing table.
ipv6-address prefix-length	Enter the IPv6 address in the x:x:x:x format followed by the prefix length in the /x format.
	Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros

Command Mode

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

ipv6 address

CES

Configure an IPv6 address to an interface.

Syntax

ipv6 address {ipv6-address prefix-length}

To remove the IPv6 address, use the **no ipv6 address** { ipv6-address prefix-length} command.

Parameters

ipv6-address prefix-length	Enter the IPv6 address in the X:X:X:X format followed by the prefix length in the /X format.
	Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros

Defaults

No default values or behavior

Command Modes

INTERFACE

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced

Example Figure 17-1. Command Example: ipv6 address

```
FTOS(conf)#interface gigabitethernet 10/0 FTOS(conf-if-gi-10/0)#ipv6 address ?
X:X:X:X:X
                          IPv6 address
FTOS(conf-if-gi-10/0)#ipv6 address 2002:1:2::3 ?
                          Prefix length in bits
<0-128>
FTOS(conf-if-gi-10/0) #ipv6 address 2002:1:2::3 /96 ?
FTOS(conf-if-gi-10/0)#ipv6 address 2002:1:2::3 /96
FTOS (conf-if-gi-10/0) #show config
interface GigabitEthernet 10/0
 no ip address
 ipv6 address 2002:1:2::3 /96
 no shutdown
FTOS(conf-if-gi-10/0)#
```

Usage Information

FTOS allows multiple IPv6 addresses to be configured on an interface. When the **no ipv6 address** command is issued without specifying a particular IPv6 address, all IPv6 addresses on that interface are

ipv6 route

CES

Establish a static IPv6 route.

Syntax

ipv6 route ipv6-address prefix-length { ipv6-address | interface | interface ipv6-address } [distance] [tag value] [permanent]

To remove the IPv6 route, use the **no ipv6 route** *ipv6-address prefix-length* { *ipv6-address* | interface | interface ipv6-address} [distance] [tag value] [permanent] command.

Parameters

ipv6-address prefix-length	Enter the IPv6 address in the X:X:X::X format followed by the prefix length in the /X format.
	Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a loopback interface, enter the keyword loopback followed by a number from zero (0) to 16383.
	• For the null interface, enter the keyword null followed by zero (0).
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
ipv6-address	(OPTIONAL) Enter the forwarding router IPv6 address in the x:x:x:x:x format.
	Note: The :: notation specifies successive hexadecimal fields of zeros
distance	(OPTIONAL) Enter a number as the distance metric assigned to the route.
	Range: 1 to 255
tag value	(OPTIONAL) Enter the keyword tag followed by a tag value number.
	Range: 1 to 4294967295
permanent	(OPTIONAL) Enter the keyword permanent to specify that the route is not to be removed, even if the interface assigned to that route goes down.
	Note: If you disable the interface with an IPv6 address associated with the keyword permanent , the route disappears from the routing table.

Defaults No default values or behavior

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced

Example Figure 17-2. Command Example: ipv6 route

```
FTOS(conf)#ipv6 route 44::0 /64 33::1 ?
<1-255>
                                Distance metric for this route
permanent
                                Permanent route
tag
                                Set tag for this route
FTOS(conf)#ipv6 route 55::0 /64 ?
X:X:X:X:X
                                Forwarding router's address
gigabitethernet
                                Gigabit Ethernet interface
loopback
                                Loopback interface
null
                                Null interface
port-channel
                                Port channel interface
sonet.
                                Sonet interface
                                TenGigabit Ethernet interface
tenGigabitethernet
                                VLAN interface
vlan
FTOS(conf)#ipv6 route 55::0 /64 gigabitethernet 9/0 ?
<1-255>
                                Distance metric for this route
X:X:X:X:X
                                Forwarding router's address
                                Permanent route
permanent
tag
                                Set tag for this route
FTOS(conf)#ipv6 route 55::0 /64 gigabitethernet 9/0 66::1 ?
<1-255>
                                Distance metric for this route
permanent
                                Permanent route
taq
                                Set tag for this route
FTOS#
```

Usage Information

When the interface goes down, FTOS withdraws the route. The route is re-installed, by FTOS, when the interface comes back up. When a recursive resolution is "broken," FTOS withdraws the route. The route is re-installed, by FTOS, when the recursive resolution is satisfied.

Related Commands

show ipv6 route View the IPv6 configured routes.

ipv6 unicast-routing

Enable IPv6 Unicast routing.

Syntax ipv6 unicast-routing

To disable unicast routing, use the **no ipv6 unicast-routing** command.

Defaults Enabled

Command Modes

CONFIGURATION

Command History

Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced

Usage Information

Since this command is enabled by default, it does not appear in the running configuration. When unicast routing is disabled, the **no ipv6 unicast-routing** command is included in the running configuration. Whenever unicast routing is disabled or re-enabled, FTOS generates a syslog message indicating the action.

Disabling unicast routing on an E-Series chassis causes the following behavior:

- static and protocol learnt routes are removed from RTM and from the CAM; packet forwarding to these routes is terminated.
- connected routes and resolved neighbors remain in the CAM and new IPv6 neighbors are still discoverable
- additional protocol adjacencies (OSPFv3 and BGP4) are brought down and no new adjacencies are formed
- the IPv6 address family configuration (under router bgp) is deleted
- IPv6 Multicast traffic continues to flow unhindered

show ipv6 cam linecard

Displays the IPv6 CAM entries for the specified line card.

Syntax

show ipv6 cam linecard *slot-number* **port-set** {0-1} [summary | index | ipv6 address]

Parameters

slot-number	Enter the line card slot ID number.
	Range: 0 to 13 on the E1200; 0 on 6 for E600, and 0 to 5 on the E300.
port-set	Enter the Port Set to
summary (OPTIONAL) Enter the keyword summary to display a table listing a prefixes and the total number prefixes which can be entered into the IPv	
index	(OPTIONAL) Enter the index in the IPv6 CAM
ipv6-address	Enter the IPv6 address in the x:x:x:x/n format to display networks that have more specific prefixes.
	Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Introduced
Version 7.8.1.0	Introduced on C-Series

Usage Information

The forwarding table displays host route first, then displays route originated by routing protocol including static route.

The egress port section displays the egress port of the forwarding entry which is designated as:

C for the Control Processor

1 for the Route Processor 1

2 for the Route Processor 2

Examples

Figure 17-3. Command Example: show ipv6 cam linecard fib (C or E-Series)

leighbor		Mac-Addr	D				
			Port	VId			
31] 2002:44:1:1::11		00:00:01:	la:le:d5 Gi 13/2	0			
Prefix	Nex	t-Нор	Mac-Addr		Port	VId	E
3147] 100::/64	[0] 2002:44:1:1::11	-		Gi 0/0		1
	[0] 2002:44:1:24::11			Gi 0/0		1
	[0] 2002:44:1:23::11			Gi 0/0		1
	[0] 2002:44:1:21::11			Gi 0/0		1
	[0] 2002:44:1:20::11	. -		Gi 0/0	0) 1
	[0] 2002:44:1:19::11	. -		Gi 0/0	0	1
TOS#							

Figure 17-4. Command Example: show ipv6 cam linecard (C or E-Series)

FTO	S# <mark>s</mark> h	ow ipv6 cam linecard 1 port	-set	0					
Neig	ghbo:	r				Port	VId		
[0]	fe80::201:e8ff:fe17:5cae			00:01:e8:17:5c:ae	BLK	100		
[1]	fe80::201:e8ff:fe17:5bbe			00:01:e8:17:5b:be	BLK	0		
[2]	fe80::201:e8ff:fe17:5bbd			00:01:e8:17:5b:bd	BLK	0		
[3] fe80::201:e8ff:fe17:5cb0			00:01:e8:17:5c:b0	BLK	0			
[4] fe80::201:e8ff:fe17:5cae		00:01:e8:17:5c:ae	BLK	1000				
[5]	fe80::201:e8ff:fe17:5caf			00:01:e8:17:5c:af	BLK	0		
Pre:	fix		Fir	st-Hop	Mac-Addr		Port	VId	EC
]	80]	2222::2/128	[2] :	00:00:00:0	00:00:00	RP2	0	0
[:TO:		3333::2/128	[2] ::1	00:00:00:0	00:00:00	RP2	0	0

show ipv6 cam stack-unit

S Displays the IPv6 CAM entries for the specified stack-unit.

Syntax show ipv6 cam stack-unit unit-number port-set {0-1} [summary | index | ipv6 address]

Parameters

unit-number	Enter the stack unit's ID number.		
	Unit ID range:		
	S60 : 0-11		
	all other S-Series: 0-7		
port-set	Enter the Port Set to		
summary	(OPTIONAL) Enter the keyword summary to display a table listing network prefixes and the total number prefixes which can be entered into the IPv6 CAM.		
index	(OPTIONAL) Enter the index in the IPv6 CAM		
ipv6-address	Enter the IPv6 address in the x:x:x:x/n format to display networks that have more specific prefixes.		
	Range: /0 to /128		
	Note: The :: notation specifies successive hexadecimal fields of zeros.		

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced

show ipv6 fib linecard

View all Forwarding Information Base entries.

Syntax

show ipv6 fib linecard *slot-number* {**summary** | *ipv6-address*}

Parameters

slot-number	Enter the number of the line card slot.	
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300	
summary (OPTIONAL) Enter the keyword summary to view a summary of entries in IR		
ipv6-address	Enter the IPv6 address in the x:x:x:x/n format to display networks that have more specific prefixes.	
	Range: /0 to /128	
	Note: The :: notation specifies successive hexadecimal fields of zeros.	

Command Mode

EXEC

EXEC Privilege

Vers	sion 8.2.1.0	Introduced on E-Series ExaScale
Vers	sion 7.8.1.0	Introduced on C-Series and S-Series
Vers	sion 7.4.1.0	Introduced

show ipv6 fib stack-unit

S View all Forwarding Information Base entries.

Syntax

show ipv6 fib stack-unit unit-number [summary] ipv6-address

Parameters

slot-number	Enter the number of the stack unit.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
summary	(OPTIONAL) Enter the keyword summary to view a summary of entries in IPv6 cam.
ipv6-address	Enter the IPv6 address in the X:X:X:X/n format to display networks that have more specific prefixes.
	Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros.

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced

show ipv6 interface

CES

Display the status of interfaces configured for IPv6.

Syntax

show ipv6 interface [brief] [configured] [gigabitethernet slot | slot/port] [linecard slot-number] [loopback interface-number] [port-channel number] [tengigabitethernet slot | slot/port] [vlan vlan-id]

Parameters

interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Loopback interface, enter the keyword Loopback followed by a number from 0 to 16383.
	• For the Null interface, enter the keyword null followed by zero (0).
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
brief	(OPTIONAL) View a summary of IPv6 interfaces.
configured	(OPTIONAL) View information on all IPv6 configured interfaces
gigabitethernet	(OPTIONAL) View information for an IPv6 gigabitethernet interface.
linecard slot-number	(OPTIONAL) View information for a specific IPv6 line card or S-Series stack-unit
	Range: 0 to 13 on a E1200, 0 to 6 on a E600, and 0 to 5 on a E300.
	Range: 0-7 for C-Series
	Range 0-11 for S60, 0-7 for all other S-Series

loopback	(OPTIONAL) View information for IPv6 loopback interfaces.
port-channel	(OPTIONAL) View information for IPv6 port channels.
tengigabitethernet	(OPTIONAL) View information for an IPv6 tengigabitethernet interface.
vlan	(OPTIONAL) View information for IPv6 VLANs.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced

Example

Figure 17-5. Command Example: show ipv6 interface

```
FTOS#show ipv6 interface gigabitethernet 1/1
GigabitEthernet 1/1 is up, line protocol is up
  IPV6 is enabled
 Link Local address: fe80::201:e8ff:fe04:62c4
 Global Unicast address(es):
    2001::1, subnet is 2001::/64
   2002::1, subnet is 2002::/120
   2003::1, subnet is 2003::/120
    2004::1, subnet is 2004::/32
  Global Anycast address(es):
  Joined Group address(es):
   ff02::1
   ff02::2
   ff02::1:ff00:1
   ff02::1:ff04:62c4
   MTU is 1500
  ICMP redirects are not sent
 DAD is enabled: number of DAD attempts: 1
 ND reachable time is 30 seconds
  ND advertised reachable time is 30 seconds
 ND advertised retransmit interval is 30 seconds
```

show ipv6 route

CES

Displays the IPv6 routes.

Syntax

show ipv6 route [ipv6-address prefix-length] [hostname] [all] [bgp as number] [connected] [isis tag] [list prefix-list name] [ospf process-id] [rip] [static] [summary]

Parameter

ipv6-address prefix-length	(OPTIONAL) Enter the IPv6 address in the x:x:x:x: format followed by the prefix length in the /x format. Range: /0 to /128
	The ∷ notation specifies successive hexadecimal fields of zeros.
hostname	(OPTIONAL) View information for this IPv6 routes with Host Name

all	(OPTIONAL) View information for all IPv6 routes
bgp	(OPTIONAL) View information for all IPv6 BGP routes
connected	(OPTIONAL) View only the directly connected IPv6 routes.
isis	(OPTIONAL) View information for all IPv6 IS-IS routes
list	(OPTIONAL) View the IPv6 prefix list
ospf	(OPTIONAL) View information for all IPv6 OSPF routes
rip	(OPTIONAL) View information for all IPv6 RIP routes
static	(OPTIONAL) View only routes configured by the ipv6 route command.
summary	(OPTIONAL) View a brief list of the configured IPv6 routes.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S=-Series
Version 7.4.1.0	Introduced

Example

Figure 17-6. Command Example: show ipv6 route

```
FTOS#show ipv6 route
Codes: C - connected, L - local, S - static, R - RIP,
B - BGP, IN - internal BGP, EX - external BGP, LO - Locally Originated,
O - OSPF, IA - OSPF inter area, N1 - OSPF NSSA external type 1,
N2 - OSPF NSSA external type 2, E1 - OSPF external type 1,
E2 - OSPF external type 2, i - IS-IS, L1 - IS-IS level-1,
L2 - IS-IS level-2, IA - IS-IS inter area, * - candidate default,
Gateway of last resort is not set
            Destination Dist/Metric, Gateway, Last Change
   С
             2001::/64 [0/0]
              Direct, Gi 1/1, 00:28:49
    С
             2002::/120 [0/0]
            Direct, Gi 1/1, 00:28:49
2003::/120 [0/0]
    С
              Direct, Gi 1/1, 00:28:49
             2004::/32 [0/0]
    C
              Direct, Gi 1/1, 00:28:49
             fe80::/10 [0/0]
              Direct, Nu 0, 00:29:09
```

Example

Figure 17-7. Command Example: show ipv6 route summary

Table 17-1. show ipv6 route Command Example Fields

Field	Description
(undefined)	Identifies the type of route:
	• L = Local
	• C = connected
	• S = static
	• R = RIP
	• B = BGP
	• IN = internal BGP
	• EX = external BGP
	• LO = Locally Originated
	• O = OSPF
	• IA = OSPF inter area
	• N1 = OSPF NSSA external type 1
	• N2 = OSPF NSSA external type 2
	• E1 = OSPF external type 1
	• E2 = OSPF external type 2
	• i = IS-IS
	• L1 = IS-IS level-1
	• $L2 = IS-IS \text{ level-}2$
	• IA = IS-IS inter-area
	• * = candidate default
	• > = non-active route
	• += summary routes
Destination	Identifies the route's destination IPv6 address.
Gateway	Identifies whether the route is directly connected and on which interface the route is configured.
Dist/Metric	Identifies if the route has a specified distance or metric.
Last Change	Identifies when the route was last changed or configured.

trust_ipv6-diffserv

CES Allows the dynamic classification of IPv6 DSCP.

Syntax trust ipv6-diffserv

To remove the definition, use the **no trust ipv6-diffserv** command.

Defaults This command has no default behavior or values.

Command Modes CONFIGURATION-POLICY-MAP-IN

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced

Usage Information

When trust IPv6 diffserv is configured, matched bytes/packets counters are *not* incremented in the **show qos statistics** command.

Trust diffserv (IPv4) can co-exist with **trust ipv6-diffserv** in an Input Policy Map. Dynamic classification happens based on the mapping detailed in the following table.

Table 17-2. IPv6 -Diffserv Mapping

IPv6 Service Class Field	Queue ID
111XXXXX	7
110XXXXX	6
101XXXXX	5
100XXXXX	4
011XXXXX	3
010XXXXX	2
001XXXXX	1
000XXXXX	0

iSCSI Optimization

Overview

Internet Small Computer System Interface (iSCSI) optimization enables quality-of-service (QoS) treatment for iSCSI storage traffic on the following platforms as indicated: [S55] [S60] [S4810].

The following FTOS commands are used to configure and verify the iSCSI Optimization feature:

- iscsi aging time
- iscsi cos
- iscsi enable
- iscsi priority-bits
- iscsi profile-compellent
- iscsi target port
- show iscsi
- show iscsi session
- show iscsi session detailed
- show run iscsi

iscsi aging time

[54810]

Set the aging time for iSCSI sessions.

Syntax iscsi aging time time

To remove the iSCSI session aging time, use the no iscsi aging time command.

Parameters

time	Enter the aging time for the iSCSI session.
	Range: 5 to 43,200 minutes.

Defaults 10 minutes.

CONFIGURATION **Command Mode**

Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

iscsi cos

[54810]

Set the QoS policy that will be applied to the iSCSI flows.

Syntax

iscsi cos {enable | disable | dot1p vlan-priority-value [remark] | dscp dscp-value [remark]}

To disable the QoS policy, use the iscsi cos disable command.

Parameters

enable	Enter the keyword enable to allow the application of preferential QoS treatment to iSCSI traffic so that the iSCSI packets are scheduled in the switch with a dot1p priority 4 regardless of the VLAN priority tag in the packet. Default: iSCSI packets are handled with dotp1 priority 4 without remark.
disable	Enter the keyword disable to disable the application of preferential QoS treatment to iSCSI frames.
dot1p vlan-priority-value	Enter the dot1p value of the VLAN priority tag assigned to the incoming packets in an iSCSI session.
	Range: 0 to 7.
	Default: The dot1p value in ingress iSCSI frames is not changed and is used in iSCSI TLV advertisements if you did not enter the iscsi priority-bits command.
dscp dscp-value	Enter the DSCP value assigned to the incoming packets in an iSCSI session.
	The valid range is 0 to 63.
	Default: The DSCP value in ingress packets is not changed.
remark	Marks the incoming iSCSI packets with the configured dot1p or DSCP value when they egress to the switch.
	Default: The dot1and DSCP values in egress packets are not changed.

Defaults

See above.

Command Modes

CONFIGURATION

Command History

Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

Usage Information By default, iSCSI flows are assigned to dot1p priority 4. Dell Networking recommends changing the dot1p priority-queue setting to 0 (zero).

iscsi enable

(S60)

[54810]

Globally enable iSCSI optimization.

Syntax

iscsi enable

To disable iSCSI optimization, use the no iscsi enable command.

Parameters

enable Enter the keyword enable to enable the iSCSI optimization feature.

Defaults

Disabled.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.8	Introduced on the S60
Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

Usage Information

- LLDP must be enabled before using this command.
- LLDP cannot be disabled if iSCSI is enabled.

iscsi priority-bits

[54810]

Configure the priority bitmap to be advertised in iSCSI application TLVs.

Syntax iscsi priority-bits

To remove the configured priority bitmap, use the no iscsi priority-bits command.

Defaults 4 (0x10 in the bitmap)

Command Modes PROTOCOL LLDP (only on global, not on interface)

Command History

Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

iscsi profile-compellent

S55 S60

Configure the auto-detection of Compellent arrays on a port.

[54810]

Syntax iscsi profile-compellent

Defaults Compellent disk arrays are not detected.

Command Modes INTERFACE

Version 8.3.5.3	Introduced on the S55
Version 8.3.3.8	Introduced on the S60
Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

iscsi target port

[54810]

Configure the iSCSI target ports and optionally, the IP addresses on which iSCSI communication will be monitored.

Syntax

iscsi target port [tcp-port-2...tcp-port-16]ip-address [ip-address]

To remove the configured iSCSI target ports or IP addresses, use the no iscsi target port command.

Parameters

tcp-port-2tcp- port-16	Enter the tcp-port number of the iSCSI target ports. The tcp-port-n is the TCP port number or a list of TCP port numbers on which the iSCSI target listens to requests. Separate port numbers with a comma. Default: 860, 3260.
ip-address	(Optional) Enter the ip-address that the iSCSI will monitor.
	The ip-address specifies the IP address of the iSCSI target.

Defaults

860, 3260.

Command Modes

CONFIGURATION

Command History

Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

Usage Information

You can configure up to 16 target TCP ports on the switch in one command or multiple commands.

When you use the no iscsi target port command and the TCP port to be deleted is one bound to a specific IP address, the IP address value must be included in the command.

show iscsi

(54810)

Display the currently configured iSCSI settings.

Syntax

show iscsi

Command Mode

EXEC

EXEC Privilege

Command History

Version 8.3.12.0	Introduced on the S4810. Support added for cam modification.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

Example

FTOS#show iscsi

iSCSI is enabled

iSCSI session monitoring is disabled iSCSI COS : dot1p is 4 no-remark

Session aging time: 10

Maximum number of connections is 256

iSCSI Targets and TCP Ports:

TCP Port Target IP Address 3260 860

Related **Commands**

show iscsi session	Display information on active iSCSI sessions on the switch.
show iscsi session detailed	Display detailed information on active iSCSI sessions on the switch.
show run iscsi	show run iscsi

show iscsi session

[54810]

Display information on active iSCSI sessions on the switch.

Syntax show iscsi session

Command Mode EXEC

EXEC Privilege

Command **History**

Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

Usage Information

Only sessions observed by the switch will be learnt; sessions flowing through an adjacent switch will not be learnt. Session monitoring learns sessions that actually flow through the switch, it does not learn all sessions in the entire topology.

After a switch is reloaded, any information exchanged during the initial handshake is not available. If the switch picks up the communication after reloading, it would detect a session was in progress but could not obtain complete information for it. Any incomplete information of this type would not be available in the "show" commands.

Example

FTOS# show isci session

Session 0:

Target: iqn.2001-05.com.equallogic:0-8a0906-0e70c2002-10a0018426a48c94-iom010

Initiator: iqn.1991-05.com.microsoft:win-x918v27yajg

ISID: 400001370000

Session 1:

Target: iqn.2001-05.com.equallogic:0-8a0906-0f60c2002-0360018428d48c94-iom011

Initiator: iqn.1991-05.com.microsoft:win-x9l8v27yajg

ISID: 400001370000.

Related Commands

show iscsi	Display the currently configured iSCSI settings.
show iscsi session detailed	Display detailed information on active iSCSI sessions on the switch.
show run iscsi	show run iscsi

show iscsi session detailed

EXEC

[54810]

Display detailed information on active iSCSI sessions on the switch.

Syntax

show iscsi session detailed [session isid]

Parameters

Enter the session's iSCSi ID to display detailed information on specified iSCSi session. isid

Command Mode

EXEC Privilege

Command History

Version 8.3.12.0 Introduced on the S4810. Version 8.3.16.0 Introduced on MXL 10/40GbE Switch IO Module

Example

FTOS# show isci session detailed :

Target:iqn.2010-11.com.ixia:ixload:iscsi-TG1

Initiator:iqn.2010-11.com.ixia.ixload:initiator-iscsi-2c

Up Time:00:00:01:28(DD:HH:MM:SS)

Time for aging out:00:00:09:34(DD:HH:MM:SS)

ISID:806978696102

Connection Initiator Initiator Tarqet Tarqet IP Address TCP Port IP Address TCPPort 10.10.0.44 33345 10.10.0.101 3260

Session 1

Target:iqn.2010-11.com.ixia:ixload:iscsi-TG1

Initiator:ign.2010-11.com.ixia.ixload:initiator-iscsi-35

Up Time:00:00:01:22(DD:HH:MM:SS)

Time for aging out:00:00:09:31(DD:HH:MM:SS)

ISID:806978696102

Connection Initiator Initiator Target Target P Port IP Address TCPPort 33432 10.10.0.101 3260 IP Address TCP Port ID 10.10.0.53

Related **Commands**

show iscsi	Display the currently configured iSCSI settings.
show iscsi session	Display information on active iSCSI sessions on the switch.
show run iscsi	show run iscsi

show run iscsi

S60

[54810]

Display all globally-configured non-default iSCSI settings in the current FTOS session.

Syntax

show run iscsi

Command Mode

EXEC Privilege

Version 8.3.3.8	Introduced on the S60.
Version 8.3.12.0	Introduced on the S4810.
Version 8.3.16.0	Introduced on MXL 10/40GbE Switch IO Module

```
Example FTOS(conf) # show run iscsi
```

iscsi enable FTOS(conf) #

Link Aggregation Control Protocol (LACP)

Overview

This chapter contains commands for Dell Networking's implementation of Link Aggregation Control Protocol (LACP) for the creation of dynamic link aggregation groups (LAGs — called port-channels in FTOS parlance). For static LAG commands, see the section Port Channel Commands in the Interfaces chapter), based on the standards specified in the IEEE 802.3 Carrier sense multiple access with collision detection (CSMA/CD) access method and physical layer specifications.

Commands in this chapter generally are supported on all three Dell Networking platforms — C-Series, E-Series, and S-Series — as indicated by the following symbols under command headings: [C][E][S]

Commands

Use the following commands for LACP:

- clear lacp counters
- debug lacp
- lacp long-timeout
- lacp port-priority
- lacp system-priority
- lacp ungroup member-independent
- port-channel mode
- port-channel-protocol lacp
- show lacp

In addition, an FTOS option provides hitless dynamic LACP states (no noticeable impact to dynamic LACP states after an RPM failover) on E-Series.

clear lacp counters

Clear Port Channel counters.

Syntax clear lacp port-channel-number counters

Parameters

port-channel-number Enter the Port Channel number to clear the counters. C-Series and S-Series Range: 1-128 E-Series Range: 1-255 for TeraScale

Defaults Without a Port Channel specified, the command clears all Port Channel counters.

Command Modes EXEC

EXEC Privilege

Command History

Related Commands

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced on E-Series
show lacp	Display the lacp configuration

debug lacp

CES

Debug LACP (configuration, events etc.)

Syntax debug lacp [config | events | pdu [in | out | [interface [in | out]]]]

To disable LACP debugging, use the **no debug lacp [config | events | pdu [in | out | [interface [in | out]]]]** command.

Parameters

config	(OPTIONAL) Enter the keyword config to debug the LACP configuration.
events	(OPTIONAL) Enter the keyword events to debug LACP event information.
pdu in out	(OPTIONAL) Enter the keyword pdu to debug LACP Protocol Data Unit information. Optionally, enter an in or out parameter to:
	• Receive enter in
	• Transmit enter out
interface in out	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	Optionally, enter an in or out parameter:
	• Receive enter in
	• Transmit enter Out

Defaults This command has no default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced on E-Series

lacp long-timeout

Configure a long timeout period (30 seconds) for an LACP session.

Syntax lacp long-timeout

To reset the timeout period to a short timeout (1 second), use the **no lacp long-timeout** command.

Defaults 1 second

Command Modes INTERFACE (conf-if-po-number)

> Command History

Version 7.6.1.0 Support added for S-Series Version 7.5.1.0 Support added for C-Series Version 7.5.1.0 Introduced on E-Series

Usage Information This command applies to dynamic port-channel interfaces only. When applied on a static port-channel, the command has no effect.

Related Commands

Display the lacp configuration show lacp

lacp port-priority

CES

Configure the port priority to influence which ports will be put in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.

Syntax lacp port-priority priority-value

To return to the default setting, use the **no lacp port-priority** priority-value command.

Parameters

Enter the port-priority value. The higher the value number the lower the priority. priority-value Range: 1 to 65535 Default: 32768

Defaults 32768

Command Modes INTERFACE

> Command **History**

Version 8.3.3.1 Introduced on the S60. Version 7.6.1.0 Support added for S-Series Version 7.5.1.0 Support added for C-Series Version 6.2.1.1 Introduced on E-Series

lacp system-priority

CES Configure the LACP system priority.

Syntax lacp system-priority priority-value

To return to the default setting, use the **no lacp system-priority** priority-value command.

Parameters

priority-value Enter the port-priority value. The higher the value, the lower the priority.

Range: 1 to 65535

Default: 32768

Defaults 32768

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced on E-Series

lacp ungroup member-independent

S55

S60

Enable BMP boot for the device connected to the LACP LAG.

(54810)

Syntax lacp ungroup member-independent {port-channel port-channel-id}

Defaults Not configured.

Command Modes CONFIGURATION

Usage Information During boot-up in a stacking configuration, the system must be able to reach the DHCP server with the image and configuration image. During bootup, only untagged DHCP requests are sent to the DHCP server to receive an offer on static LAGs between switches. The DHCP server must be configured to start in JumpStart mode. If switches are connected using LACP port-channel like ToR, use the **port-channel** parameter on the TOR side of the configuration to allow member ports of a completely un-grouped lacp port-channel to inherit vlan membership of that port channel to ensure untagged packets reach the DHCP server located on the TOR. To ungroup the port-channel configurations, use the **no lacp ungroup member-independent** command.

Command History

Version 8.3.5.3	Introduced on S55
Version 8.3.3.8	Introduced on S60
Version 8.3.12.0	Added port-channel parameter.
Version 8.3.8.0	Introduced on S4810

port-channel mode

Configure the LACP port channel mode. CES

Syntax port-channel number mode [active] [passive] [off]

Parameters

number	Enter the port-channel number.
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
active	Enter the keyword active to set the mode to the active state.*
passive	Enter the keyword passive to set the mode to the passive state.*
off	Enter the keyword off to set the mode to the off state.*

^{*} The LACP modes are defined in the table below.

Defaults off

Command Modes INTERFACE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Usage Information

The LACP modes are defined in the following table.

Table 19-1. LACP Modes

Mode	Function
active	An interface is in an active negotiating state in this mode. LACP runs on any link configured in the active state and also automatically initiates negotiation with other ports by initiating LACP packets.
passive	An interface is not in an active negotiating state in this mode. LACP runs on any link configured in the passive state. Ports in a passive state respond to negotiation requests from other ports that are in active states. Ports in a passive state respond to LACP packets.
off	An interface can not be part of a dynamic port channel in the off mode. LACP will not run on a port configured in the off mode.

port-channel-protocol lacp

CES Enable LACP on any LAN port.

Syntax port-channel-protocol lacp

To disable LACP on a LAN port, use the **no port-channel-protocol lacp** command.

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 6.2.1.1	Introduced

Related Commands

show lacp	Display the LACP information.
show interfaces port-channel	Display information on configured Port Channel groups.

show lacp

CES

Display the LACP matrix.

Syntax

show lacp port-channel-number [sys-id | counters]

Parameters

port-channel-number	Enter the port-channel number to display the LACP matrix.
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
sys-id	(OPTIONAL) Enter the keyword sys-id and the value that identifies a system.
counters	(OPTIONAL) Enter the keyword counters to display the LACP counters.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Example 1 Figure 19-1. show lacp port-channel-number command

```
FTOS#show lacp 1
Port-channel 1 admin up, oper up, mode lacp
Actor System ID: Priority 32768, Address 0001.e800.a12b
Partner System ID: Priority 32768, Address 0001.e801.45a5
                           Actor Admin Key 1, Oper Key 1, Partner Oper Key 1
                           LACP LAG 1 is an aggregatable link
A - Active LACP, B - Passive LACP, C - Short Timeout, D - Long Timeout
E - Aggregatable Link, F - Individual Link, G - IN_SYNC, H - OUT_OF_SYNC
I - Collection enabled, J - Collection disabled, K - Distribution enabled L - Distribution disabled, M - Partner Defaulted, N - Partner Non-defaulted, O - Receiver is in expired state,
P - Receiver is not in expired state
Port Gi 10/6 is enabled, LACP is enabled and mode is lacp
            Admin: State ACEHJLMP Key 1
  Actor
                                                          Priority 128
               Oper: State ACEGIKNP Key 1
                                                          Priority 128
   Partner Admin: State BDFHJLMP Key 0
                                                          Priority 0
               Oper: State BCEGIKNP Key 1
                                                         Priority 128
FTOS#
```

Example 2 Figure 19-2. show lacp sys-id command Example

```
FTOS#show lacp 1 sys-id
Actor System ID: Priority 32768, Address 0001.e800.a12b
Partner System ID: Priority 32768, Address 0001.e801.45a5
```

Example 3 Figure 19-3. show lacp counter command Example

```
FTOS#show lacp 1 counters
LACP PDU Marker PDU Unknown Illegal
Port Xmit Recv Xmit Recv Pkts Rx Pkts Rx
Gi 10/6 200 200 0 0 0
FTOS#
```

Related Commands

clear lacp counters	Clear the LACP counters.
show interfaces port-channel	Display information on configured Port Channel groups.

Layer 2

Overview

This chapter describes commands to configure Layer 2 features. It contains the following sections:

- **MAC Addressing Commands**
- Virtual LAN (VLAN) Commands

Some MAC addressing commands are supported only on the E-Series, some on all three Dell Networking platforms, and some on two Dell Networking platforms. Support is indicated by these characters, where appropriate, under each command heading: [C][E][S]

The VLAN commands are supported on all three Dell Networking platforms — C E S

MAC Addressing Commands

The following commands are related to configuring, managing, and viewing MAC addresses:

- clear mac-address-table dynamic
- mac accounting destination
- mac-address-table aging-time
- mac-address-table static
- mac-address-table station-move threshold
- mac-address-table station-move time-interval
- mac-address-table station-move refresh-arp
- mac cam fib-partition
- mac learning-limit
- mac learning-limit learn-limit-violation
- mac learning-limit station-move-violation
- mac learning-limit reset
- show cam mac linecard (count)
- show cam maccheck linecard
- show cam mac linecard (dynamic or static)
- show cam mac stack-unit
- show mac-address-table
- show mac-address-table aging-time
- show mac accounting destination
- show mac cam
- show mac learning-limit

clear mac-address-table dynamic

CES

Clear the MAC address table of all MAC address learned dynamically.

Syntax

clear mac-address-table dynamic {address mac-address | all | interface | vlan vlan-id}

Parameters

address mac-address	Enter the keyword address followed by a MAC address in nn:nn:nn:nn:nn format.
all	Enter the keyword all to delete all MAC address entries in the MAC address table.
interface interface	Enter the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
vlan vlan-id	Enter the keyword vlan followed by a VLAN ID number from 1 to 4094.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

mac accounting destination

E Configure a destination counter for Layer 2 traffic.

Syntax

mac accounting destination { mac-address vlan vlan-id | vlan} [bytes | packets]

To delete a destination counter, enter **no mac accounting destination**.

mac-address	Enter the MAC address in the nn:nn:nn:nn:nn:nn format to count Layer 2 packets or bytes sent to that MAC address.
vlan vlan-id	Enter the keyword vian followed by the VLAN ID to count Layer 2 packets or bytes sent to the VLAN. Range: 1 to 4094.
bytes	(OPTIONAL) Enter the keyword bytes to count only bytes
packets	(OPTIONAL) Enter the keyword packets to count only packets.

Defaults Not configured.

Command Modes INTERFACE (available on physical interfaces only)

> Command History

Version 7.4.1.0 Introduced on E-Series

Usage You must place the interface in Layer 2 mode (using the switchport command) prior to configuring the Information mac accounting destination command.

mac-address-table aging-time

CESSpecify an aging time for MAC addresses to be removed from the MAC Address Table.

Syntax mac-address-table aging-time seconds

Parameters

Enter either zero (0) or a number as the number of seconds before MAC addresses are seconds relearned. To disable aging of the MAC address table, enter 0.

E-Series Range from CONFIGURATION mode: 10 - 1000000 E-Series Range from INTERFACE VLAN mode: 1 - 1000000

C-Series and S-Series Range: 10 - 1000000

Default: 1800 seconds

Defaults 1800 seconds

Command Modes CONFIGURATION

INTERFACE VLAN (E-Series only)

Command History

Version 8.3.1.0	On the E-Series, available in INTERFACE VLAN context and reduced minimum aging time in INTERFACE VLAN context from 10 seconds to 1 second.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

mac learning-limit	Set the MAC address learning limits for a selected interface.
show mac-address-table aging-time	Display the MAC aging time.

mac-address-table static

CES Associate specific MAC or hardware addresses to an interface and VLANs.

Syntax mac-address-table static mac-address output interface vlan vlan-id

> To remove a MAC address, use the no mac-address-table static mac-address output interface vlan vlan-id command.

Parameters		
i didilicters	mac-address	Enter the 48-bit hexidecimal address in nn:nn:nn:nn:nn:nn format.
	output interface	Enter the keyword output followed by one of the following interfaces:
		 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
		 For a Port Channel interface, enter the keyword port-channel followed by a number:
		C-Series Range: 1-128
		E-Series Range: 1 to 255 for TeraScale.
		 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
		 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	vlan vlan-id	Enter the keyword vlan followed by a VLAN ID.
		Range:1 to 4094.
Defaults	Not configured.	
Command Modes	CONFIGURATION	
Command History	Version 8.3.3.1	Introduced on the S60.
inotory	Version 7.6.1.0	Introduced on S-Series
	Version 7.5.1.0	Introduced on C-Series
	pre-Version 6.2.1.1	Introduced on E-Series
Dalatad		
Related Commands	show mac-address-table	Displays the MAC address table.

mac-address-table station-move threshold

Change the frequency with which the MAC address station-move trap is sent after a MAC address changes in a VLAN. A trap is sent if a station move is detected above a threshold number of times in a given interval.

Syntax [no] mac-address-table station-move threshold *number* interval *count*

Parameters

threshold number	Enter the keyword threshold followed by the number of times MAC addresses in VLANs can change before an SNMP trap is sent. Range: 1 to 10
interval seconds	Enter the keyword interval followed by the number of seconds.
	Range: 5 to 60

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information For information on the specific trap sent and the corresponding Syslog refer to Appendix A, SNMP

Traps.

mac-address-table station-move time-interval

Reduce the amount of time FTOS takes to detect aged entries and station moves.

Syntax [no] mac-address-table station-move time-interval number

Parameters time-interval number Select the interval of the successive scans of the MAC address table that are

used to detect a aged entries and station moves.

Range: 500 to 5000ms

Defaults 5000ms

Command Modes CONFIGURATION

> Command History

Version 7.8.1.0 Introduced on E-Series

Usage Information FTOS takes 4 to 5 seconds to detect aged entries and station moves because the MAC address table scanning routine runs every 5000 ms by default. To achieve faster detection, reduce the scanning

interval.

mac-address-table station-move refresh-arp

Ensure that ARP refreshes the egress interface when a station move occurs due to a topology change. CES

Syntax [no] mac-address-table station-move refresh-arp

Defaults No default values or behavior

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Usage Information See the "NIC Teaming" section of the Layer 2 chapter in the FTOS Configuration Guide for details on using this command.

mac cam fib-partition

Reapportion the amount of Content Addressable Memory (CAM) available for MAC address learning (FIB) versus the amount available for MAC ACLs on a line card.

Syntax mac cam fib-partition {25 | 50 | 75 | 100} slot-number To return to the default setting, enter **no mac cam fib-partition**.

Parameters

Enter the keyword 25 to set aside 25% of the CAM for MAC address learning.
Enter the keyword 50 to set aside 50% of the CAM for MAC address learning.
Enter the keyword 75 to set aside 75% of the CAM for MAC address learning.
Enter the keyword 100 to set aside 100% of the MAC CAM for MAC address learning. With this configuration, no MAC ACLs are processed.
Enter the line card slot number. Range: 0 to 13 for the E1200 0 to 6 for the E600 0 to 5 for the E300

Defaults

75 (75% of the MAC CAM for MAC address learning)

Command Modes

CONFIGURATION

Usage Information After setting the CAM partition size, the line card resets.

Related Commands

show mac cam Display the current MAC CAM partition values.

mac learning-limit

CES

Limit the maximum number of MAC addresses (static + dynamic) learned on a selected interface.

Syntax

mac learning-limit address_limit [vlan vlan-id] [station-move [dynamic]] [no-station-move [dynamic]] | [dynamic [no-station-move | station-move]]

Parameters

address_limit	Enter the maximum number of MAC addresses learned.
	Range: 1 to 1000000
vlan vlan-id	On the E-Series only, enter the keyword followed by the VLAN ID.
	Range: 1-4094
dynamic	(OPTIONAL) Enter the keyword dynamic to allow aging of MACs even though a learning limit is configured.
no-station-move	(OPTIONAL) Enter the keyword no-station-move to disallow a station move (associate the learned MAC address with the most recently accessed port) on learned MAC addresses.
station-move	(OPTIONAL) Enter the keyword station-move to allow a station move on learned MAC addresses.

Defaults

On C-Series, the default behavior is **no-station-move** + static.

On E-Series, the default behavior is **station-move** + static.

"Static" means manually entered addresses, which do not age.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added vlan option on E-Series.
Version 8.2.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series; added station-move option
Version 6.5.1.0	Added support for MAC Learning-Limit on LAG

Usage Information

This command and its options are supported on physical interfaces, static LAGs, LACP LAGs, and VLANs.

If the **vlan** option is not specified, then the MAC address counters is not VLAN-based. That is, the sum of the addresses learned on all VLANs (not having any learning limit configuration) is counted against the MAC learning limit.

MAC Learning Limit violation logs and actions are not available on a per-VLAN basis.

With the keyword **no-station-move** option, MAC addresses learned through this feature on the selected interface will persist on a per-VLAN basis, even if received on another interface. Enabling or disabling this option has no effect on already learned MAC addresses.

Once the MAC address learning limit is reached, the MAC addresses do not age out unless you add the dynamic option. To clear statistics on MAC address learning, use the clear counters command with the learning-limit parameter.



Note: If you configure this command on an interface in a routed VLAN, and once the MAC addresses learned reaches the limit set in the mac learning-limit command, IP protocols are affected. For example, VRRP sets multiple VRRP Masters, and OSPF may not come up.

When a channel member is added to a port-channel and there is not enough ACL CAM space, then the MAC limit functionality on that port-channel is undefined. When this occurs, unconfigure the existing configuration first and then reapply the limit with a lower value.

Related **Commands**

clear counters	Clear counters used in the show interface command
clear mac-address-table dynamic	Clear the MAC address table of all MAC address learned dynamically.
show mac learning-limit	Display MAC learning-limit configuration.

mac learning-limit learn-limit-violation



Configure an action for a MAC address learning-limit violation.

Syntax

mac learning-limit learn-limit-violation {log | shutdown}

To return to the default, use the no mac learning-limit learn-limit-violation {log | shutdown} command.

log	Enter the keyword log to generate a syslog message on a learning-limit violation.
shutdown	Enter the keyword shutdown to shut down the port on a learning-limit violation.

Defaults No default behavior or values

Command Modes INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on S-Series
Version 7.8.1.0	Introduced on C-Series
Version 7.5.1.0	Introduced on E-Series

Usage Information This is supported on physical interfaces, static LAGs, and LACP LAGs.

Related Commands

show mac learning-limit Display details of the mac learning-limit

mac learning-limit station-move-violation

© E S Specify the actions for a station move violation.

Syntax mac learning-limit station-move-violation {log | shutdown-both | shutdown-offending | shutdown-original}

To disable a configuration, use the **no mac learning-limit station-move-violation** command, followed by the configured keyword.

Parameters

log	Enter the keyword log to generate a syslog message on a station move violation.
shutdown-both	Enter the keyword shutdown to shut down both the original and offending interface and generate a syslog message.
shutdown-offending	Enter the keyword shutdown-offending to shut down the offending interface and generate a syslog message.
shutdown-original	Enter the keyword shutdown-original to shut down the original interface and generate a syslog message.

Defaults No default behavior or values

Command Modes INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on S-Series
Version 7.8.1.0	Introduced on C-Series
Version 7.5.1.0	Introduced on E-Series

Usage Information This is supported on physical interfaces, static LAGs, and LACP LAGs.

Related Commands

show mac learning-limit Display details of the mac learning-limit

mac learning-limit reset

CES Reset the MAC address learning-limit error-disabled state.

Syntax mac learning-limit reset

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series
Version 7.5.1.0	Introduced on E-Series

show cam mac linecard (count)

Display the CAM size and the portions allocated for MAC addresses and for MAC ACLs. (E)

Syntax show cam mac linecard slot port-set port-pipe count [vlan vlan-id] [interface interface]

Parameters

linecard slot	(REQUIRED) Enter the keyword linecard followed by a slot number to select the linecard for which to gather information.
	E-Series range: 0 to 6.
port-set port-pipe	(REQUIRED) Enter the keyword port-set followed by a Port-Pipe number to select the Port-Pipe for which to gather information.
	E-Series range: 0 or 1
count	(REQUIRED) Enter the keyword count to display CAM usage by interface type.
interface interface	(OPTIONAL) Enter the keyword interface followed by the interface type, slot and port information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
vlan vlan-id	(OPTIONAL) Enter the keyword vlan followed by the VLAN ID to display the MAC address assigned to the VLAN.
	Range: 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

pre-Version 6.2.1.1 Introduced on E-Series

show cam maccheck linecard

C

Display the results of the BCMI2 check command.

Note: This command was deprecated in FTOS version 8.3.3.9.

Syntax

show cam maccheck linecard slot port-set port-pipe

Parameters

linecard slot	(REQUIRED) Enter the keyword linecard followed by a slot number to select the linecard for which to gather information. C300 range: 0 to 7; C150 range: 0 to 4
port-set port-pipe	(REQUIRED) Enter the keyword port-set followed by a Port-Pipe number to select the Port-Pipe for which to gather information. Range: 0 or 1

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.9	Deprecated command
Version 7.6.1.0	Introduced on C-Series

Example

Figure 20-1. show cam maccheck linecard Command Output Example

Usage Information

Use this command to check various flags associated with each MAC address in the CAM.

Figure 20-1 shows information for two MAC addresses. The second entry is for MAC address 00:00:00:00:00:00:00 (leading 0s are not shown), which is shown as learned on VLAN ID 4094 (0xfff), as shown below in Figure 20-2 and Figure 20-3. Above, "STATIC_BIT=0" means that the address is dynamically learned.

When an entry is listed as STATIC_BIT=1, its HIT_SA is 0, which signifies that this address is not getting continuously learned trough traffic. The HIT_DA is set when a new learn happens, and after the first age sweep, it gets reset.

Example Figure 20-2. show mac-address-table Command Output Example

```
FTOS#show mac-address-table
VlanId
       Mac Address
                      Type Interface
4094
    00:00:a0:00:00:00
                    Dynamic Gi 2/0
                                       Active
 -----!
```

Figure 20-3. show cam mac linecard Command Output Example Example

```
FTOS#show cam mac linecard 2 port-set 0
VlanId
       Mac Address
                      Region
                              Interface
0 ff:ff:ff:ff:ff: STATIC
4094 00:00:a0:00:00: DYNAMIC
                               00001
                               Gi 2/0
!-----!
```

show cam mac linecard (dynamic or static)

CE Display the CAM size and the portions allocated for MAC addresses and for MAC ACLs.

Syntax show cam mac linecard slot port-set port-pipe [address mac_addr | dynamic | interface interface | static | vlan vlan-id

linecard slot	(REQUIRED) Enter the keyword linecard followed by a slot number to select the linecard for which to gather information.
	C-Series Range: 0 to 4 (C150); 0 to 8 (C300)
	E-Series Range: 0 to 6
port-set port-pipe	(REQUIRED) Enter the keyword port-set followed by a Port-Pipe number to select the Port-Pipe for which to gather information.
	Range: 0 or 1
address mac-addr	(OPTIONAL) Enter the keyword address followed by a MAC address in the nn:nn:nn:nn:nn format to display information on that MAC address.
dynamic	(OPTIONAL) Enter the keyword dynamic to display only those MAC addresses learned dynamically by the switch.
interface interface	(OPTIONAL) Enter the keyword interface followed by the interface type slot and port information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
static	(OPTIONAL) Enter the keyword static to display only those MAC address specifically configured on the switch.
vlan vlan-id	(OPTIONAL) Enter the keyword vlan followed by the VLAN ID to display the MAC address assigned to the VLAN.
	Range: 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 20-4. show cam mac linecard Command Example

```
FTOS#show cam mac linecard 1 port-set 0
        (TableID) assignments:
00 (01) \ 01 (01) \ 02 (01) \ \bar{03} (01) \ 04 (01) \ 05 (01) \ 06 (01) \ 07 (01) \ 08 (01) \ 09 (01) \ 10 (01) \ 11 (01)
12(01) 13(01) 14(01) 15(01) 16(01) 17(01) 18(01) 19(01) 20(01) 21(01) 22(01) 23(01)
Index Table ID VlanId
                                Mac Address
                                                                 Interface
                                                      Region
                           00:01:e8:0d:b7:3b
                                                    LOCAL DA
                                                                        1e000
                           00:01:e8:0d:b7:3a
                                                    LOCAL DA
                                                                         1e000
101
                           00:01:e8:00:04:00
                                                    SYSTEM STATIC
                                                                         01c05
102
         0
                   0
                           01:80:00:00:00:00
                                                    SYSTEM STATIC
                                                                         01c05
                                                    SYSTEM STATIC
                                                                         01c01
103
         0
                   0
                           01:00:0c:cc:cc
                                                    SYSTEM_STATIC
SYSTEM_STATIC
104
         0
                   0
                           01:80:c2:00:00:02
                                                                         01c02
                           01:80:c2:00:00:0e
105
         0
                   0
                                                                         01c01
                                                    SYSTEM_STATIC
SYSTEM STATIC
106
                   0
                           00:01:e8:0d:b7:68
                                                                        DROP
         0
107
                   0
                           00:01:e8:0d:b7:67
                                                                        DROP
         0
                                                    SYSTEM_STATIC
SYSTEM_STATIC
108
         0
                   0
                           00:01:e8:0d:b7:66
                                                                        DROP
109
                   0
                           00:01:e8:0d:b7:65
                                                                        DROP
         0
                                                    SYSTEM_STATIC
SYSTEM_STATIC
         0
                   0
                           00:01:e8:0d:b7:64
                                                                         DROP
110
                   0
                           00:01:e8:0d:b7:63
                                                                        DROP
111
         0
                                                    SYSTEM_STATIC
SYSTEM_STATIC
SYSTEM_STATIC
                   0
                           00:01:e8:0d:b7:62
         0
                                                                        DROP
112
         0
                   0
                           00:01:e8:0d:b7:61
                                                                         DROP
113
114
         0
                   0
                           00:01:e8:0d:b7:60
                                                                        DROP
                                                    SYSTEM_STATIC
SYSTEM_STATIC
115
         0
                   0
                           00:01:e8:0d:b7:5f
                                                                        DROP
116
         0
                   0
                           00:01:e8:0d:b7:5e
                                                                        DROP
                   Ω
                                                    SYSTEM_STATIC
117
         0
                           00:01:e8:0d:b7:5d
                                                                        DROP
FTOS#
```

show cam mac stack-unit

Display the Content Addressable Memory (CAM) size and the portions allocated for MAC addresses and for MAC ACLs.

Syntax

S

show cam mac stack-unit *unit_number* **port-set** *port-pipe* **count** [**vlan** *vlan-id*] [**interface** *interface*]

stack-unit unit_number	(REQUIRED) Enter the keyword linecard followed by a stack member number to select the linecard for which to gather information. S-Series Range: 0 to 1
port-set port-pipe	(REQUIRED) Enter the keyword port-set followed by a Port-Pipe number to select the Port-Pipe for which to gather information. Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
address mac-addr	(OPTIONAL) Enter the keyword address followed by a MAC address in the nn:nn:nn:nn:nn:nn format to display information on that MAC address.
dynamic	(OPTIONAL) Enter the keyword dynamic to display only those MAC addresses learned dynamically by the switch.
static	(OPTIONAL) Enter the keyword static to display only those MAC address specifically configured on the switch.

interface interface	(OPTIONAL) Enter the keyword interface followed by the interface type, slot and port information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	S-Series Range: 1-128	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
vlan vlan-id	(OPTIONAL) Enter the keyword vlan followed by the VLAN ID to display the MAC address assigned to the VLAN.	
	Range: 1 to 4094.	
EXEC		
EXEC Privilege		
Version 8.3.3.1	Introduced on the S60.	

show mac-address-table

Version 7.6.1.0

CES

Command

History

Command Modes

Display the MAC address table.

Syntax

show mac-address-table [dynamic | static] [address mac-address | interface interface | vlan vlan-id] [count [vlan vlan-id] [interface interface-type [slot [/port]]]]

This version of the command introduced for S-Series

dynamic	(OPTIONAL) Enter the keyword dynamic to display only those MAC addresses learned dynamically by the switch. Optionally, you can also add one of these combinations: address/ <i>mac-address</i> , interface/ <i>interface</i> , or vlan <i>vlan-id</i> .	
static	(OPTIONAL) Enter the keyword static to display only those MAC address specifically configured on the switch. Optionally, you can also add one of these combinations: address/ <i>mac-address</i> , interface/ <i>interface</i> , or vlan <i>vlan-id</i> .	
address mac-address	(OPTIONAL) Enter the keyword address followed by a MAC address in the nn:nn:nn:nn:nn format to display information on that MAC address.	
interface interface	(OPTIONAL) Enter the keyword interface followed by the interface type, slot and port information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a Port Channel interface, enter the keyword port-channel followed by a number: 	
	C-Series and S-Series Range: 1-128	
	E-Series Range: 1 to 255 for TeraScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	

interface interface-type	(OPTIONAL) Instead of entering the keyword interface followed by the interface type, slot and port information, as above, you can enter the interface type, followed by just a slot number.
vlan vlan-id	(OPTIONAL) Enter the keyword vian followed by the VLAN ID to display the MAC address assigned to the VLAN. Range: 1 to 4094.
count	(OPTIONAL) Enter the keyword count , followed optionally, by an interface or VLAN ID, to display total or interface-specific static addresses, dynamic addresses, and MAC addresses in use.

Command Modes

EXEC

EXEC Privilege

Command History

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 20-5. show mac-address-table Command Example

```
FTOS#show mac-address-table

VlanId Mac Address Type Interface State
999 00:00:00:00:00:19 Dynamic Gi 0/1 Active
999 00:00:00:00:29 Dynamic Gi 0/2 Active

FTOS#
```

Table 20-1. show mac-address-table Information

Column Heading	Description
VlanId	Displays the VLAN ID number.
Mac Address	Displays the MAC address in nn:nn:nn:nn:nn format.
Туре	Lists whether the MAC address was manually configured (Static) or learned (Dynamic).
Interface	Displays the interface type and slot/port information. The following abbreviations describe the interface types:
	gi—Gigabit Ethernet followed by a slot/port.
	po—Port Channel followed by a number. Range: 1 to 255 for TeraScale
	so—Sonet followed by a slot/port.
	• te—10-Gigabit Ethernet followed by a slot/port.
State	Lists if the MAC address is in use (Active) or not in use (Inactive).

Figure 20-6. show mac-address-table count Command Example

```
FTOS#show mac-address-table count
MAC Entries for all vlans:
Dynamic Address Count: 5
Static Address (User-defined) Count: 0
Total MAC Addresses in Use: 5
FTOS#
```

Table 20-2. show mac-address-table count Information

Line Beginning with	Description
MAC Entries	Displays the number of MAC entries learnt per VLAN.
Dynamic Address	Lists the number of dynamically learned MAC addresses.
Static Address	Lists the number of user-defined MAC addresses.
Total MAC	Lists the total number of MAC addresses used by the switch.

Related **Commands**

aging time.

show mac-address-table aging-time

CES Display the aging times assigned to the MAC addresses on the switch.

show mac-address-table aging-time [vlan vlan-id] **Syntax**

Parameters

vlan vlan-id	On the E-Series, enter the keyword vlan followed by the VLAN ID to display the MAC address aging time for MAC addresses on the VLAN.
	Range: 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 8.3.1.0	Added the vlan option on the E-Series.
Version 7.7.1.0	Introduced on C-Series and S-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 20-7. show mac-address-table aging-time Command Example

FTOS#show mac-address-table aging-time Mac-address-table aging time : 1800 FTOS#

Related Commands

show mac-address-table	Display the current MAC address configuration.	

show mac accounting destination

Display destination counters for Layer 2 traffic (available on physical interfaces only). \mathbb{E}

Syntax

show mac accounting destination [mac-address vlan vlan-id] [interface interface [mac-address vlan vlan-id] [vlan vlan-id] [vlan vlan-id]

Parameters 4 8 1

mac-address	(OPTIONAL) Enter the MAC address in the nn:nn:nn:nn:nn:nn format to display information on that MAC address.		
interface interface	(OPTIONAL) Enter the keyword interface followed by the interface type, slot and port information:		
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 		
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 		
vlan vlan-id	(OPTIONAL) Enter the keyword vian followed by the VLAN ID to display the MAC address assigned to that VLAN.		
	Range: 1 to 4094.		

Command Modes

EXEC

EXEC Privilege

Command History

pre-Version 6.2.1.1 Introduced on E-Series

Usage Information

MAC Accounting information can be accessed using SNMP via the Force10 Monitor MIB. For more information on enabling SNMP, refer to Chapter 3 of the *FTOS Configuration Guide*.



Note: Currently, the Force10 MONITOR MIB does not return the MAC addresses in an increasing order via SNMP. As a workaround, you can use the **-C c** option in **snmpwalk** or **snmpbulkwalk** to access the Force10 MONITOR MIB. For example:

% snmpwalk -C c -v 2c -c public 133.33.33.131 enterprise.6027.3.3.3

Example

Figure 20-8. show mac accounting destination Command Example

FTOS#show mac acco	ounting	g desti	nation	interface	gigabitethernet 2/1	
Destination	Out	Port	VLAN	Packets	Bytes	
00:44:00:00:00:00 00:44:00:00:00:01 00:22:00:00:00:00 00:44:00:00:00:00 00:44:00:00:00:01	Te Te Te Te	11/0 11/0 11/0 11/0 11/0	1000 1000 1000 2000 2000	10000 10000 10000 10000	5120000 5120000 5120000 5120000 5120000	
FTOS#						/

Related Commands

show mac accounting access-list

Display MAC access list configurations and counters (if configured).

show mac cam

E Display the CAM size and the portions allocated for MAC addresses and for MAC ACLs.

Syntax show mac cam

Command Modes EXEC

EXEC Privilege

Command History

pre-Version 6.2.1.1 Introduced on E-Series

Example Figure 20-9. show mac cam Command Example

```
FTOS#show mac cam
                MAC CAM Size
Slot
      Type
                                 MAC FIB Entries
                                                      MAC ACL Entries
     E24PD
 0
                 64K entries
                                      48K (75%)
                                                             8K (25%)
2 E24PD2 128K entries
11 EX2YD 64K entries
                                      64K (50%)
16K (25%)
                                                            32K (50%)
24K (75%)
Note: All CAM entries are per portpipe.
FTOS#
```

Table 20-3. show mac cam Information

Field	Description
Slot	Lists the active line card slots.
Туре	Lists the type of line card present in the slot.
MAC CAM Size	Displays the total CAM size available.
	Note : A portion of the MAC CAM is used for system operations, therefore adding the MAC FIB and MAC ACL will be less than the MAC CAM.
MAC FIB Entries	Displays the amount and percentage of CAM available for MAC addresses.
MAC ACL Entries	Displays the amount and percentage of CAM available for MAC ACLs.

show mac learning-limit

CE Display MAC address learning limits set for various interfaces.

show mac learning-limit [violate-action] [detail] [interface interface [vlan vlan-id]]

Parameters

Syntax

violate-action	(OPTIONALY) Enter the keyword violate-action to display the MAC learning limit violation status.		
detail	(OPTIONAL) Enter the keyword detail to display the MAC learning limit in detail.		
interface interface	(OPTIONAL) Enter the keyword interface with the following keywords and slot/port or number information:		
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 		
	 For SONET interfaces, enter the keyword sonet followed by the slot/ port information. 		
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 		
	 For a Port Channel interface, enter the keyword port-channel followed by a Port Channel ID between 1 and 255. 		
vlan vlan-id	On the E-Series, enter the keyword vlan followed by the VLAN ID.		
	Range: 1-4094		

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.1.0	Added vlan option on E-Series.
Version 7.7.1.0	Introduced on C-Series
Version 7.5.1.0	Added support for violate-action and detail options
Version 6.5.1.0	Added support for Port Channel

Example

E-Series output:

FTOS#show mad	c learnin	ıg-1	imit			
Interface	Vlan		Learning	Dynamic	Static	Unknown SA
Slot/port	Id		Limit	MAC count	MAC count	Drops
Gi 5/84	2	2		0	0	0
Gi 5/84	*	5		0	0	0
Gi 5/85	3	3		0	0	0
Gi 5/85	*	10		0	0	0
FTOS#show mad	c learnin	ıg-1	imit interface	gig 5/84		
Interface	Vlan		Learning	Dynamic	Static	Unknown SA
Slot/port	Id		Limit	MAC count	MAC count	Drops
Gi 5/84	2	2		0	0	0
Gi 5/84	*	5		0	0	0
FTOS#show mad	c learnin	ıg-1	imit interface	gig 5/84 vlan 2	2	
Interface	Vlan		Learning	Dynamic	Static	Unknown SA
Slot/port	Id		Limit	MAC count	MAC count	Drops
Gi 5/84	2	2		0	0	0

Example C-Series/S-Series output:

FTOS#show mac	learning-limit							
Interface	Learning	Dynamic	Static		Unknown	SA		
Slot/port	Limit	MAC count	MAC count		Drops			
Gi 1/0	10	0		0			0	
Gi 1/1	5	0		0			0	
FTOS#show mac	learning-limit	interface gig	1/0					
Interface	Learning	Dynamic	Static		Unknown	SA		
Slot/port	Limit	MAC count	MAC count		Drops			
Gi 1/0	1.0	0		Ο				Ω

Virtual LAN (VLAN) Commands

The following commands configure and monitor Virtual LANs (VLANs). VLANs are a virtual interface and use many of the same commands as physical interfaces.

You can configure an IP address and Layer 3 protocols on a VLAN called Inter-VLAN routing. FTP, TFTP, ACLs and SNMP are not supported on a VLAN.

Occasionally, while sending broadcast traffic over multiple Layer 3 VLANs, the VRRP state of a VLAN interface may continually switch between Master and Backup.

- description
- · default vlan-id
- default-vlan disable
- enable vlan-counters
- name
- show config
- · show vlan
- tagged
- track ip
- untagged

See also VLAN Stacking and see VLAN-related commands, such as portmode hybrid, in Chapter 14, Interfaces.

description CES

Add a description about the selected VLAN.

Syntax description description

To remove the description from the VLAN, use the **no description** command.

Parameters

description Enter a text string description to identify the VLAN (80 characters maximum).

Defaults No default behavior or values

Command Modes INTERFACE VLAN

> Command History

Version 8.3.3.1 Introduced on the S60. Version 7.6.1.0 Introduced on C-Series and S-Series Version 6.3.1.0 Introduced on E-Series

Related **Commands**

Display VLAN configuration. show vlan

default vlan-id

CES Specify a VLAN as the Default VLAN.

Syntax default vlan-id vlan-id

> To remove the default VLAN status from a VLAN and VLAN 1 does not exist, use the no default vlan-id vlan-id syntax.

Parameters

vlan-id Enter the VLAN ID number of the VLAN to become the new Default VLAN. Range: 1 to 4094. Default: 1

Defaults The Default VLAN is VLAN 1.

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information To return VLAN 1 as the Default VLAN, use this command syntax (**default-vlan-id 1**).

The Default VLAN contains only untagged interfaces.

Related Commands

interface vlan Configure a VLAN.

default-vlan disable

CES

Disable the default VLAN so that all switchports are placed in the Null VLAN until they are explicitly configured as a member of another VLAN.

Defaults The default VLAN is enabled.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on the S60.

Version 8.3.1.0 Introduced

Usage Information **no default vlan disable** is not listed in the running-configuration, but when the default VLAN is disabled, **default-vlan disable** is listed in the running-configuration.

enable vlan-counters

Display VLAN counters for ingress and/or egress hardware. You must be in restricted mode to use this command.

Syntax enable vlan-output-counters [ingress | egress | all]

To return to the default (disabled), use the **no enable vlan-output-counters** command.

Defaults Disabled—VLAN counters are disabled in hardware (all linecards/port-pipes) by default.

Command Modes CONFIGURATION

Command History

_	Version 8.1.1.2	Introduced on E-Series ExaScale E600i
	Version 8.1.1.0	Introduced on E-Series ExaScale E1200i

Example

```
FTOS(conf)#enable vlan-output-counters
FTOS(conf)#exit
FTOS#show interface vlan 101
Vlan 101 is down, line protocol is down
Address is 00:01:e8:26:e0:5b, Current address is 00:01:e8:26:e0:5b
Interface index is 1107787877
Internet address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 01:12:44
Queueing strategy: fifo
Input Statistics:
    0 packets, 0 bytes
                                  Enabling VLAN output reveals the output statistics counters for the VLAN
Output Statistics:
     0 packets, 0 bytes
Time since last interface status change: 01:12:44
FTOS#
FTOS#show interfaces vlan 1
Vlan 1 is down, line protocol is down
Address is 00:01:e8:13:a5:aa, Current address is 00:01:e8:13:a5:aa
Interface index is 1107787777
Internet address is not set
MTU 1554 bytes, IP MTU 1500 bytes
LineSpeed 1000 Mbit
ARP type: ARPA, ARP Timeout 04:00:00
Last clearing of "show interface" counters 01,36:01
Queueing strategy: fifo
Input Statistics:
     100000 packets, 10000000 bytes
Output Statistics:
     200000 packets, 20800000 bytes
Time since last interface status change: 01:36:01
```

Usage Information

FTOS supports a command to enable viewing of the VLAN input/output counters. This command also applies to SNMP requests. If the command is not enabled, IFM returns zero values for VLAN output counters.

SNMP counters differ from show interface counters as SNMP counters must maintain history. At any point, the value of SNMP counters reflect the amount of traffic being carried on the VLAN.

VLAN output counters may show higher than expected values because source-suppression drops are counted.

During an RPM failover event, all SNMP counters remain intact. The counters will sync over to the secondary RPM.

name

[C][E][S]

Assign a name to the VLAN.

Syntax name vlan-name

To remove the name from the VLAN, enter **no name**.

Parameters

vlan-name

Enter up to 32 characters as the name of the VLAN.

Defaults

Not configured.

Command Modes INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

To display information about a named VLAN, enter the show vlan command with the name parameter or the show interfaces description command.

Related Commands

description	escription Assign a descriptive text string to the interface.	
interface vlan	Configure a VLAN.	
show vlan	Display the current VLAN configurations on the switch.	

show config

CES

Display the current configuration of the selected VLAN.

Syntax show config

Command Modes INTERFACE VLAN

Example

Figure 20-10. show config Command Sample Output for a Selected VLAN

FTOS(conf-if-vl-100) #show config! interface Vlan 100 no ip address no shutdown FTOS(conf-if-vl-100)#

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

show vlan

CES

Display the current VLAN configurations on the switch.

Syntax

show vlan [**brief** | **id** *vlan-id* | **name** *vlan-name*]

Parameters

brief	(OPTIONAL) Enter the keyword brief to display the following information:
	• VLAN ID
	 VLAN name (left blank if none is configured.)
	Spanning Tree Group ID
	MAC address aging time
	• IP address
id vlan-id	(OPTIONAL) Enter the keyword id followed by a number from 1 to 4094. Only information on the VLAN specified is displayed.
name vlan-name	(OPTIONAL) Enter the keyword name followed by the name configured for the VLAN. Only information on the VLAN named is displayed.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Augmented to display PVLAN data for C-Series and S-Series; revised output to include Description field to display user-entered VLAN description
Version 7.6.1.0	Introduced on S-Series; revised output to display Native VLAN
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 20-11. show vlan Command Example

```
FTOS#show vlan
Codes: * - Default VLAN, G - GVRP VLANs, P - Primary, C - Community, I - Isolated
Q: U - Untagged, T - Tagged
x - Dot1x untagged, X - Dot1x tagged
G - GVRP tagged, M - Vlan-stack
      NUM
                Status
                               Description
                                                                               Q Ports
                Inactive
      1
                                                                              U Po1(Gi 13/0)
T Po20(Gi 13/6), Gi 13/25
                Active
                                                                               T Gi 13/7
                                                                              T Po20 (Gi 13/6)
T Gi 13/7
U Gi 13/1
      3
                Active
                                                                              U Po2(Gi 13/2)
T Po20(Gi 13/6)
      4
                Active
                                                                               T Gi 13/7
                                                                               T Po20(Gi 13/6)
      5
                Active
                                                                              T Gi 13/7
U Gi 13/3
                                                                              U Po3 (Gi 13/4)
T Po20 (Gi 13/6)
                Active
      6
                                                                               T Gi 13/7
                Active
                                                                               T Po20(Gi 13/6)
                                                                              T Gi 13/7
U Gi 13/5
Ρ
     100
                Active
                                                                               T Pol(Gi 0/1)
T Gi 0/2
     101
                Inactive
                                                                               T Gi 0/3
                                                                               T Gi 0/4
     102
                Inactive
FTOS#
```

Table 20-4. show vlan Information

Column Heading	Description
(Column 1 — no heading)	asterisk symbol (*) = Default VLAN
	G = GVRP VLAN
	P = primary VLAN
	C = community VLAN
	I = isolated VLAN
NUM	Displays existing VLAN IDs.
Status	Displays the word Inactive for inactive VLANs and the word Active for active VLANs.
Q	Displays G for GVRP tagged, M for member of a VLAN-Stack VLAN, T for tagged interface, U (for untagged interface), X (uncapitalized x) for Dot1x untagged, or X (capitalized X) for Dot1x tagged.
Ports	Displays the type, slot, and port information. For the type, $Po = port$ channel, $Gi = gigabit$ ethernet, and $Te = ten$ gigabit ethernet.

Figure 20-12. Example of Output of show vlan id

```
FTOS# show vlan id 40
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
  x - Dot1x untagged, X - Dot1x tagged
  G - GVRP tagged, M - Vlan-stack
        Status
                  Description
                                                   Q Ports
                                                   M Gi 13/47
   40
         Active
FTOS#show vlan id 41
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
  x - Dot1x untagged, X - Dot1x tagged
  G - GVRP tagged, M - Vlan-stack
   NUM
          Status
                  Description
                                                    Q Ports
                                                   T Gi 13/47
   41
          Active
FTOS#show vlan id 42
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
  x - Dot1x untagged, X - Dot1x tagged
  G - GVRP tagged, M - Vlan-stack
                                                    Q Ports
   NUM
         Status
                    Description
                                                    U Gi 13/47
   42
          Active
FTOS#
```

Figure 20-13. Example of Output of show vlan brief

FTOS#show vlan br VLAN Name	STG	MAC Ag:	ing IP Address
1		1800	unassigned
1	0		
2	0	1800	2.2.2.2/24
3	0	1800	3.3.3.2/24
FTOS#			
_			

Figure 20-14. Using VLAN Name

```
FTOS(conf)#interface vlan 222
FTOS (conf-if-v1-222) #name test
FTOS(conf-if-v1-222) #do show vlan name test
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
x - Dot1x untagged, X - Dot1x tagged
G - GVRP tagged, M - Vlan-stack
                                                                    Q Ports
U Gi 1/22
     MUM
              Status
                           Description
              Inactive
     222
FTOS(conf-if-v1-222)#
```

Related **Commands**

vlan-stack compatible	Enable the Stackable VLAN feature on the selected VLAN.
interface vlan	Configure a VLAN.

tagged

CES

Add a Layer 2 interface to a VLAN as a tagged interface.

Syntax

tagged interface

To remove a tagged interface from a VLAN, use **no tagged** interface command.

followed by the slot/port information.

Parameters

interface Enter the following keywords and slot/port or number information: For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. For a Port Channel interface, enter the keyword **port-channel** followed by a C-Series and S-Series Range: 1-128 E-Series Range: 1 to 255 for TeraScale. For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet**

Defaults

All interfaces in Layer 2 mode are untagged.

Command Modes

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

When you use the **no tagged** command, the interface is automatically placed in the Default VLAN as an untagged interface unless the interface is a member of another VLAN. If the interface belongs to several VLANs, you must remove it from all VLANs to change it to an untagged interface.

Tagged interfaces can belong to multiple VLANs, while untagged interfaces can only belong to one VLAN at a time.

Related Commands

interface vlan	Configure a VLAN.
untagged	Specify which interfaces in a VLAN are untagged.

track ip

Track the Layer 3 operational state of a Layer 3 VLAN, using a subset of the VLAN member interfaces.

Syntax track ip interface

To remove the tracking feature from the VLAN, use the **no track ip** interface command.

Parameters

interface	Enter the following keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel interface, enter the keyword port-channel followed by a number:
	C-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Not configured

Command Modes

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

When this command is configured, the VLAN is operationally UP if any of the interfaces specified in the **track ip** command are operationally UP, and the VLAN is operationally DOWN if none of the tracking interfaces are operationally UP.

If the **track ip** command is not configured, the VLAN's Layer 3 operational state depends on all the members of the VLAN.

The Layer 2 state of the VLAN, and hence the Layer 2 traffic is not affected by the **track ip** command configuration.

Related Commands

interface vlan	Configure a VLAN.
tagged	Specify which interfaces in a VLAN are tagged.

untagged

Add a Layer 2 interface to a VLAN as an untagged interface.

Syntax untagged interface

To remove an untagged interface from a VLAN, use the **no untagged** interface command.

Parameters

interface	Enter the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For Port Channel interface types, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

All interfaces in Layer 2 mode are untagged.

Command Modes

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

Untagged interfaces can only belong to one VLAN.

In the Default VLAN, you cannot use the ${\color{blue} no}$ untagged interface command. To remove an untagged interface from all VLANs, including the Default VLAN, enter the INTERFACE mode and use the no switchport command.

Related Commands

interface vlan	Configure a VLAN.
tagged	Specify which interfaces in a VLAN are tagged.

Link Layer Detection Protocol (LLDP)

Overview

Link Layer Detection Protocol (LLDP) advertises connectivity and management from the local station to the adjacent stations on an IEEE 802 LAN. LLDP facilitates multi-vendor interoperability by using standard management tools to discover and make available a physical topology for network management. The FTOS implementation of LLDP is based on IEEE standard 801.1ab.

Commands

This chapter contains the following commands, in addition to the commands in the related section — LLDP-MED Commands.

- advertise dot1-tlv
- advertise dot3-tlv
- advertise management
- clear lldp counters
- clear lldp neighbors
- debug lldp interface
- disable
- hello
- mode
- multiplier
- protocol lldp (Configuration)
- protocol lldp (Interface)
- show lldp neighbors
- show lldp statistics
- show running-config lldp

The starting point for using LLDP is invoking LLDP with the **protocol lldp** command in either the CONFIGURATION or INTERFACE mode.

The information distributed by LLDP is stored by its recipients in a standard Management Information Base (MIB). The information can be accessed by a network management system through a management protocol such as SNMP.

See the Link Layer Discovery Protocol chapter of the FTOS Configuration Guide for details on implementing LLDP/LLDP-MED.

advertise dot1-tlv

CES

Advertise dot1 TLVs (Type, Length, Value).

Syntax

advertise dot1-tlv {port-protocol-vlan-id | port-vlan-id | vlan-name}

To remove advertised dot1-tlv, use the **no advertise dot1-tlv** {port-protocol-vlan-id | port-vlan-id | vlan-name} command.

Parameters

port-protocol-vlan-id	Enter the keyword port-protocol-vlan-id to advertise the port protocol VLAN identification TLV.
port-vlan-id	Enter the keyword port-vlan-id to advertise the port VLAN identification TLV.
vlan-name	Enter the keyword vlan-name to advertise the vlan-name TLV. This keyword is only supported on C-Series and S-Series.

Defaults

Disabled

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series, added vlan-name option.	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Related Commands

protocol lldp (Configuration)	Enable LLDP globally.
debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show running-config lldp	Display the LLDP running configuration

advertise dot3-tlv

CES

Advertise dot3 TLVs (Type, Length, Value).

Syntax

advertise dot3-tlv {max-frame-size}

To remove advertised dot3-tlv, use the **no advertise dot3-tlv** {max-frame-size} command.

Parameters

max-frame-size Enter the keyword max-frame-size to advertise the dot3 maximum frame size.

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

advertise management

Advertise management TLVs (Type, Length, Value). CES

Syntax advertise management -tlv {system-capabilities | system-description | system-name}

> To remove advertised management TLVs, use the no advertise management -tlv {system-capabilities | system-description | system-name} command.

Parameters

system-capabilities	Enter the keyword system-capabilities to advertise the system capabilities TLVs.
system-description	Enter the keyword system-description to advertise the system description TLVs.
system-name	Enter the keyword system-name to advertise the system name TLVs.

Defaults No default values or behavior

Command Modes CONFIGURATION (conf-lldp)

> Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Usage Information

All three command options — system-capabilities, system-description, and system-name — -can be invoked individually or together, in any sequence.

advertise management-tlv

[Z]

S55 S60 Advertise management TLVs (Type, Length, Value).

(54810)

Syntax advertise management-tlv {management-address | system-capabilities | system-description| system-name}

> To remove advertised management TLVs, use the **no advertise management-tlv** {management-address | system-capabilities | system-description | system-name} command.

Parameters

management-address	Enter the keyword management-address to advertise the management IP address TLVs to the LLDP peer.
system-capabilities	Enter the keyword system-capabilities to advertise the system capabilities TLVs to the LLDP peer.
system-description	Enter the keyword system-description to advertise the system description TLVs to the LLDP peer.
system-name	Enter the keyword system-name to advertise the system name TLVs to the LLDP peer.

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.9	Introduced on the S60
Version 8.3.5.4	Introduced on the S55
Version 9.1.(0.0)	Modified to support management-address parameter
Version 8.3.11.1	Introduced on the Z9000
Version 8.3.7.0	Introduced on the S4810
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Usage Information The command options — management-address, system-capabilities, system-description, and system-name — can be invoked individually or together, in any sequence.

advertise management-tlv (Interface)

Z

S55

[S60]

Advertise management TLVs (Type, Length, Value) to the specified interface.

(54810)

Syntax

advertise management-tlv {management-address | system-capabilities | system-description| system-name}

To remove advertised management TLVs, use the **no advertise management-tlv** {management-address | system-capabilities | system-description | system-name} command.

Parameters

management-address	Enter the keyword management-address to advertise the management IP address TLVs to the specified interface.
system-capabilities	Enter the keyword system-capabilities to advertise the system capabilities TLVs to the specified interface.
system-description	Enter the keyword system-description to advertise the system description TLVs to the specified interface.
system-name	Enter the keyword system-name to advertise the system name TLVs to the specified interface.

Defaults

No default values or behavior

Command Modes

CONFIGURATION (conf-interface-lldp)

Version 8.3.3.9	Introduced on the S60
Version 8.3.5.4	Introduced on S55
Version 9.1.(0.0)	Introduced on the Z9000 and S4810

Usage Information All three command options — system-capabilities, system-description, and system-name — -can be invoked individually or together, in any sequence.

clear IIdp counters

CES

Clear LLDP transmitting and receiving counters for all physical interfaces or a specific physical interface.

Syntax

clear IIdp counters interface

Parameters

interface

Enter the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword **FastEthernet** followed by the slot/ port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **gigabitEthernet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword tenGigabitEthernet followed by the slot/port information.

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

clear IIdp neighbors

Clear LLDP neighbor information for all interfaces or a specific interfaces.

Syntax

clear IIdp neighbors { interface}

Parameters

interface

Enter the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword **FastEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword gigabitEthernet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword tenGigabitEthernet followed by the slot/port information.

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series

Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

debug lldp interface CES Enable LLDP de

Enable LLDP debugging to display timer events, neighbor additions or deletions, and other information about incoming and outgoing packets.

Syntax

To disable debugging, use the **no debug lldp interface** { interface | all } {events } {packet {brief | } detail} {tx | rx | both}} command.

Parameters

interface	Enter the following keywords and slot/port or number information:	
	• For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.	
	 For a 1-Gigabit Ethernet interface, enter the keyword gigabitEthernet followed by the slot/port information. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword tenGigabitEthernet followed by the slot/port information. 	
	Note: The FastEthernet option is not supported on S-Series.	
all	(OPTIONAL) Enter the keyword all to display information on all interfaces.	
events	(OPTIONAL) Enter the keyword events to display major events such as timer	
	events.	
packet	(OPTIONAL) Enter the keyword packet to display information regarding packets coming in or going out.	
brief	(OPTIONAL) Enter the keyword brief to display brief packet information.	
detail	(OPTIONAL) Enter the keyword detail to display detailed packet information.	
tx	(OPTIONAL) Enter the keyword tx to display transmit only packet information.	
rx	(OPTIONAL) Enter the keyword rx to display receive only packet information	
both	(OPTIONAL) Enter the keyword both to display both receive and transmit packet information.	

Defaults

No default values or behavior

Command Modes

EXEC Privilege

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

disable

CES

Enable or disable LLDP.

Syntax

disable

To enable LLDP, use the no disable

Defaults

Enabled, that is no disable

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Related Commands

protocol lldp (Configuration)	Enable LLDP globally.
debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show running-config lldp	Display the LLDP running configuration

hello

CES

Configure the rate at which the LLDP control packets are sent to its peer.

Syntax

hello seconds

To revert to the default, use the **no hello** seconds command.

Parameters

seconds	Enter the rate, in seconds, at which the control packets are sent to its peer.
	Rate: 5 - 180 seconds
	Default: 30 seconds

Defaults

30 seconds

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

mode

CES

Set LLDP to receive or transmit.

Syntax

mode {tx | rx}

To return to the default, use the **no mode** {tx | rx} command.

Parameters

tx	Enter the keyword tx to set the mode to transmit.
rx	Enter the keyword rx to set the mode to receive.

Defaults

Both transmit and receive

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Related Commands

protocol lldp (Configuration)	Enable LLDP globally.
show lldp neighbors	Display the LLDP neighbors

multiplier

ĊES

Set the number of consecutive misses before LLDP declares the interface dead.

Syntax

multiplier integer

To return to the default, use the **no multiplier** integer command.

Parameters

integer	Enter the number of consecutive misses before the LLDP declares the interface dead.
	Range: 2 - 10

Defaults

4 x hello

Command Modes

CONFIGURATION (conf-lldp) and INTERFACE (conf-if-interface-lldp)

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

protocol lldp (Configuration)

Enable LLDP globally on the switch. CES

Syntax protocol IIdp

To disable LLDP globally on the chassis, use the **no protocol lldp** command.

Defaults Disabled

Command Modes CONFIGURATION (conf-lldp)

> Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

protocol lldp (Interface)

CESEnter the LLDP protocol in the INTERFACE mode.

Syntax [no] protocol lldp

To return to the global LLDP configuration mode, use the **no protocol lidp** command from the

Interface mode.

Defaults LLDP is not enabled on the interface.

Command Modes INTERFACE (conf-if-interface-lldp)

> Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Usage Information When you enter the LLDP protocol in the Interface context, it overrides global configurations. When you execute the **no protocol lldp** from the INTERFACE mode, interfaces will begin to inherit the configuration from the global LLDP CONFIGURATION mode.

show lldp neighbors

CES Display LLDP neighbor information for all interfaces or a specified interface.

Syntax show IIdp neighbors [interface] [detail]

Parameters (OPTIONAL) Enter the following keywords and slot/port or number information: • For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information. • For a 1-Gigabit Ethernet interface, enter the keyword gigabitEthernet followed by the slot/port information. • For a 10-Gigabit Ethernet interface, enter the keyword tenGigabitEthernet followed by the slot/port information. detail (OPTIONAL) Enter the keyword detail to display all the TLV information, timers, and

Defaults No default values or behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Example

Figure 21-1. show IIdp neighbors Command Output

LLDP tx and rx counters.

R1(conf-if-gi Loc PortID			neighbors Rem Port	Id	 Rem Chassis Id	
- /	R2 R3				00:01:e8:06:95:3e 00:01:e8:09:c2:4a	

Usage Information

Omitting the keyword **detail** displays only the remote chassis ID, Port ID, and Dead Interval.

show IIdp statistics

CES Display the LLDP statistical information.

Syntax show IIdp statistics

Defaults No default values or behavior

Command Modes EXEC Privilege

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Example Figure 21-2. show IIdp statistics Command Output

```
FTOS#show lldp statistics
Total number of neighbors:
Last table change time :
                                      Mon Oct 02 16:00:52 2006
Number of Table Inserts :
Number of Table Deletes :
                                      1621
                                      200
Number of Table Drops
                                      0
Number of Table Age Outs :
                                      400
FTOS#
```

show running-config IIdp

CES Display the current global LLDP configuration.

Syntax show running-config IIdp

Defaults No default values or behavior

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
Version 7.4.1.0	Introduced on E-Series	

Example

```
FTOS#show running-config lldp
protocol lldp
 advertise dot1-tlv port-protocol-vlan-id port-vlan-id
 advertise dot3-tlv max-frame-size
 advertise management-tlv system-capabilities system-description
hello 15
multiplier 3
no disable
FTOS#
```

LLDP-MED Commands

The LLDP-MED commands in this section are:

- advertise med guest-voice
- advertise med guest-voice-signaling
- advertise med location-identification
- advertise med power-via-mdi
- advertise med softphone-voice
- advertise med streaming-video
- advertise med video-conferencing
- advertise med video-signaling
- advertise med voice
- advertise med voice-signaling

FTOS LLDP-MED (Media Endpoint Discovery) commands are an extension of the set of LLDP TLV advertisement commands. The C-Series and S-Series support all commands, as indicated by these symbols underneath the command headings:

The E-Series generally supports the commands, too, as indicated by the [E] symbol under command headings. However, LLDP-MED commands are more useful on the C-Series and the S50V model of the S-Series, because they support Power over Ethernet (PoE) devices.

As defined by ANSI/TIA-1057, LLDP-MED provides organizationally specific TLVs (Type Length Value), so that endpoint devices and network connectivity devices can advertise their characteristics and configuration information. The Organizational Unique Identifier (OUI) for the Telecommunications Industry Association (TIA) is 00-12-BB.

- **LLDP-MED Endpoint Device**—any device that is on an IEEE 802 LAN network edge, can communicate using IP, and uses the LLDP-MED framework.
- **LLDP-MED Network Connectivity Device**—any device that provides access to an IEEE 802 LAN to an LLDP-MED endpoint device, and supports IEEE 802.1AB (LLDP) and TIA-1057 (LLDP-MED). The Dell Networking system is an LLDP-MED network connectivity device.

With regard to connected endpoint devices, LLDP-MED provides network connectivity devices with the ability to:

- · manage inventory
- manage Power over Ethernet (POE)
- · identify physical location
- identify network policy

advertise med guest-voice

CES

Configure the system to advertise a separate limited voice service for a guest user with their own IP telephony handset or other appliances that support interactive voice services.

Syntax

advertise med guest-voice { vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the **no advertise med guest-voice** { *vlan-id layer2_priority DSCP_value*} | { **priority-tagged** *number*} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority.
	Range: 0 to 7
DSCP_value	Enter the DSCP value.
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command History

Related Commands

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
protocol lldp (Configuration)	Enable LLDP globally.
debug lldp interface	Debug LLDP.
show lldp neighbors	Display the LLDP neighbors.
show running-config lldp	Display the LLDP running configuration.

advertise med guest-voice-signaling

CES

Configure the system to advertise a separate limited voice service for a guest user when the guest voice control packets use a separate network policy than the voice data.

Syntax

advertise med guest-voice-signaling {vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the no advertise med guest-voice-signaling { vlan-id layer2_priority DSCP_value} | {priority-tagged number} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority.
	Range: 0 to 7
DSCP_value	Enter the DSCP value.
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show running-config lldp	Display the LLDP running configuration

Related **Commands**

advertise med location-identification

CES Configure the system to advertise a location identifier.

Syntax advertise med location-identification {coordinate-based value | civic-based value | ecs-elin value}

To return to the default, use the **no advertise med location-identification** {coordinate-based value | civic-based value | ecs-elin value} command.

Parameters

coordinate-based value	Enter the keyword coordinate-based followed by the coordinated based location in hexadecimal value of 16 bytes.
civic-based value	Enter the keyword civic-based followed by the civic based location in hexadecimal format. Range: 6 to 255 bytes
ecs-elin value	Enter the keyword ecs-elin followed by the Emergency Call Service (ecs) Emergency Location Identification Number (elin) numeric location string. Range: 10 to 25 characters

Defaults unconfigured

Command Modes CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series and E-Series	

Usage Information

ECS—Emergency Call Service such as defined by TIA or National Emergency Numbering Association (NENA)

ELIN—Emergency Location Identification Number, a valid North America Numbering Plan format telephone number supplied for ECS purposes.

Related Commands

debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show running-config lldp	Display the LLDP running configuration

advertise med power-via-mdi

C S Configure the system to advertise the Extended Power via MDI TLV.

Syntax advertise med power-via-mdi

To return to the default, use the **no advertise med power-via-mdi** command.

Defaults unconfigured

Command Modes CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	

Usage Information

Advertise the Extended Power via MDI on all ports that are connected to an 802.3af powered, LLDP-MED endpoint device.

Related Commands

debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show running-config lldp	Display the LLDP running configuration

advertise med softphone-voice

CES

Configure the system to advertise softphone to enable IP telephony on a computer so that the computer can be used as a phone.

Syntax

advertise med softphone-voice {vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the no advertise med softphone-voice {vlan-id layer2_priority DSCP_value} | {priority-tagged number} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7
DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series and E-Series	
-		
debug lldp interface	Debug LLDP	
show lldp neighbors	Display the LLDP neighbors	
show lldp neighbors	Display the LLDP running configuration	

Related **Commands**

advertise med streaming-video

CES

Configure the system to advertise streaming video services for broadcast or multicast-based video. This does not include video applications that rely on TCP buffering.

Syntax

advertise med streaming-video {vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the **no advertise med streaming-video** { *vlan-id layer2_priority DSCP_value*} | { **priority-tagged** *number*} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7
DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7
·	·

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
dahua IIda intarfasa	Dahua I I DD

Related Commands

debug lldp interface	Debug LLDP	
show lldp neighbors	Display the LLDP neighbors	
show lldp neighbors	Display the LLDP running configuration	

advertise med video-conferencing

CES

Configure the system to advertise dedicated video conferencing and other similar appliances that support real-time interactive video.

Syntax

advertise med video-conferencing { vlan-id layer2_priority DSCP_value} | { **priority-tagged** number}

To return to the default, use the **no advertise med video-conferencing** { *vlan-id layer2_priority DSCP_value*} | { **priority-tagged** *number*} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7

DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series and E-Series	
debug lldp interface	Debug LLDP	
show lldp neighbors	Display the LLDP neighbors	

Display the LLDP running configuration

Related Commands

advertise med video-signaling

show running-config lldp



Configure the system to advertise video control packets that use a separate network policy than video data.

Syntax

advertise med video-signaling {vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the no advertise med video-signaling {vlan-id layer2_priority DSCP_value} | {priority-tagged number} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7
DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
debug lldp interface	Debug LLDP

show lldp neighbors	Display the LLDP neighbors
show lldp neighbors	Display the LLDP running configuration

advertise med voice

CES

Configure the system to advertise a dedicated IP telephony handset or other appliances supporting interactive voice services.

Syntax

advertise med voice {vlan-id layer2_priority DSCP_value} | {priority-tagged number}

To return to the default, use the **no advertise med voice** { vlan-id layer2_priority DSCP_value} | { priority-tagged number} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7
DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
debug lldp interface	Debug LLDP
1 111 111	D. 1 4 HDD . H

Related Commands

;	debug lldp interface	Debug LLDP
	show lldp neighbors	Display the LLDP neighbors
	show running-config lldp	Display the LLDP running configuration

advertise med voice-signaling



Configure the system to advertise when voice control packets use a separate network policy than voice data.

Syntax

advertise med voice-signaling {*vlan-id layer2_priority DSCP_value*} | {**priority-tagged** *number*}

To return to the default, use the **no advertise med voice-signaling** { *vlan-id layer2_priority DSCP_value*} | { **priority-tagged** *number*} command.

Parameters

vlan-id	Enter the VLAN ID.
	Range: 1 to 4094
layer2_priority	Enter the Layer 2 priority (C-Series and E-Series only).
	Range: 0 to 7
DSCP_value	Enter the DSCP value (C-Series and E-Series only).
	Range: 0 to 63
priority-tagged number	Enter the keyword priority-tagged followed the Layer 2 priority.
	Range: 0 to 7

Defaults

unconfigured

Command Modes

CONFIGURATION (conf-lldp)

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series and E-Series
debug lldp interface	Debug LLDP
show lldp neighbors	Display the LLDP neighbors
show lldp neighbors	Display the LLDP running configuration

Related Commands

Multiple Spanning Tree Protocol (MSTP)

Overview

Multiple Spanning Tree Protocol (MSTP), as implemented by FTOS, conforms to IEEE 802.1s. MSTP is supported by FTOS on all Dell Networking systems (C-Series, E-Series, and S-Series), as indicated by the characters that appear below each command heading:

- C-Series: C
- E-Series: E
- S-Series: [S]

Commands

The following commands configure and monitor MSTP:

- debug spanning-tree mstp
- disable
- forward-delay
- hello-time
- max-age
- max-hops
- msti
- protocol spanning-tree mstp
- revision
- show config
- show spanning-tree mst configuration
- show spanning-tree msti
- spanning-tree
- spanning-tree msti
- spanning-tree mstp edge-port
- tc-flush-standard

debug spanning-tree mstp

Enable debugging of Multiple Spanning Tree Protocol and view information on the protocol.

Syntax debug spanning-tree mstp [all | bpdu interface {in | out} | events]

To disable debugging, enter **no debug spanning-tree mstp**.

Parameters

all	(OPTIONAL) Enter the keyword all to debug all spanning tree operations.
bpdu interface (in	(OPTIONAL) Enter the keyword bpdu to debug Bridge Protocol Data Units.
out}	(OPTIONAL) Enter the interface keyword along with the type slot/port of the interface you want displayed. Type slot/port options are the following:
	• For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range:1-255 for TeraScale
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	Optionally, enter an in or out parameter in conjunction with the optional interface:
	•For Receive, enter in
	•For Transmit, enter out
events	(OPTIONAL) Enter the keyword events to debug MSTP events.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 22-1. debug spanning-tree mstp bpdu Command Example

FTOS#debug spanning-tree mstp bpdu gigabitethernet 2/0 ? in Receive (in) out Transmit (out)

description

CESEnter a description of the Multiple Spanning Tree

Syntax description { description}

To remove the description, use the **no description** { description} command.

Parameters

description Enter a description to identify the Multiple Spanning Tree (80 characters maximum).

Defaults No default behavior or values

Command Modes SPANNING TREE (The prompt is "config-mstp".)

> Command History

Introduced on the S60. Version 8.3.3.1 pre-7.7.1.0 Introduced

Related Commands

Enter Multiple SPANNING TREE mode on the switch. protocol spanning-tree mstp

disable

CES Globally disable Multiple Spanning Tree Protocol on the switch.

Syntax disable

To enable Multiple Spanning Tree Protocol, enter **no disable**.

Defaults Multiple Spanning Tree Protocol is disabled

Command Modes MULTIPLE SPANNING TREE

> Command History

Version 8.3.3.1 Introduced on the S60. Version 7.6.1.0 Added support for S-Series Version 7.5.1.0 Added support for C-Series Version 6.5.1.0 Introduced

Related Commands

protocol spanning-tree mstp Enter MULTIPLE SPANNING TREE mode.

forward-delay CES

The amount of time the interface waits in the Blocking State and the Learning State before transitioning to the Forwarding State.

Syntax forward-delay seconds

To return to the default setting, enter **no forward-delay.**

Parameters

seconds	Enter the number of seconds the interface waits in the Blocking State and the Learning State before transiting to the Forwarding State.
	Range: 4 to 30
	Default: 15 seconds.

Defaults

15 seconds

Command Modes

MULTIPLE SPANNING TREE

Command History

Related Commands

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced
max-age	Change the wait time before MSTP refreshes protocol configuration information.
hello-time	Change the time interval between RPDUs



Set the time interval between generation of Multiple Spanning Tree Bridge Protocol Data Units (BPDUs).

Syntax

hello-time seconds

To return to the default value, enter **no hello-time**.

Parameters

seconds	Enter a number as the time interval between transmission of BPDUs.
	Range: 1 to 10.
	Default: 2 seconds.

Defaults

2 seconds

Command Modes

MULTIPLE SPANNING TREE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced
forward-delay	The amount of time the interface waits in the Blocking State and the Learning State before transitioning to the Forwarding State.
max-age	Change the wait time before MSTP refreshes protocol configuration information.

Related Commands

max-age

CES

Set the time interval for the Multiple Spanning Tree bridge to maintain configuration information before refreshing that information.

Syntax

max-age seconds

To return to the default values, enter **no max-age**.

Parameters

max-age	Enter a number of seconds the FTOS waits before refreshing configuration information.
	Range: 6 to 40
	Default: 20 seconds.

Defaults

20 seconds

Command Modes

MULTIPLE SPANNING TREE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced
forward_delay	The amount of time the interface waits in the Blocking State and the Learning State

Related Commands

forward-delay	The amount of time the interface waits in the Blocking State and the Learning State before transitioning to the Forwarding State.
hello-time	Change the time interval between BPDUs.

max-hops CES



Configure the maximum hop count.

Syntax

max-hops number

To return to the default values, enter **no max-hops**.

Parameters

range	Enter a number for the maximum hop count.
	Range: 1 to 40
	Default: 20

Defaults

20 hops

Command Modes

MULTIPLE SPANNING TREE

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced

Usage Information

The **max-hops** is a configuration command that applies to both the IST and all MST instances in the MSTP region. The BPDUs sent out by the root switch set the remaining-hops parameter to the configured value of max-hops. When a switch receives the BPDU, it decrements the received value of the remaining hops and uses the resulting value as remaining-hops in the BPDUs. If the remaining-hops reaches zero, the switch discards the BPDU and ages out any information that it holds for the port.

msti

CES

Configure Multiple Spanning Tree instance, bridge priority, and one or multiple VLANs mapped to the MST instance.

Syntax

msti instance {vlan range | bridge-priority priority}

To disable mapping or bridge priority no msti instance {vlan range | bridge-priority priority}

Parameters

msti instance	Enter the Multiple Spanning Tree Protocol Instance
	Range: zero (0) to 63
vlan range	Enter the keyword vlan followed by the identifier range value.
	Range: 1 to 4094
bridge-priority priority	Enter the keyword bridge-priority followed by a value in increments of 4096 as the bridge priority.
	Range: zero (0) to 61440
	Valid priority values are: 0, 4096, 8192, 12288, 16384, 20480, 24576,
	28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440. All other values are rejected.

Defaults

default bridge-priority is 32768

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

By default, all VLANs are mapped to MST instance zero (0) unless you use the **vlan** *range* command to map it to a non-zero instance.

name

CES

The name you assign to the Multiple Spanning Tree region.

Syntax

name region-name

To remove the region name, enter no name

Parameters

region-name	Enter the MST region name.
	Range: 32 character limit

Defaults no default name

Command Modes MULTIPLE SPANNING TREE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced

Usage Information

For two MSTP switches to be within the same MSTP region, the switches must share the same region name (including matching case).

Related Commands

msti	Map the VLAN(s) to an MST instance
revision	Assign revision number to the MST configuration.

protocol spanning-tree mstp

CES

Enter the MULTIPLE SPANNING TREE mode to enable and configure the Multiple Spanning Tree group.

Syntax protocol spanning-tree mstp

To disable the Multiple Spanning Tree group, enter no protocol spanning-tree mstp command.

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example Figure 22-2. protocol spanning-tree mstp Command Example

FTOS(conf) #protocol spanning-tree mstp FTOS (config-mstp) #no disable

Usage Information

MSTP is not enabled when you enter the MULTIPLE SPANNING TREE mode. To enable MSTP globally on the switch, enter no disable while in MULTIPLE SPANNING TREE mode.

Refer to the FTOS Configuration Guide for more information on Multiple Spanning Tree Protocol.

Related **Commands**

disable Disable Multiple Spanning Tree.

Defaults Disable.

Command Modes MULTIPLE SPANNING TREE Usage Information

Refer to the FTOS Configuration Guide for more information on Multiple Spanning Tree Protocol.

revision

CES

The revision number for the Multiple Spanning Tree configuration

Syntax

revision range

To return to the default values, enter **no revision**.

Parameters

range Enter the revision number for the MST configuration.
Range: 0 to 65535
Default: 0

Defaults

0

Command Modes

MULTIPLE SPANNING TREE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced

Usage Information For two MSTP switches to be within the same MST region, the switches must share the same revision number.

Related Commands

msti	Map the VLAN(s) to an MST instance	
name	Assign the region name to the MST region.	

show config

CES

View the current configuration for the mode. Only non-default values are shown.

Syntax

show config

Command Modes

MULTIPLE SPANNING TREE

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced on E-Series

Example Figure 22-3. show config Command for MULTIPLE SPANNING TREE Mode

```
FTOS(conf-mstp)#show config
protocol spanning-tree mstp
 no disable
 name CustomerSvc
 revision 2
MSTI 10 VLAN 101-105
 max-hops 5
FTOS (conf-mstp)#
```

show spanning-tree mst configuration

CES View the Multiple Spanning Tree configuration.

Syntax show spanning-tree mst configuration

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 22-4. show spanning-tree mst configuration Command Example

```
FTOS#show spanning-tree mst configuration
MST region name: CustomerSvc
Revision: 2
MSTI
        VID
         101-105
 10
FTOS#
```

Usage Information

You must enable Multiple Spanning Tree Protocol prior to using this command.

show spanning-tree msti

CES View the Multiple Spanning Tree instance.

Syntax show spanning-tree msti [instance-number [brief]]

Parameters

instance-number	[Optional] Enter the Multiple Spanning Tree Instance number
	Range: 0 to 63
brief	[Optional] Enter the keyword brief to view a synopsis of the MST instance.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.4.1.0	Expanded to display port error disable state (EDS) caused by loopback BPDU inconsistency (see Figure 22-6)

Example

Figure 22-5. show spanning-tree msti [instance-number] Command Example

FTOS#show spanning-tree msti 10 MSTI 10 VLANs mapped 101-105 Bridge Identifier has priority 32768, Address 0001.e802.3506 Configured hello time 2, max age 20, forward delay 15, max hops 5 Current root has priority 16384, Address 0001.e800.0a5c Number of topology changes 0, last change occurred 3058087 Port 82 (GigabitEthernet 2/0) is designated Forwarding Port path cost 0, Port priority 128, Port Identifier 128.82 Designated root has priority 16384, address 0001.e800.0a:5c Designated bridge has priority 32768, address 0001.e802.35:06 Designated port id is 128.82, designated path cost Number of transitions to forwarding state 1 BPDU (Mrecords): sent 1109, received 0 The port is not in the portfast mode Port 88 (GigabitEthernet 2/6) is root Forwarding Port path cost 0, Port priority 128, Port Identifier 128.88 Designated root has priority 16384, address 0001.e800.0a:5c Designated bridge has priority 16384, address 0001.e800.0a:5c Designated port id is 128.88, designated path cost Number of transitions to forwarding state BPDU (Mrecords): sent 19, received 1103 The port is not in the portfast mode Port 89 (GigabitEthernet 2/7) is alternate Discarding Port path cost 0, Port priority 128, Port Identifier 128.89 Designated root has priority 16384, address 0001.e800.0a:5c Designated bridge has priority 16384, address 0001.e800.0a:5c Designated port id is 128.89, designated path cost Number of transitions to forwarding state 3 BPDU (Mrecords): sent 7, received 1103 The port is not in the portfast mode FTOS#

Example 2 Figure 22-6. show spanning-tree msti with EDS and LBK

```
FTOS#show spanning-tree msti 0 brief
MSTI 0 VLANs mapped 1-4094
Executing IEEE compatible Spanning Tree Protocol
Root ID Priority 32768, Address 0001.e801.6aa8
Root Bridge hello time 2, max age 20, forward delay 15, max hops 20
Bridge ID Priority 32768, Address 0001.e801.6aa8
We are the root of MSTI 0 (CIST)
Configured hello time 2, max age 20, forward delay 15, max hops 20 CIST regional root ID Priority 32768, Address 0001.e801.6aa8
CIST external path cost 0
Interface
                                                               Designated
 Name PortID Prio Cost Sts Cost Bridge ID
                                                                                   PortID
Gi 0/0 128.257 128 20000 EDS 0 32768 0001.e801.6aa8 128.257
Interface
 Name
            Role PortID Prio Cost Sts Cost Link-type Edge Boundary
Gi 0/0 ErrDis 128.257 128 20000 EDS 0 P2P No No
FTOS#show spanning-tree msti 0
MSTI 0 VLANs mapped 1-4094
Root Identifier has priority 32768, Address 0001.e801.6aa8
Root Bridge hello time 2, max age 20, forward delay 15, max hops 20 Bridge Identifier has priority 32768, Address 0001.e801.6aa8 Configured hello time 2, max age 20, forward delay 15, max hops 20
We are the root of MSTI 0 (CIST)
Current root has priority 32768, Address 0001.e801.6aa8
CIST regional root ID Priority 32768, Address 0001.e801.6aa8
CIST external path cost 0
Number of topology changes 1, last change occurred 00:00:15 ago on Gi 0/0
                                                                                   Loopback BPDU
Port path cost 20000, Port priority 128, Port Identifier 128.257Inconsistency Designated root has priority 32768, address 0001.e801.6aa8
Designated bridge has priority 32768, address 0001.e801.6aa8
Designated port id is 128.257, designated path cost 0
Number of transitions to forwarding state 1
Number of transitions to forwarding state 1
BPDU (MRecords): sent 21, received 9
The port is not in the Edge port mode
```

Usage Information

You must enable Multiple Spanning Tree Protocol prior to using this command.

spanning-tree

CES Enable Multiple Spanning Tree Protocol on the interface.

Syntax spanning-tree

To disable the Multiple Spanning Tree Protocol on the interface, use **no spanning-tree**

Parameters	spanning-tree	Enter the keyword spanning-tree to enable the MSTP on the interface.
		Default: Enable

Defaults Enable

Command Modes **INTERFACE**

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
pre-Version 6.2.1.0	Introduced on E-Series

spanning-tree msti

CES Configure Multiple Spanning Tree instance cost and priority for an interface.

Syntax spanning-tree msti instance {cost cost | priority priority}

To remove the cost or priority for the MST instance, use **no spanning-tree msti** *instance* {**cost** *cost* | **priority** }

Parameters

msti instance	Enter the keyword msti and the MST Instance number.
	Range: zero (0) to 63
cost cost	(OPTIONAL) Enter the keyword cost followed by the port cost value.
	Range: 1 to 200000
	Defaults:
	100 Mb/s Ethernet interface = 200000
	1-Gigabit Ethernet interface = 20000
	10-Gigabit Ethernet interface = 2000
	Port Channel interface with one 100 Mb/s Ethernet = 200000
	Port Channel interface with one 1-Gigabit Ethernet = 20000
	Port Channel interface with one 10-Gigabit Ethernet = 2000
	Port Channel with two 1-Gigabit Ethernet = 18000
	Port Channel with two 10-Gigabit Ethernet = 1800
	Port Channel with two 100-Mbps Ethernet = 180000
priority priority	Enter keyword priority followed by a value in increments of 16 as the priority.
	Range: 0 to 240.
	Default: 128

Defaults

cost = depends on the interface type; priority = 128

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced on E-Series

spanning-tree mstp edge-port

CES

Configures the interface as an Multiple Spanning Tree edge port and optionally a Bridge Protocol Data Unit (BPDU) guard.

Syntax spanning-tree mstp edge-port [bpduguard [shutdown-on-violation]]

Parameters

mstp edge-port	Enter the keywords mstp followed by the keyword edge-port to configure the interface as a Multiple Spanning Tree edge port.
bpduguard	(OPTIONAL) Enter the keyword portfast to enable Portfast to move the interface into forwarding mode immediately after the root fails. Enter the keyword bpduguard to disable the port when it receives a BPDU.
shutdown-on-v iolation	(OPTIONAL) Enter the keyword shutdown-on-violation to hardware disable an interface when a BPDU is received and the port is disabled.

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on the S60.
Version 8.2.1.0	Introduced hardware shutdown-on-violation option
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.1.1.0	Support for BPDU guard added

Usage Information

On an MSTP switch, a port configured as an edge port will immediately transition to the forwarding state. Only ports connected to end-hosts should be configured as an edge port. Consider an edge port similar to a port with spanning-tree portfast enabled.

If **shutdown-on-violation** is not enabled, BPDUs will still be sent to the RPM CPU.

tc-flush-standard

CES

Enable the MAC address flushing upon receiving every topology change notification.

Syntax tc-flush-standard

To disable, use the **no tc-flush-standard** command.

Defaults Disabled

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Added support for S-Series
Version 7.5.1.0	Added support for C-Series
Version 6.5.1.0	Introduced

Usage Information

By default FTOS implements an optimized flush mechanism for MSTP. This helps in flushing the MAC addresses only when necessary (and less often) allowing for faster convergence during topology changes. However, if a standards-based flush mechanism is needed, this knob command can be turned on to enable flushing MAC addresses upon receiving every topology change notification.

Multicast

Overview

The platforms on which a command is supported is indicated by the character — [E] for the E-Series, [C] for the C-Series, and [S] for the S-Series — that appears below each command heading.

This chapter contains the following sections:

- **IPv4 Multicast Commands**
- **IPv6 Multicast Commands**

IPv4 Multicast Commands

The IPv4 Multicast commands are:

- clear ip mroute
- ip mroute
- ip multicast-lag-hashing
- ipv6 multicast-routing
- ip multicast-limit
- mac-flood-list
- mtrace
- multicast-buffering enable
- queue backplane multicast
- restrict-flooding
- show ip mroute
- show ip rpf
- show queue backplane multicast

clear ip mroute

CES Clear learned multicast routes on the multicast forwarding table. To clear the PIM tree information base, use clear ip pim tib command.

Syntax clear ip mroute {group-address [source-address] | *}

Parameters

group-address [source-address]	Enter multicast group address and source address (if desired), in dotted decimal format, to clear information on a specific group.
*	Enter * to clear all multicast routes.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.8.1.0	Introduced on C-Series	
E-Series legacy command		

Related Commands

show ip pim tib	Show the PIM Tree Information Base.	

ip mroute



Assign a static mroute.

Syntax

ip mroute $destination \ mask \{ip\text{-}address \mid \text{null 0} \mid \{\{\text{bgp} \mid \text{ospf}\} \ process\text{-}id \mid \text{isis} \mid \text{rip} \mid \text{static}\} \}$ $\{ip\text{-}address \mid \text{tag} \mid \text{null 0}\}\}$ [distance]

To delete a specific static mroute, use the command **ip mroute** destination mask {ip-address | null 0| {{bgp| ospf} process-id | isis | rip | static} {ip-address | tag | null 0}} [distance].

To delete all mroutes matching a certain mroute, use the **no ip mroute** destination mask command.

Parameters

destination	Enter the IP address in dotted decimal format of the destination device.		
mask	Enter the mask in slash prefix formation ($\slash x$) or in dotted decimal format.		
null 0	(OPTIONAL) Enter the null followed by zero (0).		
[protocol [process-id tag]	(OPTIONAL) Enter one of the routing protocols:		
ip-address]	• Enter the BGP as-number followed by the IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor.		
	Range:1-65535		
	 Enter the OSPF process identification number followed by the IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor. 		
	Range: 1-65535		
	• Enter the IS-IS alphanumeric tag string followed by the IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor.		
	• Enter the RIP IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor.		
static ip-address	(OPTIONAL) Enter the Static IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor.		
ip-address	(OPTIONAL) Enter the IP address in dotted decimal format of the reverse path forwarding (RPF) neighbor.		
distance	(OPTIONAL) Enter a number as the distance metric assigned to the mroute.		
	Range: 0 to 255		

Defaults Not configured.

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1 Introduced on S60

E-Series legacy command

Related Commands

show ip mroute View the E-Series routing table.

ip multicast-lag-hashing

Distribute multicast traffic among Port Channel members in a round-robin fashion.

Syntax ip multicast-lag-hashing

To revert to the default, enter **no ip multicast-lag-hashing**.

Defaults Disabled

Command Modes CONFIGURATION

> Command History

Version 6.3.1.0 Introduced for E-Series

Usage Information By default, one Port Channel member is chosen to forward multicast traffic. With this feature turned on, multicast traffic will be distributed among the Port Channel members in a round-robin fashion. This feature applies to the routed multicast traffic. If IGMP Snooping is turned on, this feature also applies to switched multicast traffic.

Related **Commands**

ipv6 multicast-routing Enable IP multicast forwarding.

ip multicast-routing

CESEnable IP multicast forwarding.

Syntax ip multicast-routing

To disable multicast forwarding, enter no ip multicast-routing.

Defaults Disabled

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1 Introduced on S60

E-Series legacy command

Usage Information You must enter this command to enable multicast on the E-Series.

After you enable multicast, you can enable IGMP and PIM on an interface. In the INTERFACE mode, enter the ip pim sparse-mode command to enable IGMP and PIM on the interface.

Related Commands

ip pim sparse-mode	Enable IGMP and PIM on an interface.	
--------------------	--------------------------------------	--

ip multicast-limit

CES

Use this feature to limit the number of multicast entries on the system.

Syntax

ip multicast-limit limit

Parameters

limit	Enter the desired maximum number of multicast entries on the system.
	E-Series Range: 1 to 50000
	E-Series Default: 15000
	C-Series Range: 1 to 10000
	C-Series Default: 4000
	S-Series Range: 1 to 2000
	S-Series Default: 400

Defaults

As above

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series
Version 7.6.1.0	Introduced on E-Series

Usage Information

This features allows the user to limit the number of multicast entries on the system. This number is the sum total of all the multicast entries on all line cards in the system. On each line card, the multicast module will only install the maximum possible number of entries, depending on the configured CAM profile.

The IN-L3-McastFib CAM partition is used to store multicast routes and is a separate hardware limit that is exists per port-pipe. Any software-configured limit might be superseded by this hardware space limitation. The opposite is also true, the CAM partition might not be exhausted at the time the system-wide route limit set by the ip multicast-limit is reached.

Related Commands

show ip igmp groups

mac-flood-list

E

Provide an exception to the restrict-flood configuration so that multicast frames within a specified MAC address range to be flooded on all ports in a VLAN.

Syntax

mac-flood-list mac-address mask vlanvlan-list [min-speed speed]

Parameters

mac-address	Enter a multicast MAC address in hexadecimal format.	
mac-mask	Enter the MAC Address mask.	

vlan vlan-list	Enter the VLAN(s) in which flooding will be restricted. Separate values by commas—no spaces (1,2,3) or indicate a list of values separated by a hyphen (1-3).	
	Range: 1 to 4094	
min-speed min-speed	(OPTIONAL) Enter the minimum link speed that ports must have to receive the specified flooded multicast traffic.	

Defaults

None

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on E-Series

Usage Information

When the mac-flood-list with the min-speed option is used in combination with the restrict-flood command, mac-flood-list command has higher priority than the restrict-flood command.

Therefore, all multicast frames matching the mac-address range specified using the mac-flood-list command are flooded according to the mac-flood-list command. Only the multicast frames not matching the mac-address range specified using the mac-flood-list command are flooded according to the restrict-flood command.

Related Commands

restrict-flooding	Prevent Layer 2 multicast traffic from being forwarded on ports below a	
	specified speed.	

mtrace

(E)

Trace a multicast route from the source to the receiver.

Syntax

mtrace {source-address/hostname} {destination-address/hostname} {group-address}

Parameters

source-address/ hostname	Enter the source IP address in dotted decimal format (A.B.C.D).
destination-address/ hostname	Enter the destination (receiver) IP address in dotted decimal format (A.B.C.D).
group-address	Enter the multicast group address in dotted decimal format (A.B.C.D).

Command Modes

EXEC Privilege

Command History

Version 7.5.1.0	Expanded to support originator
Version 7.4.1.0	Expanded to support intermediate (transit) router
E-Series legacy command	

Usage Information

Mtrace is an IGMP protocol based on the Multicast trace route facility and implemented according to the IETF draft "A trace route facility for IP Multicast" (draft-fenner-traceroute-ipm-01.txt). FTOS supports the Mtrace client and transmit functionality.

As an Mtrace client, FTOS transmits Mtrace queries, receives, parses and prints out the details in the response packet received.

As an Mtrace transit or intermediate router, FTOS returns the response to Mtrace queries. Upon receiving the Mtrace request, FTOS computes the RPF neighbor for the source, fills in the request and the forwards the request to the RPF neighbor. While computing the RPF neighbor, the static mroute and mBGP route is preferred over the unicast route.

multicast-buffering enable

[S60]

Enable buffering for all multicast traffic on the buffering unit.

Syntax

[no] multicast-buffering enable

Command Modes

CONFIGURATION

Command History

Version 8.3.3.8 Introduced on S60.

Usage Information

Use this command to enable backpressure messages for multicast traffic and allow the system to start buffering multicast traffic. If multicast traffic is buffered for one group on any port, all multicast, Destination Lookup Failure (DLF) and broadcast traffic is buffered. Note that multicast packets might be dropped if either of the following occurs:

- continuous oversubscription at the egress
- if the packet is not drained for a long period because of slow draining rate at the egress port compared to high ingress rate.

You must reboot the switch to enable the command on a standalone unit. Buffering multicast units is not supported on stacked units.

Related Commands

show hardware	Display the data plane or management plane input and output statistics
stack-unit	of the designated component of the designated stack member.

queue backplane multicast

Reallocate the amount of bandwidth dedicated to multicast traffic.

Syntax

queue backplane multicast bandwidth-percentage percentage

Parameters

percentage	Enter the percentage of backplane bandwidth to be dedicated to multicast traffic.	
	Range: 5-95	

Defaults

80% of the scheduler weight is for unicast traffic and 20% is for multicast traffic by default.

Command Modes

CONFIGURATION

Command History

Version 7.7.1.0	Introduced on E-Series	

Example Figure 23-1. Command Example: queue backplane multicast

FTOS(conf)#queue backplane multicast bandwidth-percent 30 FTOS (conf) #exit FTOS#00:14:04: %RPM0-P:CP %SYS-5-CONFIG I: Configured from console by console show run | grep bandwidth queue backplane multicast bandwidth-percent 30 FTOS#

Related Commands

show queue backplane multicast

Display the backplane bandwidth configuration about how much bandwidth is dedicated to multicast versus unicast.

restrict-flooding

Prevent Layer 2 multicast traffic from being flooded on ports below a specified link speed. (E)

Syntax restrict-flooding multicast min-speed speed

Parameters min-speed min-speed Enter the minimum link speed that a port must have to receive flooded

> multicast traffic. Range: 1000

Defaults None

Command Modes INTERFACE VLAN

> Command History

Version 7.7.1.0 Introduced on E-Series

Usage Information This command restricts flooding for all unknown multicast traffic on ports below a certain speed. If you want some multicast traffic to be flooded on slower ports, use the command mac-flood-list without the min-speed option, in combination with restrict-flooding. With mac-flood-list you specify the traffic you want to be flooded using a MAC address range.

You may not use unicast MAC addresses when specifying MAC address ranges, and do not overlap MAC addresses ranges, when creating multiple mac-flood-list entries for the same VLAN. Restricted Layer 2 Flooding is not compatible with MAC accounting or VMANs.

Related **Commands**

mac-flood-list Flood multicast frames with specified MAC addresses to all ports in a VLAN.

show ip mroute

CES View the Multicast Routing Table.

Syntax show ip mroute [static | group-address [source-address] | active [rate] | count | summary]

Parameters

static	(OPTIONAL) Enter the keyword static to view static multicast routes.
group-address [source-address]	(OPTIONAL) Enter the multicast group-address to view only routes associated with that group. Enter the source-address to view routes with that group-address and source-address.
active [rate]	(OPTIONAL) Enter the keyword active to view only active multicast routes. Enter a rate to view active routes over the specified rate. Range: 0 to 10000000
count	(OPTIONAL) Enter the keyword count to view the number of multicast routes and packets on the E-Series.
summary	(OPTIONAL) Enter the keyword summary to view routes in a tabular format.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
E-Series legacy command	

Example 1 Figure 23-2. Command Example: show ip mroute static

```
FTOS#show ip mroute static

Mroute: 23.23.23.0/24, interface: Lo 2
Protocol: static, distance: 0, route-map: none, last change: 00:00:23

FTOS#
```

Example 2 Figure 23-3. Command Example: show ip mroute

```
FTOS#show ip mroute

IP Multicast Routing Table

(*, 224.10.10.1), uptime 00:05:12
    Incoming interface: GigabitEthernet 3/12
    Outgoing interface list:
        GigabitEthernet 3/13

(1.13.1.100, 224.10.10.1), uptime 00:04:03
    Incoming interface: GigabitEthernet 3/4
    Outgoing interface list:
        GigabitEthernet 3/12
        GigabitEthernet 3/13

(*, 224.20.20.1), uptime 00:05:12
    Incoming interface: GigabitEthernet 3/12
    Outgoing interface GigabitEthernet 3/12
    Outgoing interface list:
        GigabitEthernet 3/4

FTOS#
```

Table 23-1. Command Example Fields: show ip mroute

Field	Description
(S,G)	Displays the forwarding entry in the multicast route table.
uptime	Displays the amount of time the entry has been in the multicast forwarding table.
Incoming interface	Displays the reverse path forwarding (RPF) information towards the the source for (S,G) entries and the RP for (*,G) entries.
Outgoing interface list:	Lists the interfaces that meet one of the following: a directly connected member of the Group statically configured member of the Group received a (*,G) or (S,G) Join message

show ip rpf

View reverse path forwarding.

Syntax

show ip rpf

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
E-Series legacy command		

Usage Information

Static mroutes are used by network administrators to control the reachability of the multicast sources. If a PIM registered multicast source is reachable via static mroute as well as unicast route, the distance of each route is examined and the route with shorter distance is the one the PIM selects for reachability.

Note: The default distance of mroutes is zero (0) and is CLI configurable on a per route basis.

Example

Figure 23-4. Command Example: show ip rpf

```
FTOS#show ip rpf
RPF information for 10.10.10.9
   RPF interface: Gi 3/4
RPF neighbor: 165.87.31.4
   RPF route/mask: 10.10.10.9/255.255.255
   RPF type: unicast
```

show queue backplane multicast

Display the backplane bandwidth configuration about how much bandwidth is dedicated to multicast \mathbb{E} versus unicast.

Syntax show queue backplane multicast bandwidth-percentage

Defaults None Command Modes EXEC

EXEC Privilege

Command History

Version 7.7.1.0 Introduced on E-Series

Example

Figure 23-5. Command Example: show queue backplane multicast

FTOS#show queue backplane multicast bandwidth-percent Configured multicast bandwidth percentage is 80

Related Commands

queue backplane multicast Reallocate the amount of bandwidth dedicated to multicast traffic.

IPv6 Multicast Commands

IPv6 Multicast commands are:

- clear ipv6 mroute
- ipv6 multicast-limit
- ipv6 multicast-routing
- show ipv6 mroute
- show ipv6 mroute mld
- show ipv6 mroute summary

clear ipv6 mroute

E Clear learned multicast routes on the multicast forwarding table. To clear the PIM tib, use clear ip pim tib command.

Syntax clear ipv6 mroute { group-address [source-address] | * }

Parameters

group-address [source-address]	Enter multicast group address and source address (if desired) to clear information on a specific group. Enter the addresses in the x:x:x:x format.
	The :: notation specifies successive hexadecimal fields of zero.
*	Enter * to clear all multicast routes.

Defaults No default behavior or values

Command Modes EXEC Privilege

Command History

Version 7.4.1.0 Introduced

ipv6 multicast-limit

Limit the number of multicast entries on the system.

Syntax ipv6 multicast-limit limit

Parameters limit Enter the desired maximum number of multicast entries on the system.

> Range: 1 to 50000 Default: 15000

Defaults 15000 routes

Command Modes CONFIGURATION

> Command History

Version 8.3.1.0 Introduced

Usage Information The maximum number of multicast entries allowed on each line card is determined by the CAM profile. Multicast routes are stored in the IN-V6-McastFib CAM region, which has a fixed number of entries. Any limit configured via the CLI is superseded by this hardware limit. The opposite is also true; the CAM might not be exhausted at the time the CLI-configured route limit is reached.

ipv6 multicast-routing

Enable IPv6 multicast forwarding. [E]

Syntax ipv6 multicast-routing

To disable multicast forwarding, enter no ipv6 multicast-routing.

Defaults Disabled

Command Modes CONFIGURATION

> Command **History**

E-Series legacy command

show ipv6 mroute

View IPv6 multicast routes.

Syntax show ipv6 mroute [group-address [source-address]] [active rate] [count group-address [source

source-address]]

Parameters

(OPTIONAL) Enter the IPv6 multicast group-address to view only group-address routes associated with that group. Optionally, enter the IPv6 [source-address] source-address to view routes with that group-address and source-address.

active [<i>rate</i>]	(OPTIONAL) Enter the keyword active to view active multicast sources. Enter a rate to view active routes over the specified rate. Range: 0 to 10000000 packets/second
<pre>count group-address[source source-address]}</pre>	(OPTIONAL) Enter the keyword count to view the number of IPv6 multicast routes and packets on the E-Series. Optionally, enter the IPv6 source-address count information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 7.4.1.0

Introduced

Example

Figure 23-6. Command Example: show ipv6 mroute

```
FTOS#show ipv6 mroute
IP Multicast Routing Table (165:87:32::30, ff05:100::1), uptime 00:01:11
  Incoming interface: Vlan 200 Outgoing interface list:
    GigabitEthernet 2/14
(165:87:37::30, ff05:200::1), uptime 00:01:04
  Incoming interface: Port-channel 200 Outgoing interface list:
    Vlan 200
(165:87:31::30, ff05:300::1), uptime 00:01:19
  Incoming interface: GigabitEthernet 2/14
  Outgoing interface list:
    Port-channel 200
(165:87:32::30, ff05:1100::1), uptime 00:01:08
  Incoming interface: Vlan 200
  Outgoing interface list:
    GigabitEthernet 2/14
(165:87:37::30, ff05:2200::1), uptime 00:01:01
  Incoming interface: Port-channel 200 Outgoing interface list:
    Vlan 200
FTOS#
```

Example Figure 23-7. Command Example: show ipv6 mroute active

```
FTOS#show ipv6 mroute active 10

Active Multicast Sources - sending >= 10 pps

Group: ff05:300::1
    Source: 165:87:31::30
    Rate: 100 pps

Group: ff05:3300::1
    Source: 165:87:31::30
    Rate: 100 pps

Group: ff3e:300::4000:1
    Source: 165:87:31::20
    Rate: 100 pps

Group: ff3e:3300::4000:1
    Source: 165:87:31::20
    Rate: 100 pps

FTOS#
```

Example Figure 23-8. Command Example: show ipv6 mroute count group

```
FTOS#show ipv6 mroute count group ff05:3300::1
IP Multicast Statistics
1 routes using 648 bytes of memory
1 groups, 1.00 average sources per group
Forwarding Counts: Pkt Count/Pkts per second
Group: ff05:3300::1, Source count: 1
Source: 165:87:31::30, Forwarding: 3997/0
FTOS#
```

Example Figure 23-9. Command Example: show ipv6 mroute count source

```
FTOS#show ipv6 mroute count source 165:87:31::30
IP Multicast Statistics
2 routes using 1296 bytes of memory
2 groups, 1.00 average sources per group
Forwarding Counts: Pkt Count/Pkts per second
Group: ff05:300::1, Source count: 1
Source: 165:87:31::30, Forwarding: 3993/0
Group: ff05:3300::1, Source count: 1
Source: 165:87:31::30, Forwarding: 3997/0
FTOS#
```

show ipv6 mroute mld

Display the Multicast MLD information.

Syntax show ipv6 mroute [mld [group-address | all | vlan vlan-id]]

Parameters

mld	(OPTIONAL) Enter the keyword mld to display Multicast MLD information.
group-address	(OPTIONAL) Enter the multicast group address in the X:X:X:X format. The ∷ notation specifies successive hexadecimal fields of zero.
all	(OPTIONAL) Enter the keyword all to view all the MLD information.
vlan <i>vlan-id</i>	(OPTIONAL) Enter the keyword vlan followed by the VLAN ID to view MLD VLAN information.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command **History**

Version 7.4.1.0 Introduced

Example Figure 23-10. Command Example: show ipv6 mroute mld all

```
FTOS#show ipv6 mroute mld all

MLD SNOOPING MRTM Table

(*, ff05:100::1), uptime 00:04:21
   Incoming vlan: Vlan 200
   Outgoing interface list:
        GigabitEthernet 2/15
        GigabitEthernet 2/16

(*, ff05:200::1), uptime 00:04:15
   Incoming vlan: Vlan 200
   Outgoing interface list:
        GigabitEthernet 2/15
        GigabitEthernet 2/16

(*, ff05:1100::1), uptime 00:04:18
   Incoming vlan: Vlan 200
   Outgoing interface list:
        GigabitEthernet 2/15
        GigabitEthernet 2/15
        GigabitEthernet 2/15
        GigabitEthernet 2/15
        GigabitEthernet 2/15
        GigabitEthernet 2/16

FTOS#
```

show ipv6 mroute summary

E Display a summary of the Multicast routing table.

Syntax show ipv6 mroute summary

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 7.4.1.0 Introduced

Example

Figure 23-11. Command Example: show ipv6 mroute summary

```
FTOS#show ipv6 mroute summary

IP Multicast Routing Table
12 groups, 12 routes

(165:87:32::30, ff05:100::1), 00:00:24
(165:87:37::30, ff05:200::1), 00:00:24
(165:87:31::30, ff05:300::1), 00:00:24
(165:87:32::30, ff05:1100::1), 00:00:21
(165:87:37::30, ff05:2200::1), 00:00:21
(165:87:31::30, ff05:3300::1), 00:00:21
(165:87:32::20, ff3e:100::4000:1), 00:00:41
FTOS#
```

Neighbor Discovery Protocol (NDP)

Overview

Neighbor Discovery Protocol for IPv6 is defined in RFC 2461 as part of the Stateless Address Autoconfiguration protocol. It replaces the Address Resolution Protocol used with IPv4. It defines mechanisms for solving the following problems:

- Router discovery: Hosts can locate routers residing on a link.
- Prefix discovery: Hosts can discover address prefixes for the link.
- Parameter discovery
- Address autoconfiguration configuration of addresses for an interface
- Address resolution mapping from IP address to link-layer address
- Next-hop determination
- Neighbor Unreachability Detection (NUD): Determine that a neighbor is no longer reachable on the link.
- Duplicate Address Detection (DAD): Allow a node to check whether a proposed address is already in use.
- Redirect: The router can inform a node about a better first-hop.

NDP makes use of the following five ICMPv6 packet types in its implementation:

- **Router Solicitation**
- Router Advertisement
- **Neighbor Solicitation**
- Neighbor Advertisement
- Redirect

Commands

The Neighbor Discovery Protocol (NDP) commands in this chapter are:

- clear ipv6 neighbors
- ipv6 nd managed-config-flag
- ipv6 nd max-ra-interval
- ipv6 nd mtu
- ipv6 nd other-config-flag
- ipv6 nd prefix
- ipv6 nd ra-lifetime
- ipv6 nd reachable-time
- ipv6 nd suppress-ra

- ipv6 neighbor
- show ipv6 neighbors

clear ipv6 neighbors

Delete all entries in the IPv6 neighbor discovery cache, or neighbors of a specific interface. Static entries will not be removed using this command.

Syntax clear ipv6 neighbors [ipv6-address] [interface]

Parameters

ipv6-address	Enter the IPv6 address of the neighbor in the X:X:X:X format to remove a specific IPv6 neighbor.	
	The :: notation specifies successive hexadecimal fields of zero.	
interface interface	To remove all neighbor entries learned on a specific interface, enter the keyword interface followed by the interface type and slot/port or number information of the interface:	
	 For a Fast Ethernet interface, enter the keyword fastEthernet followed by the slot/port information. 	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a Port Channel interface, enter the keyword port-channel followed by a number from 1 to 255. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
	 For a VLAN, enter the keyword vlan followed by the VLAN ID. The range is from 1 to 4094. 	

Command Modes

EXEC

EXEC Privilege

ipv6 nd managed-config-flag

Set the managed address configuration flag in the IPv6 router advertisement. The description of this flag from RFC 2461 (http://tools.ietf.org/html/rfc2461) is:

M: 1-bit "Managed address configuration" flag. When set, hosts use the administered (stateful) protocol for address autoconfiguration in addition to any addresses autoconfigured using stateless address autoconfiguration. The use of this flag is described in:

Thomson, S. and T. Narten, "IPv6 Address Autoconfiguration", RFC 2462, December 1998.

Syntax ipv6 nd managed-config-flag

To clear the flag from the IPv6 router advertisements, use the **no ipv6 nd managed-config-flag** command.

Defaults The default flag is 0.

Command Modes INTERFACE

ipv6 nd max-ra-interval

Configure the interval between the IPv6 router advertisement (RA) transmissions on an interface.

Syntax ipv6 nd max-ra-interval { interval} min-ra-interval { interval}

To restore the default interval, use the **no ipv6 nd max-ra-interval** command.

Parameters

max-ra-interval { interval}	Enter the keyword max-ra-interval followed by the interval in seconds. Range: 4 to 1800 seconds
min-ra-interval { interval}	Enter the keyword min-ra-interval followed by the interval in seconds. Range: 3 to 1350 seconds

Defaults Max RA interval: 600 seconds, Min RA interval: 200 seconds

Command Modes INTERFACE

ipv6 nd mtu

CESConfigure an IPv6 neighbor discovery.

Syntax ipv6 nd mtu number

Parameters

mtu number	Set the MTU advertisement value in Routing Prefix
	Advertisement packets. Range: 1280 to 9234

Defaults No default values or behavior

Command Modes INTERFACE

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced

Usage Information The **ip nd mtu** command sets the value advertised to routers. It does not set the actual MTU rate. For example, if **ip nd mtu** is set to 1280, the interface will still pass 1500-byte packets.

The **mtu** command sets the actual frame size passed, and can be larger than the advertised MTU. If the mtu setting is larger than the ip nd mtu, an error message is sent, but the configuration is accepted.

% Error: nd ra mtu is greater than link mtu, link mtu will be used.

Related Commands

mtu Set the maximum link MTU (frame size) for an Ethernet interface.	
--	--

ipv6 nd other-config-flag

Set the other stateful configuration flag in the IPv6 router advertisement. The description of this flag from RFC 2461 (http://tools.ietf.org/html/rfc2461) is:

O: 1-bit "Other stateful configuration" flag. When set, hosts use the administered (stateful) protocol for autoconfiguration of other (non-address) information. The use of this flag is described in:

Thomson, S. and T. Narten, "IPv6 Address Autoconfiguration", RFC 2462, December 1998.

Syntax ipv6 nd other-config-flag

To clear the flag from the IPv6 router advertisements, use the ${\bf no}$ ipv6 ${\bf nd}$ other-config-flag

command.

Defaults The default flag is 0.

Command Modes INTERFACE

ipv6 nd prefix

Configure how IPv6 prefixes are advertised in the IPv6 router advertisements. The description of an IPv6 prefix from RFC 2461(http://tools.ietf.org/html/rfc2461) is a bit string that consists of some number of initial bits of an address.

Syntax ipv6 nd prefix { ipv6-address prefix-length | default} [no-advertise] | [no-autoconfig | no-rtr-address | off-link]

To prevent a prefix (or prefixes) from being advertised, use the **no ipv6 nd prefix** { *ipv6-address* prefix-length | **default**} [no-advertise {valid-lifetime seconds | preferred-lifetime seconds}] | [no-autoconfig | no-rtr-address | off-link] command.

Parameters

ipv6-address prefix-length	Enter the IPv6 address in the X:X:X:X format followed by the prefix length in the /x format.
	Range: /0 to /128
	The :: notation specifies successive hexadecimal fields of zeros
default	(OPTIONAL) Enter the keyword default to specify the prefix default parameters.
no-advertise	(OPTIONAL) Enter the keyword no-advertise to not advertise prefixes.
no-autoconfig	(OPTIONAL) Enter the keyword no-autoconfig to not use prefixes for auto-configuration.
no-rtr-address	(OPTIONAL) Enter the keyword no-rtr-address to not send full router addresses in prefix advertisement.
off-link	(OPTIONAL) Enter the keyword off-link to not use prefixes for on-link determination.

Defaults Not configured

Command Modes INTERFACE

ipv6 nd ra-lifetime

Configure the router lifetime value in the IPv6 router advertisements on an interface. The description of router lifetime from RFC 2461(http://tools.ietf.org/html/rfc2461) is:

Router Lifetime: 16-bit unsigned integer. The lifetime associated with the default router in units of seconds. The maximum value corresponds to 18.2 hours. A Lifetime of 0 indicates that the router is not a default router and SHOULD NOT appear on the default router list. The Router Lifetime applies only to the router's usefulness as a default router; it does not apply to information contained in other message fields or options. Options that need time limits for their information include their own lifetime fields.

ipv6 nd ra-lifetime seconds **Syntax**

To restore the default values, use the **no ipv6 nd ra-lifetime** command.

Parameters

Enter the lifetime value in seconds. seconds Range: 0 to 9000

Defaults 9000 seconds

Command Modes INTERFACE

ipv6 nd reachable-time

Configure the amount of time that a remote IPv6 node is considered available after a reachability confirmation event has occurred. The description of reachable time from RFC 2461(http:// tools.ietf.org/html/rfc2461) is:

Reachable Time: 32-bit unsigned integer. The time, in milliseconds, that a node assumes a neighbor is reachable after having received a reachability confirmation. Used by the Neighbor Unreachability Detection algorithm. A value of zero means unspecified (by this router).

Syntax ipv6 nd reachable-time { milliseconds}

To restore the default time, use the **no ipv6 nd reachable-time** command.

Parameters

milliseconds	Enter the leachability time in milliseconds.
	Range: 0 to 3600000

3600000 milliseconds **Defaults**

Command Modes INTERFACE

ipv6 nd suppress-ra

Suppress the IPv6 router advertisement transmissions on an interface.

Syntax ipv6 nd suppress-ra

To enable the sending of IPv6 router advertisement transmissions on an interface, use the **no ipv6 nd** suppress-ra command.

Defaults

Enabled

Command Modes

INTERFACE

ipv6 neighbor

(E)

Configure a static entry in the IPv6 neighbor discovery.

Syntax

ipv6 neighbor {ipv6-address} {interface interface} {hardware_address}

To remove a static IPv6 entry from the IPv6 neighbor discovery, use the **no ipv6 neighbor** { *ipv6-address*} { **interface** interface} command.

Parameters

ipv6-address	Enter the IPv6 address of the neighbor in the X:X:X::X format.	
	The :: notation specifies successive hexadecimal fields of zero	
interface interface	Enter the keyword interface followed by the interface type and slot/port or number information:	
	 For a Fast Ethernet interface, enter the keyword fastEthernet followed by the slot/port information. 	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a Port Channel interface, enter the keyword port-channel followed by a number from 1 to 255. 	
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
hardware_address	Enter a 48-bit hardware MAC address in nn:nn:nn:nn:nn:nn format.	

Defaults

No default behavior or values

Command Modes

CONFIGURATION

show ipv6 neighbors

E

Display IPv6 discovery information. Entering the command without options shows all IPv6 neighbor addresses stored on the CP (control processor).

Syntax

show ipv6 neighbors [ipv6-address] [cpu {rp1 [ipv6-address] | rp2 [ipv6-address]}] [interface interface]

Parameters

ipv6-address	Enter the IPv6 address of the neighbor in the X:X:X:X: format.
	The :: notation specifies successive hexadecimal fields of zero

cpu	Enter the keyword cpu followed by either rp1 or rp2 (Route Processor 1 or 2), optionally followed by an IPv6 address to display the IPv6 neighbor entries stored on the designated RP.		
interface interface	 For a Fast Ethernet interface, enter the keyword fastEthernet followed by the slot/port information. 		
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 		
	 For a Port Channel interface, enter the keyword port-channel followed by a number from 1 to 255. 		
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 		
	• For a VLAN, enter the keyword vlan followed by the VLAN ID. The range is from 1 to 4094.		

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Example Figure 24-1. Command Example: show ipv6 neighbors

					_
FTOS#show ipv6 neighbors					
IPv6 Address Expires(min)	Hardware Address	State	Interface	VLAN	CPU
fe80::201:e8ff:fe17:5bc6					
1439	00:01:e8:17:5b:c6	STALE	Gi 1/9	-	CP
fe80::201:e8ff:fe17:5bc7					
1439 fe80::201:e8ff:fe17:5bc8	00:01:e8:17:5b:c7	STALE	Gi 1/10	-	CP
1439	00:01:e8:17:5b:c8	STALE	Gi 1/11	_	CP
fe80::201:e8ff:fe17:5caf			/		
0.3	00:01:e8:17:5c:af	REACH	Po 1	-	CP
fe80::201:e8ff:fe17:5cb0					
1439 fe80::201:e8ff:fe17:5cb1	00:01:e8:17:5c:b0	STALE	Po 32	-	CP
1439	00:01:e8:17:5c:b1	STALE	Po 255	_	CP
fe80::201:e8ff:fe17:5cae	00.01.00.17.00.21	0111111	10 233		01
1439	00:01:e8:17:5c:ae	STALE	Gi 1/3	Vl 100) CP
fe80::201:e8ff:fe17:5cae					
1439 fe80::201:e8ff:fe17:5cae	00:01:e8:17:5c:ae	STALE	Gi 1/5	VI 100	00 CP
	00:01:e8:17:5c:ae	STALE	Gi 1/7	777 200	ח כם
FTOS#	00.01.00.17.30.ae	OTALL	G1 1//	VI 200	O CF

Open Shortest Path First (OSPFv2 and OSPFv3)

Overview

Open Shortest Path First version 2 for IPv4 is supported on platforms [C][E][S]

Open Shortest Path First version 3 (OSPFv3) for IPv6 is supported on platforms [C] [E]



Note: The C-Series supports OSPFv3 with FTOS version 7.8.1.0 and later.

OSPF is an Interior Gateway Protocol (IGP), which means that it distributes routing information between routers in a single Autonomous System (AS). OSPF is also a link-state protocol in which all routers contain forwarding tables derived from information about their links to their neighbors.

The fundamental mechanisms of OSPF (flooding, DR election, area support, SPF calculations, etc.) are the same for OSPFv2 and OSPFv3. OSPFv3 runs on a per-link basis instead of on a per-IP-subnet basis.

This chapter is divided into 2 sections. There is no overlap between the two sets of commands. You cannot use an OSPFv2 command in the IPv6 OSPFv3 mode.

OSPFv2 Commands



Note: FTOS version 7.8.1.0 introduces Multi-Process OSPF on IPv4 (OSPFv2) only. It is not supported on OSPFv3 (IPv6).

Note that the CLI now requires that the Process ID be included when entering the ROUTER-OSPF mode. Each command entered applies to the specified OSPFv2 process only.

OSPFv2 Commands

The Dell Networking implementation of OSPFv2 is based on IETF RFC 2328. The following commands enable you to configure and enable OSPFv2.

- area default-cost
- area nssa
- area range
- area stub
- area virtual-link
- auto-cost

- clear ip ospf
- clear ip ospf statistics
- debug ip ospf
- default-information originate
- · default-metric
- description
- distance
- distance ospf
- distribute-list in
- distribute-list out
- enable inverse mask
- fast-convergence
- flood-2328
- graceful-restart grace-period
- graceful-restart helper-reject
- graceful-restart mode
- graceful-restart role
- ip ospf auth-change-wait-time
- ip ospf authentication-key
- ip ospf cost
- ip ospf dead-interval
- ip ospf hello-interval
- · ip ospf message-digest-key
- ip ospf mtu-ignore
- ip ospf network
- ip ospf priority
- ip ospf retransmit-interval
- ip ospf transmit-delay
- log-adjacency-changes
- maximum-paths
- mib-binding
- network area
- passive-interface
- redistribute
- redistribute bgp
- redistribute isis
- router-id
- router ospf
- show config
- show ip ospf
- show ip ospf asbr
- show ip ospf database
- show ip ospf database asbr-summary
- show ip ospf database external
- show ip ospf database network
- show ip ospf database nssa-external

- show ip ospf database opaque-area
- show ip ospf database opaque-as
- show ip ospf database opaque-link
- show ip ospf database router
- show ip ospf database summary
- show ip ospf interface
- show ip ospf neighbor
- show ip ospf routes
- show ip ospf statistics
- show ip ospf topology
- show ip ospf virtual-links
- summary-address
- timers spf

area default-cost



Set the metric for the summary default route generated by the area border router (ABR) into the stub area. Use this command on the border routers at the edge of a stub area.

Syntax

area area-id default-cost cost

To return default values, use the **no area** area-id **default-cost** command.

Parameters

area-id	Specify the OSPF area in dotted decimal format (A.B.C.D.) or enter a number from zero (0) to 65535.
cost	Specifies the stub area's advertised external route metric.
	Range: zero (0) to 65535.

Defaults

cost = 1; no areas are configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

In FTOS, cost is defined as reference bandwidth/bandwidth.

Related Commands

area stub	Create a stub area.	
-----------	---------------------	--

area nssa

CES

Specify an area as a Not So Stubby Area (NSSA).

Syntax

area area-id nssa [default-information-originate] [no-redistribution] [no-summary]

To delete an NSSA, enter no area area-id nssa.

Parameters

area-id	Specify the OSPF area in dotted decimal format (A.B.C.D) or enter a number from 0 and 65535.
no-redistribution	(OPTIONAL) Specify that the redistribute command should not distribute routes into the NSSA. You should only use this command in a NSSA Area Border Router (ABR).
default-information-ori ginate	(OPTIONAL) Allows external routing information to be imported into the NSSA by using Type 7 default.
no-summary	(OPTIONAL) Specify that no summary LSAs should be sent into the NSSA.

Defaults

Not configured

Command Mode

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

area range

CES

Summarize routes matching an address/mask at an area border router (ABR).

Syntax

area area-id range ip-address mask [not-advertise]

To disable route summarization, use the **no area** area-id **range** ip-address mask command.

Parameters

area-id	Specify the OSPF area in dotted decimal format (A.B.C.D.) or enter a number from zero (0) to 65535.
ip-address	Specify an IP address in dotted decimal format.
mask	Specify a mask for the destination prefix. Enter the full mask (for example, 255.255.255.0).
not-advertise	(OPTIONAL) Enter the keyword not-advertise to set the status to DoNotAdvertise (that is, the Type 3 summary-LSA is suppressed and the component networks remain hidden from other areas.)

Defaults

No range is configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Only the routes within an area are summarized, and that summary is advertised to other areas by the ABR. External routes are not summarized.

Related Commands

area stub	Create a stub area.
router ospf	Enter the ROUTER OSPF mode to configure an OSPF instance.

area stub



Configure a stub area, which is an area not connected to other areas.

Syntax

area area-id stub [no-summary]

To delete a stub area, enter **no area** area-id **stub**.

Parameters

area-id	Specify the stub area in dotted decimal format (A.B.C.D.) or enter a number from zero (0) to 65535.
no-summary	(OPTIONAL) Enter the keyword no-summary to prevent the ABR from sending summary Link State Advertisements (LSAs) into the stub area.

Defaults

Disabled

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Use this command to configure all routers and access servers within a stub.

Related Commands

router ospf	Enter the ROUTER OSPF mode to configure an OSPF instance.	
-------------	---	--

area virtual-link

CES

Set a virtual link and its parameters.

Syntax

area area-id virtual-link router-id [[authentication-key [encryption-type] key] | [message-digest-key keyid md5 [encryption-type] key]] [dead-interval seconds] [hello-interval seconds] [retransmit-interval seconds] [transmit-delay seconds]

To delete a virtual link, use the **no area** area-id **virtual-link** router-id command.

To delete a parameter of a virtual link, use the **no area** area-id **virtual-link** router-id [[authentication-key [encryption-type] key] | [message-digest-key keyid md5 [encryption-type] key]] [dead-interval seconds] [hello-interval seconds] [retransmit-interval seconds] [transmit-delay seconds] command syntax.

Parameters

area-id	Specify the transit area for the virtual link in dotted decimal format (A.B.C.D.) or enter a number from zero (0) to 65535.
router-id	Specify an ID (IP address in dotted decimal format) associated with a virtual link neighbor.
authentication-key	(OPTIONAL) Choose between two authentication methods:
[encryption-type] key message-digest-key keyid md5 [encryption-type] key	• Enter the keyword authentication-key to enable simple authentication followed by an alphanumeric string up to 8 characters long. Optionally, for the <i>encryption-type</i> variable, enter the number 7 before entering the <i>key</i> string to indicate that an encrypted password will follow.
	 Enter the keyword message-digest-key followed by a number from 1 to 255 as the keyid. After the keyid, enter the keyword md5 followed by the key. The key is an alphanumeric string up to 16 characters long. Optionally, for the encryption-type variable, enter the number 7 before entering the key string to indicate that an encrypted password will follow.
dead-interval seconds	(OPTIONAL) Enter the keyword dead-interval followed by a
	number as the number of seconds for the interval.
	Range: 1 to 8192.
	Default: 40 seconds.
hello-interval seconds	(OPTIONAL) Enter the keyword hello-interval followed by the number of seconds for the interval.
	Range: 1 to 8192. Default: 10 seconds.
retransmit-interval seconds	(OPTIONAL) Enter the keyword retransmit-interval followed by
	the number of seconds for the interval.
	Range: 1 to 8192.
	Default: 5 seconds.
transmit-delay seconds	(OPTIONAL) Enter the keyword transmit-delay followed by the number of seconds for the interval.
	Range: 1 to 8192.
	Default: 1 second.

Defaults

 $\label{eq:dead-interval} \begin{subarray}{l} \textbf{dead-interval} \ seconds = 40 \ seconds; \ \textbf{retransmit-interval} \ seconds = 10 \ seconds; \ \textbf{retransmit-interval} \ seconds = 1 \ second$

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

All OSPF areas must be connected to a backbone area (usually Area 0). Virtual links connect broken or discontiguous areas.

You cannot enable both authentication options. Choose either the authentication-key or message-digest-key option.

auto-cost

CES

Specify how the OSPF interface cost is calculated based on the reference bandwidth method.

Syntax

auto-cost [reference-bandwidth ref-bw]

To return to the default bandwidth or to assign cost based on the interface type, use the **no auto-cost** [reference-bandwidth] command.

Parameters

ref-bw	(OPTIONAL) Specify a reference bandwidth in megabits per second.
	Range: 1 to 4294967
	Default: 100 megabits per second.

Defaults

100 megabits per second.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

clear ip ospf

CES

Clear all OSPF routing tables.

Syntax

clear ip ospf process-id [process]

Parameters

process-id	Enter the OSPF Process ID to clear a specific process. If no Process ID is entered, all OSPF processes are cleared.
process	(OPTIONAL) Enter the keyword process to reset the OSPF process.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

clear_ip_ospf statistics

C E S Clear the packet statistics in interfaces and neighbors.

Syntax clear ip ospf process-id statistics [interface name {neighbor router-id}]

Parameters

process-id	Enter the OSPF Process ID to clear statistics for a specific process.
	If no Process ID is entered, all OSPF processes are cleared.
interface name	(OPTIONAL) Enter the keyword interface followed by one of the following interface keywords and slot/port or number information:
	For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	For a SONET interface, enter the keyword sonet followed by the slot/port information.
	For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
neighbor router-id	(OPTIONAL) Enter the keyword neighbor followed by the neighbor's router-id in dotted decimal format (A.B.C.D.).

Defaults

No defaults values or behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series
show ip ospf statis	tics Display the OSPF statistics

Related Commands

debug ip ospf

CES

Display debug information on OSPF. Entering **debug ip ospf** enables OSPF debugging for the first OSPF process,.

Syntax

debug ip ospf process-id [bfd |event | packet | spf]

To cancel the debug command, enter **no debug ip ospf**.

Parameters

process-id	Enter the OSPF Process ID to debug a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
bfd	(OPTIONAL) Enter the keyword bfd to debug only OSPF BFD information.
event	(OPTIONAL) Enter the keyword event to debug only OSPF event information.
packet	(OPTIONAL) Enter the keyword packet to debug only OSPF packet information.
spf	(OPTIONAL) Enter the keyword spf to display the Shortest Path First information.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-1. Command example: debug ip ospf process-id packet

```
FTOS#debug ip ospf 1 packet
OSPF process 90, packet debugging is on
08:14:24 : OSPF(100:00):
Xmt. v:2 t:1(HELLO) l:44 rid:192.1.1.1
          aid:0.0.0.1 chk:0xa098 aut:0 auk: keyid:0 to:Gi 4/3 dst:224.0.0.5 netmask:255.255.255.0 pri:1 N-, MC-, E+, T-,
                hi:10 di:40 dr:90.1.1.1 bdr:0.0.0.0
```

Table 25-1. Output Descriptions for debug ip ospf process-id packet

Field	Description
8:14	Displays the time stamp.
OSPF	Displays the OSPF process ID: instance ID.
v:	Displays the OSPF version. FTOS supports version 2 only.
t:	Displays the type of packet sent: 1 - Hello packet 2 - database description 3 - link state request 4 - link state update 5 - link state acknowledgement
1:	Displays the packet length.
rid:	Displays the OSPF router ID.

Table 25-1. Output Descriptions for debug ip ospf process-id packet

Field	Description
aid:	Displays the Autonomous System ID.
chk:	Displays the OSPF checksum.
aut:	States if OSPF authentication is configured. One of the following is listed: • 0 - no authentication configured • 1 - simple authentication configured using the ip ospf authentication-key command) • 2 - MD5 authentication configured using the ip ospf message-digest-key command.
auk:	If the ip ospf authentication-key command is configured, this field displays the key used.
keyid:	If the ip ospf message-digest-key command is configured, this field displays the MD5 key
to:	Displays the interface to which the packet is intended.
dst:	Displays the destination IP address.
netmask:	Displays the destination IP address mask.
pri:	Displays the OSPF priority
N, MC, E, T	Displays information available in the Options field of the HELLO packet: N + (N-bit is set) N - (N-bit is not set) MC+ (bit used by MOSPF is set and router is able to forward IP multicast packets) MC- (bit used by MOSPF is not set and router cannot forward IP multicast packets) E + (router is able to accept AS External LSAs) E - (router cannot accept AS External LSAs) T + (router can support TOS)
hi:	Displays the amount of time configured for the HELLO interval.
di:	Displays the amount of time configured for the DEAD interval.
dr:	Displays the IP address of the designated router.
bdr:	Displays the IP address of the Border Area Router.

default-information originate

C E S Configure the FTOS to generate a default external route into an OSPF routing domain.

Syntax

default-information originate [always] [metric metric-value] [metric-type type-value] [route-map map-name]

To return to the default values, enter **no default-information originate**.

Parameters

always	(OPTIONAL) Enter the keyword always to specify that default route information must always be advertised.
metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number to configure a metric value for the route. Range: 1 to 16777214

metric-type type-value	(OPTIONAL) Enter the keyword metric-type followed by an OSPF link state type of 1 or 2 for default routes. The values are:
	• 1 = Type 1 external route
	• 2 = Type 2 external route.
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of an established route map.

Defaults

Disabled.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Related Commands

redistribute Redistribute routes from other routing protocols into OSPF.

default-metric

CES

Change the metrics of redistributed routes to a value useful to OSPF. Use this command with the redistribute command.

Syntax

default-metric number

To return to the default values, enter **no default-metric** [number].

Parameters

number	Enter a number as the metric.
	Range: 1 to 16777214.

Defaults

Disabled.

Command Modes

ROUTER OSPF

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Related Commands

	D 11 11 0 0 0 1 1 1 0 0 0 0 0 0 0 0 0 0	
redistribute	Redistribute routes from other routing protocols into OSPF.	
real surreace	reconstitute routes from other routing protocols into obtain	

description

Add a description about the selected OSPF configuration.

Syntax description description

To remove the OSPF description, use the **no description** command.

Parameters

description Enter a text string description to identify the OSPF configuration (80 characters maximum).

Defaults

No default behavior or values

Command Modes

ROUTER OSPF

Command History

Introduced on S60
Introduced support for Multi-Process OSPF.
Introduced on S-Series
Introduced on C-Series
Introduced on E-Series

Related Commands

show ip ospf asbr	Display VLAN configuration.
-------------------	-----------------------------

distance

CES

Define an administrative distance for particular routes to a specific IP address.

Syntax

distance weight [ip-address mask access-list-name]

To delete the settings, use the **no distance** weight [ip-address mask access-list-name] command.

Parameters

weight	Specify an administrative distance.
J	Range: 1 to 255.
	Default: 110
ip-address	(OPTIONAL) Enter a router ID in the dotted decimal format.
	If you enter a router ID, you must include the mask for that router address.
mask	(OPTIONAL) Enter a mask in dotted decimal format or /n format.
access-list-name	(OPTIONAL) Enter the name of an IP standard access list, up to 140 characters.

Defaults

110

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
	Increased name string to accept up to 140 characters. Prior to 7.8.1.0, names are up to 16 characters long.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

distance ospf

CES Configure an OSPF distance metric for different types of routes.

Syntax distance ospf [external dist3] [inter-area dist2] [intra-area dist1]

To delete these settings, enter **no distance ospf**.

Parameters

external dist3	(OPTIONAL) Enter the keyword external followed by a number to specify a distance for external type 5 and 7 routes.
	Range: 1 to 255
	Default: 110.
inter-area dist2	(OPTIONAL) Enter the keyword inter-area followed by a number to specify a distance metric for routes between areas.
	Range: 1 to 255
	Default: 110.
intra-area dist1	(OPTIONAL) Enter the keyword intra-area followed by a number to specify a distance metric for all routes within an area.
	Range: 1 to 255
	Default: 110.

Defaults

external dist3 = 110; inter-area dist2 = 110; intra-area dist1 = 110.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

To specify a distance for routes learned from other routing domains, use the redistribute command.

distribute-list in

CES

Apply a filter to incoming routing updates from OSPF to the routing table.

Syntax

distribute-list prefix-list-name in [interface]

To delete a filter, use the **no distribute-list** prefix-list-name in [interface] command.

Parameters

prefix-list-name	Enter the name of a configured prefix list.
interface	(OPTIONAL) Enter one of the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	• For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094

Defaults

Not configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

distribute-list out

CES

Apply a filter to restrict certain routes destined for the local routing table after the SPF calculation.

Syntax

distribute-list prefix-list-name out [bgp | connected | isis | rip | static]

To remove a filter, use the **no distribute-list** *prefix-list-name* **out** [**bgp** | **connected** | **isis** | **rip** | **static**] command.

Parameters

Enter the name of a configured prefix list.
(OPTIONAL) Enter the keyword bgp to specify that BGP routes are distributed.*
(OPTIONAL) Enter the keyword connected to specify that connected routes are distributed.
(OPTIONAL) Enter the keyword isis to specify that IS-IS routes are distributed.*
(OPTIONAL) Enter the keyword rip to specify that RIP routes are distributed.*
(OPTIONAL) Enter the keyword static to specify that only manually configured routes are distributed.

^{*} BGP and ISIS routes are not available on the C-Series. BGP, ISIS, and RIP routes are not available on the S-Series.

Defaults

Not configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

The distribute-list out command applies to routes being redistributed by autonomous system boundary routers (ASBRs) into OSPF. It can be applied to external type 2 and external type 1 routes, but not to intra-area and inter-area routes.

enable inverse mask

 \mathbb{C} FTOS, by default, permits the user to input OSPF network command with a net-mask. This command provides a choice between inverse-mask or net-mask (the default).

Syntax enable inverse mask

To return to the default net-mask, enter **no enable inverse mask.**

Defaults net-mask

Command Modes CONFIGURATION

> Command History

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

fast-convergence

CES

This command sets the minimum LSA origination and arrival times to zero (0), allowing more rapid route computation so that convergence takes less time.

Syntax fast-convergence {number}

To cancel fast-convergence, enter **no fast convergence**.

Parameters

number	Enter the convergence level desired. The higher this parameter is set, the faster OSPF converge takes place.
	Range: 1-4

Defaults None.

Command Modes ROUTER OSPF

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on all platforms.

Usage Information The higher this parameter is set, the faster OSPF converge takes place. Note that the faster the convergence, the more frequent the route calculations and updates. This will impact CPU utilization and may impact adjacency stability in larger topologies.

Generally, convergence level 1 meets most convergence requirements. Higher convergence levels should only be selected following consultation with Dell Networking technical support.

flood-2328

CES

Enable RFC-2328 flooding behavior.

Syntax

flood-2328

To disable, use the **no flood-2328** command.

Defaults

Disabled

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

In OSPF, flooding is the most resource-consuming task. The flooding algorithm, described in RFC-2328, requires that OSPF flood LSAs (Link State Advertisements) on all interfaces, as governed by LSA's flooding scope (see Section 13 of the RFC). When multiple direct links connect two routers, the RFC-2328 flooding algorithm generates significant redundant information across all links.

By default, FTOS implements an enhanced flooding procedure that dynamically and intelligently determines when to optimize flooding. Whenever possible, the OSPF task attempts to reduce flooding overhead by selectively flooding on a subset of the interfaces between two routers.

When **flood-2328** is enabled, this command configures FTOS to flood LSAs on all interfaces.

graceful-restart grace-period

CES

Specifies the time duration, in seconds, that the router's neighbors will continue to advertise the router as fully adjacent regardless of the synchronization state during a graceful restart.

Syntax

graceful-restart grace-period seconds

To disable the grace period, enter **no graceful-restart grace-period**.

Parameters

seconds	Time duration, in seconds, that specifies the duration of the restart process before OSPF terminates the process.
	Range: 40 to 3000 seconds

Defaults

Not Configured

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.4	Introduced on S60
Version 7.8.1.0	Introduced for S-Series
	Introduced support for Multi-Process OSPF.
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

OSPF Graceful Restart is not supported on the S60 system.

graceful-restart helper-reject

CES Specify the OSPF router to not act as a helper during graceful restart.

Syntax graceful-restart helper-reject ip-address

To return to default value, enter no graceful-restart helper-reject.

Parameters

ip-address	Enter the OSPF router-id, in IP address format, of the restart router that will
	not act as a helper during graceful restart.

Defaults Not Configured

Command Modes ROUTER OSPF

> Command History

Version 8.3.3.4	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
	Restart role enabled on S-Series (Both Helper and Restart roles now supported on S-Series.
Version 7.7.1.0	Helper-Role supported on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

graceful-restart mode

CES Enable the graceful restart mode.

Syntax graceful-restart mode [planned-only | unplanned-only]

To disable graceful restart mode, enter **no graceful-restart mode**.

Parameters

planned-only	(OPTIONAL) Enter the keywords planned-only to indicate graceful restart is supported in a planned restart condition only.
unplanned-only	(OPTIONAL) Enter the keywords unplanned-only to indicate graceful restart is supported in an unplanned restart condition only.

Defaults Support for both planned and unplanned failures.

Command Modes ROUTER OSPF

Command History

Version 8.3.3.4	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

graceful-restart role

CES

Specify the role for your OSPF router during graceful restart.

Syntax

graceful-restart role [helper-only | restart-only]

To disable graceful restart role, enter **no graceful-restart role**.

Parameters

role helper-only	(OPTIONAL) Enter the keywords helper-only to specify the OSPF router is a helper only during graceful restart.
role restart-only	(OPTIONAL) Enter the keywords restart-only to specify the OSPF router is a restart only during graceful-restart.

Defaults

OSPF routers are, by default, both helper and restart routers during a graceful restart.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.4	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
	Restart and helper roles supported on S-Series
Version 7.7.1	Helper-Role supported on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

ip ospf auth-change-wait-time © E S OSPF provides a grace period while

OSPF provides a grace period while OSPF changes its interface authentication type. During the grace period, OSPF sends out packets with new and old authentication scheme till the grace period expires.

Syntax

ip ospf auth-change-wait-time seconds

To return to the default, enter **no ip ospf auth-change-wait-time**.

Parameters

seconds	Enter seconds
	Range: 0 to 300

Defaults

zero (0) seconds

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

ip ospf authentication-key

Enable authentication and set an authentication key on OSPF traffic on an interface.

Syntax ip ospf authentication-key [encryption-type] key

To delete an authentication key, enter **no ip ospf authentication-key**.

Parameters

encryption-type	(OPTIONAL) Enter 7 to encrypt the key.
key	Enter an 8 character string. Strings longer than 8 characters are truncated.

Defaults Not configured.

Command Modes INTERFACE

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information All neighboring routers in the same network must use the same password to exchange OSPF information.

ip ospf cost

ĊES Change the cost associated with the OSPF traffic on an interface.

Syntax ip ospf cost cost

To return to default value, enter **no ip ospf cost**.

Parameters

cost Enter a number as the cost. Range: 1 to 65535.

Defaults The default cost is based on the reference bandwidth.

Command Modes INTERFACE

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

If this command is not configured, cost is based on the auto-cost command.

When you configure OSPF over multiple vendors, use the ip ospf cost command to ensure that all routers use the same cost. Otherwise, OSPF routes improperly.

Related Commands

auto-cost Control how the OSPF interface cost is calculated.

ip ospf dead-interval

CES

Set the time interval since the last hello-packet was received from a router. After the interval elapses, the neighboring routers declare the router dead.

Syntax ip ospf dead-interval seconds

To return to the default values, enter **no ip ospf dead-interval**.

Parameters

Seconds Enter the number of seconds for the interval.
Range: 1 to 65535. Default: 40 seconds.

Defaults 40 seconds

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information By default, the dead interval is four times the default hello-interval.

Related Commands

ip ospf hello-interval Set the time interval between hello packets.

ip ospf hello-interval

CES

Specify the time interval between the hello packets sent on the interface.

Syntax ip ospf hello-interval seconds

To return to the default value, enter **no ip ospf hello-interval**.

Parameters

Seconds Enter a the number of second as the delay between hello packets.

Range: 1 to 65535.

Default: 10 seconds.

Defaults 10 seconds

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

The time interval between hello packets must be the same for routers in a network.

Related **Commands**

ip ospf dead-interval Set the time interval before a router is declared dead.

ip ospf message-digest-key

CES

Enable OSPF MD5 authentication and send an OSPF message digest key on the interface.

Syntax

ip ospf message-digest-key keyid md5 key

To delete a key, use the **no ip ospf message-digest-key** *keyid* command.

Parameters

keyid	Enter a number as the key ID.
	Range: 1 to 255.
key	Enter a continuous character string as the password.

Defaults

No MD5 authentication is configured.

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

To change to a different key on the interface, enable the new key while the old key is still enabled. The FTOS will send two packets: the first packet authenticated with the old key, and the second packet authenticated with the new key. This process ensures that the neighbors learn the new key and communication is not disrupted by keeping the old key enabled.

After the reply is received and the new key is authenticated, you must delete the old key. Dell Networking recommends keeping only one key per interface.



Note: The MD5 secret is stored as plain text in the configuration file with service password encryption.

ip ospf mtu-ignore

Disable OSPF MTU mismatch detection upon receipt of database description (DBD) packets.

Syntax ip ospf mtu-ignore

To return to the default, enter **no ip ospf mtu-ignore**.

Defaults Enabled

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

ip ospf network

Set the network type for the interface.

Syntax ip ospf network {broadcast | point-to-point}

To return to the default, enter **no ip ospf network**.

Parameters

broadcast	Enter the keyword broadcast to designate the interface as part of a broadcast network.
point-to-point	Enter the keyword point-to-point to designate the interface as part of a point-to-point network.

Defaults Not configured.

Command Modes ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

ip ospf priority

Set the priority of the interface to determine the Designated Router for the OSPF network.

Syntax ip ospf priority number

To return to the default setting, enter **no ip ospf priority**.

Parameters

number	Enter a number as the priority.
	Range: 0 to 255.
	The default is 1.

Defaults

1

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Setting a priority of 0 makes the router ineligible for election as a Designated Router or Backup Designated Router.

Use this command for interfaces connected to multi-access networks, not point-to-point networks.

ip ospf retransmit-interval

(C) (E) (S)

Set the retransmission time between lost link state advertisements (LSAs) for adjacencies belonging to the interface.

Syntax

ip ospf retransmit-interval seconds

To return to the default values, enter **no ip ospf retransmit-interva**l.

Parameters

seconds	Enter the number of seconds as the interval between retransmission.
	Range: 1 to 3600.
	Default: 5 seconds.
	This interval must be greater than the expected round-trip time for a packet to travel
	between two routers.

Defaults

5 seconds

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Set the time interval to a number large enough to prevent unnecessary retransmissions. For example, the interval should be larger for interfaces connected to virtual links.

ip ospf transmit-delay

Set the estimated time elapsed to send a link state update packet on the interface.

Syntax ip ospf transmit-delay seconds

To return to the default value, enter **no ip ospf transmit-delay**.

Parameters

Seconds

Enter the number of seconds as the transmission time. This value should be greater than the transmission and propagation delays for the interface.

Range: 1 to 3600.

Default: 1 second.

Defaults 1 second

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

log-adjacency-changes

CES Set FTOS to send a Syslog message about changes in the OSPF adjacency state.

Syntax log-adjacency-changes

To disable the Syslog messages, enter no log-adjacency-changes.

Defaults Disabled.

Command Mode ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

maximum-paths

C E S Enable the software to forward packets over multiple paths.

Syntax maximum-paths number

To disable packet forwarding over multiple paths, enter **no maximum-paths**.

Parameters

number	Specify the number of paths.
	Range: 1 to 16.
	Default: 4 paths.

Defaults

Command Modes ROUTER OSPF

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

mib-binding

CES Enable this OSPF process ID to manage the SNMP traps and process SNMP queries.

Syntax mib-binding

To mib-binding on this OSPF process, enter **no mib-binding**.

Defaults None.

Command Modes ROUTER OSPF

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced to all platforms.

Usage Information

This command is either enabled or disabled. If no OSPF process is identified as the MIB manager, the first OSPF process will be used.

If an OSPF process has been selected, it must be disabled prior to assigning new process ID the MIB responsibility.

network area

CES Define which interfaces run OSPF and the OSPF area for those interfaces.

Syntax network ip-address mask area area-id

To disable an OSPF area, use the **no network** *ip-address mask* **area** *area-id* command.

Parameters

ip-address	Specify a primary or secondary address in dotted decimal format. The primary address
	is required before adding the secondary address.

mask	Enter a network mask in /prefix format. (/x)
area-id	Enter the OSPF area ID as either a decimal value or in a valid IP address.
	Decimal value range: 0 to 65535
	IP address format: dotted decimal format A.B.C.D.
	Note: If the area ID is smaller than 65535, it will be converted to a decimal value. For example, if you use an area ID of 0.0.0.1, it will be converted to 1.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

To enable OSPF on an interface, the network area command must include, in its range of addresses, the primary IP address of an interface.



Note: An interface can be attached only to a single OSPF area.

If you delete all the network area commands for Area 0, the show ip ospf command output will not list Area 0.

passive-interface

CES

Suppress both receiving and sending routing updates on an interface.

Syntax

passive-interface {default | interface}

To enable both the receiving and sending routing, enter the **no passive-interface** *interface* command.

To return all OSPF interfaces (current and future) to active, enter the **no passive-interface default** command.

Parameters

default	Enter the keyword default to make all OSPF interfaces (current and future) passive.
interface	Enter the following keywords and slot/port or number information:
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Modified to include the default keyword.
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Although the passive interface will neither send nor receive routing updates, the network on that interface will still be included in OSPF updates sent via other interfaces.

The default keyword sets all interfaces as passive. You can then configure individual interfaces, where adjacencies are desired, using the **no passive-interface** interface command. The no form of this command is inserted into the configuration for individual interfaces when the no passive-interface interface command is issued while passive-interface default is configured.

This command behavior has changed as follows:

passive-interface interface

- The previous **no passive-interface** interface is removed from the running configuration.
- The ABR status for the router is updated.
- Save **passive-interface** interface into the running configuration.

passive-interface default

- All present and future OSPF interface are marked as passive.
- Any adjacency are explicitly terminated from all OSPF interfaces.
- All previous **passive-interface** interface commands are removed from the running configuration.
- All previous **no passive-interface** interface commands are removed from the running configuration.

no passive-interface interface

- Remove the interface from the passive list.
- The ABR status for the router is updated.
- If passive-interface default is specified, then save no passive-interface interface into the running configuration.

No passive-interface default

- Clear everything and revert to the default behavior.
- All previously marked passive interfaces are removed.
- May update ABR status.

redistribute

CES

Redistribute information from another routing protocol throughout the OSPF process.

Syntax

redistribute {connected | rip | static} [metric metric-value | metric-type type-value] [route-map map-name] [tag tag-value]

To disable redistribution, use the **no redistribute** {connected | isis | rip | static} command.

Parameters

connected	Enter the keyword connected to specify that information from active routes on interfaces is redistributed.
rip	Enter the keyword rip to specify that RIP routing information is redistributed.
static	Enter the keyword static to specify that information from static routes is redistributed.
metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number.
	Range: 0 (zero) to 16777214.
metric-type type-value	(OPTIONAL) Enter the keyword metric-type followed by one of the following:
	• 1 = OSPF External type 1
	• 2 = OSPF External type 2
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of the route map.
tag tag-value	(OPTIONAL) Enter the keyword tag followed by a number.
	Range: 0 to 4294967295

Defaults

Not configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

To redistribute the default route (0.0.0.0/0), configure the default-information originate command.

Related Commands

default-information originate Generate a default route into the OSPF routing domain.

redistribute bgp

CES

Redistribute BGP routing information throughout the OSPF instance.

Syntax

redistribute bgp as number [metric metric-value] | [metric-type type-value] | [tag tag-value]

To disable redistribution, use the **no redistribute bgp** as number [**metric** metric-value] | [**metric-type** type-value] [**route-map** map-name] [**tag** tag-value] command.

Parameters

	as number	Enter the autonomous system number.
		Range: 1 to 65535
•	metric metric-value	(OPTIONAL) Enter the keyword metric followed by the metric-value number. Range: 0 to16777214

metric-type type-value	(OPTIONAL) Enter the keyword metric-type followed by one of the following:
	• 1 = for OSPF External type 1
	• 2 = for OSPF External type 2
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of the route map.
tag tag-value	(OPTIONAL) Enter the keyword tag to set the tag for routes redistributed into OSPF. Range: 0 to 4294967295

Defaults

No default behavior or values

Command Modes

ROUTER OSPF

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.3	Introduced Route Map for BGP Redistribution to OSPF
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Modified to include the default keyword.
pre-Version 6.1.1.1	Introduced on E-Series

redistribute isis

CES

Redistribute IS-IS routing information throughout the OSPF instance.

Syntax

redistribute isis [tag] [level-1 | level-1-2 | level-2] [metric metric-value | metric-type type-value] [route-map map-name] [tag tag-value]

To disable redistribution, use the **no redistribute isis** [tag] [level-1 | level-1-2 | level-2] [metric metric-value | metric-type type-value] [route-map map-name] [tag tag-value] command.

Parameters

tag	(OPTIONAL) Enter the name of the IS-IS routing process.
level-1	(OPTIONAL) Enter the keyword level-1 to redistribute only IS-IS Level-1 routes.
level-1-2	(OPTIONAL) Enter the keyword level-1-2 to redistribute both IS-IS Level-1 and Level-2 routes.
level-2	(OPTIONAL) Enter the keyword level-2 to redistribute only IS-IS Level-2 routes.
metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number.
	Range: 0 (zero) to 4294967295.
metric-type type-value	(OPTIONAL) Enter the keyword metric-type followed by one of the following:
	 1 = for OSPF External type 1 2 = for OSPF External type 2

route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of the route map.
tag tag-value	(OPTIONAL) Enter the keyword tag followed by a number. Range: 0 to 4294967295

Defaults

Not configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

IS-IS is not supported on S-Series platforms.

router-id

CES

Use this command to configure a fixed router ID.

Syntax

router-id ip-address

To remove the fixed router ID, use the **no router-id** ip-address command.

Parameters

ip-address	Enter the router ID in the IP address format
------------	--

Defaults

This command has no default behavior or values.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support for Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-2. Command Example: router-id

```
FTOS (conf) #router ospf 100
FTOS (conf-router ospf) #router-id 1.1.1.1
Changing router-id will bring down existing OSPF adjacency [y/n]:

FTOS (conf-router_ospf) #show config
!
router ospf 100
router-id 1.1.1.1
FTOS (conf-router ospf) #no router-id
Changing router-id will bring down existing OSPF adjacency [y/n]:
FTOS#
```

Usage Information

You can configure an arbitrary value in the IP address format for each router. However, each router ID must be unique. If this command is used on an OSPF router process, which is already active (that is, has neighbors), a prompt reminding you that changing router-id will bring down the existing OSPF adjacency. The new router ID is effective at the next reload.

router ospf

CES

Enter the ROUTER OSPF mode to configure an OSPF instance.

Syntax

router ospf process-id [vrf {vrf name}]

To clear an OSPF instance, enter **no router ospf** process-id.

Parameters

process-id	Enter a number for the OSPF instance.
	Range: 1 to 65535.
vrf name	(Optional) E-Series Only : Enter the VRF process identifier to tie the OSPF instance to the VRF. All network commands under this OSPF instance are subsequently tied to the VRF instance.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.9.1.0	Introduced VRF
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-3. Command Example: router ospf

```
FTOS(conf) #router ospf 2
FTOS(conf-router_ospf)#
```

Usage Information

You must have an IP address assigned to an interface to enter the ROUTER OSPF mode and configure OSPF.

Once the OSPF process and the VRF are tied together, the OSPF Process ID cannot be used again in the system.

show config

[C][E][S]

Display the non-default values in the current OSPF configuration.

Syntax

show config

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-4. Command Example: show config

```
FTOS(conf-router_ospf)#show config
!
router ospf 3
passive-interface FastEthernet 0/1
FTOS(conf-router_ospf)#
```

show ip ospf

CES

Display information on the OSPF process configured on the switch.

Syntax

show ip ospf process-id [vrf vrf name]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
vrf name	E-Series Only : Show only the OSPF information tied to the VRF process.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.9.1.0	Introduced VRF
Version 7.9.1.0	Introduced VRF
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.8.1.0	Introduced <i>process-id</i> option, in support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series
-	

Usage Information

If you delete all the network area commands for Area 0, the show ip ospf command output will not list Area 0.

Example

Figure 25-5. Command Example: show ip ospf process-id

```
FTOS>show ip ospf 1
Routing Process ospf 1 with ID 11.1.2.1
Supports only single TOS (TOS0) routes
It is an autonomous system boundaryrouter
SPF schedule delay 0 secs, Hold time between two SPFs 5 secs
Number of area in this router is 1, normal 1 stub 0 nssa 0
Area BACKBONE (0.0.0.0)

Number of interface in this area is 2
SPF algorithm executed 4 times
Area ranges are
FTOS>
```

Table 25-2. Command Output Descriptions: show ip ospf process-id

Line Beginning with	Description
"Routing Process"	Displays the OSPF process ID and the IP address associated with the process ID.
"Supports only"	Displays the number of Type of Service (TOS) rouse supported.
"SPF schedule"	Displays the delay and hold time configured for this process ID.
"Number of"	Displays the number and type of areas configured for this process ID.

Related **Commands**

show ip ospf database	Displays information about the OSPF routes configured.
show ip ospf interface	Displays the OSPF interfaces configured.
show ip ospf neighbor	Displays the OSPF neighbors configured.
show ip ospf virtual-links	Displays the OSPF virtual links configured.

show ip ospf asbr

Display all ASBR routers visible to OSPF.

Syntax show ip ospf process-id asbr

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.8.1.0	Introduced <i>process-id</i> option, in support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

Use this command to isolate problems with external routes. In OSPF, external routes are calculated by adding the LSA cost to the cost of reaching the ASBR router. If an external route does not have the correct cost, use this command to determine if the path to the originating router is correct. The display output is not sorted in any order.



Note: ASBRs that are not in directly connected areas are also displayed.

Example

Figure 25-6. Command Example: show ip ospf process-id asbr

You can determine if an ASBR is in a directly connected area (or not) by the flags. For ASBRs in a directly connected area, E flags are set. In the figure above, router 1.1.1.1 is in a directly connected area since the Flag is E/-/-/. For remote ASBRs, the E flag is clear (-/-/-/)

show ip ospf database

Display all LSA information. If OSPF is not enabled on the switch, no output is generated.

Syntax show ip ospf process-id database [database-summary]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
database-summary	(OPTIONAL) Enter the keywords database-summary to the display the number of LSA types in each area and the total number of LSAs.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 25-7. Command Example: show ip ospf process-id database

FTOS>show ip ospf 1 database OSPF Router with ID (11.1.2.1) (Process ID 1) Router (Area 0.0.0.0) Link ID ADV Router Age Seq# Checksum Link count Age 5eq# 5x707e 676 0x80000097 0x1035 2 11.1.2.1 13.1.1.1 11.1.2.1 13.1.1.1 676 2 13.1.1.1 676 0x80000097 0x1033 192.68.135.2 1419 0x80000294 0x9cbd Seq# 0x° Network (Area 0.0.0.0) Link ID ADV Router Age 10.2.3.2 13.1.1.1 676 10.2.4.2 192.68.135.2 908 Checksum 0x80000003 0x6592 0x80000055 0x683e Type-5 AS External Type-5 AS External

ADV Router Age Seq#

0.0.0.0 192.68.135.2 908 0x800

1.1.1.1 192.68.135.2 908 0x800

10.1.2.0 11.1.2.1 718 0x800

10.2.2.0 11.1.2.1 718 0x800

10.2.3.0 11.1.2.1 718 0x800

10.2.4.0 13.1.1.1 1184 0x800

11.1.2.1 718 0x800 Checksum Tag 0x80000052 0xeb83 100 0x8000002a 0xbd27 0x80000002 0x9012 0x80000002 0x851c 0x80000002 0x80000002 0x7927 0x6e31
 13.1.1.1
 1184
 0x80000002

 13.1.1.1
 1184
 0x80000008

 11.1.2.1
 718
 0x80000002

 11.1.2.1
 718
 0x80000005

 192.68.135.2
 1663
 0x80000054

 13.1.1.1
 1192
 0x8000006b

 13.1.1.1
 1184
 0x8000006b
 0x45db 0 0x831e 0 11.1.2.0 0x78280 12.1.2.0 0xd8d6 0 13.1.1.0 13.1.2.0 0x27180 0x1c22 0 172.16.1.0 148 0x8000006d 0x533b Ω 13.1.1.1 FTOS>

Table 25-3. Command Output Description: show ip ospf process-id database

Field	Description
Link ID	Identifies the router ID.
ADV Router	Identifies the advertising router's ID.
Age	Displays the link state age.
Seq#	Identifies the link state sequence number. This number enables you to identify old or duplicate link state advertisements.
Checksum	Displays the Fletcher checksum of an LSA's complete contents.
Link count	Displays the number of interfaces for that router.

Related **Commands**

show ip ospf database asbr-summary

CES Display information about AS Boundary LSAs.

Syntax show ip ospf process-id database asbr-summary [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-8. Command Example: show ip ospf database asbr-summary (Partial)

```
FTOS#show ip ospf 100 database asbr-summary

OSPF Router with ID (1.1.1.10) (Process ID 100)

Summary Asbr (Area 0.0.0.0)

LS age: 1437
Options: (No TOS-capability, No DC, E)
LS type: Summary Asbr
Link State ID: 103.1.50.1
Advertising Router: 1.1.1.10
LS Seq Number: 0x8000000f
Checksum: 0x8221
Length: 28
Network Mask: /0
TOS: 0 Metric: 2

LS age: 473
Options: (No TOS-capability, No DC, E)
LS type: Summary Asbr
Link State ID: 104.1.50.1
Advertising Router: 1.1.1.10
LS Seq Number: 0x80000010
Checksum: 0x4198
Length: 28
--More--
```

Table 25-4. Command Output Descriptions: show ip ospf database asbr-summary

Item	Description
LS Age	Displays the LSA's age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	• TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	• E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA's type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the advertising router's ID.
Checksum	Displays the Fletcher checksum of the an LSA's complete contents.
Length	Displays the length in bytes of the LSA.
Network Mask	Displays the network mask implemented on the area.
TOS	Displays the Type of Service (TOS) options. Option 0 is the only option.
Metric	Displays the LSA metric.

Related Commands

show ip ospf database	Displays OSPF database information.

show ip ospf database external

CES Display information on the AS external (type 5) LSAs.

show ip ospf process-id database external [link-state-id] [adv-router ip-address]

Parameters

Syntax

process-id	Enter the OSPF Process ID to show a specific process. If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	 (OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following: the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Fig

Figure 25-9. Command Example: show ip ospf database external

```
FTOS#show ip ospf 1 database external
              OSPF Router with ID (20.20.20.5) (Process ID 1)
                   Type-5 AS External
  LS age: 612
  Options: (No TOS-capability, No DC, E)
LS type: Type-5 AS External
Link State ID: 12.12.12.2
  Advertising Router: 20.31.3.1
LS Seq Number: 0x80000007
  Checksum: 0x4cde
  Length: 36
Network Mask: /32
       Metrics Type: 2
       TOS: 0
       Metrics: 25
Forward Address: 0.0.0.0
       External Route Tag: 43
  LS age: 1868
  Options: (No TOS-capability, DC)
  LS type: Type-5 AS External
Link State ID: 24.216.12.0
  Advertising Router: 20.20.20.8
  LS Seq Number: 0x8000005
  Checksum: 0xa00e
  Length: 36
  Network Mask: /24
       Metrics Type: 2
       TOS: 0
       Metrics: 1
       Forward Address: 0.0.0.0
       External Route Tag: 701
FTOS#
```

Table 25-5. Command Example Descriptions: show ip ospf *process-id* database external

Item	Description
LS Age	Displays the LSA age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA's type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the router ID of the LSA's originating router.
LS Seq Number	Identifies the link state sequence number. This number enables you to identify old or duplicate LSAs.
Checksum	Displays the Fletcher checksum of an LSA's complete contents.

Table 25-5. Command Example Descriptions: show ip ospf process-id database external

Item	Description
Length	Displays the length in bytes of the LSA.
Network Mask	Displays the network mask implemented on the area.
Metrics Type	Displays the external type.
TOS	Displays the TOS options. Option 0 is the only option.
Metrics	Displays the LSA metric.
Forward Address	Identifies the address of the forwarding router. Data traffic is forwarded to this router. If the forwarding address is 0.0.0.0, data traffic is forwarded to the originating router.
External Route Tag	Displays the 32-bit field attached to each external route. This field is not used by the OSPF protocol, but can be used for external route management.

Related Commands

show ip ospf database	Displays OSPF database information.

show ip ospf database network

CES

Syntax

Display the network (type 2) LSA information.

show ip ospf process-id database network [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process. If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 25-10. Command Example: show ip ospf process-id database network

```
FTOS#show ip ospf 1 data network
            OSPF Router with ID (20.20.20.5) (Process ID 1)
                Network (Area 0.0.0.0)
 LS age: 1372
 Options: (No TOS-capability, DC, E)
 LS type: Network
Link State ID: 202.10.10.2
 Advertising Router: 20.20.20.8
 LS Seq Number: 0x80000006
 Checksum: 0xa35
 Length: 36
 Network Mask: /24
     Attached Router: 20.20.20.8
     Attached Router: 20.20.20.9
     Attached Router: 20.20.20.7
                Network (Area 0.0.0.1)
 LS age: 252
 Options: (TOS-capability, No DC, E)
 LS type: Network
 Link State ID: 192.10.10.2
 Advertising Router: 192.10.10.2
 LS Seq Number: 0x80000007
 Checksum: 0x4309
 Length: 36
 Network Mask: /24
     Attached Router: 192.10.10.2
     Attached Router: 20.20.20.1
     Attached Router: 20.20.20.5
FTOS#
```

Table 25-6. Command Example Descriptions: show ip ospf *process-id* database network

Item	Description
LS Age	Displays the LSA age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA's type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the router ID of the LSA's originating router.
Checksum	Identifies the link state sequence number. This number enables you to identify old or duplicate LSAs.
Length	Displays the Fletcher checksum of an LSA's complete contents.
Network Mask	Displays the length in bytes of the LSA.
Attached Router	Identifies the IP address of routers attached to the network.

Related Commands

show ip ospf database	Displays OSPF database information.	

show ip ospf database nssa-external

Display NSSA-External (type 7) LSA information.

Syntax show ip ospf database nssa-external [link-state-id] [adv-router ip-address]

Parameters

link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:	
	 the network's IP address for Type 3 LSAs or Type 5 LSAs 	
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs 	
	• the default destination (0.0.0.0) for Type 5 LSAs	
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.	
ip-audi c ss	information about that router.	

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Related **Commands**

show ip ospf database	Displays OSPF database information.
-----------------------	-------------------------------------

show ip ospf database opaque-area

CES Display the opaque-area (type 10) LSA information.

show ip ospf process-id database opaque-area [link-state-id] [adv-router ip-address] **Syntax**

Parameters

process-id	Enter the OSPF Process ID to show a specific process. If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.8.1.0	Introduced support of Multi-Process OSPF.	

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-11. Command Example: show ip ospf *process-id* database opaque-area (Partial)

```
OSPF Router with ID (3.3.3.3) (Process ID 1)

Type-10 Opaque Link Area (Area 0)

LS age: 1133
Options: (No TOS-capability, No DC, E)
LS type: Type-10 Opaque Link Area
Link State ID: 1.0.0.1
Advertising Router: 10.16.1.160
LS Seq Number: 0x80000416
Checksum: 0x376
Length: 28
Opaque Type: 1
Opaque ID: 1
Unable to display opaque data

LS age: 833
Options: (No TOS-capability, No DC, E)
LS type: Type-10 Opaque Link Area
Link State ID: 1.0.0.2
Advertising Router: 10.16.1.160
LS Seq Number: 0x800000002
Checksum: 0x19c2
--More--
```

Table 25-7. Command Example Descriptions: show ip ospf process-id database opaque-area

Item	Description
LS Age	Displays the LSA's age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	• E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA's type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the advertising router's ID.
Checksum	Displays the Fletcher checksum of the an LSA's complete contents.
Length	Displays the length in bytes of the LSA.
Opaque Type	Displays the Opaque type field (the first 8 bits of the Link State ID).
Opaque ID	Displays the Opaque type-specific ID (the remaining 24 bits of the Link State ID).

Related Commands

show ip ospf database	Displays OSPF database information.	

show ip ospf database opaque-as

Display the opaque-as (type 11) LSA information.

Syntax show ip ospf process-id database opaque-as [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Related Commands

show ip ospf database	Displays OSPF database information.
SHOW ID USDI Uatabase	Displays OSI I database illibilitation.

show ip ospf database opaque-link

CĖS Display the opaque-link (type 9) LSA information.

Syntax show ip ospf process-id database opaque-link [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keyword adv-router followed by the IP address of an Advertising Router to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series
show in cenf database	Displays OSDE database information

Related Commands

show ip ospf database router

CĖS

Display the router (type 1) LSA information.

Syntax show ip ospf process-id database router [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 25-12. Command Example: show ip ospf process-id database router (Partial)

```
FTOS#show ip ospf 100 database router
            OSPF Router with ID (1.1.1.10) (Process ID 100)
                Router (Area 0)
 LS age: 967
 Options: (No TOS-capability, No DC, E)
 LS type: Router
 Link State ID: 1.1.1.10
 Advertising Router: 1.1.1.10
 LS Seq Number: 0x8000012f
 Checksum: 0x3357
 Length: 144
 AS Boundary Router
 Area Border Router
  Number of Links: 10
   Link connected to: a Transit Network
     (Link ID) Designated Router address: 192.68.129.1
     (Link Data) Router Interface address: 192.68.129.1
    Number of TOS metric: 0
     TOS 0 Metric: 1
   Link connected to: a Transit Network
     (Link ID) Designated Router address: 192.68.130.1
     (Link Data) Router Interface address: 192.68.130.1
    Number of TOS metric: 0
     TOS 0 Metric: 1
   Link connected to: a Transit Network
     (Link ID) Designated Router address: 192.68.142.2
     (Link Data) Router Interface address: 192.68.142.2
    Number of TOS metric: 0
     TOS 0 Metric: 1
   Link connected to: a Transit Network
     (Link ID) Designated Router address: 192.68.141.2
     (Link Data) Router Interface address: 192.68.141.2
    Number of TOS metric: 0
TOS 0 Metric: 1
   Link connected to: a Transit Network
     (Link ID) Designated Router address: 192.68.140.2
     (Link Data) Router Interface address: 192.68.140.2
    Number of TOS metric: 0
     TOS 0 Metric: 1
   Link connected to: a Stub Network
     (Link ID) Network/subnet number: 11.1.5.0
 More-
```

Table 25-8. Command Example Descriptions: show ip ospf process-id database router

Item	Description
LS Age	Displays the LSA age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	• TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	• DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the router ID of the LSA's originating router.

Table 25-8. Command Example Descriptions: show ip ospf process-id database router

Item	Description
LS Seq Number	Displays the link state sequence number. This number detects duplicate or old LSAs.
Checksum	Displays the Fletcher checksum of an LSA's complete contents.
Length	Displays the length in bytes of the LSA.
Number of Links	Displays the number of active links to the type of router (Area Border Router or AS Boundary Router) listed in the previous line.
Link connected to:	Identifies the type of network to which the router is connected.
(Link ID)	Identifies the link type and address.
(Link Data)	Identifies the router interface address.
Number of TOS Metric	Lists the number of TOS metrics.
TOS 0 Metric	Lists the number of TOS 0 metrics.

Related Commands

show ip ospf database Displays OSPF database information.

show ip ospf database summary

Display the network summary (type 3) LSA routing information.

Syntax show ip ospf process-id database summary [link-state-id] [adv-router ip-address]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
link-state-id	(OPTIONAL) Specify LSA ID in dotted decimal format. The LSA ID value depends on the LSA type, and it can be one of the following:
	 the network's IP address for Type 3 LSAs or Type 5 LSAs
	 the router's OSPF router ID for Type 1 LSAs or Type 4 LSAs
	• the default destination (0.0.0.0) for Type 5 LSAs
adv-router ip-address	(OPTIONAL) Enter the keywords adv-router ip-address to display only the LSA information about that router.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 25-13. Command Example: show ip ospf process-id database summary

```
FTOS#show ip ospf 100 database summary
             OSPF Router with ID (1.1.1.10) (Process ID 100)
                 Summary Network (Area 0.0.0.0)
  LS age: 1551
  Options: (No TOS-capability, DC, E)
 LS type: Summary Network
Link State ID: 192.68.16.0
  Advertising Router: 192.168.17.1
  LS Seq Number: 0x80000054
  Checksum: 0xb5a2
  Length: 28
 Network Mask: /24
      TOS: 0 Metric: 1
 LS age: 9
 Options: (No TOS-capability, No DC, E) LS type: Summary Network
  Link State ID: 192.68.32.0
 Advertising Router: 1.1.1.10
  LS Seq Number: 0x80000016
  Checksum: 0x987c
  Length: 28
 Network Mask: /24
      TOS: 0 Metric: 1
 LS age: 7
 Options: (No TOS-capability, No DC, E) LS type: Summary Network
 Link State ID: 192.68.33.0
  Advertising Router: 1.1.1.10
 LS Seq Number: 0x80000016
 Checksum: 0x1241
 Length: 28
Network Mask: /26
      TOS: 0 Metric: 1
FTOS#
```

Table 25-9. Command Example Descriptions: show ip ospf process-id database summary

Items	Description
LS Age	Displays the LSA age.
Options	Displays the optional capabilities available on router. The following options can be found in this item:
	TOS-capability or No TOS-capability is displayed depending on whether the router can support Type of Service.
	DC or No DC is displayed depending on whether the originating router can support OSPF over demand circuits.
	E or No E is displayed on whether the originating router can accept AS External LSAs.
LS Type	Displays the LSA's type.
Link State ID	Displays the Link State ID.
Advertising Router	Identifies the router ID of the LSA's originating router.
LS Seq Number	Identifies the link state sequence number. This number enables you to identify old or duplicate LSAs.
Checksum	Displays the Fletcher checksum of an LSA's complete contents.
Length	Displays the length in bytes of the LSA.

Table 25-9. Command Example Descriptions: show ip ospf process-id database summary

Items	Description
Network Mask	Displays the network mask implemented on the area.
TOS	Displays the TOS options. Option 0 is the only option.
Metric	Displays the LSA metrics.

Related Commands

show ip ospf database Displays OSPF database information.

show ip ospf interface

Display the OSPF interfaces configured. If OSPF is not enabled on the switch, no output is generated.

Syntax show ip ospf process-id interface [interface]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For the null interface, enter the keyword null followed by zero (0).
	 For loopback interfaces, enter the keyword loopback followed by a number from 0 to 16383.
	• For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN, enter the keyword vlan followed by the VLAN ID. The range is from 1 to 4094.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced process-id option, in support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 25-14. Command Example: show ip ospf process-id interface

```
FTOS>show ip ospf int
GigabitEthernet 13/17 is up, line protocol is up
  Internet Address 192.168.1.2/30, Area 0.0.0.1
  Process ID 1, Router ID 192.168.253.2, Network Type BROADCAST, Cost: 1
  Transmit Delay is 1 sec, State DR, Priority 1
  Designated Router (ID) 192.168.253.2, Interface address 192.168.1.2
  Backup Designated Router (ID) 192.168.253.1, Interface address 192.168.1.1
  Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
    Hello due in 00:00:02
  Neighbor Count is 1, Adjacent neighbor count is 1
    Adjacent with neighbor 192.168.253.1 (Backup Designated Router)
GigabitEthernet 13/23 is up, line protocol is up
Internet Address 192.168.0.1/24, Area 0.0.0.1
Process ID 1, Router ID 192.168.253.2, Network Type BROADCAST, Cost: 1
  Transmit Delay is 1 sec, State DROTHER, Priority 1
Designated Router (ID) 192.168.253.5, Interface address 192.168.0.4
Backup Designated Router (ID) 192.168.253.3, Interface address 192.168.0.2
  Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
  Hello due in 00:00:08

Neighbor Count is 3, Adjacent neighbor count is 2
     Adjacent with neighbor 192.168.253.5 (Designated Router)
     Adjacent with neighbor 192.168.253.3 (Backup Designated Router)
Loopback 0 is up, line protocol is up
  Internet Address 192.168.253.2/32, Area 0.0.0.1
Process ID 1, Router ID 192.168.253.2, Network Type LOOPBACK, Cost: 1
Loopback interface is treated as a stub Host.
FTOS>
```

Table 25-10. Command Example Descriptions: show ip ospf process-id interface

Line beginning with	Description
GigabitEthernet	This line identifies the interface type slot/port and the status of the OSPF protocol on that interface.
Internet Address	This line displays the IP address, network mask and area assigned to this interface.
Process ID	This line displays the OSPF Process ID, Router ID, Network type and cost metric for this interface.
Transmit Delay	This line displays the interface's settings for Transmit Delay, State, and Priority. In the State setting, BDR is Backup Designated Router.
Designated Router	This line displays the ID of the Designated Router and its interface address.
Backup Designated	This line displays the ID of the Backup Designated Router and its interface address.
Timer intervals	This line displays the interface's timer settings for Hello interval, Dead interval, Transmit Delay (Wait), and Retransmit Interval.
Hello due	This line displays the amount time till the next Hello packet is sent out this interface.
Neighbor Count	This line displays the number of neighbors and adjacent neighbors. Listed below this line are the details about each adjacent neighbor.

show ip ospf neighbor

Display the OSPF neighbors configured.

Syntax show ip ospf process-id neighbor

Parameters

process-id Enter the OSPF Process ID to show a specific process.

If no Process ID is entered, command applies only to the first OSPF process.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-15. Command Example: show ip ospf process-id neighbor

FTOS#show ip ospf 34 neighbor Neighbor ID Pri Dead Time Address Interface Area 00:00:32 182.10.10.3 00:00:37 192.10.10.2 20.20.20.7 FULL/DR Gi 0/0 0.0.0.2 192.10.10.2 1 FULL/DR Gi 0/1 0.0.0.1 20.20.20.1 FULL/DROTHER00:00:36 192.10.10.4 Gi 0/1 0.0.0.1

Table 25-11. Command Example Descriptions: show ip ospf process-id neighbor

Row Heading	Description
Neighbor ID	Displays the neighbor router ID.
Pri	Displays the priority assigned neighbor.
State	Displays the OSPF state of the neighbor.
Dead Time	Displays the expected time until FTOS declares the neighbor dead.
Address	Displays the IP address of the neighbor.
Interface	Displays the interface type slot/port information.
Area	Displays the neighbor's area (process ID).

show ip ospf routes

CES Display routes as calculated by OSPF and stored in OSPF RIB.

Syntax show ip ospf process-id routes

Parameters

process-id Enter the OSPF Process ID to show a specific process.

If no Process ID is entered, command applies only to the first OSPF process.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

This command is useful in isolating routing problems between OSPF and RTM. For example, if a route is missing from the RTM/FIB but is visible from the display output of this command, then likely the problem is with downloading the route to the RTM.

This command has the following limitations:

- The display output is sorted by prefixes; intra-area ECMP routes are not displayed together.
- For Type 2 external routes, type 1 cost is not displayed.

Example

Figure 25-16. Command Example: show ip ospf process-id routes

FTOS#show ip osp	of 100 re	oute			
Prefix	Cost	Nexthop	Interface	Area	Type
1.1.1.1	1	0.0.0.0	Lo 0	0	Intra-Area
3.3.3.3	2	13.0.0.3	Gi 0/47	1	Intra-Area
13.0.0.0	1	0.0.0.0	Gi 0/47	0	Intra-Area
150.150.150.0	2	13.0.0.3	Gi 0/47	_	External
172.30.1.0	2	13.0.0.3	Gi 0/47	1	Intra-Are
FTOS#			,		

show ip ospf statistics

CES

Display OSPF statistics.

Syntax

show ip ospf process-id statistics global | [interface name {neighbor router-id}]

Parameters

process-id	Enter the OSPF Process ID to show a specific process.			
	If no Process ID is entered, command applies only to the first OSPF process.			
global	Enter the keyword global to display the packet counts received on all running OSPF interfaces and packet counts received and transmitted by all OSPF neighbors.			

interface name	(OPTIONAL) Enter the keyword interface followed by one of the following interface keywords and slot/port or number information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	• For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094
neighbor router-id	(OPTIONAL) Enter the keyword neighbor followed by the neighbor's router-id in dotted decimal format (A.B.C.D.).

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

Figure 25-17. Command Example: show ip ospf process-id statistics global

igule 25-17.	Comman	u Lxaiii	ic. silo	w ip osp	i process ia	Statistic	,s gi
FTOS#show ip	ospf 1 sta	tistics	global				
OSPF Packet (Total RX 10 TX 10	Error 0		DDiscr 2 0	LSReq 0 0	LSUpd 0 0	LSAck 0 0	
OSPF Global (Hello-Q LSR-Q Other-Q))	Tx-Mark 0 0 0	Rx-Mar 2 0	k	
Error packets Intf-Down Wrong-Len Auth-Err Version No-Buffer Q-OverFlow	0 0 0 0	Non-Dr Invld-Nl MD5-Err AreaMis Seq-No Unkown-		-	Self-Org Nbr-State Chksum Conf-Issue: Socket	s	0 0 0 0
Error packets Socket Errors FTOS#	s (Only fo						,

Table 25-12. Command Example Descriptions: show ip ospf statistics process-id global

Row Heading	Description
Total	Displays the total number of packets received/transmitted by the OSPF process
Error	Displays the error count while receiving and transmitting packets by the OSPF process
Hello	Number of OSPF Hello packets
DDiscr	Number of database description packets
LSReq	Number of link state request packets
LSUpd	Number of link state update packets
LSAck	Number of link state acknowledgement packets
TxQ-Len	The transmission queue length
RxQ-Len	The reception queue length
Tx-Mark	The highest number mark in the transmission queue
Rx-Mark	The highest number mark in the reception queue
Hello-Q	The queue, for transmission or reception, for the hello packets
LSR-Q	The queue, for transmission or reception, for the link state request packets.
Other-Q	The queue, for transmission or reception, for the link state acknowledgement, database description, and update packets.

Table 25-13. Error Definitions: show ip ospf statistics process-id global

Error Type	Description
Intf_Down	Received packets on an interface that is either down or OSPF is not enabled.
Non-Dr	Received packets with a destination address of ALL_DRS even though SELF is not a designated router
Self-Org	Receive the self originated packet
Wrong_Len	The received packet length is different to what was indicated in the OSPF header
Invld-Nbr	LSA, LSR, LSU, and DDB are received from a peer which is not a neighbor peer
Nbr-State	LSA, LSR, and LSU are received from a neighbor with stats less than the loading state
Auth-Error	Simple authentication error
MD5-Error	MD5 error
Cksum-Err	Checksum Error
Version	Version mismatch
AreaMismatch	Area mismatch
Conf-Issue	The received hello packet has a different hello or dead interval than the configuration
No-Buffer	Buffer allocation failure
Seq-no	A sequence no errors occurred during the database exchange process
Socket	Socket Read/Write operation error
Q-overflow	Packet(s) dropped due to queue overflow
Unknown-Pkt	Received packet is not an OSPF packet

The **show ip ospf** *process-id* **statistics** command displays the error packet count received on each interface as:

- The hello-timer remaining value for each interface
- The wait-timer remaining value for each interface
- The grace-timer remaining value for each interface
- The packet count received and transmitted for each neighbor
- Dead timer remaining value for each neighbor
- Transmit timer remaining value for each neighbor
- The LSU Q length and its highest mark for each neighbor
- The LSR Q length and its highest mark for each neighbor

Example

Figure 25-18. Command Example: show ip ospf process-id statistics

```
FTOS#show ip ospf 100 statistics
Interface GigabitEthernet 0/8
    Hello-Timer 9, Wait-Timer 0, Grace-Timer 0
Error packets (Only for RX)
Intf-Down
                                                  Self-Org
                 0
                     Non-Dr
                     Invld-Nbr
                                                                      0
                                                  Nbr-State
Wrong-Len
                 Ω
                                             Ω
Auth-Error
                 Ω
                     MD5-Error
                                              0
                                                  Cksum-Err
                                                                      0
                     AreaMisMatch
                                                                      0
Version
                 0
                                                  Conf-Issue
                 0 Unkown-Pkt
SeqNo-Err
    Neighbor ID 9.1.1.2
              Hello
                           DDiscr
                                       LSReq
                                                 LSUpd
                                                            LSAck
                59
                           3
                                       1
    ΤX
                62
                            2
                                       1
                                                  0
                                                             0
     Dead-Timer
                          37, Transmit-Timer
                                                         0
     LSU-Q-Len
                           0, LSU-Q-Wmark
                                                         0
     LSR-Q-Len
                           0, LSR-Q-Wmark
```

Related Commands

clear ip ospf statistics

Clear the packet statistics in all interfaces and neighbors

show ip ospf topology

CES

Display routers in directly connected areas.

Syntax

show ip ospf process-id topology

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.

Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series and E-Series

Usage Information

This command can be used to isolate problems with inter-area and external routes. In OSPF inter-area and external routes are calculated by adding LSA cost to the cost of reaching the router. If an inter-area or external route is not of correct cost, the display can determine if the path to the originating router is correct or not.

Example

Figure 25-19. Command Example: show ip ospf process-id topology

```
FTOS#show ip ospf 1 topology
Router ID
                  Flags
                           Cost
                                   Nexthop
                                                      Interface
                                                                    Area
                 E/B/-/ 1 20.0.0.3
E/-/-/ 1 10.0.0.1
                                                  Gi 13/1
Gi 7/1
3.3.3.3
                                                                 0
1.1.1.1
                                    10.0.0.1
                                                                     1
FTOS#
```

show ip ospf virtual-links

Display the OSPF virtual links configured and is useful for debugging OSPF routing operations. If no OSPF virtual-links are enabled on the switch, no output is generated.

show ip ospf process-id virtual-links **Syntax**

Parameters

process-id	Enter the OSPF Process ID to show a specific process.
	If no Process ID is entered, command applies only to the first OSPF process.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example

Figure 25-20. Command Example: show ip ospf process-id virtual-links

```
FTOS#show ip ospf 1 virt
Virtual Link to router 192.168.253.5 is up
   Run as demand circuit
   Transit area 0.0.0.1, via interface GigabitEthernet 13/16, Cost of using 2
   Transmit Delay is 1 sec, State POINT_TO_POINT,
       Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
       Hello due in 00:00:02
FTOS#
```

Table 25-14. Command Example Descriptions: show ip ospf process-id virtual-links

Items	Description
"Virtual Link"	This line specifies the OSPF neighbor to which the virtual link was created and the link's status.
"Run as"	This line states the nature of the virtual link.
"Transit area"	This line identifies the area through which the virtual link was created, the interface used, and the cost assigned to that link.
"Transmit Delay"	This line displays the transmit delay assigned to the link and the State of the OSPF neighbor.
"Timer intervals"	This line displays the timer values assigned to the virtual link. The timers are Hello is hello-interval, Dead is dead-interval, Wait is transmit-delay, and Retransmit is retransmit-interval.
"Hello due"	This line displays the amount of time until the next Hello packet is expected from the neighbor router.
"Adjacency State"	This line displays the adjacency state between neighbors.

summary-address

CES

Set the OSPF ASBR to advertise one external route.

Syntax

summary-address ip-address mask [not-advertise] [tag tag-value]

To disable summary address, use the **no summary-address** *ip-address mask* command.

Parameters

ip-address	Specify the IP address in dotted decimal format of the address to be summarized.
mask	Specify the mask in dotted decimal format of the address to be summarized.
not-advertise	(OPTIONAL) Enter the keyword not-advertise to suppress that match the network prefix/mask pair.
tag tag-value	(OPTIONAL) Enter the keyword tag followed by a value to match on routes redistributed through a route map. Range: 0 to 4294967295

Defaults

Not configured.

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

The command area range summarizes routes for the different areas.

With "not-advertise" parameter configured, this command can be used to filter out some external routes. For example, you want to redistribute static routes to OSPF, but you don't want OSPF to advertise routes with prefix 1.1.0.0. Then you can configure summary-address 1.1.0.0 255.255.0.0 not-advertise to filter out all the routes fall in range 1.1.0.0/16.

Related **Commands**

area range Summarizes routes within an area.

timers spf

CES

Set the time interval between when the switch receives a topology change and starts a shortest path first (SPF) calculation.

Syntax timers spf delay holdtime

To return to the default, enter **no timers spf**.

Parameters

delay	Enter a number as the delay.
	Range: 0 to 4294967295.
	Default: 5 seconds
holdtime	Enter a number as the hold time.
	Range: 0 to 4294967295.
	Default: 10 seconds.

Defaults

delay = 5 seconds; holdtime = 10 seconds

Command Modes

ROUTER OSPF

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced support of Multi-Process OSPF.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Setting the delay and holdtime parameters to a low number enables the switch to switch to an alternate path quickly but requires more CPU usage.

PIM-Sparse Mode (PIM-SM)

Overview

The platforms on which a command is supported is indicated by the character — [E] for the E-Series, [C] for the C-Series, and [S] for the S-Series — that appears below each command heading.

This chapter contains the following sections:

IPv4 PIM-Sparse Mode Commands

IPv4 PIM-Sparse Mode Commands

The IPv4 PIM-Sparse Mode (PIM-SM) commands are:

- clear ip pim rp-mapping
- clear ip pim tib
- debug ip pim
- ip pim bsr-border
- ip pim bsr-candidate
- ip pim dr-priority
- ip pim graceful-restart
- ip pim join-filter
- ip pim neighbor-filter
- ip pim query-interval
- ip pim register-filter
- ip pim rp-address
- ip pim rp-candidate
- ip pim sparse-mode
- ip pim sparse-mode sg-expiry-timer
- ip pim spt-threshold
- show ip pim bsr-router
- show ip pim interface
- show ip pim neighbor
- show ip pim rp
- show ip pim tib

clear ip pim rp-mapping

Used by the bootstrap router (BSR) to remove all or particular Rendezvous Point (RP) Advertisement.

Syntax clear ip pim rp-mapping rp-address

Parameters (OPTIONAL) Enter the RP address in dotted decimal format (A.B.C.D)

Command Modes EXEC Privilege

Command History

Version 8.3.3.1 Introduced on S60

Version 8.1.1.0 Introduced on E-Series ExaScale

Version 7.8.1.0 Introduced on S-Series

clear ip pim tib

Clear PIM tree information from the PIM database.

Syntax clear ip pim tib [group]

Parameters group (OPTIONAL) Enter the multicast group address in dotted decimal format (A.B.C.D)

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

debug ip pim

CES View IP PIM debugging messages.

Syntax debug ip pim [bsr | events | group | packet [in | out] | register | state | timer [assert | hello | joinprune | register]]

To disable PIM debugging, enter **no debug ip pim**, or enter **undebug all** to disable all debugging.

Parameters

RP/BSR
es for a specific
Enter one of the

register	(OPTIONAL) Enter the keyword register to view PIM register address in dotted decimal format (A.B.C.D).
state	(OPTIONAL) Enter the keyword state to view PIM state changes.
timer [assert hello joinprune register]	(OPTIONAL) Enter the keyword timer to view PIM timers. Enter one of the optional parameters:
	 assert: to view the assertion timer.
	 hello: to view the PIM neighbor keepalive timer.
	• joinprune: to view the expiry timer (join/prune timer)
	• register: to view the register suppression timer.

Defaults

Disabled

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

ip pim bsr-border

CES

Define the border of PIM domain by filtering inbound and outbound PIM-BSR messages per interface.

Syntax

ip pim bsr-border

To return to the default value, enter **no ip pim bsr-border**.

Defaults

Disabled

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series on port-channels and S-Series.

Usage Information

This command is applied to the subsequent PIM-BSR. Existing BSR advertisements are cleaned up by time out. Candidate RP advertisements can be cleaned using the clear ip pim rp-mapping command.

ip pim bsr-candidate

CES

Configure the PIM router to join the Bootstrap election process.

Syntax

ip pim bsr-candidate interface [hash-mask-length] [priority]

To return to the default value, enter **no ip pim bsr-candidate**.

Parameters interface Enter the following keywords and slot/port or number information: For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information. For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383. For Port Channel interface types, enter the keyword port-channel followed by a number from 1 to 255. For a SONET interface, enter the keyword sonet followed by the slot/port information. For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information. For a VLAN, enter the keyword **vlan** followed by a number from 1 to 4094. hash-mask-length (OPTIONAL) Enter the hash mask length. Range: zero (0) to 32 Default: 30 (OPTIONAL) Enter the priority used in Bootstrap election process. priority Range: zero (0) to 255 Default: zero (0) **Defaults** Not configured. **Command Modes**

ip pim dr-priority

CES

Command

History

Change the Designated Router (DR) priority for the interface.

Introduced on S60

Introduced on S-Series

Added support for VLAN interface

Syntax

ip pim dr-priority priority-value

CONFIGURATION

Version 8.3.3.1

Version 7.8.1.0

Version 6.1.1.0

To remove the DR priority value assigned, use the **no ip pim dr-priority** command.

Parameters

priority-value	Enter a number. Preference is given to larger/higher number.
	Range: 0 to 4294967294
	Default: 1

Defaults

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series on port-channels and S-Series

Usage Information

The router with the largest value assigned to an interface becomes the Designated Router. If two interfaces contain the same DR priority value, the interface with the largest interface IP address becomes the Designated Router.

ip pim graceful-restart

This feature permits configuration of Non-stop Forwarding (NFS or graceful restart) capability of a PIM router to its neighbors.

Syntax

[ipv6] ip pim graceful-restart {helper-only | nsf [restart-time | stale-entry-time]}

Parameters

ipv6	Enter this keyword to enable graceful-restart for IPv6 Multicast Routes.	
helper-only	Enter the keyword helper-only to configure as a receiver (helper) only by preserving the PIM status of a graceful restart PIM neighboring router.	
nsf	Enter the keyword nfs to configure the N on-stop Forwarding capability.	
restart-time	(OPTIONAL) Enter the keyword restart-time followed by the number of seconds estimated for the PIM speaker to restart.	
	Range: 30 to 300 seconds	
	Default: 180 seconds	
stale-entry-time	(OPTIONAL) Enter the keyword stale-entry-time followed by the number of seconds for which entries are kept alive after restart.	
	Range: 30 to 300 seconds	
	Default: 60 seconds	

Defaults

as above

Command Modes

CONFIGURATION

Command History

Version 8.2.1.0 Introduced on E-Series ExaScale. Added the ipv6 option for E-Series	
Version 7.6.1.0	Introduced on E-Series

Usage Information

When an NSF-capable router comes up, it announces the graceful restart capability and restart duration as a Hello option. The receiving router notes the Hello option. Routers not NSF capable will discard the unknown Hello option and adjacency is not affected.

When an NSF-capable router goes down, neighboring PIM speaker preserves the states and continues the forwarding of multicast traffic while the neighbor router restarts.

ip pim join-filter

Permit or deny PIM Join/Prune messages on an interface using an extended IP access list. This command prevents the PIM SM router from creating state based on multicast source and/or group.

Syntax

ip pim join-filter ext-access-list {in | out}

Remove the access list using the command **no ip pim join-filter** ext-access-list {in | out}

Parameters

ext-access-list	Enter the name of an extended access list.
in	Enter this keyword to apply the access list to inbound traffic.
out	Enter this keyword to apply the access list to outbound traffic.

Defaults

None

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series on port-channels and S-Series
Version 7.7.1.0	Introduced on E-Series.

Example

Figure 26-1. Command Example: ip pim join-filter

```
FTOS(conf)# ip access-list extended iptv-channels
FTOS(config-ext-nacl)# permit ip 10.1.2.3/24 225.1.1.0/24
FTOS(config-ext-nacl)# permit ip any 232.1.1.0/24
FTOS(config-ext-nacl)# permit ip 100.1.1.0/16 any
FTOS(config-if-gi-1/1)# ip pim join-filter iptv-channels in
FTOS(config-if-gi-1/1)# ip pim join-filter iptv-channels out
```

Related Commands

ip access-list	Configure an access list based on IP addresses or protocols.
extended	

ip pim neighbor-filter

CES Configure this feature to prevent a router from participating in protocol independent Multicast (PIM).

Syntax ip pim neighbor-filter { access-list}

To remove the restriction, use the **no ip pim neighbor-filter** {access-list} command.

Parameters

access-list	Enter the name of a standard access list. Maximum 16 characters.	
-------------	--	--

Defaults

Defaults.

Command Modes

CONFIGURATION.

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series and S-Series
Version 7.6.1.0	Introduced on the E-Series

Usage Information

Do not enter this command before creating the access-list.

ip pim query-interval

Change the frequency of PIM Router-Query messages.

Syntax ip pim query-interval seconds

To return to the default value, enter **no ip pim query-interval** seconds command.

Parameters

Enter a number as the number of seconds between router query messages. seconds Default: 30 seconds Range: 0 to 65535

Defaults 30 seconds

Command Modes INTERFACE

> Command History

Version 8.3.3.1 Introduced on S60 Version 8.1.1.0 Introduced on E-Series ExaScale Version 7.8.1.0 Introduced on C-Series on port-channels and S-Series

ip pim register-filter

Use this feature to prevent a PIM source DR from sending register packets to an RP for the specified multicast source and group.

Syntax ip pim register-filter access-list

To return to the default, use the **no ip pim register-filter** access-list command.

Parameters

access-list Enter the name of an extended access list. Maximum 16 characters.

Defaults Not configured

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1 Introduced on S60 Version 7.8.1.0 Introduced on C-Series and S-Series Version 7.6.1.0 Introduced

Usage Information The access name is an extended IP access list that denies PIM register packets to RP at the source DR based on the multicast and group addresses. Do not enter this command before creating the access-list.

ip pim rp-address

CESConfigure a static PIM Rendezvous Point (RP) address for a group or access-list.

Syntax ip pim rp-address address {group-address group-address mask} override

> To remove an RP address, use the **no ip pim rp-address** address {group-address group-address mask} override command.

address	Enter the RP address in dotted decimal format (A.B.C.D).
group-address group-address mask	Enter the keyword group-address followed by a group-address mask, in dotted decimal format $(/xx)$, to assign that group address to the RP.
override	Enter the keyword override to override the BSR updates with static RP. The override will take effect immediately during enable/disable. Note: This option is applicable to multicast group range.

Defaults

Not configured

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

This address is used by first-hop routers to send Register packets on behalf of source multicast hosts. The RP addresses are stored in the order in which they are entered. RP addresses learned via BSR take priority over static RP addresses. Without the override option, RPs advertised by the BSR updates take precedence over the statically configured RPs.

ip pim rp-candidate

CES

Configure a PIM router to send out a Candidate-RP-Advertisement message to the Bootstrap (BS) router or define group prefixes that are defined with the RP address to PIM BSR.

Syntax

ip pim rp-candidate { interface [priority]

To return to the default value, enter **no ip pim rp-candidate** { interface [priority] command.

Parameters

interface	Enter the following keywords and slot/port or number information:
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383.
	 For Port Channel interface types, enter the keyword port-channel followed by a number from 1 to 255.
	 For a SONET interface, enter the keyword sonet followed by the slot port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
priority	(OPTIONAL) Enter the priority used in Bootstrap election process.
	Range: zero (0) to 255
	Default: 192

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Priority is stored at BSR router when receiving a Candidate-RP-Advertisement.

ip pim sparse-mode

Enable PIM sparse mode and IGMP on the interface. [C][E][S]

Syntax ip pim sparse-mode

To disable PIM sparse mode and IGMP, enter **no ip pim sparse-mode**.

Defaults Disabled.

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series on port-channels and S-Series

Usage Information

C-Series supports a maximum of 31 PIM interfaces.

The interface must be enabled (no shutdown command) and not have the switchport command configured. Multicast must also be enabled globally (using the ip multicast-lag-hashing command). PIM is supported on the port-channel interface.

Related Commands

ip multicast-lag-hashing	Enable multicast globally.	

ip pim sparse-mode sg-expiry-timer

CES

Enable expiry timers globally for all sources, or for a specific set of (S,G) pairs defined by an access list.

Syntax ip pim sparse-mode sg-expiry-timer seconds [access-list name]

> To disable configured timers and return to default mode, enter **no ip pim sparse-mode** sg-expiry-timer.

Parameters

seconds	Enter the number of seconds the S, G entries will be retained. Range 211-86400
access-list name	(OPTIONAL) Enter the name of a previously configured Extended ACL to enable the expiry time to specified S,G entries

Defaults

Disabled. The default expiry timer (with no times configured) is 210 sec.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 8.1.1.0	Introduced on E-Series ExaScale	
Version 7.8.1.0	Introduced	
Version 7.7.1.1	Introduced	

Usage Information

This command configures an expiration timer for all S.G entries, unless they are assigned to an Extended ACL.

ip pim spt-threshold

Configure PIM router to switch to shortest path tree when the traffic reaches the specified threshold value.

Syntax ip pim spt-threshold value | infinity

To return to the default value, enter **no ip pim spt-threshold**.

Parameters

value	(OPTIONAL) Enter the traffic value in kilobits per second.
	Default: 10 packets per second. A value of zero (0) will cause a switchover on the first packet.
infinity	(OPTIONAL) To never switch to the source-tree, enter the keyword infinity .

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on C-Series on port-channels and S-Series

Usage Information

This is applicable to last hop routers on the shared tree towards the Rendezvous Point (RP).

show ip pim bsr-router

C E S View information on the Bootstrap router.

Syntax show ip pim bsr-router

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

Example Figure 26-2. Command Example: show ip pim bsr-router

```
E600-7-rpm0#show ip pim bsr-router PIMv2 Bootstrap information
This system is the Bootstrap Router (v2)
   BSR address: 7.7.7.7 (?)
Uptime: 16:59:06, BSR Priority: 0, Hash mask length: 30
   Next bootstrap message in 00:00:08
This system is a candidate BSR
   Candidate BSR address: 7.7.7.7, priority: 0, hash mask length: 30
```

show ip pim interface

View information on the interfaces with IP PIM enabled.

Syntax show ip pim interface

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

Example

Figure 26-3. Command Example: show ip pim interface

```
E600-7-RPM0#show ip pim interface
                                                           Nbr Query DR I
Count Intvl Prio
                           Interface Ver/
Address
                                                                                             DR
                                              Mode
                                             v2/s 0 30 1 172.21.200.254

v2/s 0 30 1 172.60.1.2

v2/s 1 30 1 192.3.1.1

v2/s 0 30 1 192.4.1.1

v2/s 0 30 1 172.21.110.1

v2/s 0 30 1 172.21.110.1
172.21.200.254 Gi 7/9
172.60.1.2 Gi 7/11
192.3.1.1 Gi 7/16
192.4.1.1 Gi 13/5
172.21.110.1 Gi 13/6
172.21.203.1 Gi 13/7
```

Table 26-1. show ip pim interface Command Example Fields

Field	Description
Address	Lists the IP addresses of the interfaces participating in PIM.
Interface	List the interface type, with either slot/port information or ID (VLAN or Port Channel), of the interfaces participating in PIM.
Ver/Mode	Displays the PIM version number and mode for each interface participating in PIM. • v2 = PIM version 2 • S = PIM Sparse mode
Nbr Count	Displays the number of PIM neighbors discovered over this interface.
Query Intvl	Displays the query interval for Router Query messages on that interface (configured with ip pim query-interval command).

Table 26-1. show ip pim interface Command Example Fields

Field	Description
	Displays the Designated Router priority value configured on the interface (ip pim dr-priority command).
DR	Displays the IP address of the Designated Router for that interface.

show ip pim neighbor

CES View PIM neighbors.

Syntax show ip pim neighbor

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

Example

Figure 26-4. Command Example: show ip pim neighbor

FTOS#show ip pim neighbor
Neighbor Interface Uptime/Expires Ver DR
Address Prio/Mode
127.87.3.4 Gi 7/16 09:44:58/00:01:24 v2 1 / S
FTOS#

Table 26-2. show ip pim neighbor Command Example Fields

Field	Description
Neighbor address	Displays the IP address of the PIM neighbor.
Interface	List the interface type, with either slot/port information or ID (VLAN or Port Channel), on which the PIM neighbor was found.
Uptime/expires	Displays the amount of time the neighbor has been up followed by the amount of time until the neighbor is removed from the multicast routing table (that is, until the neighbor hold time expires).
Ver	Displays the PIM version number. • v2 = PIM version 2
DR prio/Mode	Displays the Designated Router priority and the mode. • 1 = default Designated Router priority (use ip pim dr-priority) • DR = Designated Router • S = source

show ip pim rp

View all multicast groups-to-RP mappings.

Syntax show ip pim rp [mapping | *group-address*]

Parameters

mapping	(OPTIONAL) Enter the keyword mapping to display the multicast groups-to-RP mapping and information on how RP is learnt.
group-address	(OPTIONAL) Enter the multicast group address mask in dotted decimal format to view RP for a specific group.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

Example 1 Figure 26-5. Command Example 1: show ip pim rp mapping

```
FTOS#sh ip pim rp
Group
                 RP
224.2.197.115
                 165.87.20.4
224.2.217.146
                 165.87.20.4
224.3.3.3
                 165.87.20.4
225.1.2.1
                 165.87.20.4
225.1.2.2
                 165.87.20.4
                 165.87.20.4
229.1.2.1
229.1.2.2
                 165.87.20.4
FTOS#
```

Example 2 Figure 26-6. Command Example 2: show ip pim rp mapping

```
FTOS#sh ip pim rp mapping
Group(s): 224.0.0.0/4
RP: 165.87.20.4, v2
    Info source: 165.87.20.5, via bootstrap, priority 0
           Uptime: 00:03:11, expires: 00:02:46
  RP: 165.87.20.3, v2
     Info source: 165.87.20.5, via bootstrap, priority 0
          Uptime: 00:03:11, expires: 00:03:03
FTOS#
```

Example 3 Figure 26-7. Command Example 3: show ip pim rp group-address

```
FTOS#sh ip pim rp 229.1.2.1
Group
                 RP
229.1.2.1
                 165.87.20.4
FTOS#
```

show ip pim tib

CES View the PIM tree information base (TIB).

Syntax show ip pim tib [group-address [source-address]]

Parameters

group-address (OPTIONAL) Enter the group address in dotted decimal format (A.B.C.D)

source-address (OPTIONAL) Enter the source address in dotted decimal format (A.B.C.D).

Command Modes EXEC

EAEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series

Example

Figure 26-8. Command Example: show ip pim tib

```
FTOS#show ip pim tib
PIM Multicast Routing Table
Flags: D - Dense, S - Sparse, C - Connected, L - Local, P - Pruned,
       R - RP-bit set, F - Register flag, T - SPT-bit set, J - Join SPT,
       M - MSDP created entry, A - Candidate for MSDP Advertisement,
       K - Ack-Pending State
Timers: Uptime/Expires
Interface state: Interface, next-Hop, State/Mode
(*, 226.1.1.1), uptime 01:29:19, expires 00:00:52, RP 10.211.2.1, flags: SCJ
  Incoming interface: GigabitEthernet 4/23, RPF neighbor 10.211.1.2
  Outgoing interface list:
    GigabitEthernet 8/0
(*, 226.1.1.2), uptime 00:18:08, expires 00:00:52, RP 10.211.2.1, flags: SCJ
  Incoming interface: GigabitEthernet 4/23, RPF neighbor 10.211.1.2
 Outgoing interface list:
GigabitEthernet 8/0
(*, 226.1.1.3), uptime 00:18:08, expires 00:00:52, RP 10.211.2.1, flags: SCJ
  Incoming interface: GigabitEthernet 4/23, RPF neighbor 10.211.1.2
 Outgoing interface list:
    GigabitEthernet 8/0
(*, 226.1.1.4), uptime 00:18:08, expires 00:00:52, RP 10.211.2.1, flags: SCJ
  Incoming interface: GigabitEthernet 4/23, RPF neighbor 10.211.1.2
 Outgoing interface list:
    GigabitEthernet 8/0
FTOS#
```

Table 26-3. show ip pim tib Command Example Fields

Field	Description
(S, G)	Displays the entry in the multicast PIM database.
uptime	Displays the amount of time the entry has been in the PIM route table.
expires	Displays the amount of time until the entry expires and is removed from the database.
RP	Displays the IP address of the RP/source for this entry.

Table 26-3. show ip pim tib Command Example Fields (continued)

Field	Description
flags	List the flags to define the entries:
	• D = PIM Dense Mode
	• S = PIM Sparse Mode
	C = directly connected
	• L = local to the multicast group
	• P = route was pruned
	• R = the forwarding entry is pointing toward the RP
	• F = FTOS is registering this entry for a multicast source
	T = packets were received via Shortest Tree Path
	J = first packet from the last hop router is received and the entry is ready to switch to SPT
	K= acknowledge pending state
Incoming interface	Displays the reverse path forwarding (RPF) interface towards the RP/ source.
RPF neighbor	Displays the next hop from this interface towards the RP/source.
Outgoing interface list:	Lists the interfaces that meet one of the following criteria:
	a directly connect member of the Group.
	statically configured member of the Group.
	received a (*,G) Join message.

PIM-Source Specific Mode (PIM-SSM)

Overview

The platforms on which a command is supported is indicated by the character — [E] for the E-Series, [C] for the C-Series, and [S] for the S-Series — that appears below each command heading.

This chapter contains the following sections:

- **IPv4 PIM Commands**
- IPv4 PIM-Source Specific Mode COmmands

IPv4 PIM Commands

The following commands apply to IPv4 PIM-SM, PIM-SSM, and PIM-DM:

- clear ip pim tib
- debug ip pim
- ip pim dr-priority
- ip pim graceful-restart
- ip pim neighbor-filter
- ip pim query-interval

IPv4 PIM-Source Specific Mode COmmands

The IPv4 PIM-Source Specific Mode (PIM-SSM) commands are:

- ip pim ssm-range
- ip pim join-filter
- show ip pim ssm-range

ip pim ssm-range

CES Specify the SSM group range using an access-list.

Syntax ip pim ssm-range {access_list_name}

Parameters

access_list_name Enter the name of the access list.

Defaults Default SSM range is 232/8 and ff3x/32

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series.
Version 7.5.1.0	Introduced on E-Series.

Usage Information

FTOS supports standard access list for the SSM range. Extended ACL cannot be used for configuring SSM range. If an Extended ACL is configured and then used in the **ip pim ssm-range** { access list name} configuration, an error is reported.

However, if **ip pim ssm-range** { access list name} is configured first and then the ACL is configured as an Extended ACL, an error is *not* reported and the ACL is not applied to the SSM range.

FTOS recommended best-practices are to configure the standard ACL, and then apply the ACL to the SSM range. Once the SSM range is applied, the changes are applied internally without requiring clearing of the TIB.

When ACL rules change, the ACL and PIM modules apply the new rules automatically.

When SSM range is configured, FTOS supports SSM for configured group range as well as default SSM range.

When the SSM ACL is removed, PIM SSM is supported for default SSM range only

show ip pim ssm-range

Display the non-default groups added using the SSM range feature.

Syntax show ip pim ssm-range

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.8.1.0	Introduced on S-Series
Version 7.7.1.0	Introduced on C-Series.
Version 7.5.1.0	Introduced on E-Series.

Port Monitoring

Overview

The Port Monitoring feature enables you to monitor network traffic by forwarding a copy of each incoming or outgoing packet from one port to another port.

The commands in this chapter are generally supported on the C-Series, E-Series, and S-Series, with one exception, as noted in the Command History fields and by these symbols under the command headings: [C] [E] [S]

Commands

- description
- flow-based enable
- monitor session
- show config
- show monitor session
- show running-config monitor session
- source

Important Points to Remember

- On the E-Series, Port Monitoring is supported on TeraScale and ExaScale platforms.
- Port Monitoring is supported on physical ports only. Logical interfaces, such as Port Channels and VLANs, are not supported.
- FTOS supports as many monitor sessions on a system as the number of port-pipes.
- A SONET port can only be configured as a monitored port.
- The monitoring (destination, "MG") and monitored (source, "MD") ports must be on the same switch.
- A monitoring port can monitor any physical port in the chassis.
- Only one MG and one MD may be in a single port-pipe.
- A monitoring port can monitor more than one port.
- More than one monitored port can have the same destination monitoring port.
- FTOS on the S-Series supports multiple source ports to be monitored by a single destination port in one monitor session.

• On the S-Series, one monitor session can have only one MG port. There is no restriction on the number of source ports, or destination ports on the chassis.



Note: The monitoring port should not be a part of any other configuration.

description

CES

Enter a description of this monitoring session

Syntax descrip

description { description}

To remove the description, use the **no description** { description} command.

Parameters

description Enter a description regarding this session(80 characters maximum).

Defaults

No default behavior or values

Command Modes

MONITOR SESSION (conf-mon-sess-session-ID)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-7.7.1.0	Introduced on E-Series

Related Commands

monitor session Enable a monitoring session.

flow-based enable

Enable flow-based monitoring.

Syntax flow-based enable

To disable flow-based monitoring, use the **no flow-based enable** command.

Defaults

Disabled, that is flow-based monitoring is not applied

Command Modes

MONITOR SESSION (conf-mon-sess-session-ID)

Command History

Version 8.1.1.0 Introduced on E-Series ExaScale

Version 7.4.1.0 Introduced on E-Series

Usage Information To monitoring traffic with particular flows ingressing/egressing the interface, appropriate ACLs can be applied in both ingress and egress direction.

Related Commands

monitor session Create a monitoring session.

monitor session

CESCreate a session for monitoring traffic.

Syntax monitor session session-ID

To delete a session, use the **no monitor session** session-ID command.

To delete all monitor sessions, use the **no monitor session** command.

Parameters

session-ID Enter a session identification number. Range: 0 to 65535

Defaults No default values or behaviors

Command Modes MONITOR SESSION (conf-mon-sess-session-ID)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

Figure 28-1. Command Example: monitor session

FTOS(conf) # monitor session 60 FTOS(conf-mon-sess-60)

Usage Information

All monitor sessions contain an implicit "mode interface," that is, if no mode is designated, the mode is set to interface as shown in the example above.

The monitor command is saved in the running configuration at the Monitor Session mode level and can be restored after a chassis reload.

Related Commands

show monitor session	Display the monitor session
show running-config monitor session	Display the running configuration of a monitor session

show config

CES Display the current monitor session configuration.

Syntax show config

Defaults No default values or behavior

Command Modes MONITOR SESSION (conf-mon-sess-session-ID)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

FTOS(conf-mon-sess-11)#show config
!
monitor session 11
source GigabitEthernet 10/0 destination GigabitEthernet 10/47 direction rx
FTOS#

show monitor session

CES

Display the monitor information of a particular session or all sessions.

Syntax

show monitor session {session-ID}

To display the monitor information for all sessions, use the **show monitor session** command.

Parameters

session-ID (OPTIONAL) Enter a session identification number.

Range: 0 to 65535

Defaults

No default values or behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

Figure 28-2. Commands Example: show monitor session

FTOS#show monitor session 11

SessionID Source Destination Direction Mode

11 Gi 10/0 Gi 10/47 rx interface

FTOS#

Related Commands

monitor session Create a session for monitoring.

show running-config monitor session

Display the running configuration of all monitor sessions or a specific session. CES

Syntax show running-config monitor session {session-ID}

> To display the running configuration for all monitor sessions, use just the **show running-config** monitor session command.

Parameters

session-ID	(OPTIONAL) Enter a session identification number.
	Range: 0 to 65535

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

```
FTOS#show running-config monitor session
monitor session 8
source GigabitEthernet 10/46 destination GigabitEthernet 10/1 direction rx
source GigabitEthernet 10/0 destination GigabitEthernet 10/47 direction rx
FTOS#show running-config monitor session 11
monitor session 11
source GigabitEthernet 10/0 destination GigabitEthernet 10/47 direction rx
```

Usage Information

The monitoring command is saved in the running configuration at the Monitor Session mode level and can be restored after a chassis reload.

Related **Commands**

monitor session	Create a session for monitoring.
show monitor session	Display a monitor session.

source

[C][E][S]

Configure a port monitor source.

Syntax

source interface destination interface direction {rx | tx | both}

To disable a monitor source, use the no source interface destination interface direction {rx | tx | both } command.

Parameters

interface	Enter the one of the following keywords and slot/port information:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
destination	Enter the keyword destination to indicate the interface destination.
direction {rx tx both}	Enter the keyword direction followed by one of the packet directional indicators.
	rx : to monitor receiving packets only
	tx : to monitor transmitting packets only
	both: to monitor both transmitting and receiving packets

Defaults

No default behavior or values

Command Modes

MONITOR SESSION (conf-mon-sess-session-ID)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Example

Figure 28-3. Command Example: Configuring a Port Monitor Source

FTOS(conf-mon-sess-11)#source gi 10/0 destination gi 10/47 direction rx FTOS(conf-mon-sess-11)#

Usage Information



Note: A SONET port can only be configured as a monitored port.

Private VLAN (PVLAN)

Overview

Starting with FTOS 7.8.1.0, the Private VLAN (PVLAN) feature of FTOS is available for the C-Series and S-Series: [C] [S]

Commands

- ip local-proxy-arp
- private-vlan mode
- private-vlan mapping secondary-vlan
- show interfaces private-vlan
- show vlan private-vlan
- show vlan private-vlan mapping
- switchport mode private-vlan

See also the following commands. The command output is augmented in FTOS 7.8.1.0 to provide PVLAN data:

- show arp in IPv4 Routing
- show vlan in Chapter 20, Layer 2

Private VLANs extend the FTOS security suite by providing Layer 2 isolation between ports within the same private VLAN. A private VLAN partitions a traditional VLAN into subdomains identified by a primary and secondary VLAN pair.

The FTOS private VLAN implementation is based on RFC 3069.

Private VLAN Concepts

Primary VLAN:

The primary VLAN is the base VLAN and can have multiple secondary VLANs. There are two types of secondary VLAN — community VLAN and isolated VLAN:

- A primary VLAN can have any number of community VLANs and isolated VLANs.
- Private VLANs block all traffic to isolated ports except traffic from promiscuous ports. Traffic received from an isolated port is forwarded only to promiscuous ports or trunk ports.

Community VLAN:

A community VLAN is a secondary VLAN of the primary VLAN:

- Ports in a community VLAN can talk to each other. Also, all ports in a community VLAN can talk to all *promiscuous ports* in the primary VLAN and vice-versa.
- Devices on a community VLAN can communicate with each other via member ports, while devices in an isolated VLAN cannot.

Isolated VLAN:

An isolated VLAN is a secondary VLAN of the primary VLAN:

- Ports in an isolated VLAN cannot talk to each other. Servers would be mostly connected to isolated VLAN ports.
- Isolated ports can talk to promiscuous ports in the primary VLAN, and vice-versa.

Port types:

- Community port: A community port is, by definition, a port that belongs to a community VLAN
 and is allowed to communicate with other ports in the same community VLAN and with
 promiscuous ports.
- **Isolated port:** An *isolated port* is, by definition, a port that, in Layer 2, can only communicate with promiscuous ports that are in the same PVLAN.
- **Promiscuous port:** A *promiscuous port* is, by definition, a port that is allowed to communicate with any other port type.
- Trunk port: A trunk port, by definition, carries VLAN traffic across switches:
- A trunk port in a PVLAN is always tagged.
- Primary or secondary VLAN traffic is carried by the trunk port in tagged mode. The tag on the
 packet helps identify the VLAN to which the packet belongs.
- A trunk port can also belong to a regular VLAN (non-private VLAN).

ip local-proxy-arp

Enable/disable Layer 3 communication between secondary VLANs in a private VLAN.

Syntax [no] ip local-proxy-arp

To disable Layer 3 communication between secondary VLANs in a private VLAN, use the **no ip local-proxy-arp** command in the INTERFACE VLAN mode for the primary VLAN.

To disable Layer 3 communication in a particular secondary VLAN, use the **no ip local-proxy-arp** command in the INTERFACE VLAN mode for the selected secondary VLAN.

Note: Even after **ip-local-proxy-arp** is disabled (**no ip-local-proxy-arp**) in a secondary VLAN, Layer 3 communication may happen between some secondary VLAN hosts, until the ARP timeout happens on those secondary VLAN hosts.

Defaults Layer 3 communication is disabled between secondary VLANs in a private VLAN.

Command Modes INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Related Commands

private-vlan mode	Set the mode of the selected VLAN to community, isolated, or primary.
private-vlan mapping secondary-vlan	Map secondary VLANs to the selected primary VLAN.
show arp	Display the ARP table.
show interfaces private-vlan	Display type and status of PVLAN interfaces.
show vlan private-vlan	Display PVLANs and/or interfaces that are part of a PVLAN.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

private-vlan mode

CS Set the PVLAN mode of the selected VLAN to community, isolated, or primary.

Syntax [no] private-vlan mode {community | isolated | primary}

To remove the PVLAN configuration, use the no private-vlan mode {community | isolated | primary | command syntax.

Parameters

community	Enter community to set the VLAN as a community VLAN, as described above.
isolated	Enter isolated to configure the VLAN as an isolated VLAN, as described above.
primary	Enter primary to configure the VLAN as a primary VLAN, as described above.

Defaults

none

Command Modes

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

The VLAN:

- Can be in only one mode, either community, isolated, or primary.
- Mode can be set to community or isolated even before associating it to a primary VLAN. This secondary VLAN will continue to work normally as a normal VLAN even though it is not associated to a primary VLAN. (A syslog message indicates this.)
- Must not have a port in it when the VLAN mode is being set.

Only ports (and port channels) configured as promiscuous, host, or PVLAN trunk ports (as described above) can be added to the PVLAN. No other regular ports can be added to the PVLAN.

After using this command to configure a VLAN as a primary VLAN, use the private-vlan mapping **secondary-vlan** command to map secondary VLANs to this VLAN.

Related **Commands**

private-vlan mapping secondary-vlan	Set the mode of the selected VLAN to primary and then associate secondary VLANs to it.
show interfaces private-vlan	Display type and status of PVLAN interfaces.

show vlan private-vlan	Display PVLANs and/or interfaces that are part of a PVLAN.
show vlan private-vlan mapping	Display primary-secondary VLAN mapping.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

private-vlan mapping secondary-vlan

Map secondary VLANs to the selected primary VLAN.

Syntax [no] private-vlan mapping secondary-vlan vlan-list

To remove specific secondary VLANs from the configuration, use the **no private-vlan mapping secondary-vlan** *vlan-list* command syntax.

Parameters

vlan-list Enter the list of secondary VLANs to associate with the selected primary VLAN, as described above. The list can be in comma-delimited or hyphenated-range format, following the convention for range input.

Defaults none

Command Modes INTERI

INTERFACE VLAN

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

The list of secondary VLANs can be:

- Specified in comma-delimited or hyphenated-range format.
- Specified with this command even before they have been created.
- Amended by specifying the new secondary VLAN to be added to the list.

Related Commands

private-vlan mode	Set the mode of the selected VLAN to community, isolated, or primary.
show interfaces private-vlan	Display type and status of PVLAN interfaces.
show vlan private-vlan	Display PVLANs and/or interfaces that are part of a PVLAN.
show vlan private-vlan mapping	Display primary-secondary VLAN mapping.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

show interfaces private-vlan

C S Display type and status of PVLAN interfaces.

Syntax show interfaces private-vlan [interface interface]

Parameters

interface interface	(OPTIONAL) Enter the keyword interface , followed by the ID of the specific
	interface for which to display PVLAN status.

Defaults

none

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

This command has two types of display — a list of all PVLAN interfaces or for a specific interface. Examples of both types of output are shown below.

Examples

Figure 29-1. show interfaces private-vlan Command Output

```
FTOS# show interfaces private-vlan
Interface Vlan PVLAN-Type Interface Type Status
       10 Primary Promi
100 Isolated Host
10 Primary Trunk
Gi 2/1
                            Promiscuous
                                              Uр
Gi 2/2
                                              Down
Gi 2/3
                             Trunk
                                              Uр
         101 Community Host
Gi 2/4
                                              Uр
```

```
FTOS# show interfaces private-vlan Gi 2/2
Interface Vlan PVLAN-Type Interface Type Status
Gi 2/2
         100 Isolated Host
                                        Uр
```

The table, below, defines the fields in the output, above.

Table 29-1. show interfaces description Command Example Fields

Field	Description
Interface	Displays type of interface and associated slot and port number
Vlan	Displays the VLAN ID of the designated interface
PVLAN-Type	Displays the type of VLAN in which the designated interface resides
Interface Type	Displays the PVLAN port type of the designated interface.
Status	States whether the interface is operationally up or down.

Related **Commands**

private-vlan mode	Set the mode of the selected VLAN to community, isolated, or primary.
show vlan private-vlan	Display PVLANs and/or interfaces that are part of a PVLAN.
show vlan private-vlan mapping	Display primary-secondary VLAN mapping.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

show vlan private-vlan

Display PVLANs and/or interfaces that are part of a PVLAN.

Syntax

 $\textbf{show vlan private-vlan} \ [\textbf{community} \ | \ \textit{interface} \ | \ \textbf{isolated} \ | \ \textbf{primary} \ | \ \textit{primary} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{interface} \ | \ \textit{inte$

Parameters

community	(OPTIONAL) Enter the keyword community to display VLANs configured as community VLANs, along with their interfaces.	
interface	(OPTIONAL) Enter the keyword community to display VLANs configured as community VLANs, along with their interfaces.	
isolated	(OPTIONAL) Enter the keyword isolated to display VLANs configured as isolated VLANs, along with their interfaces.	
primary	(OPTIONAL) Enter the keyword primary to display VLANs configured as primary VLANs, along with their interfaces.	
primary_vlan	(OPTIONAL) Enter a private VLAN ID or secondary VLAN ID to display interface details about the designated PVLAN.	
interface interface	(OPTIONAL) Enter the keyword interface and an interface ID to display the PVLAN configuration of the designated interface.	

Defaults

none

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

Examples of all types of command output are shown below. The first type of output is the result of not entering an optional keyword. It displays a detailed list of all PVLANs and their member VLANs and interfaces. The other types of output show details about PVLAN subsets.

Examples

Figure 29-2. show vlan private-vlan Command Output

	now vlan pi Secondary		n Active	Ports
10		primary	Yes	Gi 2/1,3
	100	isolated		
	101	community	Yes	Gi 2/10
20		primary	Yes	Po 10, 12-13 Gi 3/1
	200	isolated	Yes	Gi 3/2,4-6
	201	community	No	
	202	community	Yes	Gi 3/11-12
		_		

```
FTOS# show vlan private-vlan isolated
Primary Secondary Type Active Ports
10
          primary Yes Gi 2/1,3
100 isolated Yes Gi 2/2,4-6
200 isolated Yes Gi 3/2,4-6
```

```
FTOS# show vlan private-vlan community
Primary Secondary Type Active Ports
         primary Yes Gi 2/1,3
101 community Yes Gi 2/7-10
primary Yes Po 10, 12-13
10
20
                                         Gi 3/1
         201 community No
202 community Yes Gi 3/11-12
```

```
FTOS# show vlan private-vlan interface Gi 2/1
Primary Secondary Type Active Ports
10
                primary Yes
                              Gi 2/1
```

If the VLAN ID is that of a primary VLAN, then the entire private VLAN output will be displayed, as shown in Figure 29-3. If the VLAN ID is a secondary VLAN, only its primary VLAN and its particular secondary VLAN properties will be displayed, as shown in Figure 29-4.

Figure 29-3. Output of show vlan private-vlan (primary)

```
FTOS# show vlan private-vlan 10
Primary Secondary Type Active Ports
        primary Yes Gi 2/1,3
102 isolated Yes Gi 0/4
101 community Yes Gi 2/7-10
10
```

Figure 29-4. Output of show vlan private-vlan (secondary)

```
FTOS#show vlan private-vlan 102
Primary Secondary Type Active Ports
1.0
        Primary Yes Po 1
       Gi 0/2
102 Isolated Yes Gi 0/4
```

The table, below, defines the fields in the output, above.

Table 29-2. show interfaces description Command Example Fields

Field	Description	
Primary	Displays the VLAN ID of the designated or associated primary VLAN(s)	
Secondary	Displays the VLAN ID of the designated or associated secondary VLAN(s	
Туре	Displays the type of VLAN in which the listed interfaces reside	

Table 29-2. show interfaces description Command Example Fields

Field	Description	
Active	States whether the interface is operationally up or down	
Ports	Displays the interface IDs in the listed VLAN.	

Related Commands

	private-vlan mode	Set the mode of the selected VLAN to either community or isolated.
	show interfaces private-vlan	Display type and status of PVLAN interfaces.
•	show vlan private-vlan mapping	Display primary-secondary VLAN mapping.
	switchport mode private-vlan	Set the PVLAN mode of the selected port.

show vlan private-vlan mapping

C S Display primary-secondary VLAN mapping.

Syntax show vlan private-vlan mapping

Defaults none

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

The output of this command, shown below, displays the community and isolated VLAN IDs that are associated with each primary VLAN.

Figure 29-5. show vlan private-vlan mapping Command Output

```
FTOS# show vlan private-vlan mapping
Private Vlan:
Primary : 100
Isolated : 102
Community : 101
Unknown : 200
```

Related Commands

private-vlan mode	Set the mode of the selected VLAN to either community or isolated.
show interfaces private-vlan	Display type and status of PVLAN interfaces.
show vlan private-vlan mapping	Display primary-secondary VLAN mapping.
switchport mode private-vlan	Set the PVLAN mode of the selected port.

switchport mode private-vlan

Set the PVLAN mode of the selected port.

[no] switchport mode private-vlan {host | promiscuous | trunk} **Syntax**

To remove the PVLAN mode from the selected port, use the **no switchport mode private-vlan** command.

Parameters

host	Enter host to configure the selected port or port channel as an isolated interface in a PVLAN, as described above.	
promiscuous	Enter promiscuous to configure the selected port or port channel as an promiscuous interface, as described above.	
trunk	Enter trunk to configure the selected port or port channel as a trunk port in a PVLAN, as described above.	

Defaults disabled

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Usage Information

The assignment of the various PVLAN port types to port and port channel (LAG) interfaces is demonstrated below.

Example

Figure 29-6. Examples of switchport mode private-vlan Command

```
FTOS#conf
FTOS(conf)#interface GigabitEthernet 2/1
FTOS (conf-if-gi-2/1) #switchport mode private-vlan promiscuous
FTOS(conf)#interface GigabitEthernet 2/2 FTOS(conf-if-gi-2/2)#switchport mode private-vlan host
FTOS(conf)#interface GigabitEthernet 2/3
FTOS(conf-if-gi-2/3)#switchport mode private-vlan trunk
 FTOS (conf) \# interface port-channel 10 \\ FTOS (conf-if-gi-2/3) \# switchport mode private-vlan promiscuous
```

Related Commands

private-vlan mode	Set the mode of the selected VLAN to either community or isolated.
private-vlan mapping secondary-vlan	Set the mode of the selected VLAN to primary and then associate secondary VLANs to it.
show interfaces private-vlan	Display type and status of PVLAN interfaces.
show vlan private-vlan mapping	Display primary-secondary VLAN mapping.

Per-VLAN Spanning Tree plus (PVST+)

Overview

The FTOS implementation of PVST+ (Per-VLAN Spanning Tree plus) is based on the IEEE 802.1d standard Spanning Tree Protocol, but it creates a separate spanning tree for each VLAN configured.

PVST+ (Per-VLAN Spanning Tree plus) is supported by FTOS on all Dell Networking systems, as indicated by the characters that appear below each command heading:

- C-Series: C
- E-Series: E
- S-Series: S

Commands

The FTOS PVST+ commands are:

- disable
- description
- extend system-id
- protocol spanning-tree pvst
- show spanning-tree pvst
- spanning-tree pvst
- spanning-tree pvst err-disable
- tc-flush-standard
- vlan bridge-priority
- vlan forward-delay
- vlan hello-time
- vlan max-age



Note: For easier command line entry, the plus (+) sign is not used at the command line.

disable

CES

Disable PVST+ globally.

Syntax

disable

To enable PVST+, enter no disable.

Defaults PVST+ is disabled

Command Modes CONFIGURATION (conf-pvst)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

protocol spanning-tree pvst Enter PVST+ mode.

description

CES Enter a description of the PVST+

Syntax description { description}

To remove the description, use the **no description** { description} command.

Parameters description Enter a description to identify the Spanning Tree (80 characters maximum).

Defaults No default behavior or values

Command Modes SPANNING TREE PVST+ (The prompt is "config-pvst".)

Command History

Version 8.3.3.1 Introduced on S60
pre-7.7.1.0 Introduced

Related Commands

protocol spanning-tree pvst Enter SPANNING TREE mode on the switch.

extend system-id

Use Extend System ID to augment the Bridge ID with a VLAN ID so that PVST+ differentiate

between BPDUs for each VLAN. If for some reason on VLAN receives a BPDU meant for another

VLAN, PVST+ will then not detect a loop, and both ports can remain in forwarding state.

Syntax extend system-id

Defaults Disabled

Command Modes PROTOCOL PVST

Command History

Version 8.3.3.1 Introduced on S60

Version 8.3.1.0 Introduced

Example

```
FTOS(conf-pvst)#do show spanning-tree pvst vlan 5 brief
```

```
VLAN 5
Executing IEEE compatible Spanning Tree Protocol
Root ID Priority 32773, Address 0001.e832.73f7
Root Bridge hello time 2, max age 20, forward delay 15
Bridge ID Priority 32773 (priority 32768 sys-id-ext 5), Address 0001.e832.73f7
We are the root of Vlan 5
Configured hello time 2, max age 20, forward delay 15
```

Interface Name	PortID	Prio	Cost	Sts	Cost		signated idge ID	:	PortID	
· · · · · · · · · · · · · · · · · · ·	128.140 128.142		200000	FWD DIS	-		001.e832.73 0001.e832			
Interface Name	Role P	ortID	Prio	Cost	Sts	Cost	Link-type	Edge		
Gi 0/10 Gi 0/12	Desg 1	28.140 128.1		20000		0 IS 0	P2P P2P	No	No	

Related Commands

protocol spanning-tree pvst

Enter SPANNING TREE mode on the switch.

protocol spanning-tree pvst

CES Enter the PVST+ mode to enable PVST+ on a device.

Syntax protocol spanning-tree pvst

To disable PVST+, use the disable command.

Defaults This command has no default value or behavior.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Example

Figure 30-1. Configuring with protocol spanning-tree pvst Command

```
FTOS#conf
FTOS(conf) #protocol spanning-tree pvst
FTOS(conf-pvst) #no disable
FTOS (conf-pvst) #vlan 2 bridge-priority 4096
FTOS (conf-pvst) #vlan 3 bridge-priority 16384
FTOS (conf-pvst)#
FTOS(conf-pvst) #show config
protocol spanning-tree pvst
 no disable
 vlan 2 bridge-priority 4096
 vlan 3 bridge-priority 16384
FTOS#
```

Usage Information

Once PVST+ is enabled, the device runs an STP instance for each VLAN it supports.

Related Commands

disable	Disable PVST+.
show spanning-tree pvst	Display the PVST+ configuration.

show spanning-tree pvst © E S View the Per-VLAN Spanning Tree configuration.

Syntax show spanning-tree pvst [vlan vlan-id] [brief] [Interface]

Parameters

vlan vlan-id	(OPTIONAL) Enter the keyword vlan followed by the VLAN ID.
	Range: 1 to 4094
brief	(OPTIONAL) Enter the keyword brief to view a synopsis of the PVST+ configuration information.
Interface	(OPTIONAL) Enter one of the interface keywords along with the slot/port information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.4.1.0	Expanded to display port error disable state (EDS) caused by loopback BPDU inconsistency and Port VLAN ID inconsistency.
Version 6.2.1.1	Introduced

Example 1 Figure 30-2. show spanning-tree pvst brief Command

```
FTOS#show spanning-tree pvst vlan 3 brief
Executing IEEE compatible Spanning Tree Protocol
Root ID Priority 4096, Address 0001.e801.6aa8
Root Bridge hello time 2, max age 20, forward delay 15
Bridge ID Priority 16384, Address 0001.e805.e306
Configured hello time 2, max age 20, forward delay 15
Interface
                                                                                   Designated
                PortID Prio Cost Sts Cost
                                                                                                             Port.ID
 Name
                                                                                Bridge ID
Gi 1/0 128.130 128 20000
Gi 1/1 128.131 128 20000
Gi 1/16 128.146 128 20000
Gi 1/17 128.147 128 20000
                                                      FWD 20000 4096 0001.e801.6aa8 128.426
BLK 20000 4096 0001.e801.6aa8 128.427
FWD 20000 16384 0001.e805.e306 128.146
FWD 20000 16384 0001.e805.e306 128.147
Interface
 Name
                Role PortID Prio Cost Sts Cost Link-type Edge
 -----
Gi 1/0 Root 128.130 128 20000 FWD 20000 P2P
Gi 1/1 Altr 128.131 128 20000 BLK 20000 P2P
Gi 1/16 Desg 128.146 128 20000 FWD 20000 P2P
Gi 1/17 Desg 128.147 128 20000 FWD 20000 P2P
                                                                                                        Nο
                                                                                                         No
                                                                                                         Yes
                                                                                                         Yes
```

Example 2 Figure 30-3. show spanning-tree pvst vlan Command

```
FTOS#show spanning-tree pvst vlan 2
VLAN 2
Root Identifier has priority 4096, Address 0001.e805.e306
Root Edentifier has priority 1000, hadross strained Root Bridge hello time 2, max age 20, forward delay 15 Bridge Identifier has priority 4096, Address 0001.e805.e306
Configured hello time 2, max age 20, forward delay 15
We are the root of VLAN 2
Current root has priority 4096, Address 0001.e805.e306
Number of topology changes 3, last change occured 00:57:00
Port 130 (GigabitEthernet 1/0) is designated Forwarding
Port path cost 20000, Port priority 128, Port Identifier 128.130 Designated root has priority 4096, address 0001.e805.e3:06
Designated bridge has priority 4096, address 0001.e805.e3:06 Designated port id is 128.130, designated path cost 0
Number of transitions to forwarding state 1
BPDU sent 1567, received 3
The port is not in the Edge port mode
Port 131 (GigabitEthernet 1/1) is designated Forwarding
Port path cost 20000, Port priority 128, Port Identifier 128.131
Designated root has priority 4096, address 0001.e805.e3:06
Designated bridge has priority 4096, address 0001.e805.e3:06
Designated port id is 128.131, designated path cost 0
Number of transitions to forwarding state 1
BPDU sent 1567, received 0
The port is not in the Edge port mode
Port 146 (GigabitEthernet 1/16) is designated Forwarding
Port path cost 20000, Port priority 128, Port Identifier 128.146 Designated root has priority 4096, address 0001.e805.e3:06
Designated bridge has priority 4096, address 0001.e805.e3:06
Designated port id is 128.146, designated path cost 0
Number of transitions to forwarding state 1
BPDU sent 1578, received 0
The port is in the Edge port mode
Port 147 (GigabitEthernet 1/17) is designated Forwarding
Port path cost 20000, Port priority 128, Port Identifier 128.147 Designated root has priority 4096, address 0001.e805.e3:06
Designated bridge has priority 4096, address 0001.e805.e3:06
Designated port id is 128.147, designated path cost 0
Number of transitions to forwarding state 1 BPDU sent 1579, received 0
The port is in the Edge port mode
```

Example 3 Figure 30-4. show spanning-tree pvst command with EDS and LBK

FTOS#show spanning-tree pvst vlan 2 interface gigabitethernet 1/0 Loopback BPDU GigabitEthernet 1/0 of VLAN 2 is LBK INC discarding Inconsistency Edge port:no (default) port guard :none (default) (LBK_INC) Link type: point-to-point (auto) bpdu filter:disable (default) Bpdu guard : disable (default) Bpdus sent 152, received 27562 Interface Designated Bridge ID PortID Prio Cost Sts Cost 128.1223 128 20000 EDS 0 32768 0001.e800.a12b 128.1223 Gi 1/0

Example 4 Figure 30-5. show spanning-tree pvst with EDS and PVID

FTOS#show spanning-tree pvst vlan 2 interface gigabitethernet 1/0

GigabitEthernet 1/0 of VLAN 2 is PVID_INC discarding

Edge port:no (default) port guard :none (default)

Link type: point-to-point (auto) bpdu filter:disable (default)

Bpdu guard :disable (default)

Bpdus sent 1, received 0

Interface

Name

PortID

PortID

PortID

Gi 1/0 128.1223 128 20000 EDS 0 32768 0001.e800.a12b 128.1223

Related Commands

spanning-tree pvst Configure PVST+ on an interface.

spanning-tree pvst



Configure PVST+ edge port with optional Bridge Port Data Unit (BPDU) guard, VLAN, port priority, and port cost on an interface.

Syntax

spanning-tree pvst [edge-port [bpduguard [shutdown-on-violation]] | vlan vlan-range {cost number | priority value}]

To disable PVST+ on an interface, use the **no spanning-tree pvst [edge-port [bpduguard]** [shutdown-on-violation]] | vlan vlan-range {cost number | priority value}] command.

Parameters

edge-port	(OPTIONAL) Enter the keyword edge-port to configure the interface as a PVST+ edge port.
bpduguard	(OPTIONAL) Enter the keyword portfast to enable Portfast to move the interface into forwarding mode immediately after the root fails. Enter the keyword bpduguard to disable the port when it receives a BPDU.
shutdown-on-v iolation	(OPTIONAL) Enter the keyword shutdown-on-violation to hardware disable an interface when a BPDU is received and the port is disabled.
vlan vlan-range	(OPTIONAL) Enter the keyword vian followed by the VLAN number(s). Range: 1 to 4094

cost number	(OPTIONAL) Enter the keyword cost followed by the port cost value.
	Range: 1 to 200000
	Defaults:
	100 Mb/s Ethernet interface = 200000
	1-Gigabit Ethernet interface = 20000
	10-Gigabit Ethernet interface = 2000
	Port Channel interface with one 100 Mb/s Ethernet = 200000
	Port Channel interface with one 1-Gigabit Ethernet = 20000
	Port Channel interface with one 10-Gigabit Ethernet = 2000
	Port Channel with two 1-Gigabit Ethernet = 18000
	Port Channel with two 10-Gigabit Ethernet = 1800
	Port Channel with two 100-Mbps Ethernet = 180000
priority value	(OPTIONAL) Enter the keyword priority followed the Port priority value in
	increments of 16.
	Range: 0 to 240
	Default: 128

Defaults

Not Configured

Command Modes

INTERFACE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced hardware shutdown-on-violation option
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added the optional Bridge Port Data Unit (BPDU) guard
Version 6.2.1.1	Introduced

Usage Information

The BPDU guard option prevents the port from participating in an active STP topology in case a BPDU appears on a port unintentionally, or is misconfigured, or is subject to a DOS attack. This option places the port into an error disable state if a BPDU appears, and a message is logged so that the administrator can take corrective action.



Note: A port configured as an edge port, on a PVST switch, will immediately transition to the forwarding state. Only ports connected to end-hosts should be configured as an edge port. Consider an edge port similar to a port with a spanning-tree portfast enabled.

If **shutdown-on-violation** is not enabled, BPDUs will still be sent to the RPM CPU.

Example

Figure 30-6. spanning-tree pvst vlan Command Example

```
FTOS(conf-if-gi-1/1)#spanning-tree pvst vlan 3 cost 18000
FTOS (conf-if-gi-1/1) #end
FTOS(conf-if-gi-1/1) #show config
interface GigabitEthernet 1/1
no ip address
switchport
spanning-tree pvst vlan 3 cost 18000
no shutdown
FTOS (conf-if-gi-1/1) #end
FTOS#
```

Related Commands

show spanning-tree pvst

View PVST+ configuration

spanning-tree pvst err-disable

CES

Place ports in an err-disabled state if they receive a PVST+ BPDU when they are members an untagged VLAN.

Syntax spanning-tree pvst err-disable cause invalid-pvst-bpdu

Defaults Enabled; ports are placed in err-disabled state if they receive a PVST+ BPDU when they are members of an untagged VLAN.

Command Modes INTERFACE

Command History

Version 8.3.3.1 Introduced on S60

Version 8.2.1.0 Introduced

Usage Information Some non-Dell Networking systems which have hybrid ports participating in PVST+ transmit two kinds of BPDUs: an 802.1D BPDU and an untagged PVST+ BPDU.

Dell Networking systems do not expect PVST+ BPDU on an untagged port. If this happens, FTOS places the port in error-disable state. This behavior might result in the network not converging. To prevent FTOS from executing this action, use the command **no spanning-tree pvst err-disable cause invalid-pvst-bpdu**.

Related Commands

show spanning-tree pvst View the PVST+ configuration.

tc-flush-standard

CES

Enable the MAC address flushing upon receiving every topology change notification.

Syntax tc-flush-standard

To disable, use the **no tc-flush-standard** command.

Defaults Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.5.1.0	Introduced

Usage Information By default FTOS implements an optimized flush mechanism for PVST+. This helps in flushing the MAC addresses only when necessary (and less often) allowing for faster convergence during topology changes. However, if a standards-based flush mechanism is needed, this *knob* command can be turned on to enable flushing MAC addresses upon receiving every topology change notification.

vlan bridge-priority

Set the PVST+ bridge-priority for a VLAN or a set of VLANs.

Syntax vlan vlan-range bridge-priority value

To return to the default value, enter **no vlan bridge-priority** command.

Parameters

vlan vlan-range	Enter the keyword vlan followed by the VLAN number(s). Range: 1 to 4094	
bridge-priority value	Enter the keyword bridge-priority followed by the bridge priority value in increments of 4096.	
	Range: 0 to 61440	
	Default: 32768	

Defaults 32768

Command Modes CONFIGURATION (conf-pvst)

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Related **Commands**

vlan forward-delay	Change the time interval before FTOS transitions to the forwarding state
vlan hello-time	Change the time interval between BPDUs
vlan max-age	Change the time interval before PVST+ refreshes
show spanning-tree pvst	Display the PVST+ configuration

vlan forward-delay

CES

Set the amount of time the interface waits in the Listening State and the Learning State before transitioning to the Forwarding State.

Syntax vlan vlan-range forward-delay seconds

To return to the default setting, enter **no vlan forward-delay** command.

Parameters

vlan vlan-range	Enter the keyword vian followed by the VLAN number(s). Range: 1 to 4094
forward-delay seconds	Enter the keyword forward-delay followed by the time interval, in seconds, that FTOS waits before transitioning PVST+ to the forwarding state.
	Range: 4 to 30 seconds Default: 15 seconds

Defaults 15 seconds

Command Modes CONFIGUR

CONFIGURATION (conf-pvst)

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
Version 6.2.1.1	Introduced	

Related Commands

vlan bridge-priority	Set the bridge-priority value
vlan hello-time	Change the time interval between BPDUs
vlan max-age	Change the time interval before PVST+ refreshes
show spanning-tree pvst	Display the PVST+ configuration

vlan hello-time

CES Se

Set the time interval between generation of PVST+ Bridge Protocol Data Units (BPDUs).

Syntax vlan vlan-range hello-time seconds

To return to the default value, enter **no vlan hello-time** command.

Parameters

vlan vlan-range	Enter the keyword vlan followed by the VLAN number(s). Range: 1 to 4094
hello-time seconds	Enter the keyword hello-time followed by the time interval, in seconds, between transmission of BPDUs.
	Range: 1 to 10 seconds Default: 2 seconds

Defaults

2 seconds

Command Modes

CONFIGURATION (conf-pvst)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Related Commands

vlan bridge-priority	Set the bridge-priority value
vlan forward-delay	Change the time interval before FTOS transitions to the forwarding state
vlan max-age	Change the time interval before PVST+ refreshes
show spanning-tree pvst	Display the PVST+ configuration

vlan max-age

CES

Set the time interval for the PVST+ bridge to maintain configuration information before refreshing that information.

Syntax

vlan vlan-range max-age seconds

To return to the default, use the **no vlan max-age** command.

Parameters

vlan vlan-range	Enter the keyword vlan followed by the VLAN number(s). Range: 1 to 4094
max-age seconds	Enter the keyword max-age followed by the time interval, in seconds, that FTOS waits before refreshing configuration information. Range: 6 to 40 seconds Default: 20 seconds

Defaults

20 seconds

Command Modes

CONFIGURATION (conf-pvst)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced

Related **Commands**

vlan bridge-priority Set the bridge-priority value	
vlan forward-delay	Change the time interval before FTOS transitions to the forwarding state
vlan hello-time	Change the time interval between BPDUs
show spanning-tree pvst	Display the PVST+ configuration

Quality of Service (QoS)

Overview

FTOS commands for Quality of Service (QoS) include traffic conditioning and congestion control. QoS commands are not universally supported on all Dell Networking platforms. Support is indicated by the C, E and S characters under command headings.

This chapter contains the following sections:

- **Global Configuration Commands**
- Per-Port QoS Commands
- Policy-Based QoS Commands
- Queue-Level Debugging (E-Series Only)

Global Configuration Commands

- qos-rate-adjust
- qos-scheduling

qos-rate-adjust



By default, while rate limiting, policing, and shaping, FTOS does not include the Preamble, SFD, or the IFG fields. These fields are overhead; only the fields from MAC Destination Address to the CRC are used for forwarding and are included in these rate metering calculations. You can optionally include overhead fields in rate metering calculations by enabling QoS Rate Adjustment.

Syntax	qos-rate-adju	ustment	overhead-byte.	S
--------	---------------	---------	----------------	---

overhead-bytes	Include a specified number of bytes of packet overhead to include in rate limiting, policing, and shaping calculations.
	C-Series and S-Series Range: 1-31
	E-Series Range: 1-144

Defaults QoS Rate Adjustment is disabled by default, and **no qos-rate-adjust** is listed in the

running-configuration

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced

qos-scheduling



Configure QoS scheduling priority by setting the scheduled interval for unicast and multicast packets.

Syntax

qos-scheduling [unicast packet-number || multicast packet-number]

Parameters

unicast	Enter the keyword unicast for unicast packet scheduling.		
multicast	Enter the keyword multicast for multicast packet scheduling.		
packet-number	Enter the number of consecutive packets to schedule.		
	Range: 1 to 63.		
	Default: 1.		

Defaults

1

Command Modes

CONFIGURATION

Command History

Version 8.3.3.9 Introduced on the S60.

Per-Port QoS Commands

Per-port QoS ("port-based QoS") allows users to defined QoS configuration on a per-physical-port basis. The commands include:

- dot1p-priority
- rate limit
- rate police
- rate shape
- service-class dynamic dot1p
- show interfaces rate
- · strict-priority queue

dot1p-priority

Assign a value to the IEEE 802.1p bits on the traffic received by this interface.

Syntax

dot1p-priority priority-value

To delete the IEEE 802.1p configuration on the interface, enter **no dot1p-priority**.

3

Parameters

priority-value	Enter a v	alue from 0 to 7.
	dot1p	Queue Number
	0	2
	1	0
	2	1
	3	3
	4	4
	5	5
	6	6
	7	7
	For the (C-Series and S-Series,
	dot1p	Queue Number
	0	1
	1	0
	2	0
	3	1
	4	2
	5	2
	6	3

Defaults

No default behavior or values

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

The dot1p-priority command changes the priority of incoming traffic on the interface. The system places traffic marked with a priority in the correct queue and processes that traffic according to its queue.

When you set the priority for a Port Channel, the physical interfaces assigned to the Port Channel are configured with the same value. You cannot assign dot1p-priority command to individual interfaces in a Port Channel.

rate limit

 \mathbb{E}

Limit the outgoing traffic rate on the selected interface.

Syntax

rate limit [kbps] committed-rate [burst-KB] [peak [kbps] peak-rate [burst-KB]] [vlan vlan-id]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On the E-Series, Dell Networking recommends using a value greater than or equal to 512 as lower values does not yield accurate results. The default granularity is Megabits per second (Mbps).
	Range: 0-10000000
committed-rate	Enter the bandwidth in Mbps
	Range: 0 to 10000
burst-KB	(OPTIONAL) Enter the burst size in KB.
	Range: 16 to 200000
	Default: 50
peak peak-rate	(OPTIONAL) Enter the keyword peak followed by a number to specify the peak rate in Mbps.
	Range: 0 to 10000
vlan vlan-id	(OPTIONAL) Enter the keyword vian followed by a VLAN ID to limit traffic to those specific VLANs.
	Range: 1 to 4094

Defaults

Granularity for *committed-rate* and *peak-rate* is Mbps unless the **kbps** option is used.

Command Modes

INTERFACE

Command History

Version 8.2.1.0	Added kbps option on E-Series.
Version 7.7.1.0	Removed from C-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information



Note: Per Port rate limit and rate police is supported for Layer 2 tagged and untagged switched traffic and for Layer 3 traffic. Per VLAN rate limit and rate police is supported on only tagged ports with Layer 2 switched traffic.

On one interface, you can configure the rate limit or rate police command for a VLAN or you can configure the rate limit or the rate police command for the interface. For each physical interface, you can configure six rate limit commands specifying different VLANS.

If you receive the error message:

%Error: Specified VLANs overlap with existing config.

after configuring VLANs in the rate police command, check to see if the same VLANs are used in rate limit command on other interfaces. To clear the problem, remove the rate limit configuration(s), and re-configure the rate police command. After the rate police command is configured, return to the other interfaces and re-apply the rate limit configuration.

rate police

CES

Police the incoming traffic rate on the selected interface.

Syntax

rate police [kbps] committed-rate [burst-KB] [peak [kbps] peak-rate [burst-KB]] [vlan vlan-id]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On C-Series and S-Series make the following value a multiple of 64. On the E-Series, Dell Networking recommends using a value greater than or equal to 512 as lower values does not yield accurate results. The default granularity is Megabits per second (Mbps). Range: 0-10000000
committed-rate	Enter a number as the bandwidth in Mbps. Range: 0 to 10000
burst-KB	(OPTIONAL) Enter a number as the burst size in KB. Range: 16 to 200000 Default: 50
peak peak-rate	(OPTIONAL) Enter the keyword peak followed by a number to specify the peak rate in Mbps. Range: 0 to 10000
vlan vlan-id	(OPTIONAL) Enter the keyword vlan followed by a VLAN ID to police traffic to those specific VLANs. Range: 1 to 4094

Defaults

Granularity for *committed-rate* and *peak-rate* is Mbps unless the **kbps** option is used.

Command Mode

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Added kbps option on C-Series, E-Series, and Series.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information



Note: Per Port rate limit and rate police is supported for Layer 2 tagged and untagged switched traffic and for Layer 3 traffic. Per VLAN rate limit and rate police is supported on only tagged ports with Layer 2 switched traffic.

C-Series and S-Series

On one interface, you can configure the rate police command for a VLAN or you can configure the rate police command for an interface. For each physical interface, you can configure three rate police commands specifying different VLANS.

E-Series

On *one* interface, you can configure the **rate limit** or rate police command for a VLAN or you can configure the **rate limit** or the rate police command for the interface.

For each physical interface, you can configure six rate police commands specifying different VLANS.

After configuring VLANs in the rate police command, if this error message appears:

%Error: Specified VLANs overlap with existing config.

Check to see if the same VLANs are used with the **rate limit** command on other interfaces. To clear the problem, remove the **rate limit** configuration(s), and re-configure the **rate police** command. After the **rate police** command is configured, return to the other interfaces and re-apply the **rate limit** configuration.

Related Commands

rate-police Police traffic output as part of the designated policy.

rate shape

CES

Shape the traffic output on the selected interface.

Syntax

rate shape [kbps] rate [burst-KB]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On C-Series and S-Series make the following value a multiple of 64. The default granularity is Megabits per second (Mbps).	
rate	Range: 0-10000000 Enter the outgoing rate in multiples of 10 Mbps.	
Tale	Range: 0 to 10000	
burst-KB	(OPTIONAL) Enter a number as the burst size in KB.	
	Range: 0 to 10000	
	Default: 10	

Defaults

Granularity for *rate* is Mbps unless the **kbps** option is used.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Added kbps option on C-Series, E-Series, and Series.
Version 7.6.1.0	Introduced on S-Series and on C-Series
pre-Version 6.1.1.1	Introduced on E-Series
rate-shape	Shape traffic output as part of the designated policy.

Related Commands

service-class dynamic dot1p

CES

Honor all 802.1p markings on incoming switched traffic on an interface (from INTERFACE mode) or on all interfaces (from CONFIGURATION mode). A CONFIGURATION mode entry supercedes INTERFACE mode entries.

Syntax

service-class dynamic dot1p

To return to the default setting, enter **no service-class dynamic dot1p**.

Defaults

All dot1p traffic is mapped to Queue 0 unless **service-class dynamic dot1p** is enabled. Then the default mapping is as follows:

Table 31-1. Default dot1p to Queue Mapping

dot1p	E-Series Queue ID	C-Series Queue ID	S-Series Queue ID
0	2	1	1
1	0	0	0
2	1	0	0
3	3	1	1
4	4	2	2
5	5	2	2
6	6	3	3
7	7	3	3

Command Modes

INTERFACE

CONFIGURATION (C-Series and S-Series only)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Available globally on the C-Series and S-Series so that the configuration applies to all ports.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.5.1.0	Expanded command to permit configuration on port channels
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Enter this command to honor all incoming 802.1p markings, on incoming switched traffic, on the interface. By default, this facility is not enabled (that is, the 802.1p markings on incoming traffic are not honored).

This command can be applied on both physical interfaces and port channels. When you set the service-class dynamic for a port channel, the physical interfaces assigned to the port channel are automatically configured; you cannot assign the service-class dynamic command to individual interfaces in a port channel.

On the C-Series and S-Series all traffic is by default mapped to the same queue, Queue 0. If you honor dot1p on ingress, then you can create service classes based the queueing strategy using the command **service-class dynamic dot1p** from INTERFACE mode. You may apply this queuing strategy to all interfaces by entering this command from CONFIGURATION mode.

- All dot1p traffic is mapped to Queue 0 unless service-class dynamic dot1p is enabled on an interface or globally.
- Layer 2 or Layer 3 service policies supercede dot1p service classes.

service-class bandwidth-weight

Specify a minimum bandwidth for queues

Syntax service-class bandwidth-weight queue0 number queue1 number queue2 number queue3

number

Parameters

number	Enter the bandwidth-weight. The value must be a power of 2.
	Range 1-1024.

Defaults None

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on C-Series and S-Series.

Usage Information

Guarantee a minimum bandwidth to different queues globally using the command **service-class bandwidth-weight** from CONFIGURATION mode. The command is applied in the same way as the bandwidth-weight command in an output QoS policy. The **bandwidth-weight** command in QOS-POLICY-OUT mode supercedes the **service-class bandwidth-weight command**.

show interfaces rate

E Display information of either rate limiting or rate policing on the interface.

Syntax show interfaces [interface] rate [limit | police]

Parameters

interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	 For a 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
limit	(OPTIONAL) Enter the keyword limit to view the outgoing traffic rate.
police	(OPTIONAL) Enter the keyword police to view the incoming traffic rate.

Command Mode

EXEC

EXEC Privilege

Command History

pre-Version 6.1.1.1 Introduced on E-Series

Example

Figure 31-1. show interfaces rate limit Command Example

```
FTOS#show interfaces gigabitEthernet 1/1 rate limit
 Rate limit 300 (50) peak 800 (50)
   Traffic Monitor 0: normal 300 (50) peak 800 (50)
     Out of profile yellow 23386960 red 320605113
   Traffic Monitor 1: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 2: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 3: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 4: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 5: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 6: normal NA peak NA
     Out of profile yellow 0 red 0
   Traffic Monitor 7: normal NA peak NA
     Out of profile yellow 0 red 0
   Total: yellow 23386960 red 320605113
```

Table 31-2. show interfaces Command Example Fields

Field	Description
Rate limit	Committed rate (Mbs) and burst size (KB) of the committed rate
peak	Peak rate (Mbs) and burst size (KB) of the peak rate
Traffic monitor 0	Traffic coming to class 0
Normal	Committed rate (Mbs) and burst size (KB) of the committed rate
peak	Peak rate (Mbs) and burst size (KB) of the peak rate
Out of profile Yellow	Number of packets that have exceeded the configured committed rate
Out of profile Red	Number of packets that have exceeded the configured peak rate
Traffic monitor 1	Traffic coming to class 1
Traffic monitor 2	Traffic coming to class 2
Traffic monitor 3	Traffic coming to class 3
Traffic monitor 4	Traffic coming to class 4
Traffic monitor 5	Traffic coming to class 5
Traffic monitor 6	Traffic coming to class 6
Traffic monitor 7	Traffic coming to class 7
Total: yellow	Total number of packets that have exceeded the configured committed rate
Total: red	Total number of packets that have exceeded the configured peak rate

Figure 31-2. show interfaces rate police Command Example

```
FTOS#show interfaces gigabitEthernet 1/2 rate police
Rate police 300 (50) peak 800 (50)

Traffic Monitor 0: normal 300 (50) peak 800 (50)

Out of profile yellow 23386960 red 320605113

Traffic Monitor 1: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 2: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 3: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 4: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 5: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 6: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 7: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 7: normal NA peak NA

Out of profile yellow 0 red 0

Traffic Monitor 7: normal NA peak NA

Out of profile yellow 0 red 0

Total: yellow 23386960 red 320605113
```

Table 31-3. show interfaces police Command Example Fields

Field	Description
Rate police	Committed rate (Mbs) and burst size (KB) of the committed rate
peak	Peak rate (Mbs) and burst size (KB) of the peak rate
Traffic monitor 0	Traffic coming to class 0
Normal	Committed rate (Mbs) and burst size (KB) of the committed rate
peak	Peak rate (Mbs) and burst size (KB) of the peak rate
Out of profile Yellow	Number of packets that have exceeded the configured committed rate
Out of profile Red	Number of packets that have exceeded the configured peak rate
Traffic monitor 1	Traffic coming to class 1
Traffic monitor 2	Traffic coming to class 2
Traffic monitor 3	Traffic coming to class 3
Traffic monitor 4	Traffic coming to class 4
Traffic monitor 5	Traffic coming to class 5
Traffic monitor 6	Traffic coming to class 6
Traffic monitor 7	Traffic coming to class 7
Total: yellow	Total number of packets that have exceeded the configured committed rate
Total: red	Total number of packets that have exceeded the configured peak rate

strict-priority queue

CES Configure a unicast queue as a strict-priority (SP) queue.

Syntax strict-priority queue unicast queue number

Parameters

unicast queue number	Enter the keywords unicast queue followed by the queue number.
	C-Series and S-Series Range: 1 to 3
	E-Series Range: 1 to 7

Defaults No default behavior or value

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Once a unicast queue is configured as strict-priority, that particular queue, on the entire chassis, is treated as strict-priority queue. Traffic for a strict priority is scheduled before any other queues are serviced. For example, if you send 100% line rate traffic over the SP queue, it will starve all other queues on the ports on which this traffic is flowing.

Policy-Based QoS Commands

Policy-based traffic classification is handled with class maps. These maps classify unicast traffic into one of eight classes in E-Series and one of four classes in C-Series and S-Series. FTOS enables you to match multiple class maps and specify multiple match criteria. Policy-based QoS is not supported on logical interfaces, such as port-channels, VLANS, or loopbacks. The commands are:

- bandwidth-percentage
- bandwidth-weight
- class-map
- clear qos statistics
- description
- match ip access-group
- match ip dscp
- match ip precedence
- match mac access-group
- match mac dot1p
- match mac vlan
- policy-aggregate
- policy-map-input
- policy-map-output
- qos-policy-input
- qos-policy-output
- queue backplane ignore-backpressure
- queue egress
- queue ingress
- rate-limit
- rate-police
- rate-shape
- service-policy input
- service-policy output
- service-queue

- set
- show cam layer2-qos
- show cam layer3-qos
- show qos class-map
- show qos policy-map
- show qos policy-map-input
- show qos policy-map-output
- show qos qos-policy-input
- show qos qos-policy-output
- show qos statistics
- show gos wred-profile
- test cam-usage
- threshold
- trust
- wred
- wred-profile

bandwidth-percentage





Assign a percentage of weight to class/queue.

Syntax

bandwidth-percentage percentage

To remove the bandwidth percentage, use the **no bandwidth-percentage** command.

Parameters

percentage	Enter the percentage assignment of weight to class/queue.
	Range: 0 to 100% (granularity 1%)

Defaults

No default behavior or values

Command Modes

CONFIGURATION (conf-qos-policy-out)

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 6.2.1.1	Introduced on E-Series	

Usage Information

The unit of bandwidth percentage is 1%. A bandwidth percentage of 0 is allowed and will disable the scheduling of that class. If the sum of the bandwidth percentages given to all eight classes exceeds 100%, the bandwidth percentage will automatically scale down to 100%.

Related Commands

|--|

bandwidth-weight

Assign a priority weight to a queue.

Syntax bandwidth-weight weight

To remove the bandwidth weight, use the **no bandwidth-weight** command.

Parameters

weight	Enter the weight assignment to queue.
	Range: 1 to 1024 (in increments of powers of 2: 2, 4, 8, 16, 32, 64, 128, 256, 512, or 1024)

Defaults No default behavior or values

Command Modes CONFIGURATION (conf-qos-policy-out)

> Command History

Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series

Usage Information This command is not supported on the S60.

This command provides a minimum bandwidth guarantee to traffic flows in a particular queue. The minimum bandwidth is provided by scheduling packets from that queue a certain number of times relative to scheduling packets from the other queues using the Deficit Round Robin method.

Related Commands

qos-policy-output Create a QoS output policy.

class-map

CES

Create/access a class map. Class maps differentiate traffic so that you can apply separate quality of service policies to each class.

Syntax class-map {match-all | match-any} class-map-name [layer2]

Parameters

match-all	Determines how packets are evaluated when multiple match criteria exist. Enter the keyword match-all to determine that the packets must meet all the match criteria in order to be considered a member of the class.
match-any	Determines how packets are evaluated when multiple match criteria exist. Enter the keyword match-any to determine that the packets must meet at least one of the match criteria in order to be considered a member of the class.
class-map-name	Enter a name of the class for the class map in a character format (32 character maximum).
layer2	Enter the keyword layer2 to specify a Layer 2 Class Map. Default: Layer 3

Defaults Layer 3

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Class-map names can be 32 characters. layer2 available on C-Series and S-Series.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Expanded to add support for Layer 2

Usage Information

Packets arriving at the input interface are checked against the match criteria, configured using this command, to determine if the packet belongs to that class. This command accesses the CLASS-MAP mode, where the configuration commands include **match ip** and **match mac** options.

Related Commands

ip access-list extended	Configure an extended IP ACL.
ip access-list standard	Configure a standard IP ACL.
match ip access-group	Configure the match criteria based on the access control list (ACL)
match ip precedence	Identify IP precedence values as match criteria
match ip dscp	Configure the match criteria based on the DSCP value
match mac access-group	Configure a match criterion for a class map, based on the contents of the designated MAC ACL.
match mac dot1p	Configure a match criterion for a class map, based on a dot1p value.
match mac vlan	Configure a match criterion for a class map based on VLAN ID.
service-queue	Assign a class map and QoS policy to different queues.
show qos class-map	View the current class map information.

clear qos statistics

CES

Clears Matched Packets, Matched Bytes, and Dropped Packets. For TeraScale, clears Matched Packets, Matched Bytes, Queued Packets, Queued Bytes, and Dropped Packets.

Syntax

clear qos statistics interface-name.

Parameters

interface-name	Enter one of the following keywords:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

E-Series Only Behavior

If a Policy QoS is applied on an interface when clear qos statistics is issued, it will clear the egress counters in **show queue statistics** and vice versa. This behavior is due to the values being read from the same hardware registers.

The **clear qos statistics** command clears both the queued and matched byte and packet counters if the queued counters incremented based on classification of packets to the queues because of policy-based QoS. If the queued counters were incremented because of some other reason and do not reflect a matching QoS entry in CAM, then this command clears the matched byte and packet counters only.

Related Commands

show qos statistics Display qos statistics.

match ip access-group

CES

Configure match criteria for a class map, based on the access control list (ACL).

Syntax

match ip access-group access-group-name [set-ip-dscp value]

To remove ACL match criteria from a class map, enter **no match ip access-group** access-group-name [set-ip-dscp value] command.

Parameters

access-group-name	Enter the ACL name whose contents are used as the match criteria in determining if packets belong to the class specified by class-map .
set-ip-dscp value	(OPTIONAL) Enter the keyword set-ip-dscp followed by the IP DSCP value. The matched traffic will be marked with the DSCP value. Range: 0 to 63

Defaults

No default behavior or values

Command Modes

CLASS-MAP CONFIGURATION (config-class-map)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Added DSCP Marking option support on S-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.5.1.0	Added support for DSCP Marking option
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

You must enter the **class-map** command in order to access this command. Once the class map is identified, you can configure the match criteria. For class-map match-any, a maximum of five ACL match criteria are allowed. For **class-map match-all**, only one ACL match criteria is allowed.

Related **Commands**

class-map Identify the class map.

description

CES

Add a description to the selected policy map or QOS policy.

Syntax

description { description}

To remove the description, use the **no description** { description} command.

Parameters

description Enter a description to identify the policies (80 characters maximum).

Defaults

No default behavior or values

Command Modes

CONFIGURATION (policy-map-input and policy-map-output; conf-qos-policy-in and conf-qos-policy-out; wred)

Command History

Version 8.3.3.1	Introduced on S60
pre-Version 7.7.1.0	Introduced

Related Commands

policy-map-input	Create an input policy map.
policy-map-output	Create an output policy map.
qos-policy-input	Create an input QOS-policy on the router.
qos-policy-output	Create an output QOS-policy on the router.
wred-profile	Create a WRED profile.

match ip dscp

CES

Use a DSCP (Differentiated Services Code Point) value as a match criteria.

Syntax

match ip dscp dscp-list [[multicast] set-ip-dscp value]

To remove a DSCP value as a match criteria, enter **no match ip dscp** *dscp-list* [[multicast] set-ip-dscp *value*] command.

Parameters

dscp-list	Enter the IP DSCP value(s) that is to be the match criteria. Separate values by commas—no spaces (1,2,3) or indicate a list of values separated by a hyphen (1-3). Range: 0 to 63
multicast	(OPTIONAL) Enter the keyword multicast to match against multicast traffic. Note : This option is not supported on C-Series or S-Series.
set-ip-dscp value	(OPTIONAL) Enter the keyword set-ip-dscp followed by the IP DSCP value. The matched traffic will be marked with the DSCP value. Range: 0 to 63 Note : This option is not supported on S-Series.

Defaults

No default behavior or values

Command Modes

CLASS-MAP CONFIGURATION (config-class-map)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Added keyword multicast . Added DSCP Marking option support on S-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series Added support for DSCP Marking option
Version 6.2.1.1	Introduced on E-Series

Usage Information

You must enter the **class-map** command in order to access this command. Once the class map is identified, you can configure the match criteria.

The match ip dscp and match ip precedence commands are mutually exclusive.

Up to 64 IP DSCP values can be matched in one match statement. For example, to indicate IP DCSP values 0 1 2 3 4 5 6 7, enter either the command match ip dscp 0,1,2,3,4,5,6,7 or match ip dscp 0-7.



Note: Only one of the IP DSCP values must be a successful match criterion, not all of the specified IP DSCP values need to match.

Related **Commands**

class-map	Identify the class map.	

match ip precedence



Use IP precedence values as a match criteria.

Syntax

match ip precedence ip-precedence-list [[multicast] set-ip-dscp value]

To remove IP precedence as a match criteria, enter no match ip precedence ip-precedence-list [[multicast] set-ip-dscp value] command.

Parameters

ip-precedence-list	Enter the IP precedence value(s) as the match criteria. Separate values by commas—no spaces (1,2,3) or indicate a list of values separated by a hyphen (1-3). Range: 0 to 7
multicast	(OPTIONAL) Enter the keyword multicast to match against multicast traffic. Note: This option is not supported on C-Series or S-Series.
set-ip-dscp value	(OPTIONAL) Enter the keyword set-ip-dscp followed by the IP DSCP value. The matched traffic will be marked with the DSCP value. Range: 0 to 63 Note : This option is not supported on S-Series.

Defaults

No default behavior or values

Command Modes

CLASS-MAP CONFIGURATION (conf-class-map)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Added keyword multicast . Added DSCP marking option support for S-Series
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series Added support for DSCP Marking option
Version 6.2.1.1	Introduced on E-Series

Usage Information

You must enter the **class-map** command in order to access this command. Once the class map is identified, you can configure the match criteria.

The **match ip precedence** command and the **match ip dscp** command are mutually exclusive.

Up to eight precedence values can be matched in one match statement. For example, to indicate the IP precedence values 0 1 2 3 enter either the command **match ip precedence 0-3** or **match ip precedence 0,1,2,3**.



Note: Only one of the IP precedence values must be a successful match criterion, not all of the specified IP precedence values need to match.

Related Commands

class-map	Identify the class map.	
	J 1	

match mac access-group

CES

Configure a match criterion for a class map, based on the contents of the designated MAC ACL.

Syntax match mac access-group {mac-acl-name}

Parameters

mac-acl-name Enter a MAC ACL name. Its contents will be used as the match criteria in the class map.

Defaults No default values or behavior

Command Modes CLASS-MAP

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Available on the C-Series and S-Series.
Version 7.5.1.0	Added support for DSCP Marking option
Version 7.4.1.0	Introduced

Usage Information

You must enter the **class-map** command in order to access this command. Once the class map is identified, you can configure the match criteria.

Related Commands

•	T1 (10 d 1
class-map	Identify the class map.
Class map	rachtify the class map.

match mac dot1p

CES Configure a match criterion for a class map, based on a dot1p value.

Syntax match mac dot1p { dot1p-list}

Parameters dot1p-list Enter a dot1p value.

Range: 0-7

Defaults No default values or behavior

Command Modes CLASS-MAP

> Command History

Version 8.3.3.1 Introduced on S60 Version 8.2.1.0 Available on the C-Series and S-Series. Version 7.5.1.0 Added support for DSCP Marking option Version 7.4.1.0 Introduced

Usage You must enter the **class-map** command in order to access this command. Once the class map is Information identified, you can configure the match criteria.

Identify the class map.

Related

class-map

match mac vlan

Commands

Configure a match criterion for a class map based on VLAN ID. CES

Syntax match mac vlan number

Parameters Enter the VLAN ID. number

Range: 1-4094

Defaults None

Command Modes CLASS-MAP

> Command Version 8.3.3.1 Introduced on S60 **History**

Version 8.2.0.1 Introduced

Usage You must first enter the class-map command in order to access this command. You can match against Information only one VLAN ID.

Related class-map Create/access a class map. Commands

policy-aggregate

ĆES

Allow an aggregate method of configuring per-port QoS via policy maps. An aggregate QoS policy is part of the policy map (input/output) applied on an interface.

Syntax policy-aggregate qos-policy-name

To remove a policy aggregate configuration, use **no policy-aggregate** *qos-policy-name* command.

Parameters

qos-policy-name Enter	the name of the policy map in character format (32 characters maximum)
-----------------------	--

Defaults

No default behavior or values

Command Modes

CONFIGURATION (policy-map-input and policy-map-output)

This command is supported on C-Series, S-Series, and the S60 under policy-map-output only.

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Policy name character limit increased from 16 to 32.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

C-Series and S-Series

Aggregate input/output QoS policy applies to all the port ingoing/outgoing traffic. Aggregate input/output QoS policy can co-exist with per queue input/output QoS policies.

- 1. If only aggregate input QoS policy exists, input traffic conditioning configurations (rate-police) will apply. Any marking configurations in aggregate input QoS policy will be ignored.
- 2. If aggregate input QoS policy and per class input QoS policy co-exist, then aggregate input QoS policy will preempt per class input QoS policy on input traffic conditioning (rate-police). In other words, if rate police configuration exists in aggregate QoS policy, the rate police configurations in per class QoS are ignored. Marking configurations in per class input QoS policy still apply to each queue.

E-Series

Aggregate input/output QoS policy applies to all the port ingoing/outgoing traffic. Aggregate input/output QoS policy can co-exist with per queue input/output QoS policies.

- 1. If only an aggregate input QoS policy exists, input traffic conditioning configurations (rate-police) will apply. Any marking configurations in the aggregate input QoS policy will be ignored.
- 2. If an aggregate input QoS policy and a per-class input QoS policy co-exist, then the aggregate input QoS policy will preempt the per-class input QoS policy on input traffic conditioning (rate-police). In other words, if a rate police configuration exists in the aggregate QoS policy, the rate police configurations in the per-class QoS are ignored. Marking configurations in the per-class input QoS policy still apply to each queue.
- 3. If only an aggregate output QoS policy exists, egress traffic conditioning configurations (rate-limit and rate-shape) in the aggregate output QoS policy will apply. Scheduling and queuing configurations in the aggregate output QoS policy (if existing) are ignored. Each queue will use default scheduling and queuing configuration (Weighted Random Early Detection (WRED) and Bandwidth).

4. If the aggregate output QoS policy and per-queue output QoS policy co-exist, the aggregate output QoS policy will preempt a per-queue output QoS policy on egress traffic conditioning (rate-limit). In other words, if a rate limit configuration exists in the aggregate output QoS policy, the rate limit configurations in per-queue output QoS policies are ignored. Scheduling and queuing configurations (WRED and Bandwidth) in the per-queue output QoS policy still apply to each queue.

Related Commands

policy-map-input	Create an input policy map
policy-map-output	Create an output policy map (E-Series Only)

policy-map-input

(C) (E) (S)

Create an input policy map.

Syntax

policy-map-input policy-map-name [layer2]

To remove an input policy map, use the **no policy-map-input** policy-map-name [layer2] command.

Parameters

policy-map-name	Enter the name for the policy map in character format (32 characters maximum).
layer2	(OPTIONAL) Enter the keyword layer2 to specify a Layer 2 Class Map.
	Default: Layer 3

Defaults

Layer 3

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Policy name character limit increased from 16 to 32.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Expanded to add support for Layer 2
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Input policy map is used to classify incoming traffic to different flows using class-map, QoS policy, or simply using incoming packets DSCP. This command enables policy-map-input configuration mode (conf-policy-map-in).

Related **Commands**

service-queue Assign a class map and QoS policy to different queues.	
policy-aggregate	Allow an aggregate method of configuring per-port QoS via policy maps.
service-policy input	Apply an input policy map to the selected interface.

policy-map-output

C E S Create an output policy map.

Syntax policy-map-output policy-map-name

To remove a policy map, use the **no policy-map-output** *policy-map-name* command.

Parameters

policy-map-name Enter the name for the policy map in character format (16 characters maximum).

Defaults No default behavior or values

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Policy name character limit increased from 16 to 32.
Version 7.6.1.0	Introduced on C-Series and S-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information Output policy map is used to assign traffic to different flows using QoS policy. This command enables the policy-map-output configuration mode (conf-policy-map-out).

Related Commands

service-queue	Assign a class map and QoS policy to different queues.
policy-aggregate	Allow an aggregate method of configuring per-port QoS via policy maps.
service-policy output	Apply an output policy map to the selected interface.

qos-policy-input

C E S Create a QoS input policy on the router.

Syntax qos-policy-input qos-policy-name [layer2]

To remove an existing input QoS policy from the router, use **no qos-policy-input** *qos-policy-name* [layer2] command.

Parameters

qos-policy-name	Enter your input QoS policy name in character format (32 character maximum).
layer2	(OPTIONAL) Enter the keyword layer2 to specify a Layer 2 Class Map. Default: Layer 3

Defaults Layer 3

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Policy name character limit increased from 16 to 32.
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Expanded to add support for Layer 2

Usage Information

Use this command to specify the name of the input QoS policy. Once input policy is specified, rate-police can be defined. This command enables the qos-policy-input configuration mode— (conf-qos-policy-in).

When changing a "service-queue" configuration in a QoS policy map, all QoS rules are deleted and re-added automatically to ensure that the order of the rules is maintained. As a result, the Matched Packets value shown in the "show gos statistics" command is reset.



Note: On ExaScale, FTOS cannot classify IGMP packets on a Layer 2 interface using Layer 3 policy map. The packets always take the default queue, Queue 0, and cannot be rate-policed.

Related **Commands**

	rate-police	Incoming traffic policing function	
--	-------------	------------------------------------	--

qos-policy-output

Create a QoS output policy.

Syntax qos-policy-output gos-policy-name

To remove an existing output QoS policy, use **no qos-policy-output** qos-policy-name command.

Parameters

qos-policy-name	Enter your output QoS policy name in character format (32 character
	maximum).

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Policy name character limit increased from 16 to 32.
Version 7.6.1.0	Introduced on C-Series and S-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

Use this command to specify the name of the output QoS policy. Once output policy is specified, rate-limit, bandwidth-percentage, and WRED can be defined. This command enables the qos-policy-output configuration mode—(conf-qos-policy-out).

When changing a "service-queue" configuration in a QoS policy map, all QoS rules are deleted and re-added automatically to ensure that the order of the rules is maintained. As a result, the Matched Packets value shown in the "show gos statistics" command is reset.

Related Commands

rate-limit	Outgoing traffic rate-limit functionality
bandwidth-percentage	Assign weight to class/queue percentage
bandwidth-weight	Assign a priority weight to a queue.
wred	Assign yellow or green drop precedence

queue backplane ignore-backpressure

Reduce egress pressure by ignoring the ingress backpressure

Syntax queue backplane ignore-backpressure

To return to the default, use the **no queue backplane ignore-backpressure** command.

Defaults No default behavior or values

Command Modes CONFIGURATION

Command History

Version 7.7.1.0 Introduced on E-Series

queue egress

Assign a WRED Curve to all eight egress Multicast queues or designate the percentage for the Multicast bandwidth queue.

Syntax queue egress multicast linecard { slot number port-set number | all } [wred-profile name | multicast-bandwidth percentage]

To return to the default, use the **no queue egress multicast linecard** { *slot number* **port-set** *number* | **all**} [wred-profile *name* | multicast-bandwidth *percentage*] command.

Parameters

linecard number	Enter the keyword linecard followed by the line card slot number.
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.
port-set number	Enter the keyword port-set followed by the line card's port pipe.
	Range: 0 or 1
all	Enter the keyword all to apply to all line cards.
wred-profile name	(OPTIONAL) Enter the keyword wred-profile followed by your WRED profile name in character format (16 character maximum). Or use one of the pre-defined WRED profile names.
	Pre-defined Profiles:
	wred_drop, wred-ge_y, wred_ge_g, wred_teng_y, wred_teng_g
multicast-bandwidth percentage	(OPTIONAL) Enter the keyword multicast-bandwidth followed by the bandwidth percentage.
	Range: 0 to 100%

Defaults No default behavior or values

Command Modes CONFIGURATION

Command History

Version 7.5.1.0	Added support for multicast-bandwidth
Version 7.4.1.0 and 6.5.3.0	Introduced on E-Series

Usage Information

This command does not uniquely identify a queue, but rather identifies only a set of queues. The WRED curve is applied to all eight egress Multicast queues.

Important Points to Remember—multicast-bandwidth option

- A unique Multicast Weighted Fair Queuing (WFQ) setting can be applied only on a per port-pipe basis. The minimum percentage of the multicast bandwidth assigned to any of the ports in the port-pipe will take effect for the entire port-pipe.
- If the percentage of multicast bandwidth is 0, control traffic going through multicast queues are dropped.
- The no form of the command without multicast-bandwidth and wred-profile, will remove both the wred-profile and multicast-bandwidth configuration.
- On 10 Gigabit ports only, the multicast bandwidth option will work only if the total unicast bandwidth is more than the multicast bandwidth.
- If strict priority is applied along with multicast-bandwidth, the effect of strict priority is on all ports where unicast and multicast bandwidth are applied.
- When multicast bandwidth is assigned along with unicast bandwidth, first multicast bandwidth will be reserved for that port, then the remaining unicast bandwidth configured is adjusted according to the bandwidth available after reserving for multicast bandwidth.

Related **Commands**

show queue statistics egress Display the egress queue statistics

queue ingress

Assign a WRED Curve to all eight ingress Multicast queues or designate the percentage for the Multicast bandwidth queue.

Syntax

queue ingress multicast {linecard slot number port-set number | all } [wred-profile name]

To return to the default, use the no queue ingress multicast {linecard slot number port-set number | all} [wred-profile name] command.

Parameters

linecard number	Enter the keyword linecard followed by the line card slot number.
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.
port-set number	Enter the keyword port-set followed by the line card's port pipe.
	Range: 0 or 1
all	Enter the keyword all to apply to all line cards.
wred-profile name	(OPTIONAL) Enter the keyword wred-profile followed by your WRED profile name in character format (16 character maximum). Or use one of the pre-defined WRED profile names.
	Pre-defined Profiles:
	wred_drop, wred-ge_y, wred_ge_g, wred_teng_y, wred_teng_g

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command **History**

Version 7.4.1.0 and 6.5.3.0	Introduced on E-Series	

Usage Information

This command does not uniquely identify a queue, but rather identifies only a set of queues. The WRED Curve is applied to all eight ingress Multicast queues.



Note: The multicast-bandwidth option is not supported on queue ingress. If you attempt to use the multicast-bandwidth option, the following reject error message is generated:

% Error:Bandwidth-percent is not allowed for ingress
multicast

Related Commands

show queue statistics ingress	Display the ingress queue statistics	
-------------------------------	--------------------------------------	--

rate-limit

 \mathbb{E}

Specify the rate-limit functionality on outgoing traffic as part of the selected policy.

Syntax

rate-limit [kbps] committed-rate [burst-KB] [peak [kbps] peak-rate [burst-KB]]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On
•	the E-Series, Dell Networking recommends using a value greater than or equal to 512 as lower values does not yield accurate results. The default
	granularity is Megabits per second (Mbps).
	Range: 0-10000000
committed-rate	Enter the committed rate in Mbps.
	Range: 0 to 10000 Mbps
burst-KB	(OPTIONAL) Enter the burst size in KB.
	Range: 16 to 200000 KB
	Default: 50 KB
peak peak-rate	(OPTIONAL) Enter the keyword peak followed by the peak rate in Mbps.
	Range: 0 to 10000 Mbps
	Default: Same as designated for committed-rate

Defaults

Burst size is 50 KB. *peak-rate* is by default the same as *committed-rate*. Granularity for *committed-rate* and *peak-rate* is Mbps unless the **kbps** option is used.

Command Modes

QOS-POLICY-OUT

Command History

Version 8.2.1.0	Added kbps option on E-Series.
Version 7.7.1.0	Removed from C-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series
rate limit	Specify rate-limit functionality on the selected interface.
gos-policy-output	Create a OoS output policy.

Related Commands

rate-police

Specify the policing functionality on incoming traffic.

Syntax

rate-police [kbps] committed-rate [burst-KB] [peak [kbps] peak-rate [burst-KB]]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On C-Series and S-Series make the following value a multiple of 64. On the E-Series, Dell Networking recommends using a value greater than or equal to 512 as lower values does not yield accurate results. The default granularity is Megabits per second (Mbps). Range: 0-10000000
committed-rate	Enter the committed rate in Mbps. Range: 0 to 10000 Mbps
burst-KB	(OPTIONAL) Enter the burst size in KB. Range: 16 to 200000 KB Default: 50 KB
peak peak-rate	(OPTIONAL) Enter the keyword peak followed by the peak rate in Mbps. Range: 0 to 10000 Mbps Default: Same as designated for <i>committed-rate</i>

Defaults

Burst size is 50 KB. peak-rate is by default the same as committed-rate. Granularity for committed-rate and peak-rate is Mbps unless the kbps option is used.

Command Modes

QOS-POLICY-IN

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Added kbps option on C-Series, E-Series, and Series.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series
-	

Related Commands

rate police	Specify traffic policing on the selected interface.
qos-policy-input	Create a QoS output policy.

rate-shape

Shape traffic output as part of the designated policy.

Syntax

rate-shape [kbps] rate [burst-KB]

Parameters

kbps	Enter this keyword to specify the rate limit in Kilobits per second (Kbps). On
-	C-Series and S-Series make the following value a multiple of 64. The default
	granularity is Megabits per second (Mbps).
	Range: 0-10000000

rate	Enter the outgoing rate in multiples of 10 Mbps. Range: 0 to 10000
burst-KB	(OPTIONAL) Enter a number as the burst size in KB.
	Range: 0 to 10000
	Default: 10

Defaults

Burst size is 10 KB. Granularity for *rate* is Mbps unless the **kbps** option is used.

Command Modes

QOS-POLICY-OUT

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Added kbps option on C-Series, E-Series, and Series.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

rate-shape can be applied only as an aggregate policy. If it is applied as a class-based policy, then rate-shape will not take effect.

Related Commands

rate shape	Shape the traffic output of the selected interface.
qos-policy-output	Create a QoS output policy.

service-policy input

CES

Apply an input policy map to the selected interface.

Syntax

service-policy input policy-map-name [layer2]

To remove the input policy map from the interface, use the **no service-policy input** *policy-map-name* [layer2] command.

Parameters

policy-map-name	Enter the name for the policy map in character format (16 characters maximum). You can identify an existing policy map or name one that does not yet exist.
layer2	(OPTIONAL) Enter the keyword layer2 to specify a Layer 2 Class Map. Default: Layer 3

Defaults

Layer 3

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Expanded to add support for Layer 2
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

A single policy-map can be attached to one or more interfaces to specify the service-policy for those interfaces. A policy map attached to an interface can be modified.



Note: The **service-policy** commands are not allowed on a port channel.

The service-policy input policy-map-name command and the service-class dynamic dot1p command are not allowed simultaneously on an interface. However, the service-policy input command (without the *policy-map-name* option) and the **service-class dynamic** dot1p command are allowed on an interface.

Related **Commands**

policy-map-input Create an input policy map.	
--	--

service-policy output

CES Apply an output policy map to the selected interface.

Syntax service-policy output policy-map-name

> To remove the output policy map from the interface, use the **no service-policy output** policy-map-name command.

Parameters

policy-map-name	Enter the name for the policy map in character format (16 characters
	maximum). You can identify an existing policy map or name one that
	does not yet exist.

Defaults No default behavior or values

Command Modes INTERFACE

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information A single policy-map can be attached to one or more interfaces to specify the service-policy for those interfaces. A policy map attached to an interface can be modified.

Related Commands

policy-map-output Create an output policy map.

service-queue

CESAssign a class map and QoS policy to different queues.

Syntax service-queue queue-id [class-map class-map-name] [gos-policy qos-policy-name]

> To remove the queue assignment, use the **no service-queue** *queue-id* [class-map class-map-name] [qos-policy qos-policy-name] command.

Parameters

queue-id	Enter the value used to identify a queue.
	Range: 0 to 7 on E-Series (eight queues per interface), 0-3 on C-Series and S-Series (four queues per interface; four queues are reserved for control traffic.)
class-map class-map-name	(OPTIONAL) Enter the keyword class-map followed by the class map name assigned to the queue in character format (16 character maximum). Note: This option is available under policy-map-input only.
qos-policy qos-policy-name	(OPTIONAL) Enter the keyword qos-policy followed by the QoS policy name assigned to the queue in text format (16 characters maximum). This specifies the input QoS policy assigned to the queue under policy-map-input and output QoS policy under policy-map-output context.

Defaults

No default behavior or values

Command Modes

CONFIGURATION (conf-policy-map-in and conf-policy-map-out)

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
pre-Version 6.1.1.1	Introduced on E-Series	

Usage Information

There are eight (8) queues per interface on the E-Series and four (4) queues per interface on the C-Series and S-Series. This command assigns a class map or QoS policy to different queues.

Related Commands

class-map	Identify the class map.
service-policy input	Apply an input policy map to the selected interface.
service-policy output	Apply an output policy map to the selected interface.

set



Mark outgoing traffic with a Differentiated Service Code Point (DSCP) or dot1p value.

Syntax

set {ip-dscp value | mac-dot1p value}

Parameters

ip-dscp value	(OPTIONAL) Enter the keyword ip-dscp followed by the IP DSCP value.
	Range: 0 to 63
mac-dot1p value	Enter the keyword mac-dot1p followed by the dot1p value.
	Range: 0 to 7
	On the C-Series and S-Series allowed values are:0,2,4,6

Defaults

No default behavior or values

Command Modes

CONFIGURATION (conf-qos-policy-in)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	mac-dot1p available on the C-Series and S-Series
Version 7.6.1.0	Introduced on S-Series

Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Expanded to add support for mac-dot1p
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

C-Series and S-Series

Once the IP DSCP bit is set, other QoS services can then operate on the bit settings.

E-Series

Once the IP DSCP bit is set, other QoS services can then operate on the bit settings. WRED (Weighted Random Early Detection) ensures that high-precedence traffic has lower loss rates than other traffic during times of congestion.

show cam layer2-qos

Display the Layer 2 QoS CAM entries. [E]

show cam layer2-qos {[linecard number port-set number] | [interface interface]} [summary] **Syntax**

Parameters

linecard number	Enter the keyword linecard followed by the line card slot number.
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.
port-set number	Enter the keyword port-set followed by the line card's port pipe.
	Range: 0 or 1
interface interface	Enter the keyword interface followed by one of the keywords below and slot/port or number information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
summary	(OPTIONAL) Enter the keyword summary to display only the total number of CAM entries.

Defaults

No default behavior or values

Command Modes

EXEC

Command History

Version 7.4.1.0	Introduced on E-Series	
VCISIOII /.4.1.0	minoduced on E-Series	

Example Figure 31-3. show cam layer2-qos interface Command Output

Cam Index	Port	Dot1p	Proto	SrcMac	SrcMask	DstMac	DstMask 	Dot1	p DSC Marking	P (Mark	Queue ing
1817	0	-	0	00:00:00:00:cc:cc	00:00:00:00:ff:f:	f 00:00:00:00:dd:d	ld 00:00:00:00:ff:	ff ·	-	-	7
1818	0	-	0	00:00:00:00:00:c0	00:00:00:00:00:f0	0 00:00:00:00:00:d	10 00:00:00:00:00:	f0 -	-	45	5
1819	0	4	0	00:00:00:a0:00:00	00:00:00:ff:00:0	0 00:00:00:b0:00:0	00 00:00:00:ff:00:	00 4	1	-	4
1820	0	-	0x2000	00:00:00:00:00:00	00:00:00:00:00:0	0 00:00:00:00:00:h	00 ff:ff:ff:ff:ff:	ff	-	-	1
2047	0	_	0	00:00:00:00:00:00	00:00:00:00:00:00	0.00:00:00:00:00:0	00:00:00:00:00:00	00 -	-	_	0

Example Figure 31-4. show cam layer2-qos linecard Command Output

Cam Index		Dot1p	Proto	SrcMac	SrcMask	DstMac	DstMask	Dot	1p DSC Marking	P Queu Marking
01817	0	-	0	00:00:00:00:cc:cc	00:00:00:00:ff:f	f 00:00:00:00:dd:	dd 00:00:00:00:ff:	ff	-	 - 7
01818	0	-	0	00:00:00:00:00:c0	00:00:00:00:00:f	0 00:00:00:00:00:	d0 00:00:00:00:00:	f0	-	45 5
01819	0	4	0	00:00:00:a0:00:00	00:00:00:ff:00:0	0 00:00:00:b0:00:	00 00:00:00:ff:00:	00	4	- 4
1820	0	-	0x2000	00:00:00:00:00:00	00:00:00:00:00:0	00:00:00:00:00	:b0 ff:ff:ff:ff:ff	ff	-	- 1
02047 FTOS#	0	-	0	00:00:00:00:00:00	00:00:00:00:00:0	0 00:00:00:00:00	00 00:00:00:00:00:	00	-	- 0

show cam layer3-qos

E Display the Layer 3 QoS CAM entries.

Syntax show cam layer3-qos {[linecard number port-set number] | [interface interface]} [summary]

Parameters

linecard number	Enter the keyword linecard followed by the line card slot number.
	E-Series Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on E300.
port-set number	Enter the keyword port-set followed by the line card's port pipe.
	Range: 0 or 1
interface interface	Enter the keyword interface followed by one of the keywords below and slot/port or number information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a Gigabit Ethernet interface, enter the keyword GigabitEtherne followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot port information.
	 For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
summary	(OPTIONAL) Enter the keyword summary to display only the total number of CAM entries.

Defaults No default behavior or values

Command Modes EX

EXEC

Command History

Version 6.5.1.0 Introduced on E-Series

Example Figure 31-5. show cam layer3-qos linecard interface Command Output

(FTOS#	sh car	n laye	er3-qo	s inte	rface	gigabi	itetl	hernet 2/1				
	Cam Index	Port	Dscp	Proto	Tcp Flag		Dst Port	Sr	cIp	DstIp		SCP Warking	Queue
	23488 FTOS#	1	0	0 (0x0 0)	0 0	.0.0	0.0/0	0.0.0.0/0	-	TRUST	T-DSCP

In these figures outputs, note that:

- The entry TRUST-DSCP in the Queue column indicates that the trust diffserv is configured on the policy-map.
- A hyphen (-) entry in the DSCP Marking column indicates that there is no DSCP marking.
- In the Proto column (Protocol), IP, ICMP, UDP, and TCP strings are displayed. For other protocols, the corresponding protocol number is displayed.

Example Figure 31-6. show cam layer3-qos linecard port-set Command Output

(FTOS#sl	now cam	layerî	3-qos	lineca	ard 13	port-	set 0			
- 1	Cam Index	Port	Dscp	Proto		Src Port		SrcIp	DstIp	DSCP Marking	Queue
- 1	24511 24512	1	0	TCP UDP	0x5 0x2	2		1.0.0.1/24 8.0.0.8/24	2.0.0.2/24 8.0.0.8/24	23	TRUST-DSCP
	FTOS#										

Example Figure 31-7. show cam layer3-qos linecard interface Command without Trust Output

Cam Index	Port	Dscp	Proto		Src Port	Dst Port	SrcIp	DstIp	DSCP Marki	Queue ing
23488	1	56	0	0x0	0	0	0.0.0.0/0	0.0.0.0/0	-	7
23489	1	48	0	0x0	0	0	0.0.0.0/0	0.0.0.0/0	-	6
23490	1	40	0	0x0	0	0	0.0.0.0/0	0.0.0.0/0	_	5
23491	1	0	ΙP	0x0	0	0	10.1.1.1/32	20.1.1.1/32	_	0
23492	1	0	ΙP	0x0	0	0	10.1.1.1/32	20.1.1.2/32	_	0
24511	1	0	0	0x0	0	0	0.0.0.0/0	0.0.0.0/0	_	0

Example Figure 31-8. show cam layer3-qos summary Command Output

FTOS#show cam layer3-qos linecard 13 port-set 0 summary Total number of CAM entries for Port-Set 0 is 100

show qos class-map

C E S View the current class map information.

Syntax show qos class-map [class-name]

Parameters Class-name (Optional) Enter the name of a configured class map.

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Example Figure 31-9. show gos class-map Command Output

FTOS#show qos class-map Class-map match-any CM Match ip access-group ACL

Related Commands

class-map Identify the class map

show qos policy-map

CES View the QoS policy map information.

Syntax show qos policy-map {summary [interface] | detail [interface]}

Parameters

summary interface

To view a policy map interface summary, enter the keyword **summary** and optionally one of the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/ port information.
- For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

detail interface

To view a policy map interface in detail, enter the keyword **detail** and optionally one of the following keywords and slot/port or number information:

- For a Fast Ethernet interface, enter the keyword **FastEthernet** followed by the slot/ port information.
- For a Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series only: Added Trust IPv6 diffserv
Version 6.2.1.1	Introduced on E-Series

Example 1 Figure 31-10. show gos policy-map detail (IPv4) Command Output

```
FTOS#show qos policy-map detail gigabitethernet 0/0
Interface GigabitEthernet 4/1
Policy-map-input policy
Trust diffserv
Queue#
        Class-map-name
                                   Qos-policy-name
                                    q0
              CM1
                                    q1
  2
              CM2
                                    q2
              СМЗ
                                    q3
              CM4
                                    q4
                                    q5
  6
              CM6
                                    q6
q7
              CM7
FTOS#
```

Example 2 Figure 31-11. show gos policy-map detail (IPv6) Command Output (E-Series only)

```
FTOS# show gos policy-map detail gigabitethernet 0/0
Interface GigabitEthernet 8/29
Policy-map-input pmap1
Trust ipv6-diffserv
Queue#
        Class-map-name
                                   Qos-policy-name
               c0
               с1
  1
                                                     q1
  2
               c2
                                                     q2
  3
              с3
                                                     q3
  4
               c4
                                                     q4
  5
               С5
  6
               С6
               c7
FTOS#
```

Example 3 Figure 31-12. show gos policy-map summary (IPv4) Command Output

, FTOS#show qos policy-map summary

Interface policy-map-input policy-map-output Gi 4/1 Gi 4/2 PM1

PMOut FTOS#

show qos policy-map-input

View the input QoS policy map details. CES

Syntax show qos policy-map-input [policy-map-name] [class class-map-name] [qos-policy-input

qos-policy-name]

Parameters

policy-map-name	Enter the policy map name.
class class-map-name	Enter the keyword class followed by the class map name.
qos-policy-input qos-policy-name	Enter the keyword qos-policy-input followed by the QoS policy name.

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Added Trust IPv6 diffserv
Version 6.2.1.1	Introduced on E-Series

Example 1 Figure 31-13. show gos policy-map-input (IPv4) Command Output

FTOS#show qos policy-map-input

Policy-map-input PolicyMapInput

Aggregate Qos-policy-name AggPolicyIn
Queue# Class-map-name Qos-r Queue# Qos-policy-name ClassMap1 qosPolicyInput

FTOS#

Example 2 Figure 31-14. show gos policy-map-input (IPv6) Command Output

FTOS# show qos policy-map-input Policy-map-input pmap1 Trust ipv6-diffserv Queue# Class-map-r Class-map-name Qos-policy-name c0 q1 q2 1 c1 с2 3 С3 q3 С4 q4 5 С5 6 С6 c7 FTOS#

show qos policy-map-output

CES View the output QoS policy map details.

Syntax show qos policy-map-output [policy-map-name] [qos-policy-output qos-policy-name]

Parameters

policy-map-name	Enter the policy map name.	
qos-policy-output qos-policy-name	Enter the keyword qos-policy-output followed by the QoS policy name.	

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on C-Series and S-Series	
pre-Version 6.1.1.1	Introduced on E-Series	

Example

Figure 31-15. show gos policy-map-output Command Output

FTOS#show qos policy-map-output Policy-map-output PolicyMapOutput Aggregate Qos-policy-name AggPolicyOut Qos-policy-name qosPolicyOutput Queue# FTOS#

show qos qos-policy-input

CES View the input QoS policy details.

Syntax show qos qos-policy-input [qos-policy-name]

Parameters gos-policy-name Enter the QoS policy name.

Defaults No default behavior or values

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
pre-Version 6.1.1.1	Introduced on E-Series	

Example

Figure 31-16. show qos qos-policy-input Command Output

FTOS#show qos qos-policy-input

Qos-policy-input QosInput
Rate-police 100 50 peak 100 50
Dscp 32
FTOS#

show qos qos-policy-output

CESV

View the output QoS policy details.

Syntax show qos qos-policy-output [qos-policy-name]

Parameters

qos-policy-name Enter the QoS policy name.

Defaults No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on C-Series and S-Series	
pre-Version 6.1.1.1	Introduced on E-Series	

Example

Figure 31-17. show qos qos-policy-output Command Output

FTOS#show qos qos-policy-output

Qos-policy-output qosOut

Rate-limit 50 50 peak 50 50

Wred yellow 1

Wred green 1

show qos statistics

CES

View QoS statistics.

Syntax

show qos statistics {wred-profile [interface]} | [interface]

Parameters

wred-profile interface	Platform—E-Series Only: Enter the keyword wred-profile and optionally one of the following keywords and slot/port or number information:	
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information. 	
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information. 	
	 For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	
interface	Enter one of the following keywords and slot/port or number information:	
	 On the C-Series and E-Series, For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information. 	
	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information. 	
	 For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information. 	

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.7.1.1	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

The **show gos statistics** command can be used on the C-Series, but the **wred-profile** keyword must be omitted in the syntax. The show gos statistics output differs from the ED and EE series line cards and the EF series line cards. The QoS statistics for the EF series generates two extra columns, Queued Pkts and Dropped Pkts, see Example 2.



Note: The **show qos statistics** command displays Matched Packets and Matched Bytes. The show queue statistics egress command (E-Series only) displays Queued Packets and Queued Bytes. The following example explains how these two displays relate to each other.

- 9000 byte size packets are sent from Interface A to Interface B.
- The Matched Packets on Interface A are equal to the Queued Packets on Interface B.
- Matched bytes on Interface A = matched packets *9000
- Queued bytes on Interface B = queued packets *(9020)—Each packet has an additional header of 20 bytes.

Example 1 Figure 31-18. show qos statistics Command Output (ED and EE Series of E-Series)

FTOS#s	how qos statistics		
Interf	ace Gi 0/0		
Queue#	Queued Bytes	Matched Pkts	Matched Bytes
0	0	0	0
1	0	0	0
2	0	0	0
3	0	0	0
4	0	0	0
5	0	0	0
6	0	0	0
7	0	0	0
Interf	ace Gi 0/1		
Queue#	Queued Bytes	Matched Pkts	Matched Bytes
0	0	0	0
1	0	0	0
2	0	0	0
3	0	0	0
4	0	0	0
5	0	0	0
6	0	0	0
7	0	0	0

Table 31-4. show gos statistics Command Example Fields (ED and EE Series)

Field	Description	
Queue #	Queue Number	
Queued Bytes	Snapshot of the byte count in that queue.	
Matched Pkts	The number of packets that matched the class-map criteria. Note: When trust is configured, matched packet counters are not incremented in this field.	
Matched Bytes	The number of bytes that matched the class-map criteria. Note: When trust is configured, matched byte counters are not incremented in this field.	

Example 2 Figure 31-19. show qos statistics Command Output (EFSeries of E-Series)

Queue#	Queued	Queued	Matched	Matched	Dropped
	Bytes	Pkts	Pkts	Bytes	Pkts
	(Cumulative)	(Cumulative)		-	
0	0	0	1883725	1883725000	0
1	0	0	1883725	1883725000	0
2	0	0	1883725	1883725000	0
3	0	0	1883725	1883725000	0
4	0	0	1883725	1883725000	0
5	0	0	1883724	1883724000	0
6	0	0	1883720	1883720000	0
7	0	0	1883720	1883720000	0

Table 31-5. show qos statistics Command Example Fields (EF Series)

Field	Description
Queue #	Queue Number
Queued Bytes	Cumulative byte count in that queue

Table 31-5. show gos statistics Command Example Fields (EF Series) (continued)

Field	Description
Queued Pkts	Cumulative packet count in that queue.
Matched Pkts	The number of packets that matched the class-map criteria. Note: When trust is configured, matched packet counters are not incremented in this field.
Matched Bytes	The number of bytes that matched the class-map criteria. Note: When trust is configured, matched byte counters are not incremented in this field.
Dropped Pkts	The total of the number of packets dropped for green, yellow and out-of-profile.

Example 3 Figure 31-20. show gos statistics wred-profile Command Output (ED, EE, and EF Series)




Table 31-6. show gos statistics wred-profile Command Example Fields (ED, EE, and EF Series)

Field	Description	
Queue #	Queue Number	
Drop-statistic	Drop statistics for green, yellow and out-of-profile packets	
WRED-name	WRED profile name	
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile	

Related **Commands**

clear gos statistics	Clears counters as shown in show gos statistics
1	1

show gos wred-profile

E View the WRED profile details.

Syntax show qos wred-profile wred-profile-name

wred-profile-name

Defaults No default behavior or values

Command Modes EXEC

Parameters

EXEC Privilege

Command History

pre-Version 6.1.1.1 Introduced on E-Series

Example Figure 31-21. show gos wred-profile Command Output

FTOS#show qos wred-profile Wred-profile-name wred_drop min-threshold max-threshold wred_ge_y wred_ge_g wred_teng_y wred_teng_g 1024 2048 4096 2048 4096 8192 16384 8192 WRED1 2000 7000

Enter the WRED profile name to view the profile details.

test cam-usage

C E S Check the Input Policy Map configuration for the CAM usage.

Syntax test cam-usage service-policy input policy-map linecard {[number port-set portpipe number]

| [all]}

Parameters

policy-map	Enter the policy map name.
linecard number	(OPTIONAL) Enter the keyword linecard followed by the line card slot number.
port-set portpipe number	Enter the keyword port-set followed by the line card's port pipe number.
	Range: 0 or 1
linecard all	(OPTIONAL) Enter the keywords linecard all to indicate all line cards.

Defaults No default values or behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on C-Series and S-Series	
Version 7.4.1.0	Introduced on E-Series	

Example Figure 31-22. test cam-usage service-policy input policy-map linecard all Example Command

FTOS# test cam-usage service-policy input pmap_12 linecard all For a L2 Input Policy Map pmap 12, the output must be as follows, | Portpipe | CAM Partition | Available CAM | Estimated CAM | Status | per Port | (Allowed ports) 0 L2ACL 500 200 Allowed (2) 0 L2ACL 100 200 Exception 1 0 L2ACL 1000 200 Allowed (5) L2ACL 200 Exception L2ACL 1 400 200 Allowed (2) 13 FTOS#



Note: In a Layer 2 Policy Map, IPv4/IPv6 rules are not allowed and hence the output contains only L2ACL CAM partition entries.

Table 31-7. test cam-usage Command Example Fields

Field	Description
Linecard	Indicates the line card slot number.
Portpipe	Indicates the portpipe number.
CAM Partition	The CAM space where the rules are added.
Available CAM	Indicates the free CAM space, in the partition, for the classification rules. Note: The CAM entries reserved for the default rules are not included in the Available CAM column; free entries, from the default rules space, can not be used as a policy map for the classification rules.
Estimated CAM per Port	Indicates the number of free CAM entries required (for the classification rules) to apply the input policy map on a single interface. Note: The CAM entries for the default rule are not included in this column; a CAM entry for the default rule is always dedicated to a port and is always available for that interface.
Status (Allowed ports)	Indicates if the input policy map configuration on an interface belonging to a line card/port-pipe is successful—Allowed (<i>n</i>)—or not successful—Exception. The allowed number (<i>n</i>) indicates the number of ports in that port-pipe on which the Policy Map can be applied successfully.

Usage Information

This features allows you to determine if the CAM has enough space available before applying the configuration on an interface.

An input policy map with both Trust and Class-map configuration, the Class-map rules are ignored and only the Trust rule is programmed in the CAM. In such an instance, the Estimated CAM output column will contain the size of the CAM space required for the Trust rule and *not* the Class-map rule.

threshold

E

Specify the minimum and maximum threshold values for the configured WRED profiles.

Syntax

threshold min number max number

To remove the threshold values, use the **no threshold min** *number* **max** *number* command.

Parameters

min number	Enter the keyword min followed by the minimum threshold number for the WRED profile. Range: 1024 to 77824 KB
max number	Enter the keyword max followed by the maximum threshold number for the WRED profile. Range: 1024 to 77824 KB

Defaults

No default behavior or values

Command Modes

CONFIGURATION (config-wred)

Command History

pre-Version 6.1.1.1 Introduced on E-Series

Usage Information

Use this command to configure minimum and maximum threshold values for user defined profiles. Additionally, use this command to modify the minimum and maximum threshold values for the pre-defined WRED profiles. If you delete threshold values of the pre-defined WRED profiles, the profiles will revert to their original default values.

Table 31-8. Pre-defined WRED Profile Threshold Values

Pre-defined WRED Profile Name	Minimum Threshold	Maximum Threshold
wred_drop	0	0
wred_ge_y	1024	2048
wred_ge_g	2048	4096
wred_teng_y	4096	8192
wred_teng_g	8192	16384

Related Commands

wred-profile Create a WRED profile.	wred-profile	Create a WRED profile.	
-------------------------------------	--------------	------------------------	--

trust



Specify dynamic classification (DSCP) or dot1p to trust.

Syntax

trust {diffserv [fallback]| dot1p [fallback]| ipv6-diffserv}

Parameters

diffserv	Enter the keyword diffserv to specify trust of DSCP markings.
dot1p	Enter the keyword dot1p to specify trust dot1p configuration.
fallback	Enter this keyword to classify packets according to their DSCP value as a secondary option in case no match occurs against the configured class maps.
ipv6-diffserv	On E-Series only, enter the keyword ipv6-diffserv to specify trust configuration of IPv6 DSCP.

Defaults No default behavior or values

Command Modes CONFIGURATION (conf-policy-map-in)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	fallback available on the E-Series.
Version 8.2.1.0	dot1p available on the C-Series and S-Series.
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Expanded to add support for dot1p and IPv6 DSCP
pre-Version 6.1.1.1	Introduced on E-Series

Usage Information

When trust is configured, matched bytes/packets counters are not incremented in the **show qos** statistics command.

The **trust diffserv** feature is not supported on E-Series ExaScale when an IPv6 microcode is enabled.

Dynamic mapping honors packets marked according to the standard definitions of DSCP. The default mapping table is detailed in the following table.

Table 31-9. Standard Default DSCP Mapping Table

DSCP/CP hex range (XXX)	DSCP Definition	Traditional IP Precedence	E-Series Internal Queue ID	C-Series and S-Series Internal Queue ID	DSCP/CP decimal
111XXX		Network Control	7	3	- 48–63
110XXX		Internetwork Control	6	3	
101XXX	EF (Expedited Forwarding)	CRITIC/ECP	5	2	- 32–47
100XXX	AF4 (Assured Forwarding)	Flash Override	4	2	32–47
011XXX	AF3	Flash	3	1	16 21
010XXX	AF2	Immediate	2	1	16–31
001XXX	AF1	Priority	1	0	0.15
000XXX	BE (Best Effort)	Best Effort	0	0	0–15

wred

E Designate the WRED profile to yellow or green traffic.

Syntax wred {yellow | green} profile-name

To remove the WRED drop precedence, use the **no wred** {**yellow** | **green**} [*profile-name*] command.

Parameters

yellow green	Enter the keyword yellow for yellow traffic. DSCP value of xxx110 and xxx100 maps to yellow. Enter the keyword green for green traffic. DSCP value of xxx010 maps to green.
profile-name	Enter your WRED profile name in character format (16 character maximum). Or use one of the 5 pre-defined WRED profile names. Pre-defined Profiles: wred_drop, wred-ge_y, wred_ge_g, wred_teng_y, wred_teng_

Defaults No default behavior or values

Command Modes CONFIGURATION (conf-qos-policy-out)

Command History

Version 8.2.1.0 Profile name character limit increased from 16 to 32.

pre-Version 6.1.1.1 Introduced on E-Series

Usage Information

Use this command to assign drop precedence to green or yellow traffic. If there is no honoring enabled on the input, all the traffic defaults to green drop precedence.

Related Commands

wred-profile	Create a WRED profile and name that profile
trust	Define the dynamic classification to trust DSCP

wred-profile

E Create a WRED profile and name that profile.

Syntax wred-profile wred-profile-name

To remove an existing WRED profile, use the **no wred-profile** command.

Parameters

wred-profile-name	Enter your WRED profile name in character format (16 character maximum). Or use one of the pre-defined WRED profile names. You can configure up to 26 WRED profiles plus the 5 pre-defined profiles, for a total of 31 WRED profiles.
	Pre-defined Profiles:
	wred_drop, wred-ge_y, wred_ge_g, wred_teng_y, wred_teng_g

Defaults The five pre-defined WRED profiles. When a new profile is configured, the minimum and maximum threshold defaults to predefined wred_ge_g values

Command Modes CONFIGURATION

Command History pre-Version

pre-Version 6.1.1.1 Introduced on E-Series

Usage Information

Use the default pre-defined profiles or configure your own profile. You can not delete the pre-defined profiles or their default values. This command enables the WRED configuration mode—(conf-wred).

Related **Commands**

threshold Specify the minimum and maximum threshold values of the WRED profile

Queue-Level Debugging

Queue-Level Debugging is an E-Series-only feature, as indicated by the [F] character that appears below each command heading.

The following queuing statistics are available on TeraScale versions of E-Series systems.

- clear queue statistics egress
- clear queue statistics ingress
- show queue statistics egress
- show queue statistics ingress

clear queue statistics egress

Clear egress queue statistics.

Syntax clear queue statistics egress [unicast | multicast] [Interface]

Parameters

unicast multicast	(OPTIONAL) Enter the keyword multicast to clear only Multicast queue statistics. Enter the keyword unicast to clear only Unicast queue statistics.
	Default: Both Unicast and Multicast queue statistics are cleared.
Interface	(OPTIONAL) Enter one of the following interfaces to display the interface specific queue statistics.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	Fast Ethernet is not supported

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 6.2.1.1 Introduced

Usage Information

If a Policy QoS is applied on an interface when clear queue statistics egress is issued, it will clear the egress counters in show queue statistics and vice-versa. This behavior is due to the values being read from the same hardware registers.

Related Commands

clear queue statistics egress	Clear ingress queue statistics
show queue statistics egress	Display egress queue statistics
show queue statistics ingress	Display ingress queue statistics

clear queue statistics ingress

E Clear ingress queue statistics.

Syntax clear queue statistics ingress [unicast [src-card ID [dst-card ID]] | [multicast] [src-card

ΙĽ

Parameters

unicast [src-card <i>ID</i> [dst-card <i>ID</i>]]	(OPTIONAL) Enter the keyword unicast to clear Unicast queue statistics. Optionally, enter the source card identification (src-card <i>ID</i>) and the destination card identification (dst-card <i>ID</i>) to clear the unicast statistics from the source card to the destination card.
multicast [src-card ID]	(OPTIONAL) Enter the keyword multicast to clear only Multicast queue statistics. Optionally, enter the source card identification (src-card <i>ID</i>) to clear the multicast statistics from the source card. Default: Both Unicast and Multicast queue statistics are cleared.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Related Commands

clear queue statistics egress	Clear egress queue statistics
show queue statistics egress	Display egress queue statistics
show queue statistics ingress	Display ingress queue statistics

show queue statistics egress

E Display the egress queue statistics.

Syntax show queue statistics egress [unicast | multicast] [Interface] [brief]

Parameters

unicast multicast	(OPTIONAL) Enter the keyword multicast to display only Multicast queue statistics. Enter the keyword unicast to display only Unicast queue statistics.
	Default: Both Unicast and Multicast queue statistics are displayed.
Interface	(OPTIONAL) Enter one of the following interfaces to display the interface specific queue statistics.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/ port information.
	 Fast Ethernet is not supported.
brief	(OPTIONAL) Enter the keyword brief to display only ingress per link buffering and egress per port buffering statistics.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

eries	
-------	--

Usage Information

TeraScale systems display cumulative queued bytes (in KB), cumulative queued packets (in KB), and cumulative dropped packets (in KB).

The display area is limited to 80 spaces to accommodate the screen and for optimal readability. Numbers, that is values, are limited to 12 characters. The numbering conventions are detailed in the table below.

Table 31-10. Numbering Conventions for show queue egress statistics Output

Value	Divide the number by	Quotient Display	Examples
(10^11) - (10^14)	1024	K	12345678901 K
(10^14) - (10^17)	1024*1024	M	12345678901 M
> (10^17)	1024*1024*1024	Т	12345678901 T



Note: The **show queue statistics** command displays Queued Packets and Queued Bytes. The show gos statistics command displays Matched Packets and Matched Bytes. The following example explains how these two outputs relate to each other.

- 9000 byte size packets are sent from Interface A to Interface B.
- The Matched Packets on Interface A are equal to the Queued Packets on Interface B.
- Matched bytes on Interface A = matched packets *9000
- Queued bytes on Interface B = queued packets *(9020)—Each packet has an additional header of 20 bytes.

Example 1 Figure 31-23. show queue statistics egress Command (TeraScale)

	-	tistics egres	s unicas	t gigab	tetherne	t 9/1	
Interfa	ace Gi 9/1						
Egress Port Queue#	Queued bytes	Queued packets	Packet	Туре	Min KB	Max KB	Dropped packets
0	281513847K	31959000	Green Yellow	Profile	2048 1024	4096 2048	0 0 30385770
1	99281660K	11271000	Green Yellow Out of		2048 1024	4096 2048	0 0 9886100
2	99281660K	11271000	Green Yellow		2048 1024	4096 2048	0 0 9784600
3	38984440000	4322000	Green Yellow		2048 1024	4096 2048	0
4	99281660K	11271000	Green Yellow	Profile	2048 1024	4096 2048	3053753 0 0
5	39760160000	4408000	Green Yellow	Profile	2048 1024	4096 2048	9581600 0 0
6	39642900000	4395000	Green Yellow Out of	Profile	2048 1024	4096 2048	3070671 0 0 3026100
7	99274410K	11270177	Green Yellow		2048 1024	4096 2048	0
FTOS#			Out of	Prolile			9273402

Table 31-11. show queue statistics egress Command Fields

Field	Description	
Egress Port Queue#	Egress Port Queue Number	
Queued bytes	Cumulative byte count in that queue	
Queued packets	Cumulative packet count in that queue.	
Packet type	Green, yellow, and out-of-profile packets	
Min KB	Minimum threshold for WRED queue	
Max KB	Maximum threshold for WRED queue	
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile	

Example 2 Figure 31-24. show queue statistics egress multicast Command Output




Table 31-12. show queue statistics egress multicast Command Fields

Field	Description	
Packet type	Green, yellow, and out-of-profile packets	
Min KB	Minimum threshold for WRED queue	
Max KB	Maximum threshold for WRED queue	
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile	

Example 3 Figure 31-25. show queue statistics egress brief Command Output

LC	Portpipe PortPipe	Port	Dropped packets
0	0	0	0
0	0	1	0
0	0	2	0
0	0	3	0
0	0	4	0
0	0	5	0
0	0	6	0
0	0	7	0
0	0	8	0
0	0	9	0
0	0	10	0
0	0	11	0
0	0	M	0
0	1	0	0
0	1	1	0
0	1	2	0
0	1	3	0
0	1	4	0
0	1	5	0
0	1	6	0
0	1	7	0
0	1	8	0
0	1	9	0
0	1	10	0
0	1	11	0
0	1	M	0
1 FTOS#	0	0	0

Table 31-13. show queue statistics egress brief Command Fields

Field	Description	
LC	Line Card	
Portpipe	Portpipe number	
Port	Port Queue. Where M is Multicast queue	
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile	

Related Commands

clear queue statistics egress	Clear egress queue statistics.
clear queue statistics ingress	Clear ingress queue statistics.
show queue statistics ingress	Display ingress queue statistics

show queue statistics ingress

E Display the ingress queue statistics.

Syntax

show queue statistics ingress [unicast [src-card ID [dst-card ID]] | [multicast] [src-card ID]] [brief]

Parameters

unicast [src-card ID [dst-card ID]]	(OPTIONAL) Enter the keyword unicast to display Unicast queue statistics. Optionally, enter the source card identification (src-card <i>ID</i>) and the destination card identification (dst-card <i>ID</i>) to display the unicast statistics from the source card to the destination card. Destination card Identification: Range 0 to 13 or RPM
multicast [src-card ID]	(OPTIONAL) Enter the keyword multicast to display only Multicast queue statistics. Optionally, enter the source card identification (src-card <i>ID</i>) to display the multicast statistics from the source card. Default: Both Unicast and Multicast queue statistics are displayed.
brief	(OPTIONAL) Enter the keyword brief to display only ingress per link buffering and egress per port buffering statistics.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

|--|--|

Usage Information

TeraScale systems display cumulative queued bytes (in KB), cumulative queued packets (in KB), and cumulative dropped packets (in KB).

The display area is limited to 80 spaces to accommodate the screen and for optimal readability. Numbers, that is values, are limited to 12 characters. The conventions are detailed in the following table.

Table 31-14. Numbering Conventions for show queue statistics ingress Output

Value	Divide the number by	Quotient Display	Examples	
(10^11) - (10^14)	1024	K	12345678901 K	
(10^14) - (10^17)	1024*1024	M	12345678901 M	
> (10^17)	1024*1024*1024	Т	12345678901 T	



Note: The **show queue statistics** command displays Queued Packets and Queued Bytes. The show gos statistics command displays Matched Packets and Matched Bytes. The following example explains how these two displays relate to each other.

- 9000 byte size packets are sent from Interface A to Interface B.
- The Matched Packets on Interface A are equal to the Queued Packets on Interface B.
- Matched bytes on Interface A = matched packets *9000
- Queued bytes on Interface B = queued packets *(9020)—Each packet has an additional header of 20 bytes.

Figure 31-26. show queue statistics ingress Command Partial

FTOS#show	queue statistics			card 7 dst-card 3	
Linecard 7	port pipe 0, to	linecard 3	port pipe	e 0, unicast	
SF Ingress	Packet Type	Min KB	Max KB	Dropped packets	
Queue# 0	Green Yellow	4096 3276	4096 3276	0	
1	Out of Profile Green	4096	4096	0	
2	Yellow Out of Profile Green	3276 4096	3276 4096	0 0 0	
2	Yellow Out of Profile	3276	3276	0	
3	Green Yellow	4096 3276	4096 3276	0	
4	Out of Profile Green Yellow	4096 3276	4096 3276	0 0 0	
5	Out of Profile Green	4096	4096	0	
6	Yellow Out of Profile Green	3276 4096	3276 4096	0 0 0	
	Yellow Out of Profile	3276	3276	0	
7	Green Yellow Out of Profile	4096 3276	4096 3276	0 0 0	
Linecard 7 SF Ingress	port pipe 0, to Packet Type	linecard 3 Min KB	port pipe Max KB		
Queue#	Green	4096	4096	0	
	Yellow Out of Profile	3276	3276	0 0	
1	Green Yellow Out of Profile	4096 3276	4096 3276	0 0 0	
2	Green Yellow	4096 3276	4096 3276	0	
3	Out of Profile Green Yellow	4096 3276	4096 3276	0 0 0	
4	Out of Profile Green	4096	4096	0	
5	Yellow Out of Profile Green	3276 4096	3276 4096	0 0 0	
	Yellow Out of Profile	3276	3276	0	
6	Green Yellow Out of Profile	4096 3276	4096 3276	0 0 0	
7	Green Yellow	4096 3276	4096 3276	0 0	
4	Out of Profile Green Yellow	4096 3276	4096 3276	0 0 0	
5	Out of Profile Green	4096	4096	0	
6	Yellow Out of Profile Green	3276 4096	3276 4096	0 0 0	
7	Yellow Out of Profile	3276	3276	0	
7	Green Yellow Out of Profile (4096 3276)	4096 3276	0	
\					,

Table 31-15. show queue statistics Command Fields

Field	Description	
SF Ingress Queue #	Switch Fabric Queue Number	
Packet type	Green, yellow, and out-of-profile packets	
Min KB	Minimum threshold for WRED queue	
Max KB	Maximum threshold for WRED queue	
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile	

Example 2 Figure 31-27. show queue statistics ingress Multicast Command Output

FTOS#show	queue statistics	ingress mu	ılticast sr	c-card 7
inecard 7	7 port pipe 0, mul	lticast		
SF	Packet Type	Min	Max	Dropped
	racket Type	KB	KB	
Ingress		VP	VP	packets
Queue#	G	4006	4006	0
0	Green	4096	4096	0
	Yellow	3276	3276	0
_	Out of Profile			0
1	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
2	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
3	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
4	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
5	Green	4096	4096	0
-	Yellow	3276	3276	0
	Out of Profile	3270	5270	0
5	Green	4096	4096	0
0	Yellow	3276	3276	0
		32/6	32/6	
-	Out of Profile	4006	1006	0
7	Green	4096	4096	0
	Yellow Out of Profile	3276	3276	0
Linecard 5	7 port pipe 1, mul	lticast		O
				_ ,
SF	Packet Type	Min	Max	Dropped
Ingress		KB	KB	packets
Queue#				
)	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
L	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
2	Green	4096	4096	0
=	Yellow	3276	3276	0
	Out of Profile	3270	5270	0
	Green	4096	4096	0
3				0
	Yellow	3276	3276	
4	Out of Profile	4006	4006	0
4	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
5	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
	Green	4096	4096	0
	Yellow	3276	3276	0
	Out of Profile			0
7		4096	4096	0
7	Green	4096 3276	4096 3276	0
,		4096 3276	4096 3276	0 0 0

Table 31-16. show queue statistics ingress Multicast Command Fields

Field	Description
SF Ingress Queue #	Switch Fabric Queue Number
Packet type	Green, yellow, and out-of-profile packets
Min KB	Minimum threshold for WRED queue
Max KB	Maximum threshold for WRED queue
Dropped Pkts	The number of packets dropped for green, yellow and out-of-profile

Example 3 Figure 31-28. show queue statistics ingress brief Command Output




Table 31-17. show queue statistics ingress brief Command Fields

Field	Description
Dest LC	Destination Line Card
Src Port Set	Source PortPipe Number
Dest Port Set	Destination PortPipe Number
Dropped Pkts	The number of packets dropped

Related Commands

clear queue statistics egress	Clear egress queue statistics.
clear queue statistics ingress	Clear ingress queue statistics.
show queue statistics ingress	Display egress queue statistics

Router Information Protocol (RIP)

Overview

Router Information Protocol (RIP) is a Distance Vector routing protocol. FTOS supports both RIP version 1 (RIPv1) and RIP version 2 (RIPv2) on C-Series and E-Series and S-Series systems, as indicated by the characters that appear below each command heading:

- C-Series: C
- E-Series: (E)
- S-Series: S



Note: The C-Series platform supports RIP with FTOS version 7.6.1.0 and later. The S-Series platform supports RIP with FTOS version 7.8.1.0 and later. Prior to 7.6.1.0, only the E-Series platform supported RIP.

The FTOS implementation of RIP is based on IETF RFCs 2453 and RFC 1058. For more information on configuring RIP, refer to FTOS Configuration Guide.

Commands

The following commands enable you to configure RIP:

- auto-summary
- clear ip rip
- debug ip rip
- default-information originate
- default-metric
- description
- distance
- distribute-list in
- distribute-list out
- ip poison-reverse
- ip rip receive version
- ip rip send version
- ip split-horizon
- maximum-paths
- neighbor
- network
- offset-list

- output-delay
- passive-interface
- redistribute
- redistribute isis
- · redistribute ospf
- router rip
- show config
- show ip rip database
- show running-config rip
- timers basic
- version

auto-summary

CES

Restore the default behavior of automatic summarization of subnet routes into network routes. This command applies only to RIP version 2.

Syntax auto-summary

To send sub-prefix routing information, enter **no auto-summary**.

Default Enabled.

Command Modes ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

clear ip rip

CES

Update all the RIP routes in the FTOS routing table.

Syntax clear ip rip

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

This command triggers updates of the main RIP routing tables.

debug ip rip

Examine RIP routing information for troubleshooting.

Syntax

debug ip rip [interface | database | events [interface] | packet [interface] | trigger]

To turn off debugging output, use the **no debug ip rip** command.

Parameters

interface	(OPTIONAL) Enter the interface type and ID as one of the following:
mondo	 For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale, 1-128 on C-Series and S-Series.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
	Note: This option is available only on E-Series when entered as a standalone option. It is available on both C-Series and E-Series as a sub-option.
database	(OPTIONAL) Enter the keyword database to display messages when there is a change to the RIP database.
events	(OPTIONAL) Enter the keyword events to debug only RIP protocol changes.
packet	(OPTIONAL) Enter the keyword events to debug only RIP protocol packets.
	Note: This option is available only on C-Series.
trigger	(OPTIONAL) Enter the keyword trigger to debug only RIP trigger extensions.

Command Modes

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

default-information originate

CES

Generate a default route for the RIP traffic.

Syntax

default-information originate [always] [metric metric-value] [route-map map-name]

To return to the default values, enter **no default-information originate**.

Parameters

always	(OPTIONAL) Enter the keyword always to enable the switch software to
	always advertise the default route.

metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number as the metric value. Range: 1 to 16
	Default: 1
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route-map.

Defaults

Disabled.

metric: 1

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

The default route must be present in the switch routing table for the default-information originate command to take effect.

default-metric

CES

Change the default metric for routes. Use this command with the **redistribute** command to ensure that all redistributed routes use the same metric value.

Syntax

default-metric number

To return the default metric to the original values, enter **no default-metric**.

Parameters

number	Specify a number.
	Range: 1 to 16.
	The default is 1.

Default

1

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

This command ensures that route information being redistributed is converted to the same metric value.

Related Commands

redistribute	Allows you to redistribute routes learned by other methods.	

description

CES

Enter a description of the RIP routing protocol

Syntax

description { description}

To remove the description, use the **no description** { description} command.

Parameters

Defaults

No default behavior or values

Command Modes

ROUTER RIP

Command **History**

uced on S-Series
uced on C-Series
uced on E-Series

Related **Commands**

distance



Assign a weight (for prioritization) to all routes in the RIP routing table or to a specific route. Lower weights ("administrative distance") are preferred.

Syntax

distance weight [ip-address mask [prefix-name]]

To return to the default values, use the **no distance** weight [ip-address mask] command.

Parameters

weight	Enter a number from 1 to 255 for the weight (for prioritization).
	The default is 120.
ip-address	(OPTIONAL) Enter the IP address, in dotted decimal format (A.B.C.D), of the host or network to receive the new distance metric.
mask	If you enter an IP address, you must also enter a mask for that IP address, in either dotted decimal format or /prefix format $(/x)$
prefix-name	(OPTIONAL) Enter a configured prefix list name.

Defaults

weight = 120

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
default-metric	Assign one distance metric to all routes learned using the redistribute command.

distribute-list in

CES

Configure a filter for incoming routing updates.

Syntax

distribute-list prefix-list-name in [interface]

To delete the filter, use the **no distribute-list** *prefix-list-name* **in** command.

Parameters

prefix-list-name	Enter the name of a configured prefix list.
interface	(OPTIONAL) Identifies the interface type slot/port as one of the following:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a Port Channel, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale, 1-128 on C-Series and S-Series.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.

Defaults

Not configured.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.8.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	
pre-Version 6.2.1.1	Introduced on E-Series	
ip prefix-list	Enter the PREFIX-LIST mode and configure a prefix list.	

Related Commands

distribute-list out

CES

Configure a filter for outgoing routing updates.

Syntax

distribute-list prefix-list-name out [interface | bgp | connected | isis | ospf | static]

To delete the filter, use the **no distribute-list** *prefix-list-name* **out** command.

Parameters

prefix-list-name	Enter the name of a configured prefix list.
interface	(OPTIONAL) Identifies the interface type slot/port as one of the following:
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For a Port Channel, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale, 1-128 on C-Series and S-Series.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.
connected	(OPTIONAL) Enter the keyword connected to filter only directly connected routes.
isis	(OPTIONAL) Enter the keyword isis to filter only IS-IS routes.
	Note: This option is only available on E-Series.
ospf	(OPTIONAL) Enter the keyword ospf to filter all OSPF routes.
static	(OPTIONAL) Enter the keyword Static to filter manually configured routes.

Defaults

Not configured.

Command Modes

ROUTER RIP

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
ip prefix-list	Enter the PREFIX-LIST mode and configure a prefix list.

Related Commands

ip poison-reverse CES Set the pref

Set the prefix of the RIP routing updates to the RIP infinity value.

Syntax

ip poison-reverse

To disable poison reverse, enter **no ip poison-reverse**.

Defaults

Disabled.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

ip split-horizon	Set RIP routing updates to exclude routing prefixes.

ip rip receive version

CES

Set the interface to receive specific versions of RIP. The RIP version you set on the interface overrides the version command in the ROUTER RIP mode.

Syntax ip rip receive version [1] [2]

To return to the default, enter **no ip rip receive version**.

Parameters

1	(OPTIONAL) Enter the number 1 for RIP version 1.
2	(OPTIONAL) Enter the number 2 for RIP version 2.

Defaults RIPv1 and RIPv2.

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

If you want the interface to receive both versions of RIP, enter ip rip receive version 1 2.

Related Commands

ip rip send version	Sets the RIP version to be used for sending RIP traffic on an interface.
version	Sets the RIP version to be used for the switch software.

ip rip send version

CES

Set the interface to send a specific version of RIP. The version you set on the interface overrides the version command in the ROUTER RIP mode.

Syntax ip rip send version [1] [2]

To return to the default value, enter **no ip rip send version**.

Parameters

1	(OPTIONAL) Enter the number 1 for RIP version 1.
	The default is RIPv1.
2	(OPTIONAL) Enter the number 2 for RIP version 2.

Defaults RIPv1.

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

To enable the interface to send both version of RIP packets, enter ip rip send version 1 2.

Related **Commands**

ip rip receive version	Sets the RIP version for the interface to receive traffic.
version	Sets the RIP version to be used for the switch software.

ip split-horizon

CES

Enable split-horizon for RIP data on the interface. As described in RFC 2453, the split-horizon scheme prevents any routes learned over a specific interface to be sent back out that interface.

Syntax ip split-horizon

To disable split-horizon, enter no ip split-horizon.

Defaults Enabled

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

ip poison-reverse	Set the prefix for RIP routing updates.	

maximum-paths

Syntax

CES Set RIP to forward packets over multiple paths.

maximum-paths number

To return to the default values, enter **no maximum-paths**.

Parameters

number	Enter the number of paths.
	Range: 1 to 16.
	The default is 4 paths.

Defaults 4

Command Modes ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

RIP supports a maximum of 16 ECMP paths.

neighbor

CES

Define a neighbor router with which to exchange RIP information.

Syntax neighbor ip-address

To delete a neighbor setting, use the **no neighbor** *ip-address* command.

Parameters

ip-address	Enter the IP address, in dotted decimal format, of a router with which to exchange
	information.

Defaults

Not configured.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

When a neighbor router is identified, unicast data exchanges occur. Multiple neighbor routers are possible.

Use the passive-interface command in conjunction with the neighbor command to ensure that only specific interfaces are receiving and sending data.

Related Commands

passive-interface Sets the interface to only listen to RIP broadcasts.	to RIP broadcasts.
--	--------------------

network

CES

Enable RIP for a specified network. Use this command to enable RIP on all networks connected to the switch.

Syntax network ip-address

To disable RIP for a network, use the **no network** *ip-address* command.

Parameter

ip-address Specify an IP network address in dotted decimal format. You cannot specify a subnet.

Defaults

No RIP network is configured.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

You can enable an unlimited number of RIP networks.

RIP operates over interfaces configured with any address specified by the network command.

offset-list



Specify a number to add to the incoming or outgoing route metrics learned via RIP.

Syntax

offset-list prefix-list-name {in | out} offset [interface]

To delete an offset list, use the **no offset-list** prefix-list-name {in | out} offset [interface] command.

Parameters

prefix-list-name	Enter the name of an established Prefix list to determine which incoming routes will be modified.	
offset	Enter a number from zero (0) to 16 to be applied to the incoming route metric matching the access list specified.	
	If you set an offset value to zero (0), no action is taken.	
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:	
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information. 	
	• For a Port Channel interface, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale.	
	 For a SONET interface, enter the keyword sonet followed by the slot/port information. 	
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.	
	• For a VLAN, enter the keyword vlan followed by a number from 1 to 4094.	

Defaults

Not configured.

Command Modes

ROUTER RIP

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

When the offset metric is applied to an interface, that value takes precedence over an offset value that is not extended to an interface.

Related Commands

ip prefix-list	Enter the PREFIX-LIST mode and configure a prefix list.
----------------	---

output-delay

C E S Set the interpacket delay of successive packets to the same neighbor.

Syntax output-delay delay

To return to the switch software defaults for interpacket delay, enter **no output-delay**.

Parameters

delay Specify a number of milliseconds as the delay interval.

Range: 8 to 50.

Default Not configured.

Command Modes ROUTER RIP

Command History

Version 8.3.3.1 Introduced on S60

Version 7.8.1.0 Introduced on S-Series

Version 7.6.1.0 Introduced on C-Series

pre-Version 6.2.1.1 Introduced on E-Series

Usage Information This command is intended for low-speed interfaces.

passive-interface

CES Suppress routing updates on a specified interface.

Syntax passive-interface interface

To delete a passive interface, use the **no passive-interface** interface command.

Parameters

interface Enter the following information: For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.

- For a Port Channel, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale, 1-128 on C-Series and S-Series.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For a VLAN, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults Not configured.

Command Modes ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.8.1.0	Introduced on S-Series	

Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

Although the passive interface will neither send nor receive routing updates, the network on that interface will still be included in RIP updates sent via other interfaces.

Related Commands

neighbor	Enable RIP for a specified network.
network	Define a neighbor.

redistribute

CES

Redistribute information from other routing instances.

Syntax

redistribute {connected | static}

To disable redistribution, use the **no redistribute** {connected | static} command.

Parameters

connected	Enter the keyword connected to specify that information from active routes on interfaces is redistributed.
static	Enter the keyword static to specify that information from static routes is redistributed.

Defaults

Not configured.

Command Modes

ROUTER RIP

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

To redistribute the default route (0.0.0.0/0), configure the default-information originate command.

Related **Commands**

default-information	Generate a default route for RIP traffic.
originate	

redistribute isis

Redistribute routing information from an IS-IS instance. [E]

Syntax

redistribute isis [tag] [level-1 | level-1-2 | level-2] [metric metric-value] [route-map map-name]

To disable redistribution, use the no redistribute isis [tag] [level-1 | level-1-2 | level-2] [metric metric-value] [route-map map-name] command.

Parameters

tag	(OPTIONAL) Enter the name of the IS-IS routing process.	
level-1	(OPTIONAL) Enter the keyword level-1 to redistribute only IS-IS Level-1 routes.	
level-1-2	(OPTIONAL) Enter the keyword level-1-2 to redistribute both IS-IS Level-1 and Level-2 routes.	
level-2	(OPTIONAL) Enter the keyword level-2 to redistribute only IS-IS Level-2 routes.	
metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number as the metric value. Range: 0 to16	
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.	
	·	

Defaults

Not configured.

Command Modes

ROUTER RIP

Command History

pre-Version 6.2.1.1	Introduced on E-Series	
1		

Usage Information IS-IS is not supported on S-Series systems.

redistribute ospf

CES

Redistribute routing information from an OSPF process.

Syntax

redistribute ospf process-id [match external $\{1 \mid 2\} \mid match internal \mid metric \textit{metric-value}\}$ [route-map map-name]

To disable redistribution, enter no redistribute ospf process-id [match external {1 | 2} | match internal | metric metric-value] [route-map map-name] command.

Parameters

process-id	Enter a number that corresponds to the OSPF process ID to be redistributed. Range: 1 to 65355.
match external {1 2}	(OPTIONAL) Enter the keywords match external followed by the numbers 1 or 2 to indicated that external 1 routes or external 2 routes should be redistributed.
match internal	(OPTIONAL) Enter the keywords match internal to indicate that internal routes should be redistributed.
metric metric-value	(OPTIONAL) Enter the keyword metric followed by a number as the metric value. Range: 0 to 16
route-map map-name	(OPTIONAL) Enter the keyword route-map followed by the name of a configured route map.

Defaults

Not configured.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

router rip

CES

Enter the ROUTER RIP mode to configure and enable RIP.

Syntax

router rip

To disable RIP, enter **no router rip**.

Defaults

Disabled.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information To enable RIP, you must assign a network address using the network command.

Example

Figure 32-1. router rip Command Example

```
FTOS(conf)#router rip
FTOS(conf-router_rip)#
```

Related Commands

network	Enable RIP.
exit	Return to the CONFIGURATION mode.

show config

CES

Display the changes you made to the RIP configuration. Default values are not shown.

Syntax

show config

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example Figure 32-2. show config Command Example in ROUTER RIP Mode

```
FTOS(conf-router_rip) #show config
!
router rip
network 172.31.0.0
passive-interface GigabitEthernet 0/1
FTOS(conf-router_rip)#
```

show ip rip database

CES

Display the routes learned by RIP. If the switch learned no RIP routes, no output is generated.

Syntax

show ip rip database [ip-address mask]

Parameters

ip-address	(OPTIONAL) Specify an IP address in dotted decimal format to view RIP information on that network only. If you enter an IP address, you must also enter a mask for that IP address.
mask	(OPTIONAL) Specify a mask, in /network format, for the IP address.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 32-3. show ip rip database Command Example (partial)

```
FTOS#show ip rip database
Total number of routes in RIP database: 1624
204.250.54.0/24
          [50/1] via 192.14.1.3, 00:00:12, GigabitEthernet 9/15
204.250.54.0/24
                              auto-summary
203.250.49.0/24
          [50/1] via 192.13.1.3, 00:00:12, GigabitEthernet 9/14
203.250.49.0/24
                              auto-summary
210.250.40.0/24
          [50/2] via 1.1.18.2, 00:00:14, Vlan 18
[50/2] via 1.1.130.2, 00:00:12, Port-channel 30
210.250.40.0/24
                              auto-summarv
207.250.53.0/24
          [50/2] via 1.1.120.2, 00:00:55, Port-channel 20
          [50/2] via 1.1.130.2, 00:00:12, Port-channel 30 [50/2] via 1.1.10.2, 00:00:18, Vlan 10
207.250.53.0/24
                              auto-summary
208.250.42.0/24
          [50/2] via 1.1.120.2, 00:00:55, Port-channel 20 [50/2] via 1.1.130.2, 00:00:12, Port-channel 30 [50/2] via 1.1.10.2, 00:00:18, Vlan 10
208.250.42.0/24
                              auto-summary
```

Table 32-1. Fields in show ip rip database Command Output

Field	Description
Total number of routes in RIP database	Displays the number of RIP routes stored in the RIP database.
100.10.10.0/24 directly connected	Lists the route(s) directly connected.
150.100.0.0 redistributed	Lists the routes learned through redistribution.
209.9.16.0/24	Lists the routes and the sources advertising those routes.

show running-config rip

CES Use this feature to display the current RIP configuration.

Syntax show running-config rip

Defaults No default values or behavior

Command Modes EXEC Privilege

Example Figure 32-4. show running-config rip Command Example

```
show running-config rip
router rip
 distribute-list Test1 in
distribute-list Test21 out
 network 10.0.0.0
 passive-interface GigabitEthernet 2/0
 neighbor 20.20.20.20
 redistribute ospf 999
 version 2
```

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.8.1.0	Introduced on S-Series	
Version 7.7.1.0	Introduced on C-Series	
Version 7.6.1.0	Introduced on E-Series	

timers basic

CES Manipulate the RIP timers for routing updates, invalid, holddown times and flush time.

Syntax timers basic update invalid holddown flush

To return to the default settings, enter **no timers basic**.

Parameters

update	Enter the number of seconds to specify the rate at which RIP routing updates are sent.
	Range: zero (0) to 4294967295.
	Default: 30 seconds.
invalid	Enter the number of seconds to specify the time interval before routing updates are declared invalid or expired. The <i>invalid</i> value should be at least three times the <i>update</i> timer value.
	Range: zero (0) to 4294967295.
	Default: 180 seconds.
holddown	Enter the number of seconds to specify a time interval during which the route is marked as unreachable but still sending RIP packets. The <i>holddown</i> value should be at least three times the <i>update</i> timer value.
	Range: zero (0) to 4294967295.
	Default: 180 seconds.
flush	Enter the number of seconds to specify the time interval during which the route is advertised as unreachable. When this interval expires, the route is flushed from the routing table. The <i>flush</i> value should be greater than the <i>update</i> value.
	Range: zero (0) to 4294967295.
	Default is 240 seconds.

Defaults

update = 30 seconds; invalid = 180 seconds; holddown = 180 seconds; flush = 240 seconds.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

If the timers on one router are changed, the timers on all routers in the RIP domain must also be synchronized.

version

CES

Specify either RIP version 1 or RIP version 2.

Syntax

version $\{1 \mid 2\}$

To return to the default version setting, enter **no version**.

Parameters

1	Enter the keyword 1 to specify RIP version 1.
2	Enter the keyword 2 to specify RIP version 2.

Default

The FTOS sends RIPv1 and receives RIPv1 and RIPv2.

Command Modes

ROUTER RIP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

ip rip receive version	Set the RIP version to be received on the interface.
ip rip send version	Set the RIP version to be sent out the interface.

Remote Monitoring (RMON)

Overview

FTOS RMON is implemented on all Dell Networking switching platforms (C-Series, E-Series, and S-Series), as indicated by the characters that appear below each command heading:

- C-Series: [C]
- E-Series: [E]
- S-Series: [S]

FTOS RMON is based on IEEE standards, providing both 32-bit and 64-bit monitoring, and long-term statistics collection. FTOS RMON supports the following RMON groups, as defined in RFC-2819, RFC-3273, and RFC-3434:

•	Ethernet Statistics Table	RFC-2819
•	Ethernet Statistics High-Capacity Table	RFC-3273, 64bits
•	Ethernet History Control Table	RFC-2819
•	Ethernet History Table	RFC-2819
•	Ethernet History High-Capacity Table	RFC-3273, 64bits
•	Alarm Table	RFC-2819
•	High-Capacity Alarm Table (64bits)	RFC-3434, 64bits
•	Event Table	RFC-2819
•	Log Table	RFC-2819

FTOS RMON does not support the following statistics:

- etherStatsCollisions
- etherHistoryCollisions
- etherHistoryUtilization



Note: Only SNMP GET/GETNEXT access is supported. Configure RMON using the RMON commands. Collected data is lost during a chassis reboot.

Commands

The FTOS Remote Network Monitoring RMON commands are:

- rmon alarm
- rmon collection history
- rmon collection statistics
- rmon event

- rmon hc-alarm
- show rmon
- show rmon alarms
- show rmon events
- show rmon hc-alarm
- show rmon history
- show rmon log
- show rmon statistics

rmon alarm

CES

Set an alarm on any MIB object.

Syntax

rmon alarm number variable interval {delta | absolute} rising-threshold value event-number falling-threshold value event-number [owner string]

To disable the alarm, use the **no rmon alarm** *number* command.

Parameters

number	Enter the alarm integer number from 1 to 65535. The value must be unique in the RMON Alarm Table.
variable	The MIB object to monitor. The variable must be in the SNMP OID format, for example, 1.3.6.1.2.1.1.3 The object type must be a 32 bit integer.
interval	Time, in seconds, the alarm monitors the MIB variables; this is the alarmSampleType in the RMON Alarm table.
	Range: 5 to 3600 seconds
delta	Enter the keyword delta to test the change between MIB variables. This is the alarmSampleType in the RMON Alarm table.
absolute	Enter the keyword absolute to test each MIB variable directly. This is the alarmSampleType in the RMON Alarm table.
rising-threshold value event-number	Enter the keyword rising-threshold followed by the value (32bit) the rising-threshold alarm is either triggered or reset. Then enter the event-number to trigger when the rising threshold exceeds its limit. This value is the same as the alarmRisingEventIndex or alarmTable of the RMON MIB. If there is no corresponding rising-threshold event, the value is zero.
falling-threshold value event-number	Enter the keyword falling-threshold followed by the value (32bit) the falling-threshold alarm is either triggered or reset. Then enter the event-number to trigger when the falling threshold exceeds its limit.
	This value is the same as the alarmFallingEventIndex or the alarmTable of the RMON MIB. If there is no corresponding falling-threshold event, the value is zero.
owner string	(OPTIONAL) Enter the keyword Owner followed by the owner name to specify an owner for the alarm. This is the alarmOwner object in the alarmTable of the RMON MIB.

Default

owner

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

rmon collection history

Enable the RMON MIB history group of statistics collection on an interface. CES

Syntax rmon collection history {controlEntry integer} [owner name] [buckets number] [interval seconds]

> To remove a specified RMON history group of statistics collection, use the **no rmon collection** history {controlEntry integer} command.

Parameters

controlEntry integer	Enter the keyword controlEntry to specify the RMON group of statistics using a value. Then enter an integer value from 1 to 65535 that identifies the RMON group of statistics. The integer value must be a unique index in the RMON History Table.
owner name	(OPTIONAL) Enter the keyword owner followed by the owner name to record the owner of the RMON group of statistics.
buckets number	(OPTIONAL) Enter the keyword buckets followed the number of buckets for the RMON collection history group of statistics. Bucket Range: 1 to 1000 Default: 50
interval seconds	(OPTIONAL) Enter the keyword interval followed the number of seconds in each polling cycle. Range: 5 to 3600 seconds Default: 1800 seconds

Defaults No default behavior

Command Modes

CONFIGURATION INTERFACE (config-if)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

rmon collection statistics

CES Enable RMON MIB statistics collection on an interface.

Syntax rmon collection statistics {controlEntry integer} [owner name]

To remove RMON MIB statistics collection on an interface, use the no rmon collection statistics {controlEntry integer} command.

Pa	ra	m	et	ei	s

controlEntry integer	Enter the keyword controlEntry to specify the RMON group of statistics using a value. Then enter an integer value from 1 to 65535 that identifies the RMON Statistic Table. The integer value must be a unique in the RMON Statistic Table.
owner name	(OPTIONAL) Enter the keyword Owner followed by the owner name to record the owner of the RMON group of statistics.

Defaults

No default behavior

Command Modes

CONFIGURATION INTERFACE (config-if)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

rmon event

CES

Add an event in the RMON event table.

Syntax

rmon event number [log] [trap community] [description string] [ownername]

To disable RMON on an interface, use the **no rmon event** *number* [**log**] [**trap** *community*] [**description** *string*] command.

Parameters

number	Assign an event number in integer format from 1 to 65535. The number value must be unique in the RMON Event Table.
log	(OPTIONAL) Enter the keyword log to generate an RMON log entry. The log entry is triggered and sets the eventType in the RMON MIB to log or log-and-trap. Default: No log
trap community	(OPTIONAL) Enter the keyword trap followed by an SNMP community string to configure the eventType setting in the RMON MIB. This sets either snmp-trap or log-and-trap. Default: public
description string	(OPTIONAL) Enter the keyword description followed by a string describing the event.
owner name	(OPTIONAL) Enter the keyword owner followed by the name of the owner of this event.

Defaults

as described above

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

rmon hc-alarm

CES

Set an alarm on any MIB object.

Syntax

rmon hc-alarm number variable interval {delta | absolute} rising-threshold value event-number falling-threshold value event-number [owner string]

To disable the alarm, use the **no rmon hc-alarm** *number* command.

Parameters

number	Enter the alarm integer number from 1 to 65535. The value must be unique in the RMON Alarm Table.
variable	The MIB object to monitor. The variable must be in the SNMP OID format, for example, 1.3.6.1.2.1.1.3 The object type must be a 64 bit integer.
interval	Time, in seconds, the alarm monitors the MIB variables; this is the alarmSampleType in the RMON Alarm table.
	Range: 5 to 3600 seconds
delta	Enter the keyword delta to test the change between MIB variables. This is the alarmSampleType in the RMON Alarm table.
absolute	Enter the keyword absolute to test each MIB variable directly. This is the alarmSampleType in the RMON Alarm table.
rising-threshold value event-number	Enter the keyword rising-threshold followed by the value (64 bit) the rising-threshold alarm is either triggered or reset. Then enter the event-number to trigger when the rising threshold exceeds its limit. This value is the same as the alarmRisingEventIndex or alarmTable of the RMON MIB. If there is no corresponding rising-threshold event, the value is zero.
falling-threshold value event-number	Enter the keyword falling-threshold followed by the value (64 bit) the falling-threshold alarm is either triggered or reset. Then enter the event-number to trigger when the falling threshold exceeds its limit. This value is the same as the alarmFallingEventIndex or the alarmTable of the RMON MIB. If there is no corresponding falling-threshold event, the value is zero.
owner string	(OPTIONAL) Enter the keyword owner followed the owner name to specify an owner for the alarm. This is the alarmOwner object in the alarmTable of the RMON MIB.
-	

Defaults

owner

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

show rmon

CES

Display the RMON running status including the memory usage.

Syntax

show rmon

Defaults No default behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Example Figure 33-1. show rmon Command Example

```
FTOS# show rmon
RMON status

total memory used 218840 bytes.
ether statistics table: 8 entries, 4608 bytes
ether history table: 8 entries, 6000 bytes
alarm table: 390 entries, 102960 bytes
high-capacity alarm table: 5 entries, 1680 bytes
event table: 500 entries, 206000 bytes
log table: 2 entries, 552 bytes
FTOS#
```

show rmon alarms

CES

Display the contents of the RMON Alarm Table.

Syntax show rmon alarms [index] [brief]

Parameters

index	(OPTIONAL) Enter the table index number to display just that entry.	
brief	(OPTIONAL) Enter the keyword brief to display the RMON Alarm Table in an easy-to-read format.	

Defaults No default behavior

Command Modes EXEC


Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Example 1 Figure 33-2. show rmon alarms index Command Example

```
FTOS#show rmon alarm 1
RMON alarm entry 1
sample Interval: 5
object: 1.3.6.1.2.1.1.3
sample type: absolute value.
value: 255161
alarm type: rising or falling alarm.
rising threshold: 1, RMON event index: 1
falling threshold: 501, RMON event index: 501
alarm owner: 1
alarm status: OK
FTOS#
```

Example 2 Figure 33-3. show rmon alarms brief Command Example



show rmon events

CES Display the contents of RMON Event Table.

Syntax show rmon events [index] [brief]

Parameters

index	(OPTIONAL) Enter the table index number to display just that entry.
brief	(OPTIONAL) Enter the keyword brief to display the RMON Event Table in an easy-to-read format.

Defaults No default behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Example 1 Figure 33-4. show rmon event index Command Example

```
FTOS#show rmon event 1
RMON event entry 1 description: 1
     event type: LOG and SNMP TRAP.
     event community: public event last time sent: none
     event owner: 1
     event status: OK
FTOS#
```

Example 2 Figure 33-5. show rmon event brief Command Example

	description	
1	1	
2	2 3	
3	3	
4	4 5	
5	5	
6	6 7	
7	7	
8	8	
9	9	
10	10	
11	11	
12	12	
13	13	
14	14	
15	15	
16	16	
17	17	
18	18	
19	19	
20	20	
21	21	
22	22	
FTOS#		

show rmon hc-alarm

CES Display the contents of RMON High-Capacity Alarm Table.

Syntax show rmon hc-alarm [index] [brief]

Parameters

index	(OPTIONAL) Enter the table index number to display just that entry.	
brief	(OPTIONAL) Enter the keyword brief to display the RMON High-Capacity Alarm Table in an easy-to-read format.	

Defaults

No default behavior

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Example 1 Figure 33-6. show rmon hc-alarm brief Command Example

FTOS#show index	rmon hc-alarm brief SNMP OID	
1	1.3.6.1.2.1.1.3 1.3.6.1.2.1.1.3	
3	1.3.6.1.2.1.1.3	
5	1.3.6.1.2.1.1.3 1.3.6.1.2.1.1.3	
FTOS#		/

Example 2 Figure 33-7. show rmon hc-alarm index Command Example

```
FTOS#show rmon hc-alarm 1
RMON high-capacity alarm entry 1 object: 1.3.6.1.2.1.1.3
      sample interval: 5
sample type: absolute value.
      value: 185638
      alarm type: rising or falling alarm.
alarm rising threshold value: positive.
rising threshold: 1001, RMON event index: 1
      alarm falling threshold value: positive. falling threshold: 999, RMON event index: 6
      alarm sampling failed 0 times.
      alarm owner: 1
      alarm storage type: non-volatile.
      alarm status: OK
FTOS#
```

show rmon history

CES

Display the contents of the RMON Ethernet History table.

Syntax show rmon history [index] [brief]

Parameters

index	(OPTIONAL) Enter the table index number to display just that entry.
brief	(OPTIONAL) Enter the keyword brief to display the RMON Ethernet History table in an easy-to-read format.

Defaults No default behavior

Command Modes

EXEC

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 6.1.1.0	Introduced for E-Series

Example 1 Figure 33-8. show rmon history index Command Example

```
FTOS#show rmon history 6001
RMON history control entry 6001
    interface: ifIndex.100974631 GigabitEthernet 2/0
   bucket requested: 1
   bucket granted: 1
   sampling interval: 5 sec
   owner: 1
   status: OK
FTOS#
```

Example 2 Figure 33-9. show rmon history brief Command Example

FTOS#show index	rmon history brief ifIndex	interface	
-			
6001	100974631	GigabitEthernet 2/0	
6002	100974631	GigabitEthernet 2/0	
6003	101236775	GigabitEthernet 2/1	
6004	101236775	GigabitEthernet 2/1	
9001	134529054	GigabitEthernet 3/0	
9002	134529054	GigabitEthernet 3/0	
9003	134791198	GigabitEthernet 3/1	
9004	134791198	GigabitEthernet 3/1	
FTOS#		-	

show rmon log

CES

Display the contents of RMON Log Table.

Syntax

show rmon log [index] [brief]

Parameters

index	(OPTIONAL) Enter the log index number to display just that entry.
brief	(OPTIONAL) Enter the keyword brief to display the RMON Log Table in an easy-to-read format.

Defaults

No default behavior

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Example 1 Figure 33-10. show rmon log index Command Example

```
FTOS#show rmon log 2
RMON log entry, alarm table index 2, log index 1
log time: 14638 (THU AUG 12 22:10:40 2004)
description: 2
FTOS#
```

Example 2 Figure 33-11. show rmon log brief Command Example

```
FTOS#show rmon log br
eventIndex description

2 2 4
FTOS#
```

Usage Information

The log table has a maximum of 500 entries. If the log exceeds that maximum, the oldest log entry is purged to allow room for the new entry.

show rmon statistics

CESDisplay the contents of RMON Ethernet Statistics table.

Syntax show rmon statistics [index] [brief]

Parameters

index	(OPTIONAL) Enter the index number to display just that entry.
brief	(OPTIONAL) Enter the keyword brief to display the RMON Ethernet Statistics table in an easy-to-read format.

Defaults No default behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.1.1.0	Introduced for E-Series

Figure 33-12. show rmon statistics index Command Example **Example 1**

```
FTOS#show rmon statistics 6001
RMON statistics entry 6001 interface: ifIndex.100974631 GigabitEthernet 2/0
    packets dropped: 0
    bytes received: 0
    packets received: 0
    broadcast packets: 0
    multicast packets: 0
    CRC error: 0
    under-size packets: 0
     over-size packets: 0
     fragment errors: 0
    jabber errors: 0
     collision: 0
     64bytes packets: 0
    65-127 bytes packets: 0
    128-255 bytes packets: 0
256-511 bytes packets: 0
    512-1023 bytes packets: 0
    1024-1518 bytes packets: 0
    owner: 1
    status: OK
     <high-capacity data>
    HC packets received overflow: 0
    HC packets received: 0
HC bytes received overflow: 0
    HC bytes received: 0
    HC 64bytes packets overflow: 0
    HC 64bytes packets: 0
HC 65-127 bytes packets overflow: 0
    HC 65-127 bytes packets: 0
    HC 128-255 bytes packets overflow: 0 HC 128-255 bytes packets: 0
    HC 256-511 bytes packets overflow: 0
    HC 256-511 bytes packets: 0
HC 512-1023 bytes packets overflow: 0
    HC 512-1023 bytes packets: 0
    HC 1024-1518 bytes packets overflow: 0
    HC 1024-1518 bytes packets: 0
FTOS#
```

Example 2 Figure 33-13. show rmon statistics brief Command Example

1	FTOS#show index	rmon statistics br ifIndex	interface	
	6001 6002 6003 6004 9001 9002 9003 9004	100974631 100974631 101236775 101236775 134529054 134529054 134791198	GigabitEthernet 2/0 GigabitEthernet 2/0 GigabitEthernet 2/1 GigabitEthernet 2/1 GigabitEthernet 3/0 GigabitEthernet 3/0 GigabitEthernet 3/1 GigabitEthernet 3/1 GigabitEthernet 3/1	-
1	FTOS#			

Rapid Spanning Tree Protocol (RSTP)

Overview

The FTOS implementation of RSTP (Rapid Spanning Tree Protocol) is based on the IEEE 802.1w standard spanning-tree protocol. The RSTP algorithm configures connectivity throughout a bridged LAN that is comprised of LANs interconnected by bridges.

RSTP is supported by FTOS on all Dell Networking systems, as indicated by the characters that appear below each command heading:

- C-Series: [C]
- E-Series: E
- S-Series: [S]

Commands

The FTOS RSTP commands are:

- bridge-priority
- debug spanning-tree rstp
- description
- description
- forward-delay
- hello-time
- max-age
- protocol spanning-tree rstp
- show config
- show spanning-tree rstp
- spanning-tree rstp
- tc-flush-standard

bridge-priority

Set the bridge priority for RSTP.

Syntax bridge-priority priority-value

To return to the default value, enter **no bridge-priority**.

Parameters	priority-value	Enter a number as the bridge priority value in increments of 4096.	
		Range: 0 to 61440.	
		Default: 32768	
Defaults	32768		
Command Modes	CONFIGURATIO	ON RSTP (conf-rstp)	
Command History	Version 8.3.3.1	Introduced on S60	
1	Version 7.6.1.0	Support added for S-Series	
	Version 7.5.1.0	Support added for C-Series	

Enter the Rapid Spanning Tree mode

protocol spanning-tree rstp

debug spanning-tree rstp

CES Enable debugging of RSTE Enable debugging of RSTP and view information on the protocol.

> **Syntax** debug spanning-tree rstp [all | bpdu interface {in | out} | events]

> > To disable debugging, enter **no debug spanning-tree rstp**.

Param

Related

Commands

Parameters		
Parameters	all	(OPTIONAL) Enter the keyword all to debug all spanning tree operations.
	bpdu interface (in	(OPTIONAL) Enter the keyword bpdu to debug Bridge Protocol Data Units.
	out}	(OPTIONAL) Enter the interface keyword along with the type slot/port of the interface you want displayed. Type slot/port options are the following:
		• For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
		• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
		 For Port Channel groups, enter the keyword port-channel followed by a number:
		C-Series and S-Series Range: 1-128
		E-Series Range: 1-255 for TeraScale
		 For a SONET interface, enter the keyword sonet followed by the slot/port information.
		• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
		Optionally, enter an in or out parameter in conjunction with the optional interface:
		• For Receive, enter in
		• For Transmit, enter out
	events	(OPTIONAL) Enter the keyword events to debug RSTP events.
Command Modes	EXEC Privilege	
Command History	Version 7.6.1.0 S	upport added for S-Series

Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Example

Figure 34-1. debug spanning-tree rstp bpdu Command Example

FTOS#debug spanning-tree rstp bpdu gigabitethernet 2/0 ? in Receive (in) out Transmit (out)

description

CES

Enter a description of the Rapid Spanning Tree

Syntax

description { description}

To remove the description, use the **no description** { description} command.

Parameters

description Enter a description to identify the Rapid Spanning Tree (80 characters maximum).

Defaults

No default behavior or values

Command Modes

SPANNING TREE (The prompt is "config-rstp".)

Command **History**

Version 8.3.3.1	Introduced on S60
pre-7.7.1.0	Introduced

Related Commands

disable

CES

Disable RSTP globally on the system.

Syntax

disable

To enable Rapid Spanning Tree Protocol, enter no disable.

Defaults

RSTP is disabled

Command Modes

CONFIGURATION RSTP (conf-rstp)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Related **Commands**

protocol spanning-tree rstp Enter the Rapid Spanning Tree mode

forward-delay

CES

Configure the amount of time the interface waits in the Listening State and the Learning State before transitioning to the Forwarding State.

Syntax

forward-delay seconds

To return to the default setting, enter **no forward-delay.**

Parameters

seconds	Enter the number of seconds that FTOS waits before transitioning RSTP to the forwarding state.
	Range: 4 to 30
	Default: 15 seconds

Defaults

15 seconds

Command Modes

CONFIGURATION RSTP (conf-rstp)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Related Commands

hello-time	Change the time interval between BPDUs.
max-age	Change the wait time before RSTP refreshes protocol configuration information.

hello-time

CES

Set the time interval between generation of RSTP Data Units (BPDUs).

Syntax

hello-time [milli-second] seconds

To return to the default value, enter **no hello-time**.

Parameters

seconds	Enter a number as the time interval between transmission of BPDUs.
	Range: 1 to 10 seconds
	Default: 2 seconds.
milli-second	Enter this keyword to configure a hello time on the order of milliseconds.
	Range: 50 - 950 milliseconds

Defaults

2 seconds

Command Modes

CONFIGURATION RSTP (conf-rstp)

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Added milli-second to S-Series.
Version 7.6.1.0	Support added for S-Series

Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Usage Information

The hello time is encoded in BPDUs in increments of 1/256ths of a second. The standard minimum hello time in seconds is 1 second, which is encoded as 256. Millisecond hello times are encoded using values less than 256; the millisecond hello time equals (x/1000)*256.

When millisecond hellos are configured, the default hello interval of 2 seconds is still used for edge ports; the millisecond hello interval is not used.

Related **Commands**

forward-delay	Change the wait time before RSTP transitions to the Forwarding state.
max-age	Change the wait time before RSTP refreshes protocol configuration information.

max-age



Set the time interval for the RSTP bridge to maintain configuration information before refreshing that information.

Syntax max-age seconds

To return to the default values, enter **no max-age**.

Parameters

max-age	Enter a number of seconds the FTOS waits before refreshing configuration information.
	Range: 6 to 40 seconds
	Default: 20 seconds

Defaults 20 seconds

Command Modes

CONFIGURATION RSTP (conf-rstp)

Command History

Related **Commands**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series
max-age	Change the wait time before RSTP transitions to the Forwarding state.

Change the time interval between BPDUs.

protocol spanning-tree rstp

CES

Enter the RSTP mode to configure RSTP.

Syntax protocol spanning-tree rstp

hello-time

To exit the RSTP mode, enter exit

Defaults Not configured

Command Modes CONFIGURATION RSTP (conf-rstp)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Example

Figure 34-2. protocol spanning-tree rstp Command

```
FTOS(conf) #protocol spanning-tree rstp
FTOS(config-rstp) ##no disable
```

Usage Information

RSTP is not enabled when you enter the RSTP mode. To enable RSTP globally on the system, enter no description from the RSTP mode.

Related Commands

description Disable RSTP globally on the system.

show config

CES View the current configuration for the mode. Only non-default values are displayed.

Syntax show config

Command Modes

CONFIGURATION RSTP (conf-rstp)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.2.1.1	Introduced for E-Series

Example

Figure 34-3. show config Command for the RSTP Mode

```
FTOS(conf-rstp)#show config!
protocol spanning-tree rstp
no disable
bridge-priority 16384
FTOS(conf-rstp)#
```

show spanning-tree rstp

CES Display the RSTP configuration.

Syntax show spanning-tree rstp [brief]

Parameters

brief	(OPTIONAL) Enter the keyword brief to view a synopsis of the RSTP
	configuration information.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.4.1.0	Expanded to display port error disable state (EDS) caused by loopback BPDU inconsistency
Version 6.2.1.1	Introduced for E-Series

Figure 34-4. show spanning-tree rstp brief Command Example 1

```
FTOS#show spanning-tree rstp brief
Executing IEEE compatible Spanning Tree Protocol Root ID Priority 8192, Address 0001.e805.e306
Root Bridge hello time 4, max age 20, forward delay 15
Bridge ID Priority 16384, Address 0001.e801.6aa8
Configured hello time 2, max age 20, forward delay 15
Interface
                                                         Designated
Name PortID Prio Cost Sts Cost Bridge ID PortI
                                                                           PortID
Interface
Name Role PortID Prio Cost Sts Cost Link-type Edge
Gi 4/0 Desg 128.418 128 20000 FWD 20000 P2P
Gi 4/1 Desg 128.419 128 20000 FWD 20000 P2P
Gi 4/8 Root 128.426 128 20000 FWD 20000 P2P
Gi 4/9 Altr 128.427 128 20000 BLK 20000 P2P
                                                                        Yes
                                                                        Yes
                                                                         No
FTOS#
```

Example 2 Figure 34-5. show spanning-tree rstp with EDS and LBK

```
FTOS#show spanning-tree rstp br
Executing IEEE compatible Spanning Tree Protocol
Root ID Priority 32768, Address 0001.e801.6aa8
Root Bridge hello time 2, max age 20, forward delay 15
Bridge ID Priority 32768, Address 0001.e801.6aa8
We are the root
Configured hello time 2, max age 20, forward delay 15
                                                    Designated
Bridge ID PortID
Interface
           PortID Prio Cost Sts Cost
Name
Gi 0/0 128.257 128 20000 EDS 0 32768 0001.e801.6aa8 128.257
Interface
            Role PortID Prio Cost Sts Cost Link-type Edge
Name
Gi 0/0 ErrDis 128.257 128 20000 EDS 0 P2P
FTOS#show spanning-tree rstp
Root Identifier has priority 32768, Address 0001.e801.6aa8
Root Bridge hello time 2, max age 20, forward delay 15, max hops 0
Bridge Identifier has priority 32768, Address 0001.e801.6aa8
Configured hello time 2, max age 20, forward delay 15, max hops 0
We are the root
Current root has priority 32768, Address 0001.e801.6aa8
Number of topology changes 1, last change occurred 00:00:31 ago on Gi 0/0
Port 257 (GigabitEthernet 0/0) is LBK INC Discarding
                                                                                - LBK INC means
Port 257 (GigabitEthernet 0/0) is LBK_INC Discarding
Port path cost 20000, Port priority 128, Port Identifier 128.257
Designated root has priority 32768, address 0001.e801.6aa8
                                                                                 Loopback BPDU
                                                                                 Inconsistency
Designated bridge has priority 32768, address 0001.e801.6aa8 Designated port id is 128.257, designated path cost 0
Number of transitions to forwarding state 1
BPDU : sent 27, received 9
The port is not in the Edge port mode
FTOS#
```

spanning-tree rstp

CES

Configure Port cost, Edge port with optional Bridge Port Data Unit (BPDU) guard, or Port priority on the RSTP.

Syntax

spanning-tree rstp {cost Port cost | edge-port [bpduguard [shutdown-on-violation]] | priority priority}

To remove the port cost, edge port with optional BPDU, or port priority, use the **no spanning-tree** rstp {cost Port cost | edge-port [bpduguard] | priority priority} command.

Parameters

cost Port cost	(OPTIONAL) Enter the keyword cost followed by the port cost value.
	Range: 1 to 200000
	Defaults:
	100 Mb/s Ethernet interface = 200000
	1-Gigabit Ethernet interface = 20000
	10-Gigabit Ethernet interface = 2000
	Port Channel interface with one 100 Mb/s Ethernet = 200000
	Port Channel interface with one 1-Gigabit Ethernet = 20000
	Port Channel interface with one 10-Gigabit Ethernet = 2000
	Port Channel with two 1-Gigabit Ethernet = 18000
	Port Channel with two 10-Gigabit Ethernet = 1800
	Port Channel with two 100-Mbps Ethernet = 180000
edge-port	Enter the keyword edge-port to configure the interface as a Rapid Spanning Tree edge port.
bpduguard	(OPTIONAL) Enter the keyword portfast to enable Portfast to move the interface into forwarding mode immediately after the root fails.
	Enter the keyword bpduguard to disable the port when it receives a BPDU.
shutdown-on-v iolation	(OPTIONAL) Enter the keyword shutdown-on-violation to hardware disable an interface when a BPDU is received and the port is disabled.
priority priority	(OPTIONAL) Enter keyword priority followed by a value in increments of 16 as
	the priority.
	Range: 0 to 240.
	Default: 128

Defaults

Not configured

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced hardware shutdown-on-violation options
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Added the optional Bridge Port Data Unit (BPDU) guard.
Version 6.2.1.1	Introduced for E-Series

Usage Information

The BPDU guard option prevents the port from participating in an active STP topology in case a BPDU appears on a port unintentionally, or is misconfigured, or is subject to a DOS attack. This option places the port into an error disable state if a BPDU appears, and a message is logged so that the administrator can take corrective action.



Note: A port configured as an edge port, on an RSTP switch, will immediately transition to the forwarding state. Only ports connected to end-hosts should be configured as edge ports. Consider an edge port similar to a port with a spanning-tree portfast enabled.

If **shutdown-on-violation** is not enabled, BPDUs will still be sent to the RPM CPU.

Example Figure 34-6. spanning-tree rstp edge-port Command

```
FTOS(conf)#interface gigabitethernet 4/0
FTOS(conf-if-gi-4/0)#spanning-tree rstp edge-port
FTOS(conf-if-gi-4/0)#show config
!
interface GigabitEthernet 4/0
no ip address
switchport
spanning-tree rstp edge-port
no shutdown
FTOS#
```

tc-flush-standard

CES

Enable the MAC address flushing upon receiving every topology change notification.

Syntax tc-flush-standard

To disable, use the **no tc-flush-standard** command.

Defaults Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 6.5.1.0	Introduced for E-Series

Usage Information

By default FTOS implements an optimized flush mechanism for RSTP. This helps in flushing MAC addresses only when necessary (and less often), allowing for faster convergence during topology changes. However, if a standards-based flush mechanism is needed, this *knob* command can be turned on to enable flushing MAC addresses upon receiving every topology change notification.

Security

Overview

Except for the Trace List feature (E-Series only), most of the commands in this chapter are available on all three Dell Networking platforms — C-Series, E-Series, and S-Series (the S-Series models that run FTOS), as noted by the following icons that appear under each command icon: [C] [E] [S]

Commands

This chapter contains various types of security commands in FTOS, in the following sections:

- **AAA Accounting Commands**
- **Authorization and Privilege Commands**
- **Authentication and Password Commands**
- **RADIUS Commands**
- TACACS+ Commands
- Port Authentication (802.1X) Commands
- SSH Server and SCP Commands
- Secure DHCP Commands

For configuration details, see the Security chapter in the FTOS Configuration Guide.



Note: Starting with FTOS v7.2.1.0, LEAP with MSCHAP v2 supplicant is implemented.

AAA Accounting Commands

AAA Accounting enables tracking of services that users are accessing and the amount of network resources being consumed by those services. When AAA Accounting is enabled, the network server reports user activity to the TACACS+ security server in the form of accounting records. Each accounting record is comprised of accounting AV pairs and is stored on the access control server.

As with authentication and authorization, you must configure AAA Accounting by defining named list of accounting methods, and then apply that list to various interfaces. The commands are:

- aaa accounting
- aaa accounting suppress
- accounting
- show accounting

aaa accounting

CES

Enable AAA Accounting and create a record for monitoring the accounting function.

Syntax

aaa accounting {system | exec | commands level} {name | default}{start-stop | wait-start | stop-only} {tacacs+}

To disable AAA Accounting, use the **no aaa accounting {system | exec | command** *level***}** {name | default}{start-stop | wait-start | stop-only} {tacacs+} command.

Parameters

system	Enter the keyword system to send accounting information of any other AAA configuration.
exec	Enter the keyword exec to send accounting information when a user has logged in to the EXEC mode.
commands level	Enter the keyword command followed by a privilege level for accounting of commands executed at that privilege level.
name default	Enter one of the following:
	• For <i>name</i> , a user-defined name of a list of accounting methods
	 default for the default accounting methods
start-stop	Enter the keyword start-stop to send a tart accounting" notice at the beginning of the requested event and a "stop accounting" notice at the end of the event.
wait-start	Enter the keyword wait-start to ensure that the TACACS+ security server acknowledges the start notice before granting the user's process request.
stop-only	Enter the keyword stop-only to instruct the TACACS+ security server to send a "stop record accounting" notice at the end of the requested user process.
tacacs+	Enter the keyword tacacs+ to use TACACS+ data for accounting. FTOS currently only supports TACACS+ accounting.

Defaults

No default configuration or behavior

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced for S-Series	
Version 7.5.1.0	Introduced for C-Series	
Version 6.3.1.0	Introduced for E-Series	

Example

Figure 35-1. aaa accounting Command Examples

FTOS(conf)# aaa accounting exec default start-stop tacacs+ FTOS(conf)# aaa accounting command 15 default start-stop tacacs+ FTOS (config)#

Usage Information

In the example above, TACACS+ accounting is used to track all usage of EXEC command and commands on privilege level 15.

Privilege level 15 is the default. If you want to track usage at privilege level 1, for example, use aaa **accounting command 1**.

Related **Commands**

enable password	Change the password for the enable command.
login authentication	Enable AAA login authentication on terminal lines.
password	Create a password.
tacacs-server host	Specify a TACACS+ server host.

aaa accounting suppress

CES Prevent the generation of accounting records of users with user name value of NULL.

Syntax aaa accounting suppress null-username

> To permit accounting records to users with user name value of NULL, use the **no aaa accounting** suppress null-username command

Defaults Accounting records are recorded for all users.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.3.1.0	Introduced

Usage Information

FTOS issues accounting records for all users on the system, including users whose username string, due to protocol translation, is NULL. For example, a user who comes on line with the aaa authentication login method-list none command is applied. Use aaa accounting suppress command to prevent accounting records from being generated for sessions that do not have user names associated to them.

accounting

CES

Apply an accounting method list to terminal lines.

Syntax accounting { exec | commands level} method-list

Parameters

exec	Enter this keyword to apply an EXEC level accounting method list.
commands level	Enter this keyword to apply an EXEC and CONFIGURATION level accounting method list.
method-list	Enter a method list that you defined using the command aaa accounting exec or aaa accounting commands.

Defaults None

Command Modes LINE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.3.1.0	Introduced on E-Series
aaa accounting	Enable AAA Accounting and create a record for monitoring the accounting function.

Usage Information

show accounting

CES Display the active accounting sessions for each online user.

Syntax show accounting

Defaults No default configuration or behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.3.1.0	Introduced

Example

Figure 35-2. show accounting Command Example

```
FTOS#show accounting
Active accounted actions on tty2, User admin Priv 1
Task ID 1, EXEC Accounting record, 00:00:39 Elapsed, service=shell
Active accounted actions on tty3, User admin Priv 1
Task ID 2, EXEC Accounting record, 00:00:26 Elapsed, service=shell
FTOS#
```

Usage Information

This command steps through all active sessions and then displays the accounting records for the active account functions.

Authorization and Privilege Commands

Set command line authorization and privilege levels with the following commands:

- authorization
- aaa authorization commands
- aaa authorization config-commands
- aaa authorization exec
- privilege level (CONFIGURATION mode)
- privilege level (LINE mode)

authorization

CES

Apply an authorization method list to terminal lines.

Syntax

authorization { exec | commands level} method-list

Parameters

exec	Enter this keyword to apply an EXEC level authorization method list.
commands level	Enter this keyword to apply an EXEC and CONFIGURATION level authorization method list.
method-list	Enter a method list that you defined using the command aaa authorization exec or aaa authorization commands.

Defaults

None

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.3.1.0	Introduced on E-Series

Usage Information

aaa authorization commands	Set parameters that restrict (or permit) a user's access to EXEC and CONFIGURATION level commands
aaa authorization exec	Set parameters that restrict (or permit) a user's access to EXEC level commands.

aaa authorization commands

CES

Set parameters that restrict (or permit) a user's access to EXEC and CONFIGURATION level commands

Syntax

aaa authorization commands | level { name | default } { local || tacacs+ || none }

Undo a configuration with the no aaa authorization commands level {name | default} {local || tacacs+ || none} command syntax.

Parameters

commands level	Enter the keyword commands followed by the command privilege level for command level authorization.
name	Define a name for the list of authorization methods.
default	Define the default list of authorization methods.
local	Use the authorization parameters on the system to perform authorization.
tacacs+	Use the TACACS+ protocol to perform authorization.
none	Enter this keyword to apply no authorization.

Defaults

None

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.1.1.0	Added support for RADIUS

aaa authorization config-commands

Set parameters that restrict (or permit) a user's access to EXEC level commands.

Syntax aaa authorization config-commands

Disable authorization checking for CONFIGURATION level commands using the command **no aaa** authorization config-commands.

Defaults Enabled when you configure **aaa authorization commands**

Command Modes CONFIGURATION

Command History

Version 7.5.1.0 Introduced for E-Series

Usage Information

By default, the command **aaa authorization commands** configures the system to check both EXEC level and CONFIGURATION level commands. Use the command **no aaa authorization config-commands** to enable only EXEC-level command checking.

aaa authorization exec

Set parameters that restrict (or permit) a user's access to EXEC-level commands.

Syntax aaa authorization exec {name | default} {local || tacacs+ || if-authenticated || none}

Disable authorization checking for EXEC level commands using the command **no aaa authorization exec.**

Parameters

name	Define a name for the list of authorization methods.
default	Define the default list of authorization methods.
local	Use the authorization parameters on the system to perform authorization.
tacacs+	Use the TACACS+ protocol to perform authorization.
none	Enter this keyword to apply no authorization.

Defaults None

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series

Version 7.5.1.0	Introduced for C-Series
Version 6.1.1.0	Added support for RADIUS

privilege level (CONFIGURATION mode)

Change the access or privilege level of one or more commands. CES

Syntax privilege mode {level level command | reset command}

To delete access to a level and command, use the **no privilege** mode level level command command.

Parameters

mode	Enter one of the following keywords as the mode for which you are controlling access:
	configure for the CONFIGURATION mode
	exec for the EXEC mode
	• interface for the INTERFACE modes
	• line for the LINE mode
	• route-map for the ROUTE-MAP
	 router for the ROUTER OSPF, ROUTER RIP, ROUTER ISIS and ROUTER BGP modes.
level level	Enter the keyword level followed by a number for the access level.
	Range: 0 to 15.
	Level 1 is the EXEC mode and Level 15 allows access to all CLI modes and commands.
reset	Enter the keyword reset to return the security level to the default setting.
command	Enter the command's keywords to assign the command to a certain access level. You can enter one or all of the keywords
	·

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Use the enable password command to define a password for the level to which you are assigning privilege or access.

privilege level (LINE mode)

CES Change the access level for users on the terminal lines.

Syntax privilege level level

To delete access to a terminal line, use the **no privilege level** /command.

Doromotoro		
Parameters	level level	Enter the keyword level followed by a number for the access level.
		Range: 0 to 15.
		Level 1 is the EXEC mode and Level 15 allows access to all CLI modes.
Defaults	level = 15	
Command Modes	LINE	
Command		
History	Version 8.3.3.1	Introduced on S60
_	Version 7.6.1.0	Introduced for S Saries

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Authentication and Password Commands

This section contains the following commands controlling management access to the system:

- aaa authentication enable
- aaa authentication login
- access-class
- enable password
- enable restricted
- enable secret
- login authentication
- password
- password-attributes
- privilege level (CONFIGURATION mode)
- privilege level (LINE mode)
- service password-encryption
- show privilege
- show users
- timeout login response
- username

aaa authentication enable

CES Configure AAA Authentication method lists for user access to the EXEC privilege mode (the "Enable" access).

Syntax aaa authentication enable {default | method-list-name} method [... method2]

To return to the default setting, use the **no aaa authentication enable** { **default** | *method-list-name*} *method* [... *method2*] command.

Parameters

default	Enter the keyword default followed by the authentication methods to use as the default sequence of methods to be used for the Enable log-in.
	Default: default enable
method-list-name	Enter a text string (up to 16 characters long) to name the list of enabled authentication methods activated at log in.
method	Enter one of the following methods:
	 enable - use the password defined by the enable password command in the CONFIGURATION mode.
	 line - use the password defined by the password command in the LINE mode.
	• none - no authentication.
	 radius - use the RADIUS server(s) configured with the radius-server host command.
	 tacacs+ - use the TACACS+ server(s) configured with the tacacs-server host command.
method2	(OPTIONAL) In the event of a "no response" from the first method, FTOS applies the next configured method.

Defaults

Use the enable password.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 6.2.1.1	Introduced

Usage Information

By default, the Enable password is used. If aaa authentication enable default is configured, FTOS will use the methods defined for Enable access instead.

Methods configured with the aaa authentication enable command are evaluated in the order they are configured. If authentication fails using the primary method, FTOS employs the second method (or third method, if necessary) automatically. For example, if the TACACS+ server is reachable, but the server key is invalid, FTOS proceeds to the next authentication method. The TACACS+ is incorrect, but the user is still authenticated by the secondary method.

Related Commands

enable password	Change the password for the enable command.
login authentication	Enable AAA login authentication on terminal lines.
password	Create a password.
radius-server host	Specify a RADIUS server host.
tacacs-server host	Specify a TACACS+ server host.

aaa authentication login

CES

Configure AAA Authentication method lists for user access to the EXEC mode (Enable log-in).

Syntax

aaa authentication login { method-list-name | default } method [... method4]

To return to the default setting, use the **no aaa authentication login** { method-list-name | **default**} command.

Parameters

method-list-name	Enter a text string (up to 16 characters long) as the name of a user-configured method list that can be applied to different lines.
default	Enter the keyword default to specify that the method list specified is the default method for all terminal lines.
method	Enter one of the following methods:
	• enable - use the password defined by the enable password command in the CONFIGURATION mode.
	 line - use the password defined by the password command in the LINE mode.
	• local - use the user name/password defined by the in the local configuration.
	• none - no authentication.
	 radius - use the RADIUS server(s) configured with the radius-server host command.
	• tacacs+ - use the TACACS+ server(s) configured with the tacacs-server host command.
method4	(OPTIONAL) Enter up to four additional methods. In the event of a "no response" from the first method, FTOS applies the next configured method (up to four configured methods).

Default

Not configured (that is, no authentication is performed)

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.0	Introduced on E-Series

Usage Information

By default, the locally configured **username password** will be used. If **aaa authentication login default** is configured, FTOS will use the methods defined by this command for login instead.

Methods configured with the aaa authentication login command are evaluated in the order they are configured. If users encounter an error with the first method listed, FTOS applies the next method configured. If users fail the first method listed, no other methods are applied. The only exception is the **local** method. If the user's name is not listed in the local database, the next method is applied. If the correct user name/password combination are not entered, the user is not allowed access to the switch.



Note: If authentication fails using the primary method, FTOS employs the second method (or third method, if necessary) automatically. For example, if the TACACS+ server is reachable, but the server key is invalid, FTOS proceeds to the next authentication method. The TACACS+ is incorrect, but the user is still authenticated by the secondary method.

After configuring the aaa authentication login command, configure the login authentication command to enable the authentication scheme on terminal lines.

Connections to the SSH server will work with the following login mechanisms: local, radius and

Related Commands

login authentication	Apply an authentication method list to designated terminal lines.
password	Create a password.
radius-server host	Specify a RADIUS server host.
tacacs-server host	Specify a TACACS+ server host.

access-class

CES

Restrict incoming connections to a particular IP address in a defined IP access control list (ACL).

Syntax

access-class access-list-name

To delete a setting, use the **no access-class** command.

Parameters

access-list-name	Enter the name of an established IP Standard ACL.

Defaults

Not configured.

Command Modes

LINE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related Commands

line	Apply an authentication method list to designated terminal lines.
ip access-list standard	Name (or select) a standard access list to filter based on IP address.
ip access-list extended	Name (or select) an extended access list based on IP addresses or protocols.

enable password

CES

Change the password for the enable command.

Syntax

enable password [level level] [encryption-type] password

To delete a password, use the **no enable password** [encryption-type] password [level level] command.

Parameters

level level	(OPTIONAL) Enter the keyword level followed by a number as the level of access.
	Range: 1 to 15
encryption-type	(OPTIONAL) Enter the number 7 or 0 as the encryption type.
	Enter a 7 followed by a text string as the hidden password. The text string must be a password that was already encrypted by a Force10 Networks router.
	Use this parameter only with a password that you copied from the show running-config file of another Dell Networking router.
password	Enter a text string, up to 32 characters long, as the clear text password.

Defaults

No password is configured. level = 15

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Use this command to define a password for a level and use the privilege level (CONFIGURATION mode) command to control access to command modes.

Passwords must meet the following criteria:

- Start with a letter, not a number.
- Passwords can have a regular expression as the password. To create a password with a regular expression in it, you must use CNTL + v prior to entering regular expression. For example, to create the password abcd] e, you type "abcd CNTL v] e". When the password is created, you do not use the CNTL + v key combination and enter "abcd] e".



Note: The question mark (?) and the tilde (~) are not supported characters.

Related Commands

show running-config	View the current configuration.
privilege level (CONFIGURATION mode)	Control access to command modes within the switch.

enable restricted

CES

Allows Dell Networking technical support to access restricted commands.

Syntax

enable restricted [encryption-type] password

To disallow access to restricted commands, enter no enable restricted.

Daramatara		
Parameters	encryption-type	(OPTIONAL) Enter the number 7 as the encryption type.
		Enter 7 followed a text string as the hidden password. The text string must be a password that was already encrypted by a Dell Networking router.
		Use this parameter only with a password that you copied from the show running-config file of another Dell Networking router.

Command Modes

Not configured.

password

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Enter a text string, up to 32 characters long, as the clear text password.

Usage Information

Only Dell Networking Technical Support staff use this command.

enable secret

CES

Change the password for the enable command.

Syntax

enable secret [level level] [encryption-type] password

To delete a password, use the **no enable secret** [encryption-type] password [level level] command.

Parameters

level level	(OPTIONAL) Enter the keyword level followed by a number as the level of access.
	Range: 1 to 15
encryption-type	(OPTIONAL) Enter the number 5 or 0 as the encryption type.
	Enter a 5 followed a text string as the hidden password. The text string must be a password that was already encrypted by a Dell Networking router.
	Use this parameter only with a password that you copied from the show running-config file of another Dell Networking router.
password	Enter a text string, up to 32 characters long, as the clear text password.

Defaults

No password is configured. level = 15

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Use this command to define a password for a level and use the privilege level (CONFIGURATION mode) command to control access to command modes.

Passwords must meet the following criteria:

- Start with a letter, not a number.
- Passwords can have a regular expression as the password. To create a password with a regular expression in it, you must use CNTL + v prior to entering regular expression. For example, to create the password abcd] e, you type abcd CNTL v] e and when the password is created, you do not use the CNTL + v key combination and enter abcd] e.



Note: The question mark (?) and the tilde (~) are not supported characters.

Related Commands

show running-config	View the current configuration.
privilege level (CONFIGURATION mode)	Control access to command modes within the E-Series.

login authentication

CES

Apply an authentication method list to designated terminal lines.

Syntax

login authentication { method-list-name | default }

To use the local user/password database for login authentication, enter no login authentication.

Parameters

method-list-name	Enter the <i>method-list-name</i> to specify that method list, created in the aaa authentication login command, to be applied to the designated terminal line.
default	Enter the keyword default to specify that the default method list, created in the aaa authentication login command, is applied to the terminal line.

Defaults

No authentication is performed on the console lines, and local authentication is performed on the virtual terminal and auxiliary lines.

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.0	Introduced on E-Series

Usage Information

If you configure the aaa authentication login default command, then the login authentication default command automatically is applied to all terminal lines.

Related Commands

|--|

password

CES

Specify a password for users on terminal lines.

Syntax

password [encryption-type] password

To delete a password, use the **no password** password command.

Parameters

encryption-type	(OPTIONAL) Enter either zero (0) or 7 as the encryption type for the <i>password</i> entered. The options are:	
	 0 is the default and means the password is not encrypted and stored as clear text. 7 means that the password is encrypted and hidden. 	
password	Enter a text string up to 32 characters long. The first character of the <i>password</i> must be a letter. You cannot use spaces in the password.	

Defaults

No password is configured.

Command Modes

LINE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

FTOS prompts users for these passwords when the method for authentication or authorization used is "line".

Related **Commands**

enable password	Set the password for the enable command.
login authentication	Configure an authentication method to log in to the switch.
service password-encryption	Encrypt all passwords configured in FTOS.
radius-server key	Configure a key for all RADIUS communications between the switch and the RADIUS host server.
tacacs-server key	Configure a key for communication between a TACACS+ server and client.
username	Establish an authentication system based on user names.

password-attributes



Configure the password attributes (strong password).

Syntax

password-attributes [min-length number] [max-retry number] [character-restriction [upper number] [lower number] [numeric number] [special-char number]]

To return to the default, use the **no password-attributes** [min-length number] [max-retry number] [character-restriction [upper number] [lower number] [numeric number] [special-char number]] command.

Parameters

min-length number	(OPTIONAL) Enter the keyword min-length followed by the number of characters. Range: 0 - 32 characters
max-retry number	(OPTIONAL) Enter the keyword max-retry followed by the number of maximum password retries. Range: 0 - 16
character-restriction	(OPTIONAL) Enter the keyword character-restriction to indicate a character restriction for the password.

upper <i>number</i> (OPTIONAL) Enter the keyword upper followed the upper r	
	Range: 0 - 31
lower number	(OPTIONAL) Enter the keyword lower followed the lower number.
	Range: 0 - 31
numeric number	(OPTIONAL) Enter the keyword numeric followed the numeric number.
	Range: 0 - 31
special-char number	(OPTIONAL) Enter the keyword special-char followed the number of special characters permitted.
	Range: 0 - 31

Defaults

No default values or behavior

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
Version 7.4.1.0	Introduced

Related Commands

password Specify a password for users on terminal lines.

service password-encryption

CES

Encrypt all passwords configured in FTOS.

Syntax

service password-encryption

To store new passwords as clear text, enter **no service password-encryption**.

Defaults

Enabled.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series



Caution: Encrypting passwords with this command does not provide a high level of security. When the passwords are encrypted, you cannot return them to plain text unless you re-configure them. To remove an encrypted password, use the **no password** password command.

Usage Information

To keep unauthorized people from viewing passwords in the switch configuration file, use the service password-encryption command. This command encrypts the clear-text passwords created for user name passwords, authentication key passwords, the privileged command password, and console and virtual terminal line access passwords.

To view passwords, use the show running-config command.

show privilege

CESView your access level.

Syntax show privilege

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 35-3. show privilege Command Output

FTOS#show privilege Current privilege level is 15 FTOS#

Related Commands

privilege level (CONFIGURATION mode)

Assign access control to different command modes.

show users

CES

View information on all users logged into the switch.

Syntax show users [all]

Parameters

all (OPTIONAL) Enter the keyword **all** to view all terminal lines in the switch.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-4. show users Command Example

FTOS#show user Host(s) Location Line User 0 console 0 idle admin 3 vty 1 admin idle 172.31.1.4 FTOS#

Table 1 describes the information in the **show users** command example.

Table 1 show users Command Example Fields

Field	Description
(untitled)	Indicates with a * which terminal line you are using.
Line	Displays the terminal lines currently in use.
User	Displays the user name of all users logged in.
Host(s)	Displays the terminal line status.
Location	Displays the IP address of the user.

Related Commands

username Enable a user.

timeout login response

CES

Specify how long the software will wait for login input (for example, user name and password) before timing out.

Syntax timeout login response seconds

To return to the default values, enter **no timeout login response**.

Parameters

Seconds Enter a number of seconds the software will wait before logging you out.

Range: 1 to 300.

Default: 300 seconds.

Defaults seconds = 300 seconds

Command Modes LINE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The software measures the period of inactivity defined in this command as the period between consecutive keystrokes. For example, if your password is "password" you can enter "p" and wait 29 seconds to enter the next letter.

username

CES

Establish an authentication system based on user names.

Syntax

username name [access-class access-list-name] [nopassword | {password | secret}} [encryption-type] password] [privilege level]

If you do not want a specific user to enter a password, use the **nopassword** option.

To delete authentication for a user, use the **no username** name command.

Parameters

name	Enter a text string for the name of the user up to 63 characters.		
	Note: If the entered username is longer than 16 characters, the BSD username and password are not created. This is a BSD limitation, not an FTOS limitation. FTOS supports up to 63 characters for the username and password.		
access-class access-list-name	Enter the keyword access-class followed by the name of a configured access control list (either a IP access control list or MAC access control list).		
nopassword	Enter the keyword nopassword to specify that the user should not enter a password.		
password	Enter the keyword password followed by the <i>encryption-type</i> or the password.		
secret	Enter the keyword secret followed by the <i>encryption-type</i> or the password.		
encryption-type	Enter an encryption type for the <i>password</i> that you will enter.		
	 0 directs FTOS to store the password as clear text. It is the default encryption type when using the password option. 		
	 7 to indicate that a password ecrypted using a DES hashing algorithm will follow. This encryption type is available with the password option only. 		
	• 5 to indicate that a password ecrypted using an MD5 hashing algorithm will follow. This encryption type is available with the secret option only, and is the default encryption type for this option.		
password	Enter a string up to 32 characters long.		
privilege level	Enter the keyword privilege followed by a number from zero (0) to 15.		
secret	Enter the keyword secret followed by the encryption type.		

Defaults

The default encryption type for the **password** option is 0. The default encryption type for the **secret** option is 5.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.4	Enhanced BSD encryption	
Version 8.3.3.1	Introduced on S60 Added BSD encryption to MD5 passwords	
Version 7.7.1.0	Added support for secret option and MD5 password encryption. Extended <i>name</i> from 25 characters to 63.	
Version 7.6.1.0	Introduced for S-Series	
Version 7.5.1.0	Introduced for C-Series	
E-Series original Command		

Usage Information

To view the defined user names, use the show running-config user command.

When creating a username and secret password, a new userID is also created: **bsd-username**. This additional username and password is automatically created on all systems, but is applicable to the Automations features SmartScripts and HyperLink (still in Beta phase).

When you create a username and secret password (for example, **username** *qsmythe* **secret** *q12lmo*), the system creates **bsd-username** *qsmyth* **secret** *random-password*. The random password is assigned by the system for BSD shell access for the automation features. When you show your configuration, both passwords appear.

```
FTOS#: show run
.
.
.
.
username <username> secret 5 <password>
bsd-username <username> secret <password>
.
.
FTOS#
```

When you save the configuration, and reload the system, both new passwords are applied to the configuration. If you downgrade to a release prior to FTOS 8.3.3.4, the BSD username and password are removed from the configuration.

The BSD username is created when you enter a new username in the CLI. It is not created from a preexisting username. Following an upgrade to FTOS 8.3.3.3, you must enter a new (or re-enter the old) username and password to get the BSD username.



Note: If the entered username is longer than 16 characters, the BSD username and password are not created. This is a BSD limitation, not an FTOS limitation. FTOS supports up to 63 characters for the username and password.

Related Commands

password	Specify a password for users on terminal lines.
show running-config	View the current configuration.

RADIUS Commands

The RADIUS commands supported by FTOS. are:

- debug radius
- · ip radius source-interface
- · radius-server deadtime
- radius-server host
- radius-server key
- radius-server retransmit
- radius-server timeout

debug radius

CES View RADIUS transactions to assist with troubleshooting.

Syntax debug radius

To disable debugging of RADIUS, enter no debug radius.

Defaults Disabled.

Command Modes EXEC Privilege

> Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.2.1.1	Introduced on E-Series	

ip radius source-interface

Specify an interface's IP address as the source IP address for RADIUS connections.

Syntax ip radius source-interface interface

To delete a source interface, enter **no ip radius source-interface**.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword loopback followed by a number from zero (0) to 16838.
- For the Null interface, enter the keywords **null 0**.
- For the Port Channel interface, enter the keyword port-channel followed by a number:

C-Series and S-Series Range: 1-128 E-Series Range: 1 to 255 for TeraScale

- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For VLAN interface, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults Not configured.

Command Mode CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.2.1.1	Introduced on E-Series	

radius-server deadtime

CES

Configure a time interval during which non-responsive RADIUS servers to authentication requests are skipped.

Syntax

radius-server deadtime seconds

To disable this function or return to the default value, enter **no radius-server deadtime**.

Parameters

seconds	Enter a number of seconds during which non-responsive RADIUS servers are skipped.
	Range: 0 to 2147483647 seconds.
	Default: 0 seconds.

Defaults

0 seconds

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced for S-Series	
Version 7.5.1.0	Introduced for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

radius-server host

CES

Configure a RADIUS server host.

Syntax

radius-server host { hostname | ip-address} [auth-port port-number] [retransmit retries] [timeout seconds] [key [encryption-type] key]

To delete a RADIUS server host or return to the default values, use the **no radius-server host** { *hostname* | *ip-address*} [auth-port] [retransmit] [timeout] command.

Parameters

hostname	Enter the name of the RADIUS server host.
ip-address	Enter the IP address, in dotted decimal format, of the RADIUS server host.
auth-port port-number	(OPTIONAL) Enter the keyword auth-port followed by a number as the port number. Range: zero (0) to 65535
	The default <i>port-number</i> is 1812.
retransmit retries	(OPTIONAL) Enter the keyword retransmit followed by a number as the number of attempts. This parameter overwrites the radius-server retransmit command.
	Range: zero (0) to 100
	Default: 3 attempts

timeout seconds	(OPTIONAL) Enter the keyword timeout followed by the seconds the time interval the switch waits for a reply from the RADIUS server. This parameter overwrites the radius-server timeout command. Range: 0 to 1000 Default: 5 seconds
key [encryption-type] key	(OPTIONAL) Enter the keyword key followed by an optional encryption-type and a string up to 42 characters long as the authentication key. This authentication key is used by the RADIUS host server and the RADIUS daemon operating on this switch.
	For the encryption-type, enter either zero (0) or 7 as the encryption type for the <i>key</i> entered. The options are:
	• 0 is the default and means the password is not encrypted and stored as clear text.
	• 7 means that the password is encrypted and hidden.
	Configure this parameter last because leading spaces are ignored.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.7.1.0	Authentication key length increased to 42 characters	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.2.1.1	Introduced on E-Series	

Usage Information

Configure up to six RADIUS server hosts by using this command for each server host configured. FTOS searches for the RADIUS hosts in the order they are configured in the software.

The global default values for timeout, retransmit, and key optional parameters are applied, unless those values are specified in the radius-server host or other commands. If you configure timeout, retransmit, or key values, you must include those keywords when entering the no radius-server host command syntax to return to the global default values.

Related Commands

login authentication	Set the database to be checked when a user logs in.
radius-server key	Set a authentication key for RADIUS communications.
radius-server retransmit	Set the number of times the RADIUS server will attempt to send information.
radius-server timeout	Set the time interval before the RADIUS server times out.

radius-server key

CES

Configure a key for all RADIUS communications between the switch and the RADIUS host server.

Syntax

radius-server key [encryption-type] key

To delete a password, enter **no radius-server key**.

Parameters		
Faranielers	encryption-type	(OPTIONAL) Enter either zero (0) or 7 as the encryption type for the <i>key</i> entered. The options are:
		• 0 is the default and means the key is not encrypted and stored as clear text.
		• 7 means that the key is encrypted and hidden.
	key	Enter a string that is the key to be exchanged between the switch and RADIUS servers. It can be up to 42 characters long.
Defaults	Not configured.	
Command Modes	CONFIGURATION	
Command	Version 8.3.3.1	Introduced on S60
History		
	Version 7.7.1.0	Authentication key length increased to 42 characters
	Version 7.6.1.0	Support added for S-Series
	Version 7.5.1.0	Support added for C-Series
	pre-Version 6.2.1.1	Introduced on E-Series
Usage Information	The key configured o	n the switch must match the key configured on the RADIUS server daemon.
	• 1	n the radius-server host command is configured, the key configured with the mand is the default key for all RADIUS communications.
Related Commands	radius-server host	Configure a RADIUS host.

radius-server retransmit

CES

Configure the number of times the switch attempts to connect with the configured RADIUS host server before declaring the RADIUS host server unreachable.

Syntax radius-server retransmit retries

To configure zero retransmit attempts, enter **no radius-server retransmit**. To return to the default setting, enter radius-server retransmit 3.

Parameters

retries	Enter a number of attempts that FTOS tries to locate a RADIUS server.
	Range: zero (0) to 100.
	Default: 3 retries.

Defaults 3 retries

CONFIGURATION

Command History

Command Modes

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related **Commands**

Configure a RADIUS host. radius-server host

radius-server timeout

CES

Configure the amount of time the RADIUS client (the switch) waits for a RADIUS host server to reply to a request.

Syntax

radius-server timeout seconds

To return to the default value, enter no radius-server timeout.

Parameters

seconds Enter the number of seconds between an unsuccessful attempt and the FTOS times out. Range: zero (0) to 1000 seconds. Default: 5 seconds.

Defaults

5 seconds

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Related **Commands**

Configure a RADIUS host. radius-server host

TACACS+ Commands

FTOS supports TACACS+ as an alternate method for login authentication.

- debug tacacs+
- ip tacacs source-interface
- tacacs-server host
- tacacs-server key

debug tacacs+

CES

View TACACS+ transactions to assist with troubleshooting.

Syntax

debug tacacs+

To disable debugging of TACACS+, enter no debug tacacs+.

Defaults

Disabled.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

ip tacacs source-interface

CES

Specify an interface's IP address as the source IP address for TACACS+ connections.

Syntax

ip tacacs source-interface interface

To delete a source interface, enter no ip tacacs source-interface.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword loopback followed by a number from zero (0) to 16838.
- For the Null interface, enter the keywords **null 0**.
- For the Port Channel interface, enter the keyword port-channel followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale

- For a SONET interface, enter the keyword sonet followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
- For VLAN interface, enter the keyword vlan followed by a number from 1 to 4094

Defaults

Not configured.

Command Mode

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

tacacs-server host

CES

Specify a TACACS+ host.

Syntax

tacacs-server host {hostname | ip-address} [port number] [timeout seconds] [key key]

To remove a TACACS+ server host, use the **no tacacs-server host** { hostname | ip-address} command.

Parameters

hostname	Enter the name of the TACACS+ server host.
ip-address	Enter the IP address, in dotted decimal format, of the TACACS+ server host.
port number	(OPTIONAL) Enter the keyword port followed by a number as the port to be used by the TACACS+ server.
	Range: zero (0) to 65535
	Default: 49
timeout seconds	(OPTIONAL) Enter the keyword timeout followed by the number of seconds the switch waits for a reply from the TACACS+ server.
	Range: 0 to 1000
	Default: 10 seconds
key key	(OPTIONAL) Enter the keyword key followed by a string up to 42 characters long as the authentication key. This authentication key must match the key specified in the tacacs-server key for the TACACS+ daemon.
	Configure this parameter last because leading spaces are ignored.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Authentication key length increased to 42 characters
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

To list multiple TACACS+ servers to be used by the aaa authentication login command, configure this command multiple times.

If you are not configuring the switch as a TACACS+ server, you do not need to configure the port, timeout and key optional parameters. If you do not configure a key, the key assigned in the tacacs-server key command is used.

Related **Commands**

aaa authentication login	Specify the login authentication method.
tacacs-server key	Configure a TACACS+ key for the TACACS server.

tacacs-server key

C E S Configure a key for communication between a TACACS+ server and client.

Syntax tacacs-server key [encryption-type] key

To delete a key, use the no tacacs-server key key

Parameters

encryption-type	(OPTIONAL) Enter either zero (0) or 7 as the encryption type for the <i>key</i> entered. The options are:
	0 is the default and means the key is not encrypted and stored as clear text.7 means that the key is encrypted and hidden.
key	Enter a text string, up to 42 characters long, as the clear text password. Leading spaces are ignored.

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Authentication key length increased to 42 characters
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information The key configured with this command must match the key configured on the TACACS+ daemon.

Port Authentication (802.1X) Commands

The 802.1X Port Authentication commands are:

- dot1x authentication (Configuration)
- dot1x authentication (Interface)
- dot1x auth-fail-vlan
- dot1x auth-server
- dot1x guest-vlan
- dot1x max-eap-req
- dot1x port-control
- dot1x quiet-period
- dot1x reauthentication
- dot1x reauth-max
- dot1x server-timeout
- dot1x supplicant-timeout
- dot1x tx-period
- show dot1x interface

An authentication server must authenticate a client connected to an 802.1X switch port. Until the authentication, only EAPOL (Extensible Authentication Protocol over LAN) traffic is allowed through the port to which a client is connected. Once authentication is successful, normal traffic passes through the port.

FTOS supports RADIUS and Active Directory environments using 802.1X Port Authentication.

Important Points to Remember

FTOS limits network access for certain users by using VLAN assignments. 802.1X with VLAN assignment has these characteristics when configured on the switch and the RADIUS server.

- 802.1X is supported on C-Series, E-Series, and S-Series.
- 802.1X is not supported on the LAG or the channel members of a LAG.
- If no VLAN is supplied by the RADIUS server or if 802.1X authorization is disabled, the port is configured in its access VLAN after successful authentication.
- If 802.1X authorization is enabled but the VLAN information from the RADIUS server is not valid, the port returns to the unauthorized state and remains in the configured access VLAN. This prevents ports from appearing unexpectedly in an inappropriate VLAN due to a configuration error. Configuration errors create an entry in Syslog.
- If 802.1X authorization is enabled and all information from the RADIUS server is valid, the port is placed in the specified VLAN after authentication.
- If port security is enabled on an 802.1X port with VLAN assignment, the port is placed in the RADIUS server assigned VLAN.
- If 802.1X is disabled on the port, it is returned to the configured access VLAN.
- When the port is in the force authorized, force unauthorized, or shutdown state, it is placed in the configured access VLAN.
- If an 802.1X port is authenticated and put in the RADIUS server assigned VLAN, any change to the port access VLAN configuration will not take effect.
- The 802.1X with VLAN assignment feature is not supported on trunk ports, dynamic ports, or with dynamic-access port assignment through a VLAN membership.

dot1x authentication (Configuration)

[C][E][S]Enable dot1x globally; dot1x must be enabled both globally and at the interface level.

Syntax dot1x authentication

To disable dot1x on an globally, use the **no dot1x authentication** command.

Defaults Disabled

Command Modes CONFIGURATION

> Command History

> > Related

Commands

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series
dot1x authentication (Interface)	Enable dot1x on an interface

dot1x authentication (Interface)

Enable dot1x on an interface; dot1x must be enabled both globally and at the interface level.

Syntax dot1x authentication

To disable dot1x on an interface, use the **no dot1x authentication** command.

Defaults Disabled

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on C-Series and S-Series	
Version 7.4.1.0	Introduced on E-Series	

Related Commands

dot1x authentication (Configuration) Enable dot1x globally

dot1x auth-fail-vlan

C E S Configure a authentication failure VLAN for users and devices that fail 802.1X authentication.

Syntax dot1x auth-fail-vlan vlan-id [max-attempts number]

To delete the authentication failure VLAN, use the **no dot1x auth-fail-vlan** *vlan-id* [max-attempts *number*] command.

Parameters

vlan-id	Enter the VLAN Identifier. Range: 1 to 4094
max-attempts number	(OPTIONAL) Enter the keyword max-attempts followed number of attempts desired before authentication fails. Range: 1 to 5 Default: 3

Defaults 3 attempts

Command Modes CONFIGURATION (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series, E-Series and S-Series

Usage Information If the host responds to 802.1X with an incorrect login/password, the login fails. The switch will attempt to authenticate again until the maximum attempts configured is reached. If the authentication fails after all allowed attempts, the interface is moved to the authentication failed VLAN.

Once the authentication VLAN is assigned, the port-state must be toggled to restart authentication. Authentication will occur at the next re-authentication interval (dot1x reauthentication).

Related Commands

dot1x port-control Enable port-control on an interface
--

dot1x guest-vlan	Configure a guest VLAN for non-dot1x devices
show dot1x interface	Display the 802.1X information on an interface

dot1x auth-server

CESConfigure the authentication server to RADIUS.

Syntax dot1x auth-server radius

Defaults No default behavior or values

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

dot1x guest-vlan

CES Configure a guest VLAN for limited access users or for devices that are not 802.1X capable.

Syntax dot1x guest-vlan vlan-id

To disable the guest VLAN, use the **no dot1x guest-vlan** *vlan-id* command.

Parameters

vlan-id	Enter the VLAN Identifier.
	Range: 1 to 4094

Defaults Not configured

Command Modes CONFIGURATION (conf-if-interface-slot/port)

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series, E-Series, and S-Series

Usage Information

802.1X authentication is enabled when an interface is connected to the switch. If the host fails to respond within a designated amount of time, the authenticator places the port in the guest VLAN.

If a device does not respond within 30 seconds, it is assumed that the device is not 802.1X capable. Therefore, a guest VLAN is allocated to the interface and authentication, for the device, will occur at the next re-authentication interval (dot1x reauthentication).

If the host fails authentication for the designated amount of times, the authenticator places the port in authentication failed VLAN (dot1x auth-fail-vlan).



Note: Layer 3 portion of guest VLAN and authentication fail VLANs can be created regardless if the VLAN is assigned to an interface or not. Once an interface is assigned a guest VLAN (which has an IP address), then routing through the guest VLAN is the same as any other traffic. However, interface may join/leave a VLAN dynamically.

Related Commands

dot1x auth-fail-vlan	Configure a VLAN for authentication failures
dot1x reauthentication	Enable periodic re-authentication
show dot1x interface	Display the 802.1X information on an interface

dot1x max-eap-req

CES

Configure the maximum number of times an EAP (Extensive Authentication Protocol) request is transmitted before the session times out.

Syntax dot1x max-eap-req number

To return to the default, use the **no dot1x max-eap-req** command.

Parameters

number Enter the number of times an EAP request is transmitted before a session time-out.

Range: 1 to 10

Default: 2

Defaults 2

Command Modes INTERFACE

Command History

Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Introduced on C-Series and S-Series

Version 7.4.1.0 Introduced on E-Series

interface range Configure a range of interfaces

Related Commands

dot1x port-control

CES Enable port control on an interface.

Syntax dot1x port-control {force-authorized | auto | force-unauthorized}

Parameters

force-authorized	Enter the keyword force-authorized to forcibly authorize a port.
auto	Enter the keyword auto to authorize a port based on the 802.1X operation result.
force-unauthorized	Enter the keyword force-unauthorized to forcibly de-authorize a port.

Defaults No default behavior or values

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

Usage Information The authenticator performs authentication only when port-control is set to **auto**.

dot1x quiet-period

CES

Set the number of seconds that the authenticator remains quiet after a failed authentication with a client.

Syntax

dot1x quiet-period seconds

To disable quiet time, use the **no dot1x quiet-time** command.

Parameters

seconds Enter the number of seconds. Range: 1 to 65535 Default: 30

Defaults

30 seconds

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

dot1x reauthentication

CES

Enable periodic re-authentication of the client.

Syntax

dot1x reauthentication [interval seconds]

To disable periodic re-authentication, use the **no dot1x reauthentication** command.

Parameters

interval seconds	(Optional) Enter the keyword interval followed by the interval time, in seconds, after which re-authentication will be initiated.
	Range: 1 to 31536000 (1 year)
	Default: 3600 (1 hour)

Defaults

3600 seconds (1 hour)

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series
interface range	Configure a range of interfaces

Related Commands

dot1x reauth-max

CES

Configure the maximum number of times a port can re-authenticate before the port becomes unauthorized.

Syntax

dot1x reauth-max number

To return to the default, use the **no dot1x reauth-max** command.

Parameters

number	Enter the permitted number of re-authentications.
	Range: 1 - 10
	Default: 2

Defaults

2

Command Modes

INTERFACE

Command History

Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

dot1x server-timeout

CES

Configure the amount of time after which exchanges with the server time out.

Syntax

dot1x server-timeout seconds

To return to the default, use the **no dot1x server-timeout** command.

Parameters

seconds	Enter a time-out value in seconds.
	Range: 1 to 300, where 300 is implementation dependant.
	Default: 30

Defaults

30 seconds

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series
Version 7.4.1.0	Introduced on E-Series

dot1x supplicant-timeout

CES

Configure the amount of time after which exchanges with the supplicant time out.

Syntax

dot1x supplicant-timeout seconds

To return to the default, use the **no dot1x supplicant-timeout** command.

Parameters seconds Enter a time-out value in seconds.

Range: 1 to 300, where 300 is implementation dependant.

Default: 30

Defaults 30 seconds

Command Modes INTERFACE

> Command History

Version 8.3.3.1 Introduced on S60 Version 7.6.1.0 Introduced on C-Series and S-Series Version 7.4.1.0 Introduced on E-Series

dot1x tx-period

CESConfigure the intervals at which EAPOL PDUs are transmitted by the Authenticator PAE.

Syntax dot1x tx-period seconds

To return to the default, use the **no dot1x tx-period** command.

Parameters Enter the interval time, in seconds, that EAPOL PDUs are transmitted. seconds

Range: 1 to 31536000 (1 year)

Default: 30

Defaults 30 seconds

Command Modes INTERFACE

> Command History

Version 8.3.3.1 Introduced on S60 Version 7.6.1.0 Introduced on C-Series and S-Series Version 7.4.1.0 Introduced on E-Series

show dot1x interface

CES Display the 802.1X information on an interface.

Syntax show dot1x interface interface

Parameters

interface Enter one of the following keywords and slot/port or number information:

- For a Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Fast Ethernet interface, enter the keyword **FastEthernet** followed by the slot/
- For a Ten Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series, E-Series, and S-Series

Example

Figure 35-5. show dot1x interface command Example

```
FTOS#show dot1x int Gi 2/32
802.1x information on Gi 2/32:
Dot1x Status:
                       Enable
Port Control:
                       AUTO
                       UNAUTHORIZED
Port Auth Status:
Re-Authentication:
                       Disable
Untagged VLAN id:
                       None
Guest VLAN:
Guest VLAN id:
                       Enable
                       10
Auth-Fail VLAN:
                       Enable
Auth-Fail VLAN id: 11
Auth-Fail Max-Attempts: 3
Tx Period:
                       30 seconds
Ouiet Period:
                       60 seconds
ReAuth Max:
Supplicant Timeout:
                       30 seconds
Server Timeout:
                       30 seconds
Re-Auth Interval:
                       3600 seconds
Max-EAP-Req:
Auth Type:
                       SINGLE_HOST
Auth PAE State:
                       Initialize
Backend State:
                       Initialize
FTOS#
```

SSH Server and SCP Commands

FTOS supports SSH Protocol versions 1.5 and 2.0. Secure Shell (SSH) is a protocol for secure remote login over an insecure network. SSH sessions are encrypted and use authentication.

- crypto key generate
- · debug ip ssh
- ip scp topdir
- ip ssh authentication-retries
- ip ssh connection-rate-limit
- ip ssh hostbased-authentication
- ip ssh key-size
- ip ssh password-authentication
- ip ssh pub-key-file
- ip ssh rhostsfile
- ip ssh rsa-authentication (Config)
- ip ssh rsa-authentication (EXEC)
- ip ssh server
- show crypto
- show ip ssh

- show ip ssh client-pub-keys
- show ip ssh rsa-authentication
- ssh

crypto key generate

Generate keys for the SSH server.

Syntax

crypto key generate {rsa | rsa1}

Parameters

rsa	Enter the keyword rsa followed by the key size to generate a SSHv2 RSA host keys.
	Range: 1024 to 2048
	Default: 1024
rsa1	Enter the keyword rsa1 followed by the key size to generate a SSHv1 RSA host keys.
	Range: 1024 to 2048
	Default: 1024

Defaults

Key size 1024

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-6. crypto key generate rsa1 command example

```
FTOS#conf
FTOS(conf)#crypto key generate rsal
Enter key size <1024-2048>. Default<1024>: 1024
Host key already exists. Do you want to replace. [y/n]
FTOS (conf) #
```

Usage Information

The host keys are required for key-exchange by the SSH server. If the keys are not found when the server is enabled (**ip ssh server enable**), the keys are automatically generated.

This command requires user interaction and will generate a prompt prior to overwriting any existing host keys.



Note: Only a user with superuser permissions should generate host-keys.

Related Commands

ip ssh server	Enable the SSH server.
show crypto	Display SSH host public keys

debug ip ssh

C E S Enables collecting SSH debug information.

Syntax debug ip ssh {client | server}

To disable debugging, use the **no debug ip ssh** {client | server} command.

Parameters

client	Enter the keyword client to enable collecting debug information on the client.
server	Enter the keyword server to enable collecting debug information on the server.

Defaults Disabled on both client and server

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information Debug information includes details for key-exchange, authentication, and established session for each connection.

ip scp topdir

(C) (E) (S) Identify a location for files used in secure copy transfer.

Syntax ip scp topdir directory

To return to the default setting, enter **no ip scp topdir** command.

Parameters

directory	Enter a directory name.	

Defaults The internal flash (**flash:**) is the default directory.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

To configure the switch as a SCP server, use the ip ssh server command.

Related Commands

ip ssh server	Enable SSH and SCP server on the switch.	

ip ssh authentication-retries

CES Configure the maximum number of attempts that should be used to authenticate a user.

Syntax ip ssh authentication-retries 1-10

Parameters

1-10 Enter the number of maximum retries to authenticate a user. Range: 1 to 10 Default: 3

Defaults 3

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information This command specifies the maximum number of attempts to authenticate a user on a SSH connection with the remote host for password authentication. SSH will disconnect when the number of password failures exceeds authentication-retries.

ip ssh connection-rate-limit

CES Configure the maximum number of incoming SSH connections per minute.

Syntax ip ssh connection-rate-limit 1-10

Parameters

1-10	Enter the number of maximum number of incoming SSH connections allowed per minute.
	Range: 1 to 10 per minute
	Default: 10 per minute

Defaults 10 per minute

Command Modes CONFIGURATION

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ip ssh hostbased-authentication

CES Enable hostbased-authentication for the SSHv2 server.

Syntax ip ssh hostbased-authentication enable

To disable hostbased-authentication for SSHv2 server, use the **no ip ssh hostbased-authentication enable** command.

Parameters

enable Enter the keyword **enable** to enable hostbased-authentication for SSHv2 server.

Defaults Disable by default

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

If this command is enabled, clients can login without a password prompt. This provides two levels of authentication:

- rhost-authentication is done with the file specified in the **ip ssh rhostfile** command
- checking client host-keys is done with the file specified in the ip ssh pub-key-file command

If no ip ssh rsa-authentication enable is executed, host-based authentication is disabled.



Note: Administrators must specify the two files (rhosts and pub-key-file) to configure host-based authentication.

Related Commands

ip ssh pub-key-file	Public keys of trusted hosts from a file.
ip ssh rhostsfile	Trusted hosts and users for rhost authentication.

ip ssh key-size

CES Configure the size of the server-generated RSA SSHv1 key.

Syntax ip ssh key-size 512-869

Parameters

512-869	Enter the key-size number for the server-generated RSA SSHv1 key.
	Range: 512 to 869
	Default: 768

Defaults Key size 768

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series

Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

The server-generated key is used for SSHv1 key-exchange.

ip ssh password-authentication

CES Enable password authentication for the SSH server.

Syntax ip ssh password-authentication enable

To disable password-authentication, use the **no ip ssh password-authentication enable**.

Parameters

enable Enter the keyword **enable** to enable password-authentication for the SSH server.

Defaults enabled

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information With password authentication enabled, users can authenticate using local, RADIUS, or TACACS+ password fallback order as configured.

ip ssh pub-key-file

CES Specify the file to be used for host-based authentication.

Syntax ip ssh pub-key-file { WORD}

Parameters WORD Enter the file name for the host-based authentication.

Defaults No default behavior or values

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 35-7. ip ssh pub-key-file Command Example

FTOS#conf FTOS(conf)# ip ssh pub-key-file flash://knownhosts FTOS(conf)#

Usage Information

This command specifies the file to be used for the host-based authentication. The file creates/ overwrites the file flash://ADMIN_DIR/ssh/knownhosts and deletes the user specified file. Even though this is a global configuration command, it will not appear in the running configuration since this command needs to be run just once.

The file contains the OpenSSH compatible public keys of the host for which host-based authentication is allowed. An example known host file format:

poclab4,123.12.1.123 ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAox/QQp8xYhzOxn07yh4VGPAoUfgKoieTHO9G4sNV+ui+DWEc3cgYAcU5Lai1MU2ODrzhCwyDNp05tKBU3tReG1o8AxLi6+S4hyEMqHzkzBFNVqHzpQc+Rs4p2urzV0F4pRKnaXdHf3Lk4D460HZRhhVrxqeNxPDpEnWIMPJi0ds= ashwani@poclab4



Note: For **rhostfile** and **pub-key-file**, the administrator must FTP the file to the chassis.

Related Commands

show ip ssh client-pub-keys Display the client-public keys used for the host-based authentication.

ip ssh rhostsfile

CES

Specify the rhost file to be used for host-based authorization.

Syntax

ip ssh rhostsfile { WORD}

Parameters

WORD	Enter the rhost file name for the host-based authentication.	
------	--	--

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-8. ip ssh rhostsfile Command Example

FTOS#conf FTOS(conf)# ip ssh rhostsfile flash://shosts FTOS(conf)#

Usage Information

This command specifies the rhost file to be used for host-based authentication. This file creates/ overwrites the file flash:/ADMIN_DIR/ssh/shosts and deletes the user specified file. Even though this is a global configuration command, it will not appear in the running configuration since this command needs to be run just once.

This file contains hostnames and usernames, for which hosts and users, rhost-authentication can be allowed.



Note: For **rhostfile** and **pub-key-file**, the administrator must FTP the file to the switch.

ip ssh rsa-authentication (Config)

Enable RSA authentication for the SSHv2 server. CES

Syntax ip ssh rsa-authentication enable

To disable RSA authentication, use the **no ip ssh rsa-authentication enable** command.

Parameters

enable Enter the keyword **enable** to enable RSA authentication for the SSHv2 server.

Defaults RSA authentication is disabled by default

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1 Introduced on S60 Version 7.6.1.0 Introduced for S-Series Version 7.5.1.0 Introduced for C-Series pre-Version 6.1.1.0 Introduced for E-Series

Usage Information Enabling RSA authentication allows the user to login without being prompted for a password. In addition, the OpenSSH compatible SSHv2 RSA public key must be added to the list of authorized keys (ip ssh rsa-authentication my-authorized-keys device://filename command).

Related Commands

Add keys for RSA authentication. ip ssh rsa-authentication (EXEC)

ip ssh rsa-authentication (EXEC)

Add keys for the RSA authentication. CES

ip ssh rsa-authentication {my-authorized-keys WORD} Syntax

To delete the authorized keys, use the **no ip ssh rsa-authentication {my-authorized-keys}**

command.

Parameters my-authorized-keys WORD Enter the keyword **my-authorized-keys** followed by the file name of the RSA authorized-keys.

Defaults No default behavior or values

Command Modes EXEC

> Command Version 8.3.3.1 Introduced on S60 History Version 7.6.1.0 Introduced for S-Series

Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

If you want to log in without being prompted for a password, log in through RSA authentication. To do that, you must first add the SSHv2 RSA public keys to the list of authorized keys. This command adds the specified RSA keys to the following file:

flash://**ADMIN_DIR**/ssh/authorized-keys-username (where username is the user associated with this terminal).



Note: The **no** form of this command deletes the file flash://ADMIN_DIR/ssh/authorized-keys-username

Related Commands

show ip ssh rsa-authentication	Display RSA authorized keys.
ip ssh rsa-authentication (Config)	Enable RSA authentication.

ip ssh server



Configure an SSH server.

Syntax

ip ssh server {enable | port port-number} [version {1 | 2}]

To disable SSH server functions, enter **no ip ssh server enable** command.

Parameters

enable	Enter the key word enable to start the SSH server.
port port-number	(OPTIONAL) Enter the keyword port followed by the port number of the listening port of the SSH server. Range: 1 to 65535 Default: 22
[version {1 2}]	(OPTIONAL) Enter the keyword version followed by the SSH version 1 or 2 to specify only SSHv1 or SSHv2.

Defaults

Default listening port is 22

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Expanded to include specifying SSHv1 or SSHv2; Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

This command enables the SSH server and begins listening on a port. If a port is not specified, listening is on SSH default port 22.

Example

Figure 35-9. ip ssh server port Command Example

```
FTOS# conf
FTOS(conf)# ip ssh server port 45
FTOS(conf)# ip ssh server enable
FTOS#
```

Related **Commands**

show ip ssh Display the ssh information

show crypto

CES

Display the public part of the SSH host-keys.

Syntax

show crypto key mypubkey {rsa | rsa1}

Parameters

Key	Enter the keyword key to display the host public key.
mypubkey	Enter the keyword mypubkey to display the host public key.
rsa	Enter the keyword rsa to display the host SSHv2 RSA public key.
rsa1	Enter the keyword rsa1 to display the host SSHv1 RSA public key.

Defaults

No default behavior or values

Command Modes

EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-10. show crypto Command Examples

FTOS#show crypto key mypubkey rsa ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAtzkZME/ e8V8smnXR22EJGQhCMkEOkuisa+OILVoMYU1ZKGfj0W5BPCSvF/ x5ifqYFFwUzJNOcsJK7vjSsnmMhChF2YSvXlvTJ6h971FJAQlOsgd0ycpocsF+DNLKfJnx7SAjhakFQMwG g/g78ZkDT3Ydr8KKjfSI4Bg/WS8B740=

FTOS#show crypto key mypubkey rsa1 1024 35

7988956754966765265006379622189779927609278523638839223055081819166009928132616408 6643457746022192295189039929663345791173742247431553750501676929660273790601494434 050000015179864425629613385774919236081771341059533760063913083FTOS#

Usage Information

This command is useful if the remote SSH client implements Strict Host Key Checking. You can copy the host key to your list of known hosts.

Related **Commands**

Generate SSH keys. crypto key generate

show ip ssh

CES

Display information about established SSH sessions.

Syntax

show ip ssh

Command Modes EXEC

EXEC Privilege

Example

Figure 35-11. show ip ssh Command Example

```
.
FTOS#show ip ssh
SSH server
                           : enabled.
SSH server version
                           : v1 and v2.
Password Authentication
                          : enabled.
Hostbased Authentication
                          : disabled
RSA
             Authentication : disabled.
   Vty
                Encryption
                                 Remote IP
   0
                3DES
                                 172.16.1.162
   1
                3DES
                                 172.16.1.162
                                 172.16.1.162
FTOS
```

Related Commands

ip ssh server	Configure an SSH server.
show ip ssh client-pub-keys	Display the client-public keys.

show ip ssh client-pub-keys

Display the client public keys used in host-based authentication.

Syntax show ip ssh client-pub-keys

Defaults No default behavior or values

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-12. show ip ssh client-pub-keys Command Example

FTOS#show ip ssh client-pub-keys

poclab4,123.12.1.123 ssh-rsa AAAAB3NzaC1yc2EAAAABIWAAAIEAox/ QQp8xYhzOxn07yh4VGPAoUfgKoieTHO9G4sNV+ui+DWEc3cgYAcU5Lai1MU2ODrzhCwyDNp05tKBU3tReG1 o8AxLi6+S4hyEMqHzkzBFNVqHzpQc+Rs4p2urzV0F4pRKnaXdHf3Lk4D460HZRhhVrxqeNxPDpEnWIMPJi0 ds= ashwani@poclab4

FTOS#

Usage Information

This command displays the contents of the file flash://ADMIN_DIRssh/knownhosts

Related Commands

ip ssh pub-key-file Configure the file name for the host-based authentication

show ip ssh rsa-authentication

Display the authorized-keys for the RSA authentication. CES

Syntax show ip ssh rsa-authentication {my-authorized-keys}

Parameters

my-authorized-keys Display the RSA authorized keys.

Defaults No default behavior or values

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 35-13. show ip ssh rsa-authentication Command Example

FTOS#show ip ssh rsa-authentication my-authorized-keys ssh-rsa

AAAAB3NzaC1yc2EAAAABIwAAAIEAyB1714gFp4r2DRHIvMc1VZd0Sg5GQxRV1y1X1JOMeO6Nd0WuYyzrQMM4qJAoBwtneOXfLBcHF3V2hcMIqaZN+CRCnw/

 $\verb|zcMlnCf0+qVTdloofsea5r09ks| 0xTp0CNfHXZ3NuGCq9Ov33m9+U9tMwhS8vy8AVxdH4x4km3c3t5Jvc=| |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |xdefined | |$ freedom@poclab4

FTOS#

Usage Information

This command displays the contents of the file flash:/ADMIN_DIR/ssh/authorized-keys.username.

Related **Commands**

ip ssh rsa-authentication (Config) Configure the RSA authorized keys.

ssh

CES

Open an SSH connection specifying the hostname, username, port number and version of the SSH

Syntax

ssh { hostname | ipv4 address | ipv6 address} [-I username | -p port-number | -v {1 | 2}]

Parameters

hostname	(OPTIONAL) Enter the IP address or the hostname of the remote device.
vrf instance	(OPTIONAL) E-Series Only : Enter the keyword vrf following by the VRF Instance name to open a SSH connection to that instance.
ipv4 address	(OPTIONAL) Enter the IP address in dotted decimal format A.B.C.D.
ipv6-address prefix-length	(OPTIONAL) Enter the IPv6 address in the x:x:x:x:x format followed by the prefix length in the /x format. Range: /0 to /128
	Note: The :: notation specifies successive hexadecimal fields of zeros
-I username	(OPTIONAL) Enter the keyword -I followed by the user name used in this SSH session.
	Default: The user name of the user associated with the terminal.

-p port-number	(OPTIONAL) Enter the keyword -p followed by the port number.
	Range: 1 to 65536
	Default: 22
-v {1 2}	(OPTIONAL) Enter the keyword -v followed by the SSH version 1 or 2.
	Default: The version from the protocol negotiation

Defaults

As above.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.9.1.0	Introduced VRF
Version 7.6.1.0	Introduced for S-Series
Version 7.5.1.0	Added IPv6 support; Introduced for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 35-14. ssh Command Example

FTOS#ssh 123.12.1.123 -l ashwani -p 5005 -v 2

Secure DHCP Commands

DHCP as defined by RFC 2131 provides no authentication or security mechanisms. Secure DHCP is a suite of features that protects networks that use dynamic address allocation from spoofing and attacks.

- clear ip dhcp snooping
- ip dhcp relay
- ip dhcp snooping
- ip dhcp snooping database
- ip dhcp snooping binding
- ip dhcp snooping database renew
- ip dhcp snooping trust
- ip dhcp source-address-validation
- ip dhcp snooping vlan
- · show ip dhcp snooping

clear ip dhcp snooping

C S Clear the DHCP binding table.

Syntax clear ip dhcp snooping binding

Command Modes EXEC Privilege

Default None

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

Related Commands

show ip dhcp snooping Display the contents of the DHCP binding table.

ip dhcp relay

Parameters

Enable Option 82.

Syntax ip dhcp relay information-option [trust-downstream]

trust-downstream Configure the system to trust Option 82 when it is received from the previous-hop router.

Command Modes CONFIGURATION

> **Default** Disabled

Command Version 8.3.3.1 History

Introduced on S60 Version 7.8.1.0 Introduced on C-Series and S-Series

ip dhcp snooping

Enable DHCP Snooping globally.

Syntax [no] ip dhcp snooping

Command Modes CONFIGURATION

> **Default** Disabled

Command History

Version 8.3.3.1 Introduced on S60 Version 7.8.1.0 Introduced on C-Series and S-Series

Usage Information When enabled, no learning takes place until snooping is enabled on a VLAN. Upon disabling DHCP Snooping the binding table is deleted, and Option 82, IP Source Guard, and Dynamic ARP Inspection

are disabled.

Related **Commands**

ip dhep snooping vlan Enable DHCP Snooping on one or more VLANs.

ip dhcp snooping database

Delay writing the binding table for a specified time.

Syntax ip dhcp snooping database write-delay minutes

Command History

Version 8.3.3.1 Introduced on S60

Version 7.8.1.0 Introduced on C-Series and S-Series

ip dhcp snooping binding

Create a static entry in the DHCP binding table.

Syntax [no] ip dhcp snooping binding mac address vlan-id ip ip-address interface type slot/port lease number

Parameters

mac address	Enter the keyword mac followed by the MAC address of the host to which the server is leasing the IP address.
vlan-id vlan-id	Enter the keyword vian-id followed by the VLAN to which the host belongs.
	Range: 2-4094
ip ip-address	Enter the keyword ip followed by the IP address that the server is leasing.
interface type	Enter the keyword interface followed by the type of interface to which the host is connected.
	• For an 10/100 Ethernet interface, enter the keyword fastethernet .
	• For a Gigabit Ethernet interface, enter the keyword gigabitethernet .
	 For a SONET interface, enter the keyword sonet.
	 For a Ten Gigabit Ethernet interface, enter the keyword tengigabitethernet.
slot/port	Enter the slot and port number of the interface.
lease time	Enter the keyword lease followed by the amount of time the IP address will be leased.
	Range: 1-4294967295

Command Modes EXEC

EXEC Privilege

Default None

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series
show in dhen snooning	Display the contents of the DHCP hinding table

Related Commands

ip dhcp snooping database renew

Renew the binding table.

Syntax ip dhcp snooping database renew

Command Modes EXEC

EXEC Privilege

Default None

Command History

Version 8.3.3.1	Introduced on S60
Version 7.8.1.0	Introduced on C-Series and S-Series

ip dhcp snooping trust

Configure an interface as trusted.

Syntax [no] ip dhcp snooping trust

Command Modes INTERFACE

> Default Untrusted

Command History

Version 8.3.3.1 Introduced on S60 Version 7.8.1.0 Introduced on C-Series and S-Series

ip dhcp source-address-validation

Enable IP Source Guard. $\mathbb{C}[\mathbb{S}]$

[no] ip dhcp source-address-validation

Command Modes INTERFACE

Syntax

Default Disabled

Command History

Version 8.3.3.1 Introduced on S60 Version 7.8.1.0 Introduced on C-Series and S-Series

ip dhcp snooping vlan

Enable DHCP Snooping on one or more VLANs.

Syntax [no] ip dhcp snooping vlan name

Command -History _

Version 8.3.3.1 Introduced on S60

Version 7.8.1.0 Introduced on C-Series and S-Series

Usage Information

When enabled the system begins creating entries in the binding table for the specified VLAN(s). Note that learning only happens if there is a trusted port in the VLAN.

Related Commands

ip dhcp snooping trust Configure an interface as trusted.

show ip dhcp snooping

C S Display the contents of the DHCP binding table.

Syntax show ip dhcp snooping binding

Command Modes EXEC

EXEC Privilege

Default None

Command History

Version 8.3.3.1 Introduced on S60

Version 7.8.1.0 Introduced on C-Series and S-Series

Related Commands

clear ip dhcp snooping Clear the contents of the DHCP binding table.

Service Provider Bridging

Overview

Service Provider Bridging is composed of VLAN Stacking, Layer 2 Protocol Tunneling, and Provider Backbone Bridging as described in the FTOS Configuration Guide Service Provider Bridging chapter.

This chapter includes CLI information for FTOS Layer 2 Protocol Tunneling (L2PT). L2PT enables protocols to tunnel through an 802.1q tunnel. L2PT is available in FTOS for the C-Series C, E-Series E, and S-Series S.

L2PT is supported on E-Series ExaScale $\boxed{\mathbb{E}_{|X|}}$ with FTOS 8.2.1.0. and later.

Refer to Chapter 45, VLAN Stacking or Chapter 41, Spanning Tree Protocol (STP) and Chapter 12, GARP VLAN Registration (GVRP) for further information related to those features.

Commands

The L2PT commands are:

- debug protocol-tunnel
- protocol-tunnel
- protocol-tunnel destination-mac
- protocol-tunnel enable
- protocol-tunnel rate-limit
- show protocol-tunnel

Important Points to Remember

- L2PT is enabled at the interface VLAN-Stack VLAN level. For details on Stackable VLAN (VLAN-Stacking) commands, see Chapter 45, VLAN Stacking.
- The default behavior is to disable protocol packet tunneling through the 802.1q tunnel.
- Rate-limiting is required to protect against BPDU attacks.
- A port channel (including through LACP) can be configured as a VLAN-Stack access or trunk
- ARP packets work as expected across the tunnel.
- FEFD works the same as with Layer 2 links.
- Protocols that use Multicast MAC addresses (OSPF for example) work as expected and carry over to the other end of the VLAN-Stack VLAN.

debug protocol-tunnel

Enable debugging to ensure incoming packets are received and rewritten to a new MAC address.

Syntax debug protocol-tunnel interface {in | out | both} [vlan vlan-id] [count value]

To disable debugging, use the **no debug protocol-tunnel interface {in | out | both} [vlan** *vlan-id*] [count *value*] command.

Parameters

interface	Enter one of the following interfaces and slot/port information:
	 For a Fast Ethernet interface, enter the keyword FastEthernet followed by the slot/port information.
	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	• For Port Channel interface types, enter the keyword port-channel followed by a number from 1 to 255 for TeraScale and ExaScale.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
in out both	Enter the keyword in , out , or both to debug incoming interfaces, outgoing interfaces, or both incoming and outgoing interfaces.
vlan vlan-id	Enter the keyword vian followed by the VLAN ID.
	Range: 1 to 4094
count value	Enter the keyword count followed by the number of debug outputs.
	Range: 1 to 100
Debug Disabled	
EXEC Privilege	
Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the C-Series, E-Series and E-Series ExaScale.

protocol-tunnel

Defaults

Command History

Command Modes

© E S Enable protocol tunneling per VLAN-Stack VLAN.

Syntax protocol-tunnel stp

Version 7.4.1.0

To disable protocol tunneling, use the **no protocol-tunnel stp** command.

Introduced

Stp Enter the keyword **Stp** to enable protocol tunneling on a spanning tree, including STP, MSTP, RSTP, and PVST.

Defaults No default values or behavior

Command Modes CONF-IF-VLAN

Command

History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the C-Series, E-Series and E-Series ExaScale.
Version 7.4.1.0	Introduced

Example

Figure 36-1. Protocol-tunneling Command Example

```
FTOS#conf
FTOS(conf)#interface vlan 2
FTOS(conf-if-vl-2)#vlan-stack compatible
FTOS(conf-if-vl-2)#member Gi1/2-3
FTOS(conf-if-v1-2) #protocol-tunnel stp
FTOS (conf-if-v1-2)#
```

Usage Information



Note: When VLAN-Stacking is enabled, no protocol packets are tunneled.

Related Commands

show protocol-tunnel

Display tunneling information for all VLANs

protocol-tunnel destination-mac

CES

Overwrite the BPDU destination MAC address with a specific value.

Syntax

protocol-tunnel destination-mac xstp address

Parameters

Change the default destination MAC address used for L2PT to another value. stp

Defaults

The default destination MAC is 01:01:e8:00:00:00.

Command Modes

CONFIGURATION

Command **History**

Versio	on 8.3.3.1	Introduced on S60
Versio	on 8.2.1.0	Introduced on the C-Series and S-Series.
Versio	on 7.4.1.0	Introduced

Usage Information

When VLAN-Stacking is enabled, no protocol packets are tunneled.

Related Commands

Display tunneling information for all VLANs show protocol-tunnel

protocol-tunnel enable

CES

Enable protocol tunneling globally on the system.

Syntax

protocol-tunnel enable

To disable protocol tunneling, use the **no protocol-tunnel enable** command.

Defaults

Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60
Version 7.4.1.0 Introduced

Usage Information FTOS must have the default CAM profile with the default microcode before you enable L2PT.

protocol-tunnel rate-limit

CES Enable traffic rate limiting per box.

Syntax protocol-tunnel rate-limit rate

To reset the rate limit to the default, use the **no protocol-tunnel rate-limit** *rate* command.

Parameters

rate Enter the rate in frames per second.
Range: 75 to 3000
Default: 75

Defaults 75 Frames per second

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60

Version 8.2.1.0 Introduced on the C-Series, E-Series Terascale, and E-Series ExaScale. Maximum rate limit on E-Series reduced from 4000 to 3000.

Version 7.4.1.0 Introduced

Example Figure 36-2. protocol-tunnel rate-limit Command Example

FTOS#
FTOS#conf
FTOS(conf)#protocol-tunnel rate-limit 1000
FTOS(conf)#

Related Commands

show protocol-tunnel	Display tunneling information for all VLANs
show running-config	Display the current configuration.

show protocol-tunnel

Display protocol tunnel information for all or a specified VLAN-Stack VLAN.

Syntax show protocol-tunnel [vlan vlan-id]

Parameters

vlan vlan-id(OPTIONAL) Enter the keyword vlan followed by the VLAN ID to display information
for the one VLAN.Range: 1 to 4094

Defaults No default values or behavior

Command Modes EXEC

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the C-Series, E-Series and E-Series ExaScale.
Version 7.4.1.0	Introduced

Example Figure 36-3. show protocol-tunnel Command Example

```
FTOS#show protocol-tunnel
System Rate-Limit: 1000 Frames/second
                 Vlan Protocol(s)
2 STP, PVST
Interface
                                  STP, PVST
STP, PVST
STP, PVST
Gi1/2
Gi1/3
                      3
Po35
                      4
FTOS#
```

Example Figure 36-4. show protocol-tunnel command example for a specific VLAN

```
FTOS#show protocol-tunnel vlan 2
System Rate-Limit: 1000 Frames/second
Interface Vlan Protocol(s)
Gi1/2
              2
                      STP, PVST
FTOS#
```

Related Commands

show running-config	Display the current configuration.	
---------------------	------------------------------------	--

sFlow

Overview

sFlow commands are supported on these platforms: [C][E][S].

FTOS sFlow monitoring system includes an sFlow Agent and an sFlow Collector. The sFlow Agent combines the flow samples and interface counters into sFlow datagrams and forwards them to the sFlow Collector. The sFlow Collector analyses the sFlow Datagrams received from the different devices and produces a network-wide view of traffic flows.

Important Points to Remember

- Dell Networking recommends that the sFlow Collector be connected to the Dell Networking chassis through a line card port rather than the RPM Management Ethernet port.
- FTOS exports all sFlow packets to the sFlow Collector. A small sampling rate can equate to a large number of exported packets. A backoff mechanism will automatically be applied to reduce this amount. Some sampled packets may be dropped when the exported packet rate is high and the backoff mechanism is about to or is starting to take effect. The dropEvent counter, in the sFlow packet, will always be zero.
- sFlow sampling is done on a per-port basis.
- Community list and local preference fields are not filled up in the extended gateway element in the sFlow datagram.
- The 802.1P source priority field is not filled up in the extended switch element in the sFlow datagram.
- Only Destination and Destination Peer AS numbers are packed in the dst-as-path field in the extended gateway element.
- If the packet being sampled is redirected using PBR (Policy-Based Routing), the sFlow datagram may contain incorrect extended gateway/router information.
- sFlow does not support packing extended information for IPv6 packets. Only the first 128 bytes of the IPv6 packet is shipped in the datagram.
- The source VLAN field in the extended switch element will not be packed in case of a routed
- The destination VLAN field in the extended switch element will not be packed in case of a multicast packet.
- The maximum number of packets that can be sampled and processed per second is:
 - 7500 packets when no extended information packing is enabled
 - 7500 packets when only extended-switch information packing is enabled (see sflow extended-switch enable)
 - 1600 packets when extended-router and/or extended-gateway information packing is enabled (see Figure and sflow extended-gateway enable)
- There is no limit on the number of interfaces where sFlow can be enabled.

Commands

The sFlow commands are:

- · sflow collector
- sflow enable (Global)
- sflow enable (Interface)
- sflow extended-gateway enable
- sflow extended-router enable
- sflow extended-switch enable
- sflow polling-interval (Global)
- sflow polling-interval (Interface)
- sflow sample-rate (Global)
- sflow sample-rate (Interface)
- show sflow
- show sflow linecard

sflow collector

CES

Specify a collector(s) to which sFlow datagrams are forwarded.

Syntax

sflow collector *ip-address* **agent-addr** *ip-address* [*number* [**max-datagram-size** *number*]] | [**max-datagram-size** *number*]

To delete the specified collector(s), use the **no sflow collector** *ip-address* **agent-addr** *ip-address* [number [max-datagram-size number]] | [max-datagram-size number] command

Parameters

ip-address	Enter the ip address of the collector in dotted decimal format.
agent-addr ip-address	Enter the keyword agent-addr followed by the sFlow agent IP address in dotted decimal format.
number	(OPTIONAL) Enter the udp port number (User Datagram Protocol).
	Range: 0 to 65535
	Default: 6343
max-datagram-size number	(OPTIONAL) Enter the keyword max-datagram-size followed by the size number in bytes. Range: 400 to 1500 Default: 1400

Defaults

Not configured

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series

Version 6.5.1.0	Expanded the no form of the command to mirror the syntax used to configure
Version 6.2.1.1	Introduced on E-Series

Usage Information

You can specify up to 2 sFlow collectors. If 2 collectors are specified, the samples are sent to both.

As part of the sFlow-MIB, if the SNMP request originates from a configured collector, FTOS will return the corresponding configured agent IP in MIB requests. FTOS checks to ensure that two entries are not configured for the same collector IP with a different agent IP. Should that happen, FTOS generates the following error:

%Error: Different agent-addr attempted for an existing collector

sflow enable (Global)

CES Enable sFlow globally.

Syntax sflow enable

To disable sFlow, use the **no sflow enable** command.

Defaults sFlow is disabled by default

Command Modes CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

sFlow is disabled by default. In addition to this command, sFlow needs to be enable on individual interfaces where sFlow sampling is desired.

Related **Commands**

sflow enable (Interface) Enable sFlow on Interfaces.

sflow enable (Interface)

CESEnable sFlow on Interfaces.

Syntax sflow enable

To disable sFlow, use the **no sflow enable** command.

Defaults sFlow is disabled by default on all interfaces

Command Modes **INTERFACE**

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

When sFlow is enable on an interface, flow sampling is done on any traffic going out of the interface.



Note: Once a physical port is a member of a LAG, it will inherit the sFlow configuration from the LAG port.

Related Commands

sflow enable (Global) Turn sFlow on globally

sflow extended-gateway enable

Enable packing information on an extended gateway.

Syntax sflow extended-gateway [extended-router] [extended-switch] enable

To disable packing information, use the **no sflow extended-gateway [extended-router]** [extended-switch] enable command.

Parameters

extended-router	Enter the keyword extended-router to collect extended router information.
extended-switch	Enter the keyword extended-switch to collect extended switch information.
enable	Enter the keyword enable to enable global extended information.

Defaults

Disabled

Command Modes

CONFIGURATION

Command History

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Introduced on E-Series

Usage Information

The **show sflow** command displays the configured global extended information.

FTOS 7.8.1.0 and later enhances the sFlow implementation for real time traffic analysis on the E-Series to provide extended gateway information in cases where the destination IP addresses are learned by different routing protocols, and for cases where the destination is reachable over ECMP.

Example Figure 37-1. show sflow Command Output

```
.
FTOS#show sflow
sFlow services are enabled
Global default sampling rate: 64
Global default counter polling interval: 1000
Global extended information enabled: gateway, router, switch
1 collectors configured
Collector IP addr: 20.20.20.2, Agent IP addr: 10.11.201.7, UDP port: 6343
1732336 UDP packets exported
0 UDP packets dropped
12510225 sFlow samples collected
0 sFlow samples dropped due to sub-sampling
```

Related Commands

show sflow Display the sFlow configuration

sflow extended-router enable

Enable packing information on a router and switch.

Syntax sflow extended-router [extended-switch] enable

To disable packing information, use the no sflow extended-router [extended-switch] enable command.

Parameters

extended-switch	Enter the keyword extended-switch to collect extended switch information.
enable	Enter the keyword enable to enable global extended information.

Defaults Disabled

Command Modes CONFIGURATION

Command **History**

Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.4.1.0	Introduced on E-Series

Usage Information

FTOS 7.8.1.0 and later enhances the sFlow implementation for real time traffic analysis on the E-Series to provide extended gateway information in cases where the destination IP addresses are learned by different routing protocols, and for cases where the destination is reachable over ECMP.

Related Commands

sflow extended-gateway enable	Enable packing information on an extended gateway
sflow extended-switch enable	Enable packing information on a switch.
show sflow	Display the sFlow configuration

sflow extended-switch enable

CES Enable packing information on a switch only.

Syntax sflow extended-switch enable

To disable packing information, use the **no sflow extended-switch [enable]** command.

Parameters

enable Enter the keyword **enable** to enable global extended information.

Defaults

Disabled

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced on E-Series

Usage Information

FTOS 7.8.1.0 and later enhances the sFlow implementation for real time traffic analysis on the E-Series to provide extended gateway information in cases where the destination IP addresses are learned by different routing protocols, and for cases where the destination is reachable over ECMP.

Related Commands

sflow extended-gateway enable	Enable packing information on an extended gateway.
sflow extended-router enable	Enable packing information on a router.
show sflow	Display the sFlow configuration

sflow polling-interval (Global)

CES

Set the sFlow polling interval at a global level.

Syntax

sflow polling-interval interval value

To return to the default, use the **no sflow polling-interval** interval command.

Parameters

interval value	Enter the interval value in seconds.
	Range: 15 to 86400 seconds
	Default: 20 seconds

Defaults

20 seconds

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

The polling interval for an interface is the maximum number of seconds between successive samples of counters to be sent to the collector. This command changes the global default counter polling (20 seconds) interval. You can configure an interface to use a different polling interval.

Related **Commands**

sflow polling-interval (Interface)

Set the polling interval for an interface

sflow polling-interval (Interface)

Set the sFlow polling interval at an interface (overrides the global-level setting.) CES

Syntax sflow polling-interval interval value

To return to the default, use the **no sflow polling-interval** interval command.

Parameters

interval value Enter the interval value in seconds. Range: 15 to 86400 seconds Default: The global counter polling interval

Defaults The same value as the current global default counter polling interval

Command Modes INTERFACE

> Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

This command sets the counter polling interval for an interface.

Related Commands

sflow polling-interval (Global)

Globally set the polling interval

sflow sample-rate (Global)

CES Change the global default sampling rate.

sflow sample-rate value **Syntax**

To return to the default sampling rate, enter the **no sflow sample-rate**.

Parameters value Enter the sampling rate value.

> Range: C-Series and S-Series: 256 to 8388608 packets E-Series TeraScale and ExaScale: 2 to 8388608

Enter values in powers of 2 only, for example 4096, 8192, 16384 etc.

Default: 32768 packets

Defaults 32768

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

Sample-rate is the average number of packets skipped before the sample is taken. This command changes the global default sampling rate. You can configure an interface to use a different sampling rate than the global sampling rate. If the value entered is not a correct power of 2, the command generates an error message with the previous and next power of 2 value. Select one of these two packet numbers and re-enter the command.

Related Commands

sflow sample-rate (Interface)

Change the Interface sampling rate.

sflow sample-rate (Interface)

CES

Change the Interface default sampling rate.

Syntax sflow sample-rate value

To return to the default sampling rate, enter the **no sflow sample-rate**.

Parameters

value	Enter the sampling rate value.
	Range: C-Series and S-Series: 256 to 8388608 packets
	E-Series TeraScale and ExaScale: 2 to 8388608 packets
	Enter values in powers of 2 only, for example 4096, 8192, 16384 etc.
	Default: 32768 packets

Defaults

The Global default sampling

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Usage Information

This command changes the sampling rate for an Interface. By default, the sampling rate of an interface is set to the same value as the current global default sampling rate. If the value entered is not a correct power of 2, the command generates an error message with the previous and next power-of-2 value. Select one of these two number and re-enter the command.

Related Commands

sflow sample-rate (Global)

Change the sampling rate globally.

show sflow

CES

Display the current sFlow configuration

Syntax

show sflow [interface]

Parameters

interface

(OPTIONAL) Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Example

Figure 37-2. show sflow Command Example

```
FTOS#show sflow
sFlow services are enabled
Global default sampling rate: 32768
Global default counter polling interval: 20
1 collectors configured
Collector IP addr: 133.33.33.53, Agent IP addr: 133.33.31.116, UDP port: 6343
0 UDP packets exported
0 UDP packets dropped
165 sFlow samples collected
0 sFlow samples dropped due to sub-sampling—This count is always zero (0)
Linecard 1 Port set 0 H/W sampling rate 8192
 Gi 1/16: configured rate 8192, actual rate 8192, sub-sampling rate 1 Gi 1/17: configured rate 16384, actual rate 16384, sub-sampling rate 2
Linecard 3 Port set 1 H/W sampling rate 16384
  Gi 3/40: configured rate 16384, actual rate 16384, sub-sampling rate 1
FTOS#
```

Usage Information

The dropEvent counter (sFlow samples dropped due to sub-sampling) shown in the figure above will always display a value of zero.

show sflow linecard

CES Display the sFlow information on a line card.

Syntax show sflow linecard { slot number}

Parameters

slot number (OPTIONAL) Enter a slot number to view information on the line card in that slot.

Range: 0 to 13 on a E1200, 0 to 6 on a E600/E600i, and 0 to 5 on a E300.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduces on S-Series Stacking
Version 8.1.1.0	Introduced on E-Series ExaScale
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced on E-Series

Example

Figure 37-3. show sflow linecard Command Example

```
FTOS#show sflow linecard 1
Linecard 1
Samples rcvd from h/w :165
Samples dropped for sub-sampling :0
Total UDP packets exported :0
UDP packets exported via RPM :77
UDP packets dropped :
FTOS#
```

SNMP and Syslog

Overview

This chapter contains commands to configure and monitor SNMP v1/v2/v3 and Syslog. Both features are supported on the C-Series, E-Series, and S-Series platforms, as indicated by the following symbols under each of the command headings: [C] [E] [S]

The chapter contains the following sections:

- **SNMP Commands**
- **Syslog Commands**

SNMP Commands

The SNMP commands available in FTOS are:

- show snmp
- show snmp engineID
- show snmp group
- show snmp user
- snmp ifmib ifalias long
- snmp-server community
- snmp-server contact
- snmp-server enable traps
- snmp-server engineID
- snmp-server group
- snmp-server host
- snmp-server location
- snmp-server packetsize
- snmp-server trap-source
- snmp-server user
- snmp-server view
- snmp trap link-status

The Simple Network Management Protocol (SNMP) is used to communicate management information between the network management stations and the agents in the network elements. FTOS supports SNMP versions 1, 2c, and 3, supporting both read-only and read-write modes. FTOS sends SNMP traps, which are messages informing an SNMP management system about the network. FTOS supports up to 16 SNMP trap receivers.

Important Points to Remember

- Typically, 5-second timeout and 3-second retry values on an SNMP server are sufficient for both LAN and WAN applications. If you experience a timeout with these values, the recommended best practice on Dell Networking switches (to accommodate their high port density) is to increase the timeout and retry values on your SNMP server to the following:
 - SNMP Timeout—greater than 3 seconds
 - SNMP Retry count—greater than 2 seconds
- If you want to query an E-Series switch using SNMP v1/v2/v3 with an IPv6 address, configure the IPv6 address on a non-management port on the switch.
- If you want to send SNMP v1/v2/v3 traps from an E-Series using an IPv6 address, use a non-management port.
- SNMP v3 informs are not currently supported with IPv6 addresses.
- If you are using ACLs in SNMP v3 configuration, group ACL overrides user ACL if the user is part of that group.
- SNMP operations are not supported on a VLAN.

show snmp

CES

Display the status of SNMP network elements.

Syntax

show snmp

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Example

Figure 38-1. show snmp Command Example

```
FTOS#show snmp
      32685 SNMP packets input
          0 Bad SNMP version errors
          0 Unknown community name
          0 Illegal operation for community name supplied
      0 Encoding errors
96988 Number of requested variables
          0 Number of altered variables
      31681 Get-request PDUs
        968 Get-next PDUs
          0 Set-request PDUs
      61727 SNMP packets output
          0 Too big errors (Maximum packet size 1500)
          9 No such name errors
          0 Bad values errors
          0 General errors
      32649 Response PDUs
      29078 Trap PDUs
FTOS#
```

Related Commands

snmp-server community

Enable SNMP and set community string.

show snmp engineID

CES

Display the identification of the local SNMP engine and all remote engines that are configured on the router.

Syntax

show snmp engineID

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
	E-Series legacy command

Example

Figure 38-2. show snmp engineID Command

FTOS#show snmp engineID Local SNMP engineID: 0000178B02000001E80214A8 Remote Engine ID 80001F88043132333435 IP-addr Port 172.31.1.3 5009 80001F88043938373635 172.31.1.3 FTOS#

Related Commands

snmp-server engineID

Configure local and remote SNMP engines on the router

show snmp group

CES

Display the group name, security model, status, and storage type of each group.

Syntax

show snmp group

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
	E-Series legacy command

Usage Information

The following example displays a group named **ngroup**. The ngroup has a security model of version 3 (v3) with authentication (auth), the read and notify name is nview with no write view name specified, and finally the row status is active.

Example Figure 38-3. show snmp group Command Example

FTOS#show snmp group groupname: ngroup readview : nview

notifyview: nview row status: active

FTOS#

Related Commands

snmp-server group

Configure an SNMP server group

security model: v3 auth

writeview: no write view specified

show snmp user

CES

Display the information configured on each SNMP user name.

Syntax

show snmp user

Command Modes

EXEC

EXEC Privilege

Example

Figure 38-4. show snmp user Command Example

FTOS#show snmp user User name: v1v2creadu

Engine ID: 0000178B02000001E80214A8 storage-type: nonvolatile Authentication Protocol: None active

Privacy Protocol: None

FTOS#

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
	E-Series legacy command

snmp ifmib ifalias long

CES

Display the entire description string through the Interface MIB, which would be truncated otherwise to 63 characters.

Syntax

snmp ifmib ifalias long

Defaults

Interface description truncated beyond 63 characters

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced for S-Series	-

Version 7.5.1.0	Introduced for C-Series
unknown	Introduced for E-Series

Example

Figure 38-5. snmp ifmib ifalias long Command Example

```
----command run on host connected to switch: --
> snmpwalk -c public 10.10.13.0 .1.3.6.1.2.1.31 | grep -i alias | more IF-MIB::ifAlias.134530304 = STRING: This is a port connected to Router2. This is a
port connected to
IF-MIB::ifAlias.134792448 = STRING:
!----command run on FTOS switch: -----!
FTOS#snmp ifmib ifalias long
!----command run on server connected to switch: -----!
> snmpwalk -c public 10.10.10.130 .1.3.6.1.2.1.31 | grep -i alias | more
IF-MIB::ifAlias.134530304 = STRING: This is a port connected to Router2. This is a
port connected to Router2. This is a port
connected to Router2. This is a port connected to Router2.
IF-MIB::ifAlias.134792448 = STRING:
```

snmp-server community



Configure a new community string access for SNMPv1, v2, and v3.

Syntax

snmp-server community community-name {ro | rw} [ipv6 ipv6-access-list-name [ipv6 ipv6-access-list-name | access-list-name | security-name name] | security-name name [ipv6 ipv6-access-list-name | access-list-name | security-name name | access-list-name [ipv6 ipv6-access-list-name | access-list-name | security-name name]]]

To remove access to a community, use the **no snmp-server community** community-string {ro | rw} [security-name name [access-list-name | ipv6 access-list-name | access-list-name ipv6 access-list-name]] command.

Parameters

community-name	Enter a text string (up to 20 characters long) to act as a password for SNMP.
ro	Enter the keyword ro to specify read-only permission.
rw	Enter the keyword rw to specify read-write permission.
ipv6 access-list-name	(Optional) Enter the keyword ipv6 followed by a an IPv6 ACL name (a string up to 16 characters long).
security-name name	(Optional) Enter the keyword security-name followed by the security name as defined by the community MIB.
access-list-name	(Optional) Enter a standard IPv4 access list name (a string up to 16 characters long).

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Ver. 6.2.1.1	Introduced on E-Series

Usage Information

The example below configures a community named **public** that is mapped to the security named **guestuser** with Read Only (**ro**) permissions.

Example

Figure 38-6. snmp-server community Command Example

```
FTOS#config
FTOS(conf)# snmp-server community public ro
FTOS(conf)# snmp-server community guest ro security-name guestuser
FTOS(conf)#
```

The **security-name** parameter maps the community string to an SNMPv3 user/security name as defined by the community MIB.

If a community string is configured without a **security-name** (for example, **snmp-server community public ro**), the community is mapped to a default security-name/group:

- v1v2creadu / v1v2creadg maps to a community with **ro** permissions
- v1v2cwriteu/ v1v2cwriteg maps to a community with rw permissions

This command is indexed by the *community-name* parameter.

If the snmp-server community command is not configured, you cannot query SNMP data. Only Standard IPv4 ACL and IPv6 ACL is supported in the optional *access-list-name*.

The command options **ipv6**, **security-name**, and *access-list-name* are recursive. In other words, each option can, in turn, accept any of the three options as a sub-option, and each of those sub-options can accept any of the three sub-options as a sub-option, and so forth. The following example demonstrates the creation of a standard IPv4 ACL called "snmp-ro-acl" and then assigning it to the SNMP community "guest":

Example

Figure 38-7. snmp-server community Command Example

```
FTOS(conf)# ip access-list standard snmp-ro-acl
FTOS(config-std-nacl)#seq 5 permit host 10.10.10.224
FTOS(config-std-nacl)#seq 10 deny any count
!
FTOS(conf)#snmp-server community guest ro snmp-ro-acl
FTOS(conf)#
```



Note: For IPv6 ACLs, only IPv6 and UDP types are valid for SNMP; TCP, ICMP rules are not valid for SNMP. In IPv6 ACLs port rules are not valid for SNMP.

Related Commands

ip access-list standard	Name (or select) a standard access list to filter based on IP address.
ipv6 access-list	Configure an access list based on IPv6 addresses or protocols.
show running-config snmp	Display the current SNMP configuration and defaults.

snmp-server contact



Configure contact information for troubleshooting this SNMP node.

Syntax

snmp-server contact text

To delete the SNMP server contact information, use the **no snmp-server contact** command.

Parameters

Defaults

No default values or behavior

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
	E-Series legacy command

snmp-server enable traps

CES

Enable and configure SNMP traps.

Syntax

snmp-server enable traps [notification-type] [notification-option]

linkup

To disable traps, use the **no snmp-server enable traps** [notification-type] [notification-option] command.

Parameters

notification-type	Enter the type of notification from the list below:
	• bgp —for notification of changes in BGP process
	 envmon—for Dell Networking device notifications when an environmental threshold is exceeded
	• snmp —for notification of the RFC 1157 traps.
	• stp - Allow Spanning Tree protocol notification (RFC 1493)
	 xstp - Allow MSTP (802.1s), RSTP (802.1w), and PVST+ state change traps
notification-option	For the envmon notification-type, enter one of the following optional parameters:
	• fan
	 supply
	temperature
	For the snmp notification-type, enter one of the following optional parameters:
	• authentication
	• coldstart
	• linkdown

Defaults

Not enabled.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series; Added support for STP and xSTP notification types.
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Usage Information

FTOS supports up to 16 SNMP trap receivers.

If this command is not configured, no traps controlled by this command are sent. If you do not specify a *notification-type* and *notification-option*, all traps are enabled.

Related Commands

snmp-server community Enable SNMP and set the community string.

snmp-server engineID

CES

Configure name for both the local and remote SNMP engines on the router.

Syntax

snmp-server engineID [local engineID] [remote ip-address udp-port port-number engineID]

To return to the default, use the **no snmp-server engineID** [**local** *engineID*] [**remote** *ip-address* **udp-port** *port-number engineID*] command

Parameters

local engineID	Enter the keyword local followed by the engine ID number that identifies the copy of the SNMP on the <i>local</i> device. Format (as specified in RFC 3411): 12 octets.
	• The first 4 octets are set to the private enterprise number.
	• The remaining 8 octets are the MAC address of the chassis.
remote ip-address	Enter the keyword remote followed by the IP address that identifies the copy of the SNMP on the <i>remote</i> device.
udp-port port-number engineID	Enter the keyword udp-port followed by the UDP (User Datagram Protocol) port number on the remote device.
g	Range: 0 to 65535
	Default: 162

Defaults

As above

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Usage Information

Changing the value of the SNMP Engine ID has important side effects. A user's password (entered on the command line) is converted to an MD5 (Message Digest Algorithm) or SHA (Secure Hash Algorithm) security digest. This digest is based on both the password and the local Engine ID. The command line password is then destroyed, as required by RFC 2274. Because of this deletion, if the local value of the Engine ID changes, the security digests of SNMPv3 users will be invalid, and the users will have to be reconfigured.

For the remote Engine ID, the host IP and UDP port are the indexes to the command that are matched to either overwrite or remove the configuration.

Related Commands

show snmp engineID	Display SNMP engine and all remote engines that are configured on the router
show running-config snmp	Display the SNMP running configuration

snmp-server group

CES Configure a new SNMP group or a table that maps SNMP users to SNMP views.

Syntax

snmp-server group [group_name {1 | 2c | 3 {auth | noauth | priv}}] [read name] [write name] [notify name] [access-list-name | ipv6 access-list-name | access-list-name ipv6 access-list-name]]

To remove a specified group, use the **no snmp-server group** [group_name {v1 | v2c | v3 {auth | noauth | priv}}] [read name] [write name] [notify name] [access-list-name | ipv6 access-list-name | access-list-name ipv6 access-list-name]] command.

Parameters

group_name	Enter a text string (up to 20 characters long) as the name of the group. Defaults: The following groups are created for mapping to read/write community/security-names.
	 v1v2creadg — maps to a community/security-name with ro permissions 1v2cwriteg — maps to a community/security-name rw permissions
1 2c 3	(OPTIONAL) Enter the security model version number (1, 2c, or 3).
1 20 3	• 1 is the least secure version
	• 3 is the most secure of the security modes.
	• 2c allows transmission of informs and counter 64, which allows for integers twice the width of what is normally allowed.
	Default: 1
auth	(OPTIONAL) Enter the keyword auth to specify authentication of a packet without encryption.
noauth	(OPTIONAL) Enter the keyword noauth to specify no authentication of a packet.
priv	(OPTIONAL) Enter the keyword priv to specify both authentication and then scrambling of the packet.
read name	(OPTIONAL) Enter the keyword read followed by a name (a string of up to 20 characters long) as the read view name.
	Default: GlobalView is set by default and is assumed to be every object belonging to the Internet (1.3.6.1) OID space.
write name	(OPTIONAL) Enter the keyword write followed by a name (a string of up to 20 characters long) as the write view name.
notify name	(OPTIONAL) Enter the keyword notify followed by a name (a string of up to 20 characters long) as the notify view name.
access-list-name	(Optional) Enter the standard IPv4 access list name (a string up to 16 characters long).
ipv6 access-list-name	(Optional) Enter the keyword ipv6 followed by the IPv6 access list name (a string up to 16 characters long)
access-list-name ipv6 access-list-name	(Optional) Enter both an IPv4 and IPv6 access list name.

Defaults

As defined above

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

Usage Information

The following example specifies the group named **harig** as a version **3** user requiring both authentication and encryption and read access limited to the read named **rview**.



Note: For IPv6 ACLs, only IPv6 and UDP types are valid for SNMP; TCP, ICMP rules are not valid for SNMP. In IPv6 ACLs port rules are not valid for SNMP.

Example

Figure 38-8. snmp-server group Command Example

FTOS#conf FTOS(conf)# snmp-server group harig 3 priv read rview FTOS#



Note: The number of configurable groups is limited to 16 groups.

Related Commands

show snmp group	Display the group name, security model, view status, and storage type of each group.
show running-config snmp	Display the SNMP running configuration

snmp-server host



Configure the recipient of an SNMP trap operation.

Syntax

snmp-server host *ip-address* | *ipv6-address* [traps | informs] [version 1 | 2c | 3] [auth | no auth | priv] [community-string] [udp-port port-number] [notification-type]

To remove the SNMP host, use the **no snmp-server host** *ip-address* [traps | informs] [version 1 | 2c | 3] [auth | noauth | priv] [community-string] [udp-port number] [notification-type] command.

Parameters

ip-address	Enter the keyword host followed by the IP address of the host (configurable hosts is limited to 16).
ipv6-address	Enter the keyword host followed by the IPv6 address of the host in the x:x:x:x format.
	The :: notation specifies successive hexadecimal fields of zero
traps	(OPTIONAL) Enter the keyword traps to send trap notifications to the specified host.
	Default: traps
informs	(OPTIONAL) Enter the keyword informs to send inform notifications to the specified host.
	Default: traps

version 1 2c 3	(OPTIONAL) Enter the keyword version to specify the security model followed by the security model version number 1 , 2c , or 3 .
	• Version 1 is the least secure version
	• version 3 is the most secure of the security modes.
	• Version 2c allows transmission of informs and counter 64, which allows for integers twice the width of what is normally allowed.
	Default: Version 1
auth	(OPTIONAL) Enter the keyword auth to specify authentication of a packet without encryption.
noauth	(OPTIONAL) Enter the keyword noauth to specify no authentication of a packet.
priv	(OPTIONAL) Enter the keyword priv to specify both authentication and then scrambling of the packet.
community-string	Enter a text string (up to 20 characters long) as the name of the SNMP community.
	Note: For version 1 and version 2c security models, this string represents the name of the SNMP community. The string can be set using this command, however it is recommended that you set the community string using the snmp-server community command before executing this command. For version 3 security model, this string is the USM user security name.
udp-port port-number	(OPTIONAL) Enter the keywords udp-port followed by the port number of the remote host to use. Range: 0 to 65535. Default: 162
notification-type	(OPTIONAL) Enter one of the following keywords as the type of trap to be sent to the host:
	• bgp - allow BGP state change traps
	• envmon - allows environment monitor traps
	• snmp - Allows SNMP-type notification (RFC 1157) traps.
	• stp - Allow Spanning Tree protocol notification (RFC 1493)
	• xstp - Allow MSTP (802.1s), RSTP (802.1w), and PVST+ state change traps
	Default: All trap types are sent to host

Defaults

As shown

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series; Added support for STP and xSTP notification types.
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Usage Information

In order to configure the router to send SNMP notifications, you must enter at least one **snmp-server** host command. If you enter the command with no keywords, all trap types are enabled for the host. If you do not enter an **snmp-server host** command, no notifications are sent.

In order to enable multiple hosts, you must issue a separate snmp-server host command for each host. You can specify multiple notification types in the command for each host.

When multiple **snmp-server host** commands are given for the same host and type of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command will be in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command will replace the first.

The **snmp-server host** command is used in conjunction with the **snmp-server enable** command. Use the snmp-server enable command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable** command and the **snmp-server host** command for that host must be enabled.



Note: For v1 / v2c trap configuration, if the community-string is not defined using the **snmp-server community** command prior to using this command, the default form of the **snmp-server community** command will automatically be configured, with the community-name the same as specified in the **snmp-server host** command.

Configuring Informs

To send an inform, follow the step below.

- 1. Configure a remote engine ID.
- 2. Configure a remote user.
- 3. Configure a group for this user with access rights.
- 4. Enable traps.
- 5. Configure a host to receive informs.

Related Commands

snmp-server enable traps	Enable SNMP traps.
snmp-server community	Configure a new community SNMPv1 or SNMPv2c

snmp-server location



Configure the location of the SNMP server.

Syntax

snmp-server location text

To delete the SNMP location, enter **no snmp-server location**.

Parameters

text Enter an alpha-numeric text string, up to 55 characters long.		text	Enter an alpha-numeric text string, up to 55 characters long.
--	--	------	---

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

snmp-server packetsize

[C][E][S]

Set the largest SNMP packet size permitted when the SNMP server is receiving a request or generating a reply, use the snmp-server packetsize global configuration command.

Syntax

snmp-server packetsize byte-count

Parameters

byte-count	Enter one of the following values 8, 16, 24 or 32. Packet sizes are 8000 bytes, 16000 bytes,
	32000 bytes, and 64000 bytes.

Defaults

8

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy co	mmand	

snmp-server trap-source

CES

Configure a specific interface as the source for SNMP traffic.

Syntax

snmp-server trap-source interface

To disable sending traps out a specific interface, enter **no snmp trap-source**.

Parameter

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Loopback interface, enter the keyword **loopback** followed by a number from 0 to 16383.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.

Defaults

The IP address assigned to the management interface is the default.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0 Support added for C-Series	
E-Series legacy co	ommand

Usage Information

For this snmp-server trap-source command to be enabled, you must configure an IP address on the interface and enable the interface configured as an SNMP trap source.

Related Commands

snmp-server community Set the community string.

snmp-server user



Configure a new user to an SNMP group.

Syntax

snmp-server user name {group_name remote ip-address udp-port port-number} [1 | 2c | 3] [encrypted] [auth {md5 | sha} auth-password] [priv des56 priv password] [access-list-name | ipv6 access-list-name | access-list-name ipv6 access-list-name]

To remove a user from the SNMP group, use the **no snmp-server user** name {group_name remote ip-address udp-port port-number} [1 | 2c | 3] [encrypted] [auth {md5 | sha} auth-password] [priv des56 priv password] [access-list-name | ipv6 access-list-name | access-list-name ipv6 access-list-name] command.

Parameters

the SNMP on the remote device. Letter the keyword udp-port followed by the UDP (User Datagram Prote port number on the remote device. Range: 0 to 65535. Default: 162 1 2c 3		
Defaults: The following groups are created for mapping to read/write community/security-names. v1v2creadu — maps to a community rw permissions 1v2cwriteu — maps to a community rw permissions Enter the keyword remote followed by the IP address that identifies the community remote port-number on the remote device. Enter the keyword udp-port followed by the UDP (User Datagram Proteoport number on the remote device. Range: 0 to 65535. Default: 162 (OPTIONAL) Enter the security model version number (1, 2c, or 3). 1 is the least secure version 3 is the most secure of the security modes. 2c allows transmission of informs and counter 64, which allows for intwice the width of what is normally allowed. Default: 1 encrypted (OPTIONAL) Enter the keyword encrypted to specify the password appending the true characters of the strip auth (OPTIONAL) Enter the keyword auth to specify authentication of a pack without encryption. md5 sha (OPTIONAL) Enter the keyword md5 or sha to designate the authenticatevel. md5 — Message Digest Algorithm sha — Secure Hash Algorithm auth-password (OPTIONAL) Enter a text string (up to 20 characters long) password that enable the agent to receive packets from the host. Minimum: 8 characters long	name	
remote ip-address Enter the keyword remote followed by the IP address that identifies the composition the SNMP on the remote device. Udp-port port-number Enter the keyword udp-port followed by the UDP (User Datagram Prote port number on the remote device. Range: 0 to 65535. Default: 162 1 2c 3 (OPTIONAL) Enter the security model version number (1, 2c, or 3). 1 is the least secure version 2 callows transmission of informs and counter 64, which allows for intwice the width of what is normally allowed. Default: 1 encrypted (OPTIONAL) Enter the keyword encrypted to specify the password appearencypted format (a series of digits, masking the true characters of the strint (OPTIONAL) Enter the keyword auth to specify authentication of a pack without encryption. md5 sha (OPTIONAL) Enter the keyword md5 or sha to designate the authenticatevel. md5 — Message Digest Algorithm sha — Secure Hash Algorithm auth-password (OPTIONAL) Enter a text string (up to 20 characters long) password that enable the agent to receive packets from the host. Minimum: 8 characters long	group_name	Defaults: The following groups are created for mapping to read/write
the SNMP on the remote device. Letter the keyword udp-port followed by the UDP (User Datagram Prote port number on the remote device. Range: 0 to 65535. Default: 162 1 2c 3		
port number on the remote device. Range: 0 to 65535. Default: 162 1 2c 3	remote ip-address	Enter the keyword remote followed by the IP address that identifies the copy of the SNMP on the <i>remote</i> device.
1 is the least secure version 3 is the most secure of the security modes. 2c allows transmission of informs and counter 64, which allows for intwice the width of what is normally allowed. Default: 1 encrypted (OPTIONAL) Enter the keyword encrypted to specify the password appencrypted format (a series of digits, masking the true characters of the strint (OPTIONAL) Enter the keyword auth to specify authentication of a pack without encryption. md5 sha (OPTIONAL) Enter the keyword md5 or sha to designate the authentication of the series of the strint (OPTIONAL) Enter the keyword md5 or sha to designate the authentication of the series of the strint (OPTIONAL) Enter the keyword md5 or sha to designate the authentication of the series of the strint (OPTIONAL) Enter a text string (up to 20 characters long) password that the enable the agent to receive packets from the host. Minimum: 8 characters long	udp-port port-number	Range: 0 to 65535.
encrypted (OPTIONAL) Enter the keyword encrypted to specify the password appenrypted format (a series of digits, masking the true characters of the string auth (OPTIONAL) Enter the keyword auth to specify authentication of a pack without encryption. md5 sha (OPTIONAL) Enter the keyword md5 or sha to designate the authenticated level. md5 — Message Digest Algorithm sha — Secure Hash Algorithm auth-password (OPTIONAL) Enter a text string (up to 20 characters long) password that the enable the agent to receive packets from the host. Minimum: 8 characters long	1 2c 3	 1 is the least secure version 3 is the most secure of the security modes. 2c allows transmission of informs and counter 64, which allows for integers twice the width of what is normally allowed.
without encryption. (OPTIONAL) Enter the keyword md5 or sha to designate the authentical level. md5 — Message Digest Algorithm sha — Secure Hash Algorithm (OPTIONAL) Enter a text string (up to 20 characters long) password that enable the agent to receive packets from the host. Minimum: 8 characters long	encrypted	(OPTIONAL) Enter the keyword encrypted to specify the password appear in encrypted format (a series of digits, masking the true characters of the string).
level. md5 — Message Digest Algorithm sha — Secure Hash Algorithm (OPTIONAL) Enter a text string (up to 20 characters long) password that enable the agent to receive packets from the host. Minimum: 8 characters long	auth	(OPTIONAL) Enter the keyword auth to specify authentication of a packet
enable the agent to receive packets from the host. Minimum: 8 characters long	md5 sha	md5 — Message Digest Algorithm
(ODERONAL) E. al. 1. Immin desEC.	auth-password	
	priv des56	(OPTIONAL) Enter the keyword priv des56 to initiate a privacy authentication level setting using the CBC-DES privacy authentication algorithm (des56).

priv password	(OPTIONAL) Enter a text string (up to 20 characters long) password that will enables the host to encrypt the contents of the message it sends to the agent. Minimum: 8 characters long
access-list-name	(Optional) Enter the standard IPv4 access list name (a string up to 16 characters long).
ipv6 access-list-name	(Optional) Enter the keyword ipv6 followed by the IPv6 access list name (a string up to 16 characters long)
access-list-name ipv6 access-list-name	(Optional) Enter both an IPv4 and IPv6 access list name.

Defaults

As above

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy co	ommand

Usage Information



Note: For IPv6 ACLs, only IPv6 and UDP types are valid for SNMP; TCP, ICMP rules are not valid for SNMP. In IPv6 ACLs port rules are not valid for SNMP.

No default values exist for authentication or privacy algorithms and no default password exist. If you forget a password, you cannot recover it; the user must be reconfigured. You can specify either a plain-text password or an encrypted cypher-text password. In either case, the password will be stored in the configuration in an encrypted form and displayed as encrypted in the show running-config command.

If you have an encrypted password, you can specify the encrypted string instead of the plain-text password. The following command is an example of how to specify the command with an encrypted string:

Examples

Figure 38-9. snmp-server user Command Example

FTOS# snmp-server user privuser v3group v3 encrypted auth md5 9fc53d9d908118b2804fe80e3ba8763d priv des56 d0452401a8c3ce42804fe80e3ba8763d

The following command is an example of how to enter a plain-text password as the string authpasswd for user authuser of group v3group.

FTOS#conf FTOS(conf)# snmp-server user authuser v3group v3 auth md5 authpasswd

The following command configures a remote user named **n3user** with a **v3** security model and a security level of authNOPriv.

FTOS#conf FTOS(conf)# snmp-server user n3user ngroup remote 172.31.1.3 udp-port 5009 3 auth md5 authpasswd



Note: The number of configurable users is limited to 16.

Related Commands

show snmp user	Display the information configured on each SNMP user name.

snmp-server view

CES

Configure an SNMPv3 view.

Syntax

snmp-server view view-name oid-tree {included | excluded}

To remove an SNMPv3 view, use the **no snmp-server view** *view-name oid-tree* {**included** | **excluded**} command.

Parameters

view-name	Enter the name of the view (not to exceed 20 characters).
oid-tree	Enter the OID sub tree for the view (not to exceed 20 characters).
included	(OPTIONAL) Enter the keyword included to include the MIB family in the view.
excluded	(OPTIONAL) Enter the keyword excluded to exclude the MIB family in the view.

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy co	mmand	

Usage Information

The *oid-tree* variable is a full sub-tree starting from 1.3.6 and can not specify the name of a sub-tree or a MIB. The following example configures a view named **rview** that allows access to all objects under 1.3.6.1:

Example

Figure 38-10. snmp-server view Command Example

FTOS# conf FTOS#(conf) snmp-server view rview 1.3.6.1 included

Related Commands

show running-config snmp Display the SNMP running configuration

snmp trap link-status

CES

Enable the interface to send SNMP link traps, which indicate whether the interface is up or down.

Syntax

snmp trap link-status

To disable sending link trap messages, enter **no snmp trap link-status**.

Defaults Enabled.

Command Modes INTERFACE

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy co	ommand

Usage Information

If the interface is expected to flap during normal usage, you could disable this command.

Syslog Commands

The following commands allow you to configure logging functions on all Dell Networking switches:

- clear logging
- default logging buffered
- default logging console
- default logging monitor
- default logging trap
- logging
- logging buffered
- logging console
- logging facility
- logging history
- logging history size
- logging monitor
- logging on
- logging source-interface
- logging synchronous
- logging trap
- show logging
- show logging driverlog stack-unit (S-Series)
- terminal monitor

clear logging

CES Clear the messages in the logging buffer.

Syntax clear logging

Defaults None.

Command Modes EXEC Privilege

Command

History Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0 Support added for C-Series

E-Series legacy command

Related Commands

show logging Display logging settings and system messages in the internal buffer.

default logging buffered

Return to the default setting for messages logged to the internal buffer.

Syntax default logging buffered

Defaults size = 40960; level = 7 or debugging

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0 Support added for C-Series

E-Series legacy command

Related Commands

logging buffered Set the logging buffered parameters.

default logging console

CES Return the default settings for messages logged to the console.

Syntax default logging console

Defaults level = 7 or debugging

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0 Support added for C-Series

E-Series legacy command

Related Commands

logging console Set the logging console parameters.

default logging monitor

Return to the default settings for messages logged to the terminal.

Syntax default logging monitor

Defaults level = 7 or debugging

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0 Support added for C-Series	
E-Series legacy co	mmand

Related **Commands**

logging monitor	Set the logging monitor parameters.
terminal monitor	Send system messages to the terminal/monitor.

default logging trap

CES Return to the default settings for logging messages to the Syslog servers.

Syntax default logging trap

Defaults level = 6 or informational

Command Modes CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy co	E-Series legacy command	

Related Commands

logging trap	Limit messages logged to the Syslog servers based on severity.

logging CES

Configure an IP address or host name of a Syslog server where logging messages will be sent.

Syntax logging {ip-address | hostname}

To disable logging, enter no logging.

Parameters

ip-address	Enter the IP address in dotted decimal format.
hostname	Enter the name of a host already configured and recognized by the switch.

Defaults Disabled

Command Modes

CONFIGURATION

Command History

	T. 1 1 000
Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Related Commands

logging on	Enables the logging asynchronously to logging buffer, console, Syslog server, and terminal lines.
logging trap	Enables logging to the Syslog server based on severity.

logging buffered



Enable logging and specify which messages are logged to an internal buffer. By default, all messages are logged to the internal buffer.

Syntax

logging buffered [level] [size]

To return to the default values, enter **default logging buffered**. To disable logging stored to an internal buffer, enter **no logging buffered**.

Parameters

level	(OPTIONAL) Indicate a value from 0 to 7 or enter one of the following equivalent words: emergencies, alerts, critical, errors, warnings, notifications, informational, or debugging. Default: 7 or debugging.
size	(OPTIONAL) Indicate the size, in bytes, of the logging buffer. The number of messages buffered depends on the size of each message. Range: 40960 to 524288. Default: 40960 bytes.

Defaults

level = 7; *size* = 40960 bytes

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Usage Information

When you decrease the buffer size, all messages stored in the buffer are lost. Increasing the buffer size does not affect messages stored in the buffer.

Related Commands

clear logging	Clear the logging buffer.
default logging buffered	Returns the logging buffered parameters to the default setting.
show logging	Display the logging setting and system messages in the internal buffer.

logging console

Specify which messages are logged to the console.

Syntax logging console [level]

> To return to the default values, enter default logging console. To disable logging to the console, enter no logging console.

Parameters

level (OPTIONAL) Indicate a value from 0 to 7 or enter one of the following parameters: emergencies, alerts, critical, errors, warnings, notifications, informational, or debugging. Default: 7 or debugging.

Defaults 7 or debugging

Command Modes CONFIGURATION

> Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Related **Commands**

clear logging	Clear logging buffer.
default logging console	Returns the logging console parameters to the default setting.
show logging	Display logging settings and system messages in the internal buffer.

logging facility

Configure the Syslog facility, used for error messages sent to Syslog servers.

Syntax logging facility [facility-type]

To return to the default values, enter **no logging facility**.

Parameters facility-type (OPTIONAL) Enter one of the following parameters. auth (authorization system) cron (Cron/at facility) deamon (system deamons) kern (kernel) local0 (local use) local1 (local use) local2 (local use) local3 (local use) local4 (local use) local5 (local use) local6 (local use) local7 (local use) lpr (line printer system) mail (mail system) news (USENET news) sys9 (system use) sys10 (system use) sys11 (system use) sys12 (system use) sys13 (system use) sys14 (system use)

syslog (Syslog process)
user (user process)

The default is local7.

uucp (Unix to Unix copy process)

Defaults local7

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

Related Commands

logging	Enable logging to a Syslog server.
logging on	Enables logging.

logging history

CES

Specify which messages are logged to the history table of the switch and the SNMP network management station (if configured).

Syntax logging history level

To return to the default values, enter **no logging history**.

Parameters

Indicate a value from 0 to 7 or enter one of the following equivalent words: emergencies, alerts, critical, errors, warnings, notifications, informational, or debugging.
The default is 4.

Defaults

4 or warnings

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

Usage Information

When you configure the snmp-server trap-source command, the system messages logged to the history table are also sent to the SNMP network management station.

Related **Commands**

show logging history

Display information logged to the history buffer.

logging history size

CES

Specify the number of messages stored in the FTOS logging history table.

Syntax

logging history size size

To return to the default values, enter **no logging history size**.

Parameters

size	Indicate a value as the number of messages to be stored.
	Range: 0 to 500.
	Default: 1 message.

Defaults

1 message

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

Usage Information

When the number of messages reaches the limit you set with the logging history size command, older messages are deleted as newer ones are added to the table.

Related Commands

show logging history Display information logged to the history buffer.

logging monitor

Specify which messages are logged to Telnet applications.

Syntax logging monitor [level]

To disable logging to terminal connections, enter **no logging monitor**.

Parameters

level Indicate a value from 0 to 7 or enter one of the following parameters: emergencies, alerts, critical, errors, warnings, notifications, informational, or debugging.

The default is 7 or debugging.

Defaults 7 or debugging

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0 Support added for C-Series

E-Series legacy command

Related Commands

default logging monitor Returns the logging monitor parameters to the default setting.

logging on

CES

Specify that debug or error messages are asynchronously logged to multiple destinations, such as logging buffer, Syslog server, or terminal lines.

Syntax logging on

To disable logging to logging buffer, Syslog server and terminal lines, enter **no logging on**.

Defaults Enabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1 Introduced on S60

Version 7.6.1.0 Support added for S-Series

Version 7.5.1.0 Support added for C-Series

E-Series legacy command

Usage Information When you enter **no logging on**, messages are logged only to the console.

Related Commands

logging	Enable logging to Syslog server.
logging buffered	Set the logging buffered parameters.
logging console	Set the logging console parameters.
logging monitor	Set the logging parameters for the terminal connections.

logging source-interface

[C][E][S]

Specify that the IP address of an interface is the source IP address of Syslog packets sent to the Syslog server.

Syntax

logging source-interface interface

To disable this command and return to the default setting, enter no logging source-interface.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For Loopback interfaces, enter the keyword loopback followed by a number from zero (0) to 16383.
- For the management interface on the RPM, enter the keyword **ManagementEthernet** followed by the slot/port information. The slot range is 0-1 and the port range is 0.
- For a Port Channel, enter the keyword **port-channel** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1-255 for TeraScale,

- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- For a Ten Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For VLAN interface, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
F-Series legacy command	

Usage Information

Syslog messages contain the IP address of the interface used to egress the router. By configuring the logging source-interface command, the Syslog packets contain the IP address of the interface configured.

Related Commands

logging	Enable the logging to another device.	
---------	---------------------------------------	--

logging synchronous

CES

Synchronize unsolicited messages and FTOS output.

Syntax

logging synchronous [level |evel | all] [limit number-of-buffers]

To disable message synchronization, use the no logging synchronous [level level | all] [limit number-of-buffers] command.

Parameters

all	Enter the keyword all to ensure that all levels are printed asynchronously.	
level level	Enter the keyword level followed by a number as the severity level. A high number indicates a low severity level and visa versa.	
	Range: 0 to 7.	
	Default: 2	
all	Enter the keyword all to turn off all	
limit number-of-buffers	Enter the keyword limit followed by the number of buffers to be queued for the terminal after which new messages are dropped Range: 20 to 300 Default: 20	

Defaults

Disabled. If enabled without *level* or *number-of-buffers* options specified, *level* = 2 and *number-of-buffers* = 20 are the defaults.

Command Modes

LINE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
F-Series legacy command	

Usage Information

When logging synchronous is enabled, unsolicited messages appear between software prompts and outputs. Only the messages with a severity at or below the set level are sent to the console.

If the message queue limit is reached on a terminal line and messages are discarded, a system message appears on that terminal line. Messages may continue to appear on other terminal lines.

Related Commands

Enables logging.
s logging.

logging trap



Specify which messages are logged to the Syslog server based the message severity.

Syntax logging trap [level]

To return to the default values, enter **default logging trap**. To disable logging, enter **no logging trap**.

Parameters

level	Indicate a value from 0 to 7 or enter one of the following parameters: emergencies, alerts, critical, errors, warnings, notifications, informational, or debugging.
	The default is 6.

Defaults

6 or informational

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series

Version 7.5.1.0	Support added for C-Series	
E-Series legacy	command	
logging	Enable the logging to another device.	
logging on	Enables logging.	

Related Commands

show logging
CES Dis

Display the logging settings and system messages logged to the internal buffer of the switch.

Syntax

show logging [number | **history** [reverse][number] | reverse [number] | **summary**]

Parameters

number	(OPTIONAL) Enter the number of message to be displayed on the output.
	Range: 1 to 65535
history	(OPTIONAL) Enter the keyword history to view only information in the Syslog history table.
reverse	(OPTIONAL) Enter the keyword reverse to view the Syslog messages in FIFO (first in, first out) order.
summary	(OPTIONAL) Enter the keyword summary to view a table showing the number of messages per type and per slot. Slots *7* and *8* represent RPMs.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
E-Series legacy command	

Figure 38-11. show logging Command Example (Partial)

```
FTOS#show logging
Syslog logging: enabled
    Console logging: level debugging
   Monitor logging: level debugging
   Buffer logging: level debugging, 5604 Messages Logged, Size (524288 bytes)
   Trap logging: level informational
Oct. 8 Q9:25:37: %RPM1:RP1 %BGP-5-ADJCHANGE: Connection with neighbor 223.80.255.254 closed. Hold time expired
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.200.13.2 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.13 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 1.1.14.2 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.14 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 1.1.11.2 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.5 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.4.1.3 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.4 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.6 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.12 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.15 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.1.1.3 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.200.12.2 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 1.1.10.2 Up
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Session closed by neighbor 1.1.10.2 (Hold time expired)
Oct 8 09:25:38: %RPM1:RP1 %BGP-5-ADJCHANGE: Neighbor 192.200.14.7 Up
Oct 8 09:26:25: %RPM1:RP1 %BGP-5-ADJCHANGE: Connection with neighbor 1.1.11.2 closed. Neighbor recycled
Oct 8 09:26:25: %RPM1:RP1 %BGP-5-ADJCHANGE: Connection with neighbor 1.1.14.2 closed. Neighbor recycled
--More--
```

Figure 38-12. show logging history Command Example

```
FTOS#show logging history
Syslog History Table: 1 maximum table entries,
saving level Warnings or higher
SNMP notifications not Enabled
%RPM:0:0 %CHMGR-2-LINECARDDOWN - Line card 3 down - IPC timeout
FTOS#
```

show logging driverlog stack-unit (S-Series)

Display the driver log for the specified stack member.

Syntax show logging driverlog stack-unit unit#

Parameters

Stack-unit unit#

Enter the keyword Stack-unit followed by the stack member ID of the switch for which you want to display the driver log.

Unit ID range:
S60: 0-11
all other S-Series: 0-7

Defaults No default values or behavior

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.3.1	Introduced on the S60.
Version 7.6.1.0	Introduced for S-Series

Usage Information

This command displays internal software driver information, which may be useful during troubleshooting switch initialization errors, such as a downed Port-Pipe.

terminal monitor

CES Configure the FTOS to display messages on the monitor/terminal.

terminal monitor **Syntax**

To return to default settings, enter **terminal no monitor**.

Defaults Disabled.

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
E-Series legacy command		

Related Commands

logging monitor	Set the logging parameters on the monitor/terminal.	

S-Series Stacking Commands

Overview

All commands in this chapter are specific to the S-Series platform, as indicated by the [5] character that appears below each command heading. The commands are always available and operational, whether or not the S-Series has a stacking module inserted. You can use the commands to pre-configure a switch, so that the configuration settings are invoked when the switch is attached to other S-Series units.

For details on using the S-Series stacking feature, see the chapter "Stacking S-Series Switches" in the FTOS Configuration Guide.

The S60 supports stacking with FTOS version 8.3.3.4 and later.

Commands

The commands in this chapter are used for managing the stacking of S-Series systems:

- power-cycle
- redundancy disable-auto-reboot
- redundancy force-failover stack-unit
- reset stack-unit
- show redundancy
- show system stack-ports
- stack-unit priority
- stack-unit provision
- stack-unit renumber
- upgrade system stack-unit (S-Series stack member)

S60 range: 0 - 11

power-cycle



Power-cycle the unit.

stack-unit

Syntax

power-cycle [stack-unit | all]

Parameters

Enter the stack member unit identifier of the stack member to reset.

Defaults None

Command Modes EXEC Privilege

Command History

Version 8.3.3.4 Introduced on S60

Usage Information This command applies to the S60 only.

redundancy disable-auto-reboot

Prevent the S-Series stack management unit and standby unit from rebooting if they fails.

Syntax redundancy disable-auto-reboot [stack-unit | all]

To return to the default, enter no redundancy disable-auto-reboot stack-unit.

Parameters

Stack-unit Enter the stack member unit identifier of the stack member to reset.

S60 range: 0 - 11

all other S-Series range: 0-7

Defaults Disabled (the failed switch is automatically rebooted).

Command Modes CONFIGURATION

Command History

Version 8.3.3.4 Introduced on S60

Version 8.3.1.0 Added the **all** option

Version 7.7.1.0 Introduced on S-Series

Usage Information Enabling this command keeps the failed switch in the failed state. It will not reboot until it is manually rebooted. When enabled, it is not displayed in the running-config. When disabled, it is displayed in the running-config.

Related Commands

show redundancy Display the current redundancy status.

redundancy force-failover stack-unit

S Force the backup unit in the stack to become the management unit.

Syntax redundancy force-failover stack-unit

Defaults Not enabled

Command Modes EXEC Privilege

reset stack-unit

Reset any designated stack member except the management unit (master unit).

Syntax

reset stack-unit stack-unit hard

Parameters

stack-unit	Enter the stack member unit identifier of the stack member to reset.
	S60 range : 0 - 11
	all other S-Series range: 0-7
hard	Reset the stack unit if the unit is in a problem state.

Default

none

Command Modes

CONFIGURATION

Command History

Version 8.3.3.4	Introduced on S60
Version 8.3.1.0	Added hard reset option.
Version 7.8.1.0	Augmented to run on the standby unit in order to reset the standby unit directly.
Version 7.7.1.0	Introduced on S-Series

Usage Information

Resetting the management unit is not allowed, and an error message will be displayed if you try to do so. Resetting is a soft reboot, including flushing the forwarding tables.

Starting with FTOS 7.8.1.0, you can run this command directly on the stack standby unit (standby master) to reset the standby. You cannot reset any other unit from the standby unit.

Example

Figure 39-1. Using the reset stack-unit Command on the Stack Standby Unit

```
FTOS#show system brief
Stack MAC : 00:01:e8:51:4e:f8
   Stack Info --
                 Status
                                                 CurTyp
                                                              Version
Unit UnitType
                                    ReqTyp
                                                                            Ports
                                                 S50N
                                                             4.7.7.117
  0 Member
                 online
                                    S50N
  1
      Member
                   online
                                    S50N
                                                 S50N
                                                              4.7.7.117
                                                                            52
                                                              4.7.7.117
  2
                                    S50N
      Member
                   online
                                                 S50N
                                                                            52
  3
      Member
                   online
                                    S50N
                                                 S50N
                                                              4.7.7.117
                                                                            52
  4
      Standby
                   online
                                    S50N
                                                 S50N
                                                              4.7.7.117
                                                                            52
  5
      Member
                    online
                                    S50N
                                                 S50N
                                                              4.7.7.117
                                                                            52
  6
      Mgmt
                   online
                                    S50N
                                                 S50N
                                                              4.7.7.117
                                                                            52
      Member
                   online
                                    S50N
                                                 S50N
                                                              4.7.7.117
FTOS (standby) #reset ? << Standby management unit
stack-unit
                          Unit number
FTOS(standby) #reset stack-unit ?
< 0 - 7 >
                          Unit number id
FTOS(standby) #reset stack-unit 6
% Error: Reset of master unit is not allowed. << Resetting master not allowed
FTOS(standby) #reset stack-unit 0
% Error: Reset of stack units from standby is not allowed.<<no reset of other member</pre>
FTOS (standby) #
FTOS (standby) #reset stack-unit 4 << Resetting standby unit success!
00:02:50: %STKUNIT4-S:CP %CHMGR-5-STACKUNIT RESET: Stack unit 4 being reset 00:02:50: %STKUNIT4-S:CP %CHMGR-2-STACKUNIT_DOWN: Stack unit 4 down - reset
00:02:50: %STKUNIT4-S:CP %IFMGR-1-DEL PORT: Removed port: Gi 4/1-48
FTOS (standby) #rebooting
U-Boot 1.1.4 (Mar 6 2008 - 00:00:04)
```

Related Commands

reload	Reboot FTOS.
upgrade (S-Series management unit)	Reset the designated S-Series stack member.

show redundancy

Display the current redundancy configuration (status of automatic reboot configuration on stack management unit).

Syntax show redundancy

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.4	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Example Figu

Figure 39-2. show redundancy Command Output

```
FTOS#show redundancy
-- SSeries Redundancy Configuration --
-----
Auto reboot :
                                        Enabled
-- Stack-unit Status --
        Mgmt ID:
 Stack-unit ID:
Stack-unit Redundancy Role: Primary Stack-unit State: Active Stack-unit SW Version: 7.7.1.0
 Link to Peer:
-- PEER Stack-unit Status --
Peer stack-unit ID: 1
Stack-unit SW Version: 7.7.1 0
-- Stack-unit Redundancy Configuration --
 Primary Stack-unit: mgmt-id 0
Auto Data Sync: Full
 Auto Data Sync:
 Auto reboot Stack-unit: Hot Failover Enabled Auto failover limit: 3 times in 60
                                          3 times in 60 minutes
-- Stack-unit Failover Record --
    _____
 Failover Count:
 Last failover timestamp:
Last failover Reason:
Last failover type:
                                         None
                                         None
 Last failover type:
                                          None
-- Last Data Block Sync Record: --
Line Card Config: succeeded Mar 07 1996 00:27:39
Start-up Config: succeeded Mar 07 1996 00:27:39
Runtime Event Log: succeeded Mar 07 1996 00:27:39
Running Config: succeeded Mar 07 1996 00:27:39
ACL Mgr: succeeded Mar 07 1996 00:27:39
```

show system stack-ports

Display information about the stacking ports on all switches in the S-Series stack. S

Syntax show system stack-ports [status | topology]

Parameters

status	(OPTIONAL) Enter the keyword status to display the command output without the Connection field.
topology	(OPTIONAL) Enter the keyword topology to limit the table to just the Interface and Connection fields.

Defaults No default behavior

Command Modes EXEC

EXEC Privilege

Command **History**

Version 8.3.3.4	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Example

Figure 39-3. show system stack-ports Command Example

FTOS# show Topology: I	system stack- Ring	ports			
Interface	Connection	Link Speed (Gb/s)	Admin Status	Link Status	
0/49	1/49	12	up	up	
0/50		12	up	down	
0/51	2/49	24	up	up	
1/49	0/49	12	up	up	
1/50	2/51	12	up	up	
2/49	0/51	24	up	up	
2/51	1/50	12	up	up	
2/52		12	up	down	
FTOS#			-		
_					

Example

Figure 39-4. show system stack-ports status Command Example

FTOS# show Topology:	system stack-p Ring	orts status		
Interface	Link Speed (Gb/s)	Admin Status	Link Status	
0/49	12	up	up	
0/50	12	up	down	
0/51	24	up	up	
1/49	12	up	up	
1/50	12	up	up	
2/49	24	up	up	
2/51	12	up	up	
2/52	12	up	down	
\ FTOS#		_		

Example

Figure 39-5. show system stack-ports topology Command Example




Table 39-1. show interfaces description Command Example Fields

Field	Description
Topology	Lists the topology of stack ports connected: Ring, Daisy chain, or Standalone
Interface	The unit/port ID of the connected stack port on this unit
Link Speed	Link Speed of the stack port (12 or 24) in Gb/s
Admin Status	The only currently listed status is Up.
Connection	The stack port ID to which this unit's stack port is connected

Related Commands

reset stack-unit	Reset the designated S-Series stack member.
show hardware stack-unit	Display the data plane or management plane input and output statistics of the designated component of the designated stack member.
show system (S-Series)	Display the current status of all stack members or a specific member.
upgrade (S-Series management unit)	Upgrade the bootflash image or system image of the S-Series management unit.

stack-unit priority

S Configure the ability of an S-Series switch to become the management unit of a stack.

Syntax stack-unit stack-unit priority preference

Parameters

stack-unit	Enter the stack member unit identifier of the stack member to reset.
	S60 range : 0 - 11
	all other S-Series range: 0-7
preference	This preference parameter allows you to specify the management priority of one backup switch over another,
	Range 0-14, with 0 the lowest priority and 14 the highest.
	The switch with the highest priority value will be chosen to become the management unit if the active management unit fails or on the next reload.

Defaults

1

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.4	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Related **Commands**

reload	Reboot FTOS.
show system (S-Series)	Display the current status of all stack members or a specific member.

stack-unit provision

(S)

Pre-configure a logical stacking ID of a switch that will join the stack. This is an optional command that is executed on the management unit.

stack-unit stack-unit provision {S25N|S25P|S25V|S50N|S50V |S60} **Syntax**

Parameters

stack-unit	Enter the stack member unit identifier of the stack member to reset.	
	S60 range : 0 - 11	
	all other S-Series range: 0-7	
S25N S25P S25V S50N S50V S60	Enter the S-Series model identifier of the switch to be added as a stack member. This identifier is also referred to as the <i>provision type</i> .	

Defaults

When this value is not set, a switch joining the stack is given the next available sequential stack member identifier.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.4	Introduced on S60	
Version 7.7.1.0	Introduced on S-Series	

Related **Commands**

reload	Reboot FTOS.
show system (S-Series)	Display the current status of all stack members or a specific member.

stack-unit renumber

Change the stack member ID of any stack member or a stand-alone S-Series.

Syntax stack-unit stack-unit renumber stack-unit

Parameters

stack-unit	Enter the stack member unit identifier of the stack member to reset.
	S60 range : 0 - 11
	all other S-Series range: 0-7
	The first instance of this value is the stack member unit identifier, from 0 to 7, of the switch that you want add to the stack.
	The second instance of this value is the desired new unit identifier number.

Defaults

none

Command Modes

EXEC Privilege

Command History

Version 8.3.3.4	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Usage Information

You can renumber any switch, including the management unit or a stand-alone unit.

You cannot renumber a unit to a number of an active member in the stack.

When executing this command on the master, the stack reloads. When the members are renumbered, only that specific unit will reset and come up with the new unit number.

Example

Figure 39-6. stack-unit renumber Command Example

S50V_7.7#stack-unit 0 renumber 2

Renumbering master unit will reload the stack. Proceed to renumber [confirm yes/no]:

Related Commands

reload	Reboot FTOS.
reset stack-unit	Reset the designated S-Series stack member.
show system (S-Series)	Display the current status of all stack members or a specific member.

upgrade system stack-unit (S-Series stack member)

Copy the boot image or FTOS from the management unit to one or more stack members.

Syntax

upgrade {boot | system} stack-unit {all | stack-unit}

Parameters

boot	Enter this keyword to copy the boot image from the management unit to the designated stack members.
system	Enter this keyword to copy the FTOS image from the management unit to the designated stack members.
all	Enter this keyword to copy the designated image to all stack members.
stack-unit	Enter the stack member unit identifier of the stack member to reset. S60 range: 0 - 11 all other S-Series range: 0-7

Defaults

No configuration or default values

Command Modes

EXEC

Command History

Version 8.3.3.4	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Usage Information

You must reload FTOS after using the **upgrade** command.

Related Commands

reload	Reboot FTOS.
reset stack-unit	Reset the designated S-Series stack member.
show system (S-Series)	Display the current status of all stack members or a specific member.
show version	Display the current FTOS version information on the system.
upgrade (S-Series management unit)	Upgrade the bootflash image or system image of the S-Series management unit.

Storm Control

Overview

The FTOS Storm Control feature allows users to limit or suppress traffic during a traffic storm (Broadcast/Unknown Unicast Rate Limiting, or Multicast on the C-Series and S-Series).

Support for particular Dell Networking platforms (C-Series, E-Series, or S-Series) is indicated by the characters that appear below each command heading:

- C-Series: C
- E-Series: [E]
- S-Series: S

Commands

The Storm Control commands are:

- show storm-control broadcast
- show storm-control multicast
- show storm-control unknown-unicast
- storm-control broadcast (Configuration)
- storm-control broadcast (Interface)
- storm-control multicast (Configuration)
- storm-control multicast (Interface)
- storm-control unknown-unicast (Configuration)
- storm-control unknown-unicast (Interface)

Important Points to Remember

- Interface commands can only be applied on physical interfaces (VLANs and LAG interfaces are not supported).
- An INTERFACE-level command only support storm control configuration on ingress.
- An INTERFACE-level command overrides any CONFIGURATION-level ingress command for that physical interface, if both are configured.
- The CONFIGURATION-level storm control commands can be applied at ingress or egress and are supported on all physical interfaces.
- When storm control is applied on an interface, the percentage of storm control applied is calculated based on the advertised rate of the line card. It is not based on the speed setting for the line card.

- Do not apply per-VLAN QoS on an interface that has storm control enabled (either on an interface or globally).
- When broadcast storm control is enabled on an interface or globally on ingress, and DSCP marking for a DSCP value 1 is configured for the data traffic, the traffic will go to queue 1 instead of queue 0.
- Similarly, if unicast storm control is enabled on an interface or globally on ingress, and DSCP marking for a DSCP value 2 is configured for the data traffic, the traffic will go to queue 2 instead of queue 0.



Note: Bi-directional traffic (unknown unicast and broadcast), along with egress storm control, causes the configured traffic rates to be split between the involved ports. The percentage of traffic that each port receives after the split is not predictable. These ports can be in the same/different port pipes, or the same/different line cards.

show storm-control broadcast

CES

Display the storm control broadcast configuration.

Syntax show storm-control broadcast [interface]

Parameters

interface

(OPTIONAL) Enter one of the following interfaces to display the interface specific storm control configuration.

- For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a SONET interface, enter the keyword **sonet** followed by the slot/port information.
- Fast Ethernet is not supported.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.5.1.0	Introduced on E-Series

Example

Figure 40-1. show storm-control broadcast Command Example (E-Series)

	FTOS#show storm-control broadcast gigabitethernet 11/11				
Broadcast storm control configuration					
	Interface	Direction	Percentage	Wred Profile	
	Gi 11/11	Ingress	5.6		
	Gi 11/11 FTOS#	Egress	5.6	-	
					/

Example Figure 40-2. show storm-control broadcast Command Example (C-Series)

FTOS#show storm-control broadcast gigabitethernet 3/24 Broadcast storm control configuration Direction Interface Packets/Second Gi 3/24 Ingress 1000 FTOS#

show storm-control multicast

Display the storm control multicast configuration.

Syntax show storm-control multicast [interface]

Parameters

interface

(OPTIONAL) Enter one of the following interfaces to display the interface specific storm control configuration.

- For Fast Ethernet, enter the keyword **Fastethernet** followed by the slot/port
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series

Example

Figure 40-3. show storm-control multicast Command Example

FTOS#show storm-control multicast gigabitethernet 1/0 Multicast storm control configuration Interface Direction Packets/Second Gi 1/0 Ingress FTOS#

show storm-control unknown-unicast

CES

Display the storm control unknown-unicast configuration

Syntax

show storm-control unknown-unicast [interface]

Parameters

interface

(OPTIONAL) Enter one of the following interfaces to display the interface specific storm control configuration.

- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a SONET interface, enter the keyword sonet followed by the slot/port information.
- Fast Ethernet is not supported.

Defaults

No default behavior or values

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.10	Introduced on C-Series
Version 6.5.1.0	Introduced on E-Series

Example E-Series

Figure 40-4. show storm-control unknown-unicast Command Example (E-Series)

FTOS#show storm-control unknown-unicast gigabitethernet 11/1

Unknown-unicast storm control configuration

Interface Direction Percentage Wred Profile

Gi 11/1 Ingress 5.9
Gi 11/1 Egress 5.7 w8

FTOS#

Example C-Series

Figure 40-5. show storm-control unknown-unicast Command Example (C-Series)

FTOS#show storm-control unknown-unicast gigabitethernet 3/0

Unknown-unicast storm control configuration

Interface Direction Packets/Second
Gi 3/0 Ingress 1000

FTOS#

storm-control broadcast (Configuration)

CESConfigure the percentage of broadcast traffic allowed in or out of the network.

Syntax storm-control broadcast [percentage decimal_value in | out] | [wred-profile name]] [packets_per_second in]

> To disable broadcast rate-limiting, use the **storm-control broadcast** [percentage decimal value in out] | [wred-profile name]] [packets_per_second in] command.

Parameters

percentage decimal_value in out	E-Series Only : Enter the percentage of broadcast traffic allowed in or out of the network. Optionally, you can designate a decimal value percentage, for example, 55.5%.
	Percentage: 0 to 100
	0 % blocks all related traffic
	100% allows all traffic into the interface
	Decimal Range: .1 to .9
wred-profile name	E-Series Only : (Optionally) Enter the keyword wred-profile followed by the profile name to designate a wred-profile.
wred-profile name packets_per_second in	E-Series Only: (Optionally) Enter the keyword wred-profile followed by the
packets_per_second	E-Series Only: (Optionally) Enter the keyword wred-profile followed by the profile name to designate a wred-profile. C-Series and S-Series Only: Enter the packets per second of broadcast traffic

Defaults No default behavior or values

Command Modes

CONFIGURATION (conf)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Added percentage decimal value option
Version 6.5.1.0	Introduced on E-Series

Usage Information

Broadcast storm control is valid on Layer 2/Layer 3 interfaces only. Layer 2 broadcast traffic is treated as unknown-unicast traffic.

storm-control broadcast (Interface)

Configure the percentage of broadcast traffic allowed on an interface (ingress only). CES

Syntax storm-control broadcast [percentage decimal_value in] [[wred-profile name]] [packets_per_second in]

> To disable broadcast storm control on the interface, use the no storm-control broadcast [percentage { decimal_value} in] [[wred-profile name]] [packets_per_second in] command.

Parameters

percentage decimal_value in	E-Series Only : Enter the percentage of broadcast traffic allowed in to the network. Optionally, you can designate a decimal value percentage, for example, 55.5%.
	Percentage: 0 to 100
	0 % blocks all related traffic
	100% allows all traffic into the interface
	Decimal Range: .1 to .9
wred-profile name	E-Series Only : (Optionally) Enter the keyword wred-profile followed by the profile name to designate a wred-profile.
packets_per_second in	C-Series and S-Series Only : Enter the packets per second of broadcast traffic allowed into the network.
	C-Series and S-Series Range: 0 to 33554431
	S60 Range: 0 to 33554368
	The minimum number of PPS limited on the S60 is 2.

Defaults

No default behavior or values

Command Modes

INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
Version 7.4.1.0	E-Series Only: Added percentage decimal value option	
Version 6.5.1.0	Introduced on E-Series	

storm-control multicast (Configuration)

CS

Configure the packets per second (pps) of multicast traffic allowed in to the C-Series and S-Series networks only.

Syntax

storm-control multicast packets_per_second in

To disable storm-control for multicast traffic into the network, use the **no storm-control multicast** *packets_per_second* **in** command.

Parameters

packets_per_second in	C-Series and S-Series Only : Enter the packets per second of multicast traffic allowed into the network followed by the keyword in .
	C-Series and S-Series Range: 0 to 33554431
	S60 Range: 0 to 33554368
	The minimum number of PPS limited on the S60 is 2

Defaults

No default behavior or values

Command Modes

CONFIGURATION (conf)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series only

Usage Information

Broadcast traffic (all 0xFs) should be counted against broadcast storm control meter, not against the multicast storm control meter. It is possible, however, that some multicast control traffic may get dropped when storm control thresholds are exceeded.

storm-control multicast (Interface)

[C][S]Configure the percentage of multicast traffic allowed on an C-Series or S-Series interface (ingress only) network only.

Syntax storm-control multicast packets_per_second in

> To disable multicast storm control on the interface, use the **no storm-control multicast** packets_per_second in command.

Parameters

C-Series and S-Series Only: Enter the packets per second of broadcast traffic packets_per_second allowed into the network. C-Series and S-Series Range: 0 to 33554431 S60 Range: 0 to 33554368 The minimum number of PPS limited on the S60 is 2

Defaults No default behavior or values

Command Modes INTERFACE (conf-if-interface-slot/port)

> Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on C-Series and S-Series

storm-control unknown-unicast (Configuration)

CESConfigure the percentage of unknown-unicast traffic allowed in or out of the network.

Syntax storm-control unknown-unicast [percentage decimal_value [in | out]] | [wred-profile name]] [packets per second in]

> To disable storm control for unknown-unicast traffic, use the **no storm-control unknown-unicast** [percentage decimal_value [in | out] | [wred-profile name]] [packets_per_second in] command.

Parameters

percentage E-Series Only: Enter the percentage of broadcast traffic allowed in or out of the network. Optionally, you can designate a decimal value percentage, for decimal_value [in | example, 55.5%. out] Percentage: 0 to 100 0 % blocks all related traffic 100% allows all traffic into the interface Decimal Range: .1 to .9

wred-profile name	E-Series Only : (Optionally) Enter the keyword wred-profile followed by the profile name to designate a wred-profile.
packets_per_second in	C-Series and S-Series Only : Enter the packets per second of broadcast traffic allowed into the network.
	Range: 0 to 33554431
	The minimum number of PPS limited on the S60 is 2

Defaults

No default behavior or values

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	E-Series Only: Added percentage decimal value option
Version 6.5.1.0	Introduced on E-Series

Usage Information

Unknown Unicast Storm-Control is valid for Layer 2 and Layer 2/Layer 3 interfaces.

storm-control unknown-unicast (Interface)

CES

Configure percentage of unknown-unicast traffic allowed on an interface (ingress only).

Syntax

storm-control unknown-unicast [percentage decimal_value in] | [wred-profile name]] [packets_per_second in]

To disable unknown-unicast storm control on the interface, use the **no storm-control** unknown-unicast [percentage decimal_value in] | [wred-profile name]] [packets_per_second in] command.

Parameters

percentage decimal_value in	E-Series Only : Enter the percentage of broadcast traffic allowed in to the network. Optionally, you can designate a decimal value percentage, for example, 55.5%.
	Percentage: 0 to 100
	0 % blocks all related traffic
	100% allows all traffic into the interface
	Decimal Range: .1 to .9
wred-profile name	E-Series Only : (Optionally) Enter the keyword wred-profile followed by the profile name to designate a wred-profile.
packets_per_second in	C-Series and S-Series Only : Enter the packets per second of broadcast traffic allowed into the network.
	C-Series and S-Series Range: 0 to 33554431
	S60 Range: 0 to 33554368
	The minimum number of PPS limited on the S60 is 2

Defaults

No default behavior or values

Command Modes

INTERFACE (conf-if-interface-slot/port)

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Introduced on S-Series	
Version 7.5.1.0	Introduced on C-Series	
Version 7.4.1.0	E-Series Only: Added percentage decimal value option	
Version 6.5.1.0	Introduced on E-Series	

Spanning Tree Protocol (STP)

Overview

The commands in this chapter configure and monitor the IEEE 802.1d Spanning Tree protocol (STP) and are supported on all three Dell Networking switch/routing platforms, as indicated by the [C], [E], and S characters under the command headings:

Commands

- bridge-priority
- bpdu-destination-mac-address
- debug spanning-tree
- description
- disable
- forward-delay
- hello-time
- max-age
- protocol spanning-tree
- show config
- show spanning-tree 0
- spanning-tree

bridge-priority

CES

Set the bridge priority of the switch in an IEEE 802.1D Spanning Tree.

Syntax

bridge-priority { priority-value | primary | secondary }

To return to the default value, enter **no bridge-priority**.

Parameters

priority-value	Enter a number as the bridge priority value.
	Range: 0 to 65535.
	Default: 32768.
primary	Enter the keyword primary to designate the bridge as the root bridge.
secondary	Enter the keyword secondary to designate the bridge as a secondary root bridge.

Defaults

priority-value = 32768

Command Modes

SPANNING TREE (The prompt is "config-stp".)

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

bpdu-destination-mac-address

Use the Provider Bridge Group address in Spanning Tree or GVRP PDUs.

Syntax bpdu-destination-mac-address [stp | gvrp] provider-bridge-group

Parameters

xstp	Force STP, RSTP, and MSTP to use the Provider Bridge Group address as the destination MAC address in its BPDUs.
gvrp	Forces GVRP to use the Provider Bridge GVRP Address as the destination MAC address in its PDUs.

Defaults

The destination MAC address for BPDUs is the Bridge Group Address.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on C-Series and S-Series.

debug spanning-tree

CES

Enable debugging of Spanning Tree Protocol and view information on the protocol.

Syntax

debug spanning-tree { stp-id [all | bpdu | config | events | exceptions | general | root] | protocol}

To disable debugging, enter no debug spanning-tree.

Parameters

stp-id	Enter zero (0). The switch supports one Spanning Tree group with a group ID of 0.
protocol	Enter the keyword for the type of STP to debug, either mstp , pvst , or rstp .
all	(OPTIONAL) Enter the keyword all to debug all spanning tree operations.
bpdu	(OPTIONAL) Enter the keyword bpdu to debug Bridge Protocol Data Units.
config	(OPTIONAL) Enter the keyword config to debug configuration information.
events	(OPTIONAL) Enter the keyword events to debug STP events.
general	(OPTIONAL) Enter the keyword general to debug general STP operations.
root	(OPTIONAL) Enter the keyword root to debug STP root transactions.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

When you enable **debug spanning-tree bpdu** for multiple interfaces, the software only sends information on BPDUs for the last interface specified.

Related Commands

protocol spanning-tree Enter SPANNING TREE mode on the switch.

description

CES

Enter a description of the Spanning Tree

Syntax description { description}

To remove the description from the Spanning Tree, use the **no description** { description} command.

Parameters

Enter a description to identify the Spanning Tree (80 characters maximum). description

Defaults No default behavior or values

Command Modes SPANNING TREE (The prompt is "config-stp".)

> Command **History**

> > Related

Version 8.3.3.1	Introduced on S60
pre-7.7.1.0	Introduced
	E (CDANNING TREE 1 d '/ 1

Commands

protocol spanning-tree	Enter SPANNING TREE mode on the switch.	

disable

CES

Disable Spanning Tree Protocol globally on the switch.

Syntax disable

To enable Spanning Tree Protocol, enter **no disable**.

Defaults Enabled (that is, Spanning Tree Protocol is disabled.)

Command Modes SPANNING TREE

> Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.7.1.0	Introduced on S-Series	

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
protocol spanning-tree	Enter SPANNING TREE mode.

Related Commands

forward-delay

CES

The amount of time the interface waits in the Listening State and the Learning State before transitioning to the Forwarding State.

Syntax forward-delay seconds

To return to the default setting, enter **no forward-delay.**

Parameters

seconds	Enter the number of seconds the FTOS waits before transitioning STP to the forwarding state.
	Range: 4 to 30
	Default: 15 seconds.

Defaults

15 seconds

Command Modes

SPANNING TREE

Command History

Related

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
max-age	Change the wait time before STP refreshes protocol configuration information.
hello-time	Change the time interval between BPDUs.

Commands

$h \land l$	la tima	
nei	lo-time	-
		_

CES

Set the time interval between generation of Spanning Tree Bridge Protocol Data Units (BPDUs).

Syntax

hello-time seconds

To return to the default value, enter **no hello-time**.

Parameters

seconds	Enter a number as the time interval between transmission of BPDUs.
	Range: 1 to 10.
	Default: 2 seconds.

Defaults

2 seconds

Command Modes

SPANNING TREE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
forward-delay	Change the wait time before STP transitions to the Forwarding state.
max-age	Change the wait time before STP refreshes protocol configuration information.

Related Commands

forward-delay	Change the wait time before STP transitions to the Forwarding state.
max-age	Change the wait time before STP refreshes protocol configuration information.

max-age

CES

Set the time interval for the Spanning Tree bridge to maintain configuration information before refreshing that information.

Syntax max-age seconds

To return to the default values, enter **no max-age**.

Parameters

seconds	Enter a number of seconds the FTOS waits before refreshing configuration information.
	Range: 6 to 40
	Default: 20 seconds.

Defaults 20 seconds

Command Modes SPANNING TREE

> Command **History**

Related Commands

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series
forward-delay	Change the wait time before STP transitions to the Forwarding state.

protocol spanning-tree

CES Enter the SPANNING TREE mode to enable and configure the Spanning Tree group.

Syntax protocol spanning-tree stp-id

hello-time

To disable the Spanning Tree group, enter **no protocol spanning-tree** *stp-id* command.

Change the time interval between BPDUs.

Parameters

stp-id	Enter zero (0). FTOS supports one Spanning Tree group, group 0.	

Defaults Not configured.

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 41-1. protocol spanning-tree Command Example

FTOS(conf) #protocol spanning-tree 0
FTOS(config-stp)#

Usage Information

STP is not enabled when you enter the SPANNING TREE mode. To enable STP globally on the switch, enter no disable from the SPANNING TREE mode.

Related Commands

disable Disable Spanning Tree group 0. To enable Spanning Tree group 0, enter **no disable**.

show config

CES

Display the current configuration for the mode. Only non-default values are displayed.

Syntax show config

Command Modes

SPANNING TREE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example

Figure 41-2. show config Command for the SPANNING TREE Mode

FTOS(config-stp)#show config
protocol spanning-tree 0
 no disable
FTOS(config-stp)#

show spanning-tree 0

CES

Display the Spanning Tree group configuration and status of interfaces in the Spanning Tree group.

Syntax

show spanning-tree 0 [active | brief | interface interface | root | summary]

Parameters

0	Enter 0 (zero) to display information about that specific Spanning Tree group.
active	(OPTIONAL) Enter the keyword active to display only active interfaces in Spanning Tree group 0.
brief	(OPTIONAL) Enter the keyword brief to display a synopsis of the Spanning Tree group configuration information.

interface interface	(OPTIONAL) Enter the keyword interface and the type slot/port of the interface you want displayed. Type slot/port options are the following:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For a SONET interface, enter the keyword sonet followed by the slot/port information.
	• For Port Channel groups, enter the keyword port-channel followed by a number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1-255 for TeraScale
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
root	(OPTIONAL) Enter the keyword root to display configuration information on the Spanning Tree group root.
summary	(OPTIONAL) Enter the keyword summary to only the number of ports in the Spanning Tree group and their state.
EXEC Privilege	
Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Command Modes

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example Figure 41-3. show spanning-tree Command Example

```
FTOS#show spann 0
     Executing IEEE compatible Spanning Tree Protocol
           Bridge Identifier has priority 32768, Address 0001.e800.0a56
           Configured hello time 2, max age 20, forward delay 15
           We are the root of the spanning tree
           Current root has priority 32768 address 0001.e800.0a56 Topology change flag set, detected flag set
           Number of topology changes 1 last change occurred 0:00:05 ago
                     from GigabitEthernet 1/3
           Timers: hold 1, topology change 35
hello 2, max age 20, forward_delay 15
Times: hello 1, topology change 1, notification 0, aging 2
     Port 26 (GigabitEthernet 1/1) is Forwarding
           Port path cost 4, Port priority 8, Port Identifier 8.26 Designated root has priority 32768, address 0001.e800.0a56
           Designated bridge has priority 32768, address 0001.e800.0a56
           Designated port id is 8.26, designated path cost 0
           Timers: message age 0, forward_delay 0, hold 0
           Number of transitions to forwarding state 1
           BPDU: sent:18, received 0
           The port is not in the portfast mode
     Port 27 (GigabitEthernet 1/2) is Forwarding
           Port path cost 4, Port priority 8, Port Identifier 8.27 Designated root has priority 32768, address 0001.e800.0a56
           Designated bridge has priority 32768, address 0001.e800.0a56
           Designated port id is 8.27, designated path cost 0
           Timers: message age 0, forward_delay 0, hold 0
           Number of transitions to forwarding state 1
           BPDU: sent:18, received 0
           The port is not in the portfast mode
     Port 28 (GigabitEthernet 1/3) is Forwarding
            Port path cost 4, Port priority 8, Port Identifier 8.28
           Designated root has priority 32768, address 0001.e800.0a56
           Designated bridge has priority 32768, address 0001.e800.0a56
Designated port id is 8.28, designated path cost 0
Timers: message age 0, forward_delay 0, hold 0
           Number of transitions to forwarding state 1
           BPDU: sent:31, received 0
           The port is not in the portfast mode
FTOS#
```

Table 41-1. show spanning-tree Command Example Information

Field	Description
"Bridge Identifier."	Lists the bridge priority and the MAC address for this STP bridge.
"Configured hello"	Displays the settings for hello time, max age, and forward delay.
"We are"	States whether this bridge is the root bridge for the STG.
"Current root"	Lists the bridge priority and MAC address for the root bridge.
"Topology flag."	States whether the topology flag and the detected flag were set.
"Number of"	Displays the number of topology changes, the time of the last topology change, and on what interface the topology change occurred.

Table 41-1. show spanning-tree Command Example Information (continued)

Field	Description
"Timers"	Lists the values for the following bridge timers:
	hold time
	topology change
	hello time
	max age
	forward delay
"Times"	List the number of seconds since the last:
	hello time
	topology change
	notification
	• aging
"Port 1"	Displays the Interface type slot/port information and the status of the interface (Disabled or Enabled).
"Port path"	Displays the path cost, priority, and identifier for the interface.
"Designated root"	Displays the priority and MAC address of the root bridge of the STG that the interface belongs.
"Designated port"	Displays the designated port ID

Figure 41-4. show spanning-tree brief Command Example

```
FTOS#show span 0 brief
     Executing IEEE compatible Spanning Tree Protocol
           Root ID
                         Priority 32768
             Address 0001.e800.0a56
           Root Bridge hello time 2, max age 20, forward delay 15
           Bridge ID
                           Priority 32768,
              Address 0001.e800.0a56
           Configured hello time 2, max age 20, forward delay 15
Interface
                                                Designated
Bridge ID
                 PortID Prio Cost Sts Cost
                                                                           PortID
Name
                 8.26 8 4 FWD 0 32768 0001.e800.0a56 8.26
8.27 8 4 FWD 0 32768 0001.e800.0a56 8.27
8.28 8 4 FWD 0 32768 0001.e800.0a56 8.28
Gi 1/1
Gi 1/2
Gi 1/3
FTOS#
```

Usage Information You must enable Spanning Tree group 0 prior to using this command.

spanning-tree

CES

Configure Spanning Tree group id, cost, priority, and Portfast for an interface.

Syntax

spanning-tree stp-id [cost cost] [portfast [bpduguard]] [priority priority]

To disable Spanning Tree group on an interface, use the **no spanning-tree** stp-id [cost cost] [portfast [bpduguard] [shutdown-on-violation]] [priority priority] command.

Parameters

Enter the Spanning Tree Protocol group ID.
Range: 0
(OPTIONAL) Enter the keyword cost followed by a number as the cost.
Range: 1 to 65535
Defaults:
100 Mb/s Ethernet interface = 19
1-Gigabit Ethernet interface = 4
10-Gigabit Ethernet interface = 2
Port Channel interface with 100 Mb/s Ethernet = 18
Port Channel interface with 1-Gigabit Ethernet = 3
Port Channel interface with 10-Gigabit Ethernet = 1
(OPTIONAL) Enter keyword priority followed by a number as the priority.
Range: zero (0) to 15.
Default: 8
(OPTIONAL) Enter the keyword portfast to enable Portfast to move the interface into
forwarding mode immediately after the root fails.
Enter the keyword bpduguard to disable the port when it receives a BPDU.
(OPTIONAL) Enter the keyword shutdown-on-violation to hardware disable an interface when a BPDU is received and the port is disabled.

Defaults

cost = depends on the interface type; priority = 8

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced hardware shutdown-on-violation option
Version 7.7.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 6.2.1.1	Introduced

Usage Information

If you enable **portfast bpduguard** on an interface and the interface receives a BPDU, the software disables the interface and sends a message stating that fact. The port is in ERR_DISABLE mode, yet appears in the **show interface** commands as enabled.

If **shutdown-on-violation** is not enabled, BPDUs will still be sent to the RPM CPU.

Time and Network Time Protocol (NTP)

Overview

The commands in this chapter configure time values on the system, either using FTOS, or the hardware, or using the Network Time Protocol (NTP). With NTP, the switch can act only as a client to an NTP clock host. For details, see the "Network Time Protocol" section of the Management chapter in the FTOS Configuration Guide.

The commands in this chapter are generally supported on the C-Series, E-Series, and S-Series, with some exceptions, as noted in the Command History fields and by these symbols under the command headings: C E S

Commands

- calendar set
- clock read-calendar
- clock set
- clock summer-time date
- clock summer-time recurring
- clock timezone
- clock update-calendar
- debug ntp
- ntp authenticate
- ntp authentication-key
- ntp broadcast client
- ntp disable
- ntp multicast client
- ntp server
- ntp source
- ntp trusted-key
- ntp update-calendar
- show calendar
- show clock
- show ntp associations
- show ntp status

calendar set

CES

Set the time and date for the switch hardware clock.

Syntax

calendar set time month day year

Parameters

time	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format, for example, 17:15:00 is 5:15 pm.
month	Enter the name of one of the 12 months in English.
	You can enter the name of a day to change the order of the display to <i>time day month year</i> .
day	Enter the number of the day.
	Range: 1 to 31.
	You can enter the name of a month to change the order of the display to time day month
	year.
year	Enter a four-digit number as the year.
	Range: 1993 to 2035.

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 42-1. calendar set Command Example

```
FTOS#calendar set 08:55:00 june 18 2006
FTOS#
```

Usage Information

You can change the order of the *month* and *day* parameters to enter the time and date as *time day month year*.

In the switch, the hardware clock is separate from the software and is called the calendar. This hardware clock runs continuously. After the hardware clock (the calendar) is set, the FTOS automatically updates the software clock after system bootup. You cannot delete the hardware clock (calendar).

To manually update the software with the hardware clock, use the command clock read-calendar.

Related Commands

clock read-calendar	Set the software clock based on the hardware clock.
clock set	Set the software clock.
clock update-calendar	Set the hardware clock based on the software clock.
show clock	Display clock settings.

clock read-calendar

CESSet the software clock on the switch from the information set in hardware clock (calendar).

Syntax clock read-calendar

Defaults Not configured.

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

In the switch, the hardware clock is separate from the software and is called the calendar. This hardware clock runs continuously. After the hardware clock (the calendar) is set, the FTOS automatically updates the software clock after system bootup.

You cannot delete this command (that is, there is not a "no" version of this command).

clock set

CES Set the software clock in the switch.

Syntax clock set time month day year

Parameters

time	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format, example, 17:15:00 is 5:15 pm.
month	Enter the name of one of the 12 months, in English.
	You can enter the number of a day and change the order of the display to time day month year.
day	Enter the number of the day.
	Range: 1 to 31.
	You can enter the name of a month to change the order of the display to time month day year.
year	Enter a four-digit number as the year.
	Range: 1993 to 2035.

Defaults Not configured

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example

Figure 42-2. clock set Command Example

FTOS#clock set 16:20:00 19 may 2001 FTOS#

Usage Information

You can change the order of the *month* and *day* parameters to enter the time and date as *time day month year*. You cannot delete the software clock.

The software clock runs only when the software is up. The clock restarts, based on the hardware clock, when the switch reboots.

Dell Networking recommends that you use an outside time source, such as NTP, to ensure accurate time on the switch.

Related Commands

ntp update-calendar Set the switch using the NTP settings.

clock summer-time date

CES

Set a date (and time zone) on which to convert the switch to daylight savings time on a one-time basis.

Syntax

clock summer-time time-zone **date** start-month start-day start-year start-time end-month end-day end-year end-time [offset]

To delete a daylight savings time zone configuration, enter **no clock summer-time**.

Parameters

time-zone	Enter the three-letter name for the time zone. This name is displayed in the show clock output.
start-month	Enter the name of one of the 12 months in English.
	You can enter the name of a day to change the order of the display to <i>time day month</i> year.
start-day	Enter the number of the day.
	Range: 1 to 31.
	You can enter the name of a month to change the order of the display to <i>time day month year</i> .
start-year	Enter a four-digit number as the year.
	Range: 1993 to 2035.
start-time	Enter the time in hours:minutes. For the hour variable, use the 24-hour format, example, 17:15 is 5:15 pm.
end-day	Enter the number of the day.
	Range: 1 to 31.
	You can enter the name of a month to change the order of the display to <i>time day month year</i> .
end-month	Enter the name of one of the 12 months in English.
	You can enter the name of a day to change the order of the display to time day month
	year.
end-time	Enter the time in hours:minutes. For the hour variable, use the 24-hour format, example, 17:15 is 5:15 pm.

end-year	Enter a four-digit number as the year. Range: 1993 to 2035.
offset	(OPTIONAL) Enter the number of minutes to add during the summer-time period.
	Range: 1 to1440.
	Default: 60 minutes

Defaults

Not configured.

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Related Commands

calendar set	Set the hardware clock.
clock summer-time recurring	Set a date (and time zone) on which to convert the switch to daylight savings time each year.
show clock	Display the current clock settings.

clock summer-time recurring

CES

Set the software clock to convert to daylight savings time on a specific day each year.

Syntax

clock summer-time time-zone recurring [start-week start-day start-month start-time end-week end-day end-month end-time [offset]]

To delete a daylight savings time zone configuration, enter **no clock summer-time**.

Parameters

time-zone	Enter the three-letter name for the time zone. This name is displayed in the show clock output.
	You can enter up to eight characters.
start-week	(OPTIONAL) Enter one of the following as the week that daylight savings begins and then enter values for <i>start-day</i> through <i>end-time</i> :
	• week-number: Enter a number from 1-4 as the number of the week in the month to start daylight savings time.
	• first: Enter this keyword to start daylight savings time in the first week of the month.
	• last: Enter this keyword to start daylight savings time in the last week of the month.
start-day	Enter the name of the day that you want daylight saving time to begin. Use English three letter abbreviations, for example, Sun, Sat, Mon, etc. Range: Sun – Sat
start-month	Enter the name of one of the 12 months in English.
start-time	Enter the time in hours:minutes. For the hour variable, use the 24-hour format, example, 17:15 is 5:15 pm.

end-week	Enter the one of the following as the week that daylight savings ends:
	• week-number: enter a number from 1-4 as the number of the week to end daylight savings time.
	 first: enter the keyword first to end daylight savings time in the first week of the month.
	• last: enter the keyword last to end daylight savings time in the last week of the month.
end-day	Enter the weekday name that you want daylight saving time to end. Enter the weekdays using the three letter abbreviations, for example Sun, Sat, Mon etc.
	Range: Sun to Sat
end-month	Enter the name of one of the 12 months in English.
end-time	Enter the time in hours:minutes:seconds. For the hour variable, use the 24-hour format, example, 17:15:00 is 5:15 pm.
offset	(OPTIONAL) Enter the number of minutes to add during the summer-time period.
	Range: 1 to 1440.
	Default: 60 minutes.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
Version 7.4.1.0	Updated the <i>start-day</i> and <i>end-day</i> options to allow for using the three-letter abbreviation of the weekday name.
pre-Version 6.1.1.0	Introduced for E-Series
-	

Related Commands

calendar set	Set the hardware clock.
clock summer-time date	Set a date (and time zone) on which to convert the switch to daylight savings time on a one-time basis.
show clock	Display the current clock settings.

clock timezone

CES

Configure a timezone for the switch.

Syntax

clock timezone timezone-name offset

To delete a timezone configuration, enter **no clock timezone**.

Parameters

timezone-name	Enter the name of the timezone. You cannot use spaces.
offset	Enter one of the following:
	• a number from 1 to 23 as the number of hours in addition to UTC for the timezone.
	• a minus sign (-) followed by a number from 1 to 23 as the number of hours

Default

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Coordinated Universal Time (UTC) is the time standard based on the International Atomic Time standard, commonly known as Greenwich Mean time. When determining system time, you must include the differentiator between UTC and your local timezone. For example, San Jose, CA is the Pacific Timezone with a UTC offset of -8.

clock update-calendar

Set the switch hardware clock based on the software clock. CES

Syntax clock update-calendar

Defaults Not configured.

Command Modes EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

Use this command only if you are sure that the hardware clock is inaccurate and the software clock is correct. You cannot delete this command (that is, there is not a "no" form of this command).

Related Commands

calendar set Set the hardware clock.	
--------------------------------------	--

debug ntp



Display Network Time Protocol (NTP) transactions and protocol messages for troubleshooting.

Syntax

debug ntp {adjust | all | authentication | events | loopfilter | packets | select | sync}

To disable debugging of NTP transactions, use the no debug ntp {adjust | all | authentication | events | loopfilter | packets | select | sync} command.

Parameters

adjust	Enter the keyword adjust to display information on NTP clock adjustments.
all	Enter the keyword all to display information on all NTP transactions.
authentication	Enter the keyword authentication to display information on NTP authentication transactions.
events	Enter the keyword events to display information on NTP events.
loopfilter	Enter the keyword loopfilter to display information on NTP local clock frequency.

packets	Enter the keyword packets to display information on NTP packets.	
select	Enter the keyword select to display information on the NTP clock selection.	
sync	Enter the keyword sync to display information on the NTP clock synchronization.	

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ntp authenticate

CES

Enable authentication of NTP traffic between the switch and the NTP time serving hosts.

Syntax

ntp authenticate

To disable NTP authentication, enter no ntp authentication.

Defaults

Not enabled.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

You also must configure an authentication key for NTP traffic using the ntp authentication-key command.

Related Commands

ntp authentication-key	Configure authentication key for NTP traffic.
ntp trusted-key	Configure a key to authenticate

ntp authentication-key

CES

Specify a key for authenticating the NTP server.

Syntax

ntp authentication-key number md5 [0 | 7] key

Parameters

number	Specify a number for the authentication key. Range: 1 to 4294967295. This number must be the same as the number parameter configured in the ntp trusted-key command.
md5	Specify that the authentication key will be encrypted using MD5 encryption algorithm.
0	Specify that authentication key will be entered in an unencrypted format (default).

7	Specify that the authentication key will be entered in DES encrypted format.
key	Enter the authentication key in the previously specified format.

Defaults

NTP authentication is not configured by default. If you do not specify the option $[0 \mid 7]$, 0 is selected by default.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Added options [0 7] for entering authentication key.
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Usage Information

After configuring the ntp authentication-key command, configure the ntp trusted-key command to complete NTP authentication.

FTOS versions 8.2.1.0 and later use an encryption algorithm to store the authentication key that is different from previous FTOS versions; beginning in version 8.2.1.0, FTOS uses DES encryption to store the key in the startup-config when you enter the command **ntp authentication-key**. Therefore, if your system boots with a startup-configuration from an FTOS versions prior to 8.2.1.0 in which you have configured ntp authentication-key, the system cannot correctly decrypt the key, and cannot authenticate NTP packets. In this case you must re-enter this command and save the running-config to the startup-config.

Related **Commands**

ntp authenticate	Enables NTP authentication.
ntp trusted-key	Configure a trusted key.

ntp broadcast client



Set up the interface to receive NTP broadcasts from a Dell Networking switch/router acting as an NTP server.

Syntax ntp broadcast client

To disable broadcast, enter no ntp broadcast client.

Defaults Disabled

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ntp disable

C E S Prevent an interface from receiving NTP packets.

Syntax ntp disable

To re-enable NTP on an interface, enter **no ntp disable**.

Default Disabled (that is, if an NTP host is configured, all interfaces receive NTP packets)

Command Modes INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

ntp multicast client

E Configure the switch to receive NTP information from the network via multicast.

Syntax ntp multicast client [multicast-address]

To disable multicast reception, use the **no ntp multicast client** [multicast-address] command.

Parameters

multicast-address (OPTIONAL) Enter a multicast address. If you do not enter a multicast address, the address 224.0.1.1 is configured.

Defaults Not configured.

Command Modes INTERFACE

Command History

pre-Version 6.1.1.0 Introduced for E-Series

ntp server

CES Configure an NTP time-serving host.

Syntax ntp server address [key keyid] [prefer] [version number]

To delete an NTP server configuration, use the **no ntp server** *ip-address* command.

Parameters

address	Enter either an IP address, in dotted decimal format, of the NTP time server, or enter the name of the server associated with the IP address.
key keyid	(OPTIONAL) Enter the keyword key and a number as the NTP peer key.
	Range: 1 to 4294967295

prefer	(OPTIONAL) Enter the keyword prefer to indicate that this peer has priority over other servers.
version number	(OPTIONAL) Enter the keyword version and a number to correspond to the NTP version used on the server.
	Range: 1 to 3

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

Usage Information

You can configure multiple time serving hosts (up to 250). From these time serving hosts, the FTOS will choose one NTP host with which to synchronize. Use the show ntp associations to determine which server was selected.

Since a large number of polls to NTP hosts can impact network performance, Dell Networking recommends that you limit the number of hosts configured.

Related Commands

show ntp associations Displays NTP servers configured and their status.

ntp source



Specify an interface's IP address to be included in the NTP packets.

Syntax

ntp source interface

To delete the configuration, enter **no ntp source**.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For an 100/1000 Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Loopback interfaces, enter the keyword **loopback** followed by a number from zero (0) to 16383.
- For a Port Channel interface, enter the keyword **lag** followed by a number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale

- For SONET interface types, enter the keyword **sonet** followed by the slot/port information.
- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For VLAN interface, enter the keyword **vlan** followed by a number from 1 to 4094.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

ntp trusted-key

CES

Set a key to authenticate the system to which NTP will synchronize.

Syntax

ntp trusted-key number

To delete the key, use the **no ntp trusted-key** *number* command.

Parameters

number	Enter a number as the trusted key ID.
	Range: 1 to 4294967295.

Defaults

Not configured.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

Usage Information

The *number* parameter in the ntp trusted-key command must be the same number as the *number* parameter in the ntp authentication-key command. If you change the ntp authentication-key command, you must also change the ntp trusted-key command.

Related Commands

ntp authentication-key	Set an authentication key for NTP.
ntp authenticate	Enable the NTP authentication parameters you set.

ntp update-calendar

CES

Configure the FTOS to update the calendar (the hardware clock) with the NTP-derived time.

Syntax

ntp update-calendar [minutes]

To return to default setting, enter **no ntp update-calendar**.

Parameters

minutes	(OPTIONAL) Enter the number of minutes between updates from NTP to the hardware clock.
	Range: 1 to 1440.
	Default: 60 minutes.

Defaults

Not enabled.

Command Modes

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

show calendar

CES

Display the current date and time based on the switch hardware clock.

Syntax

show calendar

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

Example

Figure 42-3. show calendar Command Example

FTOS#show calendar 16:33:30 UTC Tue Jun 26 2001 FTOS#

Related Commands

show clock

Display the time and date from the switch software clock.

show clock

CES

Display the current clock settings.

Syntax

show clock [detail]

Parameters

detail (OPTIONAL) Enter the keyword **detail** to view the source information of the clock.

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 42-4. show clock Command Example

FTOS#show clock 11:05:56.949 UTC Thu Oct 25 2001 FTOS#

Example Figure 42-5. show clock detail Command Example

FTOS#show clock detail
12:18:10.691 UTC Wed Jan 7 2009
Time source is RTC hardware
Summer time starts 02:00:00 UTC Sun Mar 8 2009
Summer time ends 02:00:00 ABC Sun Nov 1 2009
FTOS#

Related Commands

clock summer-time recurring	Display the time and date from the switch hardware clock.
show calendar	Display the time and date from the switch hardware clock.

show ntp associations

C E S Display the NTP master and peers.

Syntax show ntp associations

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60	
Version 7.6.1.0	Support added for S-Series	
Version 7.5.1.0	Support added for C-Series	
pre-Version 6.1.1.0	Introduced for E-Series	

Example Figure 42-6. show ntp associations Command Example

FTOS#show ntp associations st when poll reach delay offset remote ref clock disp ______ 10.10.120.5 0.0.0.0 16 - 256 0 0.00 0.000 16000.0 127.127.1.0 11 6 16 377 -0.08 0.0.0.0 16 - 256 0 0.00 0.0.0.0 16 - 256 0 0.00 *172.16.1.33 -0.08 -1499.9 104.16 0.000 16000.0 0.000 16000.0 172.31.1.33 192.200.0.2 * master (synced), # master (unsynced), + selected, - candidate

Table 42-1. show ntp associations Command Fields

Field	Description
(none)	One or more of the following symbols could be displayed:
	* means synchronized to this peer
	# means almost synchronized to this peer
	• + means the peer was selected for possible synchronization
	- means the peer is a candidate for selection
	• ~ means the peer is statically configured
remote	Displays the remote IP address of the NTP peer.
ref clock	Displays the IP address of the remote peer's reference clock.
st	Displays the peer's stratum, that is, the number of hops away from the external time source. A 16 in this column means the NTP peer cannot reach the time source.
when	Displays the last time the switch received an NTP packet.
poll	Displays the polling interval (in seconds).
reach	Displays the reachability to the peer (in octal bitstream).
delay	Displays the time interval or delay for a packet to complete a round-trip to the NTP time source (in milliseconds).
offset	Displays the relative time of the NTP peer's clock to the switch clock (in milliseconds).
disp	Displays the dispersion.

Related Commands

show ntp status	Display current NTP status.

show ntp status

CES Display the current NTP status.

Syntax show ntp status

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Support added for S-Series
Version 7.5.1.0	Support added for C-Series
pre-Version 6.1.1.0	Introduced for E-Series

Example Figure 42-7. show ntp status Command Example

FTOS#show ntp status Clock is synchronized, stratum 2, reference is 100.10.10.10 frequency is -32.000 ppm, stability is 15.156 ppm, precision is 4294967290 reference time is BC242FD5.C7C5C000 (10:15:49.780 UTC Mon Jan 10 2000) clock offset is clock offset msec, root delay is 0.01656 sec root dispersion is 0.39694 sec, peer dispersion is peer dispersion msec peer mode is client FTOS#

Table 42-2. show ntp status Command Example Information

Field	Description
"Clock is"	States whether or not the switch clock is synchronized, which NTP stratum the system is assigned and the IP address of the NTP peer.
"frequency is"	Displays the frequency (in ppm), stability (in ppm) and precision (in Hertz) of the clock in this system.
"reference time is"	Displays the reference time stamp.
"clock offset is"	Displays the system offset to the synchronized peer and the time delay on the path to the NTP root clock.
"root dispersion is"	Displays the root and path dispersion.
"peer mode is"	State what NTP mode the switch is. This should be client mode.

Related Commands

show ntp associations	Display information on NTP master and peer configurations.

S60 u-Boot

Overview

All commands in this chapter are in u-Boot. These commands are supported on the [560] only.

To access this mode, hit any key when the following line appears on the console during a system boot: Hit any key to stop autoboot:

You enter u-Boot immediately, as indicated by the => prompt.



Note: This chapter discusses only a few commands available in uBoot. The commands included here are those that are comparable to those found in the Boot User mode on other S-Series systems.

Commands

- printenv
- reset
- save
- setenv



Note: You cannot use the Tab key to complete commands in this mode.

printenv

Display the current system boot variable and other system settings.

Syntax printenv

Command Modes uBoot

> Command History

Version 8.3.3.1 Introduced on the S60.

Example => printenv baudrate=9600 uboot filesize=0x80000 bootfile=FTOS-SC-1.2.0.0E3.bin bootcmd=echo Booting primary bootline...; \$primary_boot; boot; echo Failed; echo Booting secondary bootline...; \$secondary_boot; boot; echo Failed; echo Booting default bootline....; \$default_boot; boot; echo Failed; echo Rebooting...; reset bootdelay=5 loads echo=1 rootpath=/opt/nfsroot hostname=unknown loadaddr=640000 ftpuser=FTOS ftppasswd=FTOS uboot=u-boot.bin tftpflash=tftpboot \$loadaddr \$uboot; protect off 0xfff80000 +\$filesize; erase 0x fff80000 +\$filesize; cp.b \$loadaddr 0xfff80000 \$filesize; protect on 0xfff80000 +\$filesize; cmp.b \$loadaddr 0xfff80000 \$filesize ethact=eTSEC1 ethaddr=00:01:E8:82:09:B2 serverip=10.11.9.4 primary boot=f10boot tftp://10.11.9.2/si-s60-40g secondary_boot=f10boot flash0_____ MAC Address default_boot=f10boot tftp://192.168.128.1/FTOS-SC-1.2.0.0E3.bin gatewayip=10.11.192.254 ipaddr=10.11.198.114 Variables netmask=255.255.0.0 mgmtautoneg=true Default Gateway Address mgmtspeed100=true mgmtfullduplex=true - Management IP Address stdin=serial stdout=serial stderr=serial Environment size: 1002/8188 bytes Reload the S60 system.

reset

Syntax reset

Command Modes uBoot

Command History

Version 8.3.3.1 Introduced on the S60.

Usage Information

You must save your changes before resetting the system, or all changes will be lost.

save

Save configurations created in uBoot.

Syntax

save

Command Modes

uBoot

Command History

Version 8.3.3.1 Introduced on the S60.

Usage Information

You must save your changes before resetting the system, or all changes will be lost.

setenv

Configure system settings.

Syntax

setenv [gatewayip address | primary_image f10boot location | secondary_image f10boot location | default_image f10boot location | ipaddr address | ethaddr address | enablepwdignore | stconfigignore]

Parameters

gatewayip address	Enter the IP address for the default gateway.
primary_image	Enter the keywords primary_image to configure the boot parameters used in the first attempt to boot FTOS.
secondary_image	Enter the keywords secondary_image to configure boot parameters used if the primary operating system boot selection is not available.
default_image	Enter the keywords default_image to configure boot parameters used if the secondary operating system boot parameter selection is not available. The default location should always be the internal flash device (flash:), and a verified image should be stored there.
location	Enter the location of the image file to be loaded. The keyword f10boot must precede the location when using this command. For example, primary_image f10boot tftp://10.10.10.10/server
ipaddr	Enter the keyword ipaddr to configure the system management IP address.
ethaddr	Enter the keyword ethaddr to configure system management MAC address.
address	Enter the IP address in standard IPv4 format and the MAC address in standard MAC format.
enablepwdignore	Enter the keywords enablepwdignore true to reload the system software without the enable password configured.
stconfigignore	Enter the keywords stconfigignore true ignore the startup configuration file when reloading the system.

Command Modes

uBoot

Command History

Version 8.3.3.1 Introduced on the S60.

Uplink Failure Detection (UFD)

Overview

Uplink Failure Detection (UFD) provides detection of the loss of upstream connectivity and, if used with NIC teaming, automatic recovery from a failed link.

Uplink Failure Detection is supported on the following platforms: [S] (S50 only) and 54810

Commands

- clear ufd-disable
- debug uplink-state-group
- description
- downstream
- downstream auto-recover
- downstream disable links
- enable
- show running-config uplink-state-group
- show uplink-state-group
- uplink-state-group
- upstream

clear ufd-disable

S S50 only S55 [S60]

Re-enable one or more downstream interfaces on the switch/router that are in a UFD-disabled error state so that an interface can send and receive traffic.

54810

Syntax clear ufd-disable {interface | uplink-state-group group-id}

Daramatara		
Parameters	interface interfac	Specifies one or more downstream interfaces.
		For interface, enter one of the following interface types:
		• Fast Ethernet: fastethernet { <i>slot/port</i> <i>slot/port-range</i> }
		• 1-Gigabit Ethernet: gigabitethernet { <i>slot/port slot/port-range</i> }
		 10-Gigabit Ethernet: tengigabitethernet {slot/port slot/port-range}
		• Port channel: port-channel {1-512 <i>port-channel-range</i> }
		Where port-range and port-channel-range specify a range of ports separated by a dash (-) and/or individual ports/port channels in any order; for example: gigabitethernet 1/1-2,5,9,11-12 port-channel 1-3,5
		A comma is required to separate each port and port-range entry.
	uplink-state-grou	Re-enables all UFD-disabled downstream interfaces in the group.
	group-id	Valid <i>group-id</i> values are 1 to 16.
Defaults	A downstream inte and in a UFD-disab	rface in an uplink-state group that has been disabled by UFD is disabled bled error state.
Command Modes	CONFIGURATION	7
Command	Version 8.3.12.0	Introduced on S4810
History		
	Version 8.4.2.3	Introduced on the S-Series S50.
Related		
Commands	downstream	Assign a port or port-channel to the uplink-state group as a downstream interface.
	uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

debug uplink-state-group

S S50 only Enable debug messages for events related to a specified uplink-state group or all groups.

S55 S60

[54810]

Defaults

Syntax debug uplink-state-group [group-id]

Parameters

group-id

Enables debugging on the specified uplink-state group. Valid group-id values are 1 to 16.

None

are r to

Command Modes EXEC Privilege

Command History	Version 8.3.12.0	Introduced on S4810
,	Version 8.4.2.3	Introduced on the S-Series S50.
Usage Information	To turn off debug command.	ging event messages, enter the no debug uplink-state-group [group-id]
Related	clear ufd-disable	Re-enable downstream interfaces that are in a UFD-disabled error state.

description

S S50 only

Commands

Enter a text description of an uplink-state group.

S55 S60

54810

Syntax description text

Parameters text Text description of the uplink-state group.

Maximum length: 80 alphanumeric characters.

Defaults None

Command Modes UPLINK-STATE-GROUP

> Command Version 8.3.12.0 Introduced on S4810 History

> > Version 8.4.2.3 Introduced on the S-Series S50.

Related Commands

Create an uplink-state group and enabling the tracking of upstream uplink-state-group

Example FTOS(conf-uplink-state-group-16) # description test FTOS (conf-uplink-state-group-16) #

downstream S S50 only

Assign a port or port-channel to the uplink-state group as a downstream interface.

S55 S60

54810

Syntax downstream interface

Parameters interface Enter one of the following interface types: Fast Ethernet: **fastethernet** { *slot/port | slot/port-range* } 1-Gigabit Ethernet: **gigabitethernet** { *slot/port* | *slot/port-range* } 10-Gigabit Ethernet: **tengigabitethernet** { *slot/port |slot/port-range* } Port channel: **port-channel** {1-512 | *port-channel-range*} Where port-range and port-channel-range specify a range of ports separated by a dash (-) and/or individual ports/port channels in any order; for example: gigabitethernet 1/1-2,5,9,11-12 port-channel 1-3,5

Defaults

None

Command Modes

UPLINK-STATE-GROUP

Command History

Version 8.3.12.0	Introduced on S4810
Version 8.4.2.3	Introduced on the S-Series S50.

A comma is required to separate each port and port-range entry.

Usage Information

You can assign physical port or port-channel interfaces to an uplink-state group.

You can assign an interface to only one uplink-state group. Each interface assigned to an uplink-state group must be configured as either an upstream or downstream interface, but not both.

You can assign individual member ports of a port channel to the group. An uplink-state group can contain either the member ports of a port channel or the port channel itself, but not both.

To delete an uplink-state group, enter the **no downstream** interface command.

Related Commands

upstream	Assign a port or port-channel to the uplink-state group as an upstream interface.
uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

downstream auto-recover

S S50 only

[S55] [S60]

Enable auto-recovery so that UFD-disabled downstream ports in an uplink-state group automatically come up when a disabled upstream port in the group comes back up.

54810

Syntax downstream auto-recover

Defaults The auto-recovery of UFD-disabled downstream ports is enabled.

Command Modes UPLINK-STATE-GROUP

Command History	Version 8.3.12.0	Introduced on S4810
•	Version 8.4.2.3	Introduced on the S-Series S50.
Usage Information	To disable auto-recommand.	ecovery on downstream links, enter the no downstream auto-recover
Related Commands	downstream	Assign a port or port-channel to the uplink-state group as a downstream interface.
	unlink-state-group	Create an unlink-state group and enabling the tracking of unstream

downstream disable links

S S50 only S55 S60

54810

Configure the number of downstream links in the uplink-state group that will be disabled if one upstream link in an uplink-state group goes down.

Syntax downstream disable links {number |all}

Parameters	number	Enter the number of downstream links to be brought down by UFD. Range: 1 to 1024.
	all	Brings down all downstream links in the group.

Defaults No downstream links are disabled when an upstream link in an uplink-state group goes down.

Command Modes UPLINK-STATE-GROUP

Command **History**

Version 8.3.12.0	Introduced on S4810
Version 8.4.2.3	Introduced on the S-Series S50.

Usage Information

A user-configurable number of downstream interfaces in an uplink-state group are put into a link-down state with an UFD-Disabled error message when one upstream interface in an uplink-state group goes down.

If all upstream interfaces in an uplink-state group go down, all downstream interfaces in the same uplink-state group are put into a link-down state.

To revert to the default setting, enter the **no downstream disable links** command.

Related **Commands**

downstream	Assign a port or port-channel to the uplink-state group as a downstream interface.
uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

enable

S S50 only

Enable uplink state group tracking for a specific Uplink Failure Detection (UFD) group.

(S55) (S60)

S4810)

Syntax enable

Defaults Upstream-link tracking is automatically enabled in an uplink-state group.

Command Modes UPLINK-STATE-GROUP

Command History

Version 8.3.12.0 Introduced on S4810

Version 8.4.2.3 Introduced on the S-Series S50.

Usage Information

Commands

To disable upstream-link tracking without deleting the uplink-state group, enter the **no enable** command.

Related

uplink-state-group

Create an uplink-state group and enabling the tracking of upstream

show running-config uplink-state-group

S S50 only Display the current configuration of one or more uplink-state groups.

S55 S60

54810

Syntax show running-config uplink-state-group [group-id]

Parameters

group-id

Displays the current configuration of all uplink-state groups or a

specified group. Valid *group-id* values are 1 to 16.

Defaults None

Command Modes EXEC

EXEC Privilege

Command History

Version 8.3.12.0 Introduced on S4810

Version 8.4.2.3 Introduced on the S-Series S50.

Example FTOS#show running-config uplink-state-group

no enable

uplink state track 1

downstream GigabitEthernet 0/2,4,6,11-19

```
upstream TengigabitEthernet 0/48, 52
upstream PortChannel 1
uplink state track 2
downstream GigabitEthernet 0/1,3,5,7-10
upstream TengigabitEthernet 0/56,60
```

Related **Commands**

show uplink-state-group	Display status information on a specified uplink-state group or all groups.
uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

show uplink-state-group

S S50 only

Display status information on a specified uplink-state group or all groups.

S55 S60

54810

Syntax

show uplink-state-group [group-id] [detail]

Parameters

group-id	Displays status information on a specified uplink-state group or all groups. Valid <i>group-id</i> values are 1 to 16.
detail	Displays additional status information on the upstream and downstream interfaces in each group

Defaults

None

Command Modes

EXEC

EXEC Privilege

Command **History**

Version 8.3.12.0	Introduced on S4810
Version 8.4.2.3	Introduced on the S-Series S50.

Example

```
FTOS# show uplink-state-group
```

```
Uplink State Group: 1 Status: Enabled, Up
Uplink State Group: 3 Status: Enabled, Up
Uplink State Group: 5 Status: Enabled, Down
Uplink State Group: 6 Status: Enabled, Up
Uplink State Group: 7 Status: Enabled, Up
Uplink State Group: 16 Status: Disabled, Up
FTOS# show uplink-state-group 16
Uplink State Group: 16 Status: Disabled, Up
FTOS#show uplink-state-group detail
(Up): Interface up (Dwn): Interface down (Dis): Interface disabled
Uplink State Group : 1
                            Status: Enabled, Up
Upstream Interfaces :
```

Downstream Interfaces :

Uplink State Group : 3 Status: Enabled, Up Upstream Interfaces : Gi 0/46(Up) Gi 0/47(Up)

Downstream Interfaces : Te 13/0(Up) Te 13/1(Up) Te 13/3(Up) Te 13/5(Up) Te 13/6(Up)

Downstream Interfaces : Te 13/2 (Dis) Te 13/4 (Dis) Te 13/11 (Dis) Te 13/12 (Dis) Te 13/13 (Dis) Te 13/14 (Dis) Te 13/15 (Dis)

Uplink State Group : 6 Status: Enabled, Up

Upstream Interfaces :
Downstream Interfaces :

Uplink State Group : 7 Status: Enabled, Up

Upstream Interfaces : Downstream Interfaces :

Uplink State Group : 16 Status: Disabled, Up

Upstream Interfaces : Gi 0/41(Dwn) Po 8(Dwn)

Downstream Interfaces : Gi 0/40(Dwn)

Related Commands

show running-config uplink-state-group	Display the current configuration of one or more uplink-state groups.
uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

uplink-state-group

S S50 only

Create an uplink-state group and enabling the tracking of upstream links on a switch/router.

S55 [S60]

54810

Parameters

Syntax uplink-state-group group-id

group-id Enter the ID number of an uplink-state group. Range: 1-16.

Defaults None

Command Modes CONFIGURATION

Command History

Version 8.3.12.0 Introduced on S4810

Version 8.4.2.3 Introduced on the S-Series S50.

Usage Information After you enter the command, you enter uplink-state-group configuration mode to assign upstream and downstream interfaces to the group.

An uplink-state group is considered to be operationally up if at least one upstream interface in the group is in the link-up state.

An uplink-state group is considered to be operationally down if no upstream interfaces in the group are in the link-up state. No uplink-state tracking is performed when a group is disabled or in an operationally down state.

To delete an uplink-state group, enter the **no uplink-state-group** *group-id* command.

To disable upstream-link tracking without deleting the uplink-state group, enter the no enable command in uplink-state-group configuration mode.

Related **Commands**

show running-config uplink-state-group	Display the current configuration of one or more uplink-state groups.
show uplink-state-group	Display status information on a specified uplink-state group or all groups.

Example

FTOS(conf) #uplink-state-group 16 FTOS (conf)#

02:23:17: %RPMO-P:CP %IFMGR-5-ASTATE UP: Changed uplink state group Admin state to up: Group 16

upstream

S S50 only

Assign a port or port-channel to the uplink-state group as an upstream interface.



Syntax

upstream interface

Parameters

interface	Enter one of the following interface types:
	 Fast Ethernet: fastethernet {slot/port slot/port-range}
	• 1-Gigabit Ethernet: gigabitethernet { <i>slot/port</i> <i>slot/port-range</i> }
	• 10-Gigabit Ethernet: tengigabitethernet { <i>slot/port</i> <i>slot/port-range</i> }
	• 40-Gigabit Ethernet: fortyGigE { <i>slot/port</i> <i>slot/port-range</i> }
	• Port channel: port-channel {1-512 <i>port-channel-range</i> }
	Where <i>port-range</i> and <i>port-channel-range</i> specify a range of ports
	separated by a dash (-) and/or individual ports/port channels in any order; for example:
	gigabitethernet 1/1-2,5,9,11-12
	port-channel 1-3,5
	A comma is required to separate each port and port-range entry.

Defaults

None

Command Modes

UPLINK-STATE-GROUP

Command History

Version 8.3.12.0	Introduced on S4810
Version 8.4.2.3	Introduced on the S-Series S50.

Usage Information

You can assign physical port or port-channel interfaces to an uplink-state group.

You can assign an interface to only one uplink-state group. Each interface assigned to an uplink-state group must be configured as either an upstream or downstream interface, but not both.

You can assign individual member ports of a port channel to the group. An uplink-state group can contain either the member ports of a port channel or the port channel itself, but not both.

To delete an uplink-state group, enter the **no upstream** *interface* command.

Related Commands

downstream	Assign a port or port-channel to the uplink-state group as a downstream interface.
uplink-state-group	Create an uplink-state group and enabling the tracking of upstream links.

Example

FTOS(conf-uplink-state-group-16)# upstream gigabitethernet 1/10-15 FTOS(conf-uplink-state-group-16)#

VLAN Stacking

Overview

With the VLAN-Stacking feature (also called Stackable VLANs and QinQ), available on all Dell Networking platforms (C-Series [C], E-Series [E], and S-Series [S]) that are supported by this version of FTOS, you can "stack" VLANs into one tunnel and switch them through the network transparently.

Commands

The commands included are:

- dei enable
- dei honor
- dei mark
- member
- show interface dei-honor
- show interface dei-mark
- vlan-stack access
- vlan-stack compatible
- vlan-stack dot1p-mapping
- vlan-stack protocol-type
- vlan-stack trunk

For information on basic VLAN commands, see Virtual LAN (VLAN) Commands in the chapter Layer 2.

Important Points to Remember

- If Spanning Tree Protocol (STP) is not enabled across the Stackable VLAN network, STP BPDUs from the customer's networks are tunneled across the Stackable VLAN network.
- If STP is enabled across the Stackable VLAN network, STP BPDUs from the customer's networks are consumed and not tunneled across the Stackable VLAN network unless protocol tunneling is enabled.

Note: For details on protocol tunneling on the E-Series, see Chapter 36, Service Provider Bridging.

Layer 3 protocols are not supported on a Stackable VLAN network.

- Assigning an IP address to a Stackable VLAN is supported when all the members are only
 Stackable VLAN trunk ports. IP addresses on a Stackable VLAN-enabled VLAN is not supported
 if the VLAN contains Stackable VLAN access ports. This facility is provided for SNMP
 management over a Stackable VLAN enabled VLAN containing only Stackable VLAN trunk
 interfaces. Layer 3 routing protocols on such a VLAN are not supported.
- It is recommended that you do not use the same MAC address, on different customer VLANs, on the same Stackable VLAN.
- Interfaces configured using Stackable VLAN access or Stackable VLAN trunk commands will not
 switch traffic for the default VLAN. These interfaces will switch traffic only when they are added
 to a non-default VLAN.
- Starting with FTOS 7.8.1 for C-Series and S-Series (FTOS 7.7.1 for E-Series, 8.2.1.0 for E-Series ExaScale), a vlan-stack trunk port is also allowed to be configured as a tagged port and as an untagged port for single-tagged VLANs. When the vlan-stack trunk port is also a member of an untagged vlan, the port should be in hybrid mode. See portmode hybrid.

dei enable

CS

Make packets eligible for dropping based on their DEI value.

Syntax

dei enable

Defaults

Packets are colored green; no packets are dropped.

Command Mode

CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

dei honor



Honor the incoming DEI value by mapping it to an FTOS drop precedence. You may enter the command once for 0 and once for 1.

Syntax

dei honor {0 | 1} {green | red | yellow}

Parameters

0 1	Enter the bit value you want to map to a color.	
green	Choose a color:	
red	• Green : High priority packets that are the least preferred to be dropped.	
yellow	• Yellow: Lower priority packets that are treated as best-effort.	
	Red: Lowest priority packets that are always dropped (regardless of congestion	
	status).	

Defaults

Disabled; Packets with an unmapped DEI value are colored green.

Command Mode

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

Usage Information You must first enable DEI for this configuration to take effect.

Related **Commands**

dei enable

dei mark

[C][S]

Set the DEI value on egress according to the color currently assigned to the packet.

Syntax

dei mark {green | yellow} {0 | 1}

Parameters

0 1	Enter the bit value you want to map to a color.	
green	Choose a color:	
yellow	• Green : High priority packets that are the least preferred to be dropped.	
	 Yellow: Lower priority packets that are treated as best-effort. 	

Defaults

All the packets on egress will be marked with DEI 0.

Command Mode

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

Usage Information

You must first enable DEI for this configuration to take effect.

Related Commands

dei enable

member

CES

Assign a Stackable VLAN access or trunk port to a VLAN. The VLAN must contain the vlan-stack compatible command in its configuration.

Syntax

member interface

To remove an interface from a Stackable VLAN, use the **no member** interface command.

Parameters

interface

Enter the following keywords and slot/port or number information:

- For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
- For a Port Channel, enter the keyword **port-channel** followed by a number from 1 to 255 for TeraScale and ExaScale; 1 to 128 for C-Series and S-Series.
- For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.

Defaults

Not configured.

Command Mode

CONF-IF-VLAN

Command

History ____

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the E-Series ExaScale
Version 7.6.1.0	Support added for C-Series and S-Series
E-Series original Command	

Usage Information

You must enable the Stackable VLAN (using the vlan-stack compatible command) on the VLAN prior to adding a member to the VLAN.

Related Commands

vlan-stack compatible Enable Stackable VLAN on a VLAN.

show interface dei-honor

C S Display the **dei honor** configuration.

Syntax show interface dei-honor [interface slot/port | linecard number port-set number]

Parameters

interface slot/port	Enter the interface type followed by the line card slot and port number.
linecard number port-set number	Enter linecard followed by the line card slot number, then enter port-set followed by the port-pipe number.

Command Mode

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

Example

FTOS#show interface dei-honor

Default Drop precedence: Green

Interface	CFI/DEI	brop precedence
Gi 0/1	0	Green
Gi 0/1	1	Yellow
Gi 8/9	1	Red
Gi 8/40	0	Yellow

Related Commands

dei honor

show interface dei-mark

C S Display the **dei mark** configuration.

Syntax show interface dei-mark [interface slot/port | linecard number port-set number]

Parameters

interface slot/port	Enter the interface type followed by the line card slot and port number.
linecard number port-set number	Enter linecard followed by the line card slot number, then enter port-set followed by the port-pipe number.

Command Mode EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

Example FTOS#show interface dei-mark

Default CFI/DEI Marking: 0

Interface	Drop precedence	CFI/DEI
Gi 0/1	Green	0
Gi 0/1	Yellow	1
Gi 8/9	Yellow	0
Gi 8/40	Yellow	0

Related Commands

dei mark

vlan-stack access

CES Specify a Layer 2 port or port channel as an access port to the Stackable VLAN network.

Syntax vlan-stack access

To remove access port designation, enter **no vlan-stack access**.

Defaults Not configured.

Command Modes INTERFACE

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the E-Series ExaScale
Version 7.6.1.0	Support added for C-Series and S-Series
E-Series original C	Command

Usage Information

Prior to enabling this command, you must enter the switchport command to place the interface in Layer 2 mode.

To remove the access port designation, the port must be removed (using the no member interface command) from all Stackable VLAN enabled VLANs.

vlan-stack compatible

CES Enable the Stackable VLAN feature on a VLAN.

Syntax vlan-stack compatible

To disable the Stackable VLAN feature on a VLAN, enter **no vlan-stack compatible**.

Defaults Not configured.

Command Modes CONF-IF-VLAN

Command History


Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the E-Series ExaScale
Version 7.6.1.0	Support added for C-Series and S-Series
E-Series original Command	

Usage Information

You must remove the members prior to disabling the Stackable VLAN feature.

To view the Stackable VLANs, use the **show vlan** command in the EXEC Privilege mode. Stackable VLANs contain members, designated by the M in the Q column of the command output.

Figure 45-1. show vlan Command Example with Stackable VLANs



vlan-stack dot1p-mapping

CS

Map C-Tag dot1p values to a S-Tag dot1p value. C-Tag values may be separated by commas, and dashed ranges are permitted. Dynamic Mode CoS overrides any Layer 2 QoS configuration in case of conflicts.

Syntax

vlan-stack dot1p-mapping c-tag-dot1p values sp-tag-dot1p value

Parameters

c-tag-dot1p value	Enter the keyword followed by the customer dot1p value that will be mapped to a service provider do1p value. Range: 0-7	
sp-tag-dot1p value	Enter the keyword followed by the service provider dot1p value. Range: 0-7	

Defaults

None

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.3.1.0	Introduced on C-Series and S-Series.

vlan-stack protocol-type

CES

Define the Stackable VLAN Tag Protocol Identifier (TPID) for the outer VLAN tag (also called the VMAN tag). If you do not configure this command, FTOS assigns the value 0x9100.

Syntax

vlan-stack protocol-type number

Parameters

Enter the hexadecimal number as the Stackable VLAN tag. On the E-Series: FTOS accepts the Most Significant Byte (MSB) and then appends zeros for the Least Significant Byte (LSB). On the C-Series and S-Series: You may specify both bytes of the 2-byte S-Tag TPID. E-Series Range: 0-FF C-Series and S-Series Range: 0-FFFF Default: 9100

Defaults

0x9100

number

Command Modes

CONFIGURATION

Command **History**

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the E-Series ExaScale. C-Series and S-Series accept both bytes of the 2-byte S-Tag TPID.
Version 8.2.1.0	Introduced on the E-Series ExaScale
Version 7.6.1.0	Support added for C-Series and S-Series
E-Series original Command	

Usage Information

See the FTOS Configuration Guide for specific interoperability limitations regarding the S-Tag TPID.

On E-Series TeraScale, the two characters you enter in the CLI for number become the MSB, as shown in Table 45-1.

Table 45-1. Configuring a TPID on the E-Series TeraScale

number	Resulting TPID
1	0x0100
10	0x1000
More than two characters.	Configuration rejected.

On E-Series ExaScale, C-Series, and S-Series, four characters you enter in the CLI for *number* are interpreted as follows:

Table 45-2. Configuring a TPID on the E-Series TeraScale

number	Resulting TPID
1	0x0001
10	0x0010
81	0x0081
8100	0x8100

Related Commands

portmode hybrid	Set a port (physical ports only) to accept both tagged and untagged frames. A port configured this way is identified as a hybrid port in report displays.
vlan-stack trunk	Specify a Layer 2 port or port channel as a trunk port to the Stackable VLAN network.

vlan-stack trunk

CES

Specify a Layer 2 port or port channel as a trunk port to the Stackable VLAN network.

Syntax vlan-stack trunk

To remove a trunk port designation from the selected interface, enter **no vlan-stack trunk**.

Defaults

Not configured.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 8.2.1.0	Introduced on the E-Series ExaScale
Version 7.8.1.0	Functionality augmented for C-Series and S-Series to enable multi-purpose use of the port. See Usage Information, below.
Version 7.7.1.0	Functionality augmented for E-Series to enable multi-purpose use of the port. See Usage Information, below.
Version 7.6.1.0	Introduced for C-Series and S-Series
E-Series original C	ommand

Usage Information

Prior to using this command, you must execute the **switchport** command to place the interface in Layer 2 mode.

To remove the trunk port designation, the port must first be removed (using the **no member** *interface* command) from all Stackable VLAN-enabled VLANs.

Starting with FTOS 7.7.1.0 for E-Series, the VLAN-Stack trunk port can transparently tunnel, in a service provider environment, customer-originated xSTP control protocol PDUs. See Chapter 36, Service Provider Bridging.

Starting with FTOS 7.8.1.0 for C-Series and S-Series (FTOS 7.7.1 for E-Series), a VLAN-Stack trunk port is also allowed to be configured as a tagged port and as an untagged port for single-tagged VLANs. When the VLAN-Stack trunk port is also a member of an untagged VLAN, the port should be in hybrid mode. See portmode hybrid.

In Example 1 below.a VLAN-Stack trunk port is configured and then also made part of a single-tagged VLAN.

In Example 2 below, the Tag Protocol Identifier (TPID) is set to 8848. The "Gi 3/10" port is configured to act as a VLAN-Stack access port, while the "TenGi 8/0" port will act as a VLAN-Stack trunk port, switching Stackable VLAN traffic for VLAN 10, while also switching untagged traffic for VLAN 30 and tagged traffic for VLAN 40. (To allow VLAN 30 traffic, the native VLAN feature is required, by executing the **portmode hybrid** command. See portmode hybrid in Interfaces.

Example 1 Figure 45-2. Adding a Stackable VLAN Trunk Port to a Tagged VLAN

```
FTOS(conf-if-gi-0/42)#switchport
FTOS(conf-if-gi-0/42)#vlan-stack trunk
FTOS (conf-if-gi-0/42) #show config
interface GigabitEthernet 0/42
 no ip address
 switchport
 vlan-stack trunk
 no shutdown
FTOS(conf-if-gi-0/42)#interface vlan 100
FTOS(conf-if-vl-100) #vlan-stack compatible
FTOS(conf-if-vl-100-stack) #member gigabitethernet 0/42
FTOS(conf-if-vl-100-stack) #show config
interface Vlan 100
 no ip address
 vlan-stack compatible
 member GigabitEthernet 0/42
 shutdown
FTOS(conf-if-vl-100-stack)#interface vlan 20
FTOS(conf-if-vl-20)#tagged gigabitethernet 0/42
FTOS(conf-if-v1-20) #show config
interface Vlan 20
no ip address
 tagged GigabitEthernet 0/42
 shutdown
FTOS(conf-if-v1-20)#do show vlan
Codes: * - Default VLAN, G - GVRP VLANs
Q: U - Untagged, T - Tagged
x - Dotlx untagged, X - Dotlx tagged
G - GVRP tagged, M - Vlan-stack
    NUM
          Status
                      Description
                                                            O Ports
            Inactive
    1
    20
          Active
Active
                                                            T Gi 0/42
    100
                                                            M Gi 0/42
FTOS(conf-if-v1-20)#
```

Example 2 Figure 45-3. Adding a Stackable VLAN Trunk Port to Tagged and Untagged VLANs

```
FTOS(config)#vlan-stack protocol-type 88A8
FTOS (config) #interface gigabitethernet 3/10
FTOS (conf-if-gi-3/10) #no shutdown
FTOS(conf-if-gi-3/10)#switchport
FTOS (conf-if-gi-3/10) #vlan-stack access FTOS (conf-if-gi-3/10) #exit
FTOS(config)#interface tenGigabitethernet 8/0
FTOS (conf-if-te-10/0) #no shutdown
FTOS (conf-if-te-10/0) #portmode hybrid
FTOS (conf-if-te-10/0) #switchport
FTOS (conf-if-te-10/0) #vlan-stack trunk
FTOS(conf-if-te-10/0)#exit
FTOS(config)#interface vlan 10
FTOS(conf-if-vlan)#vlan-stack compatible
FTOS(conf-if-vlan) #member Gi 7/0, Gi 3/10, TenGi 8/0
FTOS (conf-if-vlan) #exit
FTOS(config)#interface vlan 30
FTOS(conf-if-vlan) #untagged TenGi 8/0
FTOS(conf-if-vlan)#exit
FTOS(config)#
FTOS(config)#interface vlan 40
FTOS(conf-if-vlan) #tagged TenGi 8/0
FTOS (conf-if-vlan) #exit
FTOS(config)#
```

Virtual Router Redundancy Protocol (VRRP)

Overview

Virtual Router Redundancy Protocol (VRRP) commands are supported on all platforms: [C], [E], and [S].

To enter the VRRP mode on an interface, use the vrrp-group command at the INTERFACE mode. The interface must be in Layer 3 mode. You can configure up to 12 VRRP groups on one interface.

For configuration details, see the VRRP chapter in the FTOS Configuration Guide.

Commands

The commands are:

- advertise-interval
- authentication-type
- clear counters vrrp
- debug vrrp
- description
- disable
- hold-time
- preempt
- priority
- show config
- show vrrp
- virtual-address
- vrrp-group

advertise-interval

CES Set the time interval between VRRP advertisements.

Syntax advertise-interval seconds

To return to the default settings, enter **no advertise-interval**.

Parameters

seconds	Enter a number of seconds.
	Range: 1 to 255.
	Default: 1 second.

Defaults

1 second.

Command Modes

INTERFACE-VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information Dell Networking recommends that you keep the default setting for this command. If you do change the time interval between VRRP advertisements on one router, you must change it on all routers.

authentication-type

CES

Enable authentication of VRRP data exchanges.

Syntax

authentication-type simple [encryption-type] password

To delete an authentication type and password, enter **no authentication-type**.

Parameters

simple	Enter the keyword simple to specify simple authentication.		
encryption-type	(OPTIONAL) Enter one of the following numbers:		
	 0 (zero) for an unencrypted (clear text) password 7 (seven) for hidden text password. 		
password	Enter a character string up to 8 characters long as a password. If you do not enter an encryption-type, the password is stored as clear text.		

Defaults

Not configured.

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

The password is displayed in the show config output if the encryption-type is unencrypted or clear text. If you choose to encrypt the password, the show config displays an encrypted text string.

clear counters vrrp

CES Clear the counters maintained on VRRP operations.

Syntax clear counters vrrp [vrrp-id]

Parameters

(OPTIONAL) Enter the number of the VRRP group ID. vrrp-id Range: 1 to 255

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

debug vrrp

Allows you to enable debugging of VRRP.

Syntax

debug vrrp interface [vrrp-id] {all | packets | state | timer}

To disable debugging, use the **no debug vrrp** interface [vrrp-id] {all | packets | state | timer} command.

Parameters

:	4-	£	
ın	tΩ	rta	റമ

Enter the following keywords and slot/port or number information:

- For a 1-Gigabit Ethernet interface, enter the keyword **GigabitEthernet** followed by the slot/port information.
- For Port Channel interface types, enter the keyword port-channel followed by the number:

C-Series and S-Series Range: 1-128

E-Series Range: 1 to 255 for TeraScale

- For a 10-Gigabit Ethernet interface, enter the keyword **TenGigabitEthernet** followed by the slot/port information.
- For a VLAN interface, enter the keyword vlan followed by the VLAN ID. The VLAN ID range is from 1 to 4094.

vrrp-id	(OPTIONAL) Enter a number from 1 to 255 as the VRRP group ID.
all	Enter the keyword all to enable debugging of all VRRP groups.
bfd	Enter the keyword bfd to enable debugging of all VFFP BFD interactions
packets	Enter the keyword packets to enable debugging of VRRP control packets.
state	Enter the keyword state to enable debugging of VRRP state changes.
timer	Enter the keyword timer to enable debugging of the VRRP timer.

Command Modes

EXEC Privilege

Command History

Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

If no options are specified, debug is active on all interfaces and all VRRP groups.

description

CES

Configure a short text string describing the VRRP group.

Syntax description text

To delete a VRRP group description, enter **no description**.

Parameters

text Enter a text string up to 80 characters long.

Defaults

Not enabled.

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

disable

CES

Disable a VRRP group.

Syntax

disable

To re-enable a disabled VRRP group, enter **no disable**.

Defaults

C and S-Series default: VRRP is enabled.

E-Series default: VRRP is disabled.

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information To enable VRRP traffic, assign an IP address to the VRRP group using the virtual-address command and enter **no disable**.

Related Commands

virtual-address Specify the IP address of the Virtual Router.

hold-time

CES

Specify a delay (in seconds) before a switch becomes the MASTER virtual router. By delaying the initialization of the VRRP MASTER, the new switch can stabilize its routing tables.

Syntax

hold-time seconds

To return to the default value, enter **no hold-time**.

Parameters

seconds	Enter a number of seconds.
	Range: 0 to 65535.
	Default: zero (0) seconds.

Defaults

zero (0) seconds

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

If a switch is a MASTER and you change the hold timer, you must disable and re-enable VRRP for the new hold timer value to take effect.

Related Commands

disable	Disable a VRRP group.
---------	-----------------------

preempt

CES

Permit a BACKUP router with a higher priority value to preempt or become the MASTER router.

Syntax

To prohibit preemption, enter **no preempt**.

Defaults

Enabled (that is, a BACKUP router can preempt the MASTER router).

Command Modes

VRRP

preempt

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

priority

CES

Specify a VRRP priority value for the VRRP group. This value is used by the VRRP protocol during the MASTER election process.

Syntax

priority priority

To return to the default value, enter **no priority**.

Parameters

priority	Enter a number as the priority. Enter 255 only if the router's virtual address is the same as the interface's primary IP address (that is, the router is the OWNER).
	Range: 1 to 255. Default: 100.

Defaults

100

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

To guarantee that a VRRP group becomes MASTER, configure the VRRP group's virtual address with same IP address as the interface's primary IP address and change the priority of the VRRP group to 255.

If you set the priority to 255 and the virtual-address is not equal to the interface's primary IP address, an error message appears.

show config

CES

View the non-default VRRP configuration.

Syntax

show config [verbose]

Parameters

verbose	(OPTIONAL) Enter the keyword verbose to view all VRRP group configuration information, including defaults.

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example Figure 46-1. Command Example: show config

```
FTOS(conf-if-vrid-4) #show con
vrrp-group 4
 virtual-address 119.192.182.124
```

show vrrp

View the VRRP groups that are active. If no VRRP groups are active, the FTOS returns No Active VRRP group."

Syntax show vrrp [vrrp-id] [interface] [brief]

Parameters

vrrp-id	(OPTIONAL) Enter the Virtual Router Identifier for the VRRP group to view only that
	group.
	Range: 1 to 255.
interface	(OPTIONAL) Enter the following keywords and slot/port or number information:
	• For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
	 For Port Channel interface types, enter the keyword port-channel followed by the number:
	C-Series and S-Series Range: 1-128
	E-Series Range: 1 to 255 for TeraScale
	 For SONET interfaces, enter the keyword sonet followed by the slot/port information.
	 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
	 For a VLAN interface, enter the keyword vlan followed by the VLAN ID. The VLAN ID range is from 1 to 4094.
brief	(OPTIONAL) Enter the keyword brief to view a table of information on the VRRP groups on the E-Series.

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Example Figure 46-2. show vrrp brief Command Example

```
FTOS>Interface Grp Pri Pre State Master addr
                     Virtual addr(s)
FTOS>
```

Table 46-1. Command Example Descriptions: show vrrp brief

Item	Description
Interface	Lists the interface type, slot and port on which the VRRP group is configured.
Grp	Displays the VRRP group ID.
Pri	Displays the priority value assigned to the interface. If the track command is configured to track that interface and the interface is disabled, the <i>cost</i> is subtracted from the priority value assigned to the interface.
Pre	States whether preempt is enabled on the interface. • Y = Preempt is enabled. • N = Preempt is not enabled.
State	Displays the operational state of the interface by using one of the following: NA/IF (the interface is not available). MASTER (the interface associated with the MASTER router). BACKUP (the interface associated with the BACKUP router).
Master addr	Displays the IP address of the MASTER router.
Virtual addr(s)	Displays the virtual IP addresses of the VRRP routers associated with the interface.

Figure 46-3. Command Example: show vrrp

```
FTOS>show vrrp
GigabitEthernet 12/3, VRID: 1, Net: 10.1.1.253
State: Master, Priority: 105, Master: 10.1.1.253 (local)
Hold Down: 0 sec, Preempt: TRUE, AdvInt: 1 sec
Adv rcvd: 0, Adv sent: 1862, Gratuitous ARP sent: 0
Virtual MAC address:
 00:00:5e:00:01:01
Virtual IP address:
 10.1.1.252
Authentication: (none)
Tracking states for 1 interfaces:
 Up GigabitEthernet 12/17 priority-cost 10
\label{eq:GigabitEthernet 12/4, VRID: 2, Net: 10.1.2.253} \\ State: Master, Priority: 110, Master: 10.1.2.253 \; (local)
Hold Down: 10 sec, Preempt: TRUE, AdvInt: 1 sec
Adv rcvd: 0, Adv sent: 1862, Gratuitous ARP sent: 0 Virtual MAC address:
 00:00:5e:00:01:02
Virtual IP address:
 10.1.2.252
Authentication: (none)
Tracking states for 2 interfaces:
 Up GigabitEthernet 2/1 priority-cost 10
 Up GigabitEthernet 12/17 priority-cost 10
FTOS>
```

Table 46-2. Command Example Description: show vrrp

Line Beginning with	Description
GigabitEthernet 12/3	Displays the Interface, the VRRP group ID, and the network address. If the interface is no sending VRRP packets, 0.0.0 appears as the network address.
State: master	Displays the interface's state: • Na/If (not available), • master (MASTER virtual router) • backup (BACKUP virtual router) the interface's priority and the IP address of the MASTER.
Hold Down:	 This line displays additional VRRP configuration information: Hold Down displays the hold down timer interval in seconds. Preempt displays TRUE if preempt is configured and FALSE if preempt is not configured. AdvInt displays the Advertise Interval in seconds.
Adv revd:	 This line displays counters for the following: Adv rcvd displays the number of VRRP advertisements received on the interface. Adv sent displays the number of VRRP advertisements sent on the interface. Gratuitous ARP sent displays the number of gratuitous ARPs sent.
Virtual MAC address	Displays the virtual MAC address of the VRRP group.
Virtual IP address	Displays the virtual IP address of the VRRP router to which the interface is connected.
Authentication:	States whether authentication is configured for the VRRP group. If it is, the authentication type and the password are listed.
Tracking states	This line is displayed if the track command is configured on an interface. Below this line, the following information on the tracked interface is displayed: • Dn or Up states whether the interface is down or up. • the interface type slot/port information

track



Monitor an interface and lower the priority value of the VRRP group on that interface if it is disabled.

Syntax

track interface [priority-cost cost]

To disable monitoring, use the **no track** *interface* command.

Parameters	interface	Enter the following keywords and slot/port or number information:
	interrace	 For a 1-Gigabit Ethernet interface, enter the keyword GigabitEthernet followed by the slot/port information.
		 For a Loopback interface, enter the keyword loopback followed by a number from 0 to 16383.
		 For Port Channel interface types, enter the keyword port-channel followed by the number:
		C-Series and S-Series Range: 1-128
		E-Series Range: 1 to 255 for TeraScale
		 For SONET interfaces, enter the keyword sonet followed by the slot/port information.
		 For a 10-Gigabit Ethernet interface, enter the keyword TenGigabitEthernet followed by the slot/port information.
		• For a VLAN interface, enter the keyword vlan followed by a number from 1 to 4094.
	cost	(OPTIONAL) Enter a number as the amount to be subtracted from the priority value.
		Range: 1 to 254.
		Default: 10.

Defaults

cost = 10

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

If the interface is disabled, the cost value is subtracted from the priority value and forces a new MASTER election if the priority value is lower than the priority value in the BACKUP virtual routers.

virtual-address

CES

Configure up to 12 IP addresses of virtual routers in the VRRP group. You must set at least one virtual address for the VRRP group to start sending VRRP packets.

Syntax

virtual-address ip-address1 [... ip-address12]

To delete one or more virtual IP addresses, use the **no virtual-address** *ip-address1* [... *ip-address12*] command.

Parameters

ip-addre	ess1	Enter an IP address of the virtual router in dotted decimal format.
		The IP address must be on the same subnet as the interface's primary IP address.
ip-add	dress12	(OPTIONAL) Enter up 11 additional IP addresses of virtual routers in dotted decimal format. Separate the IP addresses with a space.
		The IP addresses must be on the same subnet as the interface's primary IP address.

Defaults

Not configured.

Command Modes

VRRP

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
Version 7.4.1.0	Introduced support for telnetting to the VRRP group IP address assigned using this command
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

The VRRP group only becomes active and sends VRRP packets when a virtual IP address is configured. When you delete the virtual address, the VRRP group stops sending VRRP packets.

A system message appears after you enter or delete the virtual-address command.

To guarantee that a VRRP group becomes MASTER, configure the VRRP group's virtual address with the same IP address as the interface's primary IP address and change the priority of the VRRP group to 255.

You can ping the virtual addresses configured in all VRRP groups.

vrrp-group

Assign a VRRP ID to an interface. You can configure up to 12 VRRP groups per interface.

Syntax vrrp-group vrrp-id

Parameters

vrrp-id	Enter a number as the group ID.
	Range: 1 to 255.

Defaults

Not configured.

Command Modes

INTERFACE

Command History

Version 8.3.3.1	Introduced on S60
Version 7.6.1.0	Introduced on S-Series
Version 7.5.1.0	Introduced on C-Series
pre-Version 6.2.1.1	Introduced on E-Series

Usage Information

The VRRP group only becomes active and sends VRRP packets when a virtual IP address is configured. When you delete the virtual address, the VRRP group stops sending VRRP packets.

Related Commands

|--|

S-Series Debugging and Diagnostics

This chapter contains three sections:

- **Diagnostics and Monitoring Commands**
- Offline Diagnostic Commands
- **Buffer Tuning Commands**
- **Hardware Commands**

Diagnostics and Monitoring Commands

For similar commands, see also Chapter 4, Control and Monitoring.

logging coredump server

Enable the S-Series to send application core dumps to an FTP server.

Syntax logging coredump server server username username password [type] password

> To disable core dump logging, use the no logging coredump server server username username password password

Parameters

server	Enter the hostname or IP address of the FTP server where FTOS sends application core dumps.
username	Enter the username to access the FTP server.
type	Enter the password type. Enter 0 to specify that an unencrypted password will follow, or 7 to specify that a Type 7 encrypted password will follow.
password	Enter the password to access the FTP server.

Defaults Disabled

Command Modes CONFIGURATION

Command History

Version 8.3.3.1	Introduced on S60
Version 7.7.1.0	Introduced on S-Series

Usage Information

You must use this command to enable core dump logging before a software exception occurs. If the FTP server is unreachable, FTOS aborts the application core dump.

Offline Diagnostic Commands

The offline diagnostics test suite is useful for isolating faults and debugging hardware. While tests are running, FTOS results are saved as a text file (TestReport-SU-X.txt) in the flash directory. This show file command is available only on master and standby.

Important Points to Remember

- Offline diagnostics can only be run when the unit is offline.
- You can only run offline diagnostics on a unit to which you are connected via console.
 In other words, you cannot run diagnostics on a unit to which you are connected via a stacking link.
- Diagnostic results are printed to the screen. FTOS does not write them to memory.
- Diagnostics only test connectivity, not the entire data path.

The offline diagnostics commands are:

- diag stack-unit
- offline stack-unit
- online stack-unit

diag stack-unit

S Run offline diagnostics on a stack unit.

Syntax diag stack-unit number [alllevels | level0 | level1 | level2]

Parameters

number	Enter the stack-unit number.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
alllevels	Enter the keyword alllevels to run the complete set of offline diagnostic tests.
level0	Enter the keyword level0 to run Level 0 diagnostics. Level 0 diagnostics check for the presence of various components and perform essential path verifications. In addition, they verify the identification registers of the components on the board.
level1	Enter the keyword Level1 to run Level 1 diagnostics. Level 1 diagnostics is a smaller set of diagnostic tests with support for automatic partitioning. They perform status/self test for all the components on the board and test their registers for appropriate values. In addition, they perform extensive tests on memory devices (e.g., SDRAM, flash, NVRAM, EEPROM, and CPLD) wherever possible. There are no tests on 10G links. At this level, stack ports are shut down automatically.
level2	Enter the keyword level2 to run Level 2 diagnostics. Level 2 diagnostics is a full set of diagnostic tests with no support for automatic partitioning. Level 2 diagnostics are used primarily for on-board loopback tests and more extensive component diagnostics. Various components on the board are put into loop back mode, and test packets are transmitted through those components. These diagnostics also perform snake tests using VLAN configurations. You must physically remove the unit from the stack to test 10G links.

Defaults

None

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.7.1.0	Introduced on S-Series	

offline stack-unit

Place a stack unit in the offline state.

Syntax offline stack-unit number

Parameters

number	Enter the stack unit number.	
	Unit ID range:	
	S60 : 0-11	
	all other S-Series: 0-7	

Defaults

Command Mode EXEC Privilege

None

Command **History**

Version 8.3.3.1	Introduced on the S60.	
Version 8.2.1.0	Added warning message to off-line diagnostic	
Version 7.7.1.0	Introduced on S-Series	

Related Commands

show environment (S-Series) View S-Series system component status (for example, temperature, voltage).

Usage Information

You cannot enter this command on a Master or Standby unit.

The system reboots when the off-line diagnostics complete. This is an automatic process. A warning message appears when the offline stack-unit command is implemented.

Warning - Diagnostic execution will cause stack-unit to reboot after completion of diags.

Proceed with Offline-Diags [confirm yes/no]:y

online stack-unit

Place a stack unit in the online state.

Syntax online stack-unit number

Parameters

number	Enter the stack unit number.	_
	Unit ID range:	
	S60 : 0-11	
	all other S-Series: 0-7	

Defaults None

Command Mode

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.7.1.0	Introduced on S-Series
show environment (S-Series)	View S-Series system component status (for example, temperature, voltage).

Related Commands

w environment (S-Series) View S-Series system component status (for example, temperature, voltage).

Buffer Tuning Commands

The buffer tuning commands are:

- buffer (Buffer Profile)
- buffer (Configuration)
- buffer-profile (Configuration)
- buffer-profile (Interface)
- show buffer-profile
- show buffer-profile interface



Warning: Altering the buffer allocations is a sensitive operation. Do not use any buffer tuning commands without first contacting the Dell Networking Technical Assistance Center.

buffer (Buffer Profile)



Allocate an amount of dedicated buffer space, dynamic buffer space, or packet pointers to queues 0 to 3.

Syntax

buffer [dedicated | dynamic | packets-pointers] queue0 *number* queue1 *number* queue2 *number* queue3 *number*

Parameters

dedicated	Enter this keyword to configure the amount of dedicated buffer space per queue.
dynamic	Enter this keyword to configure the amount of dynamic buffer space per Field Processor.
packets-pointers	Enter this keyword to configure the number of packet pointers per queue.
queue0 number	Enter this keyword to allocate an amount of buffer space or packet pointers to Queue 0.
	Dedicated Buffer Range: 0-2013
	Dynamic Buffer Range:
	FP: 0-2013
	CSF: 0-131200 (in multiples of 80)
	Packet Pointer Range: 0-2047

queue1 number	Enter this keyword to allocate an amount of buffer space or packet pointers to Queue 1.
	Dedicated Buffer Range: 0-2013
	Dynamic Buffer Range:
	FP: 0-2013
	CSF: 0-131200 (in multiples of 80)
	Packet Pointer Range: 0-2047
queue2 number	Enter this keyword to allocate an amount of buffer space or packet pointers to Queue 2.
	Dedicated Buffer Range: 0-2013
	Dynamic Buffer Range:
	FP: 0-2013
	CSF: 0-131200 (in multiples of 80)
	Packet Pointer Range: 0-2047
queue3 number	Enter this keyword to allocate an amount of buffer space or packet pointers to Queue 3.
	Dedicated Buffer Range: 0-2013
	Dynamic Buffer Range:
	FP: 0-2013
	CSF: 0-131200 (in multiples of 80)
	Packet Pointer Range: 0-2047
	·

Defaults

None

Command Mode

BUFFER PROFILE

Command **History**

Version 7.7.1.0	Introduced on S-Series	
Version 7.6.1.0	Introduced on C-Series	

Related Commands

buffer-profile (Configuration) Create a buffer profile that can be applied to an interface.

buffer (Configuration)

Apply a buffer profile to all Field or Switch Fabric processors in a port-pipe.

buffer [csf | fp-uplink] linecard slot port-set port-pipe buffer-policy buffer-profile

Parameters

csf	Enter this keyword to apply a buffer profile to all Switch Fabric processors in a port-pipe.
fp-uplink	Enter this keyword to apply a buffer profile to all Field Processors in a a port-pipe.
linecard slot	Enter the keyword linecard followed by the line card slot number.
port-set port-pipe	Enter the keyword port-set followed by the port-pipe number. Range: 0-3 on C-Series, 0-1 on S-Series
buffer-policy buffer-profile	Enter the keyword buffer-policy followed by the name of a buffer profile you created.

None

Command Mode R

BUFFER PROFILE

Usage Information

If you attempt to apply a buffer profile to a non-existent port-pipe, FTOS displays the following message. However, the configuration still appears in the running-config.

%DIFFSERV-2-DSA_BUFF_CARVING_INVALID_PORT_SET: Invalid FP port-set 2 for linecard 2. Valid range of port-set is <0-1>

Usage Information

When you remove a buffer-profile using the command **no buffer-profile** [fp | csf] from CONFIGURATION mode, the buffer-profile name still appears in the output of **show buffer-profile** [detail | summary]. After a line card reset, the buffer profile correctly returns to the default values, but the profile name remains. Remove it from the show buffer-profile [detail | summary] command output by entering **no buffer** [fp-uplink | csf] linecard port-set buffer-policy from CONFIGURATION mode and **no buffer-policy** from INTERFACE mode.

Command History

Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
1	

Related Commands

buffer-profile (Configuration) Create a buffer profile that can be applied to an interface.

buffer-profile (Configuration)

C S Create a buffer profile that can be applied to an interface.

Syntax

buffer-profile {{fp | csf} profile-name | global {1Q|4Q}

Parameters

fp	Enter this keyword to create a buffer profile for the Field Processor.	
csf	Enter this keyword to create a buffer profile for the Switch Fabric Processor.	
profile-name	Create a name for the buffer profile.	
global	Apply one of two pre-defined buffer profiles to all of the port-pipes in the system.	
1Q	Enter this keyword to choose a pre-defined buffer profile for single queue (i.e non-QoS) applications.	
4Q	Enter this keyword to choose a pre-defined buffer profile for four queue (i.e QoS) applications.	

Defaults

global 4Q

Command Mode

CONFIGURATION

Command History

H	
Version 7.8.1.0	Added global keyword.
Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series
buffer (Buffer Profile)	Allocate an amount of dedicated buffer space, dynamic buffer space, or packet pointers to gueues 0 to 3.

Related Commands

Usage Information

The buffer-profile global command fails if you have already applied a custom buffer-profile on an interface. Similarly, when buffer-profile global is configured, you cannot not apply buffer-profile on any interface.

If the default buffer-profile (4Q) is active, FTOS displays an error message instructing you to remove the default configuration using the command no **buffer-profile global**.

You must reload the system for the global buffer-profile to take effect.

buffer-profile (Interface)

Apply a buffer profile to an interface.

Syntax buffer-profile profile-name

profile-name Enter the name of the buffer profile you want to apply to the interface.

Defaults None

Command Mode INTERFACE

> Command **History**

Parameters

Version 7.7.1.0 Introduced on S-Series Version 7.6.1.0 Introduced on C-Series

Related Commands

buffer-profile (Configuration) Create a buffer profile that can be applied to an interface.

show buffer-profile

Display the buffer profile that is applied to an interface.

Syntax show buffer-profile {detail | summary} {csf | fp-uplink}

Parameters

detail	Display the buffer allocations of the applied buffer profiles.
summary	Display the buffer-profiles that are applied to line card port-pipes in the system.
csf	Display the Switch Fabric Processor buffer profiles that you have applied to line card port-pipes in the system.
fp-uplink	Display the Field Processor buffer profiles that you have applied to line card port-pipes in the system.

Defaults None

Command Mode INTERFACE

Command History

Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series

Example Figure 47-1. show buffer-profile Command Example

FTOS#

FTOS#show buffer-profile summary fp-uplink
Linecard Port-set Buffer-profile
0 0 test1
4 0 test2

Related Commands

buffer-profile (Configuration) Create a buffer profile that can be applied to an interface.

show buffer-profile interface

Display the buffer profile that is applied to an interface.

Syntax show buffer-profile {detail | summary} interface interface slot/port

Parameters

detail	Display the buffer allocations of a buffer profile.
summary	Display the Field Processors and Switch Fabric Processors that are applied to line card port-pipes in the system.
interface interface	Enter the keyword interface followed by the interface type, either gigabitethernet or tengigabitethernet .
slot/port	Enter the slot and port number of the interface.

Defaults None

Command Mode INTERFACE

Command History

Version 7.7.1.0	Introduced on S-Series
Version 7.6.1.0	Introduced on C-Series

Example

Figure 47-2. show buffer-profile interface Command Example

FTOS#show buffer-profile detail csf linecard 4 port-set 0 Linecard 4 Port-set 0 Buffer-profile test Dedicated Buffer Buffer Packets Oueue# (Bytes) 718 36960 18560 358 358 2 3 4 18560 18560 358 9600 64 5 9600 64 9600 64 9600 63 FTOS#

Related Commands

buffer-profile (Configuration) Create a buffer profile that can be applied to an interface.

Hardware Commands

These commands display information from a hardware sub-component or ASIC.

The commands are:

- clear hardware system-flow
- clear hardware system-flow
- hardware watchdog
- show hardware layer2 acl
- show hardware layer3
- show hardware stack-unit
- show hardware stack-unit buffering-unit
- show hardware system-flow

clear hardware stack-unit

Clear statistics from selected hardware components.

Syntax

clear hardware stack-unit id {counters | unit 0-1 counters | cpu data-plane statistics | cpu party-bus statistics | stack-port 0-52}

Parameters

stack-unit id	Enter the keyword stack-unit to select a particular stack member and then enter one of the following command options to clear a specific collection of data. Unit ID range: S60 : 0-11
	all other S-Series: 0-7
counters	Enter the keyword counters to clear the counters on the selected stack member.
unit 0-1 counters	Enter the keyword unit along with a port-pipe number, from <i>0</i> to <i>1</i> , followed by the keyword counters to clear the counters on the selected port-pipe.
	Note: S25 models (S25N, S25P, S25V, etc.) have only port-pipe 0.
cpu data-plane statistics	Enter the keywords cpu data-plane statistics to clear the data plane statistics.
cpu party-bus statistics	Enter the keywords cpu party-bus statistics to clear the management statistics.
stack-port 0-52	Enter the keyword stack-port followed by the port number of the stacking port to clear the statistics of the particular stacking port.
	Range: 0 to 52
	Note : You can identify stack port numbers by physical inspection of the rear modules. The numbering is the same as for the 10G ports. You can also inspect the output of the show system stack-ports command.

Defaults

No default behavior or values

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
show hardware stack-unit	Display the data plane or management plane input and output statistics of the designated component of the designated stack member.

Related Commands

clear hardware system-flow

S Clear system-flow statistics from selected hardware components.

Syntax clear hardware system-flow layer2 stack-unit id port-set 0-1 counters

Parameters

stack-unit id	Enter the keyword stack-unit to select a particular stack member and then enter one of the following command options to clear a specific collection of data. Unit ID range: S60 : 0-11 all other S-Series : 0-7
port-set 0-1 counters	Enter the keyword port-set along with a port-pipe number, from <i>0</i> to <i>1</i> , followed by the keyword counters to clear the system-flow counters on the selected port-pipe. Note : S25 models (S25N, S25P, S25V, etc.) have only port-pipe 0.

Defaults No default behavior or values

Command Modes EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series
show hardware stack-unit	Display the data plane or management plane input and output statistics of the designated component of the designated stack member.

Related Commands

hardware watchdog

Set the watchdog timer to trigger a reboot and restart the system.

Syntax hardware watchdog

Defaults Enabled

Command Mode CONFIGURATION

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced

Usage Information

This command enables a hardware watchdog mechanism that automatically reboots an FTOS switch/ router with a single unresponsive unit. This is a last resort mechanism intended to prevent a manual power cycle.

show hardware layer2 acl

Display Layer 2 ACL data for the selected stack member and stack member port-pipe.

Syntax show hardware layer2 acl stack-unit id port-set 0-1

Parameters

stack-unit id	Enter the keyword stack-unit to select a stack ID.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
port-set 0-1	Enter the keyword port-set with a port-pipe number — 0 or 1. The S25 models of the S-Series have only port-pipe 0.

Defaults No default behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.	
Version 7.8.1.0	Introduced on S-Series	

show hardware layer3

Display Layer 3 ACL or QoS data for the selected stack member and stack member port-pipe.

Syntax show hardware layer3 {acl | qos} stack-unit id port-set 0-1

Parameters

acl ∣ qos	Enter either the keyword acl or the keyword qos to select between ACL or QoS data.
stack-unit id	Enter the keyword stack-unit to select a stack ID.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
port-set 0-1	Enter the keyword port-set with a port-pipe number — 0 or 1. The S25 models of the S-Series have only port-pipe 0.

Defaults No default behavior

Command Modes EXEC Privilege

Command History

ion 8.3.3.1 Introduced on the S60.
ion 7.8.1.0 Introduced on S-Series

show hardware stack-unit



Display the data plane or management plane input and output statistics of the designated component of the designated stack member.

Syntax

show hardware stack-unit stack-unit {cpu data-plane statistics [stack-port 0-52] | cpu party-bus statistics | drops [unit number [port 0-27]] | stack-port 0-52 | ti-monitor | unit 0-1 {counters | details | port-stats [detail] | register}}

Parameters

stack-unit stack-unit {command-option}	Enter the keyword stack-unit to select a particular stack member and then enter one of the following command options to display a collection of data based on the option entered. Unit ID range: S60 range : 0 - 11 all other S-Series range : 0-7
cpu data-plane statistics	Enter the keywords cpu data-plane statistics , optionally followed by the keywords stack port and its number — 0 to 52 — to display the data plane statistics, which shows the Higig port raw input/output counter statistics to which the stacking module is connected.
cpu party-bus statistics	Enter the keywords cpu party-bus statistics , to display the Management plane input/output counter statistics of the pseudo party bus interface.
drops [unit <i>0-1</i> [port <i>0-27</i>]]	Enter the drops keyword to display internal drops on the selected stack member. Optionally, use the unit keyword with 0 or 1 to select port-pipe 0 or 1, and then use port <i>0-27</i> to select a port on that port-pipe.
stack-port 0-52	Enter this keyword and a stacking port number to select a stacking port for which to display statistics. Identify the stack port number as you would to identify a 10G port that was in the same place in one of the rear modules.
	Note: You can identify stack port numbers by physical inspection of the rear modules. The numbering is the same as for the 10G ports. You can also inspect the output of the show system stack-ports command.
unit 0-1 {counters details port-stats [detail] register}	Enter the unit keyword followed by 0 or 1 for port-pipe 0 or 1, and then enter one of the following keywords to troubleshoot errors on the selected port-pipe and to give status on why a port is not coming up to register level: counters , details , port-stats [detail], or register
TI monitor	Enter the unit keyword to show information regarding the TI register. S60 only

Defaults

No default behavior

Command Modes

EXEC

EXEC Privilege

Command History

Version 8.3.3.4	Added ti-monitor information for the S60.
Version 8.3.3.1	Introduced on the S60.

Version 7.8.1.0	Modified: stack-port keyword range expanded from 49-52 to 0-52; output modified for the cpu data-plane statistics option; the following options were added: drops [unit 0-1 [port 0-27]]; unit 0-1 {counters details port-stats [detail] register}
Version 7.7.1.0	Introduced on S-Series

Example 1 Figure 47-3. show hardware stack-unit cpu data-plane statistics Command Example

```
FTOS#show hardware stack-unit 0 cpu data-plane statistics stack-port 49
Input Statistics:
      1856 packets, 338262 bytes
      141 64-byte pkts, 1248 over 64-byte pkts, 11 over 127-byte pkts
      222 over 255-byte pkts, 236 over 511-byte pkts, 0 over 1023-byte pkts
     919 Multicasts, 430 Broadcasts
      0 runts, 0 giants, 0 throttles
     0 CRC, 0 overrun, 0 discarded
Output Statistics:
     325 packets, 27629 bytes, 0 underruns
9 64-byte pkts, 310 over 64-byte pkts, 1 over 127-byte pkts
1 over 255-byte pkts, 2 over 511-byte pkts, 2 over 1023-byte pkts
      0 Multicasts, 3 Broadcasts, 322 Unicasts
      0 throttles, 0 discarded, 0 collisions
Rate info (interval 299 seconds):
     Input 00.00 Mbits/sec
      Output 00.00 Mbits/sec
FTOS#
```

Example 2 Figure 47-4. show hardware stack-unit cpu party-bus statistics Command Example

```
FTOS#show hardware stack-unit 0 cpu party-bus statistics
Input Statistics:
   8189 packets, 8076608 bytes
   0 dropped, 0 errors
Output Statistics:
   366 packets, 133100 bytes
   0 errors
FTOS#
```

Example 3 Figure 47-5. show hardware stack-unit drops Command Example

```
FTOS#show hardware stack-unit 0 drops unit 1 port 27
 --- Ingress Drops
Ingress Drops
IBP CBP Full Drops
PortSTPnotFwd Drops
IPv4 L3 Discards
Policy Discards
                            : 0
Packets dropped by FP
(L2+L3) Drops
Port bitmap zero Drops
Rx VLAN Drops
 --- Ingress MAC counters---
Ingress FCSDrops
Ingress MTUExceeds
                            : 0
 --- MMU Drops
HOL DROPS
                             : 0
                             : 0
TxPurge CellErr
                             : 0
Aged Drops
 --- Egress MAC counters---
Egress FCS Drops
                             . 0
 --- Egress FORWARD PROCESSOR Drops
IPv4 L3UC Aged & Drops : 0
TTL Threshold Drops
                            : 0
                          : 0
INVALID VLAN CNTR Drops
L2MC Drops
                             : 0
PKT Drops of ANY Conditions : 0
Hg MacUnderflow
                            : 0
Hg MacUnderflow : 0
TX Err PKT Counter : 0 25
FTOS#
```

Example 4 Figure 47-6. show hardware stack-unit port-stats Command Example

FTOS#	show h ena/	ardware speed/		unit 0 auto	unit 0 p	ort-sta	ts	lrn	inter	max	loop	
port	link	duplex		neq?	state	pause	discrd	ops		frame	back	
ge0	down	dupiex	SW	Yes	Block	pause	Untag	FA	SGMII	1554	Dack	
ge0 ge1	!ena		SW	Yes	Block		Tag	FA	SGMII	1554		
ge1 ge2	!ena	_	SW	Yes	Block		Tag	FA	SGMII	1554		
gez ge3	!ena	_	SW	Yes	Block		Tag	FA	SGMII	1554		
ge3 ge4	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge 1 ge5	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ges ge6	!ena	_	SW	Yes	Forward		Tag	F	SGMII			
geo ge7	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge7 ge8	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
geo ge9	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge10	!ena	_	SW	Yes	Forward		Tag	F	SGMII	9252		
ge10 ge11	!ena	_	SW	Yes	Forward		Tag	F	SGMII	9252		
gell gel2	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge12 ge13	!ena		SW	Yes	Forward		Tag	F	SGMII	1554		
ge13	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge14 ge15	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge15 ge16	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge10 ge17	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge17 ge18	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge10 ge19	!ena		SW	Yes	Forward		Tag	F	SGMII	1554		
ge19 ge20	!ena	_	SW	Yes	Forward		Tag	F	SGMII			
ge20 ge21	!ena	_	SW	Yes	Forward		Tag	F	SGMII			
ge21 ge22	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
ge22 ge23	!ena	_	SW	Yes	Forward		Tag	F	SGMII	1554		
hq0	up	12G FD	SW	No	Forward		None	F	XGMII			
hg1	up	12G FD	SW	No	Forward		None	F	XGMII			
	down	10G FD	SW	No	Forward		None	F	XGMII			
hg2	down	10G FD 10G FD	SW SW	NO No	Forward			r F	XGMII			
hg3	down 0	TOG FD	DW	INO	rorward		None	г	VGIAITT	T0200		
FTOS#	U											
r 105#												

Example 5 Figure 47-7. show hardware stack-unit unit 1 register Command Example

```
FTOS#show hardware stack-unit 0 unit 1 register
0x0068003c AGINGCTRMEMDEBUG.mmu0 = 0x00000000
0 \times 0068003 d AGINGEXPMEMDEBUG.mmu0 = 0 \times 000000000
0 \times 00680017 ASFCONFIG.mmu0 = 0 \times 000000000
0x0060004c ASFPORTSPEED.ge0 = 0x00000000
0x0060104c ASFPORTSPEED.ge1 = 0x00000000
0x0060204c ASFPORTSPEED.ge2 = 0x00000000
0x0060304c ASFPORTSPEED.ge3 = 0x00000000
0x0060404c ASFPORTSPEED.ge4 = 0x00000000
0x0060504c ASFPORTSPEED.ge5 = 0x00000000
0x0060604c ASFPORTSPEED.ge6 = 0x00000000
0x0060704c ASFPORTSPEED.ge7 = 0x00000000
0x0060804c ASFPORTSPEED.ge8 = 0x00000000
0x0060904c ASFPORTSPEED.ge9 = 0x00000000
0x0060a04c ASFPORTSPEED.ge10 = 0x00000000
0x0060b04c ASFPORTSPEED.ge11 = 0x00000000
0x0060c04c ASFPORTSPEED.ge12 = 0x00000000
0x0060d04c ASFPORTSPEED.ge13 = 0x00000000
0x0060e04c ASFPORTSPEED.ge14 = 0x00000000
0x0060f04c ASFPORTSPEED.ge15 = 0x00000000
0x0061004c ASFPORTSPEED.ge16 = 0x00000000
0x0061104c ASFPORTSPEED.ge17 = 0x00000000
0x0061204c ASFPORTSPEED.ge18 = 0x00000000
0x0061304c ASFPORTSPEED.ge19 = 0x00000000
0x0061404c ASFPORTSPEED.ge20 = 0x00000000
0x0061504c ASFPORTSPEED.ge21 = 0x00000000
0x0061604c ASFPORTSPEED.ge22 = 0x00000000
0x0061704c \text{ ASFPORTSPEED.ge23} = 0x00000005
0x0061804c ASFPORTSPEED.hq0 = 0x00000007
0x0061904c ASFPORTSPEED.hg1 = 0x00000007
0x0061a04c ASFPORTSPEED.hg2 = 0x00000000
0x0061b04c ASFPORTSPEED.hg3 = 0x00000000
0x0061c04c ASFPORTSPEED.cpu0 = 0x00000000
0x00780000 \text{ AUX ARB CONTROL.ipipe0} = 0x0000001c
0x0e700102 BCAST BLOCK MASK.ge0 = 0x00000000
0x0e701102 BCAST BLOCK MASK.ge1 = 0x00000000
0x0e702102 BCAST_BLOCK_MASK.ge2 = 0x00000000
0x0e703102 BCAST_BLOCK_MASK.ge3 = 0x00000000
0x0e704102 BCAST_BLOCK_MASK.ge4 = 0x00000000

0x0e705102 BCAST_BLOCK_MASK.ge5 = 0x00000000

0x0e706102 BCAST_BLOCK_MASK.ge6 = 0x00000000

0x0e707102 BCAST_BLOCK_MASK.ge7 = 0x00000000
0x0e708102 BCAST_BLOCK_MASK.ge8 = 0x00000000
0x0e709102 BCAST_BLOCK_MASK.ge9 = 0x00000000
0x0e70a102 BCAST_BLOCK_MASK.ge10 = 0x00000000

0x0e70b102 BCAST_BLOCK_MASK.ge11 = 0x00000000

0x0e70c102 BCAST_BLOCK_MASK.ge12 = 0x00000000

0x0e70d102 BCAST_BLOCK_MASK.ge13 = 0x00000000

0x0e70d102 BCAST_BLOCK_MASK.ge14 = 0x00000000

0x0e70e102 BCAST_BLOCK_MASK.ge15 = 0x00000000

0x0e70f102 BCAST_BLOCK_MASK.ge15 = 0x00000000
0x0e710102 BCAST_BLOCK_MASK.ge16 = 0x00000000
0x0e711102 BCAST_BLOCK_MASK.ge17 = 0x00000000
0x0e712102 BCAST_BLOCK_MASK.ge18 = 0x00000000
0x0e713102 BCAST_BLOCK_MASK.ge19 = 0x00000000
0x0e714102 BCAST_BLOCK_MASK.ge20 = 0x00000000
0x0e715102 BCAST BLOCK MASK.ge21 = 0x00000000
0x0e716102 BCAST BLOCK MASK.ge22 = 0x00000000
0x0e717102 BCAST_BLOCK_MASK.ge23 = 0x00000000
0x0e718102 BCAST_BLOCK_MASK.hg0 = 0x00000000
0x0e719102 BCAST_BLOCK_MASK.hg1 = 0x00000000
0x0e71a102 BCAST_BLOCK_MASK.hg2 = 0x00000000
0x0e71b102 BCAST BLOCK MASK.hq3 = 0x00000000
0x0e71c102 BCAST_BLOCK_MASK.cpu0 = 0x00000000
0x0b700001 BCAST_STORM_CONTROL.ge0 = 0x00000000
0x0b701001 BCAST_STORM_CONTROL.ge1 = 0x00000000
0x0b702001 BCAST_STORM_CONTROL.ge2 = 0x00000000
0x0b703001 BCAST_STORM_CONTROL.ge3 = 0x00000000
0x0b704001 BCAST_STORM_CONTROL.ge3 = 0x00000000

0x0b705001 BCAST_STORM_CONTROL.ge4 = 0x00000000

0x0b706001 BCAST_STORM_CONTROL.ge5 = 0x00000000

0x0b706001 BCAST_STORM_CONTROL.ge6 = 0x000000000

0x0b707001 BCAST_STORM_CONTROL.ge7 = 0x000000000
0x0b708001 BCAST_STORM_CONTROL.ge8 = 0x00000000
0x0b709001 BCAST_STORM_CONTROL.ge9 = 0x00000000
0x0b709001 BCAST_STORM_CONTROL.ge9 = 0x00000000
0x0b70a001 BCAST_STORM_CONTROL.ge10 = 0x00000000
     -----!
```

Example 4 Figure 47-8. show hardware stack-unit unit 1 details Command Example

```
.
FTOS#
show hardware stack-unit 0 unit 1 details
The total no of FP & CSF Devices in the Card is 2
The total no of FP Devices in the Card is 2
The total no of CSF Devices in the Card is 0
The number of ports in device 0 is - 24
The number of Hg ports in devices 0 is - 4
The CPU Port of the device is 28
The number of ports in device 1 is - 24
The number of \overline{\text{Hg}} ports in devices 1 is - 4
The CPU Port of the device is 28
The staring unit no the SWF in the device is 0
The Current Link Status Is
Front End Link Status
                            Back Plane Link Status 0x00000000
****************
Link Status of all the ports in the Device - 1
The linkStatus of Front End Port 0 is FALSE
The linkStatus of Front End Port 1 is FALSE
The linkStatus of Front End Port 2 is FALSE
The linkStatus of Front End Port 3 is FALSE
The linkStatus of Front End Port 4 is FALSE
The linkStatus of Front End Port 5 is FALSE
The linkStatus of Front End Port 6 is FALSE
The linkStatus of Front End Port 7 is FALSE
The linkStatus of Front End Port 8 is FALSE
The linkStatus of Front End Port 9 is FALSE
The linkStatus of Front End Port 10 is FALSE
The linkStatus of Front End Port 11 is FALSE
The linkStatus of Front End Port 12 is FALSE
The linkStatus of Front End Port 13 is FALSE
The linkStatus of Front End Port 14 is FALSE
The linkStatus of Front End Port 15 is FALSE
The linkStatus of Front End Port 16 is FALSE
The linkStatus of Front End Port 17 is FALSE
The linkStatus of Front End Port 18 is FALSE
The linkStatus of Front End Port 19 is FALSE
The linkStatus of Front End Port 20 is FALSE
The linkStatus of Front End Port 21 is FALSE
The linkStatus of Front End Port 22 is FALSE
The linkStatus of Front End Port 23 is TRUE
The linkStatus of Hg Port 24 is TRUE
The linkStatus of Hg Port 25 is TRUE
The linkStatus of Hg Port 26 is FALSE
The linkStatus of Hg Port 27 is FALSE
!------ output truncated -----!
```

show hardware stack-unit buffering-unit

[S60]

Display the multicast buffering information for a standalone switch.

Syntax

show hardware stack-unit stack-unit buffering unit { [execute-shell-cmd command name | no-more] [queue-stats multicast cos-queue queue number]

Parameters

stack-unit stack-unit {command-option}	Enter the keyword stack-unit to select a particular stack member and then enter one of the following command options to display a collection of data based on the option entered. Unit ID range: S60 range : 0 - 11
buffering unit	Select the stack member to be the buffering unit. S60 range : 0 - 11
execute-shell-cmd command name	Enter the keyword execute-shell-cmd to execute a shell commands:
no-more	Enter this command to stop collecting the buffer usage information for multicast traffic enabled by the shell command.
queue-stats multicast cos-queue queue number	Enter the keyword queue-stats multicast cos-queue to collect the multicast cos values for each of the 8 virtual queues.

Command Mode

EXEC

EXEC Privilege

Command **History**

Version 8.3.3.8	Introduced on the S60.

Related **Commands**

queue backplane multicast Enable buffering for all multicast traffic on the buffering unit.

show hardware system-flow

Display Layer 3 ACL or QoS data for the selected stack member and stack member port-pipe.

show hardware system-flow layer2 stack-unit idport-set 0-1 [counters]

Parameters

Syntax

acl ∣ qos	For the selected stack member and stack member port-pipe, display which system flow entry the packet hits and what queue the packet takes as it dumps the raw system flow tables.
stack-unit id	Enter the keyword stack-unit to select a stack member ID.
	Unit ID range:
	S60 : 0-11
	all other S-Series: 0-7
port-set 0-1 [counters]	Enter the keyword port-set with a port-pipe number — 0 or 1. The S25 models of the S-Series have only port-pipe 0.
	(OPTIONAL) Enter the keyword counters to display hit counters for the selected ACL or QoS option.

Defaults

No default behavior

Command Modes

EXEC Privilege

Command History

Version 8.3.3.1	Introduced on the S60.
Version 7.8.1.0	Introduced on S-Series

Example 1 Figure 47-9. show hardware system-flow layer2 counters Command Example

EntryId	Description	#HITS
2048	STP BPDU Redirects	0
2047	LLDP BPDU Redirects	0
2045	LACP traffic Redirects	0
2044	GVRP traffic Redirects	0
2043	ARP Reply Redirects	0
2042	802.1x frames Redirects	0
2041	VRRP frames Redirects	0
2040	GRAT ARP	0
2039	DROP Cases	0
2038	OSPF1 STUB	0
2037	OSPF2 STUB	0
2036	VRRP STUB	0
2035	L2 DST HIT+BC MAC+VLAN 4095	0
2034	L2_DST_HIT+BC MAC	0
2033	Catch all	0
384	OSPF[224.0.0.5] Packets	0
383	OSPF[224.0.0.6] Packets	0
382	VRRP Packets	0
380	BCast L2 DST HIT on VLAN 4095	
379	BCAST L2_DST_HIT Packets	0
4	Unknown L2MC Packets	0
3	L2DLF Packets	0
2	L2UCAST Packets	0
1	L2BCASTPackets	0
25		

Example 2 Figure 47-10. show hardware system-flow layer2 (non-counters) Command Example

```
FTOS#show hardware system-flow layer2 stack-unit 0 port-set 0
EID 2048: gid=1,
slice=15, slice_idx=0x00, prio=0x800, flags=0x82, Installed
            tcam: color indep=0,
                                      higig=0, higig mask=0,
           KEY=0x0000000 0000000 0000000 0180c200 0000000 0000000 0000000
, FPF4=0x00
          0x00
       action={act=Drop, param0=0(0x00), param1=0(0x00)},
action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
       meter=NULL.
       counter={idx=0, mode=0x01, entries=1}
############## FP Entry for redirecting LLDP BPDU to RSM ################
EID 2047: gid=1,
       higig=0, higig_mask=0,
           KEY=0x00000000 00000000 00000000 0180c200 000e0000 00000000 00000000
, FPF4=0x00
           0x00
       action=\{act=Drop, param0=0(0x00), param1=0(0x00)\},\
       action=\{act=CosQCpuNew, param0=7(0x07), param1=0(0x00)\},\
       action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)}
       action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
       meter=NULL,
       counter={idx=1, mode=0x01, entries=1}
############ FP Entry for redirecting LACP traffic to CPU Port ###########
EID 2045: gid=1,
       slice=15, slice idx=0x02, prio=0x7fd, flags=0x82, Installed
            tcam: color indep=0,
                                      higig=0, higig mask=0,
           KEY=0x00000000 00000000 00000000 0180c200 00020000 00000000 00000000
, FPF4=0x00
          0x00
       action={act=Drop, param0=0(0x00), param1=0(0x00)},
       action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)},
       action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)}, action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
       meter=NULL.
       counter={idx=2, mode=0x01, entries=1}
############## FP Entry for redirecting GVRP traffic to RSM ###########
EID 2044: gid=1,
       slice=15, slice_idx=0x03, prio=0x7fc, flags=0x82, Installed
            tcam: color indep=0,
                                      higig=0, higig_mask=0,
           \mathtt{KEY} = 0 \times 00000000 \ 000000000 \ 000000000 \ 0180 \\ \mathtt{C200} \ 002\overline{1}0000 \ 00000000 \ 000000000
, FPF4=0x00
          0x00
       action=\{act=Drop, param0=0(0x00), param1=0(0x00)\}
       action={act=CosQCpuNew, param0=7(0x07), param1=0(0x00)}, action={act=CopyToCpu, param0=0(0x00), param1=0(0x00)},
       action={act=UpdateCounter, param0=1(0x01), param1=0(0x00)},
       meter=NULL,
       counter={idx=3, mode=0x01, entries=1}
EID 2043: gid=1
       slice=15, slice_idx=0x04, prio=0x7fb, flags=0x82, Installed
            tcam: color indep=0,
                                      higig=0, higig mask=0,
           , FPF4=0x00
          0x00
       action=\{act=Drop, param0=0(0x00), param1=0(0x00)\},
```



SNMP Traps

This chapter lists the traps sent by FTOS. Each trap is listed by the fields Message ID, Trap Type, and Trap Option, and the next is the message(s) associated with the trap.

Table A-1. SNMP Traps and Error Messages

Message ID	Trap Type	Trap Option
COLD_START	SNMP	COLDSTART
%SNMP-5-SNMP_COLD_START: SNMP COL	.D_START trap sent.	
WARM_START	SNMP	WARMSTART
COPY_CONFIG_COMPLETE	SNMP	NONE
SNMP Copy Config Command Completed		
LINK_DOWN	SNMP	LINKDOWN
%IFA-1-PORT_LINKDN: changed interface state	te to down:%d	
LINK_UP	SNMP	LINKUP
%IFA-1-PORT_LINKUP: changed interface stat	e to up:%d	
AUTHENTICATION_FAIL	SNMP	AUTH
%SNMP-3-SNMP_AUTH_FAIL: SNMP Authe	ntication failed.Request with in	valid community string.
EGP_NEIGHBOR_LOSS	SNMP	NONE
OSTATE_DOWN	SNMP	LINKDOWN
%IFM-1-OSTATE_DN: changed interface state	to down:%s	
%IFM-5-CSTATE_DN:Changed interface Physic	cal state to down: %s	
OSTATE_UP	SNMP	LINKUP
%IFM-1-OSTATE_UP: changed interface state t	•	
%IFM-5-CSTATE_UP: Changed interface Physi	_	
RMON_RISING_THRESHOLD	SNMP	NONE
%RPM0-P:CP %SNMP-4-RMON_RISING_TH		
RMON_FALLING_THRESHOLD	SNMP	NONE
%RPM0-P:CP %SNMP-4-RMON_FALLING_T	HRESHOLD: RMON falling th	
RMON_HC_RISHING_THRESHOLD	SNMP	NONE
	_THRESHOLD: RMON high-o	capacity rising threshold alarm from SNMP OID <oid></oid>
RMON_HC_FALLING_THRESHOLD	SNMP	NONE
%RPM0-P:CP %SNMP-4-RMON_HC_FALLIN	-	n-capacity falling threshold alarm from SNMP OID <oid></oid>
RESV	NONE	NONE
N/A		

Table A-1. SNMP Traps and Error Messages (continued)

Message ID	Trap Type	Trap Option
CHM_CARD_DOWN	ENVMON	NONE
%CHMGR-1-CARD_SHUTDOWN: %sLine	card %d down - %s	
%CHMGR-2-CARD_DOWN: %sLine card %	ód down - %s	
CHM_CARD_UP	ENVMON	NONE
%CHMGR-5-LINECARDUP: %sLine card %	od is up	
CHM_CARD_MISMATCH	ENVMON	NONE
%CHMGR-3-CARD_MISMATCH: Mismatc	h: line card %d is type %s - type %	s required.
CHM_CARD_PROBLEM	ENVMON	NONE
CHM_ALARM_CUTOFF	ENVMON	NONE
CHM_SFM_UP	ENVMON	NONE
CHM_SFM_DOWN	ENVMON	NONE
CHM_RPM_UP	ENVMON	NONE
%RAM-6-RPM_STATE: RPM1 is in Active S	State	,
%RAM-6-RPM_STATE: RPM0 is in Standby	State	
CHM_RPM_DOWN	ENVMON	NONE
%CHMGR-2-RPM_DOWN: RPM 0 down - l		
%CHMGR-2-RPM_DOWN: RPM 0 down - 0	card removed	
CHM_RPM_PRIMARY	ENVMON	NONE
%RAM-5-COLD_FAILOVER: RPM Failove	•	
%RAM-5-HOT_FAILOVER: RPM Failover %RAM-5-FAST_FAILOVER: RPM Failover	•	
CHM_SFM_ADD	ENVMON	NONE
%TSM-5-SFM_DISCOVERY: Found SFM 1	ENVINON	NONE
CHM_SFM_REMOVE	ENVMON	NONE
%TSM-5-SFM_REMOVE: Removed SFM 1	ENVION	NONE
CHM_MAJ_SFM_DOWN	ENVMON	NONE
%CHMGR-0-MAJOR_SFM: Major alarm: S		NONE
CHM_MAJ_SFM_DOWN_CLR	ENVMON	NONE
		NONE
%CHMGR-5-MAJOR_SFM_CLR: Major ala		NONE
CHM_MIN_SFM_DOWN	ENVMON	NONE
%CHMGR-2-MINOR_SFM: MInor alarm: N		NONE
CHM_MIN_SFM_DOWN_CLR	ENVMON	NONE
%CHMGR-5-MINOR_SFM_CLR: Minor ala		_
CHM_PWRSRC_DOWN	ENVMON	SUPPLY
%CHMGR-2-PEM_PRBLM: Major alarm: pr	oblem with power entry module %	ó S

Table A-1. SNMP Traps and Error Messages (continued)

Message ID	Trap Type	Trap Option	
CHM_PWRSRC_CLR	ENVMON	SUPPLY	
%CHMGR-5-PEM_OK: Major alarm cleared: power entry module %s is good			
CHM_MAJ_ALARM_PS	ENVMON	SUPPLY	
%CHMGR-0-MAJOR_PS: Major alarm: insufficient power %s			
CHM_MAJ_ALARM_PS_CLR	ENVMON	SUPPLY	
%CHMGR-5-MAJOR_PS_CLR: major alarm cleared: sufficient power			
CHM_MIN_ALARM_PS	ENVMON	SUPPLY	
%CHMGR-1-MINOR_PS: Minor alarm: power supply non-redundant			
CHM_MIN_ALARM_PS_CLR	ENVMON	SUPPLY	
%CHMGR-5-MINOR_PS_CLR: Minor alarm cleared: power supply redundant			
CHM_MIN_ALRM_TEMP	ENVMON	ТЕМР	
%CHMGR-2-MINOR_TEMP: Minor alarm: chassis temperature			
CHM_MIN_ALRM_TEMP_CLR	ENVMON	ТЕМР	
%CHMRG-5-MINOR_TEMP_CLR: Minor alarm cleared: chassis temperature normal (%s %d temperature is within threshold of %dC)			
CHM_MAJ_ALRM_TEMP	ENVMON	ТЕМР	
%CHMGR-2-MAJOR_TEMP: Major alarm: chassis temperature high (%s temperature reaches or exceeds threshold of %dC)			
CHM_MAJ_ALRM_TEMP_CLR	ENVMON	ТЕМР	
%CHMGR-2-MAJOR_TEMP_CLR: Major alarm cleared: chassis temperature lower (%s %d temperature is within threshold of %dC)			
CHM_FANTRAY_BAD	ENVMON	FAN	
For E1200: %CHMGR-2-FAN_TRAY_BAD: Major alarm: fan tray %d is missing or down %CHMGR-2-ALL_FAN_BAD: Major alarm: all fans in fan tray %d are down. For E600 and E300: %CHMGR-2-FANTRAYBAD: Major alarm: fan tray is missing %CHMGR-2-FANSBAD: Major alarm: most or all fans in fan tray are down			
CHM_FANTRAY_BAD_CLR	ENVMON	FAN	
For the E1200: %CHMGR-5-FAN_TRAY_OK: Major alarm cleared: fan tray %d present For the E600 and E300: %CHMGR-5-FANTRAYOK: Major alarm cleared: fan tray present			
CHM_MIN_FANBAD	ENVMON	FAN	
For the E1200: %CHMGR-2-FAN_BAD: Minor alarm: some fans in fan tray %d are down For the E600 and E300: %CHMGR- 2-1FANBAD: Minor alarm: fan in fan tray is down			
CHM_MIN_FANBAD_CLR	ENVMON	FAN	
For E1200: %CHMGR-2-FAN_OK: Minor alarm c			
For E600 and E300: %CHMGR-5-FANOK: Minor alarm cleared: all fans in fan tray are good			
TME_TASK_SUSPEND	ENVMON	NONE	
%TME-2-TASK SUSPENDED: SUSPENDED - svce:%d - inst:%d - task:%s			
TME_TASK_TERM	ENVMON	NONE	
%TME-2-ABNORMAL_TASK_TERMINATION: CRASH - task:%s %s			
CHM_CPU_THRESHOLD	ENVMON	NONE	
%CHMGR-5-CPU_THRESHOLD: Cpu %s usage above threshold. Cpu5SecUsage (%d)			
%CHMGR-5-CPU_THRESHOLD: Cpu %s usage	above uneshold. Cpubbecosage (%d)		

Table A-1. SNMP Traps and Error Messages (continued)

Message ID	Trap Type	Trap Option	
%CHMGR-5-CPU_THRESHOLD_CLR: Cpu %s usage drops below threshold. Cpu5SecUsage (%d)			
CHM_MEM_THRESHOLD	ENVMON	NONE	
%CHMGR-5-MEM_THRESHOLD: Memory %s usage above threshold. MemUsage (%d)			
CHM_MEM_THRESHOLD_CLR	ENVMON	NONE	
%CHMGR-5-MEM_THRESHOLD_CLR: Memory %s usage drops below threshold. MemUsage (%d)			
MACMGR_STN_MOVE	ENVMON	NONE	
%MACMGR-5-DETECT_STN_MOVE: Station Move threshold exceeded for Mac %s in vlan %d			
VRRP_BADAUTH	PROTO	NONE	
%RPM1-P:RP2 %VRRP-3-VRRP_BAD_AUTH: vrid-1 on Gi 11/12 rcvd pkt with authentication type mismatch. %RPM1-P:RP2 %VRRP-3-VRRP_BAD_AUTH: vrid-1 on Gi 11/12 rcvd pkt with authentication failure.			
VRRP_GO_MASTER	PROTO	NONE	
%VRRP-6-VRRP_MASTER: vrid-%d on %s entering MASTER			
BGP4_ESTABLISHED	PROTO	NONE	
%TRAP-5-PEER_ESTABLISHED: Neighbor %a, state %s			
BGP4_BACKW_XSITION	PROTO	NONE	
%TRAP-5-BACKWARD_STATE_TRANS: Neighbor %a, state %s			