

Open Networking Hardware Diagnostic Guide

September 2017

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

1 About this guide	7
Notices	7
Related documents	7
2 ONIE and Dell EMC OS installation instructions	8
DIAG-OS installation	8
ONIE and DIAG OS installation	9
ONIE service discovery and OS installation	9
Installation ONIE from BIOS	10
ONIE UEFI-based installation using USB	10
3 ONIE overview	16
Boot processes	16
POST	16
Capturing support data from ONIE	16
Change default grub boot entry	17
View system information	17
4 Dell EMC DIAG OS	19
Diagnostic package download	19
Diagnostic test suite	22
View DIAG versions	22
View CPLD versions	22
Install or upgrade DIAG tools	22
Restore factory defaults	23
5 Dell EMC DiagOS tools	24
Diagnostic tools	24
cpdupgradetool	25
Tests	25
CLI options	25
Output	25
Configuration file format	26
cputool	26
Tests	26
CLI options	26
Output	27
Configuration file format	28
eepromtool	28
Tests	28
CLI options	28
Output	29

Configuration file format.....	31
ethtool.....	31
fantool.....	31
Tests.....	32
CLI options.....	32
Outputtest output.....	33
Configuration file format.....	34
flashrom.....	35
gpiotool.....	35
CLI options.....	35
Output.....	36
list output.....	36
get output.....	36
set output.....	36
Configuration file format.....	37
i2ctool.....	37
Tests.....	37
CLI options.....	38
Outputscan Output.....	39
test Output.....	39
read Output.....	40
write Output.....	41
Configuration file format.....	41
ledtool.....	41
Tests.....	42
CLI options.....	42
Outputlist output.....	43
get Output.....	43
Configuration file format.....	44
lpctool.....	44
CLI options.....	44
Outputread Output.....	45
write Output.....	45
memtool.....	45
Tests.....	45
CLI options.....	46
Outputlist Output.....	47
info Output.....	48
test Output.....	48
read Output.....	49
write Output.....	49
Constraints.....	49
Data flow.....	49
Configuration file format.....	49
nputool.....	50

Tests.....	50
CLI options.....	50
nvrantool.....	55
Tests.....	56
CLI option.....	56
Outputread outputwrite output.....	56
Configuration file format.....	57
opticstool.....	58
Tests.....	58
CLI options.....	58
Outputshow=brief outputshow outputshow --int=interface # output.....	58
Configuration file format.....	61
pcitool.....	63
Tests.....	63
CLI options.....	63
Outputscan outputtest outputshow output.....	64
Configuration file format.....	66
phytool.....	67
Tests.....	67
CLI optionsOutput.....	67
ptool.....	69
Tests.....	69
CLI options.....	69
Outputlist outputlistdevicenames outputread outputwrite outputtest output.....	70
Configuration file format.....	71
psutool.....	72
Tests.....	72
CLI optionstest option.....	72
Configuration file format.....	73
rtctool.....	74
Tests.....	74
CLI options.....	74
smartctl.....	75
smarttool.....	75
SMF upgrade binariesCLI options.....	75
SMF MSS upgrade.....	76
Upgrading SMF FPGA.....	78
smbiostool.....	80
CLI options.....	80
Output.....	81
storagetool.....	81
Tests.....	81
CLI options.....	81
Outputlist outputtest outputsmart outputbonnie output.....	82
smartctl.....	84

bonnie++.....	86
temptool.....	86
Tests.....	86
CLI options.....	87
Outputtest output.....	87
Configuration file format.....	88
vmetestool.....	88
CLI options.....	88
edatool.....	89
Tests.....	89
CLI options.....	89
Output.....	89
Configuration file format.....	92
Verbose mode.....	93
Diagnostic package.....	93
6 Technical support.....	94
Accessing support services.....	94
Technical assistance center.....	94
Hardware replacement.....	95

About this guide

This guide provides site preparation recommendations, step-by-step procedures for rack mounting and desk mounting, inserting optional modules, and connecting to a power source.

Notices

- ⚠ **CAUTION:** To avoid electrostatic discharge (ESD) damage, wear grounding wrist straps when handling this equipment.
- ⚠ **WARNING:** Only trained and qualified personnel can install this equipment. Read this guide before you install and power up this equipment. This equipment contains two power cords. Disconnect both power cords before servicing.
- ⚠ **WARNING:** This equipment contains optical transceivers, which comply with the limits of Class 1 laser radiation.



Figure 1. Class 1 laser product tag

- ⚠ **WARNING:** When no cable is connected, visible and invisible laser radiation may be emitted from the aperture of the optical transceiver ports. Avoid exposure to laser radiation and do not stare into open apertures.

Related documents

For more information about the Open Networking (-ON) platform, see the following documents.

- *Dell EMC OS10 User Guide*
- *Dell EMC OS9 Command Line Reference Guide*
- *Dell EMC OS9 Configuration Guide*
- *Dell EMC Getting Started Guide or Dell EMC Setup Guide*
- *Dell EMC Installation Guide*
- *Dell EMC Release Notes*

ONIE and Dell EMC OS installation instructions

This section describes the different methods to install ONIE and the Dell EMC OS on your system.

NOTE: After installing the NOS and DIAG-OS, if you boot into ONIE Install mode, ONIE assumes ownership of the system; ONIE Install mode is sticky. In this situation, ONIE stays in Install mode until NOS and Diag-OS is successfully installed again. If you want to boot into ONIE for any reason other than installation, use Rescue mode or Update mode.

NOTE: To access ONIE, use the RJ-45 console port.

Topics:

- [DIAG-OS installation](#)
- [ONIE and DIAG OS installation](#)
- [ONIE service discovery and OS installation](#)
- [Installation ONIE from BIOS](#)

DIAG-OS installation

NOTE: If you have a recovery USB plugged into your system, you must remove it before installing the DIAG-OS.

- 1 Assign an IP address to the management interface.
Confirm you can reach the network.
- 2 Use following command to install the DIAG-OS from the ONIE prompt:

```
ONIE:/ # onie-nos-install tftp://n.n.n.n/diag-installer-x86_64-dell_<platform>_<processor id>-r0.bin
```

After the DIAG-OS installs, the system reboots and displays following menu:

NOTE: By default, the system boots in DIAG-OS mode.

```
GNU GRUB version 2.02~beta2+e4a1fe391
```

```
+-----+
| *EDA-DIAG
|  ONIE
|
|
|
|
|
|
|
+-----+
```

Use the ^ and v keys to select which entry is highlighted.
Press enter to boot the selected OS, `e' to edit the commands before booting or `c' for a command-line.

ONIE and DIAG OS installation

The following steps describe how to load ONIE and DIAG-OS on your system:

- Installing ONIE—these instructions use the universal serial bus (USB) method. To boot from a Linux USB, you must preinstall BIOS on your system.
- Installing the DIAG-OS—Install the DIAG-OS from the ONIE prompt. Ensure that your TFTP server is reachable over your network.
- ONIE operates using a 115200 baud rate. Ensure that any equipment attached to the serial port supports the required 115200 baud rate.

NOTE: The following output examples are for reference only; your output may vary.

NOTE: The management port IP, FTP server IP address, MAC address, and user-id shown are for illustration purpose only. Use your system's applicable values.

ONIE service discovery and OS installation

ONIE attempts to locate the installer through several discovery methods, as shown. To download and run an installer, the ONIE Service Discovery feature uses the first successful method found.

- 1 Pass from the boot loader.
- 2 Search locally attached storage devices for one of the ONIE default installer filenames—for example, USB.
- 3 Discover the URLs from DHCPv4.
- 4 Report discovered URLs based on the DHCPv4 responses.
- 5 Query to the IPv6 link-local neighbors using HTTP for an installer.
- 6 Start TFTP waterfall—from the DHCPv4 option 66

ONIE `ifconfig eth0` command examples

If none of the ONIE Service Discovery methods are successful, you can disable this using the `onie-discovery-stop` command.

You can install an operating system manually from HTTP, USB, FTP, or TFTP using the `onie-nos-install <URL>` command.

NOTE: If you have a recovery USB plugged into your system, you must remove it before installing the DIAG-OS using the `onie-nos-install <URL>` command.

The ONIE Install environment uses DHCP to assign an IP address to the management interface, eth0. If that fails, it uses the link-local IPv4 addr 169.254.209.190/16.

To display the IP address, use the `ifconfig eth0` command, as shown:

```
ONIE:/ # ifconfig eth0
eth0 Link encap:Ethernet HWaddr 90:B1:1C:F4:9C:76
  inet addr:n.n.n.n Bcast:n.n.n.n Mask:n.n.n.n
  inet6 addr: fe80::92b1:1cff:fef4:9c76/64 Scope:Link
  UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
  RX packets:18 errors:0 dropped:0 overruns:0 frame:0
  TX packets:24 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1000
  RX bytes:1152 (1.1 KiB) TX bytes:6864 (6.7 KiB)
  Interrupt:21 Memory:ff300000-ff320000
```

To assign an IP address to the management interface, eth0, and verify network connectivity, use the `ifconfig eth0 <ip address>` command, as shown:

```
ONIE:/ # ifconfig eth0 n.n.n.n netmask n.n.n.n UP
```

Then set speed on management interface as below

```
ONIE:/ # ethtool -s eth0 speed 100 duplex full
Verify the network connection with ping.
ONIE:/ # ping n.n.n.n
```

```
PING n.n.n.n (n.n.n.n): 56 data bytes
64 bytes from n.n.n.n: seq=0 ttl=62 time=1.357 ms
64 bytes from n.n.n.n: seq=1 ttl=62 time=0.577 ms
^C
```

Installation ONIE from BIOS

There are two options for installing ONIE from the BIOS.

- Media (usb) boot using the ONIE installer USB (using the OCP Procedure)
- Media (usb) boot using the Ubuntu installer USB (using the custom-bootable USB procedure)

Pre-requisites

The BIOS running on your system must meet the following requirements:

- Allows a change to the boot order so the system can boot from media (USB).
- Allows a baud-rate change. This is optional and you do not need it if your BIOS is running at 115200 baud rate. The default baud rate for ONIE is 115200.

⚠ CAUTION:

- These procedures are for x86-based targets only, particularly targets using Rangeley or Centerton CPU-based boards.
- Check the console (UART-0/1) used on target.
- The log messages included in this guide are subject to change.

① NOTE: The following procedure is generic and does not list a particular target. Therefore, the ONIE images are specified using the <platform>_<cpu> notation. For example, the ONIE media (usb) iso image is onie-recovery-x86_64-dell_<platform>_<cpu>-r0.iso.

ONIE UEFI-based installation using USB

The following steps describe how to create a bootable unified extensible firmware interface (UEFI) ONIE-based USB to install ONIE using Embed mode:

To install ONIE UEFI on your system, use any existing ONIE-based system to make an ONIE UEFI-based bootable USB. To make a bootable USB, use the ONIE ISO file.

- 1 Boot the ONIE target in ONIE Rescue mode.
Use ONIE Rescue mode to make the ONIE UEFI-bootable USB.

① NOTE: To select which entry is highlighted, use the up and down arrow keys. Press Enter to select an operating software-selected OS or enter e to edit the commands before booting. Enter c for a command line. The highlighted entry, displaying *, executes automatically in the operating system.

```
GNU GRUB version 2.02~beta2+e4a1fe391

+-----+
|ONIE: Install OS          |
|*ONIE: Rescue            |
|ONIE: Uninstall OS      |
|ONIE: Update ONIE       |
|ONIE: Embed ONIE        |
|EDA-DIAG                 |
|                          |
|                          |
|                          |
+-----+
```

- 2 Confirm that your system can reach the network.

- 3 Copy the ONIE ISO image to the solid-state drive (SSD) of the ONIE target.

```
ONIE:/ # wget --quiet http://xx.xx.x.xxx/tftpboot/users/<name>/onie-recovery-x86_64-dell_<platform>_c2538-r0.iso
```

To copy the image, you can use SCP, TFTP, or WGET (ftp/http).

```
scp username@xx.xx.xxx.xxx:/tftpboot/onie-recovery-x86_64-dell_<platform>_c2538-r0.iso .
```

- 4 Confirm that the ISO file copied to the SDD over the network.

```
ONIE:/ # ls -l
...
-rw-r--r-- 1 root 0 39780352 Apr 10 11:55 onie-recovery-x86_64-dell_<platform>_c2538-r0.iso
...
```

- 5 Insert a blank USB in the ONIE target's USB slot. Verify the USB block device using the ONIE logs.

```
Info: eth0: Checking link... scsi 6:0:0:0: Direct-Access Kingston DataTraveler 2.0 1.00 PQ:
0 ANSI: 4
sd 6:0:0:0: [sdb] 15148608 512-byte logical blocks: (7.75 GB/7.22 GiB)
sd 6:0:0:0: [sdb] Write Protect is off
sd 6:0:0:0: [sdb] Write cache: disabled, read cache: enabled, doesn't support DPO or FUA
sd 6:0:0:0: [sdb] Attached SCSI removable disk
```

The logs show that the USB device is present: `/dev/sdb`.

You can also check `/sys/block`.

```
ONIE:/ # cd /sys/block/sdb
ONIE:/sys/block/sdb # ls -l
-r--r--r-- 1 root 0 4096 Apr 10 13:12 alignment_offset
lrwxrwxrwx 1 root 0 0 Apr 10 13:12 bdi -> ../../devices/virtual/bdi/8:16
-r--r--r-- 1 root 0 4096 Apr 10 13:12 capability
-r--r--r-- 1 root 0 4096 Apr 10 13:12 dev
lrwxrwxrwx 1 root 0 0 Apr 10 13:12 device -> ../../devices/pci0000:00/0000:00:16.0/
usb/l1-1/1-1.1/1-1.1.1/1-1.1.1:1.0/host6/target6:0:0/6:0:0:0
...
```

- 6 Use the `dd` command to copy the ISO image to the USB.

```
ONIE:/ # dd if=./onie-recovery-x86_64-dell_<platform>_c2538-r0.iso of=/dev/sdb bs=10M
3+1 records in
3+1 records out
39780352 bytes (37.9MB) copied, 6.890503 seconds, 5.5MB/s
ONIE:/ #
```

- 7 Move the USB from the ONIE target (the system with ONIE) to the USB slot in your switch (the system without ONIE).

- 8 Power on your system and enter the **BIOS setup** menu by selecting `De1` when BIOS message appears.

If you already powered on your system, reboot the system and enter the **BIOS setup** menu by selecting `De1`.

- 9 In the **BIOS Boot** menu, select `UEFI USB`. Select `Save and Exit`.




Figure 2. Setup utility

After exiting the **BIOS Boot** menu, the system boots with the ONIE USB and presents the following menu:



Figure 3. Embed ONIE menu

- 10 Select the Embed ONIE option.

This step installs the UEFI ONIE version 3.26.11 on system. Any previous installation is removed.

Do not press any key during the Embed ONIE installation.

The following are the Embed ONIE logs:

```

ONIE: Embedding ONIE ...
Platform : x86_64-dell_<platform>_c2538-r0
Version : x.xx.x.x
Build Date: 2016-04-26T09:14-0700
[ 4.066378] dummy-irq: no IRQ given. Use irq=N
[ 14.296290] esas2r: driver will not be loaded because no ATTO esas2r devices were found

```

```

[ 14.463587] mtdoops: mtd device (mtddev=name/number) must be supplied
[ 16.328319] i8042: No controller found
[ 16.397853] fmc_write_eeprom fake-design-for-testing-f001: fmc_write_eeprom: no busid
passed, refusing all cards
[ 16.568122] intel_rapl: driver does not support CPU family 6 model 77
Info: Mounting kernel filesystems... done.
Info: Mounting ONIE-BOOT on /mnt/onie-boot ...
Info: Using eth0 MAC address: 4c:76:25:f4:7c:80
Info: eth0: Checking link... [ 18.571495] scsi 6:0:0:0: Direct-Access Kingston DataTraveler
2.0 1.00 PQ: 0 ANSI: 4
[ 18.707185] sd 6:0:0:0: Attached scsi generic sgl type 0
[ 18.707703] sd 6:0:0:0: [sdb] 15148608 512-byte logical blocks: (7.75 GB/7.22 GiB)
[ 18.796392] sd 6:0:0:0: [sdb] Write Protect is off
[ 18.797033] sd 6:0:0:0: [sdb] Write cache: disabled, read cache: enabled, doesn't support
DPO or FUA
[ 19.159563] sd 6:0:0:0: [sdb] Attached SCSI removable disk
up.
Info: Trying DHCPv4 on interface: eth0
ONIE: Using DHCPv4 addr: eth0: 1[ 20.053045] random: dropbearkey urandom read with 94 bits
of entropy available
x.xx.xxx.xx / xxx.xxx.xxx.x
Starting: dropbear ssh daemon... done.
Starting: telnetd... done.
discover: ONIE embed mode detected. Running updater.
Starting: discover... done.
Please press Enter to activate this console. Info: eth0: Checking link... up.
Info: Trying DHCPv4 on interface: eth0
ONIE: Using DHCPv4 addr: eth0: x.xx.xxx.xx / xxx.xxx.xxx.x
ONIE: Starting ONIE Service Discovery
Info: Found static url: file:///lib/onie/onie-updater
[ 29.744855] random: nonblocking pool is initialized
ONIE: Executing installer: file:///lib/onie/onie-updater
Verifying image checksum ... OK.
Preparing image archive ... OK.
ONIE: Version : x.xx.x.x
ONIE: Architecture : x86_64
ONIE: Machine : dell_<platform>_c2538
ONIE: Machine Rev : 0
ONIE: Config Version: 1
Installing ONIE on: /dev/sda
/proc/devices: No entry for device-mapper found
/proc/devices: No entry for device-mapper found
ONIE: Success: Firmware update URL: file:///lib/onie/onie-updater
ONIE: Success: Firmware update version: x.xx.x.x
ONIE: Rebooting...
discover: ONIE embed mode detected.
Stopping: discover...start-stop-daemon: warning: killing process 1441: No such process
Stopping: dropbear ssh daemon... done.
Stopping: telnetd... done.

Stopping: syslogd... done.
Info: Unmounting kernel filesystems
The system is going down NOW!
Sent SIGTERM to all processes
Sent SIGKILL to all processes
Requesting system reboot

```

After the Embed-ONIE installation finishes, the system bootups and presents the **ONIE** menu.



Figure 4. ONIE install menu

The system comes up in ONIE Install mode by default, as shown:

```

ONIE: OS Install Mode ...
Version : x.xx.x.x
Build Date: 2016-04-26T09:14-0700
ONIE: OS Install Mode ...
Version : x.xx.x.x
Build Date: 2016-04-26T09:14-0700
[ 4.759116] dummy-irq: no IRQ given. Use irq=N

[ 4.835970] esas2r: driver will not be loaded because no ATTO esas2r
devices were found
[ 5.003050] mtdoops: mtd device (mtddev=name/number) must be supplied
[ 6.867708] i8042: No controller found
[ 6.937375] fmc_write_eeprom fake-design-for-testing-f001:
fmc_write_eeprom: no busid passed, refusing all cards
[ 7.107669] intel_rapl: driver does not support CPU family 6 model 77
Info: Mounting kernel filesystems... done.
Info: Mounting ONIE-BOOT on /mnt/onie-boot ...
[ 8.018377] random: fsck urandom read with 73 bits of entropy available
Info: Mounting EFI System on /boot/efi ...
Info: Using eth0 MAC address: 4c:76:25:f4:7c:80
Info: eth0: Checking link... [ 8.902787] scsi 6:0:0:0: Direct-Access
Kingston DataTraveler 2.0 1.00 PQ: 0 ANSI: 4
[ 9.038475] sd 6:0:0:0: Attached scsi generic sgl type 0
[ 9.038993] sd 6:0:0:0: [sdb] 15148608 512-byte logical blocks: (7.75
GB/7.22 GiB)
[ 9.253877] sd 6:0:0:0: [sdb] Write Protect is off
[ 9.254546] sd 6:0:0:0: [sdb] Write cache: disabled, read cache: enabled,
doesn't support DPO or FUA
[ 9.492124] sd 6:0:0:0: [sdb] Attached SCSI removable disk
up.
Info: Trying DHCPv4 on interface: eth0
ONIE: Using DHCPv4 addr: eth0: x.xx.xxx.xx / xxx.xxx.xxx.x
Starting: dropbear ssh daemon... done.
Starting: telnetd... done.
[ 11.789298] random: nonblocking pool is initialized
discover: installer mode detected. Running installer.
Starting: discover... done.
Please press Enter to activate this console. Info: eth0: Checking link... up.
Info: Trying DHCPv4 on interface: eth0
ONIE: Using DHCPv4 addr: eth0: x.xx.xxx.xx / xxx.xxx.xxx.x
ONIE: Starting ONIE Service Discovery
Info: Fetching

```

```
http://xx.xx.xxx.x/onie-installer-x86_64-dell_<platform>_c2538-r0 ...
Info: Fetching http://xx.xx.xxx.x/onie-installer-x86_64-dell_<platform>_c2538
...
Info: Fetching http://xx.xx.xxx.x/onie-installer-dell_<platform>_c2538 ...
Info: Fetching http://xx.xx.xxx.x/onie-installer-x86_64 ...
Info: Fetching http://xx.xx.xxx.x/onie-installer ...
Info: Fetching
http://xx.xx.xxx.x/onie-installer-x86_64-dell_<platform>_c2538-r0 ...
Info: Fetching http://xx.xx.xxx.x/onie-installer-x86_64-dell_<platform>_c2538
...
```

11 Stop ONIE Discovery mode.

```
ONIE:/ # onie-discovery-stop
The operation has completed successfully.
ONIE:/ #
```

12 Verify the ONIE Linux kernel version and partition layout.

This step verifies you are running the correct kernel in ONIE as the kernel is separate from the ONIE environment.

```
ONIE:/ # uname -a
Linux onie 4.1.28-onie+ #1 SMP Wed Sep 7 14:38:43 PDT 2016 x86_64 GNU/Linux
ONIE:/ # sgdisk -p /dev/sda
Disk /dev/sda: 31277232 sectors, 14.9 GiB
Logical sector size: 512 bytes
Disk identifier (GUID): 763E53FF-B894-40FD-B0F9-FBAE2ED4B0B5
Partition table holds up to 128 entries
First usable sector is 34, last usable sector is 31277198
Partitions will be aligned on 2048-sector boundaries
Total free space is 30490733 sectors (14.5 GiB)
Number Start (sector) End (sector) Size Code Name
1 2048 526335 256.0 MiB EF00 EFI System
2 526336 788479 128.0 MiB 3000 ONIE-BOOT
ONIE:/ #
```

13 Verify that efibootmgr runs and displays the valid boot options.

```
ONIE:/ # efibootmgr
BootCurrent: 0000
Timeout: 1 seconds
BootOrder: 0000,0006,0001,0003
Boot0000* ONIE: Open Network Install Environment
Boot0001* Hard Drive
Boot0003* UEFI: Built-in EFI Shell
Boot0006* UEFI: KingstonDataTraveler 2.01.00 14
```

ONIE overview

This chapter describes system diagnostics and troubleshooting. After running the diagnostic tools, your system displays pass or fail test results. If all tests pass, the diagnostic tools exit normally. If a test fails, each diagnostic tool offers a different result.

NOTE: The troubleshooting package includes a README file that lists the tools version and the overall troubleshooting package version. For more information, see this README file.

NOTE: To download the Release Notes, go to www.dell.com/support.

This system uses the power-on self test (POST) diagnostic tool that automatically runs during the system power-on at the BIOS or U-boot level. This tool tests for catastrophic hardware failures that prevent booting the system. The error code is saved in CMOS for the next boot. There is no physical alarm indication.

Topics:

- [Boot processes](#)
- [View system information](#)

Boot processes

After the BIOS or U-Boot, POST runs to verify the devices required to boot to open network installation environment (ONIE) GRUB.

POST

POST diagnostics verify the system DRAM, DIMM, SPD, memory, RTC/NVRAM, and PCI devices. Test configuration parameters and test results are saved in NVRAM.

Capturing support data from ONIE

To capture support data from ONIE, use the following commands:

- 1 Capture support data to the screen.
`ONIE:/ # dmesg`
- 2 Capture support data to the `onie-support.tar.bz2` gzip file.
ONIE-support creates the support file. Enter the location to store the file; for example, `ONIE:/# onie-support/tmp`.
`ONIE:/ # onie-support <output_directory>`

The ONIE support file includes the following:

- `kernel_cmdline`
- `runtime-export-env`
- `runtime-process`
- `runtime-set-env`

- log/messages
- log/onie.log

Output example

```
Success: Support tarball created: /tmp/onie-support.tar.bz2
```

Change default grub boot entry

To view or set the default Boot mode, the `onie-boot-mode` command has two options `-l`, the default, and `-o`. The Grub boot default shows the current default entry.

View or set the default Grub boot entry.

```
ONIE:/ # onie-boot-mode [-o <onie_mode>]
```

The `-o` command options include:

- `install`—ONIE OS Installer mode
- `rescue`—ONIE Rescue mode
- `uninstall`—ONIE OS Uninstall mode
- `update`—ONIE Self-Update mode
- `embed`—ONIE Self-Update mode and Embed ONIE
- `none`—Uses System Default Boot mode. This mode uses the first ONIE boot menu entry.

The `-l` command option lists the current default entry—this is the default setting.

View system information

To view your system information; for example, the model, part number, serial number, and service tag, use the following commands:

- 1 Boot into ONIE.
- 2 Enter the `onie-syseeprom` command.

Command example

```
ONIE:/ # onie-syseeprom
TlvInfo Header:
  Id String:      TlvInfo
  Version:       1
  Total Length:  162
TLV Name          Code Len Value
-----
Part Number       0x22  6 0W1K08
Serial Number     0x23 20 CN0W1K08779316470002
Product Name      0x21  8 <platform>
Device Version    0x26  1 0
Label Revision    0x27  3 X00
Manufacture Date  0x25 19 04/08/2016 08:43:05
Manufacturer      0x2B  5 77931
Country Code      0x2C  2 CN
Vendor Extension  0xFD  1 0x00
MAC Addresses     0x2A  2 256
Service Tag       0x2F  7 2WCSG02
Vendor Name       0x2D  4 DELL
Diag Version      0x2E  6 01_010
Base MAC Address  0x24  6 34:17:EB:05:B4:00
Platform Name     0x28 26 x86_64-dell_<platform>_c2538-r0
ONIE Version      0x29  8 x.xx.x.x
```

```
CRC-32          0xFE    4 0x99415608
Checksum is valid.
ONIE:/ #
```

- 3 Enter the `onie-sysinfo -a` command.

Command Example

```
ONIE:/ # onie-sysinfo -a
CN0W1K08779316470002 0W1K08 34:17:EB:05:B4:00 3.28.1.2 674 dell_<platform>_c2538 0 x86_64-
dell_<platform>_c2538-r0 x86_64 1 gpt 2016-09-21T10:01-0700 bcm
ONIE:/ #
```

Dell EMC DIAG OS

The following describes the Dell EMC diagnostics. These instructions apply to systems for which the ONIE diagnostics are not available.

Topics:

- [Diagnostic package download](#)
- [View DIAG versions](#)
- [View CPLD versions](#)
- [Install or upgrade DIAG tools](#)
- [Restore factory defaults](#)

Diagnostic package download

Load or update the DIAG-OS (diag installer image) using the `onie-nos-install` command in ONIE Install or ONIE-Rescue mode. The DIAG-OS installer runs in two modes: Update mode or Install mode.

- In Update mode, the DIAG-OS updates the existing DIAG-OS and boots back to ONIE.
- In Install mode, the DIAG-OS erases the existing DIAG-OS and loads the new DIAG-OS.

NOTE: If you have a recovery USB plugged into your system, remove it before installing the DIAG-OS using the `onie-nos-install` command.

NOTE: Before you begin, go to www.dell.com/support and download the diagnostic package.

- 1 Enter the `onie-discovery-stop` command to stop ONIE Discovery mode.
- 2 Assign an ip address to the management interface and verify the network connectivity.

```
ONIE:/ # ifconfig eth0 xx.xx.xx.xx netmask xxx.xxx.x.x up
ONIE:/ # ifconfig
eth0      Link encap:Ethernet  HWaddr 34:17:EB:05:B4:00
          inet addr:xx.xx.xx.xx  Bcast:xx.xx.xxx.xxx  Mask:xxx.xxx.x.x
          inet6 addr: fe80::3617:ebff:fe05:b400/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:43 errors:0 dropped:0 overruns:0 frame:0
          TX packets:31 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:5118 (4.9 KiB)  TX bytes:7104 (6.9 KiB)
          Memory:dff40000-dff5ffff
```

- 3 Upgrade the DIAG Installer.
Again, boot to ONIE Rescue mode and install the `onie diag installer`.

Removing the existing DIAG OS and installing a new version example

NOTE: In Install mode, the DIAG-OS installation removes any existing NOS and DIAG-OS partition. If you do not create file `/tmp/diag_os_install_mode`, the DIAG-OS installs in Upgrade mode. In this case, the installation process does NOT touch any existing NOS.

```
ONIE:/ onie-nos-install tftp://<tftp-server ip>/<filepath>/filename/diag-install
er-x86_64-dell_<platform>_c2538-r0-2016-08-12.bin
discover: installer mode detected.
```

```

Stopping: discover... done.
Info: Fetching tftp://<tftp-server ip>/users/<user>/<platform>/diag-installer-x86_64-
dell_<platform>_c2538-r0-2016-08-12.bin ...
users/<user>/<platform> 100% |*****| 154M 0:00:00 ETA
ONIE: Executing installer: tftp://<tftp-server ip>/users/<user>/<platform>/diag-installer-
x86_64-dell_<platform>_c2538-r0-2016-08-12.bin
Ignoring Verifying image checksum ... OK.
cur_dir / archive_path /var/tmp/installer tmp_dir /tmp/tmp.qlnVIY
Preparing image archive ...sed -e 'l,/^exit_marker$/d' /var/tmp/installer | tar xf - OK.
Diag-OS Installer: platform: x86_64-dell_<platform>_c2538-r0

EDA-DIAG Partiton not found.
Diag OS Installer Mode : INSTALL

Creating new diag-os partition /dev/sda3 ...
Warning: The kernel is still using the old partition table.
The new table will be used at the next reboot.
The operation has completed successfully.

EDA-DIAG dev is /dev/sda3
mke2fs 1.42.13 (17-May-2015)
Creating filesystem with 262144 4k blocks and 65536 inodes
Filesystem UUID: 63fc156f-b6c1-415d-9676-ae4478704c5a
Superblock backups stored on blocks:
    32768, 98304, 163840, 229376

Allocating group tables: done
Writing inode tables: done
Creating journal (8192 blocks): done
Writing superblocks and filesystem accounting information: done

Created filesystem on /dev/sda3 with label EDA-DIAG

Mounted /dev/sda3 on /tmp/tmp.BBEygm

Preparing /dev/sda3 EDA-DIAG for rootfs install
untaring into /tmp/tmp.BBEygm

rootfs copy done
Success: Support tarball created: /tmp/tmp.BBEygm/onie-support.tar.bz2

Updating Grub Cfg /dev/sda3 EDA-DIAG

    ONIE uefi_uuid 69AD-9CBF

INSTALLER DONE...
Removing /tmp/tmp.qlnVIY
ONIE: NOS install successful: tftp://<tftp-server ip>/users/<user>/<platform>/diag-installer-
x86_64-dell_<platform>_c2538-r0-2016-08-12.bin
ONIE: Rebooting...
ONIE:/ # discover: installer mode detected.
Stopping: discover...start-stop-daemon: warning: killing process 2605: No such process
done.
Stopping: dropbear ssh daemon... done.
Stopping: telnetd... done.
Stopping: syslogd... done.
Info: Unmounting kernel filesystems
umount: can't unmount /: Invalid argument
The system is going down NOW!
Sent SIGTERM to all processes
Sent SIGKILL tosd 4:0:0:0: [sda] Synchronizing SCSI cache
reboot: Restarting system
reboot: machine restart

BIOS Boot Selector for <platform>

```

Primary BIOS Version x.xx.x.x_MRC48

SMF Version: MSS 1.3.1, FPGA 0.3

Last POR=0x11, Reset Cause=0x55

POST Configuration

CPU Signature 406D8
CPU FamilyID=6, Model=4D, SteppingId=8, Processor=0
Microcode Revision 125
Platform ID: 0x10041A43
PMG_CST_CFG_CTL: 0x40006
BBL_CR_CTL3: 0x7E2801FF
Misc EN: 0x840081
Gen PM Con1: 0x203808
Therm Status: 0x884C0000
POST Control=0xEA000100, Status=0xE6000000

BIOS initializations...

CPGC Memtest PASS

CPGC Memtest PASS

Booting `EDA-DIAG'

Loading DIAG-OS ...

[3.786758] dummy-irq: no IRQ given. Use irq=N
[3.792812] esas2r: driver will not be loaded because no ATTO esas2r devices were found
[3.818171] mtdoops: mtd device (mtddev=name/number) must be supplied
[4.880285] i8042: No controller found
[4.890134] fmc_write_eeprom fake-design-for-testing-f001: fmc_write_eeprom: no busid passed, refusing all cards
[4.901699] intel_rapl: driver does not support CPU family 6 model 77

Debian GNU/Linux 8 dell-diag-os ttyS1

dell-diag-os login: root

Password:

Linux dell-diag-os 3.15.10 #1 SMP Fri Aug 12 05:14:52 PDT 2016 x86_64

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.

Diag OS version <platform> DIAG OS x.xx.x.x
Build date/time Fri Aug 12 05:23:56 PDT 2016
Build server netlogin-eqx-03
Build by <name>

Kernel Info:

Linux 3.15.10 #1 SMP Fri Aug 12 05:14:52 PDT 2016 x86_64 GNU/Linux

Debian GNU/Linux 8 \n \l

Done Initializing Ethernet

root@dell-diag-os:~#
root@dell-diag-os:~#
root@dell-diag-os:~#
root@dell-diag-os:~#
root@dell-diag-os:~#
root@dell-diag-os:~#

- 4 Start diagnostics. To start the ONIE diagnostics, use the DIAG-OS option from the Grub menu.

- a Boot into the DIAG OS.
- b Log in as root.
- c Install the EDA-DIAG tools package.
- d Run `/opt/dell/diag/bin/edatool`.

NOTE: To return to your networking operating software, enter the `reboot` command.

Diagnostic test suite

After the system boots up, select the EDA-DIAG option to run the diagnostic test suite.

NOTE: To select which entry is highlighted, use the up and down arrow keys. Press Enter to select an operating software-selected OS or enter `e` to edit the commands before booting. Enter `c` for a command line. The highlighted entry, displaying `*`, executes automatically in the operating system.

```
GNU GRUB version 2.02~beta2+e4a1fe391
```

```
+-----+
|ONIE: Install OS
|ONIE: Rescue
|ONIE: Uninstall OS
|ONIE: Update ONIE
|ONIE: Embed ONIE
|*EDA-DIAG
|
|
|
+-----+
```

View DIAG versions

To display the DIAG version installed in the DIAG OS, use the `dpkg -l | grep dn-diags` command at the `root@dell-diag-os:~` prompt.

```
root@dell-diag-os:~# dpkg -l | grep dn-diags
ii dn-diags-<platform>-on.deb 1.10 amd64 Dell Diagnostics
root@dell-diag-os:~#
```

View CPLD versions

To view CPLD data, including the fan status, PSU status, current programmed version, and image packed version, use the `cpdupgradetool` command at the prompt.

```
root@dell-diag-os:~# cpdupgradetool --cpldver
CPLD1 Version 0x00
CPLD2 Version 0x01
CPLD3 Version 0x01
CPLD4 Version 0x01
root@dell-diag-os:~#
```

Install or upgrade DIAG tools

To install or upgrade the DIAGs in the DIAGs OS, use the `dpkg --install dn-diags-<platform>-DiagOS-3.28.1.02-2016-08-12.deb` command.

```
root@dell-diag-os:~#dpkg --install dn-diags-<platform>-DiagOS-3.28.1.02-2016-08-12.de
Selecting previously unselected package dn-diags-<platform>.deb.
(Reading database ... 18873 files and directories currently installed.)
Preparing to unpack dn-diags-<platform>-DiagOS-3.28.1.02-2016-08-12.deb ...
Unpacking dn-diags-<platform>.deb (1.10) ...
Setting up dn-diags-<platform>.deb (1.10) ...
root@dell-diag-os:~#
```

Restore factory defaults

To restore your system factory defaults, reboot the system to ONIE: Uninstall OS mode.

If it is not possible to restore your factory defaults with the installed OS, reboot the system from the Grub menu and select `ONIE: Rescue`. ONIE Rescue bypasses the installed OS and boots the system into ONIE until you reboot the system. After ONIE Rescue completes, the system resets and boots to the ONIE console.

⚠ CAUTION: Restoring factory defaults erases any installed OS and requires a long time to erase storage.

- 1 Restore the factory defaults on your system from the Grub menu using the `ONIE: Uninstall OS` command.
To select which entry is highlighted, use the up and down arrow keys.

```
GNU GRUB version 2.02~beta2+e4a1fe391

+-----+
| ONIE: Install OS          |
| ONIE: Rescue              |
| *ONIE: Uninstall OS      |
| ONIE: Update ONIE        |
| ONIE: Embed ONIE         |
|                           |
|                           |
|                           |
+-----+
```

- 2 Press **ENTER** to activate the console.
- 3 Return to the default ONIE settings using the `onie-uninstaller` command.

```
ONIE:/ # onie-uninstaller
Erasing internal mass storage device: /dev/sda4 (32MB)
  Percent complete: 100%
Erase complete.
Deleting partition 4 from /dev/sda
Erasing internal mass storage device: /dev/sda5 (300MB)
  Percent complete: 100%
Erase complete.
Deleting partition 5 from /dev/sda
Erasing internal mass storage device: /dev/sda6 (300MB)
  Percent complete: 100%
Erase complete.
Deleting partition 6 from /dev/sda
Erasing internal mass storage device: /dev/sda7 (12461MB)
  Percent complete: 100%
Erase complete.
Deleting partition 7 from /dev/sda
Installing for i386-pc platform.
Installation finished. No error reported.
Uninstall complete. Rebooting...
ONIE:/ # discover: Rescue mode detected. No discover stopped.
Stopping: dropbear ssh daemon... done.
Stopping: telnetd... done.
Stopping: syslogd... done.
Info: Unmounting kernel filesystems
The system is going down NOW!
Sent SIGTERM to all processes
Sent SIGKILL tosd 4:0:0:0: [sda] Synchronizing SCSI cache
Restarting system.
machine restart
```

Dell EMC DiagOS tools

This section describes how to use the Dell EMC diagnostics operating system (DiagOS). The DiagOS provides a suite of tools to help diagnose issues seen on the system, or to run a health check to ensure that the hardware is operating properly.

Diagnostic tools

The DiagOS uses standard Linux drivers and contains the following tools you can use to evaluate the health of your system. The tools are packaged for both the DiagOS, which is a simple OS of the same kernel version, and small `roots` to support the tools and drivers.

NOTE: By default, the system's I/O modules are down. Power up the I/O modules or the Opticstool and NPUtil reports failures. For information about how to power up the I/O modules, see the *Dell EMC Installation Guide* for your system at www.dell.com/support.

Topics:

- [cpldupgradetool](#)
- [cputool](#)
- [eepromtool](#)
- [ethtool](#)
- [fantool](#)
- [flashrom](#)
- [gpiotool](#)
- [i2ctool](#)
- [ledtool](#)
- [lpctool](#)
- [memtool](#)
- [nputool](#)
- [nvramtool](#)
- [opticstool](#)
- [pcitool](#)
- [phytool](#)
- [plttool](#)
- [psutool](#)
- [rtctool](#)
- [smartctl](#)
- [smarttool](#)
- [smbiostool](#)
- [storagetool](#)
- [temptool](#)
- [vmetool](#)
- [edatool](#)
- [Diagnostic package](#)

cpdupgradetool

The cpdupgradetool shows the CPLD version that is being used to upgrade the CPLD.

Tests

There are no defined tests with cpdupgradetool.

CLI options

```
root@dellemc-diag-os:~# cpdupgradetool
DellEmc Diag - CPLD Upgrade Tool
version 1.1, x.xx.x.x-x
build, 2017/05/23,

Syntax: cpdupgradetool <option>
Print the Help-Text:=
    cpdupgradetool --h                (or)
    cpdupgradetool -h
Print the CPLD versions:=
    cpdupgradetool --cpldver          (or)
    cpdupgradetool -c
Program a new CPLD image into CPLD's by specified index:=
    cpdupgradetool --write [--index=-1] [--image=<file>] (or)
    cpdupgradetool -w [-i -1] [-m <file>]

Usage:=
    -h, --h                Show the help text
    -c, --cpldver          CPLD version
    -w, --write            Write operation
    -i, --index=           Index
    -m, --image=           CPLD image
```

Output

```
root@dell-diag-os:/# cpdupgradetool --h
Dell Diag - CPLD Upgrade Tool
version 1.1, x.xx.x.x
build, 2016/08/12,
Syntax: cpdupgradetool <option>
Print the Help-Text:=
    cpdupgradetool --h                (or)
    cpdupgradetool -h
Print the CPLD versions:=
    cpdupgradetool --cpldver          (or)
    cpdupgradetool -c
Program a new CPLD image into CPLD's by specified index:=
    cpdupgradetool --write [--index=-1] [--image=<file>] (or)
    cpdupgradetool -w [-i -1] [-m <file>]

Usage:=
    -h, --h                Show the help text
    -c, --cpldver          CPLD version
    -w, --write            Write operation
    -i, --index=           Index
    -m, --image=           CPLD image
root@dell-diag-os:/#

root@dell-diag-os:/# cpdupgradetool --cpldver
```

```

CPLD1 Version 0x00
CPLD2 Version 0x01
CPLD3 Version 0x01
CPLD4 Version 0x01
root@dell-diag-os:/#

root@dell-diag-os:cpldupgradetool--write --image=<platform>_cpld_v01.vme
      Lattice Semiconductor Corp.
      ispVME(tm) V12.2 Copyright 1998-2011.
For daisy chain programming of all in-system programmable devices
Invalid Format: CPLD_WE assertion level
TDI:39,TCK:35,TMS:36,WE:57,TRST:58,TDO:49,SelPin:0, Freq:2400
g_CoresiIspPins Init= 30000 g_SussiIspPins Init= 2000134 g_WEAssertLevel= 0
Processing virtual machine file (./<platform>_cpld_v01.vme).....
CREATED BY: ispVM(R) System Version 18.0.1
CREATION DATE: 06/23/16 14:26:03
+=====+
| PASS! |
+=====+

```

Configuration file format

Configuration File Format

There is no configuration file associated with the cpldupgradetool

cputool

The cputool displays the CPU information, reads and writes of the MSR and the LPC bus.

Tests

There are no defined tests with the cputool.

CLI options

```

root@dellmc-diag-os:~# cputool
DellEmc Diag - Cpu Tool
version 1.1, x.xx.x.x-x
build, 2017/05/23,

Syntax: cputool <option>
Show the help-text:=
  cputool --h
  cputool -h
  (or)
Display the CPU info using CPU-ID:
  cputool --cpuid[=--option]
  cputool -i [option]
  (or)
Display the CPU info using x86info:=
  cputool --x86info[=--option]
  cputool -x [option]
  (or)
Read CPU register:=
  cputool --readmsr --cpu=<cpuNumber> --reg=<regOffset>
  cputool -r -n <cpuNumber> -R <regOffset>
  (or)
Write CPU register:=
  cputool --writemsr --cpu=<cpuNumber> --reg=<regOffset> --val=<value>
  cputool -w <cpuNumber> -R <regOffset> -V <value>
  (or)
Execute repeatedly command by count:=
  cputool --iteration=max/<count> [option1] [option2]...
  cputool -I max/<count> [option1] [option2]...
  (or)

```

```

Read the specified register in LPC bus:=
cputool --readlpc --reg=<reg> --size=<size> (or)
cputool -d -R <reg> -Z <size>
Write the specified register in LPC bus:=
cputool --writelpc --reg=<reg> --val=<value> --size=<size> (or)
cputool -W -R <reg> -V <value> -Z <size>

```

```

Usage:=
-h, --h          Show the help text
-i, --cpuid     CPU-Id
-x, --x86info   x86 info
-r, --readmsr   Read operation
-w, --writemsr  Write operation
-n, --cpu=      CPU
-R, --reg=      Register
-V, --val=      Value to be set
-Z, --size=     Size
-I, --iteration= Iteration command execution
-d, --readlpc   Read from LPC bus
-W, --writelpc  Write to LPC bus

```

Output

```

root@dell-diag-os:/# cputool --h
Dell Diag - Cpu Tool
version 1.1, x.xx.x.x
build, 2016/08/12,
Syntax: cputool <option>
Show the help-text:=
cputool --h (or)
cputool -h
Display the CPU info using CPU-ID:
cputool --cpuid[=--option] (or)
cputool -i [option]
Display the CPU info using x86info:=
cputool --x86info[=--option] (or)
cputool -x [option]
Read CPU register:=
cputool --readmsr --cpu=<cpuNumber> --reg=<regOffset> (or)
cputool -r -n <cpuNumber> -R <regOffset>
Write CPU register:=
cputool --writemsr --cpu=<cpuNumber> --reg=<regOffset> --val=<value> (or)
cputool -w <cpuNumber> -R <regOffset> -V <value>
Read the specified register in LPC bus:=
cputool --readlpc --reg=<reg> --size=<size> (or)
cputool -d -R <reg> -Z <size>
Write the specified register in LPC bus:=
cputool --writelpc --reg=<reg> --val=<value> --size=<size> (or)
cputool -W -R <reg> -V <value> -Z <size>
Usage:=
-h, --h          Show the help text
-i, --cpuid     CPU-Id
-x, --x86info   x86 info
-r, --readmsr   Read operation
-w, --writemsr  Write operation
-n, --cpu=      CPU
-R, --reg=      Register
-V, --val=      Value to be set
-Z, --size=     Size
-d, --readlpc   Read from LPC bus
-W, --writelpc  Write to LPC bus
root@dell-diag-os:/#

root@dell-diag-os:/# cputool --x86info
x86info v1.30. Dave Jones 2001-2011
Feedback to <davej@redhat.com>.
Found 4 identical CPUs

```

```
Extended Family: 0 Extended Model: 4 Family: 6 Model: 77 Stepping: 8
Type: 0 (Original OEM)
CPU Model (x86info's best guess): Unknown model.
Processor name string (BIOS programmed): Intel(R) Atom(TM) CPU C2538 @ 2.40GHz
Total processor threads: 4
This system has 1 dual-core processor with hyper-threading (2 threads per core) running at an
estimated 2.40GHz
root@dell-diag-os:/#
```

Configuration file format

There is no configuration file associated with the `cputool`.

eepromtool

To program the type, length, value (TLV) format EEPROMs, use the `eepromtool`. You can also use the `eepromtool` to show all the TLV-formatted EEPROM contents or show specific EEPROM content by specifying the EEPROM type.

Tests

The test option in EEPROM devices allows you to verify the MAC address. Use this test for MAC address consistency.

CLI options

```
DellEmc Diag - Eeprom Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23,

Syntax:= eepromtool <option>
  Display help-text:=
    eepromtool --help (or)
    eepromtool -h
  List the understood TLV codes and names:=
    eepromtool --list (or)
    eepromtool -l
  List all eeprom devices:=
    eepromtool --listdevices (or)
    eepromtool -L
  Dump the PSU eeprom:=
    eepromtool --psueepromdump (or)
    eepromtool -m
  Dump the FAN eeprom:=
    eepromtool --faneepromdump (or)
    eepromtool -F
  Show the EEPROM data:=
    eepromtool --eeprom=<eepromtype> --show (or)
    eepromtool -P <eepromtype> -x
  Reset the EEPROM data:=
    eepromtool --eeprom=<eepromtype> --erase (or)
    eepromtool -P <eepromtype> -e
  Verify the MAC address in system-eeprom and mac-eeprom:=
    eepromtool --eeprom=<eepromtype> --test (or)
    eepromtool -P <eepromtype> -t
  Look up a TLV by code and write the value to stdout:=
    eepromtool --eeprom=<eepromtype> --get <code> (or)
    eepromtool -P <eepromtype> -g <code>
  Execute repeatedly count:=
    eepromtool --iteration=max/<count> [option1] [option2]... (or)
    eepromtool -I max/<count> [option1] [option2]...
```

```
Set a TLV code to a value:=
  eepromtool --eeprom=<eepromtype> --set <code>=<value>,<code>=<value>...(or)
  eepromtool -P <eepromtype> -s <code>=<value>,<code>=<value>...
```

Usage:=

```
-h, --h          Show the help text
-l, --list       List the understood TLV codes and names
-L, --listdevices List all EEPROM devices
-m, --psueepromdump Dump the PSU EEPROM
-F, --faneepromdump Dump the FAN EEPROM
-P, --eeprom=    EEPROM type
-x, --show       Show operation
-e, --erase      Erase operation
-t, --test       Test using the pre-programmed configuration or use supplied config
-I, --iteration= Iteration command execution
-g, --get        Get operation
-s, --set        Set operation
```

Output

```
root@dell-diag-os:/opt/ngos/bin# eepromtool --list
```

```
TLV Code TLV Name
=====
```

```
0x21 Product Name
0x22 Part Number
0x23 Serial Number
0x24 Base MAC Address
0x25 Manufacture Date
0x26 Device Version
0x27 Label Revision
0x28 Platform Name
0x29 Loader Version
0x2a MAC Addresses
0x2b Manufacturer
0x2c Country Code
0x2d Vendor Name
0x2e Diag Version
0x2f Service Tag
0xfd Vendor Extension
0xfe CRC-32
```

```
root@dell-diag-os:/opt/ngos/bin# eepromtool --listdevices
```

```
CPUEEPROM1
CPUEEPROM2
CPUEEPROM3
CPUEEPROM4
CPUEEPROM5
CPUEEPROM6
CPUEEPROM7
CPUEEPROM8
FAN1EEPROM
FAN2EEPROM
FAN3EEPROM
FAN4EEPROM
FAN5EEPROM
SwitchEEPROM
```

```
root@dell-diag-os:/# eepromtool --psueepromdump
```

```
*****PSU1_CountryCode*****
```

```
Registers 0x24a - 0x24b
```

```
CN
```

```
*****PSU1_DellPartNumber*****
```

```
Registers 0x24c - 0x251
```

```
02RPHX
```

```
*****PSU1_MfgID*****
```

```
Registers 0x252 - 0x256
```

```
17972
```

```
*****PSU1_MfgDate*****
```

```
Registers 0x257 - 0x25e
```

```

151117
*****PSU1_SerialNo*****
Registers 0x25f - 0x262
01CG
*****PSU1_ServiceTag*****
Registers 0x263 - 0x269
*****PSU1_LabelRevision*****
Registers 0x26a - 0x26c
A00
*****PSU2_CountryCode*****
Registers 0x283 - 0x284
CN
*****PSU2_DellPartNumber*****
Registers 0x285 - 0x28a
02RPHX
*****PSU2_MfgID*****
Registers 0x28b - 0x28f
17972
*****PSU2_MfgDate*****
Registers 0x290 - 0x297
151117
*****PSU2_SerialNo*****
Registers 0x298 - 0x29b
015F
*****PSU2_ServiceTag*****
Registers 0x29c - 0x2a2
*****PSU2_LabelRevision*****
Registers 0x2a3 - 0x2a5
A00
root@dell-diag-os:/#

root@dell-diag-os:/opt/ngos/bin#
root@dell-diag-os:/opt/ngos/bin# eepromtool --eeprom=cpueeprom2 --set 0x21='cpu2'
Notice: Invalid TLV checksum found. Using default contents.
Adding TLV 0x21: Product Name
Programming passed.
TlvInfo Header:
Id String: TlvInfo
Version: 1
Total Length: 12
TLV Name Code Len Value
-----
Product Name 0x21 4 cpu2
CRC-32 0xFE 4 0x338B2B86
Checksum is valid.
root@dell-diag-os:/opt/ngos/bin#
root@dell-diag-os:/opt/ngos/bin# eepromtool --eeprom=cpueeprom2 --get 0x21
cpu2
root@dell-diag-os:/opt/ngos/bin#
root@dell-diag-os:/opt/ngos/bin# eepromtool --eeprom=cpueeprom2 --show
TlvInfo Header:
Id String: TlvInfo
Version: 1
Total Length: 12
TLV Name Code Len Value
-----
Product Name 0x21 4 cpu2
CRC-32 0xFE 4 0x338B2B86
Checksum is valid.
root@dell-diag-os:/opt/ngos/bin#
root@dell-diag-os:/opt/ngos/bin# eepromtool --eeprom=cpueeprom1 --erase
Programming passed.
EEPROM does not contain data in a valid TlvInfo format.
root@dell-diag-os:/opt/ngos/bin# eepromtool --eeprom=cpueeprom1 --show
Notice: Invalid TLV header found. Using default contents.
Notice: Invalid TLV checksum found. Using default contents.
TlvInfo Header:
Id String: TlvInfo
Version: 1

```

```
Total Length: 6
TLV Name Code Len Value
-----
CRC-32 0xFE 4 0xD4431C18
Checksum is valid.
root@dell-diag-os:/opt/ngos/bin#
```

Configuration file format

The eeprom devices display under the corresponding i2c bus number. Whenever you add a new EEPROM to the bus number, the number of devices in each bus number updates. Each eeprom field is separated by the '|' character. The order of the fields is:

- 1 Name of the EEPROM. Provides the same name at the eeprom option in the eepromtool.
- 2 The bus to which the EEPROM connects.
- 3 The i2c path of the EEPROM. If a MUX is present, the MUX address, offset, and value are separated by colons.
- 4 The i2c address of the EEPROM.
- 5 Specifies if the device is a 16-bit address access.
- 6 Byte count to read or write.
- 7 Specifies the format of the data in the eeprom as tlv or flat.
- 8 Write protect register, if applicable.
- 9 Write protect register mask.
- 10 Bus Return to Normal — Any bus configurations needed to return the bus to a valid setting. If you need any MUX settings, they are listed as address : register : mask : value. Each successive MUX setting is separated with a :, :

```
CONTROL_CONFIG | 1
#Control Config | method | <Mux Selection> | <Address> | <Register> | <Take Control> | <Release Control>
I2C Device Flag | lpc | - | 0 | 0x04D8 | 0x210 | 0x211 | 0x212 | 0x213 | 0x55 |
0xAA | 0x5A | 0xA5
Eeprom devices with tlv format found on bus #0: 0
Eeprom devices with tlv format found on bus #1: 15
IDEEPROM | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x50|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM1 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x50|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM2 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x51|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM3 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x52|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM4 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x53|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM5 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x54|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM6 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x55|0x00|1|tlv|lpc|0|0x220|0|1|-|-
CPUEEPROM7 | /dev/i2c-1|/dev/i2c-1 0x70:0x0:0xff:0x8|0x56|0x00|1|tlv|lpc|0|0x220|0|1|-|-
```

NOTE: (Optional) For systems that use the SmartFusion chip, the eepromtool also has two companion configuration files — default_mailbox_eeprom.cfg which holds information for the --psueepromdump command, and default_fan_mailbox_eeprom.cfg which holds information for the --faneepromdump command.

ethtool

The ethtool provides management interface details.

fantool

The fantool tests the fans in the system, sets and reports the fan speeds and the fan tray field replaceable unit (FRU) registers.

The fantool also reports the airflow direction of the fans. The psutool command controls the PSU fans.

Tests

The `fantool` tests the fans by setting them to different speeds and then verifying the configured fan speeds.

Registers and values are passed as hexadecimal values with or without the preceding `0x`. Fans display from 1 to Max System Fans.

CLI options

```
DellEmc Diag - Fan Controller Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23

Syntax: fantool <option>
Show the help-text:=
    fantool --h                                (or)
    fantool -h
Initialize the fans to the default state:=
    fantool --init                              (or)
    fantool -i
Test using the Fan Controller config file:=
    fantool --test [--fan=<fan>] [--lpc]        (or)
    fantool -t [-F <fan>] [-l]
Get the speed of the specified fan or all fans in RPM:=
    fantool --get --fan=<fan | all> [--lpc]     (or)
    fantool -g -F <fan | all> [-l]
Set the fan(s) to the speed:=
    fantool --set --fan=<fan | all> --speed=<speed in RPM> (or)
    fantool -s -F <fan | all> -S <speed in RPM>
Execute repeatedly command by count:=
    fantool --iteration=max/<count> [option1] [option2]... (or)
    fantool -I max/<count> [option1] [option2]...
Read the Register from the fan controller:=
    fantool --read --fan=<fan | all> --reg=<register | all> (or)
    fantool -r -F <fan | all> -R <register | all>
Write the Register in the Fan Controller:=
    fantool --write --fan=<fan | all> --reg=<register> --val=<value> (or)
    fantool -w -F <fan | all> -R <register> -V <value>

Usage:=
-h, --h                Show the help text
-i, --init             Initilize to default
-t, --test             Test using the pre-programmed configuration or use supplied config
-g, --get              Get operation
-s, --set              Set operation
-r, --read             Read operation
-w, --write            Write operation
-I, --iteration=       Iteration command execution
-F, --fan=             Fan Id
-R, --register=        Register
-V, --val=             Value to be set
-S, --speed=          Speed of the fan
-q, --lpc              Test by reading or modifying SmartFusion registers.
                       When this flag is used, it must be clubbed with one of above flags

*Registers and Values are passed as Hexadecimal values with or without the preceding 0x.
*Fans are from 1 to Max System Fans.
```

The `fantool` uses long options which requires two hyphens in front of the options. Options are required, optional, or none. If you require a parameter, specify it and include an equal sign. If a parameter is optional, enclose it with square brackets to show that it is optional, but do not type the brackets at the CLI. For example, `--fan` is optional and enter it as `--fan=1` or `--fan=all`, and so forth. Parameters with

angle brackets are required but have multiple options for the input. Do not type the angle brackets or the vertical line character in the CLI. Only use one option per command; for example, `--fan=1` or `--fan=all`.

- `test` — Runs through the speeds for the fan, from highest to lowest, and checks that the fan can run at the speeds of the test. If a single fan is listed on the CLI, that fan is tested. If you use the `all` option, all fans are tested. The number in the parentheses during the test is the speed the system tries to reach during the test. If a fan cannot reach the desired speed within an acceptable range after 10 checks, the fan fails for that speed and the system moves on to the next fan.
- `get` — Gets the speed of the fan and returns it in the rate process module (RPM).
- `set` — Sets the speed of the fan in the RPM.

NOTE: Commonly, fan speeds are in two registers and must be written in a specific order. The `write` command cannot change the fan speeds; use the `set` command.

Output

test output

```
root@dell-diag-os:~# fantool --test --lpc
Fan Controller Test LPC.....
Max number of Fan Trays in the System : 5
Number of fans per tray : 2
Max Fan Speed set(PWM): 255
Getting Details for Fan 1
Fan 1 is Present
Fan 1 Air flow type is Front To Rear
Fan 1 status Normal
Fan 1 speed is 8420 RPM
Getting Details for Fan 2
Fan 2 is Present
Fan 2 Air flow type is Front To Rear
Fan 2 status Normal
Fan 2 speed is 8738 RPM
Getting Details for Fan 3
Fan 3 is Present
Fan 3 Air flow type is Front To Rear
Fan 3 status Normal
Fan 3 speed is 8474 RPM
Getting Details for Fan 4
Fan 4 is Present
Fan 4 Air flow type is Front To Rear
Fan 4 status Normal
Fan 4 speed is 8757 RPM
Getting Details for Fan 5
Fan 5 is Present
Fan 5 Air flow type is Front To Rear
Fan 5 status Normal
Fan 5 speed is 8492 RPM
Getting Details for Fan 6
Fan 6 is Present
Fan 6 Air flow type is Front To Rear
Fan 6 status Normal
Fan 6 speed is 8777 RPM
Getting Details for Fan 7
Fan 7 is Present
Fan 7 Air flow type is Front To Rear
Fan 7 status Normal
Fan 7 speed is 8348 RPM
Getting Details for Fan 8
Fan 8 is Present
Fan 8 Air flow type is Front To Rear
Fan 8 status Normal
Fan 8 speed is 8585 RPM
```

```

Getting Details for Fan 9
Fan 9 is Present
Fan 9 Air flow type is Front To Rear
Fan 9 status Normal
Fan 9 speed is 8420 RPM
Getting Details for Fan 10
Fan 10 is Present
Fan 10 Air flow type is Front To Rear
Fan 10 status Normal
Fan 10 speed is 8566 RPM
Fan Controller Test LPC..... Passed
root@dell-diag-os:~#

root@dell-diag-os:~# fantool --get --lpc
Fan 1 speed is 8420 RPM
Fan 2 speed is 8757 RPM
Fan 3 speed is 8474 RPM
Fan 4 speed is 8738 RPM
Fan 5 speed is 8474 RPM
Fan 6 speed is 8757 RPM
Fan 7 speed is 8366 RPM
Fan 8 speed is 8604 RPM
Fan 9 speed is 8420 RPM
Fan 10 speed is 8566 RPM
[2]+ Done dhclient -q eth0
root@dell-diag-os:~#

root@dell-diag-os:~# fantool --get --fan=2 --lpc
Fan 2 speed is 8738 RPM
root@dell-diag-os:~#

```

Configuration file format

This example output is for platforms that do not have a SMF chip.

```

0 | Fan 1 | EMC2305 | /dev/i2c-1 | 0x4d | 0 | /dev/i2c-1 0x70:0x00:0xff:0x2 | Fan Tray 1 | 4 |
2 | /dev/i2c-1 | 0x51 | /dev/i2c-1 0x70:0x00:0xff:0x2
1 | Fan 2 | EMC2305 | /dev/i2c-1 | 0x4d | 1 | /dev/i2c-1 0x70:0x00:0xff:0x2 | Fan Tray 2 | 4 |
2 | /dev/i2c-1 | 0x51 | /dev/i2c-1 0x70:0x00:0xff:0x2
2 | Fan 3 | EMC2305 | /dev/i2c-1 | 0x4d | 2 | /dev/i2c-1 0x70:0x00:0xff:0x2 | Fan Tray 3 | 4 |
2 | /dev/i2c-1 | 0x52 | /dev/i2c-1 0x70:0x00:0xff:0x2
3 | Fan 4 | EMC2305 | /dev/i2c-1 | 0x4d | 3 | /dev/i2c-1 0x70:0x00:0xff:0x2 | Fan Tray 4 | 4 |
2 | /dev/i2c-1 | 0x52 | /dev/i2c-1 0x70:0x00:0xff:0x2
0 | Fan 5 | EMC2305 | /dev/i2c-1 | 0x4d | 0 | /dev/i2c-1 0x70:0x00:0xff:0x8 | Fan Tray 1 | 4 |
2 | /dev/i2c-1 | 0x51 | /dev/i2c-1 0x70:0x00:0xff:0x2
1 | Fan 6 | EMC2305 | /dev/i2c-1 | 0x4d | 1 | /dev/i2c-1 0x70:0x00:0xff:0x8 | Fan Tray 2 | 4 |
2 | /dev/i2c-1 | 0x51 | /dev/i2c-1 0x70:0x00:0xff:0x2
2 | Fan 7 | EMC2305 | /dev/i2c-1 | 0x4d | 2 | /dev/i2c-1 0x70:0x00:0xff:0x8 | Fan Tray 3 | 4 |
2 | /dev/i2c-1 | 0x52 | /dev/i2c-1 0x70:0x00:0xff:0x2
3 | Fan 8 | EMC2305 | /dev/i2c-1 | 0x4d | 3 | /dev/i2c-1 0x70:0x00:0xff:0x8 | Fan Tray 4 | 4 |
2 | /dev/i2c-1 | 0x52 | /dev/i2c-1 0x70:0x00:0xff:0x2
=====
0 | 7 | 8000 | 10000 | 15000 | 16000 | 13000

```

This example output shows if an LPC device such as a field programmable gate array (FPGA) controls the fans.

```

D - Data Description
# - The zero based number for this fan
Description - The Readable fan description
Presence Bit Mask
Register Offset
Status Bit Mask
Airflow Bitmask
Speed Register Offset
Speed Register Size

```

```
R - Register description
  Offset of Register
  Size in bytes
  Register Name
```

The example output shows MUX information when accessing the LPC and the timeout value.

```
#D | id | Device | Presence bit Mask | Status Register Offset | Status bit Mask
| Air Flow bitmask | Speed register offset
#R | NAME | Offset | Size in bytes
LPC-INTERFACE
D | 0 | Fan 1 | 0x01 | 0x115 | 0x01 | 0x01 | 0xF3 | 2
D | 1 | Fan 2 | 0x01 | 0x115 | 0x02 | 0x01 | 0xF5 | 2
D | 2 | Fan 3 | 0x02 | 0x115 | 0x04 | 0x02 | 0xF7 | 2
D | 3 | Fan 4 | 0x02 | 0x115 | 0x08 | 0x02 | 0xF9 | 2
D | 4 | Fan 5 | 0x04 | 0x115 | 0x10 | 0x04 | 0xFB | 2
D | 5 | Fan 6 | 0x04 | 0x115 | 0x20 | 0x04 | 0xFD | 2
D | 6 | Fan 7 | 0x08 | 0x115 | 0x40 | 0x08 | 0xFF | 2
D | 7 | Fan 8 | 0x08 | 0x115 | 0x80 | 0x08 | 0x101 | 2
D | 8 | Fan 9 | 0x10 | 0x114 | 0x01 | 0x10 | 0x103 | 2
D | 9 | Fan 10 | 0x10 | 0x114 | 0x02 | 0x10 | 0x105 | 2
R | 0xF0 | 1 | Fan Tray Count Register
R | 0xF1 | 1 | Fan Count Per Fan Tray Register
R | 0xF2 | 1 | Max Fan Speed Set Register
R | 0x113 | 1 | Fan Tray Presence Register
R | 0x116 | 1 | Fan Tray Air Flow Register
/dev/i2c-1 0x70:0:0xff:0x9:,:0x74:1:0xff:0xa
1500000
```

flashrom

To update or erase the BIOS flash memory, the `smbiostool` uses `flashrom`.

gpiotool

The `gpiotool` controls the state of the GPIO lines from the CPU or any other device that drives the GPIO lines.

The CPU GPIO lines map in Linux to `/sys/class/gpio` entries, which are manipulated through the standard read/write interfaces. There is chip numbering to support multiple GPIO chips, or chips at an offset. For devices such as the complex programmable logic device (CPLD) or field programmable gate arrays (FPGA), `gpiotool` accesses those devices to drive the GPIO lines using the standard bus interfaces such as `i2c`, `mem`, or `pci`.

CLI options

```
DellEmc Diag - GPIO Tool
version 1.4, x.xx.x.x-x
build, 2017/05/23,
```

Syntax: `gpiotool <option>`

Show the help-text:=

```
gpiotool --h (or)
gpiotool -h
```

List available gpio chips and pins:=

```
gpiotool --list (or)
gpiotool -l
```

Set GPIO pin:=

```
gpiotool --set [--chip=<chip>] --pin=<pin> --val=<value> (or)
gpiotool -s [-c <chip>] -H <pin> -V <value>
```

Get GPIO pins value:=

```
gpiotool --get [--chip=<chip>] [--pin=<pin>] (or)
gpiotool -g [-c <chip>] [-H <pin>]
```

Execute repeatedly command by count:=

```
gpiotool --iteration=max/<count> [option1] [option2]... (or)
gpiotool -I max/<count> [option1] [option2]...
```

Usage:=

```
-h, --h          Show the help text
-l, --list       List the understood TLV codes and names
-s, --set        Set operation
-g, --get        Get operation
-c, --chip=      GPIO chip
-I, --iteration= Iteration command execution
-H, --pin=       GPIO pin number
-V, --val=       Value to be set
```

Output

list output

```
root@dell-diag-os:~# gpiotool --list
Chip 0 Core Gpio bits: 60 CORE gpiochip196
=====
Bit          Name      Dir  AC  Value
=====
15          SATA_GP0    IN   LOW  0
16          SATA_LEDN   OUT  LOW  0
17          SATA3_GP0   IN   LOW  0
19          FLEX_CLK_SE0 IN   LOW  0
20          FLEX_CLK_SE1 IN   LOW  0
32          GPIO_SUS1   IN   LOW  0
33          GPIO_SUS2   OUT  LOW  0
34          CPU_RESET_B OUT  LOW  0
36          PMU_SUSCLK  OUT  LOW  0
37          PMU_SLP_DDRVTT_B IN  LOW  0
38          PMU_SLP_LAN_B IN  LOW  0
39          PMU_WAKE_B  OUT  LOW  0
40          PMU_PWRBTN_B IN  LOW  0
49          GBE_SDP0_1  IN  LOW  0
50          GBE_LED0    IN  LOW  0
51          GBE_LED1    IN  LOW  0
52          GBE_LED2    IN  LOW  0
53          GBE_LED3    IN  LOW  0
54          NCSI_RXD1   OUT  LOW  0
55          GBE_MDIO0_I2C_CLK OUT  LOW  0
58          GBE_MDIO1_I2C_DATA IN  LOW  0
59          JTAG_TRST   OUT  LOW  0
root@dell-diag-os:~#
```

get output

```
root@dell-diag-os:~# gpiotool --get --pin=1
Chip 0 Core Gpio bits: 60 CORE gpiochip196
=====
Bit          Name      Dir  Value
=====
```

set output

```
root@amazon:/opt/ngos/bin# ./gpiotool --set --pin=1 --val=1
```

Configuration file format

GPIOs are separated into groups within the configuration file, such as Core GPIOs and Suspend GPIOs (if they use different power wells for sleep operations).

Any line starting with a # is a comment. ===== is the separator between groups.

A group starts with a header using | separators and:

- # of bits defined in the GPIO interface (a hardware definition, not the number of bits being defined in the config file.)
- A name for the bit group, such as Core GPIO or SUS GPIO.
- Group Type — CORE.
- Any bus used to access the GPIO. For the CPLD-based or FPGA-based GPIOs.
- The address to use to access the GPIO. For the CPLD-based or FPGA-based GPIOs.
- All the GPIOs are zero-based in a group. The 0 map is the offset to access /sys/class/gpio/gpio# in the sysfs.

Each bit is then defined on its own line separated with | and includes the bit number, name, direction, active level, and default value.

```
#bits | Name | intf | bus | addr | 0-map
60 | Core Gpio | CORE | - | - | 196
# Bit | Name | Direction | Value
15 | SATA_GP0 | IN | LOW | 0
16 | SATA_LEDN | OUT | LOW | 0
17 | SATA3_GP0 | IN | LOW | 0
19 | FLEX_CLK_SE0 | IN | LOW | 0
20 | FLEX_CLK_SE1 | IN | LOW | 0
32 | GPIO_SUS1 | IN | LOW | 0
33 | GPIO_SUS2 | OUT | LOW | 0
34 | CPU_RESET_B | OUT | LOW | 0
36 | PMU_SUSCLK | OUT | LOW | 0
37 | PMU_SLP_DDRVTT_B | IN | LOW | 0
38 | PMU_SLP_LAN_B | IN | LOW | 0
39 | PMU_WAKE_B | OUT | LOW | 0
40 | PMU_PWRBTN_B | IN | LOW | 0
49 | GBE_SDP0_1 | IN | LOW | 0
50 | GBE_LED0 | IN | LOW | 0
51 | GBE_LED1 | IN | LOW | 0
52 | GBE_LED2 | IN | LOW | 0
53 | GBE_LED3 | IN | LOW | 0
54 | NCSI_RXD1 | OUT | LOW | 0
```

i2ctool

The `i2ctool` allows for scanning, reading, and writing of the I2C bus devices.

To read and write to devices on the i2c bus, use the `i2ctool`. The `i2ctool` also scans the i2c busses and reports what devices are found. The scan reads address 0x0 from all the devices in the address range of 0x0 to 0x7f on all i2c busses present. The `i2ctool` does not automatically traverse MUXes along the i2c bus. Other tools use this tool to read i2c device information and pass the results back through a named pipe.

Tests

To test, the `i2ctool` has a configuration file that lists all the devices on the busses. The tool runs through the list and tries to reach the devices. The `i2ctool` reports when a device is not returning data.

CLI options

DellEmc Diag - I2C Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23,

Syntax: i2ctool <option>

To Scan the (Specific) I2C devices:=
i2ctool --scan [--bus=/dev/i2c-
<bus_number>]

(or)

i2ctool -n [-b /dev/i2c-<bus_number>]

To Test the pre-programmed configuration or from config file:=

i2ctool --test [--
config=<config_file_name>]

(or)

i2ctool -t [-f <config_file_name>]

Execute repeatedly command by count:=

i2ctool --iteration=max/<count> [option1]
[option2]...

(or)

i2ctool -I max/<count> [option1] [option2]...

Read:=

i2ctool --read --bus=/dev/i2c-<bus_number> --addr=<address> --reg=<register> --
count=<count> --width=<width> --display_size=<display_size> (or)

i2ctool -r -b /dev/i2c-<bus_number> -a <address> -R <register> -C <count> -W <width> -D
<display_size>

Read(16 bit addressing):=

i2ctool --read --bus=/dev/i2c-<bus_number> --addr=<address> --reg16=<register(16bit)>
[--reg_le] --count=<count> --width=<width> --display_size=<display_size> (or)

i2ctool -r -b /dev/i2c-<bus_number> -a <address> -o <register(16bit)> [-L] -C <count> -
W <width> -D <display_size>

Write:=

i2ctool --write --bus=/dev/i2c-<bus_number> --addr=<address> --reg=<register> --
width=<width> --val=<value> (or)

i2ctool -w -b /dev/i2c-<bus_number> -a <address> -R <register> -W <width> -V <value>

Write(16 bit addressing):=

i2ctool --write --bus=/dev/i2c-<bus_number> --addr=<address> --reg16=<register(16bit)>
[--reg_le] --val=<value> (or)

i2ctool -w -b /dev/i2c-<bus_number> -a <address> -o <register(16bit)> [-L] -V <value>

Usage:

-h, --h	Show the help text
-n, --scan	Scan operation
-t, --test	Test using the pre-programmed configuration or use supplied config
-r, --read	Read operation
-w, --write	Write operation
-f, --config=	To specify the location of the config file e.g. /etc/dn/diag/<file_name>
-C, --count=	Count
-R, --reg=	Register
-o, --reg16=	Register(16 bit addressing)
-V, --val=	Value to be set
-W, --width=	Width {8,16}
-b, --buspath=	To specify the i2c bus e.g.: /dev/i2c-<bus number>
-a, --addr=	Address
-D, --display_size=	Display size, {1,2,4} of bytes
-I, --iteration=	Iteration command execution

Output

NOTE: The `i2ctool` does not automatically scan multiple MUXed segments. Before scanning, you MUST set the MUXes to select the devices you want to see on the busses. By default, the `i2ctool` scans the `i2c` devices from the root MUX where it sees the list of devices directly connected to the CPU MUX. The default scan function scans all connected busses. By specifying a bus, you can limit the scan to one bus. In the scan data, `RR` indicates a reserved address which is not used for any devices and `UU` indicates that the device is busy or mapped to the OS.

scan Output

```
root@dell-diag-os:/etc/dn/diag# i2ctool --scan
  0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00: RR RR RR RR RR RR RR RR -- -- -- -- -- -- -- --
10: -- -- -- -- -- -- -- -- 18 -- 1a -- -- -- -- --
20: -- -- -- -- -- -- -- -- -- -- -- -- -- -- 2e --
30: 30 -- 32 -- -- -- -- -- -- -- -- -- -- -- -- --
40: -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
50: 50 -- 52 -- -- -- -- -- -- -- -- -- -- -- -- --
60: -- -- -- -- -- -- -- -- -- -- 69 -- -- -- -- --
70: -- -- -- -- -- -- -- -- RR RR RR RR RR RR RR RR
  0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00: RR RR RR RR RR RR RR RR -- -- -- -- -- -- -- --
10: -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
20: -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
30: -- -- -- -- -- -- -- -- -- -- -- -- -- -- 3e --
40: -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
50: 50 51 52 53 54 55 56 57 -- -- -- -- -- -- -- --
60: -- -- -- -- -- -- -- -- -- -- -- -- -- -- -- --
70: 70 -- -- -- -- -- -- -- -- RR RR RR RR RR RR RR RR
I2C devices found on bus #0: 8
0x18 0x1a 0x2e 0x30 0x32 0x50 0x52 0x69
I2C devices found on bus #1: 10
0x3e 0x50 0x51 0x52 0x53 0x54 0x55 0x56
0x57 0x70
root@dell-diag-os:/etc/dn/diag#
```

test Output

```
root@dell-diag-os:/etc/dn/diag# i2ctool --test
Testing I2C devices:
Checking I2C devices on bus 0:
+ Checking Clock GEN          0x69 ..... Passed
+ Checking SPD0                0x50 ..... Passed
Checking I2C devices on bus 1:
+ Checking CPU Board I2C Mux   0x70 ..... Passed
+ Checking CPU Board EEPROM1   0x53 ..... Passed
+ Checking CPU Board EEPROM2   0x57 ..... Passed
+ Checking Switch Brd EEPROM   0x50 ..... Passed
+ Checking CPLD2                0x3e ..... Passed
+ Checking CPLD3                0x3e ..... Passed
+ Checking CPLD4                0x3e ..... Passed
+ Checking SFP+ 1               0x50 ..... Passed
+ Checking SFP+ 2               0x50 ..... Passed
+ Checking SFP+ 3               0x50 ..... Passed
+ Checking SFP+ 4               0x50 ..... Passed
+ Checking SFP+ 5               0x50 ..... Passed
+ Checking SFP+ 6               0x50 ..... Passed
+ Checking SFP+ 7               0x50 ..... Passed
+ Checking SFP+ 8               0x50 ..... Passed
```

```

+ Checking SFP+ 9          0x50 ..... Passed
+ Checking SFP+ 10         0x50 ..... Passed
+ Checking SFP+ 11         0x50 ..... Passed
+ Checking SFP+ 12         0x50 ..... Passed
+ Checking SFP+ 13         0x50 ..... Passed
+ Checking SFP+ 14         0x50 ..... Passed
+ Checking SFP+ 15         0x50 ..... Passed
+ Checking SFP+ 16         0x50 ..... Passed
+ Checking SFP+ 17         0x50 ..... Passed
+ Checking SFP+ 18         0x50 ..... Passed
+ Checking SFP+ 19         0x50 ..... Passed
+ Checking SFP+ 20         0x50 ..... Passed
+ Checking SFP+ 21         0x50 ..... Passed
+ Checking SFP+ 22         0x50 ..... Passed
+ Checking SFP+ 23         0x50 ..... Passed
+ Checking SFP+ 24         0x50 ..... Passed
+ Checking SFP+ 25         0x50 ..... Passed
+ Checking SFP+ 26         0x50 ..... Passed
+ Checking SFP+ 27         0x50 ..... Passed
+ Checking SFP+ 28         0x50 ..... Passed
+ Checking SFP+ 29         0x50 ..... Passed
+ Checking SFP+ 30         0x50 ..... Passed
+ Checking SFP+ 31         0x50 ..... Passed
+ Checking SFP+ 32         0x50 ..... Passed
+ Checking SFP+ 33         0x50 ..... Passed
+ Checking SFP+ 34         0x50 ..... Passed
+ Checking SFP+ 35         0x50 ..... Passed
+ Checking SFP+ 36         0x50 ..... Passed
+ Checking SFP+ 37         0x50 ..... Passed
+ Checking SFP+ 38         0x50 ..... Passed
+ Checking SFP+ 39         0x50 ..... Passed
+ Checking SFP+ 40         0x50 ..... Passed
+ Checking QSFP+ 41        0x50 ..... Passed
+ Checking QSFP+ 42        0x50 ..... Passed
+ Checking QSFP28 43       0x50 ..... Passed
+ Checking QSFP28 44       0x50 ..... Passed
+ Checking QSFP28 45       0x50 ..... Passed
+ Checking QSFP28 46       0x50 ..... Passed
+ Checking QSFP28 47       0x50 ..... Passed
+ Checking QSFP28 48       0x50 ..... Passed
I2C Devices: Overall test results ----- >>> Passed
root@dell-diag-os:/etc/dn/diag#

```

read Output

```

/opt/ngos/bin# ./i2ctool --read --bus=/dev/i2c-1 --addr=0x50 --reg=0 --count=256
0x92 0x13 0x0b 0x08 0x04 0x21 0x02 0x09 0x0b 0x11 0x01 0x08 0x0c 0x00 0x7e 0x00
0x69 0x78 0x69 0x30 0x69 0x11 0x20 0x89 0x20 0x08 0x3c 0x3c 0x00 0xf0 0x83 0x05
0x80 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x85 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x0f 0x11 0x23 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x80 0x2c 0x0f 0x13 0x35 0xe9 0x8d 0xe0 0xbb 0x80 0x50
0x31 0x38 0x4b 0x53 0x46 0x31 0x47 0x37 0x32 0x48 0x5a 0x2d 0x31 0x47 0x34 0x45
0x32 0x20 0x45 0x32 0x80 0x2c 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff
0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff
0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff
0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff 0xff

```


write Output

```
/opt/dell/diag/bin# ./i2ctool --write --bus=/dev/i2c-2 --addr=0x48 --reg=0x14 --val=1
```

Configuration file format

The configuration file format for the i2c busses is strict. Use `i2ctool --create` to create a boilerplate configuration file and editing the boilerplate configuration file rather than creating it from scratch.

The configuration file lists each bus from 0 to 4 and the devices. The number of devices MUST match the number of entries or the `i2ctool` stops functioning. If you edit out a device or add a device, you must adjust the number of devices found.

Each device is listed on its own line for that bus in comma-separated format:

```
Name
mux bus
mux level 1 setting in the format of address:value
mux level 2 setting in the format of address:value
device address
Register we can read from
byte count
```

For example:

```
#I2C devices found on bus #<Bus Number>: <Number of Devices>
#Device Name|Bus|Mux1 Address|Mux2 Address|Device Address|Offset|Count
#If device is not connected with Mux| " x " needed.
I2C devices found on bus #0: 2
Clock GEN          | /dev/i2c-0| - |0x69|0x00|1
SPD0               | /dev/i2c-0| - |0x50|0x00|1
I2C devices found on bus #1: 55
CPU Board I2C Mux  | /dev/i2c-1| - |0x70|0x00|1
CPU Board EEPROM1  | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0x8|0x53|0x00|1
CPU Board EEPROM2  | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0x8|0x57|0x00|1
Switch Brd EEPROM | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0xa:, :0x71:0x1:0xff:0xx
1|0x50|0x00:0x10|1
#TobeAdded - QUMRAN
#TobeAdded - TCAM
#TobeAdded - DPLL
CPLD2              | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0xa:, :0x71:0x10:0xff:00
x10|0x3e|0x00:0x10|1
CPLD3              | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0xa:, :0x71:0x20:0xff:00
x20|0x3e|0x00:0x10|1
CPLD4              | /dev/i2c-1| /dev/i2c-1 0x70:0x0:0xff:0xa:, :0x71:0x40:0xff:00
x40|0x3e|0x00:0x10|1 GE TMP , /dev/i2c-2, 0x70:0x0:0x9:0x74:0x1:0xb:
0x73:0x0:0x0:0x72:0x40:0x40, 0x4a, 0x00, 1
3.2.9 Ledtool
```

ledtool

The `ledtool` allows you to control the state of the front and back panel light emitting diodes (LEDs). ASIC and Phys control the port LEDs and are beyond the scope of this tool.

You can manually control the front and back panel LEDs normally controlled through the CPLD or FPGA access. When set, bits in these registers control the state of the LED.

Tests

To test the LEDs, use the `ledtool --test` command.

```
root@dell-diag-os:/opt/ngos/bin# ./ledtool --test
LED Test Started... Will take few mins to complete.
LED Tool: Overall test results ----- >>> Passed
```

CLI options

DellEmc Diag - Led Tool
version 1.0, x.xx.x.x-x
build, 2017/05/23,

Usage:

```
List the LEDs:=
  ledtool --list                               (or)
  ledtool -l
Get the state of (specific) LED(s):=
  ledtool --get [--led=<led>]                 (or)
  ledtool -g [-D <led>]
Set the state of specific LED(color and blink):=
  ledtool --set --led=<led> [--instance=<instance>] [--state=<state> | --val=<value>} (or)
  ledtool -s -D <led> [-I <instance>] {-T <state> | -V <value>}
Execute repeatedly command by count:=
  ledtool --iteration=max/<count> [option1] [option2]... (or)
  ledtool -I max/<count> [option1] [option2]...
Test using config file:=
  ledtool --test [--config=<config_file>]      (or)
  ledtool -t [-f <config_file>]
```

Syntax: ledtool <option>

```
-h, --h                Show the help text
-l, --list             List the LEDs
-g, --get              Get operation
-s, --set              Set operation
-t, --test             Test using the pre-programmed configuration or use supplied config
-D, --led=            LED
-I, --iteration=      Iteration command execution
-S, --instance=,      Instance
-T, --state=,         State of the LED
-V, --val=,           Value to be set
-f, --config=,        To specify the location of the config file e.g. /etc/dn/diag/<file_name>
```

[led] selections are:

```
Power
States: green amber flashing-amber off
System
States: amber flashing-green flashing-amber green
Fan
States: green flashing-amber off
Beacon
States: flashing-blue off
CPLD2-Mode
States: normal-mode test-mode
Port#1-18-Amber
States: off flashing-amber-fast amber flashing-amber
Port#1-18-Green
States: off flashing-green-fast green flashing-green
CPLD3-Mode
States: normal-mode test-mode
Port#19-36-Amber
```

```
States: off flashing-amber-fast amber flashing-amber
Port#19-36-Green
States: off flashing-green-fast green flashing-green
CPLD4-Mode
States: normal-mode test-mode
Port#37-48-Amber
States: off flashing-amber-fast amber flashing-amber
Port#37-48-Green
States: off flashing-green-fast green flashing-green
```

Output

list output

```
root@dell-diag-os:/etc/dn/diag# ledtool --list
Power Led : options
    green amber flashing-amber off
System Led : options
    amber flashing-green flashing-amber green
Fan Led : options
    green flashing-amber off
Beacon LED : options
    flashing-blue off
Ports 1-18 PortLED Mode : options
    normal-mode test-mode
Ports 1-18 FrontEnd AmberLed : options
    off flashing-amber-fast amber flashing-amber
Ports 1-18 FrontEnd GreenLed : options
    off flashing-green-fast green flashing-green
Ports 19-36 PortLED Mode : options
    normal-mode test-mode
Ports 19-36 FrontEnd AmberLed : options
    off flashing-amber-fast amber flashing-amber
Ports 19-36 FrontEnd GreenLed : options
    off flashing-green-fast green flashing-green
Ports 37-48 PortLED Mode : options
    normal-mode test-mode
Ports 37-48 FrontEnd AmberLed : options
    off flashing-amber-fast amber flashing-amber
Ports 37-48 FrontEnd GreenLed : options
    off flashing-green-fast green flashing-green
root@dell-diag-os:/etc/dn/diag#
```

get Output

```
root@dell-diag-os:/etc/dn/diag# ledtool --get
Power Led : flashing-amber
System Led : flashing-green
Fan Led : green
Beacon LED : off
Ports 1-18 PortLED Mode : normal-mode
Ports 1-18 FrontEnd AmberLed : off
Ports 1-18 FrontEnd GreenLed : off
Ports 19-36 PortLED Mode : normal-mode
Ports 19-36 FrontEnd AmberLed : off
Ports 19-36 FrontEnd GreenLed : off
Ports 37-48 PortLED Mode : normal-mode
Ports 37-48 FrontEnd AmberLed : off
Ports 37-48 FrontEnd GreenLed : off
root@dell-diag-os:/etc/dn/diag#
```

Configuration file format

```
CONTROL_CONFIG | 2
#Control Config | method | <Mux Selection> | <Address> | <Register> | <Take Control> | <Release Control>
I2C Device Flag | lpc | - | 0 | 0x04D8 | 0x210 | 0x211 | 0x212 | 0x213 | 0x55 | 0xAA | 0x5A | 0xA5
Led Control Flag | lpc | - | 0 | 0x04Dc | 0x210 | 0x211 | 0x212 | 0x213 | 0x55 | 0xAA | 0x55 | 0xAA
[Power]
  Power Led | lpc | - | 0 | 0x130
[green]
  1 | 5:4 | 0
[/green]
[amber]
  1 | 5:4 | 1
[/amber]
[flashing-amber]
  1 | 5:4 | 2
[/flashing-amber]
[off]
  1 | 5:4 | 3
[/off]
[/Power]
```

The ledtool config file is in a more xml style format

Each entity is specified in a [entity] tag format and closed with a [\entity] tag

Each entity is the listed the following in a '|' seperated list:

Name of the Led - this is the name that is printed in dany access to the led. the entity is the name used to access the led

bus to access the led - this can be lpc, mem or /dev/i2c-bus number

address - Address of the access to control the led

Register - the register to access to control the led

Next is a display of the state entities for this LED display. The state can be colors, on or off, or even color-blinks. XML-style tags on separate lines also specify the state entity. The data displays in a | separated list as:

- Number of instances — For normal LEDs, the instance is 1, but for fans, the instance can be more than 1.
- Bit ranges — The bit number or the range of bits from low to high contiguous bits. If you need spread bits, use multiple settings within the state tag.
- Value — The value to write to this bit or set of bits.

lpctool

To access devices on the LPC bus, use the lpctool.

The lpctool allow access on the LPC bus by using I/O transactions at the processor level. This access does not include LPC interfaces in other devices. Other DiagOS tools use lpctool to read LPC-connected registers.

CLI options

```
DellEmc Diag - LPC Tool
version 1.0, x.xx.x.x-x
build, 2017/05/23,
```

Syntax: lpctool <option>

Show the help-text:=

lpctool --h

lpctool -h

(or)

Read the specified address:=

```

lpctool --read --addr=<address> --count=<number_of_bytes> [--size=<b,w or l>] (or)
lpctool -r -a <address> -C <number_of_bytes> [-z <b,w or l>]
Write data at the specified address:=
lpctool --write --addr=address --val=data [--size=b,w or l] (or)
lpctool -w -a <address> -V <data> [-z <b,w or l>]
Execute repeatedly command by count:=
lpctool --iteration=max/<count> [option1] [option2]... (or)
lpctool -I max/<count> [option1] [option2]...
Usage:=
-h, --h          Show the help text
-w, --write     Write operation
-r, --read      Read operation
-z, --size=     Size
-I, --iteration= Iteration command execution
-C, --count=    Count
-a, --addr=     Address

```

Output

read Output

```

root@dell-diag-os:/opt/ngos/bin# ./lpctool --read --addr=102
Byte Port 0x102 : 0xde

```

write Output

```

root@dell-diag-os:/opt/ngos/bin# ./lpctool --write --addr=102 --val=10

```

memtool

The `memtool` tests the physical memories in the system.

The `memtool` performs address bus and data tests that moves 1s or 0s through the bus lines to detect stuck, missing, bridged, or other issues found during board tests. The tool also places hamming values or addresses into memory to test and report failing bits. All tests are similar to the `memtest86` application but are available through the CLI.

In addition, the `memtool` reads the types and locations of memory in the system. The memory may be physical RAMs connected to the CPU covered by caches, or memory attached or embedded in other devices or across buses. The tool must know the addressable location of the memory, the memory address, data bus sizes, and any addressing constraints; for example, byte or word addressable boundaries.

The `memtool` allocates a memory region to tests in, which is either `malloc` space or opens a memory map to the memory, and passes the pointer to access the memory.

Tests

- **Address Read**—Causes read transactions on the memory bus. Address read can loop for several iterations, checking for any changes in the data between iterations. You can specify patterns on the address bus for the bits to allow the testing for stuck address bits.
- **Address Write**—Creates write transactions on the memory bus. Address writes can loop for several iterations, and works similar to the Address Read test.
- **Address Walking 1**—Walks a 1 through the provided address space in memory for the available address bits. Address Walking 1 writes the address of the cell in the location it is referencing. After it is done writing all the locations, it walks back through and verifies that the data is correct.

- Address Walking 0—Walks a 0 address bit through the memory area available to it. Address walking 0 writes the additive inverse of the address to the location. After writing all addressed locations, it walks back through and verifies the locations data.
- Data Read—Reads transactions similar to the Address Read test, but focuses on the data bits. Patterns are placed on the data bus to test for stuck data bits.
- Data Write—Places data patterns on the bus for testing the bus and looks for stuck data bits.
- Data Walking 1—Walks a 1 through the data bits within an address location and verifies that the values are valid before overwriting.
- Data Walking 0—Walks a 0 through the data bits and verifies the value as it is testing.
- Data Sliding 1—Slides a 1 through the data testing for stuck bits. By XOR of each shift to the data, when finished, the cell holds all the 1s.
- Data Sliding 0—Slides a 0 through the data bits set to 1. By XOR of each shift of the data, when finished, the cell holds all the 1s.
- Data Pattern—Writes four different patterns to memory locations within the specified region. The patterns are 0xFFFF, 0xFF00, 0xF0F0, 0xAAAA, 0xAA55 and 0x5555. The patterns are written as repeated portions of these patterns in the memory to fill the memory and as Hamming patterns (such as Hamming [8,4], Hamming[16,11], Hamming[32,26] or Hamming[64,57]) encoding with the additional most significant byte (MSB) parity bit to cover the parity bits in the Hamming code. This pattern allows for detecting multiple bit errors.
- Data Cache—Performs a rotation of a 16MB array in four clockwise rotations for 16 iterations of the complete rotation. The 16MB size ensures that memory is not within the cache lines and causes cache ejections through each of the rotations.

CLI options

```
DellEmc Diag - Memory Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23,

Syntax: memtool <option>
Show the Help-text:=
    memtool --h                                     (or)
    memtool -h
Display the configuration info of the device:=
    memtool --info                                  (or)
    memtool -i
List all of the memory regions in the config file:=
    memtool --list                                  (or)
    memtool -l
Test using the MEM test config file:=
    memtool --test --region=<region/'ALL'> [--testlist=<test0>,<test1>...] (or)
    memtool -t -G <region/ALL> [-T <test0>,<test1>,...]
Read the specified physical address:=
    memtool --read --addr=<address> --count=<bytes> [--width=<8/16/32>] (or)
    memtool -r -a <address> -C <bytes> [-W <#8,16,32>]
Write at the specified physical address:=
    memtool --write --addr=<address> --val=<data0>,<data1>, ... ,<dataN> [--width=<8/16/32>]
(or)
    memtool -w -a <address> -V <data0>,<data1>...,<dataN> [-W <8/16/32>]
Execute repeatedly command by count:=
    memtool --iteration=max/<count> [option1] [option2]... (or)
    memtool -I max/<count> [option1] [option2]...

Usage:=
-h, --h                Show the help text
-t, --test             Test using the pre-programmed configuration or use supplied config
-i, --info            Configuration information
-l, --list            List the understood TLV codes and names
-G, --region          Region
-T, --testlist        List of tests
-I, --iteration=      Iteration command execution
-C, --count=          Count
-a, --addr=           Address
-r, --read            Read operation
-w, --write           Write operation
-V, --val=            Value to be set
-W, --width           Width {8,16}
```

Available Tests are:

```
ALL TESTS, ADDRESS_READ, ADDRESS_WRITE, ADDRESS_WALKING1, ADDRESS_WALKING0, DATA_READ,
DATA_WRITE, DATA_WALKING1, DATA_WALKING0, DATA_SLIDING1, DATA_SLIDING0, DATA_PATTERN,
DATA_CACHE
```

e.g. ADDRESS_WALKING1, DATA_WALKING1

The `memtool` uses long options for the parameters which requires two hyphens in front of the options. Options are required, optional, or none. If a parameter is required, it is specified as such and must include an equal sign; if an option is optional, it is enclosed with square brackets. However, do not type the brackets at the CLI. For example, the `-region` and `-testlist` options are optional and you must enter them as `-region=0` and `-testlist=0`.

- **List**—Lists the memory regions SDI knows. The tool queries SDI for the regions and prints a list of the regions with a region number that you can use for the subsequent options requiring a region number.
- **Info**—Lists the SPD information for the specified regions. Specifying a region allows the tool to read SPD from different DIMM modules, each specified in its own region. The output lists the actual data read and completes some parsing of the parameters so you do not have to decode the values. Decoding is based on the SPD standard definition for DDR3 and DDR4 DIMM memory.
- **Test**—Runs tests that include: Address Read/Write, Address Walking 1/0, Data Read/Write, Data Walking 1/0, Data Sliding 1/0, and Data Patterns (that writes Hamming patterns that you can use to detect multiple bit errors and identify single bit errors). These tests run during the normal memory tests. In extended memory tests, the data cache memory test runs. This test is lengthy and causes multiple ejections of data from the cache and tests the caches.
In Verbosity 0, only the pass/fail message prints for all the tests. In Verbosity 1, each test prints its own pass/fail and other information; for example, what failed in the test. Higher verbosity shows where each pass of the test performs and has verbose output. All output, regardless of verbosity, is in the log. You can see every level of detail by referring to the log.
- **Read**—Reads physical memory locations. You can loop over address read cycles to look for data that is volatile or read physical devices on the memory bus (`localbus` for Power-PC processors). You can specify a region, address, and count of successive bytes to read.
- **Write**—Writes to a physical memory address to test write cycles and memory. Similar to the `Read` command, this command takes a region, address in that region, and a comma-separated list of values to write.

Output

list Output

```
root@dell-diag-os:~# memtool --list
=====
Region ID: 0
Region Name: DDR3-0
Address: dynamically allocated, Chunk: 0x2800 KB
Largest Cache Size: 0, Cache Line Size : 0
Access: d Increment: 8 Ecc: Y Iterations: 1
Configuration device: SPD (/dev/i2c-0) at 0x50, Regs 0 to 255
Tests:
Address Read Test
Address Write Test
Address Walking 1's Test
Address Walking 0's Test
Data Read Test
Data Write Test
Data Walking 1's Test
Data Walking 0's Test
Data Sliding 1's Test
Data Sliding 0's Test
Data Pattern Tests
Data Cache Test
root@dell-diag-os:~#
```

info Output

```
root@dell-diag-os:~# memtool --info
==== SPD Data ====
Density 8192 MB, Rows: 16, Cols: 10
Bus Width: 64 bits, ECC: yes
Manufacturer: Unknown
Part Number : AW48M7228BNK0M
[00000000]: 0x92 0x13 0x0b 0x08 0x05 0x22 0x00 0x09 0x0b 0x11 0x01 0x08 0x0a 0x00 0xfe 0x00
  || .....".
[00000010]: 0x69 0x78 0x69 0x3c 0x69 0x11 0x18 0x81 0xf0 0x0a 0x3c 0x3c 0x01 0x40 0x83 0x05
  || ixi<i.....<<.@..
[00000020]: 0x80 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x88 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000030]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x0f 0x11 0x5f 0x00
  || .....
[00000040]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000050]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000060]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000070]: 0x00 0x00 0x00 0x00 0x00 0x86 0xe3 0x05 0x16 0x04 0xb3 0xd1 0x0d 0x05 0xec 0x10
  || .....
[00000080]: 0x41 0x57 0x34 0x38 0x4d 0x37 0x32 0x32 0x38 0x42 0x4e 0x4b 0x30 0x4d 0x00 0x00
  || AW48M7228BNK0M..
[00000090]: 0x00 0x00 0x00 0x00 0x00 0x00 0x41 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....A.....
[000000a0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[000000b0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[000000c0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[000000d0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[000000e0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[000000f0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
root@dell-diag-os:~#
```

test Output

```
root@dell-diag-os:~# memtool --test
Testing Memory Regions:
Testing Memory Region 0:
Address Read Test ..... Passed
Address Write Test ..... Passed
Address Walking 1's Test ..... Passed
Address Walking 0's Test ..... Passed
Data Read Test ..... Passed
Data Write Test ..... Passed
Data Walking 1's Test ..... Passed
Data Walking 0's Test ..... Passed
Data Sliding 1's Test ..... Passed
Data Sliding 0's Test ..... Passed
Data Pattern Test ..... Passed
Memory: Overall test results ----- >>> Passed
root@dell-diag-os:~#
```


read Output

```
root@dell-diag-os:~# memtool --read --addr=200  
[00000200]: 0x00  || .
```

write Output

```
root@dell-diag-os:~# memtool --write --addr=200 --val=0x50
```

Constraints

You cannot perform memory tests while other tests that allocate and use memory within the region are performing. However, you can perform the Read tests concurrently with other processes. You cannot run multiple memory tests at the same time as they may collide within the memory spaces.

Memory tests cannot test all the memory, and without cache flushes, memory tests may not get out of the caches. The SDI must ensure the memory accessed is accessing the physical memory. This check slows down the tests.

Data flow

The `memtool` is not part of the data path and does not participate in the data flow.

Configuration file format

The configuration file for the `memtool` is a list of memory segments separated by a `====` divider. Each entry describes the memory in a system that is accessible. This list allows you to review memory in RAMs, FPGAs, and RAM in a memory-mapped PCI BAR. Each parameter is on a separate line and consists of:

- `Name`—The name of the memory region.
- `Start Address`—The address that the memory starts with. If this address is system memory, use a `'l'` to request the system to get a location from the OS Heap.
- `Size`—The size of the memory. If this size is system memory, use a `'l'` to request the system to get a location from the OS Heap.
- `Access Mode`—How you access the memory; through (b)yte, (h)alfword, or (w)ord.
- `Increment`—The byte address increment for each successive memory location.
- `Ecc`—checks if ECC is available.
- `Max Chunk`—Memory is tested in chunks in which the available memory is divided into. This number is the maximum size of a chunk.
- `Max Cache`—The size of the cache—not currently used. Ensures that caches are fully tested.
- `Cache Line`—The size of a cache line—not currently used.
- `Iterations`—How many times to run the tests on this region.
- `Tests`—lists the tests to perform. Tests are specified in a comma-separated list.

Available tests are:

- `ALL_TESTS`—All the following tests, except for `DATA_CACHE`, which must be run separately.
- `ADDRESS_READ`—Read test of the address lines.

- ADDRESS_WRITE—Write test of the address lines.
- ADDRESS_WALKING1—Walking a 1 through the address lines within the memory space.
- ADDRESS_WALKING0—Walking a 0 through the address lines within the memory space.
- DATA_READ—Read test of the data lines.
- DATA_WRITE—Write test of the data lines.
- DATA_WALKING1—Walking a 1 through the data lines.
- DATA_WALKING0—Walking a 0 through the data lines.
- DATA_SLIDING1—Sliding a 1 through the data lines.
- DATA_SLIDING0—Sliding a 0 through the data lines.
- DATA_PATTERN—Writing and reading patterns from the memory.
- DATA_CACHE—Exercises the RAM by completing cache evictions by rotating a large array, usually cache-line size square, of the values in memory multiple times.
- SPD Device—Not used.
- SPD Access—Bus to use to access the SPD.
- SPD Address—The address of the SPD chip (in hex) on the bus, if applicable.
- SPD Registers—The valid registers of the SPD chip listed as *start*, *end*.

```
DDR3-0
Start Address:-
Size:-
Access Mode:d
Increment:8
Ecc:1
Max Chunk:2800
Max Cache:0
Cache Line:0
Iterations:1
Tests:ALL_TESTS
SPD Device:SPD
SPD Access:/dev/i2c-0
SPD Address:50
SPD Registers:0,ff
```

nputool

The `nputool` allows for configuring and testing the switch ASICs.

The `nputool` tests the NPU in the system. The `nputool` verifies that ports are up and traffic between the ports is working either using the CPU-generated packet or using IXIA connected to port-1 and port-2 based on the configuration.

Tests

Tests are shown in the following sections.

CLI options

The `nputool` shows the available options with the `nputool -h` or `nputool` command.

```
DellEmc Diag ---- NPU Tool
version 1.0, x.xx.x.x-x
build, 2017/05/23,
```

```
Syntax: nputool
-h, --help           := Show this help
-i, --init           := Initialize NPU chip
```

```

-t, --test
    all      := Run All NPU tests
    id       := Run test based on test ID
-s, --show
    counter  := Dump packet counters
    temp     := Display NPU temperature

-l, --lpbk [phy/mac/ext] := Specify Loopback type for traffic test
-T, --traffic [ixia_self,ixia_adj,cpu_self,cpu_adj]
           := Send IXIA or CPU traffic based on specified cfg
           self->timbercon lpbk, adj->fiber lpbk
-I, --iteration [count] := Execute repeatedly command by count
-v, --version           := Display version

```

Usage:

```

nputool -i -t [all/0/1,2,3/4/..7] -T [ixia_self/ixia_adj/cpu_self/cpu_adj]
        -l [phy/mac/ext] := Run NPU tests based on user input

nputool -I [count] -i -t 1 -T cpu_self := Run NPU test repeatedly by count
nputool -i -s temp := Display NPU temperature

```

nputool version

```

root@dell-diag-os:/etc/dn/diag# nputool --v
Dell Diag nputool - version 1.0 sdk-6.5.3 package x.xx.x.x.xx 2016/08/12
root@dell-diag-os:/etc/dn/diag#

root@dell-diag-os:/etc/dn/diag# nputool --version
Dell Diag nputool - version 1.0 sdk-6.5.3 package x.xx.x.x.xx 2016/08/12
root@dell-diag-os:/etc/dn/diag#

```

Port link status test

- nputool -i -t 0
- nputool --i --test 0

```

root@dell-diag-os:~# root@dell-diag-os:/etc/dn/diag# nputool -i -t 0
8375_B0
-bash: root@dell-diag-os:/etc/dn/diag#: No such file or directory
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
    Test link_status_test for NPU 0 ..... Passed
    Test snake_traffic_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed

```

```

root@dell-diag-os:/etc/dn/diag# nputool -init -test 0
DMA pool size: 16777216
PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0, Driver BCM88375_B0
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
    Test link_status_test for NPU 0 ..... Passed
    Test snake_traffic_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed

```

CPU traffic with external loopback

Tests the traffic sent from the CPU internally generated packet to the front-end ports that are connected with external Loopback optics.

Connect all the ports with QSFP28 Loopback optics.

- nputool -i -t 1 -T cpu_self
- nputool --init --test 1 --traffic cpu_self

```
root@dell-diag-os:/opt/ngos/bin# nputool -i -t 1 -T cpu_self
DMA pool size: 16777216 PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0,
  Driver BCM88375_B0 sysconf_probe successful global_sal_config successful ***
  1 BCM devices are detected Diag NPU initialization over
Test link_status_test for NPU 0 ..... SKIPPED <<<---
Test snake_traffic_test for NPU 0 ..... Passed
Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
Test uplink_link_status_test for NPU 0 .... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 .... SKIPPED <<<---
Test uplink_prbs_mac_test for NPU 0 .... SKIPPED <<<---
Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed
```

```
root@dell-diag-os:~# nputool --init --test 1 --traffic cpu_self
DMA pool size: 16777216 PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0,
  Driver BCM88375_B0 sysconf_probe successful global_sal_config successful ***
  1 BCM devices are detected Diag NPU initialization over
Test link_status_test for NPU 0 ..... SKIPPED <<<---
Test snake_traffic_test for NPU 0 ..... Passed
Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 .... SKIPPED <<<---
Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed
```

CPU traffic with adjacent loopback

Tests the traffic sent from the CPU internally generated packet to the front-end ports which are connected with direct attach cables (DACs) or optics with cables connected top-to-bottom.

Connect all the ports with DACs or 40G/100G optics with cables.

- nputool -i -t 1 -T cpu_adj
- nputool --init --test 1 --traffic cpu_adj

```
root@dell-diag-os:~# nputool -i -t 1 -T cpu_adj
DMA pool size: 16777216
PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0, Driver BCM88375_B0
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
  Test link_status_test for NPU 0 ..... SKIPPED <<<---
  Test snake_traffic_test for NPU 0 ..... Passed
    Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
  Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
  Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
  Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed
```

```
root@dell-diag-os:~#
```

```
root@dell-diag-os:~# nputool -init -test 1 -traffic cpu_adj
DMA pool size: 16777216
```

```

PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0, Driver BCM88375_B0
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
    Test link_status_test for NPU 0 ..... SKIPPED <<<---
    Test snake_traffic_test for NPU 0 ..... Passed
    Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
    Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed
root@dell-diag-os:~#

```

IXIA traffic with external loopback

Tests the traffic sent from IXIA to port-1 and to the front-end ports which are connected with external Loopback optics.

Connect the first port to IXIA and all other ports with QSFP28 Loopback optics.

- nputool -i -t 1 -T ixia_self -d
- nputool --init --test 1 --traffic ixia_self -d

These commands configure the virtual local area network (VLAN) and after the BCM.0> shell displays, send the traffic from IXIA. To verify the counters, run the show c command in the BCM shell.

IXIA traffic with adjacent loopback

Tests the traffic sent from IXIA to the front-end ports which are connected with DACs or optics with cables connected top-to-bottom.

Connect the first two ports to IXIA and all the remaining ports with DACs or 40G/100G optics with cables.

- nputool -i -t 1 -T ixia_adj
- nputool --init --test 1 --traffic ixia_adj

The previous commands configure the VLAN and after the BCM.0> shell displays. To verify the counters, run the show c command in the BCM shell.

CPU traffic with external loopback for uplink ports (SFP+)

Traffic is sent from the CPU to the SFP+ ports.

Connect all the ports with the SFP+ optics with TX and RX shorted.

- nputool -i -t 5 -T cpu_self
- nputool --init --test 5 --traffic cpu_self

CPU traffic for uplink ports connected between adjacent ports

Traffic is sent from the CPU internally generated packet to the front-end Dell EMC SFP+ ports which are connected with SFP+ optics using a cable.

Connect the SFP+ ports with the Dell EMC SFP+ optics using cables.

- nputool -i -t 5 -T cpu_adj
- nputool --i --test 5 --traffic cpu_adj

IXIA traffic with external loopback

Traffic is sent from the CPU internally generated packet to the front-end SFP+ ports which are connected with the Dell EMC SFP+ optics using a cable.

Connect the first port to IXIA and all other ports with Loopback optics.

- `nputool -i -t 5 -T ixia_self -d`
- `nputool --init --test 5 --traffic ixia_self -d`

Configure the VLAN and display the BCM.0> shell. To verify the counters, use the `show c` command in the BCM shell.

IXIA traffic with adjacent ports connected to IXIA

Traffic is sent from the CPU internally generated packet to the front-end ports which are connected with DACs or optics using cables connected top-to-bottom.

Connect two ports to IXIA with SFP+ optics and cables.

- `nputool -i -t 5 -T ixia_adj`
- `nputool --init --test 5 --traffic ixia_adj`

Configure the VLAN and display the BCM.0> shell. To verify the counters, use the `show c` command in the BCM shell.

PRBS for QSFP ports

Connect ports with Loopback cables and run the PRBS MAC and EXT Loopback tests.

- PRBS MAC level test `nputool -i -t 2` or `nputool --init --test 2`
- PRBS EXT level test `nputool -i -t 3` or `nputool --init --test 3`

For example:

```
root@dell-diag-os:~# nputool --init --test 2 DMA pool size: 16777216 PCI unit 0: Dev 0x8375,
Rev 0x11, Chip BCM88375_B0,
  Driver BCM88375_B0 sysconf_probe successful global_sal_config successful ***
  1 BCM devices are detected Diag NPU initialization over
Test link_status_test for NPU 0 ..... SKIPPED <<<---
Test snake_traffic_test for NPU 0 ..... SKIPPED <<<---
Test prbs_mac_test for NPU 0 ..... Passed
Test prbs_ext_test for NPU 0 ..... SKIPPED <<<---
Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed

root@dell-diag-os:~# nputool --init --test 3 DMA pool size: 16777216 PCI unit 0: Dev 0x8375,
Rev 0x11, Chip BCM88375_B0,
  Driver BCM88375_B0 sysconf_probe successful global_sal_config successful ***
  1 BCM devices are detected Diag NPU initialization over
Test link_status_test for NPU 0 ..... SKIPPED <<<---
Test snake_traffic_test for NPU 0 ..... SKIPPED <<<---
Test prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test prbs_ext_test for NPU 0 ..... Passed
Test uplink_link_status_test for NPU 0 ..... SKIPPED <<<---
Test uplink_snake_traffic_test for NPU 0 ..... SKIPPED <<<---
Test uplink_prbs_mac_test for NPU 0 ..... SKIPPED <<<---
Test uplink_prbs_ext_test for NPU 0 ..... SKIPPED <<<---
NPU tests ..... Passed
```

PRBS for uplink ports

Connect the SFP+ ports with an external Loopback cable.

- PRBS MAC level test `./nputool -i -t 6`
- PRBS EXT level test `./nputool -i -t 7`

NPU temperature

Show the current NPU temperature.

- `nputool -i -s temp`
- `nputool --init --show temp`

```
root@dell-diag-os:~# nputool -i -s temp
DMA pool size: 16777216
PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0, Driver BCM88375_B0
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
NPU 0 Temperature
-----
monitor   current   peak
-----
0         41.8     44.2
1         41.3     44.7
2         36.4     38.8
3         39.8     43.2
-----
Average 39.8, maximum peak 44.7
```

```
root@dell-diag-os:~# nputool -init -show temp
DMA pool size: 16777216
PCI unit 0: Dev 0x8375, Rev 0x11, Chip BCM88375_B0, Driver BCM88375_B0
sysconf_probe successful
global_sal_config successful
*** 1 BCM devices are detected
Diag NPU initialization over
NPU 0 Temperature
-----
monitor   current   peak
-----
0         42.3     44.2
1         40.8     44.2
2         35.9     38.8
3         40.8     43.2
-----
Average 39.9, maximum peak 44.2
root@dell-diag-os:~#
```

Debugging

With traffic commands, use the `-d` option, which displays the `BCM.0>` shell. To check counters and if the link is up, use the `ps` and `show c` commands.

nvrामtool

To read and write the NVRAM bits that the BIOS uses to control testing and the bits for the EDA tools, use the `nvrामtool`.

The NVRAM is an area, usually in a battery backed-up device such as an RTC chip, that allows the writing of bits which do not change across reboots or power cycles. These bits are used to control how devices boot and how the tests are performed. The `nvrामtool` controls both the BIOS and EDA for testing. The bits are not common across platforms and are defined in the configuration file. When using this tool, you must write the correct bits because the tool does not know the details of the registers it is writing. The `nvrामtool` can display the bit-level detail in the NVRAM registers, depending on how you define it in the configuration file.

Tests

There are no tests of the NVRAM. This tool only controls the bits.

CLI option

```
DellEmc Diag - NVRAM Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23,

Syntax: nvramtool <option>
  Show this help:=
    nvramtool --h           (or)
    nvramtool -h
  Read all or specific register NVRAM values:=
    nvramtool --read [--reg=<register>]   (or)
    nvramtool -r [-R <register>]
  Write NVRAM value:=
    nvramtool --write [--reg=<register> --val=<value>]   (or)
    nvramtool -w [-R <register> -V <value>]
  Execute repeatedly command by count:=
    nvramtool --iteration=max/<count> [option1] [option2]... (or)
    nvramtool -I max/<count> [option1] [option2]...

Usage:
  -h, --h           Show the help text
  -r, --read        Read operation
  -w, --write       Write operation
  -I, --iteration=  Iteration command execution
  -R, --reg=        Register
  -V, --val=        Value to be set
```

Output

read output

```
root@dell-diag-os:~# nvramtool --read
NVRAM Values:
0x00 0x9f 0x00 0xe6 0x03 0x03 0x00 0xea
Test Status Fail Bits : offset 0x50 = 0x0
  7 NVRAM test = 0
  6 SSD test = 0
  5 COLD/SMF Reg check = 0
  4 PCI test = 0
  3 Upper DRAM test = 0
  2 Lower DRAM test = 0
  1 ECC test = 0
  0 SPD test = 0
Test Status Pass Bits : offset 0x51 = 0x9f
  7 NVRAM test = 1
  6 SSD test = 0
  5 CPLD/SMF Reg check = 0
  4 PCI test = 1
  3 Upper DRAM test = 1
  2 Lower DRAM test = 1
  1 ECC test = 1
  0 SPD test = 1
```



```

RMT Control : offset 0x52 = 0x0
 7: 4 Undefined = 0
   3 RMT Test Enable = 0
 2: 0 RMT Test Reboot Count = 0
Status ID Byte : offset 0x53 = 0xe6
POST Control Bits : offset 0x54 = 0x3
 7 Force Cold Boot = 0
 6 POST Extended Upper DRAM test = 0
 5 POST Extended Lower DRAM test = 0
 4 POST Extended tests = 0
 3 Reserved = 0
 2 POST Verbose Mode = 0
 1 POST Stop on Error = 1
 0 POST Enable = 1
EDA Control Bits : offset 0x55 = 0x3
 5: 4 EDA Verbose Level = 0
   3 EDA Extended Tests = 0
   2 EDA Verbose Mode = 0
   1 EDA Stop on Error = 1
   0 EDA Enable = 1
EDA Extra Bits : offset 0x56 = 0x0
Control ID Byte : offset 0x57 = 0xea
root@dell-diag-os:~#

```

write output

```
./nvrantool --write --reg=0x54 --val=0x1
```

Configuration file format

The nvrantool configuration file uses the device description format and is the same format as the pltool configuration file.

```

# C - CHIP (Master | Slave - Cpld or FPGA), Address, Name, Access
# R - Register, Offset, Mask, Name, RW , Default Val
# B - Bit(s), bitnum(s), Name, RW, Default Val
# I - Information on the bits
=====
C | NVRAM | 0x72 | RTC Extended Memory | io | 0 | - | - | 0x00 | 0x0
R | 0x50 | 8 | 0xFF | Test Status Fail Bits | RO | 0x0 | 0 | 0x0
B | 7 | NVRAM test | RO | 0x0
B | 6 | SSD test | RO | 0x0
B | 5 | COLD/SMF Reg check | RO | 0x0
B | 4 | PCI test | RO | 0x0
B | 3 | Upper DRAM test | RO | 0x0
B | 2 | Lower DRAM test | RO | 0x0
B | 1 | ECC test | RO | 0x0
B | 0 | SPD test | RO | 0x0
R | 0x51 | 8 | 0xFF | Test Status Pass Bits | RO | 0x0 | 0 | 0x0
B | 7 | NVRAM test | RO | 0x0
B | 6 | SSD test | RO | 0x0
B | 5 | CPLD/SMF Reg check | RO | 0x0
B | 4 | PCI test | RO | 0x0
B | 3 | Upper DRAM test | RO | 0x0
B | 2 | Lower DRAM test | RO | 0x0
B | 1 | ECC test | RO | 0x0

```

opticstool

To check the presence or absence of optic devices, link status, and to read data from the optic devices' EEPROM, use the `opticstool`.

Tests

There are no tests on the optic devices. You can run a brief report that displays the optic presence or shows simple data, such as the serial number and device type. For more detailed information, use a device report.

CLI options

```
DellEmc Diag - Optics Tool
version 1.0, x.xx.x.x-x
build, 2017/05/23,

Syntax: opticstool <option>
  Show the help-text:=
    opticstool --h
    opticstool -h
  Show port and optics status:=
    opticstool --show[=brief] [--int=<interface>]
    opticstool -x[=brief] [-I <interface>]
  Execute repeatedly command by count:=
    opticstool --iteration=max/<count> [option1] [option2]...
    opticstool -I max/<count> [option1] [option2]...
  opticstool --read --int=<interface> [--page=<page #>] [--index=<offset>] [--cnt=<length>] (or)
  opticstool -r -I <interface> [-p <page #>] [-i <offset>] [-C <length>]
  opticstool --write --int=<interface> --page=<page #> --index=<offset> --val=<value> (or)
  opticstool -w -i <interface> -p <page #> -i <offset> -V <value>
Usage:
  -h, --h          Show the help text
  -x, --show=     Show operation
  -F, --int       Interface ID
  -I, --iteration= Iteration command execution
  -r, --read      Read operation
  -w, --write     Write operation
```

- `show` —Shows information about the optic devices. With the `brief` option, only the ID and presence displays. Without the `brief` option, more details display, such as the serial number and device type. If you specify an interface, more detail displays about that device by reading the EEPROM.

Output

show=brief output

```
root@dell-diag-os:~# opticstool --show=brief
Show Optics in System (brief)
Port #  Name      Status
-----  -
  1      SFP+ 1    PRESENT
  2      SFP+ 2    PRESENT
  3      SFP+ 3    PRESENT
  4      SFP+ 4    PRESENT
  5      SFP+ 5    PRESENT
  6      SFP+ 6    PRESENT
  7      SFP+ 7    PRESENT
```

```

8      SFP+ 8    PRESENT
9      SFP+ 9    PRESENT
10     SFP+ 10   PRESENT
11     SFP+ 11   PRESENT
12     SFP+ 12   PRESENT
13     SFP+ 13   PRESENT
14     SFP+ 14   PRESENT
15     SFP+ 15   PRESENT
16     SFP+ 16   PRESENT
17     SFP+ 17   PRESENT
18     SFP+ 18   PRESENT
19     SFP+ 19   PRESENT
20     SFP+ 20   PRESENT
21     SFP+ 21   PRESENT
22     SFP+ 22   PRESENT
23     SFP+ 23   PRESENT
24     SFP+ 24   PRESENT
25     SFP+ 25   PRESENT
26     SFP+ 26   PRESENT
27     SFP+ 27   PRESENT
28     SFP+ 28   PRESENT
29     SFP+ 29   PRESENT
30     SFP+ 30   PRESENT
31     SFP+ 31   PRESENT
32     SFP+ 32   PRESENT
33     SFP+ 33   PRESENT
34     SFP+ 34   PRESENT
35     SFP+ 35   PRESENT
36     SFP+ 36   PRESENT
37     SFP+ 37   PRESENT
38     SFP+ 38   PRESENT
39     SFP+ 39   PRESENT
40     SFP+ 40   PRESENT
41     QSFP+ 41   PRESENT
42     QSFP+ 42   PRESENT
43     QSFP28 43   PRESENT
44     QSFP28 44   PRESENT
45     QSFP28 45   PRESENT
46     QSFP28 46   PRESENT
47     QSFP28 47   PRESENT
48     QSFP28 48   PRESENT
root@dell-diag-os:~#

```

show output

```

root@dell-diag-os:~# opticstool --show
Show Optics in System

```

Port #	Name	Status	Type	Part Number	Rev	Serial Number
1	SFP+ 1	PRESENT	SFP	616740000	B	CN0C6Y7M41A0
2	SFP+ 2	PRESENT	SFP	616740000	B	CN0C6Y7M41A0
3	SFP+ 3	PRESENT	SFP	616740000	C	CN0C6Y7M01I4
4	SFP+ 4	PRESENT	SFP	616740000	C	CN0C6Y7M01I4
5	SFP+ 5	PRESENT	SFP	616740000	C	CN0C6Y7M490B@
6	SFP+ 6	PRESENT	SFP	616740000	C	CN0C6Y7M490B@
7	SFP+ 7	PRESENT	SFP	616740000	C	CN0C6Y7M490BDD
8	SFP+ 8	PRESENT	SFP	616740000	C	CN0C6Y7M490BDD
9	SFP+ 9	PRESENT	SFP	616740000	C	CN0C6Y7M482HV@
10	SFP+ 10	PRESENT	SFP	616740000	C	CN0C6Y7M482HV@
11	SFP+ 11	PRESENT	SFP	616740000	C	CN0C6Y7M490BEL
12	SFP+ 12	PRESENT	SFP	616740000	C	CN0C6Y7M490BEL
13	SFP+ 13	PRESENT	SFP	616740000	C	CN0C6Y7M490BD
14	SFP+ 14	PRESENT	SFP	616740000	C	CN0C6Y7M490BD
15	SFP+ 15	PRESENT	SFP	616740000	C	CN0C6Y7M490BDD
16	SFP+ 16	PRESENT	SFP	616740000	C	CN0C6Y7M490BDD
17	SFP+ 17	PRESENT	SFP	616740000	C	CN0C6Y7M48A2E@
18	SFP+ 18	PRESENT	SFP	616740000	C	CN0C6Y7M48A2E@

```

19 SFP+ 19 PRESENT SFP 616740000 C CNOC6Y7M482@@@
20 SFP+ 20 PRESENT SFP 616740000 C CNOC6Y7M482@@@
21 SFP+ 21 PRESENT SFP 616740000 C CNOC6Y7M48C2MF@
22 SFP+ 22 PRESENT SFP 616740000 C CNOC6Y7M48C2MF@
23 SFP+ 23 PRESENT SFP 616740000 C CNOC6Y7M40A0HB
24 SFP+ 24 PRESENT SFP 616740000 C CNOC6Y7M40A0HB
25 SFP+ 25 PRESENT SFP 616740000 C CNOC6Y7M41A0BP
26 SFP+ 26 PRESENT SFP 616740000 C CNOC6Y7M41A0BP
27 SFP+ 27 PRESENT SFP 616740000 C CNOC6Y7M411J
28 SFP+ 28 PRESENT SFP 616740000 C CNOC6Y7M411J
29 SFP+ 29 PRESENT SFP 616740000 C CNOC6Y7M41A0BR
30 SFP+ 30 PRESENT SFP 616740000 C CNOC6Y7M41A0BR
31 SFP+ 31 PRESENT SFP 616740000 C CNOC6Y7M40A0HB
32 SFP+ 32 PRESENT SFP 616740000 C CNOC6Y7M40A0HB
33 SFP+ 33 PRESENT SFP 616740000 C CNOC6Y7M49M4BG5
34 SFP+ 34 PRESENT SFP 616740000 C CNOC6Y7M49M4BG5
35 SFP+ 35 PRESENT SFP 616740000 C CNOC6Y7M49M4BEJ
36 SFP+ 36 PRESENT SFP 616740000 C CNOC6Y7M49M4BEJ
37 SFP+ 37 PRESENT SFP 599700001 A APF11370018C9V
38 SFP+ 38 PRESENT SFP 599700001 A APF11370018C9V
39 SFP+ 39 PRESENT SFP 616740000 C CNOC6Y7M48C2MUP
40 SFP+ 40 PRESENT SFP 616740000 C CNOC6Y7M48C2MUP
41 QSFP+ 41 PRESENT QSFP+ 599690001 D APF11510011VRR
42 QSFP+ 42 PRESENT QSFP+ AFBR-79E4Z-D-FT1 01 QB382231
43 QSFP28 43 PRESENT QSFP28 1002971101 1 504020274
44 QSFP28 44 PRESENT QSFP28 1002971101 1 504020274
45 QSFP28 45 PRESENT QSFP28 1002971051 1 506220006
46 QSFP28 46 PRESENT QSFP28 1002971051 1 506220006
47 QSFP28 47 PRESENT QSFP28 1002971101 1 504120586
48 QSFP28 48 PRESENT QSFP28 1002971101 1 504120586
root@dell-diag-os:~#

```

show --int=interface # output

```

root@dell-diag-os:~# opticstool --show --int=48
Show Optics in System
=====
QSFP28 48 Detailed Display
=====
Link Status
-----
Port Status
Loss of Signal      :
RX Signal Lock Error :
PCS Link State      :
Link Faults         :
Remote              :
Local               :
Idle Error          :
Illegal Symbol      :
Error Symbol        :
Present             : Present
Device Data:
[00000000]: 0x11 0x05 0x06 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000010]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000020]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000030]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000040]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000050]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000060]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x38 0x00
  || .....8.

```

```

[00000070]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| .....
[00000080]: 0x11 0x00 0x23 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| ..#.....
[00000090]: 0x00 0x00 0x01 0xa0 0x4d 0x6f 0x6c 0x65 0x78 0x20 0x49 0x6e 0x63 0x2e 0x20 0x20
|| ....Molex Inc.
[000000a0]: 0x20 0x20 0x20 0x20 0x00 0x00 0x09 0x3a 0x31 0x30 0x30 0x32 0x39 0x37 0x31 0x31
|| ...:10029711
[000000b0]: 0x30 0x31 0x20 0x20 0x20 0x20 0x20 0x20 0x31 0x20 0x00 0x00 0x00 0x00 0x00 0x4c
|| 01 1 .....L
[000000c0]: 0x00 0x00 0x00 0x00 0x35 0x30 0x34 0x31 0x32 0x30 0x35 0x38 0x36 0x20 0x20 0x20
|| ....504120586
[000000d0]: 0x20 0x20 0x20 0x20 0x31 0x35 0x30 0x32 0x31 0x30 0x20 0x20 0x00 0x00 0x00 0x18
|| 150210 ....
[000000e0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| .....
[000000f0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| .....
Vendor: Molex Inc.
Part No: 1002971101
Revision: 1
Serial Num: 504120586
ID : 0x11
Extended ID : 0x00
Connector : 0x23
Specification : 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
Encoding : 0x00
BR Nominal : 0x00
Length (9um) Km : 0x00
Length (9um) 100m : 0x00
Length (50um) 10m : 0x00
Length (62.5um) 10m : 0x00
Length (copper) 10m : 0x01
Cable Attenuation : 0x00 (2.5 Ghz) 0x00 (5.0 Ghz)
CheckCodeBase : 0x4c (0x4c)
-----
Extended ID Fields
-----
Options :
BR Max :
BR Min :
Date Code : 2015-02-10
CheckCodeExt : 0x18 (0x18)
TX Output Disable : Not Disabled
-----
Diagnostics Information
-----
Module Monitoring Values:
Current Temp: 0.000 (Celsius)
Supply Volts: 0.000 (Volts)
Channel Monitoring Values:
Recv: 0.000 0.000 0.000 0.000 (dBm)
Bias: 0.000 0.000 0.000 0.000 (mA)
root@dell-diag-os:~#

```

Configuration file format

The configuration file for the `opticstool` is:

- Optics ID—The ID of the optics port.
- Name—The printable name of the optics device—you must name the SFPs “SFP” and the QSFPs “QSFP”.

Then four entries describe how to read if a device is present, select the MUX for accessing the device, reset or not reset the device, and read data from the device.

- Present:
 - Bus to use to access presence indicators
 - Address of the device that indicates presence
 - Register of the device that indicates presence
 - Bits in the register that indicates presence—supports single bit and low-to-high range
 - Value of the bits that indicates presence
 - MUX settings to access the device
- Select—Hardware gating.
 - Bus to use to access presence indicators
 - Address of the device that indicates presence
 - Register of the device that indicates presence
 - Bits in the register that indicates presence—supports single bit and low-to-high range
 - Value of the bits that indicates presence
 - MUX settings to access the device
- Reset—Hardware reset of the device.
 - Bus to use to access presence indicators
 - Address of the device that indicates presence
 - Register of the device that indicates presence
 - Bits in the register that indicates presence—supports single bit and low-to-high range
 - Value of the bits that indicates presence
 - MUX settings to access the device
- Data:
 - Bus to use to access the device
 - Address of device on the bus
 - MUX settings to access the device

```
# portnum | Name
# Present | dev | addr | reg(:reg size) | bit(s) | p_val | <mux type> addr:buss
:mask:val, :addr:bus:mask:val
# Select | dev | addr | reg(:reg size) | bit(s) | p_val | <mux type> addr:buss
:mask:val, :addr:bus:mask:val
# Power | dev | addr | reg(:reg size) | bit(s) | p_val | <mux type> addr:buss
:mask:val, :addr:bus:mask:val
# Reset | dev | addr | reg(:reg size) | bit(s) | p_val | <mux type> addr:buss
:mask:val, :addr:bus:mask:val
# Interrupt | dev | addr | reg(:reg size) | bit(s) | p_val | <mux type> addr:buss
:mask:val, :addr:bus:mask:val
# Data | dev | addr | <mux type> addr:bus:mask:val, :addr:bus:mask:val
#
# CPLD2
1 | SFP+ 1
Present | /dev/i2c-1 | 0x3e | 0x001c:0x10 | 0 | 0 | /dev/i2c-1 0x70:0x0:0xf:0xa::
, :0x71:0x10:0xf:0x10
Select | - | 0x00 | 0x00 | 0 | 0 | - 0x00:0x0:0x0:0x0
Power | - | 0x00 | 0x00 | 0 | 0 | - 0x00:0x0:0x0:0x0
Reset | - | 0x00 | 0x00 | 0 | 0 | - 0x00:0x0:0x0:0x0
Intr | - | 0x00 | 0x00 | 0 | 0 | - 0x00:0x0:0x0:0x0
Data | /dev/i2c-1 | 0x50 | /dev/i2c-1 0x70:0x0:0xf:0xd, :0x72:0x01:0xf:0x01
2 | SFP+ 2
```

pcitool

To scan and access devices on the PCI bus, use the `pcitool`. The `pcitool` checks for missing devices and that the present devices are the proper type.

The `pcitool` scans the PCI bus for present devices and displays them and the BAR information it decodes. The tool does not handle endianness.

The `pcitool` reads the configuration file and then iterates across all devices in the configuration file. It checks the vendor/product ID to see that the correct device is at the correct address. The tool does not compare all the configuration space. The tool reads all 256 bytes of the configuration file.

Tests

The `pcitool` reads from the configuration file the devices it expects to find and reports any devices that it cannot find or if the device is not correct. The tool supports second-source parts; therefore, they are not flagged as false errors. If a mismatch occurs, the device lists with the expected value and the read value. Populate the configuration file with `-u` numbers so the device can quickly identify the failing device.

CLI options

```
DellEmc Diag - PCI Tool
version 1.5, x.xx.x.x-x
build, 2017/05/23,

Usage:
  To scan all PCI drivers and optionally show all config data :=
    pcitool --
scan[=all]                                     (or)
    pcitool -S[=all]
  To test using default PCI config-file :=
    pcitool --
test                                           (or)
    pcitool -t
  Show config data for specific bus:dev.func:=
    pcitool --show [--bus=<bus># --dev=<dev># --
func=<func>#} (or)
    pcitool -x {-B <bus># -D <dev># -F <func>#}
  Read 8-bit config register for bus:dev.func:=
    pcitool --read [--bus=<bus># --dev=<dev># --func=<func># --offset=<offset> --
count=<count>} (or)
    pcitool -r {-B <bus># -D <dev># -F <func># -O <offset> -C <count>}
  Write 8-bit config register for bus:dev.func:=
    pcitool --write [--bus=<bus># --dev=<dev># --func=<func># --offset=<offset> --
val=<value>} (or)
    pcitool -w {-B <bus># -D <dev># -F <func># -O <offset> -V <value>}
  Execute repeatedly command by count:=
    pcitool --iteration=max/<count> [option1]
[option2]... (or)
    pcitool -I max/<count> [option1] [option2]...

Syntax: pcitool <option>
-h, --h                Show the help text
-S, --scan             Scan operation
-t, --test             Test using the pre-programmed configuration or use supplied config
-x, --show             Show operation
-r, --read             Read operation
-w, --write            Write operation
-I, --iteration=       Iteration command execution
```

```

-B, --bus=           To specify the i2c bus   e.g.: /dev/i2c-<bus number>
-D, --dev=           Device
-F, --func=          Func
-O, --offset=        Set the Offset
-C, --count=         Count
-V, --val=           Value to be set

```

Output

scan output

```

root@dell-diag-os:~# pcitool --scan
Acquiring PCI device name database
Device#01: bus:dev.fn 00:00.0 - ID=0x1f0c8086, Intel Atom Processor SoC Transaction Router
Device#02: bus:dev.fn 00:01.0 - ID=0x1f108086, Intel Atom Processor PCIe Root Port 1
Device#03: bus:dev.fn 00:02.0 - ID=0x1f118086, Intel Atom Processor PCIe Root Port 2
Device#04: bus:dev.fn 00:03.0 - ID=0x1f128086, Intel Atom Processor PCIe Root Port 3
Device#05: bus:dev.fn 00:04.0 - ID=0x1f138086, Intel Atom Processor PCIe Root Port 4
Device#06: bus:dev.fn 00:0e.0 - ID=0x1f148086, Intel Atom Processor C2000 RAS
Device#07: bus:dev.fn 00:0f.0 - ID=0x1f168086, Intel Atom Processor C2000 RCEC
Device#08: bus:dev.fn 00:13.0 - ID=0x1f158086, Intel Atom processor C2000 SMBus 2.0
Device#09: bus:dev.fn 00:14.0 - ID=0x1f418086, Intel Ethernet Connection I354
Device#10: bus:dev.fn 00:14.1 - ID=0x1f418086, Intel Ethernet Connection I354
Device#11: bus:dev.fn 00:14.2 - ID=0x1f418086, Intel Ethernet Connection I354
Device#12: bus:dev.fn 00:16.0 - ID=0x1f2c8086, Intel USB Enhanced Host Controller
Device#13: bus:dev.fn 00:17.0 - ID=0x1f228086, Intel AHCI SATA2 Controller
Device#14: bus:dev.fn 00:18.0 - ID=0x1f328086, Intel AHCI SATA3 Controller
Device#15: bus:dev.fn 00:1f.0 - ID=0x1f388086, Intel ISA bridge
Device#16: bus:dev.fn 00:1f.3 - ID=0x1f3c8086, Intel PCU SMBus
Device#17: bus:dev.fn 01:00.0 - ID=0x837514e4, Broadcom Network Processor BCM88375
Device#18: bus:dev.fn 01:00.1 - ID=0x837514e4, Broadcom Network Processor BCM88375
root@dell-diag-os:~#

```

test output

```

root@dell-diag-os:~# pcitool --test
Testing PCI devices:
+ Checking PCI 00:00.0, ID=1f0c8086 ..... Passed
+ Checking PCI 00:01.0, ID=1f108086 ..... Passed
+ Checking PCI 00:02.0, ID=1f118086 ..... Passed
+ Checking PCI 00:03.0, ID=1f128086 ..... Passed
+ Checking PCI 00:0e.0, ID=1f148086 ..... Passed
+ Checking PCI 00:0f.0, ID=1f168086 ..... Passed
+ Checking PCI 00:13.0, ID=1f158086 ..... Passed
+ Checking PCI 00:14.0, ID=1f418086 ..... Passed
+ Checking PCI 00:14.1, ID=1f418086 ..... Passed
+ Checking PCI 00:14.2, ID=1f418086 ..... Passed
+ Checking PCI 00:16.0, ID=1f2c8086 ..... Passed
+ Checking PCI 00:17.0, ID=1f228086 ..... Passed
+ Checking PCI 00:18.0, ID=1f328086 ..... Passed
+ Checking PCI 00:1f.0, ID=1f388086 ..... Passed
+ Checking PCI 00:1f.3, ID=1f3c8086 ..... Passed
+ Checking PCI 01:00.0, ID=837514e4 ..... Passed
+ Checking PCI 01:00.1, ID=837514e4 ..... Passed
PCI devices: Overall test results ----- >>> Passed
root@dell-diag-os:~#

```


show output

```
root@dell-diag-os:/etc/dn/diag# pcitool --show --bus=0 --dev=4 --func=0bus
bus:dev.fn 00:04.3
[00000000]: 0x00 0x00 0x00 0x00 0x01 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000010]: 0x40 0x0e 0x40 0x00 0x00 0x00 0x00 0x00 0xe5 0xe2 0xdd 0x5b 0x47 0x7f 0x00 0x00
  || @.@.....[G...
[00000020]: 0xff 0xff 0xff 0xff 0x00 0x00 0x00 0x00 0x0c 0x00 0xad 0xfb 0x00 0x00 0x00 0x00
  || .....
[00000030]: 0xf0 0x30 0x5f 0x02 0x00 0x00 0x00 0x00 0x10 0x30 0x5f 0x02 0x00 0x00 0x00 0x00
  || .0_.....0_.....
[00000040]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x40 0x0e 0x40 0x00 0x00 0x00 0x00 0x00
  || .....@.@.....
[00000050]: 0x80 0xa9 0xa9 0x91 0xff 0x7f 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000060]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x35 0x37 0x86 0x5b 0x47 0x7f 0x00 0x00
  || .....57.[G...
[00000070]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x20 0x9f 0xa9 0x91 0xff 0x7f 0x00 0x00
  || .....
[00000080]: 0x40 0x0e 0x40 0x00 0x00 0x00 0x00 0x00 0xe4 0x1b 0x40 0x00 0x00 0x00 0x00 0x00
  || @.@.....@.....
[00000090]: 0x04 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x5c 0x9f 0xa9 0x91 0xff 0x7f 0x00 0x00
  || .....\.
[000000a0]: 0xda 0x4e 0x40 0x00 0x00 0x00 0x00 0x00 0x20 0xbe 0xa9 0x91 0x00 0x7f 0x00 0x00
  || .N@.....
[000000b0]: 0xa0 0x9f 0xa9 0x91 0x00 0x00 0x00 0x00 0x10 0x30 0x5f 0x02 0x00 0x00 0x00 0x00
  || .....0_.....
[000000c0]: 0x30 0x34 0x2e 0x30 0x00 0x74 0x65 0x73 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || 04.0.tes.....
[000000d0]: 0x2f 0x70 0x72 0x6f 0x63 0x2f 0x62 0x75 0x73 0x2f 0x70 0x63 0x69 0x2f 0x30 0x30
  || /proc/bus/pci/00
[000000e0]: 0x2f 0x30 0x34 0x2e 0x30 0x00 0x00 0x00 0x80 0xa0 0xa9 0x91 0xff 0x7f 0x00 0x00
  || /04.0.....
[000000f0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
  Base Address 0: Memory at 0x00400e40.
  Base Address 1: Memory at 0x00000000.
  Base Address 2: I/O at 0x5bdde2e0.
  Base Address 3: I/O at 0x00007f40.
  Base Address 4: I/O at 0xffffffff0.
  Base Address 5: Memory at 0x00000000.
  CardBus CIS pointer 0xfbad000c (BAR 3), address 7f47.
root@dell-diag-os:/etc/dn/diag# pcitool --show --bus=0 --dev=4 --func=0
bus:dev.fn 00:04.0
[00000000]: 0x86 0x80 0x13 0x1f 0x07 0x04 0x10 0x00 0x02 0x00 0x04 0x06 0x10 0x00 0x01 0x00
  || .....
[00000010]: 0x04 0x00 0xf6 0xdf 0x00 0x00 0x00 0x00 0x00 0x04 0x04 0x00 0xf0 0x00 0x00 0x20
  || .....
[00000020]: 0xf0 0xff 0x00 0x00 0xf1 0xff 0x01 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000030]: 0x00 0x00 0x00 0x00 0x40 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x07 0x01 0x10 0x00
  || ....@.....
[00000040]: 0x10 0x80 0x42 0x01 0x21 0x80 0x00 0x00 0x0f 0x20 0x00 0x00 0x42 0x48 0x79 0x04
  || ..B.!.....BHy.
[00000050]: 0x40 0x00 0x01 0x10 0x00 0xfd 0x18 0x00 0xc0 0x03 0x00 0x00 0x08 0x00 0x00 0x00
  || @.....
[00000060]: 0x00 0x00 0x00 0x00 0xb7 0x03 0x00 0x00 0x00 0x00 0x00 0x00 0x06 0x00 0x00 0x00
  || .....
[00000070]: 0x02 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
  || .....
[00000080]: 0x01 0x88 0x03 0xc8 0x00 0x00 0x00 0x00 0x0d 0x90 0x00 0x00 0x86 0x80 0x86 0x80
  || .....
[00000090]: 0x05 0x00 0x01 0x01 0x0c 0xf0 0xe0 0xfe 0xa1 0x41 0x00 0x00 0x00 0x00 0x00 0x00
  || .....A.....
[000000a0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
```

```

|| .....
[000000b0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| .....
[000000c0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x01 0x00 0x00 0x00
|| .....
[000000d0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x80 0x00 0x00 0x00 0x00
|| .....
[000000e0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x01 0x00 0x00 0x00 0x00 0x00
|| .....
[000000f0]: 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x03 0x00 0x00 0x00 0x00 0x00 0x00 0x00
|| .....
Base Address 0: Memory at 0xdff60000.
Base Address 1: Memory at 0x00000000.
Base Address 2: Memory at 0x00040400.
Base Address 3: Memory at 0x200000f0.
Base Address 4: Memory at 0x0000fff0.
Base Address 5: I/O at 0x0001fff0.
Address 0 at 0xdff60000, 64 bit
Address 2 at 0x00040400, 32 bit
Address 3 at 0x200000f0, 32 bit
Address 4 at 0x0000fff0, 32 bit
Extended capabilities, first structure at offset 0x40.
Extended PCI capability type 16 at 0x40, next 128.
Extended PCI capability type 1 at 0x80, next 136.
Power management entry ver. 3: Capabilities c803, Ctrl 0000, Event 0000.
Power state D0.
Extended PCI capability type 13 at 0x88, next 144.
Extended PCI capability type 5 at 0x90, next 0.
root@dell-diag-os:/etc/dn/diag#

```

Configuration file format

The configuration file format is strict for the PCI devices. To create this configuration file and remove any misidentified devices, use the `pcitool --create` option.

```
Bus:Dev:Fn= #:#. # ID= Vendor|Device Name- including any U Number information
```

Then the configuration space displays:

```

Bus:Dev.Fn=00:00.0 ID=1f0c8086 Intel Atom Processor SoC Transaction Router
 1f0c8086 00000007 06000002 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000000 00000000 ffffffff 00000000 00000000
 00000000 00000000 00000000 00000000 01000021 00000000 01000f02 00000000
Bus:Dev.Fn=00:01.0 ID=1f108086 Intel Atom Processor PCIe Root Port 1
 1f108086 00100407 06040002 00010010 dffa0004 00000000 00010100 000000f0
 0000fff0 df81de81 00000000 00000000 00000000 00000040 00000000 0010010b
 01428010 00008021 0000200f 01794842 f0420040 0000fd00 004003c0 00000008
 00000000 000003b7 00000000 00000006 00000002 00000000 00000000 00000000
 c8038801 00000000 0000900d 72708086 01010005 fee0f00c 00004161 00000000
 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
 00000000 00000000 00000000 00000001 00000000 0000000a 80000000 00000000
 00000000 00000000 00010000 00000000 00000000 00000000 00000000 00000000
Bus:Dev.Fn=00:02.0 ID=1f118086 Intel Atom Processor PCIe Root Port 2
 1f118086 00100407 06040002 00010010 dff80004 00000000 00020200 000000f0
 0000fff0 0001fff1 00000000 00000000 00000000 00000040 00000000 0010010b

```

phytool

The phytool allows setting the management phy for management port for speed, duplex auto negotiation, and Loopback; as well as reading the MAC and MAC EEPROM in the phy.

Tests

CLI options

```
DellEmc Diag - PHY Tool
version 1.1, x.xx.x.x-x
build, 2017/05/23,

Syntax: phytool <option>
  Show the help-text:=
  phytool --h                                     (or)
  phytool -h
  Read the mac address of the interface:=
  phytool --read-mac                               (or)
  phytool -R
  Write the value to the specified offset:=
  phytool --write --offset=<offset> --val=<val>     (or)
  phytool -w -o <offset> -V <val>
  Dump the eeprom contents:=
  phytool --eeprom-dump                            (or)
  phytool -x
  Dump the register contents:=
  phytool --reg-dump                               (or)
  phytool -d
  Phy loopback test:=
  phytool --lb-test[=no of packets]                (or)
  phytool -l[=no of packets]
  Execute repeatedly command by count:=
  phytool --iteration=max/<count> [option1] [option2]... (or)
  phytool -I max/<count> [option1] [option2]...
  Set the interface with parameters:=
  phytool --set-intf --speed=<speed> --duplex=<mode> --autoneg (or)
  phytool -s -S <speed> -D <mode> -A
  Show the interface settings:=
  phytool --show-intf                              (or)
  phytool -a
Usage:=
-h, --h                Show the help text
-I, --iteration=       Iteration command execution
-R, --read-mac        Read the MAC of the interface
-w, --write           Write operation
-o, --offset          Set the Offset
-V, --val             Value to be set
-x, --eeprom-dump    Dump the eeprom contents
-d, --reg-dump       Dump the register contents
-l, --lb-test=       Phy loopback test
-s, --set-intf       Set the interface with parameters
-S, --speed=         Speed
-D, --duplex=        Duplex mode
-A, --autoneg=       Auto-negotiation
-a, --show-intf      Show the interface settings
```

Output

```
root@dellemc-diag-os:/etc/dn/diag# phytool --read-mac
34:17:eb:07:7c:00

root@dellemc-diag-os:/etc/dn/diag# phytool --eeprom-dump
Offset      Values
-----
0x0000:     34 17 eb 07 7c 00 00 08 ff ff 05 10 ff ff ff ff
0x0010:     18 00 00 00 2f 40 41 1f 86 80 41 1f 86 80 80 ba
0x0020:     ff ff ff ff 80 5c 47 00 00 00 40 00 00 4c ab 03
0x0030:     00 00 00 70 0e 1a 26 44 a3 07 42 1f 01 02 02 06
0x0040:     0c 00 47 21 00 00 ff ff ac 44 f6 00 44 1f 08 09
0x0050:     40 04 3c 00 00 00 04 14 00 00 00 00 10 ff ff
0x0060:     00 01 00 40 32 13 13 40 00 01 00 40 ff ff b0 03
0x0070:     00 01 00 40 00 01 00 40 d9 09 bc 03 ff ff b5 7e
0x0080:     ff ff ff ff a5 0b 00 80 ff ff ff ff ff ff ff ff
.....

root@dellemc-diag-os:/etc/dn/diag# phytool --reg-dump
0x00000: CTRL (Device control register)      0x08100241
        Invert Loss-Of-Signal:                no
        Receive flow control:                 enabled
        Transmit flow control:                disabled
        VLAN mode:                            disabled
        Set link up:                           1
        D3COLD WakeUp capability advertisement: enabled
        Auto speed detect:                    disabled
        Speed select:                          1000Mb/s
        Force speed:                           no
        Force duplex:                          no
0x00008: STATUS (Device status register)     0x00282383
        Duplex:                               full
        Link up:                              link config
        Transmission:                          on
        DMA clock gating:                     disabled
        TBI mode:                             disabled
        Link speed:                            1000Mb/s
        Bus type:                              PCI Express
...

root@dellemc-diag-os:/etc/dn/diag# phytool --lb-test=100
TEST PASSED

NOTE: The loopback test and set-intf will terminate the ethernet driver. You need to reboot to
restart the driver cleanly.
[1]+  Terminated                  setsid /bin/kni -c 0x3 -n 2 -- -p 1 --config="(0,0,1)" >> /dev/
null

root@dellemc-diag-os:~# phytool --set-intf --speed=1000
[2]+  Done                          dhclient -q eth0
root@dellemc-diag-os:~# .....done
Port 0 Link Up - speed 1000 Mbps - full-duplex

root@dellemc-diag-os:~# root@dellemc-diag-os:~# phytool --show-intf
Settings for eth0:
    Supported ports: [ TP ]
    Supported link modes:   10baseT/Half 10baseT/Full
                           100baseT/Half 100baseT/Full
                           1000baseT/Full
    Supported pause frame use: Symmetric
    Supports auto-negotiation: Yes
    Advertised link modes:  10baseT/Half 10baseT/Full
                           100baseT/Half 100baseT/Full
                           1000baseT/Full
    Advertised pause frame use: No
```

```

Advertised auto-negotiation: Yes
Speed: 1000Mb/s
Duplex: Full
Port: Twisted Pair
PHYAD: 3
Transceiver: internal
Auto-negotiation: on
MDI-X: off (auto)
Supports Wake-on: pumbg
Wake-on: g
Current message level: 0x00000007 (7)
                                drv probe link
Link detected: yes

```

pltool

To test functionality of the CPLD and FPGA devices on the boards during startup, use the `pltool`.

The `pltool` also checks for the correct firmware loads. The tool uses the CLI to list the devices and their registers, and allows you to read and write registers in the device. The read functionality prints the details to the bit level and also any bit groupings and their meanings. The tool uses the SDI interface to get a list of devices and registers in the system, and then uses SDI to access the devices.

Tests

The `pltool` tests specified registers and values SDI identifies in the testable bits of the register. The tool reads the register using SDI interfaces and compares the testable bits from those bits the SDI database provides. If a mismatch occurs, an error displays.

CLI options

```

Syntax: pltool <option>
Show this help text:=
pltool --h                                     (or)
pltool -h
Test (RW) the scratchpad registers:=
pltool --test                                  (or)
pltool -t
List devices and registers:=
pltool --list [--lstype=<devicetype>]          (or)
pltool -l [-T <devicetype>]
List device names with address:=
pltool --listdevicenames [--devname=<devicename>] (or)
pltool -L [-n <devicename>]
Execute repeatedly command by count:=
pltool --iteration=max/<count> [option1] [option2]... (or)
pltool -I max/<count> [option1] [option2]...
Read the specified register of the device:=
pltool --read --devname=<devicename> --dev=<deviceaddr> --reg=<register> (or)
pltool -r -n <devicename> -D <deviceaddr> -R <register>
Write at the specified register of the device:=
pltool --write --devname=<devicename> --dev=<deviceaddr> --reg=<register> --val=<value>
(or)
pltool -w -n <devicename> -D <deviceaddr> -R <register> -V <value>
Dump all of the registers in a device or all devices and their current values:=
pltool --dump [--devname=<devicename>] [--dev=<deviceaddr>] (or)
pltool -d [-n <devicename>] [-D <deviceaddr>]

Usage:=
-h, --h                Show the help text
-t, --test             Test using the pre-programmed configuration or use supplied config
-l, --list             List the understood TLV codes and names
-T, --lstype          Device type

```

```

-L, --listdevicenames List Device name
-r, --read            Read operation
-w, --write          Write operation
-I, --iteration=      Iteration command execution
-n, --devname=       Device name
-D, --dev=           Device
                    (should be assigned 0 for lpc access)
-R, --reg=           Register
-V, --val=           Value to be set
-d, --dump           Dump the values in the registers of a device

```

Output

list output

```

root@dell-diag-os:~# pltool --list
CPLD1 0 cpld lpc 0 (U5)
  0x100 CPLD_VERSION bits:8 RO val:0 mask:0xff test:0 ver:0x0
    7:4 MAJOR_VER RO 0
    3:0 MINOR_VER RO 0
  0x101 BOARD_TYPE bits:8 RO val:0xff mask:0xff test:0 ver:0x0
    7:0 BOARD_TYPE RO 0x1
      3 <platform> Board
  0x102 SW_SCRATCH bits:8 RW val:0xde mask:0xff test:1 ver:0x0
    7:0 SW_SCRATCH RW 0xde
  0x103 CPLD_ID bits:8 RO val:0xff mask:0xff test:0 ver:0x0
    7:0 CPLD_ID RO 0x1
  0x10f BOARD_REV bits:8 RO val:0xff mask:0xff test:0 ver:0x0
    7:0 BOARD_REV RO 0
  0x110 CPLD_SEP_RST0 bits:8 RO val:0xff mask:0xff test:0 ver:0x0
    7 Reset Extender CPLD 4 RW 0x1
      0 Reset
      1 Not Reset
    6 Reset Extender CPLD 3 RW 0x1
      0 Reset
      1 Not Reset
    5 Reset Extender CPLD 2 RW 0x1
      0 Reset
      1 Not Reset
    4 PCA9548_RST7 RW 0x1
      0 Reset
      1 Not Reset
    3 PCA9548_RST6 RW 0x1
      0 Reset
      1 Not Reset
    2 PCA9548_RST5 RW 0x1
      0 Reset
      1 Not Reset
    1 PCA9548_RST4 RW 0x1
      0 Reset
      1 Not Reset

```

listdevicenames output

Based from the output of `--devicenames`, you can decide if you need to use the `--devname=` option in the read or write functions. You can access CPLD1 being at deviceaddress 0, using the register value for the register you want, such as:

```

root@dell-diag-os:~# pltool -listdevicenames
0x0 : CPLD1
0x3e : CPLD2
0x3e : CPLD3

```

```
0x3e : CPLD4
0x0 : SMF_FPGA
```

read output

```
root@dell-diag-os:~# pltool --read --devname=CPLD4 --dev=0x3e --reg=0x2
SW_SCRATCH : offset 0x02 = 0xde
7: 0 SW_SCRATCH = de
root@dell-diag-os:~#
```

write output

```
root@dell-diag-os:~# pltool --write --devname=CPLD4 --dev=0x3e --reg=0x2 --val=0xff
```

test output

```
root@dell-diag-os:~# pltool --test
Testing Programmable Devices:
PL Tool test:
CPLD1 ..... Passed
CPLD2: SW_SCRATCH..... Passed
CPLD3: SW_SCRATCH..... Passed
CPLD4: SW_SCRATCH..... Passed
SMF_FPGA ..... Passed
PL Tool: Overall test results ---- >>> Passed
```

Configuration file format

The pltool uses the device tree configuration format.

```
# C - CHIP (Master | Slave - Cpld or FPGA), Address, Name, Access
# R - Register, Offset, Mask, Name, RW , Default Val
# B - Bit(s), bitnum(s), Name, RW, Default Val
# I - Information on the bits
=====
C | CPLD | | CPLD1 | lpc | 0 | - | U5 | 0x01 | 0xf
R | 0x100 | 8 | 0xFF | CPLD_VERSION | RO | 0x0 | 0 | 0x0
B | 7:4 | | MAJOR_VER | RO | 0x0
B | 3:0 | | MINOR_VER | RO | 0x0
R | 0x101 | 8 | 0xFF | BOARD_TYPE | RO | 0xFF | 0 | 0x0
B | 7:0 | | BOARD_TYPE | RO | 0x01
I | 3 | | <platform> Board
R | 0x102 | 8 | 0xFF | SW_SCRATCH | RW | 0xDE | 1 | 0x0
B | 7:0 | SW_SCRATCH | RW | 0xDE
R | 0x103 | 8 | 0xFF | CPLD_ID | RO | 0xFF | 0 | 0x0
B | 7:0 | | CPLD_ID | RO | 0x01
R | 0x10F | 8 | 0xFF | BOARD_REV | RO | 0xFF | 0 | 0x0
B | 7:0 | | BOARD_REV | RO | 0x0
R | 0x110 | 8 | 0xFF | CPLD_SEP_RST0 | RO | 0xFF | 0 | 0x0
B | 7 | | Reset Extender CPLD 4 | RW | 0x1
I | 0 | | Reset
I | 1 | | Not Reset
B | 6 | | Reset Extender CPLD 3 | RW | 0x1
```

psutool

The `psutool` determines which PSUs are in the system, checks the Power Good setting, and reads the field replaceable unit (FRU) information. It does not look at the PSU fans and airflow direction of the fans.

Tests

The `psutool` looks for the presence of the PSU and if the PSU is present, it checks the Power Good setting in the CPLD. It does not read directly from the PSU but reads the CPLD information instead. If the PSU is present and it does not receive a Power Good signal, it does not know if the power plug is not installed or if the PSU is not operating correctly, so it displays a failure.

CLI options

```
DellEmc Diag - Power Supply Tool
version 1.4, x.xx.x.x-x
build, 2017/05/23,
```

```
Syntax: psutool <option>
```

```
Show the Help-text:=
```

```
psutool --h (or)
```

```
psutool -h
```

```
Test using the default config file:=
```

```
psutool --test [--supply=<power_supply>] (or)
```

```
psutool -t [-S <power_supply>]
```

```
Read the register on the Power Supply:=
```

```
psutool --read --supply=<power_supply> --reg=<register> (or)
```

```
psutool -r -S <power_supply> -r <register>
```

```
Write the value into the Power Supply Register:=
```

```
psutool --write --supply=<power_supply> --reg=<register> --val=<value> (or)
```

```
psutool -w <power_supply> -R <register> -V <value>
```

```
Verify PSU by reading SMF registers:=
```

```
psutool --lpc (or)
```

```
psutool -q
```

```
Execute repeatedly command by count:=
```

```
psutool --iteration=max/<count> [option1] [option2]... (or)
```

```
psutool -I max/<count> [option1] [option2]...
```

```
Usage:=
```

```
-h, --h          Show the help text
-t, --test       Test using the pre-programmed configuration or use supplied config
-S, --supply=   Power supply
-r, --read       Read operation
-w, --write      Write operation
-R, --register=  Register
-V, --value=     Value to be set
-I, --iteration= Iteration command execution
-q, --lpc        Verify PSU by reading SMF registers.
                  This option must be used along with test flag
```

test option

```
root@dell-diag-os:~# psutool --test --lpc
Power Supply Test all
Getting details of Power Supply 1 using LPC interface
Power Supply 1 is Present
Power Supply 1 Input Type AC
Power Supply 1 Input Voltage(VIN) : 203.250000 V
Power Supply 1 Output Voltage(VOUT) : 12.210000 V
```



```

Power Supply 1 Input Current(IIN) : 0.610000 A
Power Supply 1 Output Current(IOUT) : 9.150000 A
Power Supply 1 Input Power(PIN) : 124.000000 W
Power Supply 1 Output Power(POUT) : 111.700000 W
Power Supply 1 Temperature : 30.000000 C
Power Supply 1 Fan Present
Power Supply 1 Fan Status is Normal
Power Supply 1 Fan Airflow Type is F2B
Power Supply 1 Fan Speed(RPM) : 9072
Getting details of Power Supply 2 using LPC interface
Power Supply 2 is Present
Power Supply 2 Input Type AC
Power Supply 2 Output Voltage Low
Power Supply 2 Input Voltage(VIN) : 0.000000 V
Power Supply 2 Output Voltage(VOUT) : 0.000000 V
Power Supply 2 Input Current(IIN) : 0.000000 A
Power Supply 2 Output Current(IOUT) : 0.000000 A
Power Supply 2 Input Power(PIN) : 0.000000 W
Power Supply 2 Output Power(POUT) : 0.000000 W
Power Supply 2 Temperature : 6553.100098 C
Power Supply 2 Fan Present
Power Supply 2 Fan Status is Normal
Power Supply 2 Fan Airflow Type is F2B
Power Supply 2 Fan Speed(RPM) : 9120
Power Supply Test ..... Passed
root@dell-diag-os:~#

```

Configuration file format

This output example is for systems without a SMF chip.

```

=====
Power Supply 1 | Dell | i2c | 1 | 0x32 | 0x03 | 7 | 0 | 0x03 | 6 | 0 | /dev/i2c-1 0x70:0:0xff:
0x1 | i2c |
1 | 0x51 | 0x59 | /dev/i2c-1 0x70:0:0xff:0x10 | - | 1 | 0x40 | 0x4 | - | 6 | 0 | 1
Power Supply 2 | Dell | i2c | 1 | 0x32 | 0x03 | 3 | 0 | 0x03 | 2 | 0 | /dev/i2c-1 0x70:0:0xff:
0x1 | i2c |
1 | 0x50 | 0x58 | /dev/i2c-1 0x70:0:0xff:0x10 | - | 1 | 0x40 | 0x4 | - | 6 | 0 | 1

```

The configuration file for the `psutool` has a single supply on each line:

```

# Name | presence method | access method | bus | address | register | bits | pree
s | good reg | bits | good
=====
=====
#R | offset | size(in Bytes) | Name
#B | bit mask | name
LPC-INTERFACE
D |Power Supply 1
R | 0x234 | 2 |PSU_MAX_POWER
R | 0x236 | 1 |PSU_FUNCTION_SUPPORT
B | 0x04 |TEMP_SUPPORT
B | 0x02 |FAN_SUPPORT
B | 0x01 |VOLT_CURR_PWR_SUPPORT
R | 0x237 | 1 |PSU_STATUS
B | 0x10 |PSU_TYPE_MIS_MATCH
B | 0x08 |PSU_VOUT_LOW
B | 0x04 |PSU_VOUT_HIGH
B | 0x02 |PSU_TYPE
B | 0x01 |PSU_PRESENT_STATUS
R | 0x239 | 2 |PSU_TEMPERATURE
R | 0x23B | 2 |PSU_FAN_SPEED
R | 0x23D | 1 |PSU_FAN_STATUS
B | 0x04 |PSU_FAN_PRESENT_STATUS

```

- PSU Name —The name of the supply to display. The entries do not have to be in any named order.

- Tool Name—Name of the tool.
- Access to Present and Power Good—The type of access to the CPLD, i2c, LPC, and MEM.
- Access bus—For i2c devices. Shows which i2c bus to use.
- Address—For LPC devices, the address of the device or register.
- Register—Access size for LPC.
- Present Bit(s)—The bit or bits to indicate presence. The range of bits display as end:start and must be contiguous. Disaggregate sets of bits are not supported.
- PresentValue—The value present.
- Power Good Register, Bit(s) and Value—The bit or bits to indicate present. The range of bits display as end:start and must be contiguous. Disaggregate sets of bits are not supported.
- Tool Access Mux Definitions—If your system needs a MUX to access the CPLD, the MUX definitions display here.
- FRU and FAN Register access—Supports i2c, LPC, and MEM.

rtctool

The rtctool allows setting and testing of the real time clock (RTC) in the system.

Tests

CLI options

```
DellEmc Diag - RTC Tool
version 1.1, x.xx.x.x-x
build, 2017/05/23,

Syntax: rtctool <option>
  Show the help-text:=
    rtctool --help                (or)
    rtctool -h

  Read the current RTC:=
    rtctool --readrtc             (or)
    rtctool -r

  Test RTC device with user interrupt:=
    rtctool --testuie             (or)
    rtctool -u

  Test RTC device with alarm interrupt:=
    rtctool --testaie             (or)
    rtctool -a

  Test RTC device with periodic interrupt:=
    rtctool --testpie             (or)
    rtctool -p

  Test the RTC device:=
    rtctool --test                (or)
    rtctool -t

  Set rtc to new time (input all params in same order):=
    rtctool --setrtc --year=<year>, --mon=<month> --day=<day> --hour=<hour> --min=<min> --
sec=<sec> --tz=<offset>
    (or)
    rtctool -s -y <year> -m <month> -D <day> -H <hour> -M <min> -S <sec> -Z <offset>

  Execute repeatedly command by count:=
    rtctool --iteration=max/<count> [option1] [option2]... (or)
    rtctool -I max/<count> [option1] [option2]...

Usage:=
  -h, --help                Show the help text
  -r, --readrtc             Read operation
  -s, --setrtc              Set operation
  -u, --testuie            Test RTC device with user interrupt
```

```

-a, --testaie      Test RTC device with alarm interrupt
-p, --testpie      Test RTC device with periodic interrupt
-I, --iteration=    Iteration command execution
-y, --year=        Year
-m, --month=       Month
-D, --day=         Day
-H, --hour=        Hour
-M, --min=         Minute
-S, --sec=         Second
-Z, --offset=      +12.0 to -12.0 timezone offset

```

smartctl

smartctl controls the self-monitoring, analysis, and reporting technology (SMART) system built into most ATA/SATA and SCSI/SAS hard drives and solid-state drives. The purpose of SMART is to monitor the reliability of the hard drive and predict drive failures, and to carry out different types of drive self-tests.

smarttool

This optional tool is only available on systems using a SmartFusion chip. The SMF controls the PSU, LED control, fan monitoring, and temperature control of the switch.

Use the `smarttool` to get and set the SmartFusion Active regions and version, and to reprogram the SmartFusion FPGA.

SmartFusion (SMF) had two upgradable parts — Microcontroller subsystem (MSS) and field programmable gate array (FPGA), as shown. The online upgrade MSS images are in *.bin files. The online upgrade of FPGA image is in a *.dat file. The external upgrade of both MSS and FPGA is a *.pdb file.

There are three regions in the MSS: G — Golden, A — Primary, and B — Secondary. In principle, you cannot upgrade the region G and the bootloader. Golden is the default bootable region. If both regions A and B become corrupt, the region G image is used for booting. If A becomes corrupt, select region B and boot from region B.




Figure 5. smarttool upgradable MSS and FPGA

SMF upgrade binaries

- `<platform>_SMF_MSS_v1.3.1_A_region.bin`
- `<platform>_SMF_MSS_v1.3.1_B_region.bin`
- `<platform>_SMF_MSS_v1.3.1_G_region.bin`
- `<platform>_SMF_Logic_v0.3.dat`

CLI options

```
root@dell-diag-os:/opt/dell/diag/bin# smarttool
ERROR: main[100]: ERROR: Usage: smarttool <command> <UART dev> [<filename>|<REGION>]
```

Usage:

```
smarttool <command> [<UART dev>] [<filename>|<REGION>]
```

```
<command>    - Command string (Refer below for supported commands)
<UART dev>   - UART device name (say, "/dev/tty00")
<filename>   - Specify image file path for upgrade
<REGION>     - Specify image region.
               (G, A, B for MSS regions, g, a for FPGA region)
```

Following commands are supported:

```
-um - Upgrade MSS image
-uf - Upgrade FPGA image
-gmr - Get MSS running image region
-gfr - Get FPGA running image region
-gmv - Get MSS running image version
-smr - Select MSS running image region
-sfr - Select FPGA running image region
-help - Display help
```

SMF MSS upgrade

You can upgrade SMF MSS using the following steps:

To find out what region is running, use the `gmr` option.

- If MSS is running in region A, use the region B image to upgrade the MSS.
- If MSS is running in region B, use the region A image to upgrade the MSS.
- If MSS is running in region G, use the region A image to upgrade the MSS.

```
Upgrade mss A-region when mss is running in G-region:
./smarttool -um /dev/ttyS0 <platform>_SMF_MSS_v1.41_A_region.bin
Upgrade mss B-region when mss is running in A-region:
./smarttool -um /dev/ttyS0 <platform>_SMF_MSS_v1.41_B_region.bin
Upgrade mss A-region when mss is running in B-region:
./smarttool -um /dev/ <platform>_SMF_MSS_v1.41_A_region.bin
```

- 1 Copy all the binaries needed for the upgrade into a local directory.

```
Z9100/v1.41/* .g-os:/opt/ngos/bin/SMF1_41# scp ajogow@10.11.8.12:/tftpboot/ajogow/Z
Password:
Z9100_SMF_logic_v0.E.dat          100% 852KB 852.5KB/s 00:00
Z9100_SMF_MSS_v1.41_A_region.bin 100% 131KB 130.6KB/s 00:00
Z9100_SMF_MSS_v1.41_B_region.bin 100% 131KB 130.6KB/s 00:00
Z9100_SMF_MSS_v1.41_G_region.bin 100% 131KB 130.6KB/s 00:00
Z9100_SMF_MSS_v1.41_logic_v0.E.pdb 100% 412KB 412.1KB/s 00:00
Z9100_SMF_MSS_V1.41_logic_V0.E.Release Notes. 100% 128KB 128.0KB/s 00:00
root@dell-diag-os:/opt/ngos/bin/SMF1_41#
```

Figure 6. Copy all needed binaries

- 2 Check the MSS region using the `smarttool -gmr /dev/ttyS0` command.

```

root@dell-diag-os:/opt/ngos/bin# ./smarttool -gmr /dev/ttyS0
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for Smartfusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartGetImageRegion[303]: Sending get MSS region Action code ....
smartGetImageRegion[340]: MSS image running region is - G
smartUartClose[95]: UART dev closed

```

Figure 7. Check MSS region

- 3 Check the MSS version using `smarttool -gmv /dev/ttyS0` command.

```

root@dell-diag-os:/opt/ngos/bin# ./smarttool -gmv /dev/ttyS0
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for Smartfusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartGetImageVersion[411]: Sending get MSS version Action code ....
smartGetImageVersion[436]: MSS image version is - V1.31

smartUartClose[95]: UART dev closed
root@dell-diag-os:/opt/ngos/bin#

```

Figure 8. Check MSS version

- 4 Because the MSS is running in region G in this example, use the region A image to upgrade your device: `smarttool -um /dev/ttyS0 <Path_to_the_image>/<platform>_SMF_MSS_v1.41_A_region.bin`. The device automatically reboots after the upgrade.

```

Z9100_SMF_MSS_v1.41_A_region.bin ./smarttool_1024bytes -um /dev/ttyS0 ./SMF1_41/
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for Smartfusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartUpgradeImage[596]: Sending MSS upgrade Action code ....
smartUpgradeImage[621]: Upgrade selection mode done ...
getImageSize[875]: Image size = 0x20a64 bytes
smartUpgradeImage[642]: Sent and acknowledged image size, byte-3. sent-[0x0], recvd-[0x0]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-2. sent-[0x2], recvd-[0x2]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-1. sent-[0xa], recvd-[0xa]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-0. sent-[0x64], recvd-[0x64]
smartUpgradeImage[644]: Sent image size successfully ....
smartUpgradeImage[649]: Erasing eNVM ...
smartUpgradeImage[669]: SMART erase verification done! Proceeding image data transfer ...
smartUpgradeImage[672]: Image path selected is ./SMF1_41/Z9100_SMF_MSS_v1.41_A_region.bin
transferImage[723]: Initiating image transfer (Take minutes, Be patient)...
transferImage[821]: Reached end of image, address - 133732
transferImage[827]: End of image transfer
transferImage[837]: 8 bit Checksum value calculated by SMART is 0x17
transferImage[838]: 8 bit Checksum value calculated by CPU is 0x17
smartUpgradeImage[684]: Waiting for FPGA/eNVM to be programmed ...
[ y

BIOS (Dell, Inc.) Boot Selector

```

Figure 9. Upgrade region A

- 5 Ensure that MSS has upgraded successfully by using the `smarttool -gmv /dev/ttyS0` command after the system reboots.

```

root@dell-diaq-os:/opt/ngos/bin# ./smarttool_1024bytes -gmv /dev/ttyS0
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for Smartfusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartGetImageVersion[411]: Sending get MSS version Action code ....
smartGetImageVersion[436]: MSS image version is - V1.41

smartUartClose[95]: UART dev closed
root@dell-diaq-os:/opt/ngos/bin# █

```

Figure 10. Check MSS upgrade

Upgrading SMF FPGA

To upgrade your system using the FPGA method, follow these steps.

- 1 Copy all the binaries needed for upgrade into a local directory.


```

Z9100/v1.41/* .g-os:/opt/ngos/bin/SMFi_4i# scp ajogow@10.11.8.12:/tftpboot/ajogow/Z
Password:
Z9100_SMF_logic_v0.E.dat          100% 852KB 852.5KB/s  00:00
Z9100_SMF_MSS_v1.41_A_region.bin 100% 131KB 130.6KB/s  00:00
Z9100_SMF_MSS_v1.41_B_region.bin 100% 131KB 130.6KB/s  00:00
Z9100_SMF_MSS_v1.41_G_region.bin 100% 131KB 130.6KB/s  00:00
Z9100_SMF_MSS_v1.41_logic_v0.E.pdb 100% 412KB 412.1KB/s  00:00
Z9100_SMF_MSS_V1.41_logic_V0.E_Release_Notes. 100% 128KB 128.0KB/s  00:00
root@dell-diag-os:/opt/ngos/bin/SMFi_4i#

```

Figure 11. Copy needed binaries

- 2 Check the FPGA region using `smarttool -gfr /dev/ttyS0` command.

```

root@dell-diag-os:/opt/ngos/bin# ./smarttool_1024bytes -gfr /dev/ttyS0
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for SmartFusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartGetImageRegion[308]: Sending get FPGA region Action code ....
smartGetImageRegion[358]: FPGA image running region is - g
smartUartClose[95]: UART dev closed
root@dell-diag-os:/opt/ngos/bin# █

```

Figure 12. Check FPGA region

- 3 Get the current version of the FPGA using the `lpctool` utility. Get the FPGA running image version through the `./lpctool --read --addr=0x200 --size=b` registers at the LPC tool.

Table 1. SmartFusion FPGA registers

Offset	Name	Description
0x200	SMF_VER	SmartFusion FPGA version register

```

root@dell-diag-os:/opt/ngos/bin# ./lpctool --read --addr=0x200 --size=b
Byte Port 0x200 : 0xe
root@dell-diag-os:/opt/ngos/bin# █

```

Figure 13. Get current FPGA version

- 4 Upgrade the FPGA in smartFusion using the `# ./smarttool -uf /dev/ttyS0 <path_to_the_image>/<platform>_SMF_logic_v0.E.dat` command. To upgrade to region A, you must be in region G. The device automatically reboots after the upgrade.

```

Z9100_SMF_logic_v0.E.dat /bin# ./smartool_1024bytes -uf /dev/ttyS0 ./SMF1_41/
smartUartOpen[64]: UART dev - /dev/ttyS0 opened
smartUartInit[168]: UART initialization for Smartfusion communication done!
smartUartHandShake[950]: Initiating handshake ...
smartUartHandShake[982]: String 'SmF' Sent
smartUartHandShake[987]: 'h' Sent
smartUartHandShake[992]: 'a' Received
smartUartHandShake[995]: 'n' Sent
smartUartHandShake[1005]: 'd' Received
smartUartHandShake[1008]: 's' Sent
smartUartHandShake[1018]: 'h' Received
smartUartHandShake[1021]: 'a' Sent
smartUartHandShake[1031]: 'k' Received
smartUartHandShake[1034]: 'e' Sent
smartUartHandShake[1046]: 'k' Received
smartUartHandShake[1051]: Handshake is fine !!!
smartUpgradeImage[601]: Sending FPGA upgrade Action code ....
smartUpgradeImage[621]: Upgrade selection mode done ...
getImageSize[875]: Image size = 0xd51d4 bytes
smartUpgradeImage[642]: Sent and acknowledged image size, byte-3. sent-[0x0], recvd-[0x0]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-2. sent-[0xd], recvd-[0xd]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-1. sent-[0x51], recvd-[0x51]
smartUpgradeImage[642]: Sent and acknowledged image size, byte-0. sent-[0xd4], recvd-[0xd4]
smartUpgradeImage[644]: Sent image size successfully ....
smartUpgradeImage[654]: Erasing SPI flash ....
smartUpgradeImage[669]: SMART erase verification done! Proceeding image data transfer ...
smartUpgradeImage[672]: Image path selected is ./SMF1_41/Z9100_SMF_logic_v0.E.dat
transferImage[723]: Initiating image transfer (Take minutes, Be patient)...
transferImage[821]: Reached end of image, address - 872916
transferImage[827]: End of image transfer
transferImage[837]: 8 bit Checksum value calculated by SMART is 0xaa
transferImage[838]: 8 bit Checksum value calculated by CPU is 0xaa
smartUpgradeImage[684]: Waiting for FPGA/eNVM to be programmed ...

BIOS (Dell, Inc.) Boot Selector
Z9100 3.23.0.4 32 port 100G / 2 port sfp+ mgmt

```

Figure 14. Upgrade FPGA

- 5 Verify that the FPGA is upgraded using the `lpctool` utility. Get the FPGA running image version through the `./lpctool --read --addr=0x200 --size=b` registers of the LPC tool.

smbiostool

The `smbiostool` displays information about the BIOS and also reprograms the BIOS flash.

CLI options

```

DellEmc Diag - SMBIOS Tool
version 1.2, x.xx.x-x
build, 2017/05/23,

Usage:=
    smbiostool --h                               (or)
    smbiostool -h
Print the BIOS version:=
    smbiostool --biosversion                     (or)
    smbiostool -b
Check whether the SPI flash was detected:=
    smbiostool --biosflashdetect                 (or)
    smbiostool -f
Take a backup of the Current running BIOS:=
    smbiostool --biosread <FILEPATH>            (or)
    smbiostool -r
Update the bios:=
    smbiostool --biosupdate <FILEPATH>          (or)
    smbiostool -u <FILEPATH>
Dump the DMI table:=
    smbiostool --biosdumpall                     (or)
    smbiostool -d
Check whether the SPI flash was detected:=
    smbiostool --biosdumpfields <*options*>     (or)

```



```

    smbiostool -S <*options*>
<*options*> for biosdumpfields:=
  -q          Less verbose output
  -s          Only display the value of the given DMI string
  -t          TYPE Only display the entries of given type
  -u          Do not decode the entries
  --dump-bin <FILE> Dump the DMI data to a binary file
  --from-dump <FILE> Read the DMI data from a binary file
  -V          Display the version of dmidecode binary

```

Output

```

root@dell-diag-os:~# smbiostool --biosversion
x.xx.x.x_MRC48
root@dell-diag-os:~#

root@dell-diag-os:~# smbiostool --biosflashdetect
dmidecode -s system-version flashrom -V -p internal > /tmp/flhdet.txtFound Flash chip!!!
Found Winbond flash chip "W25Q128.V" (16384 kB, SPI) at physical address 0xff000000.

--biossupporteddevices is a list of devices supported by flashrom for reprogramming

--biosdumpall is the dump of the dmidecode data
--biosdumpfields [SUBOPT] allows you to dump specified fields using the options

The --bioserase and --bioswrite options have been rolled into a --biosupdate option.

```

storagetool

The storagetool tests mounted storage media.

The tool searches for any device in /dev/hd*, sda, sdb, or sdc and tests using them. The tests are file-copy tests to the device in the mounted file system. The files are written, compared and removed, leaving the file system as it was before the test. You can run more tests using the `bonnie++` tool and the tool reads SMART data from the device using the `smart` option.

Tests

The standard test creates a directory on the file system, opens a file for write, copies the file, compares the files, and reports errors. The test repeats 10 times. After the test completes successfully, storagetool removes all the test files.

CLI options

```

DellEmc Diag - Storage Tool
version 1.1, x.xx.x.x-x
build, 2017/05/23,

Syntax: storagetool <option>
  Show the help-text:=
    storagetool --h          (or)
    storagetool -h
  Mount usb device when inserted (mandatory):=
    storagetool --mountusb  (or)
    storagetool -m
  Unmount usb device before removed (mandatory):=
    storagetool --unmountusb (or)
    storagetool -u
  List devices:=
    storagetool --list      (or)
    storagetool -l

```

```

Test devices(empty for all):=
    storagetool --test [--dev=<device>]      (or)
    storagetool -t [-D <device>]
Get the smart status for a device
    storagetool --smart --dev=<device>      (or)
    storagetool -S -D <device>
Execute repeatedly command by count:=
    storagetool --iteration=max/<count> [option1] [option2]...(or)
    storagetool -I max/<count> [option1] [option2]...
Run the bonnie tools on the filesystems:=
    storagetool --bonnie                      (or)
    storagetool -B

```

Usage:

```

-h, --h                Show the help text
-m, --mountusb         Mount usb device when inserted (mandatory)
-u, --unmountusb       Unmount usb device when inserted (mandatory)
-l, --list             List all storage devices
-S, --smart           Smart Status
-D, --dev=            Device
-T, --test            Test using the pre-programmed configuration or use supplied config
-I, --iteration=      Iteration command execution
-B, --bonnie          Run the bonnie tools on the filesystems

```

Output

list output

```

root@dell-diag-os:~# storagetool --list
Mounted Filesystem Devices:
/dev/sda3 / ext4
root@dell-diag-os:~#

```

test output

```

root@dell-diag-os:~# storagetool --test --dev=/dev/sda3
Testing Storage Devices ..... Passed
root@dell-diag-os:~#

```

smart output

```

root@dell-diag-os:~# storagetool --smart --dev=/dev/sda3
smartctl 6.2 2013-07-26 r3841 [x86_64-linux-3.15.10] (local build)
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

=== START OF INFORMATION SECTION ===
Device Model:          InnoDisk Corp. - mSATA 3IE
Serial Number:         20160119AA144700000F
Firmware Version:     S141002c
User Capacity:         32,017,047,552 bytes [32.0 GB]
Sector Size:           512 bytes logical/physical
Rotation Rate:         Solid State Device
Device is:             Not in smartctl database [for details use: -P showall]
ATA Version is:        ACS-2 (minor revision not indicated)
SATA Version is:       SATA 3.0, 6.0 Gb/s (current: 6.0 Gb/s)
Local Time is:         Mon Jan 1 20:45:44 2001 UTC
SMART support is:      Available - device has SMART capability.
SMART support is:      Enabled

```

```

=== START OF ENABLE/DISABLE COMMANDS SECTION ===
SMART Enabled.

=== START OF READ SMART DATA SECTION ===
SMART overall-health self-assessment test result: PASSED

General SMART Values:
Offline data collection status: (0x00) Offline data collection activity
                               was never started.
                               Auto Offline Data Collection: Disabled.

Total time to complete Offline
data collection: ( 32) seconds.
Offline data collection
capabilities: (0x00) Offline data collection not supported.
SMART capabilities: (0x0003) Saves SMART data before entering
                               power-saving mode.
                               Supports SMART auto save timer.
Error logging capability: (0x00) Error logging NOT supported.
                               General Purpose Logging supported.
SCT capabilities: (0x0039) SCT Status supported.
                               SCT Error Recovery Control supported.
                               SCT Feature Control supported.
                               SCT Data Table supported.

SMART Attributes Data Structure revision number: 16
Vendor Specific SMART Attributes with Thresholds:
ID# ATTRIBUTE_NAME          FLAG     VALUE WORST THRESH TYPE      UPDATED  WHEN_FAILED RAW_VALUE
  1 Raw_Read_Error_Rate     0x0000   000    000    000    Old_age  Offline  -          0
  2 Throughput_Performance  0x0000   000    000    000    Old_age  Offline  -          0
  3 Spin_Up_Time            0x0000   000    000    000    Old_age  Offline  -          0
  5 Reallocated_Sector_Ct   0x0002   100    100    000    Old_age  Always   -          0
  7 Unknown_SSD_Attribute   0x0000   000    000    000    Old_age  Offline  -          0
  8 Unknown_SSD_Attribute   0x0000   000    000    000    Old_age  Offline  -          0
  9 Power_On_Hours          0x0002   100    100    000    Old_age  Always   -        3289
 10 Unknown_SSD_Attribute   0x0000   000    000    000    Old_age  Offline  -          0
 12 Power_Cycle_Count       0x0002   100    100    000    Old_age  Always   -         205
168 Unknown_Attribute      0x0000   000    000    000    Old_age  Offline  -          0
169 Unknown_Attribute      0x0000   000    000    000    Old_age  Offline  -          0
175 Program_Fail_Count_Chip 0x0000   000    000    000    Old_age  Offline  -          0
192 Power-Off_Refract_Count 0x0000   000    000    000    Old_age  Offline  -          0
   1 Raw_Read_Error_Rate     0x0000   000    000    000    Old_age  Offline  -
2199023255552
197 Current_Pending_Sector  0x0000   000    000    000    Old_age  Offline  -          0
240 Unknown_SSD_Attribute   0x0000   000    000    000    Old_age  Offline  -          0
225 Unknown_SSD_Attribute   0x0000   000    000    000    Old_age  Offline  -          0
170 Unknown_Attribute      0x0003   100    100    ---    Pre-fail Always   -        1966080
173 Unknown_Attribute      0x0002   100    100    ---    Old_age  Always   -        7602213
229 Unknown_Attribute      0x0002   100    100    ---    Old_age  Always   -
88470212370072
236 Unknown_Attribute      0x0002   100    100    ---    Old_age  Always   -          0
235 Unknown_Attribute      0x0002   100    000    ---    Old_age  Always   -          0
176 Erase_Fail_Count_Chip   0x0000   100    000    ---    Old_age  Offline  -          0

Read SMART Log Directory failed: scsi error aborted command
Read SMART Error Log failed: scsi error aborted command
Read SMART Self-test Log failed: scsi error aborted command
Selective Self-tests/Logging not supported

root@dell-diag-os:~#

```

bonnie output

```

root@dell-diag-os:~# storagetool --bonnie --dev=/dev/sda3
Using uid:0, gid:0.

```

```

Writing with putc()...done
Writing intelligently...done
Rewriting...done
Reading with getc()...done
Reading intelligently...done
start 'em...done...done...done...
Create files in sequential order...done.
Stat files in sequential order...done.
Delete files in sequential order...done.
Create files in random order...done.
Stat files in random order...done.
Delete files in random order...done.
Version 1.03      -----Sequential Output----- --Sequential Input- --Random-
                  -Per Chr- --Block-- -Rewrite- -Per Chr- --Block-- --Seeks--
Machine          Size K/sec %CP K/sec %CP K/sec %CP K/sec %CP K/sec %CP /sec %CP
dell-diag-os     250M 27664 96 245045 62 +++++ +++ 31064 100 +++++ +++ +++++ +++
                  -----Sequential Create----- -----Random Create-----
                  -Create-- --Read--- -Delete-- -Create-- --Read--- -Delete--
files /sec %CP /sec %CP /sec %CP /sec %CP /sec %CP /sec %CP /sec %CP
                 32 32494 97 +++++ +++ 31198 66 31739 92 +++++ +++ 26511 56
dell-diag-os,250M,27664,96,245045,62,+++++,+++,31064,100,+++++,+++,+++++,+++,32,32494,97,+++++,+
++,31198,66,31739,92,+++++,+++,26511,56

```

smartctl

To get a usage summary, use the `smartctl -h` command.

```

root@dell-diag-os:/opt/dell/diag/bin# smartctl -h
smartctl 6.2 2013-07-26 r3841 [x86_64-linux-3.15.10] (local build)
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

Usage: smartctl [options] device

===== SHOW INFORMATION OPTIONS =====

-h, --help, --usage
    Display this help and exit

-V, --version, --copyright, --license
    Print license, copyright, and version information and exit

-i, --info
    Show identity information for device

--identify[=[w][nvb]]
    Show words and bits from IDENTIFY DEVICE data (ATA)

-g NAME, --get=NAME
    Get device setting: all, aam, apm, lookahead, security, wcache, rcache, wcreorder

-a, --all
    Show all SMART information for device

-x, --xall
    Show all information for device

--scan
    Scan for devices

--scan-open
    Scan for devices and try to open each device

===== SMARTCTL RUN-TIME BEHAVIOR OPTIONS =====

-q TYPE, --quietmode=TYPE (ATA)
    Set smartctl quiet mode to one of: errorsonly, silent, nserial

```

```

-d TYPE, --device=TYPE
    Specify device type to one of: ata, scsi, sat[,auto][,N][+TYPE], usbcypress[,X],
usbjmicron[,p][,x][,N], usbsunplus, marvell, areca,N/E, 3ware,N, hpt,L/M/N, megaraid,N,
cciss,N, auto, test

-T TYPE, --tolerance=TYPE (ATA)
    Tolerance: normal, conservative, permissive, verypermissive

-b TYPE, --badsum=TYPE (ATA)
    Set action on bad checksum to one of: warn, exit, ignore

-r TYPE, --report=TYPE
    Report transactions (see man page)

-n MODE, --nocheck=MODE (ATA)
    No check if: never, sleep, standby, idle (see man page)

===== DEVICE FEATURE ENABLE/DISABLE COMMANDS =====

-s VALUE, --smart=VALUE
    Enable/disable SMART on device (on/off)

-o VALUE, --offlineauto=VALUE (ATA)
    Enable/disable automatic offline testing on device (on/off)

-S VALUE, --saveauto=VALUE (ATA)
    Enable/disable Attribute autosave on device (on/off)

-s NAME[,VALUE], --set=NAME[,VALUE]
    Enable/disable/change device setting: aam,[N|off], apm,[N|off],
lookahead,[on|off], security-freeze, standby,[N|off|now],
wcache,[on|off], rcache,[on|off], wcreorder,[on|off]

===== READ AND DISPLAY DATA OPTIONS =====

-H, --health
    Show device SMART health status

-c, --capabilities (ATA)
    Show device SMART capabilities

-A, --attributes
    Show device SMART vendor-specific Attributes and values

-f FORMAT, --format=FORMAT (ATA)
    Set output format for attributes: old, brief, hex[,id|val]

-l TYPE, --log=TYPE
    Show device log. TYPE: error, selftest, selective, directory[,g|s],
xerror[,N][,error], xselftest[,N][,selftest],
background, sasphy[,reset], sataphy[,reset],
scttemp[sts,hist], scttempint,N[,p],
scterc[,N,M], devstat[,N], ssd,
gplog,N[,RANGE], smartlog,N[,RANGE]

-v N,OPTION , --vendorattribute=N,OPTION (ATA)
    Set display OPTION for vendor Attribute N (see man page)

-F TYPE, --firmwarebug=TYPE (ATA)
    Use firmware bug workaround:
    none, nologdir, samsung, samsung2, samsung3, xerrorlba, swapid

-P TYPE, --presets=TYPE (ATA)
    Drive-specific presets: use, ignore, show, showall

-B [+]FILE, --drivedb=[+]FILE (ATA)
    Read and replace [add] drive database from FILE
    [default is +/usr/etc/smart_drivedb.h

```

```

and then /usr/share/smartmontools/drivedb.h]
===== DEVICE SELF-TEST OPTIONS =====

-t TEST, --test=TEST
  Run test. TEST: offline, short, long, conveyance, force, vendor,N,
                  select,M-N, pending,N, afterselect,[on|off]

-C, --captive
  Do test in captive mode (along with -t)

-X, --abort
  Abort any non-captive test on device

===== SMARTCTL EXAMPLES =====

smartctl --all /dev/hda                (Prints all SMART information)

smartctl --smart=on --offlineauto=on --saveauto=on /dev/hda
                                           (Enables SMART on first disk)

smartctl --test=long /dev/hda          (Executes extended disk self-test)

smartctl --attributes --log=selftest --qu
MODE, --nocheck=MODE (ATA) No check if: never, sleep, standby, idle (see man page)
===== DEVICE FEATURE ENABLE/DISABLE COMMANDS =====

```

bonnie++

bonnie++ is a test suite for storage devices that runs more comprehensive tests than the standard file system tests using the storagetool. You can run bonnie++ outside of the storagetool, but for logging purposes, use bonnie++ within storagetool.

```

root@dell-diag-os:/opt/dell/diag/bin# bonnie++
You must use the "-u" switch when running as root.
usage: bonnie++ [-d scratch-dir] [-s size (Mb) [:chunk-size (b)]]
               [-n number-to-stat[:max-size[:min-size][:num-directories]]]
               [-m machine-name]
               [-r ram-size-in-Mb]
               [-x number-of-tests] [-u uid-to-use:gid-to-use] [-g gid-to-use]
               [-q] [-f] [-b] [-p processes | -y]

Version: 1.03
root@dell-diag-os:/opt/dell/diag/bin#

```

temptool

The temptool reads from the temperature devices and reports back the temperatures.

The temperature sensors on the board are commonly connected through i2c busses. The configuration files specify the type of the device, the sensor name, the instance in that device, its location on the board, and the thresholds for reporting low, normal, and critical temperatures. To gather the information from the devices and report the values, the temptool uses the i2ctool.

Tests

The tool retrieves the data from the devices and validates that the temperatures are within the acceptable range.

CLI options

NOTE: Before using any commands, you must set the MUX settings to select the bus segments the temperature sensors are on.

```
DellEmc Diag - Temperature Tool
version 1.4, x.xx.x.x-x
build, 2017/05/23,

Syntax: temptool <option>
  Show the help-text:=
    temptool --h           (or)
    temptool -h
  Test the pre-programmed configuration:=
    temptool --test --config=<config_file> [--lpc]   (or)
    temptool -t -f <config_file> [-l]
  Execute repeatedly command by count:=
    temptool --iteration=max/<count> [option1] [option2]... (or)
    temptool -I max/<count> [option1] [option2]...
  Show the current temperature-device values:=
    temptool --show --config=<config_file> [--lpc]   (or)
    temptool -x -f <config_file> [-l]

Usage:=
  -h, --h           Show the help text
  -t, --test       Test using the pre-programmed configuration or use supplied config
  -x, --show       Show operation
  -f, --config=    To specify the location of the config file e.g. /etc/dn/diag/<file_name>
  -I, --iteration= Iteration command execution
  -q, --lpc       Use LPC interface for reading temperature
                  LPC option MUST be used with show/test flags
```

- test — Tests the sensors to make sure they are within the acceptable range.
- show — Shows the current temperature values.

Output

test output

```
root@dell-diag-os:/opt/dell/diag/bin# temptool --test --lpc
Testing Temp sensor devices:
Temperature Sensor 1 ..... Passed
Temperature Sensor 2 ..... Passed
Temperature Sensor 3 ..... Passed
Temperature Sensor 4 ..... Passed
Temperature Sensor 5 ..... Passed
Temperature Sensor 6 ..... Passed
Temperature Sensor 7 ..... Passed
Temperature Sensor 8 ..... Passed
Temperature Sensor 9 ..... Passed
Temp Sensors: Overall test results ----- >>> Passed
root@dell-diag-os:/opt/dell/diag/bin#

root@dell-diag-os:/opt/dell/diag/bin# temptool --show --lpc
Temperature Sensor 1 temperature value is 30.3 C
Temperature Sensor 2 temperature value is 23.1 C
Temperature Sensor 3 temperature value is 22.2 C
Temperature Sensor 4 temperature value is 26.0 C
Temperature Sensor 5 temperature value is 21.8 C
Temperature Sensor 6 temperature value is 22.0 C
Temperature Sensor 7 temperature value is 23.5 C
```

```
Temperature Sensor 8 temperature value is 31.0 C
Temperature Sensor 9 temperature value is 42.0 C
root@dell-diag-os:/opt/dell/diag/bin#
```

Configuration file format

This output example is for systems without a SMF chip.

```
TEMPLATE:Name of sensor|sensor type|dev bus path|dev adrs|diode|mux|low|warn|critical|COMMENTS
LM75 sensor |LM75|/dev/i2c-1|0x4d|0|/dev/i2c-1 0x70:0x00:0xff:0x1|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x49|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x4a|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x4b|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x4c|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x4e|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
LM75 sensor |LM75|/dev/i2c-1|0x4f|0|/dev/i2c-1 0x70:0x00:0xff:0x2|-5|45|50| <<==
```

The temperature sensor configuration file displays each sensor on its own line.

- **Sensor Name** — The name that describes the purpose of the sensor.
- **Sensor Driver Type** — The type of chip used for the sensor. LM75, MAX6699, and EMC1428 are supported.

```
TEMPLATE:Name of sensor|sensor type|dev bus path|dev adrs|diode|mux|low|warn|crii
tical|COMMENTS
=====
#TEMPLATE:Name of sensor|sensortype|access_type|temp_reg_offset|temp_unit|sensorr
_status_offset
LPC-INTERFACE
Temperature Sensor 1 |LM75|lpc|0x14|0.1|0xdc
Temperature Sensor 2 |LM75|lpc|0x16|0.1|0xdd
Temperature Sensor 3 |LM75|lpc|0x18|0.1|0xde
Temperature Sensor 4 |LM75|lpc|0x1a|0.1|0xdf
Temperature Sensor 5 |LM75|lpc|0x1c|0.1|0xe0
Temperature Sensor 6 |LM75|lpc|0x1e|0.1|0xe1
Temperature Sensor 7 |LM75|lpc|0x20|0.1|0xe2
Temperature Sensor 8 |LM75|lpc|0x22|0.1|0xe3
Temperature Sensor 9 |LM75|lpc|0x24|0.1|0xe4
=====
/dev/i2c-1 0x70:0:0xff:0x9:,:0x74:1:0xff:0xa
1500000
```

vmetool

The CPLDupgradetool uses vmetool to upgrade CPLD.

NOTE: Do not call the vmetool directly; use the cp1dupgradetool to call the vmetool.

CLI options

```
root@dell-diag-os:/opt/dell/diag/bin# vmetool
      Lattice Semiconductor Corp.
      ispVME(tm) V12.2 Copyright 1998-2011.
For daisy chain programming of all in-system programmable devices
Usage: vme [option] vme_file [vme_file]
Example: vme vme_file1.vme vme_file2.vme
Example: vme -c | -cl | -ch
Example: where sel_pin will be LOW for -cl option and HIGH for -ch
Example: vme -c | -cl | -ch vme_file1.vme vme_file2.vme
root@dell-diag-os:/opt/dell/diag/bin#
```


edatool

The `edatool` is included in the diagnostic tools. Use the tool to test the basic functionality of the system.

The `edatool` executes a script of simple commands, similar to commands in the CLI. Usually, the diagnostics tools run these types of tests. The success or failure of these tools is reported, and at the end of the `edatool` run, reports the PASSED or FAILED results in a standard format the test scripts can easily parse.

Tests

The `edatool` does not have a test command, but instead runs all the tests that are scripted.

CLI options

```
DellEmc Diag - Extended Diagnostics Application
version 1.4, x.xx.x.x-x
build, 2017/05/23,
```

```
Syntax: edatool <option>
Show the Help-text:=
    edatool --h                                (or)
    edatool -h
Lists tests in config files:=
    edatool --list                             (or)
    edatool -l
Config file to use for tests:=
    edatool --config=<config_file>             (or)
    edatool -f <config_file>
Config file to use for extended tests:=
    edatool --extended-config=<config_file>    (or)
    edatool -X <config_file>
Display test list or test result or modify test item status:=
    edatool --testlist=show/result/<on/off,<test_id>,<test_id>...> (or)
    edatool -L show/result/<on/off,<test_id>,<test_id>...>
Run all or selected test item in test list:=
    edatool --testrun=all/<test_id>            (or)
    edatool --R all/<test_id>
Execute repeatedly command by count:=
    edatool --iteration=max/<count> [option1] [option2]...    (or)
    edatool -I max/<count> [option1] [option2]...
```

```
Usage:=
-h, --h                Show the help text
-l, --list             List the understood TLV codes and names
-I, --iteration=       Iteration command execution
-L, --testlist=       Test list status
-R, --testrun=        Run test item
-f, --config=         To specify the location of the config file e.g. /etc/dn/diag/
<file_name>
-X, --extended-config= Config file to use for extended tests
```

Output

```
root@dell-diag-os:~# edatool
*****
* Diagnostics Application *
*****
Dell-EMC Diag edatool version 1.4, package x.xx.x.x 2016/11/21
```

```

Dell-EMC Diag cputool - version 1.1 package x.xx.x.x 2016/11/21
Dell-EMC Diag fantool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag gpiotool - version 1.4 package x.xx.x.x 2016/11/21
Dell-EMC Diag i2ctool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag ledtool - version 1.0 package x.xx.x.x 2016/11/21
Dell-EMC Diag lpctool - version 1.0 package x.xx.x.x 2016/11/21
Dell-EMC Diag memtool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag nputool - version 1.0 sdk-6.5.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag nvrantool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag opticstool - version 1.0 package x.xx.x.x 2016/11/21
Dell-EMC Diag pcitool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag pltool - version 1.5 package x.xx.x.x 2016/11/21
Dell-EMC Diag psutool - version 1.4 package x.xx.x.x 2016/11/21
Dell-EMC Diag rtctool - version 1.1 package x.xx.x.x 2016/11/21
Dell-EMC Diag smbiostool - version 1.2 package x.xx.x.x 2016/11/21
Dell-EMC Diag storagetool - version 1.1 package x.xx.x.x 2016/11/21
Dell-EMC Diag temptool - version 1.4 package x.xx.x.x 2016/11/21

```

Testing PCI devices:

```

+ Checking PCI 00:00.0, ID=1f0c8086 ..... Passed
+ Checking PCI 00:01.0, ID=1f108086 ..... Passed
+ Checking PCI 00:02.0, ID=1f118086 ..... Passed
+ Checking PCI 00:03.0, ID=1f128086 ..... Passed
+ Checking PCI 00:0e.0, ID=1f148086 ..... Passed
+ Checking PCI 00:0f.0, ID=1f168086 ..... Passed
+ Checking PCI 00:13.0, ID=1f158086 ..... Passed
+ Checking PCI 00:14.0, ID=1f418086 ..... Passed
+ Checking PCI 00:14.1, ID=1f418086 ..... Passed
+ Checking PCI 00:14.2, ID=1f418086 ..... Passed
+ Checking PCI 00:16.0, ID=1f2c8086 ..... Passed
+ Checking PCI 00:17.0, ID=1f228086 ..... Passed
+ Checking PCI 00:18.0, ID=1f328086 ..... Passed
+ Checking PCI 00:1f.0, ID=1f388086 ..... Passed
+ Checking PCI 00:1f.3, ID=1f3c8086 ..... Passed
+ Checking PCI 01:00.0, ID=837514e4 ..... Passed
+ Checking PCI 01:00.1, ID=837514e4 ..... Passed
PCI devices: Overall test results ----- >>> Passed

```

Testing I2C devices:

Checking I2C devices on bus 0:

```

+ Checking Clock GEN          0x69 ..... Passed
+ Checking SPD0                0x50 ..... Passed

```

Checking I2C devices on bus 1:

```

+ Checking CPU Board I2C Mux   0x70 ..... Passed
+ Checking CPU Board EEPROM1   0x53 ..... Passed
+ Checking CPU Board EEPROM2   0x57 ..... Passed
+ Checking Switch Brd EEPROM   0x50 ..... Passed
+ Checking CPLD2                0x3e ..... Passed
+ Checking CPLD3                0x3e ..... Passed
+ Checking CPLD4                0x3e ..... Passed
+ Checking SFP+ 1               0x50 ..... Passed
+ Checking SFP+ 2               0x50 ..... Passed
+ Checking SFP+ 3               0x50 ..... Passed
+ Checking SFP+ 4               0x50 ..... Passed

```

```
+ Checking SFP+ 5      0x50 ..... Passed
+ Checking SFP+ 6      0x50 ..... Passed
+ Checking SFP+ 7      0x50 ..... Passed
+ Checking SFP+ 8      0x50 ..... Passed
+ Checking SFP+ 9      0x50 ..... Passed
+ Checking SFP+ 10     0x50 ..... Passed
+ Checking SFP+ 11     0x50 ..... Passed
+ Checking SFP+ 12     0x50 ..... Passed
+ Checking SFP+ 13     0x50 ..... Passed
+ Checking SFP+ 14     0x50 ..... Passed
+ Checking SFP+ 15     0x50 ..... Passed
+ Checking SFP+ 16     0x50 ..... Passed
+ Checking SFP+ 17     0x50 ..... Passed
+ Checking SFP+ 18     0x50 ..... Passed
+ Checking SFP+ 19     0x50 ..... Passed
+ Checking SFP+ 20     0x50 ..... Passed
+ Checking SFP+ 21     0x50 ..... Passed
+ Checking SFP+ 22     0x50 ..... Passed
+ Checking SFP+ 23     0x50 ..... Passed
+ Checking SFP+ 24     0x50 ..... Passed
+ Checking SFP+ 25     0x50 ..... Passed
+ Checking SFP+ 26     0x50 ..... Passed
+ Checking SFP+ 27     0x50 ..... Passed
+ Checking SFP+ 28     0x50 ..... Passed
+ Checking SFP+ 29     0x50 ..... Passed
+ Checking SFP+ 30     0x50 ..... Passed
+ Checking SFP+ 31     0x50 ..... Passed
+ Checking SFP+ 32     0x50 ..... Passed
+ Checking SFP+ 33     0x50 ..... Passed
+ Checking SFP+ 34     0x50 ..... Passed
+ Checking SFP+ 35     0x50 .....
```

Configuration file format

Find the standard configuration files in the `/etc/dn/diag` directory. The configuration files are `default_eda_script.cfg` and `default_eda_extended_script.cfg` that hold the scripts for normal and extended tests, respectively.

The configuration file format has a single command on a single line. The `edatool` does not use the complex shell script constructs in the configuration file.

```
root@dell-diag-os:/etc/dn/diag# cat default_eda_script.cfg
cputool --version
fantool --version
gpiotool --version
i2ctool --version
ledtool --version
lpctool --version
mentool --version
nputool --version
nvramtool --version
optictool --version
pcitool --version
pltool --version
psutool --version
rtctool --version
smbiostool --version
storagetool --version
temptool --version
pcitool --test
i2ctool --test
temptool --test
psutool --test --lpc
fantool --test --lpc
temptool --test --lpc
pltool --test
optictool --show
mentool --test
rtctool --test
storagetool --list
eepromtool --eeprom=CPUEEPROM1 --test
nputool -i -t 0
root@dell-diag-os:/etc/dn/diag#

root@dell-diag-os:/etc/dn/diag# cat default_eda_extended_script.cfg
ledtool --test
fantool --test --lpc
root@dell-diag-os:/etc/dn/diag#
```

Do not modify the default scripts as they are used as tests for the general health status of the switch. Instead, you can write your own scripts and use them through `edatool` using the `--config=` and `--extended-config=` parameters, as shown.

```
root@dell-diag-os:/etc/dn/diag# edatool --config=/etc/dn/diag/eda.test
The extended tests are only run if the EDA Extended Tests bit is set in the NVRAM using the
nvramtool
EDA Control Bits : offset 0x55 = 0x1
5:4 EDA Verbose Level = 0
 3 EDA Extended Tests = 0
 2 EDA Verbose Mode = 0
 1 EDA Stop on Error = 0
 0 EDA Enable = 1
```

Verbose mode

Use the following steps to enable and set the verbose level.

- 1 Set the Verbose level with a value of 0 to 3 using bits 4 and 5 of the EDA control reg (0x55).
For example, to set the verbose level to 2, set bit 5 to 1 (5=1) and bit 4 to 0 (4=0).

```
root@dellemc-diag-os:~# nvrantool --write --reg=0x55 --val=0x25
```

The value is written in hexadecimal. The xx10x1xx shows the bit positions of 2, 4&5, and bit 0 on the right.

- 2 Enable Verbose mode by setting bit 2 of the same reg to 1.

NOTE: If you disable Verbose mode, or bit 2 of reg 0x55 is set to 0, the default verbosity level is 0/zero.

EDA control reg (0x55):

- 5:4—EDA Verbose Level = 0/1/2/3 or verbosity level 0, 1, 2, or 3.
- 3—EDA Extended Tests
- 2—EDA Verbose Mode = 0/1 (0=disabled; 1=enabled)
- 1—EDA Stop on Error
- 0—EDA Enable

NOTE: If you do not need the Verbose mode settings to persist through reboots, you can use the environment variable method to enable Verbose Mode.

```
export VERB_LEVEL=<setting 0,1,2 or 3>
```

To clear the environment variable, use the `unset VERB_LEVEL` command.

Diagnostic package

The diagnostic applications, libraries, and configurations are packaged in a debian package called `dn-diags-{PLATFORM}-{PACKAGE_VERSION}.deb`.

Executables are placed in `/opt/ngos/bin`, libraries are placed in `/opt/ngos/lib`, and configurations are placed in `/etc/dn/diag`. To install the package on the switch, use the `dpkg --install <package_name>` command.

Technical support

Dell EMC Support provides a range of documents and tools to assist you with effectively using Dell EMC equipment and mitigating the impact of network outages.

Through Dell EMC Support you can obtain technical information regarding Dell EMC products, access to software upgrades and patches, and open and manage your Technical Assistance Center (TAC) cases. Dell EMC support provides integrated, secure access to these services.

Topics:

- [Accessing support services](#)
- [Technical assistance center](#)
- [Hardware replacement](#)

Accessing support services

The URL for Dell EMC support is <http://www.dell.com/support>. You must have a userid and password to access support services. If you do not have a userid and password, you can request these at the website.

To request a userid, password, and Dell EMC support services:

- 1 On the Dell EMC support page, click the **Account Request** link.
- 2 Fill out the User Account Request form and click **Send**. You will receive your userid and password by email.
- 3 To access Dell EMC support services, click the **LOGIN** link and enter your userid and password.

Technical assistance center

How to contact Dell EMC TAC Log in to Dell EMC support at <http://www.dell.com/support> and select the Service Request tab.

Information to submit when opening a support case

- Your name, company name, phone number, and email address
- Preferred method of contact
- Model number
- Software version number
- Symptom description

Managing your case Log in to Dell EMC support and select the **Service Request** tab to view all open cases and Return Materials Authorizations (RMAs).

Technical documentation Log in to Dell EMC support and select the **Documents** tab. You can access this page without logging in using the **Documentation** link on the Support page.

Contact information Web: www.dell.com.

Email: Networking-Support@Dell.com

Hardware replacement

To request replacement hardware, follow these steps:

- 1 Determine the part number and serial number of the component.
To list the numbers for all components installed in the chassis, use the `show hardware` command.
- 2 Request an RMA number from TAC by opening a support case. Open a support case by:
 - Using the Create Service Request form on the Support page.
 - Contacting Dell EMC directly by email or by phone.
 - Provide the following information when using email or phone:
 - Part number, description, and serial number of the component.
 - Your name, organization name, telephone number, fax number, and email address.
 - Shipping address for the replacement component, including a contact name, phone number, and email address.