


Dell IE600

Headset


Quick Start Guide



What's in the box



Features




1 Microphone

2 Control button


 Answer/End call

1 Plug in the headset.




2 In the device-selection window, select Headset and click OK.

NOTE: If the device-selection window is not displayed, see [Enable auto popup](#).




Enable Auto Pop-up

1. Disconnect the headset.
2. In Windows search, type **Dell Audio**. From the list that appears click **Dell Audio**.
- NOTE:** **Dell Audio** is required for the headset control button to work with your computer. For more information, see *User's Guide* at dell.com/support/manuals.
3. Click **Advanced**.



4. Click **Jack Information**. Enable the auto pop-up dialog.



5. Plug in the headset.
6. In the device-selection window, select **Headset** and click **OK**.