



Views

Specifications

Copyright © 2015 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies. 2015–11 Rev. A03

Regulatory model: P64G | Type: P64G001/P64G003/P64G004/P64G005

Computer model: Inspiron 14-5451/Inspiron 14-5452/Inspiron 14-5458/Inspiron 14-5459









Base



Display

1 Power and battery-status light/hard-drive activity light

Indicates the power and battery-charge status. Press Fn+H to toggle this light between hard-drive activity light and battery-status light.

Solid white Power adapter is connected and the battery has more than 5% charge.

Amber

Off

- battery has less than 5% charge.
 Power adapter is connected and the battery is fully charged.
 - Computer is running on battery and the battery has more than 5% charge.

Computer is running on battery and the

• Computer is in sleep state, hibernation, or turned off.



Left







Right



Base



Display

1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

Network port (Inspiron 14-5458 and 2 Inspiron 14-5459 only)

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.

3 HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

4 USB 3.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

5 Media-card reader

Reads from and writes to media cards.



Right

Front

Left



Right



Base



Display

1 Headset port

Connect a headphone, a microphone, or a headset (headphone and microphone combo).

2 USB 2.0 ports (2)

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

3 Optical drive

Reads from and writes to CDs and DVDs.

4 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.



Base



Right

Front

Left



Base



Display

1 Left-click area

Press to left-click.

2 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click.

3 Right-click area

Press to right-click.

4 Power button

Press to turn on the computer if it is turned off, in sleep state or in hibernate state.

Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at www.dell.com/support/manuals.



_

Display

Front

Left

Right



Base



Display



1 Left microphone (Inspiron 14-5458 and Inspiron 14-5459 only)

Provides digital sound input for audio recording, voice calls, and so on.

2 Camera

Allows you to video chat, capture photos, and record videos.

3 Camera-status light

Turns on when the camera is in use.


4 Right microphone

Provides digital sound input for audio recording, voice calls, and so on.



Dimensions and weight

Height:	
Touch (Inspiron 14-5458 and Inspiron 14-5459 only)	23.60 mm (0.93 in)
Non-touch	23.35 mm (0.92 in)
Width	345 mm (13.58 in)
Depth	243 mm (9.56 in)
Weight (minimum):	
Touch (Inspiron 14-5458 and Inspiron 14-5459 only)	2.18 kg (4.80 lb)
Non-touch	1.92 kg (4.23 lb)
	NOTE : The weight of your laptop varies depending on the configuration ordered and the manufacturing variability.



System information

Computer model	Inspiron 14-5458 and Inspiron 14-5459	Inspiron 14-5451 and Inspiron 14-5452
Processor	 4th Generation Intel Core i3/i5 5th Generation Intel Core i3/i5/i7 6th Generation Intel Core i3/i5/i7 Intel Celeron Dual Core Intel Pentium Dual Core 	Intel Celeron Dual CoreIntel Pentium Quad Core
Chipset	Integrated in processor	Integrated in processor





Specifications

Memory

	Inspiron 14-5458 and Inspiron 14-5459	Inspiron 14-5451	Inspiron 14-5452
Slots	Two SODIMM slots	One SODIMM slot	One SODIMM slot
Туре	DDR3L	DDR3L	DDR3L
Speed	1600 MHz	1300 MHz	1600 MHz
Configurations supported	2 GB, 4 GB, 6 GB, 8 GB, 12 GB, and 16 GB	2 GB, 4 GB, and 8 GB	2 GB, 4 GB, and 8 GB



Ports and connectors

External:	
Network	One RJ45 port (Inspiron 14-5458 and Inspiron 14-5459 only)
USB	Two USB 2.0 portsOne USB 3.0 port
Audio/video	One HDMI portOne headset port (headphone and microphone combo)
Internal:	
M.2	One M.2 card slot for Wi-Fi and Bluetooth combo card



Communications

Ethernet

Wireless

10/100 Mbps Ethernet controller integrated on system board

- Wi-Fi 802.11ac
- Wi-Fi 802.11b/g/n
- Bluetooth 4.0





Specifications

Video

	Inspiron 14-5458 and Inspiron 14-5459	Inspiron 14-5451 and Inspiron 14-5452
Controller:		
Integrated	 Intel HD Graphics Intel HD Graphics 520 Intel HD Graphics 4400 Intel HD Graphics 5500 Intel HD Graphics 6000 	Intel HD Graphics
Discrete	 NVIDIA GeForce 920M (Inspiron 14-5458 only) AMD Radeon R5 M335 (Inspiron 14-5459 only) 	N/A
Memory:		
Integrated	Shared system memory	Shared system memory
Discrete	Up to 4 GB DDR3L	N/A





Audio


Controller	Realtek ALC3234 with Waves MaxxAudio
Speakers	Two
Speaker output:	
Average	2 W
Peak	2.2 W
Microphone	Single microphone
	 Digital array-microphones (Inspiron 14-5458 and Inspiron 14-5459 only)
Volume controls	Media-control shortcut keys





Storage

Interface	• SATA 3 Gbps (Inspiron 14-5451)
	SATA 6 Gbps (Inspiron 14-5452, Inspiron 14-5458, and Inspiron 14-5459)
Hard drive	One 2.5-inch drive (supports Intel Smart Response Technology)
Optical drive	One 9.5 mm DVD+/-RW drive





Media-card reader

Туре

One SD card slot

Card supported

SD card





Display

Туре			n HD WLED n HD WLED touc	:h screen			
Resolution (maximu	ım)	1366 x 76	58				
Refresh rate		60 Hz					
Operating angle		0 degree	(closed) to 135	degrees			
Pixel pitch		0.2265 m	ım				
Controls		Brightnes	s can be contro	lled using shortci	ut keys.		
		Inspiron	14-5458 and In	spiron 14-5459	Inspiron 14-545	51 and Inspiron	14-5452
Dimensions:							
Touch screen:							
Height		174.95 m	m (6.88 in)		N/A		
Width		310.40 m	m (12.22 in)		N/A		
Diagonal		356.31 m	m (14.02 in)		N/A		
Non-touch scree	n:						
Height		173.95 m	m (6.85 in)		173.95 mm (6.8	85 in)	
Width		309.40 m	nm (12.18 in)		309.40 mm (12.	18 in)	
Diagonal		354.95 m	ım (13.97 in)		354.95 mm (13.9	97 in)	
1 11	System	Memory	Ports and connectors	Communications	Video	Audio	Storage





Keyboard

Type Shortcut keys Chiclet keyboard

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

NOTE: You can change the behavior of the shortcut keys by pressing Fn+Esc or by changing **Function Key Behavior** in BIOS setup program.

List of shortcut keys.



Keyboard

Shortcut keys

F1	Mute audio	Fn + PrtScr	Turn off/on wireless
F2	Decrease volume	Fn + Esc	Toggle Fn-key lock
F3 ◀୬)	Increase volume	Fn + Insert	Sleep
F4	Play previous track/chapter	Fn + H	Toggle between power and battery-status light/hard-drive activity light
F5 ► II	Play/Pause	Fn + B	Pause/Break
F6 ►►	Play next track/chapter	Fn + R	System request
F8	Switch to external display	Fn + Ctrl	Open application menu
(F9 , p	Search	Fn + S	Toggle Scroll Lock
F10	Toggle keyboard backlight (Inspiron 14-5458 and Inspiron 14-5459 only)	$\boxed{Fn} + \boxed{End} \rightarrow$	End
F11 	Decrease brightness	Fn + Home	Home
F12	Increase brightness	Fn + PgUp	Page Up
		Fn + ↓PgDn	Page Down



Camera

Resolution:		
Still image	0.92 megapixel	
Video	1280 x 720 HD at 30 fps	
Diagonal viewing angle	74 degrees	





Touch pad

Resolution:	
Horizontal	1223 dpi
Vertical	1573 dpi
Dimensions:	
Width	105 mm (4.13 in)
Height	65 mm (2.55 in)





Battery

Туре	 4 cell "smart" lithium ion (40 WHr) 4 cell "smart" lithium ion (47 WHr)
Dimensions:	
Width	270 mm (10.63 in)
Depth	37.50 mm (1.47 in)
Height	20 mm (0.78 in)
Weight (maximum)	0.25 kg
Voltage	14.8 VDC
Charging time when the computer is off (approximate)	4 hours
Operating time	Varies depending on operating conditions and can significantly reduce under certain power-intensive conditions.
Life span (approximate)	300 discharge/charge cycles
Temperature range:	
Operating	0°C to 35°C (32°F to 95°F)
Storage	-40°C to 65°C (-40°F to 149°F)
Coin-cell battery	CR-2032





Power adapter

Туре	• 45 W
	• 65 W
Input voltage	100 VAC-240 VAC
Input frequency	50 Hz-60 Hz
Input current (maximum):	
45 W	1.30 A
65 W	1.70 A
Output current (maximum):	
45 W	2.31 A
65 W	3.34 A
Rated output voltage	19.50 VDC
Temperature range:	
Operating	0°C to 40°C (32°F to 104°F)
Storage	-40°C to 70°C (-40°F to 158°F)



Computer environment

Airborne contaminant level	G1 as defined by ISA-S71.04-1985		
	Operating	Storage	
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)	
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)	
Vibration (maximum)*	0.66 GRMS	1.30 GRMS	
Shock (maximum)	110 G [†]	160 G [‡]	
Altitude (maximum)	–15.2 m to 3048 m (–50 ft to 10,000 ft)	–15.2 m to 10,668 m (–50 ft to 35,000 ft)	

* Measured using a random vibration spectrum that simulates user environment.

† Measured using a 2 ms half-sine pulse when the hard drive is in use.

‡ Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

