

Dell Business Client Re-Image "How-To" Guide Latitude Ultrabook, E-Family & Mobile Precision Notebook

Revision 1.0.3

A03

Feb. 22th, 2017

Contents

1 Overview	3
2 "How-To"2	
2.1 Auto Installation Application	
2.2 Manual Installation Order	
Appendix A How to create and use the Dell Windows recovery image	
Appendix B Intel Rapid Storage Technology	
Appendix C DELL Command Suite	
Appendix D Dell Dock (WD15) & Dell Thunderbolt Dock (TB16) information and specifications	
Appendix b beli bock (Wb13) & beli indiderbolt bock (Ib10) information and specifications	

1 Overview

This document is a quick guidance for re-image OS on Dell Latitude & Mobile Precision notebooks. Failure to install drivers and applications in this document may result in undesirable performance. These drivers are required to enable new technologies and features.

Reinstalled images should be built from <u>Windows clean installation</u> then following steps in this guide. Dell does not recommend starting from an image built on previous generations of products or other computer systems.

This "How-To" guide applies to following Systems, and support Windows OS list in below

	Windows 10 64bit	Windows 8.1 64bit*	Windows 7 64bit*	Windows 7 32bit*
Latitude E5280/5288	Yes	No	No	No
Latitude E5480/5488	Yes	No	No	No
Latitude E5580	Yes	No	No	No
Latitude E7280	Yes	No	No	No
Latitude E7480	Yes	No	No	No
Mobile Precision 3520	Yes	No	No	No
Mobile Precision 5520	Yes	No	No	No
Latitude 3180/3189	Yes	No	No	No
Latitude 5289	Yes	No	No	No

*NOTE: Before attempting to install Windows 7 or 8.1, <u>check your processor type</u>. Systems with 7th Generation Intel® Core™ i7 Processors are **NOT** eligible for Windows 7/8.1 downgrades.

NOTE: Dell *highly recommends* you turn on Windows Update after Windows OS clean installation. The best way to keep your computer current is to turn on automatic updates. With automatic updates via internet, you don't have to search for updates online or possibly miss critical fixes or device drivers for your Windows PC. Windows Update automatically installs important updates and latest drivers as they become available. Read here for more detail

NOTE: To enable internet access, please install Ethernet controller driver first.

Search for your system model name under Select a Product selection, or enter the service tag of your system to locate Drivers & Downloads page on the Dell <u>Support Website</u>. Change the Operating System to view all available updates for your system. Select *Intel I2xx/825xx Gigabit Ethernet Network Controller Drivers* under "Network" category.

2 "How-To"

2.1 Auto Installation Application

Dell highly recommends **Dell Command | Update application (DCU)** to automate the installation of BIOS, firmware, driver and critical updates specific to your system. The application is available to download on **Dell Support Website Driver & Downloads page**. Pick your system type from the list or enter the service tag of your system to get the right version for your computer.

The DCU is supported on Precision, XPS and Latitude notebooks. The Dell Command | Update tool allows you to keep your system up to date without you having to know every driver or update needed. It will automatically interrogate your system and compare it to the available updates on dell.com/support for your specific system.

Read <u>here</u> for more detail about How to use Dell Command | Update to update all drivers BIOS and firmware for your system

NOTE: Older BIOS versions and drivers could result in your computer or not functioning optimally.

2.2 Manual Installation Order

Alternatively, Dell recommends installing the following BIOS, firmware and drivers step-by-step in the prescribed order to ensure optimal performance.

Search for your system model name under Select a Product selection, or enter the service tag of your system to locate Drivers & Downloads page on the Dell Support Website. Change the Operating System to view all available updates for your system.

NOTE: Dell *highly recommends* that you install BIOS, firmware, driver and critical updates via **Microsoft Windows Update** (in session 1) or **Dell Command I Update application** (in session 2.1, <u>available since Feb.2017</u>). Manual installation is only recommended when auto installation applications are not available.

NOTE: Following above, Dell also recommends you install firmware, driver of **Dock**WD15 and **Thunderbolt Dock TB16** via **Dell Command I Update** application. More information of **WD15**, please refer to *Dell WD15 docking Station Installation Guide*here or *Video tutorials* here. More information of **TB16**, please refer Dell Thunderbolt Dock TB16 Driver Installation Guide or *Video tutorials* here

NOTE: Dell recommends restarting your system between each driver, firmware installation.

Intel 8265/8280/7265/7260/3165/ Intel 8265/8280/37265/7260/3165/ Intel 8265/8280/37265 Bluetooth Driver Network Networ			Support Products				
Delicate Discost Software Discost and Chainest Devices Software Discost and Chainest Devices Software Discost All config required Autority (Proposed of the Chainest Network) Network	Title	Category	E5280/5480/5580 E5288/5488/5289	Precision 3520	Precision	1 1 11 1	Note
mail Day Design of Histories (Parties) A control of Professor (Parties)	DELL System BIOS	BIOS	•	■ BIO3	•	•	All config. required
Intel Device Manager Displayoris Littley (DMS) Intel Device Manager Device Manager Device Manager Littley (DMS) Intel Device Manager Device Manager Device Manager Littley (DMS) Intel Device Manager Device Manage		ı	Driver 8	& Firmware - onboard	Devices		
Centroller Divere Methods Meth		Chipset	•	•	•	•	All config. required
Intel Devent Poter Prover Open		Network	0	•	•		Required for Intel LAN config.
All config required All confi		Network	0	•	•		
Intel Moderation Chover Intel Rapid Storage Technology Briter and Serial ATA Mospener Console Audition	Intel HID Event Filter Driver	Chipset	•	•	•	•	All config. required
Intell Bapt Sharage Technology of more and Management Counties. Mall Conflic Required All Conflic Required for Mall Conflic Required All Conflic Required for Mall Requ			•	•	•		
Management Console Serial ATA Auto		Video	•	•	•	•	All config. required
Solicity Signature (Components) Solicity Solici		Serial ATA	•	•	•		All config. required
intered to pyramic Platform and thermal Framework Unipet	Realtek ALC3246 Audio Driver	Audio	•	•	•	•	All config. required
Chippet		SD Card	•	•	•		All config. required
STAMONOLECTORIS ACCIDENTMENT COMMINIST COMMINIST CONTROLLED TO COMMINIST COM	Framework	Chipset	•	•	•	•	All config. required
Intel® 1 Brunderhood (TWO) Controller Driver Intel® 2 Brunding Driver Intel®	17 0 0 1		•	•	•		5 1
Intel Toucherbold Stimware Update OLI Control/Audio (Down and Firmware Security OLI Control/Audio (Down and Firmware Security OLI Control/Audio (Down and Firmware Security OLI Control Audio (Down and Firmware Security OLI Control Audio (Down and Firmware Security OLI Control (Down and Firmware All config Required Intel Transported Security Experiments All config Required Intel Security (Down and Firmware OLI Control (Down and Firmware Input Driver & Timmware - Communication Devices Tele 1825/57256/57255(53)73.65 Wiff Driver Intel 1825/7826/57255(53)73.65 Wiff Driver Intel 1825/7826/57255(53)73.65 Wiff Driver Intel 1825/7826/57255(7726/783)56/ Intel 2825/7826/7826/7826/7826/7826/7826/7826/7826							
Del Control/Wall2 Driver and Firmware Video O							
Solida Vivideo - Driver Sequired for Incardance of Scoring Sequired for Incarda							
Intel Traited Execution Engine Components United Serial OD Diver Chipset							
Intel Sensi I O Priver Intel Integrand Sensor Solution Driver Chipset Untel Virtual Buttons Driver Chipset Untel 20 Imaging Driver Intel 1826/528677265(SD)/3165 WiFi Driver Network Network OOOO OOO OOO OOO OOO OOO OOO OOO OOO		Input	0	0	0		
Intel Intelly Firther Statistics Driver Intel 120 Imaging Driver Intel 120 Imaging Driver Intel 120 Imaging Driver Intel 120 Imaging Driver Intel 1226/5/226/726(5)(5)/3165 W/FI Driver Network O O O O O O O O O O O O O	<u> </u>					•	5 1
Intel 1826/\$2867/2865(\$200)/\$165 WiFi Driver Intel 1826/\$2865/\$2865(\$7265(\$50)/\$165 WiFi Driver Network Netw			0			8	
Intel 20 Imaging Driver Driver & Firmware - Communication Devices Required Intel 20 camera config							
Intel 18265/8265/7265(SD)/3165 WiFi Driver Network Netw						Ŏ	
Network O			Driver & Fi	rmware - Communicat	ion Devices	ı	
18265/18260/17265 Wireless 1810/1820 Wir/Pluetooth Driver Network O O O Required for Intel 18265 Wireless card only	Intel 18265/8265/7265(SD)/3165 WiFi Driver	Network	0	0	0	•	*Latitude 3180/3189 Intel 7265 Wireless card
Dell Wireless \$1810/1820 WiFi/Bluetooth Driver Dell Wireless \$211e LTE Mobile Broadband and GPS Driver & Communication DWS814E LTE Mobile Broadband Driver Communication DWS814E LTE Mobile Broadband Driver Communication DWS814E LTE Mobile Broadband Driver Communication Driver & Firmware - Dock Stands Driver & Firmware - Dock		Network	0	0	0	•	Required for Intel 8265/18265 Wireless card *Latitude 3180/3189 Intel 7265 Wireless card only
DELL Wired Dock/WD15)/Docking Monitor Stand(F51000) Firmware Update Utility ASMedia USB 3.0 Extended Host Controller Driver Docks/Stands Dell Command Dock WB16 Port Docks/Stands Dell Command Power Manager (DCPM) Dell Command Power Manager (DCPM) Dell Command Configure (DCC) Dell Command Configure (DCC) Dell Command Intel vPro (DCIV) (Aurora) Dell Command Intel vPro (DCIV) (Aurora) Dell Command Intel vPro (DCIV) (Aurora) Dell Command Dock Docks System Management Dell Command Intel vPro (DCIV) (Aurora) Dell Command Dock Docks Docks System Management Dell Command Intel vPro (DCIV) (Aurora) Dell Command Docks Docks Docks System Management Dell Command Intel vPro (DCIV) (Aurora) Dell Command Docks Dock	Intel 18265/18260/17265 WiGig Application	Network	0	0	0		Required for Intel 18265 Wireless card
DELL Wired Dock (WD15) / Docking Monitor Stand(F51000) Firmware - Dock Stands Diver & Firmware - Dock Stands Docks/Stands Required for TB16 and WD15 dock Required for TB16 and WD15 dock Required for TB16 and WD15 dock Required for IDock Applications Docks/Stands Docks/Stands Docks/Stands Docks/Stands Docks/Stan	Dell Wireless 1810/1820 WiFi/Bluetooth Driver	Network	0	0	0		Required for DELL 1820 Wireless card
Driver & Firmware - Dock Stands Delt. Wired Dock(WD15)/Docking Monitor Stand(F51000) Firmware Update Utility ASMedia USB 3.0 Extended Host Controller Driver ASMedia USB 3.0 Extended Host Controller Driver BealTek USB GBE Ethernet Controller Driver BealTek USB Audio Driver for Dell Wireless Dock, Dell Thunderbolt Dock, Dell Docking Monitor Stand and Dell Dock ASIX USB to Serial / Parallel Port Driver Dell Command Power Manager (DCPM) Dell Command Update (DCU) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Power Horio Firm Management Dell Command Integration Suite (DCIS) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Power Horio Firm Management Dell Command Powe		Communication	0	0	0		Required for DELL 5811 LTE card
DELL Wired Dock (WD15)/Docking Monitor Stand(FS1000) Firmware Update Utility Docks/Stands Required for TB16 and WD15 dock Required for T		Communication	0	0	0		Required for DELL 5814 LTE card
DELL Wired Dock(WD15)/Docking Monitor Stand(F51000) Firmware Update Utility Docks/Stands Required for TD16dock Required for TD16dock Required for LD17dock Required for LD17dock R			Drive	er & Firmware - Dock S	tands		(4) Descript for WOAT Arch
RealTek USB GBE Ethernet Controller Driver RealTek USB Audio Driver for Dell Wireless Dock, Dell Thunderbolt Dock, Dell Docking Monitor Stand and Dell Dock Stand and Dell Dock ASIX USB to Serial / Parallel Port Driver Docks/Stands Dell Command Power Manager (DCPM) Dell Command Dell Command Configure (DCC) System Management Dell Command Integration Suite (DCIS) Dell Command Integration Suite (DCIS) Dell Command Intel VPro (DCIV) (Aurora) System Management Dell Command Monitor (DCM) Dell Command Monitor (DCM) Dell Command Powershell Provider (DCPP) System Management Dell Command Dell Provider (DCPP) Dell Command Dell Command Powershell Provider (DCPP) Dell Command Dell Provider (DCPP) System Management Dell Command Dock (All Configure (DCC) System Management (All Configure (DCC) Dell Command Monitor (DCM) System Management (All Command Dell Command Powershell Provider (DCPP) Dell Command Powershell Provider (DCPP) Dell Loata Protection Dell Command Dell C		Docks/Stands	0	0	0		(2) connect AC adapter to dock then
Realtek USB Audio Driver for Dell Wireless Dock, Dell Thunderbolt Dock, Dell Docking Monitor Stand and Dell Dock ASIX USB to Serial / Parallel Port Driver Docks/Stands Dell Command Power Manager (DCPM) Dell Command Update (DCU) Dell Command Update (DCC) System Management Dell Command Integration Suite (DCIS) Dell Command Integration Suite (DCIS) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Monitor (DCM) System Management Dell Command Monitor (DCM) Dell Command Powershell Provider (DCPP) System Management Dell Command Powershell Provider (DCPP) System Management Dell Command Docks/Stands Dell Command Monitor (DCM) System Management Dell Command Monitor (DCM) Dell Command Powershell Provider (DCPP) System Management Dell Command Docks/Stands Dock	ASMedia USB 3.0 Extended Host Controller Driver	Docks/Stands					Required for TB16 dock
Dell Thunderbolt Dock, Dell Docking Monitor Stand and Dell Dock ASIX USB to Serial / Parallel Port Driver Docks/Stands Dell Command Power Manager (DCPM) Dell Command Update (DCU) Dell Command Update (DCU) Dell Command Update (DCC) Dell Command Integration Suite (DCIS) Dell Command Integration Suite (DCIS) System Management Dell Command Integration Suite (DCI) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Monitor (DCM) System Management Dell Command Monitor (DCM) System Management Dell Command Powershell Provider (DCPP) System Management Dell Data Protection Encrytion Dell Data Protection Encrytion Dell Data Protection Application Dell Update Application Appli		Docks/Stands	0	0	0		Required for TB16 and WD15 dock
ASIX USB to Serial / Parallel Port Driver Docks/Stands O O O Required for LD17 dock Applications Dell Command Power Manager (DCPM) System Utilities Dell Command Update (DCU) System Management Dell Command Configure (DCC) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Integration Suite (DCIS) System Management Dell Command Integration Suite (DCIV) (Aurora) System Management Dell Command Monitor (DCM) System Management Dell Command Monitor (DCM) System Management Dell Command Powershell Provider (DCPP) System Management Dell Command Powershell Provider (DCPP) System Management Dell Data Protection Encrytion Dell Data Protection Encrytion Dell Foundation Services - Application Application Dell Update Application	Dell Thunderbolt Dock, Dell Docking Monitor	Docks/Stands	0	0	0		Required for TB16 and WD15 dock
Dell Command Power Manager (DCPM) Dell Command Update (DCU) Dell Command Configure (DCC) Dell Command Configure (DCC) System Management Dell Command Integration Suite (DCIS) Dell Command Integration Suite (DCIS) System Management Dell Command Intel VPro (DCIV) (Aurora) System Management Dell Command Monitor (DCM) System Management Dell Command Monitor (DCM) System Management Dell Command Powershell Provider (DCPP) System Management DELL Data Protection Encrytion Dell Command Encrytion Dell Command Powershell Provider (DCPP) Dell Data Protection Application Dell Digital Delivery Application		Docks/Stands	0	_	0		Required for LD17 dock
Dell Command Update (DCU)	Dell Command Deventh (CCDA)	Combana United		Applications			All posting as suited
Dell Command Configure (DCC)							
Dell Command Integration Suite (DCIS)			ŏ	Ö	Ŏ	Ŏ	
Dell Command Intel vPro (DCIV) (Aurora) System Management O O Option for IT management	Dell Command Integration Suite (DCIS)	System Management	0	0	0	Ŏ	Option for IT management
Dell Command Powershell Provider (DCPP)				0			
DELL Data Protection Encrytion Encryti							
Dell Foundation Services - Application Application O O Option for IT management Dell Update Application O O Option for IT management Dell Digital Delivery Application Application O Option for IT management Dell Digital Delivery Application Application O Option for IT management							-
Dell Update Application O O O Option for IT management Dell Digital Delivery Application Application	DELL Data Protection Encrytion		O				and PBA features
Dell Digital Delivery Application Application Application Application			<u>o</u>			Q	
			0	0		0	
Dell Precision Optimizer (DPO) Application Mobile Precision Required	Dell Precision Optimizer (DPO)			Š	 		Mobile Precision Required

Appendix

Appendix A

How to create and use the Dell Windows recovery image

After you download the Windows recovery image <u>file</u>, follow these instructions to create a bootable USB drive or DVD, copy the recovery image onto your bootable media, and then use the media to reinstall Windows on your Dell device.

Warning: These advanced steps are intended primarily for system administrators and those familiar with command line and/or comfortable following technical tutorials.

Note: To print this document, expand the required section before you click the printer icon at the top of this document.

How to create Windows 10 installation media

Create USB installation media

Step 1: Format your USB drive as a bootable drive

Make sure that you use 8 GB or larger USB drive (32 GB Maximum) and backup any important data on it. When the drive is formatted, all existing data will be deleted.

- 1. Connect the USB drive to the PC where you'll be creating the installation media.
- 2. Open the Command Prompt window by right-clicking the **Start** button and then select **Command Prompt (Admin)** to run in administrator mode.
- 3. At the command prompt, type **diskpart** and press **Enter**.
- 4. Next, type **list volume** and press **Enter**.
- 5. From the list, determine which volume number is the connected USB drive. The volume type should be marked as Removable.
- 6. Type **select volume X**, where X is the number obtained in the previous step. For example, **select volume 9**.
- 7. Type clean and press Enter.
- 8. Type create partition primary and press Enter.
- 9. Type format fs=fat32 label='OS install' quick and press Enter.
- 10. Type active and press Enter.
- 11. To close the Command Prompt window, type exit and press Enter.

Step 2: Copy the recovery image to your bootable USB drive

- 1. Go to the location where you saved the recovery image.
- 2. Right-click the recovery image file (.iso) and on the options menu, select Mount.
- 3. Windows will open the contents of the image in File Explorer.
- 4. Copy the contents of the image to your bootable device.

Create DVD installation media

- 1. Insert the DVD into the disc drive of the PC where you'll be copying the recovery image to DVD. Make sure that the disc drive has burning capabilities.
- 2. Navigate to the folder where you saved the recovery image and double-click the iso file.
- 3. Either the Windows ISO media creation tool or installed third-party disc burning software will open.
- 4. Follow the on-screen instruction to burn the ISO to the DVD. When the process completes, you will have created bootable installation media.

Using the USB or DVD installation media to reinstall Windows 10

- 1. Connect the installation media you created to the Dell system where you want to install Windows.
- 2. Restart the system and when the Dell logo screen appears, tap the **F12** key until you see **Preparing one time boot menu** in the top-right corner of the screen.
- 3. On the boot menu, under UEFI boot, select your media type (USB or DVD) and enter your language.
- 4. On the Choose an option screen, select **Troubleshoot**, and then select **Recover from a drive**.
- 5. Follow the on-screen instructions to finish installing Windows. The installation process will take some time and your computer will restart.

Appendix B

Intel® Rapid Storage Technology

Intel® Rapid Storage Technology offers greater levels of performance, responsiveness, and expandability than ever before. Whether you are using one or multiple serial ATA (SATA) or PCIe drives, you can take advantage of enhanced performance and lower power consumption from the latest storage technologies. Additionally, you can rest easy knowing you have added protection against data loss in the event of a hard drive failure.

Unleash the Performance of Your Solid-State Drive

Intel Rapid Storage Technology has added support for next generation PCle storage devices with transfer speeds up to 1 GB/s that maximizes storage performance and improves response time for everyday usages like photo editing, video loading, and office productivity. Dynamic storage accelerator accelerates the performance of your SSD by dynamically adjusting system power management policies to deliver up to 15 percent faster performance1 during heavy multitasking compared to default power management.

Fast Access to the Files and Applications You Use Most

Intel® Smart Response Technology is a feature of Intel Rapid Storage Technology that recognizes and automatically stores your most frequently used applications and data into a high performance SSD while giving you full access to the large storage capacity of a hard disk drive (HDD). This enables a lower-cost, small-capacity SSD to be used in conjunction with a high-capacity HDD. Intel Smart Response Technology enables your system to perform faster than a system with just a HDD.

Intel Smart Response Technology also supports solid-state hybrid drives (SSHDs). Intel Smart Response Technology boosts SSHD performance by informing the drive which data you use the most so it can store it into the built-in SSD, so your most frequently used data and applications are instantly accessible.

Performance with Protection: RAID Technology

Most of us don't plan backup storage well in advance. Hard drive failure can be devastating, because it results in irretrievable content. Intel Rapid Storage Technology offers features that improve performance and data reliability for disk-intensive retrieval applications such as editing home video. For the fastest performance, Intel Rapid Storage Technology can combine from two to six drives in a configuration known as RAID 0, so data can be accessed on each drive simultaneously, speeding up response time. For the best reliability, Intel Rapid Storage Technology RAID support includes the following levels of performance and reliability:

RAID level 0 (Striping)

RAID level 1 (Mirroring)

RAID level 5 (Striping with parity)

RAID level 10 (Striping and mirroring)

Multiple drives in a PC can also provide added protection from disastrous hard drive failures by mirroring all data among two or more drives. This configuration is known as RAID 1. RAID 5 and 10 provide additional reliability by mirroring all data among three and four drives respectively.

Rapid Data Recovery

Intel® Rapid Recover Technology (Intel® RRT) provides a recovery point that can be used to quickly recover a system in the event of hard drive failure or data corruption. The clone can also be mounted as a read-only volume to allow a user to recover individual files.

Intel Smart Response Technology also supports SSHDs. An SSHD is a new type of HDD with a built-in high-performance SSD. Intel Smart Response Technology boosts SSHD performance by informing the drive which data you use the most, so it can store it into the built-in SSD.

You can create, work, and play faster than ever before without paying more for a larger SSD to store your entire digital library.

Appendix C

Dell Client Command Suite

The Dell Client Command Suite is the new name of our industry leading Client Systems Management tools. These tools make Dell commercial client systems the world's most manageable client devices. Click on a link below for more details

Dell Command | Monitor

Dell Command | Configure

<u>Dell Command | Deploy</u>

<u>Dell Command | Integration Suite for System Center 2012</u>

Dell Command | Update Catalog

Dell Command | Update

Dell Command | Power Manager

Dell Command | Intel vPro Out of Band

Dell Command | PowerShell Provider

Appendix D

Dell Dock (WD15) & Dell Thunderbolt Dock (TB16) information

Dell Dock WD15		
Display Ports	VGA, mDP, HDMI	
Number Displays Supported	21	
Max Resolution	3840 x 2160 @ 30 Hz, 2560 x 1600 @ 60Hz	
USB Ports	USB 2.0 - (2), USB 3.0 - (3)	
Thunderbolt 3 Port	None	
Audio/Headphone	3.5 mm Combo - (1), 3.5 mm Speaker Out (1)	
Network	RJ-45 Gigabit Ethernet	
	Power Adapter LED	
LED Indicators	Docking Cable Connector LED	
	RJ-45 LEDs	
Dock Connector	Proprietary Docking Connector to USB Type-C	
AC Adapter	130W/180W	
Dimensions	155 x 110 x 21 mm	
Dimensions	6.1 x 4.3 x 0.83 inches	
VA/-!	0.93 lbs	
Weight	420 g	
System Requirements	PC equipped with DisplayPort over USB-Type-C or Thunderbolt 3	
Operating Systems	Windows 7/8/8.1/10	
Systems Management ²	Wireless vPro Supported by the Notebook, Tablet or Workstation	
Docking Cable Type	DisplayPort over USB Type-C (0.8m)	
MAC Address ³	Pass Thru MAC Address (Dell Systems ONLY)	
Warranty	If purchased as a tied laptop accessory the dock shares the system warranty	
	If purchased APOS, 1 yr warranty. Advanced Exchange (DAO/APJ), Next business day exchange (MEA	

¹A 3rd display can be connected with the VGA port. The image will be in clone mode vs. Extended Desktop.

²Dell Dock WD15 does not support wired vPro. If vPro is needed, then the system host Ethernet port may be used or WiFI vPro within the system.

³The dock has the capability to pass through the system MAC address to the network.

Dell Thunderbolt Dock TB16

Display Ports	VGA, mDP, HDMI, DP, Thunderbolt
Number Displays Supported	3 @ 60Hz⁴

Dell Latitude Ultrabook, E-Family & Mobile Precision Reimage "How-To" Guide

Max Resolution	5120 x 2880 @ 60Hz
USB Ports	USB 2.0 - (2), USB 3.0 - (3)
Thunderbolt 3 Port	USB Type-C
Audio/Headphone	3.5 mm Combo - (1), 3.5 mm Speaker Out (1)
Network	RJ-45 Gigabit Ethernet
	Power Adapter LED
LED Indicators	Docking Cable Connector LED
	RJ-45 LEDs
Dock Connector	Proprietary Docking Connector to USB Type-C
AC Adapter	180W/240W
Dimensions	145 x 145 x 52 mm
	5.7 x 5.7 x 2.05 inches
Weight	1.63 lbs
	740 g
System Requirements	PC equipped with DisplayPort over USB-C or Thunderbolt
Operating Systems	Windows 7/8/8.1/10
Systems Management ²	Wireless vPro supported by the notebook, tablet, or workstation
Docking Cable Type	USB Type-C Thunderbolt (0.5m)
MAC Address ³	Pass Thru MAC Address (Dell Systems ONLY)
Warranty	If purchased as a tied laptop accessory the dock shares the system warranty
	If purchased APOS, 1 yr warranty. Advanced Exchange (DAO/APJ), Next business day exchange (EMEA
• •	or USB Type-C Universal cable required. The host device must support Thunderbolt™ 3 for
	nunderbolt speeds to be supported on the Dell Thunderbolt™ Dock. not support wired vPro. If vPro is needed, the host Ethernet port can be used, or WiFi vPro witl the host.

³ The dock will pass through the NB/Tablet MAC address

Dell Latitude Ultrabook, E-Family & Mobile Precision Reimage "How-To" Guide

⁴With Intel HD Integrated graphics. Some systems with Discrete Graphics (NVidia/AMD) may be able to display additional displays, but due to bandwidth limitations of the Thunderbolt bus, the refresh rate may have to be reduced to 30 Hz. See the TB16 user guide pg 22

The Dell Thunderbolt Dock TB16 is a device that links all your electronic devices to your laptop computer using Thunderbolt™ 3 (Type-C) cable interface. When you connect the laptop to the docking station, you can gain access to all your peripherals such as the mouse, keyboard, stereo speakers, external hard drive, and large-screen displays without having to plug each one into the laptop.

Key Features:

- Supports up to three FHD displays or two 4K displays @ 60Hz
- Supports faster data transfer of up to 40 Gbps, ideal for large files.
- Common docking experience across platforms with USB-C port(s) having data, video, and power capabilities.
- Single cable for power and data (up to 130w on supported computers only).

For more information about USB Type-C, refer to the knowledgebase article <u>USB Type-C - Frequently Asked</u> <u>Questions</u>.