

Statement of Volatility – Dell E5570

△ CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

The Dell E5570 contains both volatile and non-volatile (NV) components. Volatile components lose their data immediately after power is removed from the component. Non-volatile (NV) components continue to retain their data even after power is removed from the component. The following NV components are present on the E5570's system board.

Description	Reference Designator	Volatility Description	User Accessible for external data	Remedial Action (Action necessary to prevent loss of data)
Embedded Flash in embedded controller MEC5085	UE2	288 KB of embedded Flash memory for keyboard controller BIOS code, asset tag and BIOS passwords	No	N/A
Panel EEDID EEPROM	Part of panel assembly	Non Volatile memory, 128bytes.	No	Part of panel assembly
System BIOS	UC5	Non Volatile memory, 128 Mbit (16 MB), System BIOS and Video BIOS for basic boot operation, PSA (on board diags), PXE diags.	No	N/A
System Memory – DDR4 memory	Two SODIMM connectors: JDIMM1,2 present	Volatile memory in OFF state NOTE: See state definitions later in text. One to Two modules must be populated. System memory size will depend on SODIMM modules and must be between 2 GB and 16 GB.	Yes	Power off system
System memory SPD EEPROM	On System memory SODIMM(s) JDIMM1,2 present	Non Volatile memory 512 Bytes. Stores memory manufacturer data and timing information for correct operation of system memory.	No	N/A
RTC CMOS – BBRAM (battery backed up)	UC1 on SKL- U mother boards and UH1 on SKL- H mother boards.	Non Volatile memory, 256 Bytes. Stores CMOS information.	No	Remove the onboard coin cell battery
Video memory –	For UMA platform:	Volatile memory in off state. UMA uses main system	No	No Enter S3-S5 State below.

Dell - Restricted - Confidential

Description	Reference Designator	Volatility Description	User Accessible for external data	Remedial Action (Action necessary to prevent loss of data)
frame buffer	using system DDR4 For DSC platform: UV17, UV18, UV19, UV20	memory size allocated out of main memory. Discrete graphics system uses 2 GB DDR3L or GDDR5.		
Security Controller Serial Flash Memory	U1 (up-sell USH daughter board)	Non Volatile memory, 32 Mbit (4Mbyte)	No	N/A
Hard drive(s)	User replaceable	SSD (solid State flash drive). various sizes in GB	Yes	Low level format
TPM Controller	UZ12	Non Volatile memory, 24K bits (384K bytes) ROM	No	N/A
DP HUB EEPROM	UV9 on SKL-U mother boards only.	Non Volatile memory, 1 Mbit (128K byte)	No	N/A

CAUTION: All other components on the system board lose data if power is removed from the system. Primary power loss (unplugging the power cord and removing the battery) destroys all user data on the memory (DDR4, 1866/2133 MHz). Secondary power loss (removing the on-board coin-cell battery) destroys system data on the system configuration and timeof-day information.

In addition, to clarify memory volatility and data retention in situations where the system is put in different ACPI power states the following is provided (those ACPI power states are S0, S1, S3, S4 and S5):

S0 state is the working state where the dynamic RAM is maintained and is read/write by the processor.

S1 state is a low wake-up latency sleeping state. In this state, no system context is lost (CPU or chip set) and hardware maintains all system contexts.

S3 is called "suspend to RAM" state or stand-by mode. In this state the dynamic RAM is maintained. Dell systems will be able to go to S3 if the OS and the peripherals used in the system supports S3 state. Win8 support S3 state.

S4 is called "suspend to disk" state or "hibernate" mode. There is no power. In this state, the dynamic RAM is not maintained. If the system has been commanded to enter S4, the OS will write the system context to a non-volatile storage file and leave appropriate context markers. When the system is coming back to the working state, a restore file from the nonvolatile storage can occur. The restore file has to be valid. Dell systems will be able to go to S4 if the OS and the peripherals support S4 state. Win8 support S4 state.

S5 is the "soft" off state. There is no power. The OS does not save any context to wake up the system. No data will remain in any component on the system board, i.e. cache or memory. The system will require a complete boot when awakened. Since S5 is the shut off state, coming out of S5 requires power on which clears all registers.

The following table shows all the states supported by Dell Latitude E5570:

Model Number	SO	S1	S3	S4	S5
Dell Latitude™ E5570	Х		Х	Х	Х

© 2016 Dell Inc.

Trademarks used in this text: Dell[™], the DELL logo, Latitude[™] are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core[™] and Celeron® are registered trademarks of Intel Corporation in the U.S. and other countries. Microsoft®, Windows® are either trademarks or registered trademarks of

Microsoft Corporation in the United States and/or other countries.