



# Dell S718QL SNMP Protocol Document

## Control Commands List

Name	Feature	Oid	Value Type	Read /Write	Criteria
RFC1213-system	sysDescr	1.3.6.1.2.1.1.1.0	String	R	Dell Projector
RFC1213-system	sysObjectID	1.3.6.1.2.1.1.2.0	OID	R	.1.3.6.1.4.1.674.10901.20018
RFC1213-system	sysUpTime	1.3.6.1.2.1.1.3.0	Timetic ks	R	Operation hours * hours * minutes * seconds
RFC1213-system	sysContact	1.3.6.1.2.1.1.4.0	String	R/W	If meet web management (system status)
RFC1213-system	sysName	1.3.6.1.2.1.1.5.0	String	R/W	If meet web management (Group Name + Projector Name)
RFC1213-system	sysLocation	1.3.6.1.2.1.1.6.0	String	R/W	If meet web management (system status)
RFC1213-system	sysServices	1.3.6.1.2.1.1.7.0	Integer	R	DEFVAL { 72 }
RFC1213-interfac es	ifNumber	1.3.6.1.2.1.2.1.0	Integer	R	DEFVAL { 1 }
pdmGeneral	pdmGeneralProductName	1.3.6.1.4.1.2699.2.4.1.2.1.0	String	R	Dell S718QL
pdmGeneral	pdmGeneralSerialNumber	1.3.6.1.4.1.2699.2.4.1.2.2.0	String	R	Check PPID number (the latter 7 yards)
pdmGeneral	pdmGeneralAssetTag	1.3.6.1.4.1.2699.2.4.1.2.3.0	String	R/W	Range (0~63 byte)
pdmGeneral	pdmGeneralHardwareVersion	1.3.6.1.4.1.2699.2.4.1.2.4.0	String	R	DEFVAL ( "" )
pdmGeneral	pdmGeneralServicePerson	1.3.6.1.4.1.2699.2.4.1.2.5.0	String	R/W	Range (0~255 byte)
pdmGeneral	pdmGeneralDeviceAge	1.3.6.1.4.1.2699.2.4.1.2.6.0	Integer	R	Check display hours
pdmGeneral	pdmGeneralPowerOnCount	1.3.6.1.4.1.2699.2.4.1.2.7.0	Integer	R	Everytime Projector power on, check if the count value is added by one.
pdmGeneral	pdmGeneralManufactureDate	1.3.6.1.4.1.2699.2.4.1.2.8.0	String	R	
pdmGeneral	pdmGeneralLanguageTagSNMP	1.3.6.1.4.1.2699.2.4.1.2.9.0	String	R	en-US
pdmGeneral	pdmGeneralNtpServerAddress	1.3.6.1.4.1.2699.2.4.1.2.10.0	String	R	DEFVAL ( "" )
PdmCtr	pdmCtrIndex	1.3.6.1.4.1.2699.2.4.1.3.1.1.1	Integer	not-accessible	1
PdmCtr	pdmCtrDescription	1.3.6.1.4.1.2699.2.4.1.3.1.1.2	String	R	TI DDP4422
PdmCtr	pdmCtrHardwareVersion	1.3.6.1.4.1.2699.2.4.1.3.1.1.3	String	R	DEFVAL ( "" )
PdmCtr	pdmCtrFirmwareVersion	1.3.6.1.4.1.2699.2.4.1.3.1.1.4	String	R	
PdmCtr	pdmCtrFirmwareUpgradeable	1.3.6.1.4.1.2699.2.4.1.3.1.1.5	Integer	R	DEFVAL { 10 }
PdmCtr	pdmCtrUpgradeInstructions	1.3.6.1.4.1.2699.2.4.1.3.1.1.6	String	R	DEFVAL ( "" )
PdmCtr	pdmCtrPostStatus	1.3.6.1.4.1.2699.2.4.1.3.1.1.7	Integer	R	DEFVAL { 2 }
PdmCtr	pdmCtrPostCode	1.3.6.1.4.1.2699.2.4.1.3.1.1.8	String	R	DEFVAL ( "" )
PdmCtr	pdmCtrPostStatusDefinitions	1.3.6.1.4.1.2699.2.4.1.3.1.1.9	String	R	DEFVAL ( "" )
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.1	Integer	not-accessible	1
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.2	Integer	not-accessible	2
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.3	Integer	not-accessible	3
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.4	Integer	not-accessible	4
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.5	Integer	not-accessible	5
PdmPower	pdmPowerIndex	1.3.6.1.4.1.2699.2.4.1.4.1.1.6	Integer	not-accessible	6
PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.1	Integer	R	11 (On)
PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.2	Integer	R	7 (Standby)
PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.3	Integer	R	9 (Cooling)

PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.4	Integer	R	8 (Power Save)
PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.5	Integer	R	8 (Power Save)
PdmPower	pdmPowerImplementedState	1.3.6.1.4.1.2699.2.4.1.4.1.1.2.6	Integer	R	10 (Warming)
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.1	String	R	Power On.
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.2	String	R	Power Off.
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.3	String	R	Projector is cooling down.
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.4	String	R	Low power mode.
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.5	String	R	Low power mode.
PdmPower	pdmPowerDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.3.6	String	R	Warming up.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.1	String	R	Full power on, all components active.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.2	String	R	Standby State. Only network electronics remain on.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.3	String	R	Going down to standby mode.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.4	String	R	Power off. Fan on.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.5	String	R	Power off. Fan on.
PdmPower	pdmPowerMfrDescription	1.3.6.1.4.1.2699.2.4.1.4.1.1.4.6	String	R	Power warming up. Fan on.
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.1	Integer	R	7 (Standby)
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.2	Integer	R	11 (On)
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.3	Integer	R	3 (No Transition)
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.4	Integer	R	7 (Standby)
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.5	Integer	R	11 (On)
PdmPower	pdmPowerTargetState	1.3.6.1.4.1.2699.2.4.1.4.1.1.5.6	Integer	R	3 (No Transition)
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.1	Integer	R	120
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.2	Integer	R	30
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.3	Integer	R	0
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.4	Integer	R	120
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.5	Integer	R	20
PdmPower	pdmPowerTransitionTime	1.3.6.1.4.1.2699.2.4.1.4.1.1.6.6	Integer	R	0
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.1	Integer	R	3 (Available)
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.2	Integer	R	4 (Not available)
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.3	Integer	R	4 (Not available)
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.4	Integer	R	3 (Available)
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.5	Integer	R	3 (Available)
PdmPower	pdmPowerCommandAvailable	1.3.6.1.4.1.2699.2.4.1.4.1.1.7.6	Integer	R	4 (Not available)
PdmPower	pdmPowerCurrentState	1.3.6.1.4.1.2699.2.4.1.4.2.0	Integer	R	Check if current projector status is correct.
PdmPower	pdmPowerRequestedState	1.3.6.1.4.1.2699.2.4.1.4.3.0	Integer	R/W	Check if current projector status is correct.
pdmDisplayCap	pdmDisplayCapResolutionH	1.3.6.1.4.1.2699.2.4.1.5.1.0	Integer	R	1600
pdmDisplayCap	pdmDisplayCapResolutionV	1.3.6.1.4.1.2699.2.4.1.5.2.0	Integer	R	1200

pdmDisplayCap	pdmDisplayCapPhysSizeH	1.3.6.1.4.1.2699.2.4.1.5.3.0	String	R	DEFVAL ( "" )
pdmDisplayCap	pdmDisplayCapPhysSizeV	1.3.6.1.4.1.2699.2.4.1.5.4.0	String	R	DEFVAL ( "" )
pdmDisplaySet	pdmDisplaySetIndex	1.3.6.1.4.1.2699.2.4.1.6.1.1.1.1	Integer	not-accessible	1
pdmDisplaySet	pdmDisplaySetAffectsAll	1.3.6.1.4.1.2699.2.4.1.6.1.1.2.1	Integer	R	DEFVAL { 1 }
pdmDisplaySet	pdmDisplaySetInputSource	1.3.6.1.4.1.2699.2.4.1.6.1.1.3.1	Integer	R/W	5. HDMI 1 14. HDMI 2 16. Network 17. HDMI 3 18. USB-Video 19. USB-Music 20. USB-Photo 21. USB-Documnet 22. USB-Settings
pdmDisplaySet	pdmDisplaySetBrightness	1.3.6.1.4.1.2699.2.4.1.6.1.1.4.1	Integer	R/W	
pdmDisplaySet	pdmDisplaySetBrightnessMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.5.1	Integer	R	100
pdmDisplaySet	pdmDisplaySetContrast	1.3.6.1.4.1.2699.2.4.1.6.1.1.6.1	Integer	R/W	
pdmDisplaySet	pdmDisplaySetContrastMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.7.1	Integer	R	100
pdmDisplaySet	pdmDisplaySetRed	1.3.6.1.4.1.2699.2.4.1.6.1.1.8.1	Integer	R	DEFVAL ( 0 )
pdmDisplaySet	pdmDisplaySetGreen	1.3.6.1.4.1.2699.2.4.1.6.1.1.9.1	Integer	R	DEFVAL ( 0 )
pdmDisplaySet	pdmDisplaySetBlue	1.3.6.1.4.1.2699.2.4.1.6.1.1.10.1	Integer	R	DEFVAL ( 0 )
pdmDisplaySet	pdmDisplaySetRGBMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.11.1	Integer	R	DEFVAL ( 100 )
pdmDisplaySet	pdmDisplaySetSaturation	1.3.6.1.4.1.2699.2.4.1.6.1.1.12.1	Integer	R/W	
pdmDisplaySet	pdmDisplaySetSatMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.13.1	Integer	R	100
pdmDisplaySet	pdmDisplaySetHue	1.3.6.1.4.1.2699.2.4.1.6.1.1.14.1	Integer	R/W	
pdmDisplaySet	pdmDisplaySetHueMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.15.1	Integer	R	100
pdmDisplaySet	pdmDisplaySetSharpness	1.3.6.1.4.1.2699.2.4.1.6.1.1.16.1	Integer	R/W	
pdmDisplaySet	pdmDisplaySetSharpMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.17.1	Integer	R	31
pdmDisplaySet	pdmDisplaySetColorTemp	1.3.6.1.4.1.2699.2.4.1.6.1.1.18.1	Integer	R/W	3. Custom 4. Low 5. Mid 6. High
pdmDisplaySet	pdmDisplaySetRedClrTmp	1.3.6.1.4.1.2699.2.4.1.6.1.1.19.1	Integer	R/W	DEFVAL ( 50 )
pdmDisplaySet	pdmDisplaySetGreenClrTmp	1.3.6.1.4.1.2699.2.4.1.6.1.1.20.1	Integer	R/W	DEFVAL ( 50 )
pdmDisplaySet	pdmDisplaySetBlueClrTmp	1.3.6.1.4.1.2699.2.4.1.6.1.1.21.1	Integer	R/W	DEFVAL ( 50 )
pdmDisplaySet	pdmDisplaySetClrTmpMax	1.3.6.1.4.1.2699.2.4.1.6.1.1.22.1	Integer	R	DEFVAL ( 0 )
pdmDisplaySet	pdmDisplaySetVideoMute	1.3.6.1.4.1.2699.2.4.1.6.2.0	Integer	R/W	Blank Screen 1. Muted 2. Not Muted 3. Original 5. Wide screen 16:9 7. 4:3
pdmDisplaySet	pdmDisplaySetDisplayMode	1.3.6.1.4.1.2699.2.4.1.6.3.0	Integer	R/W	
pdmLightSource	pdmLightSourceIndex	1.3.6.1.4.1.2699.2.4.1.7.1.1.1.1	Integer	not-accessible	1
pdmLightSource	pdmLightSourceDescription	1.3.6.1.4.1.2699.2.4.1.7.1.1.2.1	String	R	Laser Diode
pdmLightSource	pdmLightSourceStatus	1.3.6.1.4.1.2699.2.4.1.7.1.1.3.1	Integer	R	3. Okay 4. Failed
pdmLightSource	pdmLightSourceEcoSetting	1.3.6.1.4.1.2699.2.4.1.7.1.1.4.1	Integer	R/W	ECO Mode 4. Off -> Normal 5. On -> Low
pdmLightSource	pdmLightSourceAge	1.3.6.1.4.1.2699.2.4.1.7.1.1.5.1	Integer	R	
pdmLightSource	pdmLightSource	1.3.6.1.4.1.2699.2.4.1.7.1.1.6.1	Integer	R	

	ErrorCounter					
pdmLightSource	pdmLightSourceReset	1.3.6.1.4.1.2699.2.4.1.7.1.1.7.1	Integer	R/W		DEFVAL {1}
pdmLightSource	pdmLightSourceReplacementCount	1.3.6.1.4.1.2699.2.4.1.7.1.1.8.1	String	R		DEFVAL { "" }
pdmLightSource	pdmLightSourceReplacementTime	1.3.6.1.4.1.2699.2.4.1.7.1.1.9.1	String	R		
pdmLightSource	pdmLightSourceReplacementInterval	1.3.6.1.4.1.2699.2.4.1.7.1.1.10.1	Integer	R		DEFVAL { 0 }
pdmLightSource	pdmLightSourceReplacementPN	1.3.6.1.4.1.2699.2.4.1.7.1.1.11.1	String	R		DEFVAL { "" }
pdmFan	pdmFanIndex	1.3.6.1.4.1.2699.2.4.1.8.1.1.1.1	Integer	not-accessible		1
pdmFan	pdmFanDescription	1.3.6.1.4.1.2699.2.4.1.8.1.1.2.1	String	R		System fan
pdmFan	pdmFanStatus	1.3.6.1.4.1.2699.2.4.1.8.1.1.3.1	Integer	R		3. Okay 4. Warning
pdmFan	pdmFanSpeed	1.3.6.1.4.1.2699.2.4.1.8.1.1.4.1	Integer	R		DEFVAL { 0 }
pdmFan	pdmFanErrorCounter	1.3.6.1.4.1.2699.2.4.1.8.1.1.5.1	Integer	R		
pdmFan	pdmFanReset	1.3.6.1.4.1.2699.2.4.1.8.1.1.6.1	Integer	R/W		DEFVAL { 1 }
pdmFan	pdmFanReplacementCount	1.3.6.1.4.1.2699.2.4.1.8.1.1.7.1	String	R		DEFVAL { "" }
pdmFan	pdmFanReplacementTime	1.3.6.1.4.1.2699.2.4.1.8.1.1.8.1	String	R		DEFVAL { '1980-01-01T00:00:00' }
pdmFan	pdmFanReplacementInterval	1.3.6.1.4.1.2699.2.4.1.8.1.1.9.1	Integer	R		DEFVAL { 0 }
pdmFan	pdmFanReplacementPartNumber	1.3.6.1.4.1.2699.2.4.1.8.1.1.10.1	String	R		DEFVAL { "" }
pdmTempSensor	pdmTempSensorIndex	1.3.6.1.4.1.2699.2.4.1.10.1.1.1.1	Integer	not-accessible		1
pdmTempSensor	pdmTempSensorDescription	1.3.6.1.4.1.2699.2.4.1.10.1.1.2.1	String	R		Measure system internal temperature.
pdmTempSensor	pdmTempSensorStatus	1.3.6.1.4.1.2699.2.4.1.10.1.1.3.1	Integer	R		DEFVAL { 2 }
pdmTempSensor	pdmTempSensorStatus	1.3.6.1.4.1.2699.2.4.1.10.1.1.4.1	Integer	R		Describes the temperature being measured by the thermal sensor in 10ths of a degree C.
pdmTempSensor	pdmTempSensorErrorCounter	1.3.6.1.4.1.2699.2.4.1.10.1.1.5.1	Integer	R		
pdmTempSensor	pdmTempSensorReset	1.3.6.1.4.1.2699.2.4.1.10.1.1.6.1	Integer	R/W		DEFVAL { 1 }
pdmTempSensor	pdmTempSensorReplaceCount	1.3.6.1.4.1.2699.2.4.1.10.1.1.7.1	String	R		DEFVAL { "" }
pdmTempSensor	pdmTempSensorReplaceTime	1.3.6.1.4.1.2699.2.4.1.10.1.1.8.1	String	R		DEFVAL { '1980-01-01T00:00:00' }
pdmTempSensor	pdmTempSensorReplaceInterval	1.3.6.1.4.1.2699.2.4.1.10.1.1.9.1	Integer	R		DEFVAL { 0 }
pdmTempSensor	pdmTempSensorReplacePN	1.3.6.1.4.1.2699.2.4.1.10.1.1.10.1	String	R		DEFVAL { "" }
pdmTempSwitch	pdmTempSwitchIndex	1.3.6.1.4.1.2699.2.4.1.11.1.1.1.1	Integer	not-accessible		1
pdmTempSwitch	pdmTempSwitchDescription	1.3.6.1.4.1.2699.2.4.1.11.1.1.2.1	String	R		Avertronics INC.
pdmTempSwitch	pdmTempSwitchStatus	1.3.6.1.4.1.2699.2.4.1.11.1.1.3.1	Integer	R		3. Okay 5. Fail
pdmTempSwitch	pdmTempSwitchErrorCounter	1.3.6.1.4.1.2699.2.4.1.11.1.1.4.1	Integer	R		
pdmTempSwitch	pdmTempSwitchReset	1.3.6.1.4.1.2699.2.4.1.11.1.1.5.1	Integer	R/W		DEFVAL { 1 }
pdmTempSwitch	pdmTempSwitchReplaceCount	1.3.6.1.4.1.2699.2.4.1.11.1.1.6.1	String	R		DEFVAL { "" }
pdmTempSwitch	pdmTempSwitchReplaceTime	1.3.6.1.4.1.2699.2.4.1.11.1.1.7.1	String	R		DEFVAL { '1980-01-01T00:00:00' }
pdmTempSwitch	pdmTempSwitchReplacePN	1.3.6.1.4.1.2699.2.4.1.11.1.1.8.1	String	R		DEFVAL { "" }
pdmConnector	pdmConnectorIndex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.1	Integer	not-accessible		1
pdmConnector	pdmConnectorIndex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.2	Integer	not-accessible		2
pdmConnector	pdmConnectorIndex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.3	Integer	not-accessible		3

pdmConnector	dex pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.4	Integer	not-accessible	4
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.5	Integer	not-accessible	5
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.6	Integer	not-accessible	6
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.7	Integer	not-accessible	7
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.8	Integer	not-accessible	8
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.9	Integer	not-accessible	9
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.10	Integer	not-accessible	10
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.11	Integer	not-accessible	11
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.12	Integer	not-accessible	12
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.13	Integer	not-accessible	13
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.14	Integer	not-accessible	14
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.15	Integer	not-accessible	15
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.16	Integer	not-accessible	16
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.17	Integer	not-accessible	17
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.18	Integer	not-accessible	18
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.19	Integer	not-accessible	19
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.20	Integer	not-accessible	20
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.21	Integer	not-accessible	21
pdmConnector	pdmConnectorIn dex	1.3.6.1.4.1.2699.2.4.1.12.1.1.1.22	Integer	not-accessible	22
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.5	String	R	HDMI 1
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.14	String	R	HDMI2
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.16	String	R	Network
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.17	String	R	HDMI 3
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.18	String	R	USB-Video
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.19	String	R	USB-Music
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.20	String	R	USB-Photo
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.21	String	R	USB-Document
pdmConnector	pdmConnectorD escription	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.22	String	R	USB-Settings
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.1	Integer	R	3 (See Note 2)
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.2	Integer	R	3
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.3	Integer	R	10
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.4	Integer	R	13
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.5	Integer	R	6
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.6	Integer	R	12
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.7	Integer	R	21
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.8	Integer	R	20
pdmConnector	pdmConnectorT ype	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.9	Integer	R	7

pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.10	Integer	R	4
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.2.11	Integer	R	9
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.12	Integer	R	22
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.13	Integer	R	23
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.14	Integer	R	6
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.15	Integer	R	12
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.16	Integer	R	6
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.17	Integer	R	6
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.18	Integer	R	20
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.19	Integer	R	20
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.20	Integer	R	20
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.21	Integer	R	20
pdmConnector	pdmConnectorType	1.3.6.1.4.1.2699.2.4.1.12.1.1.3.22	Integer	R	20
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.5	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.14	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.15	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.16	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.17	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.18	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.19	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.20	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.21	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorEnabled	1.3.6.1.4.1.2699.2.4.1.12.1.1.4.22	Integer	R	DEFVAL { 1 }
pdmConnector	pdmConnectorVideoCurrInput	1.3.6.1.4.1.2699.2.4.1.12.2.0	Integer	R/W	5. HDMI1 14. HDMI 2 16. Network 17. HDMI 3 18. USB-Video 19. USB-Music 20. USB-Photo 21. USB-Document 22. USB-Settings
pdmInterlockTable	pdmInterlockIndex	1.3.6.1.4.1.2699.2.4.1.13.1.1.1.1	Integer	not-accessible	1
pdmInterlockTable	pdmInterlockIndex	1.3.6.1.4.1.2699.2.4.1.13.1.1.2.1	String	R	DEFVAL { "" }
pdmInterlockTable	pdmInterlockIndex	1.3.6.1.4.1.2699.2.4.1.13.1.1.3.1	Integer	R	DEFVAL { 3 }
pdmLocaleCharacterSet	pdmLocaleCharacterSetIndex	1.3.6.1.4.1.2699.2.4.1.14.1.1.1.1	Integer	not-accessible	1
pdmLocaleCharacterSet	pdmLocaleCharacterSetEnum	1.3.6.1.4.1.2699.2.4.1.14.1.1.2.1	Integer	R	DEFVAL { 4 }
pdmLocaleCharacterSet	pdmLocaleCharacterSetEnumEWS	1.3.6.1.4.1.2699.2.4.1.14.2.0	Integer	R	DEFVAL { 4 }
pdmLocaleLanguage	pdmLocaleLanguageIndex	1.3.6.1.4.1.2699.2.4.1.15.1.1.1.1	Integer	not-accessible	1
pdmLocaleLanguage	pdmLocaleLanguageTag	1.3.6.1.4.1.2699.2.4.1.15.1.1.2.1	String	R	DEFVAL { en-US }
pdmLocaleLanguage	pdmLocaleLanguageTagEWS	1.3.6.1.4.1.2699.2.4.1.15.2.0	String	R	DEFVAL { en-US }
pdmLocaleLanguage	pdmLocaleLanguageTagOSD	1.3.6.1.4.1.2699.2.4.1.15.3.0	String	R	DEFVAL { en-US }

pdmLocaleLanguage	pdmLocaleLanguageTagWSM	1.3.6.1.4.1.2699.2.4.1.154.0	String	R	DEFVAL { en-US }
pdmAudio	pdmAudioDescription	1.3.6.1.4.1.2699.2.4.1.16.1.0	String	R	DEFVAL { "" }
pdmAudio	pdmAudioVolume	1.3.6.1.4.1.2699.2.4.1.16.2.0	Integer	R/W	
pdmAudio	pdmAudioMute	1.3.6.1.4.1.2699.2.4.1.16.3.0	Integer	R/W	1. Muted 2. Not Muted
pdmAudio	pdmAudioTreble	1.3.6.1.4.1.2699.2.4.1.16.4.0	Integer	R	DEFVAL { 0 }
pdmAudio	pdmAudioBass	1.3.6.1.4.1.2699.2.4.1.16.5.0	Integer	R	DEFVAL { 0 }
pdmAudio	pdmAudioBalance	1.3.6.1.4.1.2699.2.4.1.16.6.0	Integer	R	DEFVAL { 0 }
pdmAlert	pdmAlertIndex	1.3.6.1.4.1.2699.2.4.1.18.1.1.1	Integer	not-accessible	1
pdmAlert	pdmAlertGroupType	1.3.6.1.4.1.2699.2.4.1.18.1.1.2.1	String	R	See Note 1
pdmAlert	pdmAlertGroupID	1.3.6.1.4.1.2699.2.4.1.18.1.1.3.1	String	R	See Note 1
pdmAlert	pdmAlertCode	1.3.6.1.4.1.2699.2.4.1.18.1.1.4.1	String	R	DEFVAL { "" } Alert's condition has lamp Fail, Lamp hours running out, Projector Overheating, Lamp Overheating and Fan Error.
pdmAlert	pdmAlertDescription	1.3.6.1.4.1.2699.2.4.1.18.1.1.5.1	String	R	
pdmAlert	pdmAlertSeverityLevel	1.3.6.1.4.1.2699.2.4.1.18.1.1.6.1	Integer	R	See Note 1
pdmAlert	pdmAlertTrainingLevel	1.3.6.1.4.1.2699.2.4.1.18.1.1.7.1	Integer	R	DEFVAL { 2 }
pdmAlert	pdmAlertDateTime	1.3.6.1.4.1.2699.2.4.1.18.1.1.8.1	String	R	DEFVAL { '1980-01-01T00:00:00' }
pdmAlert	pdmAlertPowerOnCount	1.3.6.1.4.1.2699.2.4.1.18.1.1.9.1	String	R	DEFVAL { "" }
pdmAlert	pdmAlertSysUptime	1.3.6.1.4.1.2699.2.4.1.18.1.1.10.1	String	R	DEFVAL { "" }
pdmAlert	pdmAlertCriticalAlertsCount	1.3.6.1.4.1.2699.2.4.1.18.2.0	Integer	R	
pdmAlert	pdmAlertAllAlertsCount	1.3.6.1.4.1.2699.2.4.1.18.3.0	Integer	R	

**Note 1:**

a) If there is no any current alert, all of OID in alert table will respond default value.

pdmAlertGroupType = ""  
pdmAlertGroupID = 0  
pdmAlertSeverity = other (1)  
The reset Object will respond default.

b) If there is FAN alert happen, the tables is shown below.

pdmAlertGroupType = "Fan"  
pdmAlertGroupID = "Fan Error"  
pdmAlertSeverity = Critical (3)  
The rest Object will respond default.

c) If there is Lamp fail alert happen, the tables is shown below.

pdmAlertGroupType = "Lamp"  
pdmAlertGroupID= Lamp Fail  
pdmAlertSeverity = Critical (3)  
The rest Object will respond default.

d) If there is Projector Over-heating alert, the tables is shown below.

pdmAlertGroupType = "ThermalSensor"  
pdmAlertGroupID= "Projector Overheating"  
pdmAlertSeverity = warning (4)  
The rest Object will respond default.

**Note 2:**

1. Other
2. Unknown
3. VGA
4. DVI-D
5. DVI-I
6. HDMI
7. Component Video BNC-5
8. Component Video BNC-3
9. DisplayPort
10. S-Video
11. RJ45
12. Wireless

13. RCA Plug Video-3
14. RCA Plug Audio
15. Mini jack 2 dot 5mm Audio
16. Mini jack 3 dot 5mm Audio
17. Coax Audio
18. Fibre Audio
19. Memory Card
20. USB Memory
21. USB Display
22. Intel® WiDi
23. Internal Memory
24. HDMI2
25. Wireless Display Dongle
26. Network

**Information in this document is subject to change without notice.**

**© 2017 Dell Inc. All rights reserved.**

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell and the DELL logo are trademarks of Dell Inc.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

August 2017 Rev. A00