

Dell SupportAssist Version 1.2
For Dell OpenManage
Essentials
Support Matrix



Notes and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

Information in this publication is subject to change without notice.

© 2013 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, Dell Precision™, OptiPlex™, Latitude™, PowerEdge™, PowerVault™, PowerConnect™, OpenManage™, EqualLogic™, KACE™, FlexAddress™ and Vostro™ are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core™ and Celeron® are registered trademarks of Intel Corporation in the U.S. and other countries. AMD® is a registered trademark and AMD Opteron™, AMD Phenom™, and AMD Sempron™ are trademarks of Advanced Micro Devices, Inc. Microsoft®, Windows®, Windows Server®, MS-DOS® and Windows Vista® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Red Hat Enterprise Linux® and Enterprise Linux® are registered trademarks of Red Hat, Inc. in the United States and/or other countries. Novell® is a registered trademark and SUSE™ is a trademark of Novell Inc. in the United States and other countries. Oracle® is a registered trademark of Oracle Corporation and/or its affiliates. Citrix®, Xen®, XenServer® and XenMotion® are either registered trademarks or trademarks of Citrix Systems, Inc. in the United States and/or other countries. VMware®, Virtual SMP®, vMotion®, vCenter®, and vSphere® are registered trademarks or trademarks of VMWare, Inc. in the United States or other countries.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

This document lists the devices supported by Dell SupportAssist.



NOTE: For more information on the devices listed in this document, see the documentation for that device.

Supported Devices

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
Dell PowerEdge		
1900	Yes	Yes
1950	Yes	Yes
1955	Yes	Yes
2900	Yes	Yes
2950	Yes	Yes
2970	Yes	Yes
6950	Yes	Yes
T110II	Yes	Yes
T310	Yes	Yes
T320	Yes	Yes
T420	Yes	Yes
T620	Yes	Yes
T710	Yes	Yes
R210II	Yes	Yes
R310	Yes	Yes
R320	Yes	Yes
R410	Yes	Yes
R415	Yes	Yes
R420	Yes	Yes
R510	Yes	Yes
R515	Yes	Yes
R520	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
R610	Yes	Yes
R620	Yes	Yes
R710	Yes	Yes
R715	Yes	Yes
R720	Yes	Yes
R720xd	Yes	Yes
R815	Yes	Yes
R820	Yes	Yes
R910	Yes	Yes
M420	Yes	Yes
M520	Yes	Yes
M600	Yes	Yes
M605	Yes	Yes
M610	Yes	Yes
M610x	Yes	Yes
M620	Yes	Yes
M710	Yes	Yes
M710HD	Yes	Yes
M805	Yes	Yes
M820	Yes	Yes
M905	Yes	Yes
M910	Yes	Yes
M915	Yes	Yes
M1000e	Yes	Yes
T100	Yes	Yes
T105	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
T110	Yes	Yes
T300	Yes	Yes
T410	Yes	Yes
T605	Yes	Yes
T610	Yes	Yes
R200	Yes	Yes
R210	Yes	Yes
R300	Yes	Yes
R805	Yes	Yes
R810	Yes	Yes
R900	Yes	Yes
R905	Yes	Yes
VRTX	Yes	No*

NOTE: The VRTX servers have remote monitoring, case creation, and automatic data collection capabilities when enabled. The VRTX chassis has remote monitoring and case creation when enabled, but no automatic data collection at this time.

Dell EqualLogic

PS4100E	Yes	Yes
PS4100XV 3.5	Yes	Yes
PS4110E	Yes	Yes
PS4110 XV 3.5	Yes	Yes
PS6100E	Yes	Yes
PS6100S	Yes	Yes
PS6100X	Yes	Yes
PS6100XS	Yes	Yes
PS6100XV	Yes	Yes
PS6100XV 3.5	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
PS6110E	Yes	Yes
PS6110S	Yes	Yes
PS6110X	Yes	Yes
PS6110XS	Yes	Yes
PS6110XV	Yes	Yes
PS6110XV 3.5	Yes	Yes
PS6500E	Yes	Yes
PS6500ES	Yes	Yes
PS6500X	Yes	Yes
PS6510E	Yes	Yes
PS6510ES	Yes	Yes
PS6510X	Yes	Yes
PSM 4110E Blade Array	Yes	Yes
PSM 4110X Blade Array	Yes	Yes
PSM 4110XV Blade Array	Yes	Yes
PSM 4110XS Blade Array	Yes	Yes
PS4000E	Yes	Yes
PS4000X	Yes	Yes
PS4000XV	Yes	Yes
PS5500E	Yes	Yes
PS6000E	Yes	Yes
PS6000X	Yes	Yes
PS6000S	Yes	Yes
PS6000XV	Yes	Yes
PS6000XVS	Yes	Yes
PS6010E	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
PS6010X	Yes	Yes
PS6010S	Yes	Yes
PS6010XV	Yes	Yes
PS6010XVS	Yes	Yes
Dell PowerVault		
MD1200	Yes	No
MD1220	Yes	No
MD3060e	Yes	No
MD3200	Yes	Yes
MD3200i	Yes	Yes
MD3220	Yes	Yes
MD3220i	Yes	Yes
MD3260	Yes	Yes
MD3260i	Yes	Yes
MD3600i	Yes	Yes
MD3600f	Yes	Yes
MD3620f	Yes	Yes
MD3620i	Yes	Yes
MD3660i	Yes	Yes
MD3660f	Yes	Yes
NX200	Yes	Yes
NX300	Yes	Yes
NX400	Yes	Yes
NX3000	Yes	Yes
NX3000 HA Cluster	Yes	Yes
NX3100	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
NX3200	Yes	Yes
NX3300	Yes	No
MD1000	Yes	No
MD1120	Yes	No
Dell PowerConnect		
M8024	Yes	Yes
M8024-k	Yes	Yes
M8428-K	Yes	Yes
M6348	Yes	Yes
M6220	Yes	Yes
5524	Yes	Yes
5548	Yes	Yes
5548P	Yes	Yes
6224	Yes	Yes
6224P	Yes	Yes
6224F	Yes	Yes
6248	Yes	Yes
6248P	Yes	Yes
7024	Yes	Yes
7024P	Yes	Yes
7024F	Yes	Yes
7048	Yes	Yes
7048P	Yes	Yes
7048R	Yes	Yes
B-8000	Yes	Yes
8024	Yes	Yes

Table 1. Devices Supported By SupportAssist

Device	Remote Monitoring And Case Creation	Automatic Data Collection
8024F	Yes	Yes
Dell Force 10		
S4810	Yes	Yes

Minimum Requirements For Dell SupportAssist

Software

- Dell OpenManage Essentials 1.1 or 1.2.
- Optional: Dell OpenManage Server Administrator (OMSA) installed and operational on all managed PowerEdge devices.
- SNMP agent enabled on all managed PowerEdge, PowerEdge VRTX, EqualLogic, PowerVault, iDRAC7, CMC, Force10, and PowerConnect devices for OpenManage Essentials discovery.
- All managed PowerEdge, PowerEdge VRTX, EqualLogic, PowerVault, iDRAC7, CMC, Force10, and PowerConnect devices configured to send SNMP traps to the OpenManage Essentials server.
- All managed PowerEdge, PowerEdge VRTX, EqualLogic, PowerVault, iDRAC7, CMC, Force10, and PowerConnect devices discovered, categorized, and inventoried by the OpenManage Essentials server.
- PowerVault Modular Disk Storage Manager (MDSM) installed on the OpenManage Essentials server, in order to support PowerVault MD Series arrays.
- A trust relationship must exist between the domains of the management server and the managed nodes.
- Microsoft .Net Framework 4.0
- Microsoft ASP.Net
- IIS 7.x

Supported Operating Systems For Management Stations

- Microsoft Windows Server 2012 Standard and Datacenter Editions
- Windows Server 2008 SP2 Standard and Enterprise (x86) Editions
- Windows Server 2008 SP2 Standard and Enterprise (x64) Editions
- Windows Server 2008 R2 SP1 Standard and Enterprise Editions



NOTE: SupportAssist is also supported on a Windows Server 2008 R2 SP1 domain controller.

Supported Operating Systems For Managed Nodes

Windows

- Windows Server 2012 Essentials, Standard, and Datacenter Editions
- Windows Small Business Server 2011 Premium Edition
- Windows Server 2008 R2 SP1 Standard, Enterprise, and Foundation Editions
- Windows Server 2008 R2 Standard, Enterprise, and Foundation Editions
- Windows Server 2008 SP2 Standard, Enterprise, and Foundation (x64) Editions
- Windows Server 2008 SP2 Standard, Enterprise, and Foundation (x86) Editions
- Windows Server 2008 SP1 Standard and Enterprise (x64) Editions
- Windows Server 2008 SP1 Standard and Enterprise (x86) Editions
- Windows Server 2003 R2 SP2 Standard and Enterprise (x64) Editions
- Windows Server 2003 R2 SP2 Standard and Enterprise (x86) Editions

Linux

- SUSE Linux Enterprise Server 11 SP2 (x86_64)
- SUSE Linux Enterprise Server 11 SP3 (x86_64)
- SUSE Linux Enterprise Server 10 SP4 (x86_64)
- Red Hat Enterprise Virtualization Manager 6.4
- Red Hat Enterprise Linux 6.4
- Red Hat Enterprise Linux 6.1 (x64)

- Red Hat Enterprise Linux 6.0 (x64)
- Red Hat Enterprise Linux 5.9
- Red Hat Enterprise Linux 5 Update 7 (x86)
- Red Hat Enterprise Linux 5 Update 6 (x86_x64)
- Red Hat Enterprise Linux 5 Update 5 (x86_x64)
- Red Hat Enterprise Linux 4 Update 7 (x86)

Virtualization

- VMware vSphere ESXi 5.0 Update 2
- VMware vSphere ESXi 5.0 Update 1
- VMware vSphere ESXi 5.1 Update 1
- VMware vSphere ESXi 5.1
- VMware vSphere ESXi 5.0
- VMware vSphere ESXi 4.1
- VMware vSphere ESX 4.1 Update 1
- VMware vSphere ESX 4.1 Update 2
- VMware vSphere ESX 4.1 Update 3
- VMware vSphere ESX 4.0 Update 3

Hardware

Table 2. Minimum Hardware Requirements

Hardware	Medium Deployments	Large Deployments
Number of managed systems	Up to 500	500 to 2000
Processor	6 cores (1.8 GHz minimum)	10 cores (1.8 GHz minimum)
Memory	10 GB	12 GB
Hard drive	8 GB	10 GB

Network

- Internet connection – standard GbE network.

- Port 443 must be open on the OpenManage Essentials management server.
- The OpenManage Essentials management server on which the Dell SupportAssist client is installed must be able to communicate with the Dell SupportAssist server hosted by Dell over the HTTPS protocol.

Browsers

- Microsoft Internet Explorer 8, 9, and 10
- Mozilla FireFox 20 and 21



NOTE: Supported only on Windows-based operating systems.