

1 Software Update  
2 Profile

3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31

**Document Number: DCIM 1038**  
**Document Type: Specification**  
**Document Status: Final**  
**Document Language: E**  
**Date: 2012-03-08**

**Version: 1.0.0**



32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65

THIS PROFILE IS FOR INFORMATIONAL PURPOSES ONLY, AND MAY CONTAIN TYPOGRAPHICAL ERRORS AND TECHNICAL INACCURACIES. THE CONTENT IS PROVIDED AS IS, WITHOUT EXPRESS OR IMPLIED WARRANTIES OF ANY KIND. ABSENT A SEPARATE AGREEMENT BETWEEN YOU AND DELL™ WITH REGARD TO FEEDBACK TO DELL ON THIS PROFILE SPECIFICATION, YOU AGREE ANY FEEDBACK YOU PROVIDE TO DELL REGARDING THIS PROFILE SPECIFICATION WILL BE OWNED AND CAN BE FREELY USED BY DELL.

© 2012 Dell Inc. All rights reserved. Reproduction in any manner whatsoever without the express written permission of Dell, Inc. is strictly forbidden. For more information, contact Dell.

*Dell* and the *DELL* logo are trademarks of Dell Inc. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell disclaims proprietary interest in the marks and names of others.

# CONTENTS

66			
67	1	Scope .....	5
68	2	Normative References.....	5
69	3	Terms and Definitions .....	6
70	4	Symbols and Abbreviated Terms .....	7
71	5	Synopsis.....	7
72	6	Description .....	8
73	7	Implementation Description.....	8
74	7.1	DCIM_SoftwareInstallationService .....	9
75	7.2	Software Update Profile Registration – DCIM_LCRegisteredProfile.....	10
76	8	Methods.....	11
77	8.1	DCIM_SoftwareInstallationService.InstallFromURI ().....	11
78	8.2	DCIM_SoftwareInstallationService.InstallFromSoftwareIdentity ().....	12
79	8.3	DCIM_SoftwareInstallationService.CreateRebootJob () .....	14
80	9	Use Cases.....	14
81	10	CIM Elements.....	15
82	11	Privilege and License Requirement .....	15
83			

84 **Figures**

85 Figure 1 – Software Update Profile: Class Diagram ..... 8  
86

87 **Tables**

88 Table 1 – Related Profiles ..... 7  
89 Table 2 – CIM Elements: Software Update Profile ..... 8  
90 Table 3 – DCIM\_SoftwareInstallationService.- Operations ..... 9  
91 Table 4 – DCIM\_SoftwareInstallationService- Properties..... 9  
92 Table 5 – DCIM\_LCRegisteredProfile - Operations..... 10  
93 Table 6 – Class: DCIM\_LCRegisteredProfile..... 10  
94 Table 7 – DCIM\_SoftwareInstallationService.InstallFromURI () Method: Return Values..... 12  
95 Table 8 – SoftwareInstallationService.InstallFromURI () Method: Parameters ..... 12  
96 Table 9 – SoftwareInstallationService.InstallFromURI () Method: Standard Messages..... 12  
97 Table 10 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Return Values ..... 13  
98 Table 11 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Parameters ..... 13  
99 Table 12 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Standard Messages13  
100 Table 13 – DCIM\_SoftwareInstallationService.CreateRebootJob ()Method: Return Values ..... 14  
101 Table 14 – DCIM\_SoftwareInstallationService.CreateRebootJob ()Method: Parameters..... 14  
102 Table 15 – DCIM\_SoftwareInstallationService.CreateRebootJob () Method:: Standard Messages ..... 14  
103 Table 16 – Privilege and License Requirements ..... 15

104

105

# Software Update Profile

## 106 1 Scope

107 The Software Update Profile extends the management capabilities of referencing profiles by adding the  
108 capability to update platform firmware or software.

## 109 2 Normative References

110 Refer to the following documents for more information.

111 **NOTE:** For dated references, only the edition cited applies. For undated references, the latest edition of  
112 the referenced document (including any amendments) apply

- 113 • DMTF DSP1033, *Profile Registration Profile 1.0.0*
- 114 • *Dell Lifecycle Controller Best Practices Guide*  
115 *1.0*, [http://en.community.dell.com/techcenter/extras/m/white\\_papers/20066173.aspx](http://en.community.dell.com/techcenter/extras/m/white_papers/20066173.aspx)
- 116 • *Dell WSMAN Licenses and Privileges 1.0*
- 117 • ISO/IEC Directives, Part 2, *Rules for the structure and drafting of International*  
118 *Standards*, [http://isotc.iso.org/livelink/livelink.exe?func=ll&objId=4230456&objAction=browse&sort](http://isotc.iso.org/livelink/livelink.exe?func=ll&objId=4230456&objAction=browse&sort=subtype)  
119 [=subtype](http://isotc.iso.org/livelink/livelink.exe?func=ll&objId=4230456&objAction=browse&sort=subtype)
- 120 • Unified Modeling Language (UML) from the Open Management Group  
121 (OMG), <http://www.uml.org>
- 122 • Dell Tech Center MOF Library:  
123 <http://www.delltechcenter.com/page/DCIM.Library.MOF>
- 124 • Related Managed Object Format (MOF) files:
  - 125 ○ DCIM\_SoftwareInstallationService.mof
  - 126 ○ DCIM\_LCElementConformsToProfile.mof
  - 127 ○ DCIM\_LCRegisteredProfile.mof

128

## 129 **3 Terms and Definitions**

130 For the purposes of this document, the following terms and definitions apply.

### 131 **3.1**

132 **can** - Used for statements of possibility and capability, whether material, physical, or causal.

### 133 **3.2**

134 **cannot** - Used for statements of possibility and capability, whether material, physical, or causal.

### 135 **3.3**

136 **conditional** - Indicates requirements to be followed strictly in order to conform to the document when the  
137 specified conditions are met.

### 138 **3.4**

139 **mandatory** - Indicates requirements to be followed strictly in order to conform to the document and from  
140 which no deviation is permitted.

### 141 **3.5**

142 **may** - Indicates a course of action permissible within the limits of the document.

### 143 **3.6**

144 **need not** - Indicates a course of action permissible within the limits of the document.

### 145 **3.7**

146 **optional** - Indicates a course of action permissible within the limits of the document.

### 147 **3.8**

148 **referencing profile** - Indicates a profile that owns the definition of this class and can include a reference  
149 to this profile in its "Related Profiles" table.

### 150 **3.9**

151 **shall** - Indicates requirements to be followed strictly in order to conform to the document and from which  
152 no deviation is permitted

### 153 **3.10**

154 **shall not** - Indicates requirements to be followed strictly in order to conform to the document and from  
155 which no deviation is permitted.

### 156 **3.11**

157 **should** - Indicates that among several possibilities, one is recommended as particularly suitable, without  
158 mentioning or excluding others, or that a certain course of action is preferred but not necessarily required.

### 159 **3.12**

160 **should not** - Indicates that a certain possibility or course of action is deprecated but not prohibited.

### 161 **3.13**

#### 162 **Interop Namespace: root/interop**

163 Interop Namespace: root/interop is where instrumentation instantiates classes to advertise its capabilities  
164 for client discovery.

165 **3.14**  
166 **Implementation Namespace: root/dcim**  
167 Implementation Namespace: root/dcim is where instrumentation instantiates classes relevant to executing  
168 core management tasks.

169 **3.15**  
170 **ENUMERATE**  
171 Refers to WS-MAN **ENUMERATE** operation as described in Section 8.2 of DSP0226\_V1.1 and Section  
172 9.1 of DSP0227\_V1.0

173 **3.16**  
174 **GET**  
175 Refers to WS-MAN **GET** operation as defined in Section 7.3 of DSP00226\_V1.1 and Section 7.1 of  
176 DSP0227\_V1.0

## 177 **4 Symbols and Abbreviated Terms**

178 **4.1**  
179 **CIM** - Common Information Model

180 **4.2**  
181 **DCIM** - Dell Common Information Model

## 182 **5 Synopsis**

183 **Profile Name: Software Update**

184 **Version: 1.0.0**

185 **Organization: DCIM**

186 **CIM Schema Version: 2.26 Experimental**

187 **Central Class: DCIM\_SoftwareInstallationService**

188 **Scoping Class: DCIM\_ComputerSystem**

189 The Software Update Profile extends the management capability of the referencing profiles by adding the  
190 capability to update the platform's firmware or software.

191 DCIM\_InstallationService shall be the Central Class. CIM\_ComputerSystem shall be the Scoping Class.  
192 Table 1 identifies profiles that are related to this profile.

193

**Table 1 – Related Profiles**


<b>Profile Name</b>	<b>Organization</b>	<b>Version</b>	<b>Relationship</b>
Profile Registration	DCIM	1.0	Reference
Job Control Profile	Dell	1.0.0	Mandatory

194 **6 Description**

195 The Software Update Profile describes the management interface for driver/firmware updates.

196 Figure 1 represents the class schema for the Software Update Profile. The software update in a managed  
 197 system is represented by the instance of DCIM\_SoftwareInstallationService class. The software update  
 198 profile information is represented with the instance of LC\_RegisteredProfile. The result of a software  
 199 update represented as the instance of DCIM\_SoftUpdateConcreteJob.

200



201

202 **Figure 1 – Software Update Profile: Class Diagram**

203 **7 Implementation Description**

204 This section describes the implementation of Dell Software Update Profile.

205 **Table 2 – CIM Elements: Software Update Profile**

Element Name	Requirement	Description
<b>Classes</b>		
DCIM_SoftwareInstallationService	Mandatory	The class shall be implemented in both the <i>Implementation Namespaces: root/dcim</i> . See section 7.1
DCIM_LCElementConformsToProfile	Mandatory	The class shall be implemented in both the <i>Interop Namespace: root/interop</i> and <i>Implementation Namespace: root/dcim</i> . See section 7.1 and 7.2
DCIM_LCRegisteredProfile	Mandatory	The class shall be implemented in the <i>Interop Namespace: root/interop</i> . See section 7.2
<b>Indications</b>		
None defined in this profile		

206

## 207 7.1 DCIM\_SoftwareInstallationService

208 This section describes the implementation for the DCIM\_SoftwareInstallationService.

209 This class is instantiated in the Implementation Namespace: root/dcim.

210 The DCIM\_LCElementConformsToProfile association's ManagedElement property shall references the  
211 DCIM\_SoftwareInstallationService instance(s).

### 212 7.1.1 Resource URIs for WinRM®

213 The class Resource URI shall be:

214 [http://schemas.dell.com/wbem/wscim/1/cim-schema/2 / DCIM\\_SoftwareInstallationService](http://schemas.dell.com/wbem/wscim/1/cim-schema/2/DCIM_SoftwareInstallationService?__cimnamespace=root/dcim)  
215 [?\\_\\_cimnamespace=root/dcim](http://schemas.dell.com/wbem/wscim/1/cim-schema/2/DCIM_SoftwareInstallationService?__cimnamespace=root/dcim)

216 The key properties are SystemCreationClassName, CreationClassName, SystemName, and Name.

217 The instance Resource URI for DCIM\_SoftwareInstallationService instance shall be:

218 [http://schemas.dell.com/wbem/wscim/1/cim-schema/2/  
219 DCIM\\_SoftwareInstallationService?\\_\\_cimnamespace=root/dcim+SystemCreationClassName=DCIM\\_Co  
220 mputerSystem+SystemName= IDRAC:ID +CreationClassName= DCIM\\_SoftwareInstallationService  
221 +Name= SoftwareUpdate](http://schemas.dell.com/wbem/wscim/1/cim-schema/2/DCIM_SoftwareInstallationService?__cimnamespace=root/dcim+SystemCreationClassName=DCIM_ComputerSystem+SystemName=IDRAC:ID+CreationClassName=DCIM_SoftwareInstallationService+Name=SoftwareUpdate)

### 222 7.1.2 Operations

223 The following table lists the operations implemented on DCIM\_SoftwareInstallationService.

224 **Table 3 – DCIM\_SoftwareInstallationService.- Operations**

Operation Name	Requirements	Required Input
Get	Mandatory	Instance URI
Enumerate	Mandatory	Class URI
Invoke	Mandatory	Instance URI and Method parameters

225

### 226 7.1.3 Class Properties

227 The following table lists the implemented properties for DCIM\_SoftwareInstallationService instance in a  
228 system. The “Requirements” column shall denote whether the property is implemented (for requirement  
229 definitions, see section 0). The “Additional Requirements” column shall denote either possible values for  
230 the property, or requirements on the value formulation.

231 **Table 4 – DCIM\_SoftwareInstallationService- Properties**

Property Name	Type	Requirement	Additional Requirement
CreationClassName	String	Mandatory	The property value shall be "DCIM_SoftwareInstallationService".
Name	String	Mandatory	The property value shall be "SoftwareUpdate".
ElementName	String	Mandatory	The property value shall be "Software Installation Service".
SystemCreationClassName	String	Mandatory	The property value shall be "DCIM_ComputerSystem".
SystemName	String	Mandatory	The property value shall be "IDRAC:ID".

## 232 7.2 Software Update Profile Registration – DCIM\_LCRegisteredProfile

233 This section describes the implementation for the DCIM\_LCRegisteredProfile class.

234 This class shall be instantiated in the Interop Namespace: root/interop.

235 The DCIM\_LCElementConformsToProfile association(s)' ConformantStandard property shall reference  
236 the DCIM\_LCRegisteredProfile instance.

### 237 7.2.1 Resource URIs for WinRM®

238 The class Resource URI shall be "http://schemas.dmtf.org/wbem/wscim/1/cim-  
239 schema/2/CIM\_RegisteredProfile?\_\_cimnamespace=root/interop"

240 The key property shall be the InstanceID property.

241 The instance Resource URI shall be: "http://schemas.dell.com/wbem/wscim/1/cim-  
242 schema/2/DCIM\_LCRegisteredProfile?\_\_cimnamespace=root/interop+InstanceID=DCIM:SoftwareUpdate  
243 :1.0.0"

### 244 7.2.2 Operations

245 The following table lists the operations implemented on DCIM\_LCRegisteredProfile.

246 **Table 5 – DCIM\_LCRegisteredProfile - Operations**

Operation Name	Requirements	Required Input
Get	Mandatory	Instance URI
Enumerate	Mandatory	Class URI

247

### 248 7.2.3 Class Properties

249 The following table lists the implemented properties for DCIM\_LCRegisteredProfile instance representing  
250 Software Update Profile implementation. The "Requirements" column shall denote whether the property is  
251 implemented (for requirement definitions, see section 0). The "Additional Requirements" column shall  
252 denote either possible values for the property, or requirements on the value formulation.

253 **Table 6 – Class: DCIM\_LCRegisteredProfile**

Properties	Type	Requirement	Additional Requirements
InstanceID	string	Mandatory	This property shall have a value of "DCIM:SoftwareUpdate:1.0.0"
RegisteredName	string	Mandatory	This property shall have a value of "Software Update".
RegisteredVersion	string	Mandatory	This property shall have a value of "1.0.0".
RegisteredOrganization	uint16	Mandatory	This property shall have a value of 1 (Other).
OtherRegisteredOrganization	string	Mandatory	This property shall match "DCIM".
AdvertiseTypes[]	uint16	Mandatory	This property array shall have values: "1(Other)" and "1(Other)".
AdvertiseTypeDescriptions[]	string	Mandatory	This property array shall have values "WS-Identify" and "Interop Namespace".

Properties	Type	Requirement	Additional Requirements
ProfileRequireLicense[]	string	Mandatory	This property array shall describe the required licenses for this profile.  If no license is required for the profile, the property shall have value NULL.
ProfileRequireLicenseStatus[]	string	Mandatory	This property array shall contain the status for the corresponding license in the same element index of the ProfileRequireLicense array property. Each array element shall contain: "LICENSED" "NOT_LICENSED" If no license is required for the profile, the property shall have value NULL.

254

## 255 **8 Methods**

256 This section details the requirements for supporting intrinsic operations and extrinsic methods for the CIM  
257 elements defined by this profile.

### 258 **8.1 DCIM\_SoftwareInstallationService.InstallFromURI ()**

259 InstallFromURI method is used to generate the JobID for the update operation.

260

**Table 7 – DCIM\_SoftwareInstallationService.InstallFromURI () Method: Return Values**

Value	Description
2	Error
4096 <sup>1</sup>	Job started <sup>1</sup>

261

**Table 8 – SoftwareInstallationService.InstallFromURI () Method: Parameters**

Qualifiers	Name	Type	Description/Values
IN	URI	String	URI location of firmware to update a component.
IN	Target	CIM_SoftwareIdentity REF	Reference to CIM_SoftwareIdentity. InstanceID value of this instance maps with firmware to be updated.
OUT	Message	string	Job Completed Error Message in English.
OUT	MessageID	string	Error Message ID may be used to look-up in the Dell Message registry files. For more information, see Error Message Registry.
OUT	Message Arguments[]	string	Substitution variables for dynamic error message.
OUT	Job <sup>1</sup>	CIM_ConcreteJob REF	Reference to concrete job. InstanceID value of this instance contains the generated JobID for the update operation. <sup>1</sup>

262  
263  
264

NOTE: 1 – If return code is 4096 (Job Created), the newly created job does not execute if the LC core services are not running (DCIM\_LCEnumeration with AttributeName equal to “LifecycleControllerState” has the CurrentValue property equal to “Disabled”).

265

**Table 9 – SoftwareInstallationService.InstallFromURI () Method: Standard Messages**

MessageID (OUT parameter)	Message	MessageArguments[]
SUP001	Insufficient Method Parameters	NA
SUP002	Job Creation Failure	NA
SUP003	Either URI or Target or both are missing OR exceeding in length	NA
SUP004	Invalid Namespace	NA
SUP019	Lifecycle Controller is not enabled.	NA
SUP024	Invalid InstanceID	NA
SUP007	Component is not updateable	NA
SUP006	Could not create job file	NA

266

267 **8.2 DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity ()**

268  
269

The successful execution of this method shall create a job to install software that is referenced by the Target parameter.

270  
271

**Table 10 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Return Values**

Value	Description
2	Error
4096 <sup>1</sup>	Job started <sup>1</sup>

272

**Table 11 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Parameters**

Qualifiers	Name	Type	Description/Values
IN	Target	CIM_SoftwareIdentity REF	Reference to CIM_SoftwareIdentity. InstanceID value of this instance maps with firmware to be updated.
OUT	Message	string	Job Completed Error Message in English.
OUT	MessageID	string	Error Message ID may be used to look-up in the Dell Message registry files. For more information, see Error Message Registry.
OUT	Message Arguments[]	string	Substitution variables for dynamic error message.
OUT	Job <sup>1</sup>	CIM_ConcreteJob REF	Reference to concrete job. InstanceID value of this instance contains generated JobID for update operation. <sup>1</sup>

273  
274  
275

NOTE: 1 – If return code is 4096 (Job Created), the newly created job does not execute if the LC core services are not running (DCIM\_LCEnumeration with AttributeName equal to "LifecycleControllerState" has the CurrentValue property equal to "Disabled").

276  
277

**Table 12 – DCIM\_SoftwareInstallationService.InstallFromSoftwareIdentity () Method: Standard Messages**

MessageID (OUT parameter)	Message	MessageArguments[]
SUP001	Insufficient Method Parameters	NA
SUP002	Job Creation Failure	NA
SUP003	Either URI or Target or both are missing OR exceeding in length	NA
SUP004	Invalid Namespace	NA
SUP019	Lifecycle Controller is not enabled.	NA
SUP024	Invalid InstanceID	NA
SUP007	Component is not updateable	NA
SUP006	Could not create job file	NA

278  
279

280 **8.3 DCIM\_SoftwareInstallationService.CreateRebootJob ()**

281 This method is used to generate the reboot job to apply the updates.

282 **Table 13 – DCIM\_SoftwareInstallationService.CreateRebootJob ()Method: Return Values**

Value	Description
2	Error
4096 <sup>1</sup>	Job started <sup>1</sup>

283 **Table 14 – DCIM\_SoftwareInstallationService.CreateRebootJob ()Method: Parameters**

Qualifiers	Name	Type	Description/Values
IN	RebootStartTime	string	Scheduled start time of Reboot
IN	RebootJobType	string	Input parameter to represent the type of reboot RebootJobType shall be one of the following values: <ul style="list-style-type: none"> <li>• “PowerCycle”,</li> <li>• “Graceful Reboot without forced shutdown”,</li> <li>• “Graceful Reboot with forced shutdown”</li> </ul>
OUT	MessageID	string	Error Message ID may be used to look-up in the Dell Message registry files. For more information, see Error Message Registry.
OUT	Message Arguments[]	string	Substitution variables for dynamic error message.
OUT	Job <sup>1</sup>	CIM_ConcreteJob REF	Reference to concrete job. InstanceID value of this instance contains generated JobID for update operation <sup>1</sup>

284 NOTE: 1 – If return code is 4096 (Job Created), the newly created job will not execute if the LC core services are not  
285 running (DCIM\_LCEnumeration with AttributeName equal to “LifecycleControllerState” has the CurrentValue property  
286 equal to “Disabled”).

287 **Table 15 – DCIM\_SoftwareInstallationService.CreateRebootJob () Method:: Standard Messages**

MessageID (OUT parameter)	Message	MessageArguments[]
SUP001	Insufficient Method Parameters	NA
SUP002	Job Creation Failure	NA
SUP004	Invalid Namespace	NA
SUP005	Value Invalid reboot value.	NA
SUP019	Lifecycle Controller is not enabled.	NA

288 **9 Use Cases**

289 See *Lifecycle Controller (LC) Integration Best Practices Guide*.

290 **10 CIM Elements**

291 No other requirements are defined.

292 **11 Privilege and License Requirement**

293 The following table describes the privilege and license requirements for the listed operations. For the  
294 detailed explanation of the privileges and licenses, refer to the Dell WSMAN Licenses and Privileges  
295 specification.

296 **Table 16 – Privilege and License Requirements**

Class and Method	Operation	User Privilege Required	License Required
DCIM_SoftwareInstallationService	ENUMERATE, GET	Login	None.
DCIM_SoftwareInstallationService. InstallFromURI()	INVOKE	Login, Configure	LM_REMOTE_FIRMWARE_UP DATE
DCIM_SoftwareInstallationService. InstallFromSoftwareIdentity()	INVOKE	Login, Configure	LM_REMOTE_FIRMWARE_UP DATE
DCIM_SoftwareInstallationService. CreateRebootJob()	INVOKE	Login, Configure	LM_REMOTE_FIRMWARE_UP DATE
DCIM_LCRegisteredProfile	ENUMERATE, GET	Login	None.
DCIM_LCElementConformsToProfile	ENUMERATE, GET	Login	None.

297

298